

Digitized Automation for a Changing World

Delta Motor-mounted Pump Drive MPD/MP300 Series User Manual



Copyright Notice

©Delta Electronics, Inc. All rights reserved.

All information contained in this user manual is the exclusive property of Delta Electronics Inc. (hereinafter referred to as "Delta") and is protected by copyright law and all other laws. Delta retains the exclusive rights of this user manual in accordance with the copyright law and all other laws. No parts in this manual may be reproduced, transmitted, transcribed, translated or used in any other ways without the prior consent of Delta.

Limitation of Liability

The contents of this user manual are only for the use of the AC motor drives manufactured by Delta. Except as defined in special mandatory laws, Delta provides this user manual "as is" and does not offer any kind of warranty through this user manual for using the product, either express or implied, including but not limited to the following: (i) this product will meet your needs or expectations; (ii) the information contained in the product is current and correct; (iii) the product does not infringe any rights of any other person. You shall bear your own risk to use this product.

In no event shall Delta, its subsidiaries, affiliates, managers, employees, agents, partners and licensors be liable for any direct, incidental, special, derivative or consequential damages (including but not limited to the damages for loss of profits, goodwill, use or other intangible losses) unless the laws contain special mandatory provisions to the contrary.

Delta reserves the right to make changes to the user manual and the products described in the user manual without prior notice and afterwards.

Before Use

Please read prior to installation for safety.



- ☑ Disconnect AC input power before connecting any wiring to the AC motor drive.
- ☑ Even if the power has been turned off, a charge may remain in the DC-link capacitors with hazardous voltages before the POWER LED is OFF. Do not touch the internal circuits and components.
- ☑ There are highly sensitive MOS components on the printed circuit boards. These components are especially sensitive to static electricity. Take anti-static measures before touching these components or the circuit boards.
- ✓ Never modify the internal components or wiring.
- ☑ Ground the AC motor drive by using the ground terminal. The grounding method must comply with the laws of the country where the AC motor drive is to be installed.
- ☑ DO NOT install the AC motor drive in a location with high temperature, direct sunlight or inflammable materials or gases.



- ☑ The rated voltage of power system to install motor drives is 323V–528V. Ensure that the installation voltage is in the correct range when installing a motor drive.
- ☑ Refer to the table below for short circuit rating:

Model (Power)	Short circuit rating
460V	5 kA

- ☑ Only qualified persons are allowed to install, wire and maintain the AC motor drives.
- ☑ The performance of electrolytic capacitor will degrade if it is not charged for a long time. It is recommended to charge the drive which is stored in no charge condition every 2 years for 3~4 hours to restore the performance of electrolytic capacitor in the motor drive. Note: When power up the motor drive, use adjustable AC power source (ex. AC autotransformer) to charge the drive at 70%~80% of rated voltage for 30 minutes (do not run the motor drive). Then charge the drive at 100% of rated voltage for an hour (do not run the motor drive). By doing these, restore the performance of electrolytic capacitor before starting to run the motor drive. Do NOT run the motor drive at 100% rated voltage right away.
- ☑ Pay attention to the following precautions when transporting and installing this package (including wooden crate and wood stave)
 - If you need to deworm the wooden crate, do NOT use fumigation or you will damage the drive. Any damage to the drive caused by using fumigation voids the warranty.
 - 2. Use other methods, such as heat treatment or any other non-fumigation treatment, to deworm the wood packaging material.
 - 3. If you use heat treatment to deworm, leave the packaging materials in an environment of over 56°C for a minimum of thirty minutes.
- ☑ Connect the drive to a three-phase three-wire or three-phase four-wire Wye system to comply with UL standards.
- ☑ If the motor drive generates leakage current over AC 3.5 mA or over DC 10 mA on a grounding conductor, compliance with local grounding regulations or IEC61800-5-1 standard is the minimum requirement for grounding.

Note:

- In the pictures in this manual, the cover or safety shield is disassembled only when explaining the details of the product. During operation, install the top cover and wiring correctly according to the provisions. Refer to the operation descriptions in the manual to ensure safety.
- The figures in this instruction are only for reference and may be slightly different depending on your model, but it will not affect your customer rights.
- The content of this manual may be revised without prior notice. Please consult our distributors or download the latest version at http://www.deltaww.com/iadownload_acmotordrive

Table of Contents

Chapter 1 Introduction	1
1-1 Nameplate Information	2
1-2 Model Name	3
1-3 Serial Number	5
1-4 Instructions for Service Code	6
1-5 RFI Jumper	7
Chapter 2 Dimensions	11
2-1 The Size of the AC Motor Drive	12
2-2 The Size of the MPD	13
2-3 The Size of the Motor Axle	15
2-4 The Weight of the MPD	16
Chapter 3 Installation	17
3-1 Mounting Clearance	18
3-2 Airflow and Power Dispassion	21
Chapter 4 Wiring	23
4-1 System Wiring Diagram	25
4-2 Wiring	26
4-3 The Assembly of Motor and AC Motor Drive	27
4-4 The Wiring of Multi-pump Controlled Communication Cable	30
4-5 The Wiring of Pressure Sensor	30
Chapter 5 Main Circuit Terminals	33
5-1 Main Circuit Diagram	35
5-2 Main Circuit Terminal Specifications	36
Chapter 6 Control Terminals	41
6-1 Control Terminals	42
Chapter 7 Optional Accessories	49
7-1 Magnetic Contactor / Air Circuit Breaker and Non-fuse Circuit Breaker	50
7-2 Fuse Specification Chart	52
7-3 AC Reactor	53
7-4 EMC Shield Plate	59
7-5 Waterproof Connector	61
7-6 USB / RS-485 Communication Interface IFD6530	63
7-7 Perpetual Calendar and Battery	68
7-8 The Adapter Plate for Motor	69
7-9 Fan and Fan Cord	75
Chapter 8 Option Cards	
8-1 Option Card Installation	78
8-2 CMM-PD02 Communication Extension Card, Profibus DP	81
8-3 CMM-DN02 Communication Extension Card, DeviceNet	83

8-4 CMM-EIP02 Communication Extension Card, EtherNet/IP, Modbus TCP	86
8-5 CMMP-BT01 Communication Extension Card, Bluetooth	90
8-6 CMM-PN02 Communication card, PROFINET	92
8-7 Delta Standard Fieldbus Cables	96
Chapter 9 Specifications	97
9-1 460V Models	98
9-2 General Specifications	103
9-3 Environment for Operation, Storage and Transportation	104
9-4 Derating for Ambient Temperature, Altitude and Carrier Frequency	105
9-5 Specifications of Motor	107
Chapter 10 Digital Keypad	109
10-1 Appearance of Keypad	110
10-2 The Backlight of the Keypad Panel	110
10-3 Descriptions of Keypad Functions	111
10-4 Information Displayed on the Panel	112
10-5 Keypad Operation Process	114
10-6 Reference Table for the 16-segment Digital Keypad LED Display	118
Chapter 11 Summary of Parameter Settings	119
00 Drive Parameters	120
01 Basic Parameters	126
02 Digital Input / Output Parameters	128
03 Analog Input / Output Parameters	132
04 Multi-Step Speed Parameters	134
05 Motor Parameters	136
06 Protection Parameters (1)	138
07 Special Parameters	143
08 High-function PID Parameters	145
09 Communication Parameters	146
10 Speed Feedback Control Parameters	150
11 Advanced Parameters	151
12 Function Parameters	152
13 Macro / User-defined Macro	156
14 Protection Parameters (2)	157
Chapter 12 Descriptions of Parameter Settings	159
12-1 Descriptions of Parameter Settings	160
00 Drive Parameters	160
01 Basic Parameters	
02 Digital Input / Output Parameters	189
03 Analog Input / Output Parameters	209
04 Multi-step Speed Parameters	219
05 Motor Parameters	
06 Protection Parameters (1)	231

07 Special Parameters	255
08 High-function PID Parameters	269
09 Communication Parameters	277
10 Speed Feedback Control Parameters	295
11 Advanced Parameters	299
12 Function Parameters	301
13 Macro / User-defined Macro	319
14 Protection Parameters (2)	321
12-2 Adjustment & Application	325
Chapter 13 Warning Codes	343
Chapter 14 Fault Codes	401
Chapter 15 PLC Function Applications	467
15-1 PLC Summary	468
15-2 Notes before Using PLC	469
15-3 Start-up	471
15-4 Basic Principles of PLC Ladder Diagrams	480
15-5 Functions of Various PLC Devices	491
15-6 Introduction to the Functions of Instructions	503
15-7 Fault Display and Treatment	591
15-8 Explanation of Speed Mode Control with PLC	592
15-9 The Applications for Remote IO Control of Modbus (Use MODRW)	594
15-10 RTC (real-time clock)	601
15-11 Enable The Built-in PLC Function of MPD (Scheduled Function, Multi-master Function)	602
15-12 Function Block Diagram (FBD) for DIADesigner	608
Chapter 16 BACnet Instructions	621
16-1 Introduction to BACnet and the Steps	622
Annandiy A. Davisian History	627

Issued Edition: 01

Firmware Version: V1.03 (Refer to Parameter 00-06 on the product to get the firmware version)

Issued Date: 2025/01

Chapter 1 Introduction


- 1-1 Nameplate Information
- 1-2 Model Name
- 1-3 Serial Number
- 1-4 Instructions for Service Code
- 1-5 RFI Jumper

After receiving the AC motor drive, check for the following:


- 1. Inspect the unit after unpacking to ensure that it was not damaged during shipment. Make sure that the part number printed on the package matches the part number indicated on the nameplate.
- 2. Make sure that the mains voltage is within the range indicated on the nameplate. Install the AC motor drive according to the instructions in this manual.
- 3. Before applying power, make sure that all devices, including mains power, motor, control board and digital keypad, are connected correctly.
- 4. When wiring the AC motor drive, make sure that the wiring of input terminals "R/L1, S/L2, T/L3" are correct to prevent damage to the drive.
- 5. When power is applied, use the digital keypad to set parameters. When executing a trial run, begin with a low speed and then gradually increase the speed to the desired speed.

1-1 Nameplate Information


MPD = MP300 (AC motor drive) + MSI (Motor)



MP300 (AC motor drive)




MSI (Motor)




1-2 Model Name


MPD = MP300 (AC motor drive) + MSI (Motor)



MP300 (AC motor drive)




MSI (Motor)




1-3 Serial Number


MPD = MP300 (AC motor drive) + MSI (Motor)



MP300 (AC motor drive)




MSI (Motor)




1-4 Instructions for Service Code

Location of Service Code

Located on the product label, see the red box in the picture below.



How to use Service Code



Scan QR Code to request service

- 1. Find the QR code (as shown above).
- 2. Use a smartphone to run a QR Code reader APP.
- 3. Point your camera at the QR Code. Hold your camera steady until the QR code comes into focus.
- 4. Access the Delta After Service website.
- 5. Fill your information into the column marked with an orange star.
- 6. Enter the CAPTCHA and click "Submit" to complete the application.

Cannot find the QR Code

- 1. Open a web browser on your computer or smartphone.
- 2. Enter https://service.deltaww.com/tw/Repair/Request?type=IA in browser address bar and press the Enter key.
- 3. Fill your information into the column marked with an orange star.
- 4. Enter the CAPTCHA and click "Submit" to complete the application.


1-5 RFI Jumper


RFI Jumper:

- ☑ The drive contains Varistors / MOVs that are connected from phase to phase and from phase to ground to prevent the drive from unexpected stop or damage caused by mains surges or voltage spikes. Because the Varistors / MOVs from phase to ground are connected to ground with the RFI jumper, removing the RFI jumper disables the protection.
- ☑ In models with a built-in EMC filter, the RFI jumper connects the filer capacitors to ground to form a return path for high frequency noise in order to isolate the noise from contaminating the mains power. Removing the RFI jumper strongly reduces the effect of the built-in EMC filter. Although a single drive complies with the international standards for leakage current, an installation with several drives with built-in EMC filters can trigger the RCD. Removing the RFI jumper helps, but the EMC performance of each drive is no longer guaranteed.

Screw Torque: 6–8 kg-cm / [5.2–6.9 lb-in.] / [0.59–0.78 Nm]

As shown in the picture below, the screw works as a RFI jumper, loosen or tighten the screw to disconnect or connect the RFI jumper according to your need.






Isolating main power from ground

When the power distribution system for the drive is a floating ground system (IT Systems) or an asymmetric ground system (Corner Grounded TN Systems), you must remove the RFI jumper. Removing the RFI jumper disconnects the internal capacitors from ground to avoid damaging the internal circuits and to reduce the ground leakage current.

Important points regarding ground connection

- ☑ To ensure the safety of personnel, proper operation, and to reduce electromagnetic radiation, you must properly ground the motor and drive during installation.
- The diameter of the grounding cables must comply with the local safety regulations.
- ☑ You must connect the shielded cable to the motor drive's ground to meet safety regulations.
- ☑ Only use the shielded cable as the ground for equipment when the aforementioned points are met.
- When installing multiple drives, do not connect the grounds of the drives in series but connect each drive to ground. The following pictures show the correct and wrong ways to connect the grounds.



Pay particular attention to the following points:

- ☑ Do not remove the RFI jumper while the power is on.
- ☑ Make sure the main power is OFF before removing the RFI jumper.
- ☑ Removing the RFI jumper also cuts the capacitor conductivity of the surge absorber to ground and the built-in EMC filter capacitors. Compliance with the EMC specifications is no longer guaranteed.
- ☑ Do not remove the RFI jumper if the mains power is a symmetrical grounded power system in order to maintain the efficiency for EMC circuit.
- ☑ Remove the RFI jumper when conducting high voltage tests. When conducting a high voltage test to the entire facility, disconnect the mains power and the motor if the leakage current is too high.

Floating Ground System (IT Systems)

A floating ground system is also called an IT system, an ungrounded system, or a high impedance/resistance (greater than 30 Ω) grounded system.

- ☑ Remove the RFI jumper to disconnect the ground cable from the internal filter capacitor and surge absorber.
- ☑ Do not install an external RFI/EMC filter. The external EMC filter passes through a filter capacitor and connects power input to the ground. This is very dangerous and damages the motor drive.
- ☑ Disconnecting the ground cable from the filter prevents damage to the motor drive but compliance with EMC is no longer guaranteed.
- In situations where EMC is required, check for excess electromagnetic radiation affecting nearby low-voltage circuits. In some situations, the adapter and cable naturally provide enough suppression. If in doubt, install an extra electrostatic shielded cable on the power supply side between the main circuit and the control terminals to increase shielding.


Asymmetric Ground System (Corner Grounded TN Systems)

Caution: Do not remove the RFI jumper while power to the input terminal of the drive is ON.


In the following four situations, you must remove the RFI jumper. This is to prevent the system from grounding through the RFI and filter capacitors and damaging the drive.

You must remove the RFI jumper for an asymmetric ground system


1. Grounding at a corner in a triangle configuration




2. Grounding at a midpoint in a polygonal configuration



3. Grounding at one end in a single-phase configuration




4. No stable neutral grounding in a three-phase autotransformer configuration



You can use the RFI jumper for a symmetrical grounding power system

In a situation with a symmetrical grounding power system, you can use the RFI jumper to maintain the effect of the built-in EMC filter and surge absorber. For example, the diagram on the right is a symmetrical grounding power system.



[This page intentionally left blank]

Chapter 2 Dimensions

- 2-1 The Size of the AC Motor Drive
- 2-2 The Size of the MPD
- 2-3 The Size of the Motor Axle
- 2-4 The Weight of the MPD

2-1 The Size of the AC Motor Drive

Frame A: VFD1A6MP43JNNAA; VFD1A6MP43JFNAA; VFD3A3MP43JNNAA; VFD3A3MP43JFNAA; VFD4A7MP43JNNAA; VFD4A7MP43JFNAA; VFD6A2MP43JNNAA; VFD6A2MP43JNNAA; VFD8A5MP43JNNAA; VFD8A5MP43JFNAA; VFD11AMP43JNNAA

Frame B: VFD11AMP43JFNAA; VFD15AMP43JNNAA; VFD15AMP43JFNAA

Frame C: VFD24AMP43JNNAA; VFD24AMP43JFNAA; VFD31AMP43JNNAA; VFD31AMP43JFNAA; VFD39AMP43JNNAA; VFD39AMP43JFNAA; VFD45AMP43JNNAA; VFD45AMP43JFNAA





Figure 2-1

Frama	Dower (k)A()	Length Width		Height	Waterproof Connector		
Frame	Power (kW)	Н	W	D	А	В	
	0.75						
	1.5			115 (4.53)	M20	M25	
	2.2	000 (44, 40)	237 (9.33)				
Α	3	290 (11.42)					
	4						
	F F						
Б	5.5	000 (40 00)	077 (40 04)				
В	7.5	322 (12.68)	277 (10.91)				
	11						
С	15	386 (15.19)	255 (10.02)	214 (9.42)	M20	M40	
	18.5	300 (13.19)	255 (10.03)	214 (8.42)	IVI∠U	10140	
	22						

Table 2-1

2-2 The Size of the MPD

IM B5, IMV1 (with large flange)



Model name (MPD)	Frame (AC motor drive)	Frame and model name (Motor)	Р	N	Т	Е	L	H1	H2	S	M
MPD75B30C43N2B MPD75B30C43F2B		80-1 MSI75B-30CDXS2B1AP		400		40 (1.58)	323 (12.7)		0.70	,	105
MPD15C30C43N2B MPD15C30C43F2B MPD22C30C43N2B MPD22C30C43F2B	A	80-2 MSI15C-30CDXS2B1AP MSI22C-30CDXS2B1AP	200 (7.88)	130 (5.12)	3.5 (0.14)	50 (1.97)	323 (12.7)	191.1 (7.52)	272.3 (10.72)	12 (0.48)	165 (6.5)
MPD30C30C43N2B MPD30C30C43F2B MPD40C30C43N2B MPD40C30C43F2B1		90 MSI30C-30CDXS2B1AP MSI40C-30CDXS2B1AP	250 (9.85)	180 (7.09)		60 (2.37)	336 (13.2)	201.9 (7.95)	291.5 (11.48)		215 (8.47)
MPD55C30C43N2B	А	100-1 MSI55C-30CDXS2B1AP	300	230	4 (0.16)	80	340 (13.3)	211.3	308.1	14.5 (0.58)	265
MPD55C30C43F2B MPD75C30C43N2B MPD75C30C43F2B1	В	100-2 MSI55C-30CDXS2BFAP MSI75C-30CDXS2B1AP	(11.82) (9.06)	-	(3.15)	371 (14.6)		(12.13)		(10.44)	

Table 2-2

IM B14, IMV18 (with small flange)




Figure 2-3

Model name (MPD)	Frame (AC motor drive)	Frame and model name (Motor)	Р	N	Т	E	L	H1	H2	S	М
MPD75B30C43N2D MPD75B30C43F2D		80-1 MSI75B-30CDXS2D1AP	129 (5.08)	80 (3.15)		40 (1.58)	323 (12.7)	-		M6	100 (3.94)
MPD15C30C43N2D MPD15C30C43F2D MPD22C30C43N2D MPD22C30C43F2D	A	80-2 MSI15C-30CDXS2D1AP MSI22C-30CDXS2D1AP	134 (5.28)	95 (3.75)	3.0 (0.12)	50 (1.97)	323 (12.7)		272.3 (10.72)	M8	115 (4.53)
MPD30C30C43N2D MPD30C30C43F2D1 MPD40C30C43N2D MPD40C30C43F2D		90 MSI30C-30CDXS2D1AP MSI40C-30CDXS2D1AP	148 (5.83)	110 (4.34)	3.5 (0.14)	60 (2.37)	336 (13.2)	201.9 (7.95)	291.5 (11.48)	IVIO	130 (5.12)
MPD55C30C43N2D	А	100-1 MSI55C-30CDXS2D1AP	184	130	4	80	340 (13.3)	211.3	308.1		165
MPD55C30C43F2D MPD75C30C43N2D MPD75C30C43F2D	В	100-2 MSI55C-30CDXS2DFAP MSI75C-30CDXS2D1AP	(7.25)			(3.15)	371 (14.6)	(8.32)	(12.13)	M10	(6.5)

Table 2-3

2-3 The Size of the Motor Axle




Figure 2-4

Model name (MPD)	Frame and model name (Motor)	F	G	С
MPD75B30C43N2B MPD75B30C43N2D MPD75B30C43F2B MPD75B30C43F2D	80-1 MSI75B-30CDXS2B1AP MSI75B-30CDXS2D1AP	6 (0.24)	15.5 (0.62)	19 (0.75)
MPD15C30C43N2B MPD15C30C43N2D MPD15C30C43F2B MPD15C30C43F2D MPD22C30C43N2B MPD22C30C43N2D MPD22C30C43F2B MPD22C30C43F2B	80-2 MSI15C-30CDXS2B1AP MSI22C-30CDXS2B1AP MSI15C-30CDXS2D1AP MSI22C-30CDXS2D1AP	8	20 (0.79)	24 (0.95)
MPD30C30C43N2B MPD30C30C43N2D MPD30C30C43F2B MPD30C30C43F2D1 MPD40C30C43N2B MPD40C30C43N2D MPD40C30C43F2B1 MPD40C30C43F2D	90 MSI30C-30CDXS2B1AP MSI40C-30CDXS2B1AP MSI30C-30CDXS2D1AP MSI40C-30CDXS2D1AP	(0.32)	24 (0.95)	28 (1.11)
MPD55C30C43N2B MPD55C30C43N2D	100-1 MSI55C-30CDXS2B1AP MSI55C-30CDXS2D1AP			
MPD55C30C43F2B MPD55C30C43F2D MPD75C30C43N2B MPD75C30C43N2D MPD75C30C43F2B1 MPD75C30C43F2D	100-2 MSI55C-30CDXS2BFAP MSI75C-30CDXS2B1AP MSI55C-30CDXS2DFAP MSI75C-30CDXS2D1AP	10 (0.4)	33 (1.3)	38 (1.5)

Table 2-4

2-4 The Weight of the MPD

Model name	Model name	Power	Frame	Model name (Motor)	Туре	Weight (kg (lb))		
(MPD)	(AC motor drive)	(kW)	(Motor)	Woder Harrie (Wotor)	(Flange)	AC motor drive	Motor	MPD
MPD75B30C43N2B	VED4A6MD42 ININIAA			MSI75B-30CDXS2B1AP	IM B5, IMV1	2 5 /7 0\	11.3 (25.0)	14.8 (32.7)
MPD75B30C43N2D	VFD1A6MP43JNNAA	0.75	00.4	MSI75B-30CDXS2D1AP	IM B14, IMV18	3.5 (7.8)	9.2 (20.3)	12.7 (28.0)
MPD75B30C43F2B	VFD1A6MP43JFNAA	0.75	80-1	MSI75B-30CDXS2B1AP	IM B5, IMV1	2.7 (0.2)	11.3 (25)	15.0 (33.1)
MPD75B30C43F2D	VPD IAOWF43JFNAA			MSI75B-30CDXS2D1AP	IM B14, IMV18	3.7 (8.2)	9.2 (20.3)	12.9 (28.5)
MPD15C30C43N2B	VFD3A3MP43JNNAA			MSI15C-30CDXS2B1AP	IM B5, IMV1	3.5 (7.8)	13.6 (30.0)	17.1 (37.7)
MPD15C30C43N2D	VFD3A3WF43JININAA	1.5	80-2	MSI15C-30CDXS2D1AP	IM B14, IMV18	3.5 (7.6)	12.2 (26.9)	15.7 (34.7)
MPD15C30C43F2B	\/FD2A2MD42.IFNIAA	1.0	002	MSI15C-30CDXS2B1AP	IM B5, IMV1	2.7 (0.0)	13.6 (30.0)	17.3 (38.2)
MPD15C30C43F2D	VFD3A3MP43JFNAA			MSI15C-30CDXS2D1AP	IM B14, IMV18	3.7 (8.2)	12.2 (26.9)	15.9 (35.1)
MPD22C30C43N2B	VFD4A7MP43JNNAA			MSI22C-30CDXS2B1AP	IM B5, IMV1	3.5 (7.8)	15.3 (33.8)	18.8 (41.5)
MPD22C30C43N2D	VI 247 (11011 4001417) (1	2.2	80-2	MSI22C-30CDXS2D1AP	IM B14, IMV18	0.0 (7.0)	13.9 (30.7)	17.4 (38.4)
MPD22C30C43F2B	VFD4A7MP43JFNAA	2.2	002	MSI22C-30CDXS2B1AP	IM B5, IMV1	3.7 (8.2)	15.3 (33.8)	19.0 (41.9)
MPD22C30C43F2D	VI DANIWII 4001 WAX			MSI22C-30CDXS2D1AP	IM B14, IMV18	0.7 (0.2)	13.9 (30.7)	17.6 (38.8)
MPD30C30C43N2B	VFD6A2MP43JNNAA			MSI30C-30CDXS2B1AP	IM B5, IMV1	3.6 (8.0)	19.1 (42.1)	22.7 (50.1)
MPD30C30C43N2D	VFD0AZIVIF43JININAA	3	90	MSI30C-30CDXS2D1AP	IM B14, IMV18	3.0 (6.0)	16.5 (36.4)	20.1 (44.4)
MPD30C30C43F2B	\/ED642MD42.IENIAA	3	90	MSI30C-30CDXS2B1AP	IM B5, IMV1	3.8 (8.4)	19.1 (42.1)	22.9 (50.5)
MPD30C30C43F2D1	VFD6A2MP43JFNAA			MSI30C-30CDXS2D1AP	IM B14, IMV18	3.8 (8.4)	16.5 (36.4)	20.3 (44.8)
MPD40C30C43N2B	\/ED0.4584D40.INIA.4		00	MSI40C-30CDXS2D1AP	IM B5, IMV1	3.6 (8.0)	19.9 (43.9)	23.5 (51.8)
MPD40C30C43N2D	VFD8A5MP43JNNAA	4		MSI40C-30CDXS2B1AP	IM B14, IMV18		17.3 (38.2)	20.9 (46.1)
MPD40C30C43F2B1	\/ED045MD43.IENIAA	4	90	MSI40C-30CDXS2D1AP	IM B5, IMV1		19.9 (43.9)	23.7 (52.3)
MPD40C30C43F2D	VFD8A5MP43JFNAA			MSI40C-30CDXS2B1AP	IM B14, IMV18	3.8 (8.4)	17.3 (38.2)	21.1 (46.6)
MPD55C30C43N2B	\/FD44.4MD49.ININIA.4		400.4	MSI55C-30CDXS2B1AP	IM B5, IMV1	2.7 (0.0)	27.7 (61.1)	31.4 (69.3)
MPD55C30C43N2D	VFD11AMP43JNNAA	5.5	100-1	MSI55C-30CDXS2D1AP	IM B14, IMV18	3.7 (8.2)	24.2 (53.4)	27.9 (61.5)
MPD55C30C43F2B	\/FD44.6MD42.IFNIA.6	5.5	100.0	MSI55C-30CDXS2BFAP	IM B5, IMV1		27.7 (61.1)	31.8 (70.1)
MPD55C30C43F2D	VFD11AMP43JFNAA		100-2	MSI55C-30CDXS2DFAP	IM B14, IMV18	4.4 (0.4)	24.2 (53.4)	28.3 (62.4)
MPD75C30C43N2B	\/FD45AMD40 ININIAA			MSI75C-30CDXS2B1AP	IM B5, IMV1	4.1 (9.1)	31.3 (69.0)	35.4 (78.1)
MPD75C30C43N2D	VFD15AMP43JNNAA	7.5	100.0	MSI75C-30CDXS2D1AP	IM B14, IMV18		27.8 (61.3)	31.9 (70.4)
MPD75C30C43F2B1	\/FD45 \\\D42 \ FN\\\\\	7.5	100-2	MSI75C-30CDXS2B1AP	IM B5, IMV1	4.2.(0.2)	31.3 (69.0)	35.5 (78.3)
MPD75C30C43F2D	VFD15AMP43JFNAA			MSI75C-30CDXS2D1AP	IM B14, IMV18	4.2 (9.3)	27.8 (61.3)	32.0 (70.6)
	VFD24AMP43JNNAA	11				9 (20.1)		
	VFD24AMP43JFNAA	'''				9.2 (20.6)		
	VFD31AMP43JNNAA	15				9 (20.1)		
	VFD31AMP43JFNAA	13				9.2 (20.6)		
	VFD39AMP43JNNAA	18.5				9 (20.1)		
	VFD39AMP43JFNAA	10.0				9.2 (20.6)		
	VFD45AMP43JNNAA	22				9 (20.1)		
	VFD45AMP43JFNAA					9.2 (20.6)		

Table 2-5

Model name (adapter plate)	Frame	Weight (kg (lb))
MKMP-MAPA1	Α	2.5 (5.6)
MKMP-MAPB1	В	3 (6.7)
MKMP-MAPC1	С	5 (11.2)

Table 2-6


Chapter 3 Installation

- 3-1 Mounting Clearance
- 3-2 Airflow and Power Dispassion

3-1 Mounting Clearance

- ☑ Prevent fiber particles, scraps of paper, shredded wood, sawdust, metal particles, etc. from adhering to the heat sink.
- ☐ Install the AC motor drive in a metal cabinet. When installing one drive below another one, use a metal separator between the AC motor drives to prevent mutual heating and to prevent the risk of fire accident.
- ☐ Install the AC motor drive in a Pollution Degree 2 (IEC/EN 60664-1) environment.
- ☑ Install the AC motor drive in an IP55 and below IP rating interior environment, do not use the AC motor drive in an environment that exceeds the IP rating.

The appearances shown in the following figures are for reference only. The actual motor drives may look different.




MPD series

Frame	Model name	Cle	arance (Unit: n	Maximum ambient temperature (°C)		
	Model name	А	В	С	Without derating	With
	MPD75B30C43N2B				derading	derating 50
	MPD75B30C43N2D					
	MPD75B30C43F2B	120	50		40	
	MPD75B30C43F2D					
	MPD15C30C43N2B					
_	MPD15C30C43N2D			50		
Α	MPD15C30C43F2B			50		
	MPD15C30C43F2D					
	MPD22C30C43N2B					
	MPD22C30C43N2D					
	MPD22C30C43F2B					
	MPD22C30C43F2D					

	Model name	Clearance (Unit: mm)			Maximum ambient temperature (°C)		
Frame	Model name	А	В	С	Without derating	With derating	
	MPD30C30C43N2B	135					
	MPD30C30C43N2D						
	MPD30C30C43F2B						
	MPD30C30C43F2D1		60	60			
A	MPD40C30C43N2B		60	80	40 50		
_ ^	MPD40C30C43N2D						
	MPD40C30C43F2B1						
	MPD40C30C43F2D					50	
	MPD55C30C43N2B						
	MPD55C30C43N2D						
	MPD55C30C43F2B						
	MPD55C30C43F2D	150	70	70			
В	MPD75C30C43N2B	150	70	70			
В	MPD75C30C43N2D						
	MPD75C30C43F2B1						
	MPD75C30C43F2D						

Table 3-1



MP300 series

Frame	Model name	Clearance (Unit: mm)		
		A	В	
	VFD1A6MP43JNNAA	A 50 A A		
	VFD1A6MP43JFNAA			
_	VFD3A3MP43JNNAA		0	
Α	VFD3A3MP43JFNAA		0	
	VFD4A7MP43JNNAA			
	VFD4A7MP43JFNAA			

Chapter 3 Installation | MPD

Frame	Model name	Clearance	(Unit: mm)
. ramo	Woder Hallie	A	В
	VFD6A2MP43JNNAA		
	VFD6A2MP43JFNAA		
	VFD8A5MP43JNNAA	50	
	VFD8A5MP43JFNAA		
	VFD11AMP43JNNAA		0
	VFD11AMP43JFNAA		
В	VFD15AMP43JNNAA		
	VFD15AMP43JFNAA		
	VFD24AMP43JNNAA		
	VFD24AMP43JFNAA		
	VFD31AMP43JNNAA		
С	VFD31AMP43JFNAA		
	VFD39AMP43JNNAA		
	VFD39AMP43JFNAA		
	VFD45AMP43JNNAA		
	VFD45AMP43JFNAA		

Table 3-2

3-2 Airflow and Power Dispassion

MPD series

Frame Model name		Airflo		Power dispassion
Fiaille		(Unit: cfm)	(Unit: m³/hr)	(Unit: W)
	MPD75B30C43N2B		52.8	155
	MPD75B30C43N2D			100
	MPD75B30C43F2B			156
	MPD75B30C43F2D			150
	MPD15C30C43N2B			269
	MPD15C30C43N2D	31.1		203
	MPD15C30C43F2B	31.1		271
	MPD15C30C43F2D			271
	MPD22C30C43N2B			341
	MPD22C30C43N2D			341
Α	MPD22C30C43F2B			343
A	MPD22C30C43F2D			343
	MPD30C30C43N2B		79.2 112.2	416
	MPD30C30C43N2D			410
	MPD30C30C43F2B			419
	MPD30C30C43F2D1	46.7		419
	MPD40C30C43N2B	46.7		512
	MPD40C30C43N2D			
	MPD40C30C43F2B1			515
	MPD40C30C43F2D			515
	MPD55C30C43N2B			633
	MPD55C30C43N2D	66.1		033
	MPD55C30C43F2B			637
	MPD55C30C43F2D			037
В	MPD75C30C43N2B			775
D	MPD75C30C43N2D			110
	MPD75C30C43F2B1			700
	MPD75C30C43F2D			780

Table 3-3

Chapter 3 Installation | MPD

MP300 series

Frame	Models	Airflo		Power dispassion
	VFD1A6MP43JNNAA	(Unit: cfm)	(Unit: m³/hr)	(Unit: W)
	VFD1A6MP43JNNAA		23.3	36
	VFD1A6MP43JFNAA			
	VFD1A6MP43JFNAA			37
	VFD3A3MP43JNNAA			
	VFD3A3MP43JNNAA			82
	VFD3A3MP43JFNAA			
	VFD3A3MP43JFNAA			84
	VFD4A7MP43JNNAA			
	VFD4A7MP43JNNAA			102
	VFD4A7MP43JFNAA			
A	VFD4A7MP43JFNAA	13.8		104
	VFD6A2MP43JNNAA			
	VFD6A2MP43JNNAA			123
	VFD6A2MP43JFNAA			100
	VFD6A2MP43JFNAA			126
	VFD8A5MP43JNNAA			455
	VFD8A5MP43JNNAA			155
	VFD8A5MP43JFNAA			450
	VFD8A5MP43JFNAA			158
	VFD11AMP43JNNAA			400
	VFD11AMP43JNNAA			193
	VFD11AMP43JFNAA		125.1	407
	VFD11AMP43JFNAA	74.0		197
_	VFD15AMP43JNNAA			220
В	VFD15AMP43JNNAA			236
	VFD15AMP43JFNAA			241
	VFD15AMP43JFNAA			241
	VFD24AMP43JNNAA	86.5	147	414
	VFD24AMP43JFNAA			414
	VFD31AMP43JNNAA			539
С	VFD31AMP43JFNAA			558
	VFD39AMP43JNNAA			667
	VFD39AMP43JFNAA			007
	VFD45AMP43JNNAA			774
	VFD45AMP43JFNAA			114

Table 3-4

Chapter 4 Wiring

- 4-1 System Wiring Diagram
- 4-2 Wiring
- 4-3 The Assembly Of Motor And Ac Motor Drive
- 4-4 The Wiring Of Multi-Pump Controlled Communication Cable
- 4-5 The Wiring Of Pressure Sensor

Chapter 4 Wiring | MPD

After removing the front cover, verify that the power and control terminals are clearly noted. Read the following precautions before wiring.




- ☑ Turn off the AC motor drive power before doing any wiring. A charge with hazardous voltages may remain in the DC bus capacitors even after the power has been turned off for a short time. If the AC motor drive does not fully discharge, and assemble the wiring with a residual voltage may cause personal injury, sparks and a short circuit. Ensure your safety to use AC motor drive with no voltage.
- ☑ Only qualified personnel familiar with AC motor drives are allowed to perform installation, wiring and commissioning. Make sure the power is turned off before wiring to prevent electric shock.
- ☑ Make sure that power is only applied to the R/L1, S/L2, and T/L3 terminals. Failure
 to comply may result in damage to the equipment. The voltage and current must
 be in the range indicated on the nameplate (refer to Section 1-1 Nameplate
 Information for details).
- ☑ All units must be grounded directly to a common ground terminal to prevent damage from a lightning strike or electric shock and reduce noise interference.
- ☑ Tighten the screws of the main circuit terminals to prevent sparks caused by screws loosened due to vibration.



- ☑ For your safety, choose wires that comply with local regulations when wiring.
- ☑ Check the following items after finishing the wiring:
 - 1. Are all connections correct?
 - 2. Are there any loose wires?
 - 3. Are there any short circuits between the terminals or to ground?

4-1 System Wiring Diagram



The drive directly plugged into the motor

Figure 7-1

Power input terminal	Supply power according to the rated power specifications indicated in the manual. Refer to Chapter 09 Specifications for details.	
NFB or fuse	There may be a large inrush current during power on. Refer to Section 7-1 NFB to select a suitable NFB or Section 7-2 Fuse Specification Chart.	
Electromagnetic contactor	Switching the power ON / OFF on the primary side of the electromagnetic contactor can make the drive work / stop, but frequent switching can cause machine failure. Do not switch ON / OFF more than once an hour. Do not use the electromagnetic contactor as the power switch for the drive; doing so shortens the life of the drive.	
AC reactor (input terminal)	When the main power supply capacity is greater than 500 kVA, or when it switches into the phase capacitor, the instantaneous peak voltage and current generated may destroy the internal circuit of the drive. It is recommended that you install an input side AC reactor in the drive. This also improves the power factor and reduces power harmonics. The wiring distance should be within 10 m. Refer to Section 7-3 AC Reactor for details.	

Table 4-1

4-2 Wiring

Input: three-phase power




Figure 7-2

4-3 The Assembly of Motor and AC Motor Drive

4-3-1 Motor thermal wire selection (Skip this if thermal wire is not required)

1. Take the appropriate thermal wire out from the motor terminal box, there are KTY-84-130 and PTC-130.




Figure 7-3

4-3-2 The assembly process of AC motor drive and motor

- 1. Use cross screwdriver to loosen the screws on the front cover of the AC motor drive, and then remove the front cover.
- 2. If the motor thermal wire is required, take out the appropriate thermal wire (see section 4-3-1) and pass through the hole from the inside case. Skip this step if the thermal wire is not required.
- 3. Assemble the AC motor drive and the motor according to the direction arrow shown in the Figure 4-4. If the thermal wire is assembled, pay attention that do not let the thermal wire exceed the waterproof ring's boundary on the motor terminal box, otherwise the thermal wire will be flatted and broken.
- 4. Screw up four M5 screws according to the positions shown in the Figure 4-4 Screw Torque: 16~20 kg-cm / [13.9~17.3 lb-in.] / [1.56~1.96 Nm]
- 5. Screw up the waterproof connector before starting the wiring.
- 6. Put the front cover back, and screw up the screws according to the order from a to d (see Figure 4-4). Screw Torque: 6~8 kg-cm / [5.2~6.9 lb-in.] / [0.59~0.78 Nm]







Figure 7-4



Suggested value of striping cable



		Unit: mm	
Framo	R/L1, S/L	2, T/L3, ⊕	
Frame	а	b	
Α	60 [3 26]	0 [0 24]	
В	60 [2.36]	8 [0.31]	






Figure 7-6

4-3-3 The Assembly of Temperature Sensor (KTY-84-130, PTC-130)

- 1. As explained in the section 4-3-1, take out the appropriate temperature sensor from the motor terminal box, and works with the step 1 to 4 in the section 4-3-2.
- 2. Every temperature sensor has two bare wires, no polarity and no order of priority to connect, one connects with ACM, and another one connects with AI1 or AI2.
- 3. Organize and fix the temperature sensor by the snap lock of the case.
- 4. Put the surplus wire segment of the temperature sensor into the hole as the direction arrow shown in the Figure 4-5.




Figure 7-7

4-4 The Wiring of Multi-pump Controlled Communication Cable

To use multi-pump function, you have to connect the first RS-485 port of each station in parallel (SG1- to SG1-; SG1+ to SG1+) in the beginning; if there is a need for connecting with a upper device (HMI), connect it to the second RS-485 port (SG2- / SG2+) of the absolute master (ID1). See the figure below.




Figure 7-8

4-5 The Wiring of Pressure Sensor

Set multi-master function for the auto-change pump system, if require using the pressure feedback sensor signals to control the constant pressure in system, both master station and backup master station must have pressure signals feedback. In the situation, you can set one more pressure sensor for transferring feedback signals to the backup master station, or master station and backup master station use the same one.

Signal type	Source of power	Maximum numbers to connect
ACI	Internal power (+24V)	4
ACI	External power (+30V)	6
AVI	Internal power (+24V)	8
AVI	External power (+30V)	8

Single pump: one pressure sensor to one MP300

ACI

ACI mode with internal power: single pump




Figure 7-9

ACI mode with external power: single pump




Figure 7-10

AVI

AVI mode with internal power: single pump

AVI mode with external power: single pump




Figure 7-11




Figure 7-12

Multi-ump: one pressure sensor to more than one MP300

ACI

ACI mode with internal power: multi-pump (Max.:4)




Figure 7-13

ACI mode with external power: multi-pump (Max.:6)




Figure 7-14

AVI

AVI mode with internal power: multi-pump




Figure 7-15

AVI mode with external power: multi-pump




Figure 7-16

Chapter 5 Main Circuit Terminals

- 5-1 Main Circuit Diagram
- 5-2 Main Circuit Terminal Specifications



- ☑ Tighten the screws in the main circuit terminal to prevent sparks caused by screws loosened due to vibration.
- ☑ Ensure proper insulation of the main circuit wiring in accordance with the relevant safety regulations.



Main input power terminals

- ☑ DO NOT connect a three-phase model to one-phase power. R/L1, S/L2 and T/L3 have no phase-sequence requirement; they can be connected in any sequence.
- ☑ You must install a NFB between the three-phase power input terminals and the main circuit terminals (R/L1, S/L2, T/L3). Add a magnetic contactor (MC) to the power input wiring to cut off power quickly and reduce malfunctions when the AC motor drive protection function activates. Both ends of the MC should have an R-C surge absorber.
- ☑ Use voltage and current within the specifications in Chapter 7. Refer to Chapter 09 Specifications for details.
- ☑ If install an earth leakage circuit breaker (ELCB) to the AC motor drive as a protection to the electrical leakage, choose industrial type or time-delay type to avoid malfunction.
- ☑ Use shielded wire or conduit for the power wiring and ground the two ends of the shielding or conduit.
- ☑ DO NOT run and stop the AC motor drives by turning the power ON and OFF. Run and stop the AC motor drives by sending the RUN and STOP commands through the control terminals or the keypad. If you still need to run and stop the AC motor drives by turning the power ON and OFF, do so no more often than ONCE per hour.
- ☑ To comply with UL standards, connect the drive to a three-phase three-wire (star connection, Y connection) or three-phase four-wire (star connection, Wye connection) system type of mains power system.

Remove the front cover

- Remove the front cover before wiring the main circuit terminals and control circuit terminals. Remove the cover according to the figures below.
- The example uses the Frame A model. For different frame size models, use the same removing method.




Figure 5-1

Use cross screwdriver to loosen the screws on the front cover of the AC motor drive, and then remove the front cover.

5-1 Main Circuit Diagram



Figure 5-2

Terminals	Descriptions
R/L1, S/L2, T/L3	Mains input terminals (three-phase)
	Ground connection; comply with local regulations.

5-2 Main Circuit Terminal Specifications

- Use the specified ring lug for main circuit terminal wiring. See Figure 5-3 and Figure 5-4 for ring lug specifications. For other types of wiring, use the wires that comply with the local regulations.
- After crimping the wire to the ring lug (must be UL and CSA approved R/C (YDPU2)), install heat shrink tubing rated at a minimum of 600 V_{AC} insulation over the live part. Refer to Figure 5-4.
- Main circuit terminal: R/L1, S/L2, T/L3




Figure 5-3

Figure 5-4

Dimensions of Ring Lug


The part # of the ring lugs (produced by K.S. Terminals Inc.) in the table below are for reference only. You can buy other ring lugs of your choice to match with different frame sizes.

Unit: mm

Frame	AWG*1	Model Name	A (MAX)	B (MAX)	C (MIN)	D (MAX)	d2 (MIN)	E (MIN)	F (MIN)	W (MAX)	t (MAX)
			(IVIAA)	(IVIAA)	(IVIIIV)	(IVIAA)	(IVIIIV)	(IVIIIV)	(IVIIIV)	(IVIAA)	(IVIAA)
	22	RNBS 1-4									
	18	RNBS 1-4									
Α	16	RNBS 1-4									
	14	RNBS 2-4	12.1	3.6	6.1	5.6	4.3	13.00	4.5	7.2	1.0
	12	RNBS 5-4									
В	12	RNBS 5-4									
Ь	10	RNBS 5-4									
	8	RNBL 8-6									
С	6	RNBL 14-6	28.0	9.0	13.5	14.0	6.4	13.0	12.0	16.5	1.7
	4	RNBL 22-6									

^{*1:} Refer to the following tables for the wire size specification for models in each frame.


Frame A



- If the installation is in an environment where the ambient temperature is above 40°C, use copper wire with a rated voltage of 600V and a temperature resistance of 90°C or above for wiring.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using high-temperature resistant wires.

Model		Main Circuit Terminals R/L1, S/L2, T/L3		Terminal ⊕		
Model	Maximum Wire Gauge	Minimum Wire Gauge	Torque (±10%)	Maximum Wire Gauge	Minimum Wire Gauge	Torque (±10%)
VFD1A6MP43JNNAA, VFD1A6MP43JFNAA		0.5 mm ² (22 AWG)		2.5 mm ² (14 AWG)	2.5 mm ² (14 AWG)	
VFD3A3MP43JNNAA VFD3A3MP43JFNAA		0.75 mm ² (18 AWG)		2.5 mm ² (14 AWG)	2.5 mm ² (14 AWG)	
VFD4A7MP43JNNAA, VFD4A7MP43JFNAA	4 mm²	1.5 mm ² (16 AWG)	#6-32 UNC 8 Kg-cm	2.5 mm ² (14 AWG)	2.5 mm ² (14 AWG)	M4 8 Kg-cm
VFD6A2MP43JNNAA, VFD6A2MP43JFNAA	(12 AWG)	2.5 mm ² (14 AWG)	(7.0 lb-in.) (0.78 Nm)	2.5 mm ² (14 AWG)	2.5 mm ² (14 AWG)	(7.0 lb-in.) (0.78 Nm)
VFD8A5MP43JNNAA, VFD8A5MP43JFNAA		2.5 mm ² (14 AWG)		2.5 mm ² (14 AWG)	2.5 mm ² (14 AWG)	
VFD11AMP43JNNAA		4 mm ² (12 AWG)		4 mm ² (12 AWG)	4 mm ² (12 AWG)	


Frame B



- If the installation is in an environment where the ambient temperature is above 40°C, use copper wire with a rated voltage of 600V and a temperature resistance of 90°C or above for wiring.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using high-temperature resistant wires.

Model	Main Circuit Terminals R/L1, S/L2, T/L3			Terminal		
iviodei	Maximum	Minimum	Torque	Maximum	Minimum	Torque
	Wire Gauge	Wire Gauge	(±10%)	Wire Gauge	Wire Gauge	(±10%)
VFD11AMP43JFNAA	6 mm ²	4 mm ² (12 AWG)	#6-32 UNC 8 Kg-cm	4 mm ² (12 AWG)	4 mm ² (12 AWG)	M4 8 Kg-cm
VFD15AMP43JNNAA	(10 AWG)	6 mm ²	(7.0 lb-in.)	6 mm ²	6 mm ²	(7.0 lb-in.)
VFD15AMP43JFNAA		(10 AWG)	(0.78 Nm)	(10 AWG)	(10 AWG)	(0.78 Nm)

Frame C



- If the installation is in an environment where the ambient temperature is above 40°C, use copper wire with a rated voltage of 600V and a temperature resistance of 90°C or above for wiring.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using high-temperature resistant wires.

Madal	Main Circuit Terminals R/L1, S/L2, T/L3			Terminal ⊕		
Model	Maximum Wire Gauge	Minimum Wire Gauge	Torque (±10%)	Maximum Wire Gauge	Minimum Wire Gauge	Torque (±10%)
VFD24AMP43JNNAA		10 mm ² (8 AWG)		10 mm ² (8 AWG)	10 mm ² (8 AWG)	
VFD24AMP43JFNAA		10 mm ² (8 AWG)		10 mm ² (8 AWG)	10 mm ² (8 AWG)	
VFD31AMP43JNNAA	25 mm²	10 mm ² (8 AWG)		10 mm ² (8 AWG)	10 mm ² (8 AWG)	
VFD31AMP43JFNAA		10 mm ² (8 AWG)	M6 51 Kg-cm	10 mm ² (8 AWG)	10 mm ² (8 AWG)	M6 51 Kg-cm
VFD39AMP43JNNAA	(4 AWG)	16 mm ² (6 AWG)	(44.2 lb-in.) (5.0 N-m)	16 mm ² (6 AWG)	16 mm ² (6 AWG)	(44.2 lb-in.) (5.0 N-m)
VFD39AMP43JFNAA		16 mm ² (6 AWG)		16 mm ² (6 AWG)	16 mm ² (6 AWG)	
VFD45AMP43JNNAA		25 mm ² (4 AWG)		25 mm ² (4 AWG)	16 mm ² (6 AWG)	
VFD45AMP43JFNAA		25 mm ² (4 AWG)		25 mm ² (4 AWG)	16 mm ² (6 AWG)	

[This page intentionally left blank]

Chapter 6 Control Terminals


6-1 Control Terminals

6-1 Control Terminals




Analog input terminals (AI1-2, ACM)

- Analog input signals are easily affected by external noise. Use shielded wiring and keep it as short as possible (less than 20 m) with proper grounding. If the noise is inductive, connecting the shield to the ACM terminal can reduce interference.
- ☑ Use twisted-pair wire for weak analog signals.
- ☑ If the analog input signals are affected by noise from the AC motor drive, connect a capacitor and a ferrite core as shown the figure below.




Contact input terminals (MI1-MI4, DCM, +24 V)




- ☑ When using internal power, the terminal switches to NPN is collinear with 24V, and switches to PNP is collinear with DCM.
- ☑ It's Sink mode when the external transistor is NPN, and it's Source mode when the external transistor is PNP.

Transistor (digital) output terminals (MO, MCM)

- ☑ Connect the digital outputs to the correct polarity.
- When connecting a relay to the digital outputs, connect a surge absorber across the coil and check the polarity.





Control Terminal Distribution Diagram


Control Terminal Location Diagram

Wiring precautions:

- The RELAY terminal uses the PCB terminal block (as shown in Area 1 in the control terminal distribution diagram):
 - Tighten the wiring with a 2.5 mm width and 0.4 mm thickness slotted screwdriver.
 - The ideal length of stripped wire at the connection side is 9–10 mm.
 - When wiring bare wires, ensure that they are perfectly arranged to go through the wiring holes.
- The control terminal uses the push-in spring terminal block (as shown in Area 2 in the control terminal distribution diagram):
 - When removing wires, use the slotted screwdriver to press down the terminal, and the suggested force is 1.5 kgf.
 - Slotted screwdriver: 2.5 mm width and 0.4 mm thickness
 - The ideal length of stripped wire at the connection side is 9 mm.
 - When wiring bare wires, ensure that they are perfectly arranged to go through the wiring holes.
- The RS-485 terminal uses the PCB terminal block (as shown in Area 3 in the control terminal distribution diagram):
 - Tighten the wiring with a 2.5 mm width and 0.4 mm thickness slotted screwdriver.
 - The ideal length of stripped wire at the connection side is 9 mm.
 - When wiring bare wires, ensure that they are perfectly arranged to go through the wiring holes.

Wiring Specifications of Terminals

Name	Wiring Specifications of Control Terminals	Stripping Length (mm)		Minimum Wire Gauge	Torque (±10%)
RELAY Terminals	Solid Strand		1.5mm²	0.2mm ²	5 Kg-cm
RS-485 terminal	Solid Strand		16AWG	24AWG	[4.3 lb-in.] [0.49 Nm]
Control	Solid Strand	9	0.75mm ² 18AWG	0.25mm ²	
terminal	Stranded with ferrules with plastic sleeve		0.5mm ² 20AWG	24AWG	



Unit: mm

Suggested mo	Suggested models and dimensions for crimping terminals						
Wire Gauge	Manufacturer	Model Name	A (MAX)	B (MAX)	D (MAX)	W (MAX)	
0.25mm ² 24AWG	PHOENIX CONTACT	AI 0,25- 8 YE	12.5	8	2.6	1.1	
0.34mm ² 22AWG	PHOENIX CONTACT	AI 0,34- 8 TQ	12.5	8	3.3	1.3	
0.5mm ² 20AWG	PHOENIX CONTACT	AI 0,5 - 8 WH	14	8	3.5	1.4	

Suggested specifications and models for crimping tool: CRIMPFOX 10S - 1212045, Manufacturer: PHOENIX CONTACT DNT13-0101, Manufacturer: DINKLE

Terminal Name	Terminal function	Descriptions
+24V	Digital control signal common (Source)	+24 VDC ± 10 % 100 mA
MI 1 - MI4	Multi-function Input Selection 1–4	Refer to Pr.02-01–02-04 to program the multi-function inputs Source Mode ON: activation current 3.3 mA, and breakover voltage 11 V _{DC} OFF: cut-off voltage ≤ 5 V _{DC} Sink Mode ON: activation current 3.3 mA, and breakover voltage 13 V _{DC} OFF: cut-off voltage ≥ 19 V _{DC} ● Pr.02-00 = 0 You can set multi-function options with multi-function input terminals MI1, MI2. ● Pr.02-00 ≠ 0 The multi-function input terminals MI1, MI2 work in accordance with the setting values for Pr.02-00.

Terminal Name	Terminal function	Descriptions
МО	Multi-function Output 1 (photo coupler)	The AC motor drive outputs various monitoring signals, such as drive in operation, frequency reached, and overload indication
МСМ	Multi-function Output Common (photo coupler)	through a transistor. Max. 48 V _{DC} 50 mA
RA1 RA2	Multi-function output (Relay N.O. a)	Resistive Load 3 A (N.O.) / 3 A (N.C.) 250 V _{AC}
RB1 RB2	Multi-function output (Relay N.C. b)	5 A (N.O.) / 3 A (N.C.) 30 V _{DC} Inductive Load (COS 0.4) 1.2 A (N.O.) / 1.2 A (N.C.) 250 V _{AC}
RC1 RC2	Multi-function output common (Relay)	2.0 A (N.O.) / 1.2 A (N.C.) 30 V _{DC} To output different kinds of monitoring signals such as motor drive in operation, frequency reached, and overload indication.
+10V	Potentiometer power supply	Power supply for analog frequency setting: $\pm 10.5 \pm 0.5 \text{ V}_{DC}$ / 20 mA
Al1 Al2	Analog input	The default of Al1 terminal is 0–20 mA current mode. Change to voltage mode by switching J3 of Al1 to 0–10V side, and set Pr.03-28. The default of Al2 terminal is 0–20 mA current mode. Change to voltage mode by switching J3B of Al2 to 0–10V side, and set Pr.03-29. RA1 RB1 RC1 RB2 RC2 PNP RB2 RC2 PNP RB1 RG1 RB2 RC2 PNP RB2 RC2 PNP RB2 RC2 PNP RB486-1

Chapter 6 Control Terminals | MPD

Terminal Name	Terminal function	Descriptions
		Voltage mode (AVI) Analog voltage frequency command Impedance: 20 kΩ Range: 0 - +10 V = corresponding to maximum operation frequency (Pr.01- 00) Mode switching by setting Pr.03- 00, 03-01, 03-28, 03-29 AVI resolution=12 bits
		Current mode (ACI) ACI analog current frequency command Impedance: 250 kΩ Range: 0–20 mA / 4–20 mA = corresponding to maximum operation frequency (Pr.01-00) Mode switching by setting Pr.03-00, 03-01, 03-28, 03-29 ACI resolution = 12 bits
AFM	Multi-function analog voltage output	Range: 0–10 V corresponds to the maximum operating range of the control target Maximum output current: 2 mA, Maximum load: 5 kΩ
ACM	Analog Signal Common	Analog signal common terminal
PE	Ground function	For the use of grounding the shielding of the communication cable. Since the inner of PE terminal does not connect to system grounding, the system grounding cable and the shielded cable have to connect to PE terminal together.

Terminal Name	Terminal function	Descriptions
SG1- SG1+ SGND	RS-485 communication port (The port to communicate with multi-pump control)	SG1+, SG1-: This is for multi-pump control. The loop includes terminal resistor, and switch it by using J5. When it switches to 120 ohm, in the middle of SG1+ and SG1- is in equivalent parallel with 120 ohm resistance. When the cable of multi-pump control is too long, Its reflection wave causes signals to distort. At this moment, J5 of the first and the last drives switch to 120 ohm can decrease the influence. Remember that J5 should be at open side for the drives except the first one and the last one. SG2+, SG2-: to communicate with upper device. SGND: Signal ground of SG1+, SG1-, SG2+, SG2-
SG2- SG2+ SGND	RS-485 communication port (The port to communicate with upper device)	RA1 RB1 RC1 RB2 RC2 +10V ACM AII MI3 AII MI4 AFM +24V MO +24V MCM SGND SG1- SG1+ SG2- SG2+ PE Note: Refer to Chapter 12 DESCRIPTIONS OF PARAMETER SETTINGS parameter group 09 Communication Parameters for details.

details.

* Analog control signal wiring specification: 0.82 mm² [18 AWG] with shielded stranded wire.

[This page intentionally left blank]

Chapter 7 Optional Accessories

- 7-1 Magnetic Contactor / Air Circuit Breaker and Non-fuse Circuit Breaker
- 7-2 Fuse Specification Chart
- 7-3 AC Reactor
- 7-4 EMC Shield Plate
- 7-5 Waterproof Connector
- 7-6 USB / RS-485 Communication Interface IFD6530
- 7-7 Perpetual Calendar and Battery
- 7-8 The Adapter Plate for Motor
- 7-9 Fan and Fan Cord

The optional accessories listed in this chapter are available upon request. Installing additional accessories to your drive substantially improves the drive's performance. Select accessories according to your need or contact your local distributor for suggestions.

7-1 Magnetic Contactor / Air Circuit Breaker and Non-fuse Circuit Breaker

Magnetic Contactor (MC) and Air Circuit Breaker (ACB)

It is recommended the ambient temperature for MC should be $\geq 60^{\circ}$ C and that for ACB should be $\geq 50^{\circ}$ C. In the meanwhile, consider temperature derating for components with ON / OFF switch in accordance with the ambient temperature of the on-site distribution panel.

Frame	Models	Voltage / Three-phase	Output Current (A)	Input Current (A)	Selection of MC / ACB (A)
	VFD1A6MP43JNNAA VFD1A6MP43JFNAA		1.6	1.9	7
	VFD3A3MP43JNNAA VFD3A3MP43JFNAA		3.3	3.8	7
А	VFD4A7MP43JNNAA VFD4A7MP43JFNAA		4.7	5.4	9
	VFD6A2MP43JNNAA VFD6A2MP43JFNAA		6.2	7.2	12
	VFD8A5MP43JNNAA VFD8A5MP43JFNAA		8.5	9.9	18
	VFD11AMP43JNNAA VFD11AMP43JFNAA	460V	11.7	13.8	32
В	VFD15AMP43JNNAA VFD15AMP43JFNAA	three-phase	15.6	18.5	40
	VFD24AMP43JNNAA VFD24AMP43JFNAA		24.4	29.5	65
	VFD31AMP43JNNAA VFD31AMP43JFNAA		31.8	38.9	85
С	VFD39AMP43JNNAA VFD39AMP43JFNAA		39.2	48.5	110
	VFD45AMP43JNNAA VFD45AMP43JFNAA		45.6	56.5	120

Table 7-1

Non-fuse Circuit Breaker

- ☑ Comply with the UL standard: Per UL 61800, paragraph 6.3.7DV.2.2.1
- ☑ The rated current of the non-fuse circuit breaker should be 1.6–2.6 times the drive's rated input current. The recommended current values are shown in the table below.
- ☑ Compare the time characteristics of the non-fuse circuit breaker with those of the drive's overheated protection to ensure that there is no tripping.

Frame	Model	Voltage / Three-phase	Input / output current (the maximum)	Suggested current (A)
	VFD1A6MP43JNNAA VFD1A6MP43JFNAA	460V three- phase	1.9 / 1.6	5
_	VFD3A3MP43JNNAA VFD3A3MP43JFNAA		3.8 / 3.3	10
A	VFD4A7MP43JNNAA VFD4A7MP43JFNAA		5.4 / 4.7	15
	VFD6A2MP43JNNAA VFD6A2MP43JFNAA		7.2 / 6.2	20

Chapter 7 Optional Accessories | MPD

Frame	Model	Voltage / Three-phase	Input / output current (the maximum)	Suggested current (A)
	VFD8A5MP43JNNAA VFD8A5MP43JFNAA		9.9 / 8.5	25
	VFD11AMP43JNNAA		13.8 / 11.7	32
	VFD11AMP43JFNAA			
В	VFD15AMP43JNNAA VFD15AMP43JFNAA		18.5 / 15.6	40
	VFD24AMP43JNNAA VFD24AMP43JFNAA		29.5 / 24.4	65
С	VFD31AMP43JNNAA VFD31AMP43JFNAA		38.9 / 31.8	85
	VFD39AMP43JNNAA VFD39AMP43JFNAA		48.5 / 39.2	110
	VFD45AMP43JNNAA VFD45AMP43JFNAA		56.5 / 45.6	120

Table 7-2

7-2 Fuse Specification Chart

- It's recommended to use the fuses listed below which are tested. Do not use the fuses exceed the fuse specifications. The AC input fuse specifications are lower than the table listed below are allowed. If use the fuse lower than the specifications, ensure its root mean square value of current (Irms) is larger than the actual input current. If use the AC motor drive with 150% output overload capacity, the corresponding input current should be 1.5 times the value in the table.
- UL certified fuses apply to the short-circuit protection at the input side. For the installation in the United States, the branch circuit protection must be provided in accordance with the National Electrical Code (NEC) and any applicable local codes. Use UL certified fuses to fulfill this requirement.
- ☑ For the installation in Canada, branch circuit protection must be provided in accordance with Canadian Electrical Code and any applicable provincial codes. Use UL certified fuses to fulfill this requirement.

Model	Voltage / Three-phase	Input / output current (the maximum)	Branch circuit fuses output [A]
VFD1A6MP43JNNAA		4.0./4.0	6.4
VFD1A6MP43JFNAA		1.9 / 1.6	Class T JJS-10 600 V _{AC}
VFD3A3MP43JNNAA		3.8 / 3.3	13.2
VFD3A3MP43JFNAA		3.0 / 3.3	Class T JJS-15 600 V _{AC}
VFD4A7MP43JNNAA		5.4 / 4.7	18.8
VFD4A7MP43JFNAA		5.4 / 4.7	Class T JJS-20 600 V _{AC}
VFD6A2MP43JNNAA		7.2 / 6.2	24.8
VFD6A2MP43JFNAA		7.270.2	Class T JJS-25 600 V _{AC}
VFD8A5MP43JNNAA		9.9 / 8.5	34
VFD8A5MP43JFNAA		9.97 0.5	Class T JJS-35 600 V _{AC}
VFD11AMP43JNNAA	460V	13.8 / 11.7	46.8
VFD11AMP43JFNAA	three-phase	13.07 11.7	Class T JJS-45 600 V _{AC}
VFD15AMP43JNNAA	tillee-pliase	18.5 / 15.6	46.8
VFD15AMP43JFNAA		16.57 15.0	Class T JJS-45 600 V _{AC}
VFD24AMP43JNNAA		00.5 / 04.4	68.3
VFD24AMP43JFNAA		29.5 / 24.4	Class T JJS-60 600 V _{AC}
VFD31AMP43JNNAA		20.0 / 24.0	89.0
VFD31AMP43JFNAA		38.9 / 31.8	Class T JJS-90 600 V _{AC}
VFD39AMP43JNNAA		40 E / 20 2	109.8
VFD39AMP43JFNAA		48.5 / 39.2	Class T JJS-110 600 V _{AC}
VFD45AMP43JNNAA		56.5 / 45.6	127.7
VFD45AMP43JFNAA		50.5 / 4 5.0	Class T JJS-125 600 V _{AC}

Table 7-3

7-3 AC Reactor

AC Input Reactor

Install an AC reactor at the input side of an AC motor drive can increase line impedance, improve the power factor, reduce input current, increase system capacity, and reduce interference generated from the motor drive. It also reduces momentary voltage surges or abnormal current spikes from the mains power, further protecting the drive. For example, when the mains power capacity is higher than 500 kVA, or when using a phase-compensation capacitor, momentary voltage and current spikes may damage the AC motor drive's internal circuit. An AC reactor at the input side of the AC motor drive protects it by suppressing surges.

Installation

Install an AC input reactor in series between the mains power and the three input phases R S T, as shown in the figure below:




Figure 7-1 AC input reactor installation diagram

The size and the specification of the AC input reactor:




Figure 7-2

Unit: mm

Delta's part no.	Α	В	С	D1*D2	Е	G1	G2	PE D
DR005A0254	100	115	65	6*9	45	60	40	M4
DR008A0159	100	115	65	6*9	45	60	40	M4
DR011A0115	130	135	95	6*12	60	80.5	60	M4
DR017AP746	130	135	100	6*12	65	80.5	60	M4

Table 7-1




Figure 7-3

Unit: mm

Delta's part no.	А	В	С	D1*D2	Н	G1	G2	PE D
DR025AP507	130	195	100	6*12	65	80.5	60	M4

Table 7-2




Figure 7-4

Unit: mm

Delta's part no.	А	В	C	D1*D2	Η	G1	G2	PE D
DR003A0810	100	125	65	6*9	43	60	40	M4
DR004A0607	100	125	65	6*9	43	60	40	M4
DR006A0405	130	15	95	6*12	60	80.5	60	M4
DR009A0270	160	160	105	6*12	75	107	75	M4
DR010A0231	160	160	115	6*12	90	107	75	M4
DR012A0202	160	160	115	6*12	90	107	75	M4
DR018A0117	160	160	115	6*12	90	107	75	M4

Table 7-3




Figure 7-5

Unit: mm

Delta's part no.	Α	В	C	D1*D2	Н	G1	G2	PE D
DR024AP881	160	175	115	6*12	90	107	75	M4
DR032AP660	195	200	145	6*12	115	122	85	M6
DR038AP639	190	200	145	6*12	115	122	85	M6
DR045AP541	190	200	145	6*12	115	122	85	M6

Table 7-4

The specification of the AC input reactor

460V, 50-60 Hz / three-phase

	Data I O maret	0-1	Recommended selection			
Model	Rated Current (Arms)	Saturation Current (Arms)	AC input reactor (mH)	Delta's part no.	Weight (kg)	
VFD1A6MP43JNNAA VFD1A6MP43JFNAA	1.6	2.4	8.102	DR003A0810	1.5	
VFD3A3MP43JNNAA VFD3A3MP43JFNAA	3.3	4.95	6.077	DR004A0607	1.8	
VFD4A7MP43JNNAA VFD4A7MP43JFNAA	4.7	7.05	4.05	DR006A0405	2.8	
VFD6A2MP43JNNAA VFD6A2MP43JFNAA	6.2	9.3	2.7	DR009A0270	3.5	
VFD8A5MP43JNNAA VFD8A5MP43JFNAA	8.5	12.75	2.7	DR009A0270	3.5	
VFD11AMP43JNNAA VFD11AMP43JFNAA	11.7	17.55	2.315	DR010A0231	4.5	
VFD15AMP43JNNAA VFD15AMP43JFNAA	15.6	23.4	1.174	DR018A0117	5.3	
VFD24AMP43JNNAA VFD24AMP43JFNAA	24.4	36.6	0.881	DR024AP881	5.8	
VFD31AMP43JNNAA VFD31AMP43JFNAA	31.8	47.7	0.66	DR032AP660	9	
VFD39AMP43JNNAA VFD39AMP43JFNAA	39.2	58.8	0.639	DR038AP639	9.5	
VFD45AMP43JNNAA VFD45AMP43JFNAA	45.6	68.4	0.541	DR045AP541	10.5	

Table 7-5

The table below shows the THDi specification when using Delta's drives to work with AC/DC reactors.

Drive Spec.		Models without Built-in DC Reactors							
Reactor Spec.	No AC/DC Reactor	3% Input AC Reactor	5% Input AC Reactor	4% DC Reactor					
5th	73.3%	38.5%	30.8%	34.4%					
7th	52.74%	15.3%	9.4%	18.6%					
11th	7.28%	7.1%	6.13%	7.14%					
13th	0.4%	3.75%	3.15%	3.41%					
THDi	91%	43.6%	34.33%	38.2%					
NOTE	The THDi specification listed here assumes that there is 0.8% resistance (mains electricity) before the reactors and may be slightly different from the actual THDi, depending on the installation and environmental conditions (wires, motors).								

Table 7-6

7-4 EMC Shield Plate

EMC Shield Plate (for use with shielded cable)

Frame	Model of EMC shield plate	Reference figure
A, B	МКМР-ЕРВ	
		Figure 7-6
С	MKMP-EPC	
		Figure 7-7

Table 7-7

The appearance and the size




Table 7-8

Installation

MKMP-EPB (This example uses frame A model)

1. As shown in the right figure, fix the shield plate on the AC motor drive.

Screw	Torque	
M4	6–8 kg-cm [5.2–6.9 lb-in.] [0.59–0.78 Nm]	

2. Select a suitable metal omega clip according to the wire gauge used, and then fix the metal omega clip on the shield plate.

Screw	Torque
	6-8 kg-cm
M4	[5.2–6.9 lb-in.]
	[0.59-0.78 Nm]




Figure 7-9

Figure 7-10

MKMP-EPC

1. As shown in the right figure, fix the shield plate on the AC motor drive.

Screw	Torque
	6~8 kg-cm
M4	[5.2~6.9 lb-in.]
	[0.59~0.78 Nm]




Figure 7-11

2. Select a suitable metal omega clip according to the wire gauge used, and then fix the metal omega clip on the shield plate.

Screw	Torque
M4	6~8 kg-cm
	[5.2~6.9 lb-in.]
	[0.59~0.78 Nm]




Figure 7-12

7-5 Waterproof Connector

Waterproof connector (for wiring)

Frame	Models	Reference figure
A, B	MKMP-CG20 MKMP-CG25	
С	MKMP-CG20 MKMP-CG40	Figure 7-13

Table 7-9

The appearance and the size




Table 7-10

Suggested torque value to install

Suggested torque value to install				
			1	2
	Models	The suitable	The suggested	The suggested
		wire gauge mm [inch]	torque value kg-cm [lb-in.] [Nm]	torque value kg-cm [lb-in.] [Nm]
	MKMP-CG20	5.5 [0.22] - 9 [0.35]	20–30kg-cm [17.3–26.0 lb-in.] [1.97–2.95 Nm]	20–25kg-cm [17.3–21.7 lb-in.] [1.97–2.46 Nm]
		9 [0.35]	25–30kg-cm	
		- 14.4 [0.57]	[21.7–26.0 lb-in.] [2.46–2.95 Nm]	
	MKMP-CG25	10.5 [0.41]	30–35kg-cm	
		– 14.1 [0.56]	[26.0–30.3 lb-in.] [2.95–3.44 Nm]	28–35kg-cm
		14.1 [0.56]	25–45kg-cm	[24.3–30.3 lb-in.] [2.75–3.44 Nm]
		_	[21.7–39.0 lb-in.]	[2.75–3.44 NIII]
Figure 7-15		18.8 [0.74]	[2.46–4.42Nm]	
-		17.8 [0.7]	54~70kg-cm	
		~	[46.9~60.8lb-in.]	75~80kg-cm [65.1~69.4lb-in.]
MKMP-C	MKMP-CG40	23.7 [0.93]	[5.30~6.86Nm]	
		23.7 [0.93]	58~88kg-cm	[7.35~7.85Nm]
		~	[50.4~76.4lb-in.]	[7.00%7.00[4]]
		32.3 [1.27]	[5.69~8.63Nm]	

Table 7-11

Installation (This example uses Frame A model)

1. As the figure shown below, remove the waterproof connector nuts and the vent plugs.




Figure 7-16

2. Choose the waterproof connector which is suitable to the heat sink screw thread according to the outgoing cable position. And screw the waterproof connector to the AC motor drive according to the suggested torque value.

Note: Refer to Chapter 2 Dimensions for more details about the specification of the heat sink screw thread.




Figure 7-17

7-6 USB / RS-485 Communication Interface IFD6530

- ☑ Please thoroughly read this instruction sheet before installing and putting it into use.
- ☐ The content of this instruction sheet and the driver file may be revised without prior notice. Please consult our distributors or download the most updated instruction / driver version on Delta's download center.

Introduction

IFD6530 is a convenient RS485-to-USB converter, which does not require external power supply and complex setting process. It supports the transmission speed from 75 to 115 Kbps and auto switching direction of data transmission. In addition, it adopts RJ-45 in RS485 connector for users to wire conveniently. And its tiny dimension, handy use of plug-and-play and hot-swap provide more conveniences for connecting all Delta industrial automation products to your PC.

Applicable models: all Delta's industrial automation products.

Product application and the appearance




Figure 7-18 Figure 7-19

Specifications

Power supply	No external power is needed
Power consumption	0.4 W
Isolated voltage	2,500 V _{DC}
Transmission speed	75 Kbps, 150 Kbps, 300 Kbps, 600 Kbps, 1,200 Kbps, 2,400 Kbps, 4,800 Kbps, 9,600 Kbps, 19,200 Kbps, 38,400 Kbps, 57,600 Kbps, 115,200 Kbps
RS-485 connector	RJ45
USB connector	A type (plug)
Compatibility	In compliance with USB V2.0 specification
The maximum cable length	RS-485 communication port: 100 m
Supports RS-485 half-duplex transmission	

Table 7-12

RJ45



PIN	Description
1	Reserved
2	Reserved
3	Reserved
4	SG-

PIN	Description
5	SG+
6	Reserved
7	Reserved
8	Reserved

The accessory pack includes one cable, one side is RJ11 which connects with IFD6500, another side is two bare wires which are SG1+ (red) and SG1- (green) that can connect to two sets of communication ports on the control board of MP300.

- If you select the first set of RS-485 communication port, then lock the red bare wire to SG1+, and lock the green bare wire to SG1-.
- If you select the second set of RS-485 communication port, then lock the red bare wire to SG2+, and lock the green bare wire to SG2-.





Figure 7-20

Preparations before the driver installation

Extract the driver file (IFD6500_Drivers.exe) by the following steps.

NOTE: Do not connect IFD6530 to PC before extracting the driver file.

STEP 1



STEP 2



STEP 3







STEP 5

IFD6500 driver file is stored in a folder marked SiLabs under drive C. (c:\ SiLabs)


Driver installation


After connecting IFD6530 to PC, install the driver by the following steps.


STEP 1



STEP 2







STEP 5
Repeat Step 1 to Step 4 to complete
COM PORT setting.

LED display

- 1. Steady green LED: the power is ON.
- 2. Blinking orange LED: the data is transmitting.

7-7 Perpetual Calendar and Battery

- ☑ The perpetual calendar function has to install the battery CR2032 (this battery is common specification). Follow the figure shown below to install the battery.
- ☑ When the battery voltage is insufficient, the panel shows LBAt (Low battery voltage) to remind user to change the battery.
- ☑ This product doesn't ship with any battery and we don't sell any battery. Please purchase the battery for this product by yourself.

Install and remove

- 1. Install: Press the battery into the battery slot, and confirm the battery is securely latched. The installation is finished.
- 2. Remove: When change the battery, use a slotted screwdriver to press the latch to release the battery.






Figure 7-21

7-8 The Adapter Plate for Motor

Use this adapter plate to connect MP300 and motor. Refer to section 4-4 for the detailed assembly instruction.








Figure 7-22

Unit: mm (inch)

											•
Models	W	W1	W2	W3	W4	Н	H1	H2	H3	H4	D
MKMP-MAPA1	237.6	53.8	130.0	41.1	61.3	251.3	7.0	134.0	18.0	89.0	83.3
IVINIVIF-IVIAFA I	(9.35)	(2.11)	(5.11)	(1.61)	(2.41)	(9.89)	(0.27)	(5.27)	(0.70)	(3.50)	(3.26)
MKMP-MAPB1	277.4	55.2	167.0	59.6	61.3	283.3	7.0	134.0	18.0	89.0	108.8
IVINIVIE-IVIAED I	(10.92)	(2.17)	(6.57)	(2.34)	(2.41)	(11.15)	(0.27)	(5.27)	(0.70)	(3.50)	(4.28)
MKMP-MAPC1	243.8	17.5	208.8	73.4	92.0	309.3	9.5	137.0	15.6	64.3	127.7
	(9.56)	(0.68)	(8.22)	(2.88)	(3.62)	(12.17)	(0.37)	(5.39)	(0.61)	(2.53)	(5.02)

Table 7-13

Chapter 7 Optional Accessories | MPD

UVW wiring information for the assembly of adapter plate for motor.

Model	Main Circuit Terminals U/T1, V/T2, W/T3			
	Maximum Wire Gauge	Minimum Wire Gauge	Torque (±10%)	
VFD1A6MP43JNNAA				
VFD1A6MP43JFNAA				
VFD3A3MP43JNNAA				
VFD3A3MP43JFNAA				
VFD4A7MP43JNNAA				
VFD4A7MP43JFNAA	2.5 mm ²	2.5 mm ²	N/A	
VFD6A2MP43JNNAA	(14 AWG)	(14 AWG)	14// (
VFD6A2MP43JFNAA				
VFD8A5MP43JNNAA				
VFD8A5MP43JFNAA				
VFD11AMP43JNNAA				
VFD11AMP43JFNAA	6 mm ²	6 mm²	N/A	
VFD15AMP43JNNAA	(10 AWG)	(10 AWG)		
VFD15AMP43JFNAA				
VFD24AMP43JNNAA		10 mm² (8 AWG)		
VFD24AMP43JFNAA		10 mm² (8 AWG)		
VFD31AMP43JNNAA		10 mm² (8 AWG)		
VFD31AMP43JFNAA	16 mm ²	10 mm² (8 AWG)	M4 18.36 Kg-cm	
VFD39AMP43JNNAA	(6 AWG)	16 mm² (6 AWG)	(15.93 lb-in.) (1.8 Nm)	
VFD39AMP43JFNAA		16 mm² (6 AWG)		
VFD45AMP43JNNAA		16 mm² (6 AWG)		
VFD45AMP43JFNAA		16 mm² (6 AWG)		

Installation

Frame A, B

- 1. Remove the hole plug of fan, and assemble hole plugs for fixing motor (the holes are for the special use of MPD).
- 2. Loosen the screws of top case and open it.
- 3. Follow the steps 3-1 to 3-3 as the graph shown below to assemble the fan adapter cable.
- 4. Make sure the hole positions and the hole sizes of the motor to use with MP300, and poke the holes at the corresponding positions of the adapter plate.
- 5. 5-1) Pass the motor power cable through the hole from the inside of the fixing holder.
 - 5-2) Take a temperature sensor and pass it through the hole from the inside of the fixing holder (skip this step if it's not necessary).
 - 5-3) Strip the end sides of motor power cable at least 6.5 mm, insert the bare sides to terminals and crimp them to been fixed.
 - 5-4) Insert the terminals to the terminal block according to the phases. And then assemble the terminal block has been wired to the fixing holder.
 - 5-5) Screw the adapter plate to the motor.
- Assemble MP300 to the adapter plate, and assemble the temperature sensor cable, and then follow the step 6-2 as the graph shown below to tighten M5 screws. Torque: 20–25 kg-cm / [17.3–21.7 lb-in.] / [1.96–2.45 Nm]
- 7. Assemble the top case and tighten M4 screws. Torque: 8–10 kg-cm / [6.9–8.6 lb-in.] / [0.78–0.98 Nm]
- 8. Fix the fan adapter cable with wire mounts, and then connect the fan adapter cable to the fixed structure, see the step 8-2 as the graph shown below.




Figure 7-23




Figure 7-24

Frame C

- 1. Loosen the screws of top case and open it.
- 2. Follow the steps 2-1 to 2-3 as the graph shown below to assemble the fan adapter cable.
- 3. Make sure the hole positions and the hole sizes of the motor to use with MP300, and poke the holes at the corresponding positions of the adapter plate.
- 4. 4-1) Pass the motor power cable through the hole from the inside of the fixing holder.
 - 4-2) Take a temperature sensor and pass it through the hole from the inside of the fixing holder (skip this step if it's not necessary).
 - 4-3) Screw the motor power cable according to the specifications in section 5-2 to the terminal block.
 - 4-4) Insert the terminals to the terminal block according to the phases. And then assemble the terminal block has been wired to the fixing holder.
 - 4-5) Screw the adapter plate to the motor.
- 5. Assemble MP300 to the adapter plate, and assemble the temperature sensor cable, and then follow the step 6-2 as the graph shown below to tighten M6 screws. Torque: 35–40 kg-cm / 30.4–34.7 lb-in.] / [3.43–3.92 Nm]
- 6. Assemble the top case and tighten M4 screws. Torque: 8–10 kg-cm / [6.9–8.6 lb-in.] / [0.78–0.98 Nm]
- 7. Fix the fan adapter cable with wire mounts, and then connect the fan adapter cable to the fixed structure, see the step 7-2 as the graph shown below.




Figure 7-25




Figure 7-26

7-9 Fan and Fan Cord

• The appearance of fans and fan cords

	Models	Fan	Fan cord
Frame A	VFD1A6MP43JNNAA; VFD1A6MP43JFNAA; VFD3A3MP43JNNAA; VFD3A3MP43JFNAA; VFD4A7MP43JNNAA; VFD4A7MP43JFNAA; VFD6A2MP43JNNAA; VFD6A2MP43JFNAA; VFD8A5MP43JNNAA; VFD8A5MP43JFNAA; VFD11AMP43JNNAA	MKMP-FKMA	CBMP-CL0AA
Frame B	VFD11AMP43JFNAA; VFD15AMP43JNNAA; VFD15AMP43JFNAA	MKMP-FKMB	CBMP-CL0BA
Frame C	VFD24AMP43JFNAA; VFD24AMP43JNNAA; VFD31AMP43JFNAA; VFD31AMP43JNNAA; VFD39AMP43JFNAA; VFD39AMP43JNNAA; VFD45AMP43JFNAA; VFD45AMP43JNNAA	MKMP-FKMC	CBMP-CL0CA

- Disassemble the fan
- 1. Press down the latch of the connector by hand (as indicated by the arrow in Figure 7-20) and pull apart to separate the connector smoothly.
- Loosen the fixing screws, as shown in Figure 7-21.
 Frame A / B: M3 screw *3, torque: 6–8 Kgf-cm [5.2–6.9 lb-in.] [0.58–0.78 Nm]
 Frame C: M4 screw *4, torque: 8–10 Kgf-cm [6.9–8.6 lb-in.] [0.78–0.98 Nm]
- 3. Pull the fan upward and take it out smoothly, as shown in Figure 7-22.




Figure 7-27




Figure 7-28




Figure 7-29

[This page intentionally left blank]


Chapter 8 Option Cards

- 8-1 Option Card Installation
- 8-2 CMM-PD02 -- Communication Extension Card, Profibus DP
- 8-3 CMM-DN02 -- Communication Extension Card, DeviceNet
- 8-4 CMM-EIP02 -- Communication Extension Card, EtherNet/IP, Modbus TCP
- 8-5 CMMP-BT01 -- Communication Extension Card, Bluetooth
- 8-6 CMM-PN02 Communication card, PROFINET
- 8-7 Delta Standard Fieldbus Cables


The option cards in this chapter are optional accessories. Select the applicable option cards for your motor drive, or contact your local distributor for suggestions. The option cards can significantly improve the efficiency of the motor drive. To prevent damage to the motor drive during installation, remove the digital keypad and the cover before wiring.

8-1 Option Card Installation

Mounting Position of Option Cards



MP300 control board connector



Option card connector




Figure 8-3

Figure 8-2

Option Card Installation

- 1. Turn off the power of the motor drive, use cross screwdriver to loosen four screws of the front cover and then remove it, as shown in Figure 8-4.
- 2. Check the MOV position if there is a screw tightened. If yes, then make sure the screw is tightened well, the recommended torque is 6-8 kg-cm [5.2-6.9 lb-in] [0.59-0.78 Nm]. As shown in Figure 8-5.
- 3. Engage the lower end of the option card with the guiding slot, as shown in Figure 8-6.
- 4. Press the upper end of the option card to engage the clips, as shown in Figure 8-7.
- 5. Use cross screwdriver tighten one M3 screw, the recommended torque is 4-6 kg-cm [3.5-5.2 lb-in] [0.39-0.59 Nm], as shown in Figure 8-8.
- 6. Connect the cable and fix it in the slotted hole, as shown in Figure 8-9.




Figure 8-4




Figure 8-5





Figure 8-9

Option card cable

To correctly use the option cards, you must purchase the option cards along with the connection cables CBM-CL01A.



Grounded installation

 You must ground the option cards as listed below when wiring. The ground terminal is included in the option card package, as shown in Figure 8-11.



Installation Method

The B end of the grounding wire connects to the ground terminal block of the option card, as the No.6 shows in Figure 8-12 (see Chapter 8 for the ground terminal block position of other option cards). The A end of the grounding wire connects to the drive's PE, as the circles shown in Figure 8-13.




Figure 8-12





Figure 8-13


Frame	Screw	Torque (±10%)
A, B	M4	8 kg-cm [7.0lb-in] [0.78Nm]

8-2 CMM-PD02 -- Communication Extension Card, Profibus DP

■ Product Profile







Wire gauge: 0.25-0.5 mm² [24-20 AWG]

Stripping length: 7-8 mm

Screw torque: 2 kg-cm / [1.7 lb-in.] / [0.2 Nm]

- 1. Screw fixing hole
- 2. Positioning hole
- 3. AC motor drive connection port
- 4. Communicatio n port
- 5. Indicator NET1, NET2
- 6. Ground terminal block

■ Features

- 1. Supports PZD control data exchange.
- 2. Supports PKW access AC motor drive parameters.
- 3. Supports user diagnosis function.
- 4. Auto-detects baud rates; supports a maximum of 12 Mbps.

■ Specifications

PROFIBUS DP Connector

Interface	DB9 connector	
Transmission	High-speed RS-485	
method	· .	
Transmission	Shielded twisted-pair cable	
cable	sinciaca (wisted pair cable	
Electrical	500.1/	
isolation	500 V _{DC}	

Communication

Message type	Cyclic data exchange
Module name	CMM-PD02
GSD document	DELTA08DB.GSD
Product ID	08DB (HEX)
Serial	
transmission	9.6 kbps; 19.2 kbps; 93.75 kbps; 187.5 kbps; 500 kbps; 1.5 Mbps; 3 Mbps; 6 Mbps; 12
speed supported	Mbps (bits per second)
(auto-detection)	

Electrical Specification

Power supply voltage	15 V _{DC} (supplied by the AC motor drive)
Insulation voltage	500 V _{DC}
Power consumption	1 W
Weight	28 g


Environment

	ESD (IEC 61800-5-1, IEC 6100-4-2)	
Naiss insurante	EFT (IEC 61800-5-1, IEC 6100-4-4)	
Noise immunity	Surge Test (IEC 61800-5-1, IEC 6100-4-5)	
	Conducted Susceptibility Test (IEC 61800-5-1, IEC 6100-4-6)	
Operation /	Operation: -10–50°C (temperature), 90% (humidity)	
storage	Storage: -25-70°C (temperature), 95% (humidity)	
Shock / vibration	International standards: IEC 61131-2, IEC 68-2-6 (TEST Fc) /	
resistance	IEC 61131-2 & IEC 68-2-27 (TEST Ea)	

■ Installation

PROFIBUS DP Connector

PIN	Signal	Definition
1	-	Not defined
2	-	Not defined
3	Rxd / Txd-P	Sending / receiving data P(B)
4	-	Not defined
5	DGND	Data reference ground
6	VP	Power voltage – positive
7	-	Not defined
8	Rxd / Txd-N	Sending / receiving data N(A)
9	-	Not defined



■ LED Indicator & Troubleshooting

There are two LED indicators on the CMM-PD02: POWER LED and NET LED.

POWER LED displays the status of the working power. NET LED displays the connection status of the communication.

POWER LED (NET2)

LED status	Indication	Corrective Action
Green light on	Power supply in normal status.	No action is required.
OFF	No power	Check if the connection between the CMM-PD02 and the AC motor drive is normal.


NET LED (NET1)

LED status	Indication	Corrective Action
Green light on	Normal status	No action is required.
Red light on	The CMM-PD02 is not connected to PROFIBUS DP bus.	Connect the CMM-PD02 to the PROFIBUS DP bus.
Red light flashes	Invalid PROFIBUS communication address	Set the PROFIBUS address of the CMM-PD02 between 1–125 (decimal).
Orange light flashes	The CMM-PD02 fails to communicate with the AC motor drive.	Switch off the power and check whether the CMM-PD02 is correctly installed and normally connected to the AC motor drive.

8-3 CMM-DN02 -- Communication Extension Card, DeviceNet

Product Profile





Wire gauge: 0.25-0.5 mm² [24-20 AWG]

Stripping length: 7-8 mm

Screw torque: 2 kg-cm / [1.7 lb-in.] / [0.2 Nm]

- Screw fixing hole
- 2. Positioning hole
- 3. AC motor drive connection port
- 4. Communicati on port
- 5. Indicator NET1, NET2
- Ground terminal block

Features

- Based on the high-speed communication interface of Delta's HSSP protocol, the AC motor drive can be controlled in real-time.
- 2. Supports Group 2 only connection and polling I/O data exchange.
- 3. For I/O mapping, supports a maximum of 32 words input and 32 words output.
- 4. Supports EDS file configuration in DeviceNet configuration software.
- 5. Supports all baud rates on DeviceNet bus: 125 kbps, 250 kbps, 500 kbps and extendable baud rate mode.
- 6. Node address and baud rate can be set in the AC motor drive.
- 7. Power is supplied from the AC motor drive.

Specifications

DeviceNet Connector

Interface	5-PIN open pluggable connector. PIN interval: 5.08 mm		
Transmission method	CAN		
Transmission cable	Shielded twisted-pair cable (with 2 power cables)		
Transmission speed	125 kbps, 250 kbps, 500 kbps and extendable baud rate mode		

AC motor drive connection port

Interface	24 PIN communication terminal	
Transmission method	SPI communication	
Terminal function	 Communication module communicates with the AC motor drive through this port. The AC motor drive supplies power to communication module through this port. 	
Communication protocol	Delta HSSP protocol	

Electrical Specification

Power supply voltage	15 V _{DC} (supplied by the AC motor drive)
Insulation voltage	500 V _{DC}

Chapter 8 Option Cards | MPD

Communication	
cable power	0.85 W
consumption	
Power	1 W
consumption	I VV
Weight	23 g

Environment

Noise immunity	ESD (IEC 61800-5-1, IEC 6100-4-2)	
	EFT (IEC 61800-5-1, IEC 6100-4-4)	
	Surge Test (IEC 61800-5-1, IEC 6100-4-5)	
	Conducted Susceptibility Test (IEC 61800-5-1, IEC 6100-4-6)	
Operation /	Operation: -10–50°C (temperature), 90% (humidity)	
storage	Storage: -25–70°C (temperature), 95% (humidity)	
Shock / vibration	International standards: IEC 61800-5-1, IEC 60068-2-6 / IEC 61800-5-1, IEC 60068-2-	
resistance	27	

DeviceNet Connector

PIN	Signal	Color	Definition
1	V+	Red	24 V _{DC}
2	Н	White	Signal+
3	S	-	Ground
4	L	Blue	Signal-
5	V-	Black	0V



■ LED Indicator & Troubleshooting

There are two LED indicators on the CMM-DN02:

NS LED and MS LED. NS LED and MS LED are dual-color LEDs, displaying the connection status and error messages of the communication module.

NS LED (NET2)

LED status	Indication	Corrective Action
OFF	No power supply or the CMM-DN02 does not pass the MAC ID test.	 Check the power to the CMM-DN02 and see if the connection is normal. Make sure there is at least one node on the bus. Check if the baud rate of the CMM-DN02 is the same as that of the other nodes.
Green light flashes	The CMM-DN02 is on-line but does not connect to the master.	 Configure the CMM-DN02 to the scan list of the master. Re-download the configured data to the master.
Green light on	The CMM-DN02 is on-line and normally connects to the	No action is required.
Red light flashes	The CMM-DN02 is on-line, but I/O connection is timedout.	 Check if the network connection is normal. Check if the master operates normally.
Red light on	 Broken communication MAC ID test failure No network power supply. CMM-DN02 is off-line. 	 Make sure all MAC IDs on the network are unique. Check if the network installation is normal. Check if the baud rate of the CMM-DN02 is the same as that of the other nodes.

LED status	Indication	Corrective Action
		4. Check if the node address of the CMM-DN02 is illegal.
		5. Check if the network power supply is normal.


MS LED (NET1)

LED status	Indication	Corrective Action
OFF	No power supply or device is off-line	Check the power supply of the CMM-DN02 and see if the connection is normal.
Green light flashes	Waiting for I/O data Switch the master PLC to RUN status.	
Green light	I/O data is normal	No action is required.
Red light flashes	Mapping error	Reset the CMM-DN02. Re-power the AC motor drive.
Red light on	Hardware error	See the fault codes displayed on the keypad and find the causes. Return the unit to the factory for repair if necessary.
Orange light flashes	The CMM-DN02 is connecting with the AC motor drive.	If the flashing lasts for a long period of time, turn off the power to check if the CMM-DN02 and the AC motor drive install correctly and are normally connected to each other.

8-4 CMM-EIP02 -- Communication Extension Card, EtherNet/IP, Modbus TCP

■ Product Profile





Wire gauge: 0.25-0.5 mm² [24-20 AWG]

Stripping length: 7-8 mm

Screw torque: 2 kg-cm / [1.7 lb-in.] / [0.2 Nm]

- 1. Screw fixing hole
- 2. Positioning hole
- 3. AC motor drive connection port
- 4. Communication port
- 5. Indicator NET1 (NS), NET2 (MS)
- 6. POWER
- 7. LINK
- 8. Ground terminal block

Features

- 1. Supports Modbus TCP and EtherNet/IP protocol
- 2. 32 / 32 words parameter reading / writing correspondence
- 3. User-defined corresponding parameters
- 4. MDI / MDI-X auto-detect
- 5. E-mail alarm
- 6. IP filter simple firewall function

Specifications

Network Interface

Interface	RJ45 with Auto MDI / MDIX	
Number of ports	1 Port	
Transmission method	IEEE 802.3, IEEE 802.3u	
Transmission cable	Category 5e shielding 100 M	
Transmission speed	10/100 Mbps Auto-Detect	
Network protocol	ICMP, IP, TCP, UDP, DHCP, HTTP, SMTP, Modbus over TCP/IP, EtherNet/IP, Delta Configuration	

Electrical Specification

Power supply voltage	15 V _{DC}
Insulation voltage	500 V _{DC}
Power consumption	0.8 W
Weight	25 g

Environment

Noise immunity	ESD (IEC 61800-5-1, IEC 61000-4-2)	
	EFT (IEC 61800-5-1, IEC 61000-4-4)	
	Surge Test (IEC 61800-5-1, IEC 61000-4-5)	
	Conducted Susceptibility Test (IEC 61800-5-1, IEC 61000-4-6)	
Operation /	Operation: -10-50°C (temperature), 90% (humidity)	

storage	Storage: -25–70°C (temperature), 95% (humidity)	
Shock / vibration	International standards: IEC 61800-5-1, IEC 60068-2-6 / IEC 61800-5-1, IEC 60068-2-	
resistance	27	

■ Installation

Connecting the CMM-EIP02 to the Network

- 1. Turn off the power of the drive.
- 2. Open the front cover of the drive.
- 3. Connect the CAT-5e network cable to the RJ45 port of the CMM-EIP02 (as shown in the right figure).



RJ45 PIN Definition

PIN	Signal	Definition
4	Tyr	Positive pole for
I	Tx+	data transmission
2	Tx-	Negative pole for
2		data transmission
3	Rx+	Positive pole for
3		data reception
4		N/C

PIN	Signal	Definition
5		N/C
6	Rx-	Negative pole for data reception
7		N/C
8		N/C



■ MP300 Communication Parameter Settings when Connecting to Ethernet

When you connect the MP300 to Ethernet, set up the communication parameters based on the table below. The Ethernet master reads and writes the frequency command words and operation command words after you set the communication parameters.

MP300 Parameters	Function	Current Setting Value	Description
00-20	Master frequency	8	The frequency command is controlled by
00-21	Command source Operation command source	5	the communication card. The operation command is controlled by the communication card.
09-30	Communication Decoding Method	0	The decoding method for Delta AC motor drive.
09-75	IP configuration	0	0: Static IP 1: Dynamic IP (DHCP)
09-76	IP address 1	192	IP address 192.168.1.5
09-77	IP address 2	168	IP address 192.168.1.5
09-78	IP address 3	1	IP address 192.168.1.5
09-79	IP address 4	5	IP address 192.168.1.5
09-80	Netmask 1	255	Netmask 255.255.25.0
09-81	Netmask 2	255	Netmask 255.255.25.0
09-82	Netmask 3	255	Netmask 255.255.25.0
09-83	Netmask 4	0	Netmask 255.255.25.0
09-84	Default gateway 1	192	Default gateway 192.168.1.1.1
09-85	Default gateway 2	168	Default gateway 192.168.1.1.1
09-86	Default gateway 3	1	Default gateway 192.168.1.1.1
09-87	Default gateway 4	1	Default gateway 192.168.1.1.1

■ LED Indicator & Troubleshooting

LED indicators

Indicator	Status	Indication	Corrective Action
	The red and green lights flash alternately.	Self-test of network status	No action is required.
	Green light is ON	Already established a connection with CIP	No action is required.
NET1	Green light flashes	Never establish connection with CIP after powering ON	No action is required.
(NS)	Red light is ON	Duplicate IP	Check if the IP setting is wrong
	Red light flashes	Communication time out / disconnected / IP changed	Check if the communication setting is wrong
	Light is OFF	Network is not connected	Check if the network cable is connected.
	The red and green lights flash alternately.	Self-test of product status	No action is required.
Green light is	Green light is ON	The parameter setting finished	No action is required.
NET2	Green light flashes	No parameter setting	Follow manual instructions to set parameters
(MS)	Red light is ON	Occur an error cannot be restored	Hardware malfunction, contact with the dealer
	Red light flashes	Occur an error can be restored	Check if any parameter setting is wrong
	Light is OFF	No power supply	Check the power supply.
DOMED	ON	Power supply in normal status	No action is required.
POWER	Light is OFF	No power supply	Check the power supply.
LINK	ON	Sending / receiving network packet	No action is required.
LINK	Light is OFF	Network is not connected	Check if the network cable is connected.

Troubleshooting


Abnormality	Cause	Corrective Actions
	The AC motor drive is not	Check the power of the AC motor drive, and see if
	powered.	the power supply is normal.
POWER LED OFF	The CMM-EIP02 is not connected to the AC motor drive.	Ensure that the CMM-EIP02 is connected to the AC motor drive.
LINK LED OFF	The CMM-EIP02 is not connected to network.	Ensure that the network cable is correctly connected to network.
	Poor contact to the RJ45 connector	Ensure that the RJ45 connector is connected to the Ethernet port.
Cannot find	The CMM-EIP02 is not	Ensure that the CMM-EIP02 is correctly connected
communication card	connected to the network.	to the network.

Abnormality	Cause	Corrective Actions
	The PC and the CMM-EIP02 are in different networks and blocked by network firewall.	Search by IP or set up relevant settings using the AC motor drive keypad.
	The CMM-EIP02 is not connected to the network.	Ensure that the CMM-EIP02 is correctly connected to the network.
Cannot open CMM-	Incorrect communication setting in DCISoft	Ensure that the communication setting in DCISoft is set to Ethernet.
EIP02 setup page	The PC and the CMM-EIP02 are in different networks and blocked by network firewall.	Set up with the AC motor drive keypad.
Can open CMM- EIP02 setup page, but cannot use web monitor	Incorrect network setting in the CMM-EIP02	Check if the network setting for the CMM-EIP02 is correct. For the Intranet setting in your company, please consult your IT staff. For the Internet setting at home, please refer to the network setting instructions provided by your ISP.
Cannot send e-mails	Incorrect network setting in the CMM-EIP02	Check if the network setting for the CMM-EIP02 is correct.
	Incorrect mail server setting	Confirm the IP address for the SMTP-Server.

8-5 CMMP-BT01 -- Communication Extension Card, Bluetooth

■ Product Profile





Wire gauge: 0.25-0.5 mm² [24-20 AWG]

Stripping length: 7-8 mm

Screw torque: 2 kg-cm / [1.7 lb-in.] / [0.2 Nm]

- 1. Screw fixing hole
- 2. Positioning hole
- 3. AC motor drive connection port
- 4. Indicator POWER, ERROR

■ Features

- 1. Support to communicate with handhold devices via bluetooth signal.
- 2. Communication and power supply are fully isolated, and have strong noise immunity.

Specifications

Specifications of the wireless

Interface	Bluetooth
Transmission speed	1 Mbps / 2 Mbps
Communication protocol	GATT
Frequency	2.402-2.480GHz
Communication range	50m (under the circumstances of no barriers and no interruptions)

Electrical specification

Power supply voltage	15 V _{DC}
Insulation voltage	500 V _{DC}
Power consumption	0.8 W
Weight	25 g

Environment

	ESD (IEC 61800-5-1, IEC 6100-4-2)
Noise immunity	EFT (IEC 61800-5-1, IEC 6100-4-4)
Noise initiality	Surge Test (IEC 61800-5-1, IEC 6100-4-5)
	Conducted Susceptibility Test (IEC 61800-5-1, IEC 6100-4-6)
Operation /	Operation: -10–50°C (temperature), 90% (humidity)
storage	Storage: -25–70°C (temperature), 95% (humidity)
Shock / vibration	International standards: IEC 61131-2, IEC 68-2-6 (TEST Fc) /
resistance	IEC 61131-2 & IEC 60068-2-27 (TEST Ea)

■ LED Indicator & Troubleshooting

There are two LED indicators on the CMMP-BT01: POWER LED and ERROR LED.

POWER LED displays the status of the working power. ERROR LED displays the connection status of the communication whether it's abnormal.

POWER LED

LED status	Indication	Corrective Action
Green light is ON	Power supply in normal status.	No action is required.
OFF	No power	Check if the connection between the CMMP-BT01 and the AC motor drive is normal.
Green light flashes	APP connects with the bluetooth card	No action is required.

ERROR LED

LED status	Indication	Corrective Action
OFF	Normal status	No action is required.
Red light is ON	The bluetooth card and MP300 have abnormal communication	 Re-power ON. Remove and insert the bluetooth card again. Check the wiring. Contact with Delta.
Red light flashes	This model or the firmware version does not support the bluetooth card.	 Make sure the series and the firmware version are as follows: MH300 series: V1.03 and later MS300 series: V1.08 and later MS300-HS series: V5.04 and later MP300 series: V1.0 and later Contact with Delta.

8-6 CMM-PN02 -- Communication card, PROFINET

8-6-1 Features


CMM-PN02 connects MP300 drive to PROFINET to exchange data with the host controller easily. This simple network solution saves cost and time for connection and installation of factory automation. Moreover, its components are compatible with suppliers'.

By installing CMM-PN02 in MP300 through the main PROFINET device, you can:

- 1. Control the drive through PROFINET
- 2. Modify the drive's parameters through PROFINET
- 3. Monitor the drive's status through PROFINET

8-6-2 Product Profile






- 1. Screw fastening hole
- 2. Positioning hole for communication card
- 3. Control Panel connection port
- 4. RJ45 connection port (Port 2)
- 5. RJ45 connection port (Port 1)
- 6. BF out indicator

- 7. Ready out indicator
- 8. Link PHY1 indicator (Port 1)
- 9. Link PHY2 indicator (Port 2)
- 10. F/W indicator
- 11. D/B indicator
- 12. PE grounding terminal

8-6-3 MAC Address Definition



Def.	Description
MAC1	Port 1 MAC Address
MAC2	Port 2 MAC Address
MAC3	Interface MAC Address

8-6-4 Specifications

EtherNet Specifications

Item	Specifications		
Interface	RJ45		
Number of poles	2 ports		
Communication Mode	IEEE 802.3		
Cable	Category 5e shielding 100 M		
Transmission Speed	10 / 100 Mbps auto-negotiate		
Communication Protocol	PROFINET		

Electrical Specifications

Item	Specifications			
Power Supply Voltage	15 V _{DC}			
Power Consumption	0.8 W			
Insulation Voltage	500 V _{DC}			
Weight (g; approx)	27 (g)			

Environmental Conditions

Item	Specifications
	ESD (IEC 61800-5-1, IEC 6100-4-2)
Noise Immunity	EFT (IEC 61800-5-1, IEC 6100-4-4)
Noise initiality	Surge Test (IEC 61800-5-1, IEC 6100-4-5)
	Conducted Susceptibility Test (IEC 61800-5-1, IEC 6100-4-6)
Operating Temperature	-10-50°C (temperature), 90% (humidity)
Storage Temperature	-25–70°C (temperature), 95% (humidity)
Vibration / Shock	International standards
Resistance	IEC 61800-5-1, IEC 60068-2-6 / IEC 61800-5-1, IEC 60068-2-27

8-6-5 Definition of RJ45 Pin

RJ45 Pinout Diagram	PIN	Definition	Description
12345678	1	Tx+	Positive pole for data transmission
	2	Tx-	Negative pole for data transmission
	3	Rx+	Positive pole for receiving data
	4		N/C
	5		N/C
	6	Rx-	Negative pole for receiving data
	7		N/C
	8		N/C

8-6-6 MP300 Drive Settings

When you operate MP300 through CMM-PN02, you should set the communication card as the source of MP300 controls and settings. You need to use the keypad to configure the following parameter addresses to the corresponding values:

Chapter 8 Option Cards | MPD

Parameter	Settings/ Displayed Value	Description of Function		
00-20	8	Set communication card as the source of frequency command.		
00-21	5	Set communication card as the source of control.		
09-30	1	Decoding method is either 60xx		
09-60	12	Communication card identification: When CMM-PN02 communication card is connected, the value of this parameter displays "12".		


NOTE: To make PLC or the host controller to identify CMM-PN02, it is necessary to load the product description file of CMM-PN02 (GSDML). You can download it directly from Delta's official website.

8-6-7 LED Indicators

Name	Indicator Status		Indication	
	Always ON		Disconnected with PROFINET Controller	
BF (bus fault)	Red LED	Flashing	Normal connection, but abnormal communication with	
indicator			PROFINET Controller.	
		OFF	Normal connection with PROFINET Controller	
RDY indicator	Red/ Green Always orange		PROFINET diagnostic	
RD1 indicator	LED	Always green	PROFINET card ready.	
	Green LED	Always ON	L/A1 has network signal.	
L/A1 (Link/ Act1) indicator		Flashing	L/A1 is handshaking data.	
indicator		OFF	L/A1 doesn't have network signal.	
1 /40 /1: 114 /0	Always ON		L/A2 has network signal.	
L/A2 (Link' Act2) indicator	Green LED	Flashing	L/A2 is handshaking data	
indicator		OFF	L/A2 doesn't have network signal.	

8-6-8 Connecting to the Network

The wiring of CMM-PN02



When the installation is finished, supply electricity to the drive. The Pr.09-60 of the drive should be able to display "PROFINET" with a current value of 12. If not, make sure your version of the drive is correct (MH300 needs v.2.00 or later versions) and the communication card is correctly connected.

8-7 Delta Standard Fieldbus Cables

Delta Standard Fieldbus Cables	Models	Descriptions	Length
Davischlet Cable	UC-DN01Z-01A	DeviceNet cable	305 m
DeviceNet Cable	UC-DN01Z-02A	DeviceNet cable	305 m
	UC-EMC003-02A	Ethernet / EtherCAT cable, Shielding	0.3 m
	UC-EMC005-02A	Ethernet / EtherCAT cable, Shielding	0.5 m
	UC-EMC010-02A	Ethernet / EtherCAT cable, Shielding	1 m
Ethernet / EtherCAT cable	UC-EMC020-02A	Ethernet / EtherCAT cable, Shielding	2 m
	UC-EMC050-02A	Ethernet / EtherCAT cable, Shielding	5 m
	UC-EMC100-02A	Ethernet / EtherCAT cable, Shielding	10 m
	UC-EMC200-02A	Ethernet / EtherCAT cable, Shielding	20 m
PROFIBUS Cable	UC-PF01Z-01A	PROFIBUS DP cable	305 m

Chapter 9 Specifications

- 9-1 460V Models
- 9-2 General Specifications
- 9-3 Environment for Operation, Storage and Transportation
- 9-4 Derating for Ambient Temperature, Altitude and Carrier Frequency
- 9-5 Specifications of Motor

9-1 460V Models

460V MPD series_three-phase

	Frame	A				
	MPD models:	75B		15C		
	MPD 30C43_2B MPD 30C43_2D	N	F	N	E	
Α	pplicable Motor Output (kW)	0.7	75	1.5	5	
Α	pplicable Motor Output (HP)	1		2		
App	licable AC Motor Drive Models	VFD1A6MP43JNNAA	VFD1A6MP43JFNAA	VFD3A3MP43JNNAA	VFD3A3MP43JFNAA	
	Applicable Motor Models	MSI75B-30C MSI75B-30C	-	MSI15C-30CI MSI15C-30CI	_	
	Motor Rated Current (A)	1.5	5	3.1	1	
# p	Rated Output Torque (N.m)	2.3	2.3		4.7	
Output Rating	Rated Output Speed (rpm)	3000				
0 &	Carrier Frequency of AC Motor Drive (kHz) *1	2–15				
g	Rated Input Current (A)	1.9	9	3.8	3	
atin	Rated Voltage / Frequency	Three-phase 380–480 VAC (-15–10%), 50/60 Hz			Z	
Input Rating	Mains Input Voltage Range (V _{AC})	323–528				
	Mains Frequency Range (Hz)	47–63				
	Cooling Method	Fan cooling				
	EMC Filter		Built-in		Built-in	
	CE / RE Class *3	C1 / C2				
	IP Rating	IP55				
	PDS Efficiency Class *2		IE	S2		

	Frame			A	
MPD models:		22C		30C	
	MPD 30C43[2B MPD 30C43[2D	N	F	N	E
Α	pplicable Motor Output (kW)	2.1	2	3	
Α	pplicable Motor Output (HP)	3		4	
App	licable AC Motor Drive Models	VFD4A7MP43JNNAA	VFD4A7MP43JFNAA	VFD6A2MP43JNNAA	VFD6A2MP43JFNAA
	Applicable Motor Models	MSI22C-30C MSI22C-30C	-	MSI30C-30C MSI30C-30C	_
	Motor Rated Current (A)	4.4	4	5.8	3
t g	Rated Output Torque (N.m)	7		9.5	
Output Rating	Rated Output Speed (rpm)	3000			
0 &	Carrier Frequency of AC Motor Drive (kHz) *1	2–15			
g	Rated Input Current (A)	5.4	4	7.2	2
atin	Rated Voltage / Frequency	Three-phase 380-480 VAC (-15-10%), 50/60 Hz			Z
Input Rating	Mains Input Voltage Range (V _{AC})		323	-528	
	Mains Frequency Range (Hz)		47–63		
	Cooling Method		Fan d	cooling	
	EMC Filter		Built-in		Built-in
	CE / RE Class *3	C1 / C2			
	IP Rating	IP55			
	PDS Efficiency Class *2	IES2			

					1	
	Frame	A		В		
	MPD models:_	400	C	55	5C	
	MPD 30C43 2B MPD 30C43 2D	N	E	N	E	
Α	oplicable Motor Output (kW)	4.0)	5	.5	
Α	pplicable Motor Output (HP)	5.5	5	7	.5	
App	licable AC Motor Drive Models	VFD8A5MP43JNNAA	VFD8A5MP43JFNAA	VFD11AMP43JNNAA	VFD11AMP43JFNAA	
	Applicable Motor Models	MSI40C-30C MSI40C-30C	-		MSI55C-30CDXS2BFAP MSI55C-30CDXS2DFAP	
	Motor Rated Current (A)	8		11		
# g	Rated Output Torque (N.m)	12.7		17.5		
Output Rating	Rated Output Speed (rpm)	3000				
0 &	Carrier Frequency of AC Motor Drive (kHz) *1	2–15				
g	Rated Input Current (A)	9.9	9	13	3.8	
atin	Rated Voltage / Frequency	Three-phase 380-480 VAC (-15-10%), 50/60 Hz				
Input Rating	Mains Input Voltage Range (V _{AC})	323–528				
	Mains Frequency Range (Hz)		47	-63		
	Cooling Method	Fan cooling				
	EMC Filter	Built-in Built-in			Built-in	
	CE / RE Class *3	C1 / C2				
	IP Rating	IP55				
	PDS Efficiency Class *2		IE	S2		

	Frame	В			
	MPD models:	75C			
	MPD 30C43 _ 2B MPD 30C43 _ 2D	N	Ē		
Α	pplicable Motor Output (kW)	7.	5		
Α	pplicable Motor Output (HP)	10	0		
App	licable AC Motor Drive Models	VFD15AMP43JNNAA	VFD15AMP43JFNAA		
	Applicable Motor Models	MSI75C-30C MSI75C-30C			
	Motor Rated Current (A)	14	.7		
# g	Rated Output Torque (N.m)	23.8			
Output Rating	Rated Output Speed (rpm)	3000			
0 &	Carrier Frequency of AC Motor Drive (kHz) *1	2–15			
g	Rated Input Current (A)	18	.5		
ati.	Rated Voltage / Frequency	Three-phase 380-480 VA	AC (-15–10%), 50/60 Hz		
Input Rating	Mains Input Voltage Range (V _{AC})	323-	528		
=	Mains Frequency Range (Hz)	47–	63		
	Cooling Method	Fan co	poling		
	EMC Filter		Built-in		
	CE / RE Class *3	C1 /	C2		
	IP Rating	IPS	55		
	PDS Efficiency Class *2	IES2			

Table 9-1

NOTE:

^{*1:} The AC motor drive have to derating when the carrier frequency is higher than the default. Refer to section 9-4 for derating curve.

^{*2:} Power drive system (PDS) that IEC 61800-9-2 defines.

^{*3:} The carrier frequency is 4 kHz.

Chapter 9 Specifications | MPD

460V MP300 series_three-phase

	Frame	A			
Maria NED Maria		1A	6	3A:	3
IVIO	del: VFD MP43J 🗌 NAA	Z	Œ	N	F
Α	pplicable Motor Output (kW)	0.7	75	1.5	5
Α	pplicable Motor Output (HP)	1		2	
# p	Rated Output Capacity (kVA)	2.	1	3.2	2
Output Rating	Rated Output Current (A)	1.6		3.3	3
0 &	Carrier Frequency (kHz) *1	2–15			
g	Rated Input Current (A)	1.9		3.8	
atin	Rated Voltage / Frequency	Three-phase 380–480 VAC (-15–10%), 50/60 Hz			
Input Rating	Mains Input Voltage Range (V _{AC})	323–528			
lnp	Mains Frequency Range (Hz)	47–63			
	Cooling Method	Fan cooling			
	EMC Filter			Built-in	
	CE / RE Class *5	C1 / C2			
	IP Rating	IP55 ⁴			
	CDM Efficiency Class *2		- II	E2	

Frame		A			
Model: VFD MP43J NAA		4A7		6A2	
		N	F	N	F
Applicable Motor Output (kW)		2.2		3	
Applicable Motor Output (HP)		3		4	
Output Rating	Rated Output Capacity (kVA)	4.2		5.6	
	Output Rated Current (A)	4.7		6.2	
	Carrier Frequency (kHz) *1	2–15			
Input Rating	Rated Input Current (A)	5.4		7.2	
	Rated Voltage / Frequency	Three-phase 380-480 VAC (-15-10%), 50/60 Hz			
	Mains Input Voltage Range (V _{AC})	323–528			
	Mains Frequency Range (Hz)	47–63			
Cooling Method		Fan cooling⁺³			
EMC Filter			Built-in		Built-in
CE / RE Class *5		C1 / C2			
IP Rating		IP55 ⁴			
CDM Efficiency Class *2		IE2			

	Frame	A B					
	Jala VED MENO I TANA	8A	5	11A			
IVIO	del: VFD MP43J 🗌 NAA	N	F	N	F		
Α	pplicable Motor Output (kW)	4.0	0	5	5.5		
Α	pplicable Motor Output (HP)	5.9	5	7	.5		
# 0	Rated Output Capacity (kVA)	6.9	9	9	.9		
Output Rating	Output Rated Current (A)	8.8	5	11	.0		
OR	Carrier Frequency (kHz) *1	2–15					
g	Rated Input Current (A)	9.9 13.8					
atin	Rated Voltage / Frequency	Th	ree-phase 380–480 \	/AC (-15-10%), 50/60 H	Hz		
Input Rating	Mains Input Voltage Range (VAC)		323	-528			
4	Mains Frequency Range (Hz)		47	-63			
	Cooling Method		Fan c	ooling ^{*3}			
	EMC Filter		Built-in		Built-in		
	CE / RE Class *5		C1	/ C2			
	IP Rating		IP	55 ⁴			
	CDM Efficiency Class *2		I	= 2			

	Frame	В					
		15A					
Мо	del: VFD MP43J 🛚 NAA	N	巨				
A	oplicable Motor Output (kW)	7	7.5				
Α	oplicable Motor Output (HP)	1	0				
# D	Rated Output Capacity (kVA)	1	3				
Output Rating	Output Rated Current (A)	15.0					
0 &	Carrier Frequency (kHz) *1	2–15					
g	Rated Input Current (A)	18	3.5				
atin	Rated Voltage / Frequency	Three-phase 380-480 VAC (-15-10%), 50/60 Hz					
Input Rating	Mains Input Voltage Range (V _{AC})	323	-528				
1	Mains Frequency Range (Hz)	47	-63				
	Cooling Method	Fan co	ooling ^{*3}				
	EMC Filter		Built-in				
	CE / RE Class *5	C1 / C2					
	IP Rating	IP	IP55 ⁴				
	CDM Efficiency Class *2	IE2					

Chapter 9 Specifications | MPD

	Frame	С							
	Б	24A		31	31A)A	45A	
Мо	del: VFD MP43J 🗌 NAA	N	F	N	F	N	F	N	E
Α	pplicable Motor Output (kW)	11		1	5	18	5.5	2	2
Α	pplicable Motor Output (HP)	15	1	2	0	2	5	3	0
# Ø	Rated Output Capacity (kVA)	18.	6	24	.2	29	.9	34	.8
Output Rating	Output Rated Current (A)	24.	4	31	31.8		39.2		5.6
0 &	Carrier Frequency (kHz) *1	2~15							
ō	Rated Input Current (A)	29.	5	38.9 4			8.5 56.5		
atin	Rated Voltage / Frequency		Т	hree-phase	380–480 V	AC (-15–10°	%), 50/60 H	z	
Input Rating	Mains Input Voltage Range (V _{AC})				323~	528			
	Mains Frequency Range (Hz)				47~	63			
	Cooling Method				Fan co	oling ^{*3}			
	EMC Filter		Built-in		Built-in		Built-in		Built-in
	CE / RE Class *5				C2 /	C2			
	IP Rating				IP5	5 ^{*4}		<u>'</u>	<u>'</u>
CDM Efficiency Class *2 IE2									

Table 9-2

NOTE:

- *1: The AC motor drive have to derating when the carrier frequency is higher than the default. Refer to section 9-4 for derating curve.
- *2: Power drive system (Complete drive module · CDM) that IEC 61800-9-2 defines.
- *3: Dissipate heat by using the fan of MKMP adapter plate.
- *4: Follow the assembly instruction of MKMP adapter plate to reach the protection rating IP55.
- *5: The carrier frequency is 4 kHz.

9-2 General Specifications

	Control Method	MP300: V/F, PMSVC MPD: PMSVC (00-11 = 2)
	Applicable Motor	IM (induction motor), PM control (IPM, SPM), MSI motor
	Output frequency (Hz)	MPD: 0.00–the maximum frequency which depends on the motor specification MP300: 0.00–599 Hz
Control	Starting Torque *1	120% / 3 Hz (Conditions: V/F and IM control, with rated current) 100% / (rated frequency of motor / 20) (Conditions: PMSVC and PM control, with rated current)
Characteristics of	Speed Control Range *1	1:50 (Conditions: V/F and IM control) 1:20 (Conditions: PMSVC and PM control)
AC Motor Drive	Overload Capacity	120% of rated current can endure for 1 minute during every 5 minutes; 150% of rated current can endure for 3 seconds during every 30 seconds
	Frequency Setting Signal	0- +10V / 4 (0)-20 mA
	Main Functions	PID constant pressure control, multi-pump control, multi-master function, scheduled function, sleep function, DC preheating, flow estimation function, clean function
	Application Macro	Built-in user-defined application parameter groups.
	Rotation Direction	It's clockwise as viewed on the shaft end of the motor.
	Motor Duty Cycles	Continuous duty (S1)
Characteristic of motor*2	Motor Temperature Protection	KTY84-130 / PTC-130
motor	Insulation Classes	Class F
	Temperature Rise Classes	Class B
Protection	Protection	Over-current, Over-voltage, Over-heating of AC motor drive, Over-heating of motor, Phase loss, Speed loss
Characteristics	Pump Protection	Dry pump, High / Low water pressure, Pipe explosion, Cavitaion
Certific	cations	MP300: CE, RoHS, UL, KC MPD: CE, RoHS

Table 9-3

^{*1:} Control accuracy may vary depending on the environment, application conditions. For more information, contact Delta or your local distributors.

^{*2:} These specifications are suitable for MPD.

9-3 Environment for Operation, Storage and Transportation

DO NOT expose the AC motor drive and the motor to a poor environment, such as one with direct sunlight, corrosive / inflammable gases, humidity, grease or excessive vibration.

The salt in the air must be less than 0.01 mg/cm² every year.

	Installation Location	IEC 60364-1/ IEC	60664-1 Pollution degree 2, Indoor use only.				
		Operation	-20–40 °C -20–50 °C with derating				
	Surrounding	Storage	-40–70 °C				
	Temperature	Transportation	-20–70 °C				
		Non-condensing,	non-freezing				
Environment		Operation	Maximum 90 %				
	Rated Humidity	Storage / Transportation	Maximum 95 %				
		No water condensation					
	Air Pressure	Operation	86-106 kPa				
		Storage / Transportation	70–106 kPa				
	Altitude	<1000 m (For altit	rudes > 1000 m, derate to use it.)				
Package Drop	Storage	ICTA propodure 4	A (cocording to weight) IFC COCCO 2 24				
Fackage Diop	Transportation	151A procedure 17	A (according to weight) IEC 60068-2-31				
Vibration	Operation / Non operation	EC 60721 3M6 (2-9Hz: 7mm, 9-200Hz: 2G)					
Impact Operation / Non operation IEC 60721 3M6 (25g / 6ms)							

Table 9-4

9-4 Derating for Ambient Temperature, Altitude and Carrier Frequency

9-4-1 Derating Curve for Ambient Temperature and Altitude




Table 9-5

The rated output current derating

In normal duty, carrier frequencies are defaults.

Ambient temperature (Ta) / 100% Load Fc (kHz)	30°C	40°C	50°C
Default (%)	100	100	75

Different altitudes above sea level:

Altitude above sea level (meter)	0	1000	1500	2000
Output current / rated current (%)	100	100	95	90

Table 9-6

9-4-2 Derating Curve for Carrier Frequency

• Phase modulation mode (Pr.11-41 = 0)




Figure 9-3

The rated output current of DPWM in different carrier frequencies

Fc (kHz) Ambient temperature (Ta) 100% Load	2	3	4	5	6	7	8	9	10	11	12	13	14	15
40°C	100	100	100	93	88	83	79	75	71	68	65	62	59	56
35°C	100	100	100	100	94	91	86	82	78	75	71	68	65	62
30°C	100	100	100	100	100	98	93	89	85	81	77	74	71	68

Table 9-7

Space vector modulation mode (Pr.11-41 = 2)




Figure 9-4

The rated output current of SVPWM in different carrier frequencies (unit: %)

Fc (kHz) Ambient temperature (Ta) 100% Load	2	3	4	5	6	7	8	9	10	11	12	13	14	15
40°C	100	98	90	82	75	70	65	60	56	52	49	46	43	41
35°C	100	100	95	88	82	76	71	66	62	58	54	51	48	46
30°C	100	100	100	95	89	83	77	72	68	64	60	57	54	51

Table 9-8

9-5 Specifications of Motor

Summary of properties (0.75~7.5kW-3000rpm)

Models	Rated power (kW)	Frame (mm)	Rated speed (rpm)	Rated current (A)	Rated torque (Nm)	Maximum torque (Nm)
MSI75B-30CDXS2_1AP	0.75	80-1		1.5	2.3	3.5
MSI15C-30CDXS2_1AP	1.5	80-2		3.1	4.7	7.1
MSI22C-30CDXS2_1AP	2.2	80-2		4.4	7	10.5
MSI30C-30CDXS2_1AP	3	90	2000	5.8	9.5	14.3
MSI40C-30CDXS2_1AP	4	90	3000	8	12.7	19.1
MSI55C-30CDXS2_1AP	5.5	100-1		11	17.5	26.3
MSI55C-30CDXS2_FAP	5.5	100-2		11	17.5	26.3
MSI75C-30CDXS2_1AP	7.5	100-2		14.7	23.8	35.7

	Maximum	Moment of	Power	Full load	3/4 load	2/4 load
Models	rotor speed	inertia	factor	efficiency	efficiency	efficiency
	(rpm)	(kg-m²)	(%)	(%)	(%)	(%)
MSI75B-30CDXS2_1AP		1.16*10 ⁻³	0.85	86.3	84.6	83.5
MSI15C-30CDXS2_1AP		1.56*10 ⁻³	0.85	88.9	88.0	85.4
MSI22C-30CDXS2_1AP		1.76*10 ⁻³	0.85	90.2	91.4	89.6
MSI30C-30CDXS2_1AP	2000	3.03*10 ⁻³	0.85	91.1	92.2	90.6
MSI40C-30CDXS2_1AP	3600	3.36*10 ⁻³	0.86	91.8	92.7	91.2
MSI55C-30CDXS2_1AP		5.83*10 ⁻³	0.87	92.6	93.2	92.0
MSI55C-30CDXS2_FAP		5.83*10 ⁻³	0.87	92.6	93.2	92.0
MSI75C-30CDXS2_1AP		7.53*10 ⁻³	0.87	93.3	93.9	93.2

Table 9-9

Specification of Bearing

Models	Front bearing	Rear bearing
MSI75B-30CDXS2_1AP	0005	0004
MSI15C-30CDXS2_1AP	6305	6204
MSI22C-30CDXS2_1AP	ZZ/C3	ZZ/C3
MSI30C-30CDXS2_1AP	6306	6205
MSI40C-30CDXS2_1AP	ZZ/C3	ZZ/C3
MSI55C-30CDXS2_1AP	0000	0000
MSI55C-30CDXS2_FAP	6308 ZZ/C3	6206 ZZ/C3
MSI75C-30CDXS2_1AP	22/03	22/03

Table 9-10


NOTE: The positions mark as "_" mean the installation ways: B (IM B5 / IM V1), D (IM B14 / IM V18)

[This page intentionally left blank]


Chapter 10 Digital Keypad

- 10-1 Appearance of Keypad
- 10-2 The Backlight of the Keypad Panel
- 10-3 Descriptions of Keypad Functions
- 10-4 Information Displayed on the Panel
- 10-5 Keypad Operation Process
- 10-6 Reference Table for the 16-segment Digital Keypad LED Display

10-1 Appearance of Keypad



10-2 The Backlight of the Keypad Panel



Green light: Standby Blue light: Run Red light: Alarm

10-3 Descriptions of Keypad Functions

Display	Descriptions
RUN BT PLC	Display the target pressure and the feedback pressure, and the pressure bar changes along with the percentage.
A Hz Bar kW rpm sec	Display station number. Master ID: M; Slave ID: 2–8
A Hz Bar kW rpm sec	Display the date.
A Hz Bar kW rpm sec	Display the time.
A Hz Bar kW rpm sec	Display the present frequency setting for the drive.
A Hz Bar kW rpm sec	Display the actual output frequency to the motor.
A Hz Bar kW rpm sec	Display the user-defined output of a physical quantity. This example uses Pr.00-04 = 30 (user-defined output).
A Hz Bar kW rpm sec	Display the load current.
A Hz Bar kW rpm sec	Forward command
A Hz Bar kW rpm sec	Reverse command
A Hz Bar kW rpm sec	Display a parameter item.
A Hz Bar kW rpm sec	Display a parameter value.
A Hz Bar kW rpm sec	Display an external fault.
A Hz Bar kW rpm sec	Display "End" for approximately one second if the data has been accepted and automatically stored in the register.
A Hz Bar kW rpm sec	Display if the setting data is not accepted or data value exceeds the allowed range.

10-4 Information Displayed on the Panel

1. Operation status: RUN / STOP

The RUN LED and the STOP LED light up according to the operation status of AC motor drive.

- The RUN LED lights up: It's in operation.
- The STOP LED lights up: It's not in operation.
- 2. Source of the RUN command: PLC / BT

The BT LED and the PLC LED light up according to the operation source of AC motor drive.

- BT LED: The BT LED lights up when the the AC motor drive and the bluetooth card are connected and they can communicate normally; the BT LED flashes when using mobile app to link with the bluetooth card.
- PLC LED: The PLC LED lights up when using PLC as RUN command. Sets the corresponding display according to the descriptions below.

PLC0: Not using PLC, the PLC LED does not light up.

PLC1: Switch ON PLC and it can operate, the PLC LED flashes.

PLC2: Switch ON PLC and it cannot operate, the PLC LED lights up.

3. Alarm: ERROR / WARN

When there is any fault or warning of AC motor drive, the ERROR / WARN LED lights up, and displays the fault code in main display area, the backlight becomes red at the same time.




Fault-ERROR LED lights up



Warn-WARN LED lights up

4. Pressure bar:

Displays the target pressure divided by the feedback pressure as a percentage, one square is 10%, increases from left to right, and rounds it to the nearest whole number. Refer to the schematic diagrams below.







Example 1: The target pressure can be divided with no remainder, the pressure bar displays the calculation directly.

• The target pressure is 10 bar, the present pressure is 5:

$$10 \div 10 = 1, 5 \div 1 = 5$$
 (squares)

Example 2: The target pressure cannot be divided with no remainder, the pressure bar displays the calculation which rounds to the nearest whole number.


- The target pressure is 15 bar, the present pressure is 8:
 15 ÷ 10 = 1.5, 8 ÷ 1.5 = 5.3 (squares), rounds it down to 5 (squares)
- The target pressure is 13 bar, the present pressure is 6:
 13 ÷ 10 = 1.3, 6 ÷ 1.3 = 4.6 (squares), rounds it down to 5 (squares)

5. Unit:


When select parameters, if the units can be displayed on keypad includes the unit of the parameter (such as A, Hz, Bar, kW, rpm, sec), then the LED of this unit lights up. If the unit of the parameter isn't included in the units mentioned above, then the unit does not display.

Example 1: Selects Pr.01-00 (Motor 1 maximum operation frequency), the setting range is 0.00–180.00 Hz.

Hz is the unit can be displayed on keypad, the display is as follows:




Example 2: Selects Pr.03-00 (Al1 analog input selection), the setting value is 5, the display is as follows:



10-5 Keypad Operation Process

1. Main Page Selection



Parameter setting



Note: In the parameter setting mode, you can press MODE to return to the previous layer.


Data adjustment



Rotation direction setting




Station number setting



2. F Page (Frequency command setting page)

Setting method



Normal mode


When the frequency exceeds the maximum operation frequency, the displayed value is locked at the upper value (e.g. Set Pr.01-00 = 150.00 Hz, the value is locked at 150.0).



3. Application Macro Selection Page

- Users can set common parameters quickly in this page. Use Pr.13-01–13-50 to define the common parameters. Set Pr.13-00 = 1, select APP page and enter User-defined page to set values for parameters.
- Once enabled, the Application Marco Selection page displays "APP". If Pr.13-00 = 0, the APP page does not display.
 - The description of Pr.13-00 setting is as follows:

 Pr.13-00 = 0 specifies the application selection is inactive and does not show on the display.




Pr.13-00 = 1 specifies a user-defined application, and the keypad displays "USEr".



If Pr.13-00 = 1 and you do not set any parameters for Pr.13-01–Pr.13-50, you cannot enter the sub-layer of the USEr page.

Follow the process below to set the user-defined application macro parameters (Pr.13-00=1).



- (1) Go to Parameter Group 13 to set the application macro functions. The application macro function is enabled when Pr.13-00 ≠ 0.
- (2) Set Pr.13-00 = 1 to enable the user-defined applications.

- (3) Use Pr.13-01–Pr.13-50 to set the user-defined parameters orderly according to your requirement. The default setting 0-00 means there is no user-defined parameter. Press ENTER to set the corresponding parameters for Pr.13-01– Pr.13-50.
- (4) The setting method of user-defined parameters is the same as that for non-user-defined parameters. You can use Up and Down keys or left shift key to speed up the settings.

 Note: You must set Pr.13-01, Pr.13-02, Pr.13-03, ...orderly, otherwise the display shows "Err".
- (5) If you want to change parameters which have been set before, you have to go back to Pr.13-01–13-50.
- (6) If you want to remove unused parameters which have been set before, you have to remove the parameters from the last one.
 - For example, if there are five user-defined parameters (Pr.13-01, 13-02...13-05), to remove Pr.13-02, you must remove Pr.13-05 first, then Pr.13-04, then Pr.13-03, and then Pr.13-02.
- (7) After finishing the setting, return to the APP page, and then press ENTER. The display shows "USEr". After you press ENTER again, the parameter you just set appears.

4. Parameter setting

(1) Unsigned parameters

(Parameter setting range ≥ 0; e.g. Pr.01-00)


- A. Without using the left shift key: Use Up and Left / Down key to select and adjust the parameters. Then, press ENTER to start the parameter settings.
- B. Using the left shift key: Long press MODE for two seconds until the last digit of the parameter value starts to blink. Increase the value by pressing the Up key. The value goes back to 0 after 9.
- C. Press left / down key to shift the blinking cursor one digit to the left, and increase the value by pressing the Up key.
- D. After you finish setting the parameter, the left shift key function is not disabled automatically until you disable it manually by pressing MODE for two seconds.
- E. The upper limit for Pr.01-00 is 180.00. If you set a value greater than 180.00, "Err" appears after you press ENTER, and then the keypad shows the upper limit (180.0) for a second to remind you of the incorrect setting. The setting value remains as the original set value (default is 150.00, which means the setting value is not changed), and the cursor returns to the last digit.
- (2) Minus-signed parameter setting status 1

(The parameter value is one decimal place or no decimal point, the range can be < 0; e.g. Pr.03-03)

- A. Without using the left shift key: Use Up and Left/Down key to select and adjust the parameters. Then, press ENTER to start the parameter settings.
- B. Using the left shift key: Long press MODE for two seconds until the last digit of the parameter value starts to blink. Increase the value by pressing the Up key. The value goes back to 0 after 9.

- C. Press the left / down key to shift the blinking cursor one digit to the left, and increase the value by pressing the Up key. When you shift to the first digit and press the Up key, the digit "0" changes to "-" (minus).
- D. After you finish setting the parameter, the left shift key function is not disabled automatically until you disable it manually by pressing MODE for two seconds.
- E. For parameter values with three digits and one decimal place (Pr.03-03, -100–100.00%), the display only shows three digits.

Example: The default of Pr.03-03 is 0.0. Long pressing MODE for two seconds enables the left shift function. The process for pressing the Left / Down key shows as follows:



(3) If the displayed value is over four digits and has directing character, displays a superscript point on keypad to remind the value is five digits.

Example:

Set Pr.00-04 = 31, Pr.00-05 = 100, and the present output frequency = 150.00 Hz, the display should show 15000 (= 150 x 100), but because of digit limitation, it shows K15•00.

10-6 Reference Table for the 16-segment Digital Keypad LED Display

Number	0	1	2	3	4	5	6	7	8	9
16-segment display		-		3	1-{	5	E	7		
Letter	Α	а	В	b	С	С	D	d	Е	е
16-segment display	F	_	X	b		£.		더		1
Letter	F	f	G	g	Н	h	I	i	J	j
16-segment display	F -	*		_	}-{	}-1	I	1		j
Letter	K	k	L	l	М	m	N	n	0	0
16-segment display	} {	_		_)\/\ 	_), ()**(
Letter	Р	р	Q	q	R	r	S	S	Т	t
16-segment display	ŗ.	_	L1		F7	J**	5	_		<u>}-</u>
Letter	U	u	V	٧	W	W	Х	Х	Υ	у
16-segment display		L	},′	L1	Ш	m	X	_		_
Letter	Z	Z								
16-segment display	7	_								

Chapter 11 Summary of Parameter Settings

- 00 Drive Parameters
- 01 Basic Parameters
- 02 Digital Input / Output Parameters
- 03 Analog Input / Output Parameters
- 04 Multi-Step Speed Parameters
- 05 Motor Parameters
- 06 Protection Parameters (1)
- 07 Special Parameters
- 08 High-function PID Parameters
- 09 Communication Parameters
- 10 Speed Feedback Control Parameters
- 11 Advanced Parameters
- 12 Function Parameters
- 13 Macro / User-defined Macro
- 14 Protection Parameters (2)

Chapter 11 Summary of Parameter Settings | MPD

This chapter provides a summary of parameters (Pr.) setting ranges and defaults You can set, change, and reset parameters through the digital keypad.

NOTE:

- 1. \mathcal{N} : You can set this parameter during operation.
- 2. Refer to chapter 12 for the details of parameters.

00 Drive Parameters

Pr.	Parameter Name	Settings	Default
		404: 460 V, 3 Phase, 1 HP	
		405: 460 V, 3 Phase, 2 HP	
		406: 460 V, 3 Phase, 3 HP	
		482: 460V, 3 Phase, 4 HP	
00-00		483: 460 V, 3 Phase, 5.5 HP	Read
	AC Motor Drive Identity Code	408: 460 V, 3 Phase, 7.5 HP	only
		409: 460 V, 3 Phase, 10 HP	Offig
		410: 460 V, 3 Phase, 15 HP	
		411: 460 V, 3 Phase, 20 HP	
		412: 460 V, 3 Phase, 25 HP	
		413: 460 V, 3 Phase, 30 HP	
00-01	AC Motor Drive Rated Current	Display by models	Read
00 01	Display	Diopidy by modelo	only
		0: No function	
		1: Write protection for parameters	
		5: Return kWh displays to 0	
		6: Reset PLC	
		8: Keypad does not respond	
		9: Reset all parameters to defaults (go back to IM V/F	
		control, base frequency is 50 Hz, carrier frequency	
00-02	Parameter Reset	is 15 kHz)	0
		10: Reset all parameters to defaults (go back to	
		PMSVC control, base frequency is 150 Hz, carrier	
		frequency is 4 kHz)	
		12: Reset all parameters to defaults (go back to	
		PMSVC control, base frequency is 150 Hz, carrier	
		frequency is 4 kHz, and preserve the user-defined	
		parameter values Pr.13-01-Pr.13-50)	
		0: F (frequency command)	
		1: H (output frequency)	
		2: U (user-defined) see Pr.00-04	
00-03	Start-up Display	3: A (output current)	4
		4: P (display the setting value and the feedback of PID	
		control)	
		0: Display output current from the drive to the motor	
00-04		(A) (Unit: Amp)	
		1: Display counter value (c) (Unit: CNT)	
	Content of Multi-function Display	2: Display the drive's actual output frequency (H.)	7
	(User-Defined)	(Unit: Hz)	
		3: Display the drive's DC bus voltage (v)	
		(Unit: V _{DC})	

Pr.	Parameter Name	Settings	Default
		4: Display the drive's output voltage (E) (Unit: V _{AC})	
		5: Display the drive's output power angle (n)	
		(Unit: deg)	
		6: Display the drive's output power (P) (Unit: kW)	
		7: Display the motor speed (r) (Unit: rpm)	
		10: Display PID feedback (b) (Unit: %)	
		11: Display Al1 analog input terminal signal (1.)	
		(Unit: %)	
		12: Display AI2 analog input terminal signal (2.)	
		(Unit: %)	
		14: Display the drive's IGBT temperature (i.)	
		(Unit: °C)	
		15: Display the drive's internal temperature (c.)	
		(Unit: ⁰C)	
		16: The digital input status (ON / OFF) (i)	
		17: The digital output status (ON / OFF) (o)	
		18: Display multi-step speed (S)	
		19: The corresponding CPU digital input pin status (d)	
		20: The corresponding CPU digital output pin status	
		(0.)	
		25: Overload count (0.00–100.00%) (o.) (Unit: %)	
		26: Ground Fault GFF (G.) (Unit: %)	
		27: DC bus voltage ripple (r.) (Unit: V _{DC})	
		28: Display PLC register D1043 data (C)	
		30: Display the output of User-defined (U)	
		31: Display Pr.00-05 user gain (K)	
		36: Present operating carrier frequency of the drive (J.)	
		(Unit: Hz)	
		38: AC motor drive status (6.)	
		41: kWh display (J) (Unit: kWh)	
		42: PID target value (h.) (Unit: %)	
		43: PID compensation (o.) (Unit: %)	
		44: PID output frequency (b.) (Unit: Hz)	
		49: Display the motor's temperature (M) (PTC-130,	
		PT100, KTY84-130)	
		51: PMSVC torque offset (T.)	
		60: Display the setting value and the feedback of PID	
		control (P)	
		65: Accumulated motor operation time (days) (r.)	
		112: Estimated flow rate (F) (Unit: m³/hr)	
		113: Display the inlet pressure (I) (Unit: according to	
		Pr.00-38 setting)	
		114: Display the outlet pressure (O) (Unit: according to	
		Pr.00-25 setting)	
		115: Cavitation detection index (V)	
00-05	Coefficient Gain in Actual Output	0.00–160.00	1.00
00-05	Frequency	0.00-100.00	1.00
00-06	Firmware Version	Read only	Read
00-00	i iiiiiwaie veisioii	Modu Offiy	only

	Pr.	Parameter Name	Settings	Default
*	00-07	Parameter Protection Password Input	0–65535 0–4 (the number of password attempts)	0
*	00-08	Parameter Protection Password Setting	0–65535 0: No password protection or password is entered correctly (Pr.00-07) 1: Password has been set	0
	00-11	Speed Control Mode	0: IMVF (IM V/F control) 2: PM SVC (PM space vector control)	If Pr.00- 02 = 9, then the default is 0; if Pr.00-02 = 10 or 12, then the default is 2
	00-17	Carrier frequency	2–15 kHz	4
	00-19	PLC Command Mask	Display value bit 0: Control command is forced by PLC control bit 1: Frequency command is forced by PLC control	Read only
*	00-20	Master frequency command source (AUTO, REMOTE)	 0: Digital keypad 1: RS-485 communication (COM1) 2: External analog input (Refer to Pr.03-00) 3: External UP / DOWN terminal (multi-function input terminals) 8: Communication card (does not include CANopen card) NOTE: HOA (Hand-Off-Auto) function is valid only when this parameter uses with MO function setting 42 and 56. 	0
*	00-21	Operation command source (AUTO, REMOTE)	O: Digital keypad 1: External terminals 2: RS-485 communication (COM1) 5: Communication card (does not include CANopen card) NOTE: HOA (Hand-Off-Auto) function is valid only when this parameter uses with MO function setting 42 and 56.	0
*	00-22	Stop method	0: Ramp to stop 1: Coast to stop	0
*	00-23	Motor direction control	0: Enable forward / reverse 1: Disable reverse 2: Disable forward	0
	00-24	Digital Operator (Keypad) Frequency Command Memory	Read only	Read only
*	00-25	User-defined Characteristics 1	bit 0–3: user-defined decimal places 0000h-0000b: no decimal place 0001h-0001b: one decimal place 0002h-0010b: two decimal places 0003h-0011b: three decimal places	353

Pr.	Parameter Name	Settings	Default
		bit 4–15: user-defined unit	
		000xh: Hz	
		001xh: rpm	
		002xh: %	
		003xh: kg/cm ²	
		004xh: m/s	
		005xh: kW	
		006xh: HP	
		007xh: ppm	
		008xh: 1/m	
		009xh: kg/s	
		00Axh: kg/m	
		00Bxh: kg/h	
		00Cxh: lb/s	
		00Dxh: lb/m	
		00Exh: lb/h	
		00Fxh: ft/s	
		010xh: ft/m	
		011xh: m	
		012xh: ft	
		013xh: degC	
		014xh: degF	
		015xh: mbar	
		016xh: bar	
		017xh: Pa	
		018xh: kPa	
		019xh: mWG	
		01Axh: inWG	
		01Bxh: ftWG	
		01Cxh: psi	
		01Dxh: atm	
		01Exh: L/s	
		01Fxh: L/m	
		020xh: L/h	
		021xh: m3/s	
		022xh: m3/h	
		023xh: GPM	
		024xh: CFM	
		xxxxh: Hz	
		0: No Function	
		0-65535 (when Pr.00-25 is set to no decimal place)	
		0.0-6553.5 (when Pr.00-25 is set to one decimal	
00-26	Maximum User-defined Value 1	place)	0
00-26	waxiinuin oser-ueiineu value I	0.00-655.35 (when Pr.00-25 is set to two decimal	
		places)	
		0.000-65.535 (when Pr.00-25 is set to three decimal	
		places)	
00-27	User-defined Value 1	Read only	Read
00-27	Oser-defilied value 1	Tread Offiy	only

	Pr.	Parameter Name	Settings	Default
	00-29	LOCAL / REMOTE Selection	 Standard HOA function When switching between local and remote, the drive stops. When switching between local and remote, the drive runs with REMOTE settings for frequency and operating status. When switching between local and remote, the drive runs with LOCAL settings for frequency and operating status. When switching between local and remote, the drive runs with LOCAL settings when switched to Local and runs with REMOTE settings when switched to Remote for frequency and operating status. 	0
*	00-30	Master frequency command source (HAND, LOCAL)	O: Digital keypad 1: RS-485 communication input 2: External analog input (Refer to Pr.03-00) 3: External UP / DOWN terminal (multi-function input terminals) 8: Communication card (does not include CANopen card) NOTE: HOA (Hand-Off-Auto) function is valid only when you use with MO function setting 41 and 56.	0
*	00-31	Operation Command Source (HAND, LOCAL)	0: Digital keypad 1: External terminals 2: RS-485 communication input 5: Communication card (does not include CANopen card) NOTE: HOA (Hand-Off-Auto) function is valid only when you use with MO function setting 41 and 56.	0
*	00-32	Digital Keypad STOP Function	0: STOP key disabled 1: STOP key enabled	0
	00-33	RPWM mode	0: Disable 1: RPWM mode 1 2: RPWM mode 2 3: RPWM mode 3	0
	00-34	RPWM carrier frequency variation	0.0–4.0 kHz	0.0
	00-38	User-defined Characteristics 2	bit 0–3: user-defined decimal places 0000h-0000b: no decimal place 0001h-0001b: one decimal place 0002h-0010b: two decimal places 0003h-0011b: three decimal places bit 4–15: user-defined unit 003xh: kg/cm² 015xh: mbar 016xh: bar 017xh: Pa 018xh: kPa 019xh: mWG	353

Chapter 11 Summary of Parameter Settings | MPD

	Pr.	Parameter Name	Settings	Default
			01Axh: inWG	
			01Bxh: ftWG	
			01Cxh: psi	
			01Dxh: atm	
			0: No Function	
			0-65535 (when Pr.00-25 is set to no decimal place)	
			0.0-6553.5 (when Pr.00-25 is set to one decimal	
	00.20	Maximum Hear defined Value 2	place)	0
	00-39	00-39 Maximum User-defined Value 2	0.00-655.35 (when Pr.00-25 is set to two decimal	0
			places)	
			0.000–65.535 (when Pr.00-25 is set to three decimal	
			places)	
	00-47	Motor Punning Direction Setting	0: Motor does not change running direction	0
*	00-47	Motor Running Direction Setting	1: Motor changes running direction	U
×	00-48	Display Filter Time (Current)	0.001-65.535 sec.	0.100
×	00-49	Display Filter Time (Keypad)	0.001-65.535 sec.	0.100
	00-50	Software Varaion (Data)	Dood only	Read
	00-30	Software Version (Date)	Read only	only
	00-61	DLC Software Version	Dood only	Read
	00-61	PLC Software Version	Read only	only
	00.00	DI C Coffinger Delegate Deta	Dandank	Read
	00-62	PLC Software Release Date	Read only	only

01 Basic Parameters

	Pr.	Parameter Name	Settings	Default
	01-00	Motor 1 Maximum Operation Frequency	0.00–599.00 Hz	150.00
	01-01	Motor 1 Rated / Base Frequency	0.00-599.00 Hz	150.00
	01-02	Motor 1 Rated / Base Voltage	0.0–510.0 V	380.0
	01-03	Motor 1 Mid-Point Frequency 1	0.00-599.00 Hz	3.00
×	01-04	Motor 1 Mid-Point Voltage 1	0.0–480.0 V	22.0
	01-05	Motor 1 Mid-Point Frequency 2	0.00-599.00 Hz	1.50
×	01-06	Motor 1 Mid-Point Voltage 2	0.0–480.0 V	10.0
	01-07	Motor 1 Minimum Output Frequency	0.00–599.00 Hz	0.50
×	01-08	Motor 1 Minimum Output Voltage	0.0~480.0 V	2.0
	01-09	Start-up Frequency	0.00-599.00 Hz	0.50
N	01-10	Output Frequency Upper Limit	0.00-599.00 Hz	599.00
N	01-11	Output Frequency Lower Limit	0.00-Pr.01-10 Hz	0.00
	04.40		Pr.01-45 = 0: 0.00-600.00 sec.	10.00
×	01-12	Acceleration Time 1	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
	04.40	Deceleration Time 4	Pr.01-45 = 0: 0.00-600.00 sec.	10.00
/	01-13	Deceleration Time 1	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
	04.44	A	Pr.01-45 = 0: 0.00-600.00 sec.	10.00
^	01-14	Acceleration Time 2	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
	04.45	D 1 " T 0	Pr.01-45 = 0: 0.00-600.00 sec.	10.00
/	01-15	Deceleration Time 2	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
	04.40	Associated Tree C	Pr.01-45 = 0: 0.00–600.00 sec.	10.00
*	01-16	Acceleration Time 3	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
.,	04.47	Decaleration Time 2	Pr.01-45 = 0: 0.00–600.00 sec.	10.00
*	01-17	Deceleration Time 3	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
	04 40	Acceleration Time 4	Pr.01-45 = 0: 0.00–600.00 sec.	10.00
*	01-18	Acceleration Time 4	Pr.01-45 = 1: 0.0-6000.0 sec.	10.0
	01 10	Deceleration Time 4	Pr.01-45 = 0: 0.00-600.00 sec.	10.00
^	01-19	Deceleration Time 4	Pr.01-45 = 1: 0.0-6000.0 sec.	10.0
	04 00	IOC A cooleration Time	Pr.01-45 = 0: 0.00–600.00 sec.	10.00
*	01-20	JOG Acceleration Time	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
,	01-21	JOG Deceleration Time	Pr.01-45 = 0: 0.00-600.00 sec.	10.00
~	01-21	TOO Decementation fille	Pr.01-45 = 1: 0.0-6000.0 sec.	10.0
×	01-22	JOG Frequency	0.00–599.00 Hz	6.00
~	01-23	First / Fourth Acceleration and Deceleration Frequency	0.00–599.00 Hz	0.00
,	04.04	S-curve Acceleration Begin Time	Pr.01-45 = 0: 0.00–25.00 sec.	0.20
*	01-24	1	Pr.01-45 = 1: 0.0–250.0 sec.	0.2
,	04.05	S-curve Acceleration Arrival Time	Pr.01-45 = 0: 0.00–25.00 sec.	0.20
*	01-25	2	Pr.01-45 = 1: 0.0–250.0 sec.	0.2
,	04.00	S-curve Deceleration Begin Time	Pr.01-45 = 0: 0.00–25.00 sec.	0.20
*	01-26	1	Pr.01-45 = 1: 0.0–250.0 sec.	0.2
	04.07	S-curve Deceleration Arrival	Pr.01-45 = 0: 0.00–25.00 sec.	0.20
/	01-27	Time 2	Pr.01-45 = 1: 0.0–250.0 sec.	0.2
	01-28	Skip Frequency 1 (Upper Limit)	0.00-599.00 Hz	0.00

Chapter 11 Summary of Parameter Settings | MPD

Pr.	Parameter Name	Settings	Default
01-29	Skip Frequency 1 (Lower Limit)	0.00–599.00 Hz	0.00
01-30	Skip Frequency 2 (Upper Limit)	0.00–599.00 Hz	0.00
01-31	Skip Frequency 2 (Lower Limit)	0.00–599.00 Hz	0.00
01-32	Skip Frequency 3 (Upper Limit)	0.00–599.00 Hz	0.00
01-33	Skip Frequency 3 (Lower Limit)	0.00–599.00 Hz	0.00
		0: Determined by Pr.01-00-01-08	
01-43	V/F Curve Selection	1: V/F curve to the power of 1.5	0
		2: V/F curve to the power of 2	
		0: Linear acceleration and deceleration	
		1: Auto-acceleration and linear deceleration	
01-44	Auto-Acceleration and Auto-	2: Linear acceleration and auto-deceleration	0
01-44	Deceleration Setting	3: Auto-acceleration and auto-deceleration	0
		4: Stall prevention by auto-acceleration and auto-	
		deceleration (limited by Pr.01-12-01-21)	
01 1E	Time Unit for Acceleration and	0: Unit 0.01 sec.	0
01-45	Deceleration and S-Curve	1: Unit 0.1 sec.	U

02 Digital Input / Output Parameters

Pr.	Parameter Name	Settings	Default
02-00	Two-wire / Three-wire Operation Control	0: No function 1: Two-wire mode 1, power ON for operation control (M1: FWD / STOP, M2: REV / STOP) 2: Two-wire mode 2, power ON for operation control (M1: RUN / STOP, M2: REV / FWD) 3: Three-wire, power ON for operation control (M1: RUN, M2: REV / FWD, M3: STOP) 4: Two-wire mode 1, Quick Start (M1: FWD / STOP, M2: REV / STOP) 5: Two-wire mode 2, Quick Start (M1: RUN / STOP, M2: REV / FWD) 6: Three-wire, Quick Start (M1: RUN, M2: REV / FWD, M3: STOP) IMPORTANT 1. In the Quick Start function, the output remains ready for operation. The drive responds to the Start command immediately. 2. When using Quick Start function, the output terminals UVW are with driving voltages in order to output and respond immediately if a Start command is given. Do NOT touch the terminals or modify the motor wiring to prevent electric shocks.	1
02-01	Multi-function Input Command 1 (MI1)	0: No Function 1: Multi-step speed command 1 / multi-step position	0
02-02	Multi-function Input Command 2 (MI2)	command 1 2: Multi-step speed command 2 / multi-step position	0
02-03	Multi-function Input Command 3 (MI3)	command 2 3: Multi-step speed command 3 / multi-step position	1
02-04	Multi-function Input Command 4 (MI4)	command 3 4: Multi-step speed command 4 / multi-step position	2
		command 4 5: Reset 6: JOG command 7: Acceleration / deceleration speed inhibit 8: 1st and 2nd acceleration / deceleration time selection 9: 3rd and 4th acceleration / deceleration time selection 10: External Fault (EF) input (Pr.07-20) 11: Base Block (B.B.) input from external 13: Cancel the setting of auto-acceleration / auto- deceleration time 15: Rotating speed command from Al1 16: Rotating speed command from Al2 18: Force to stop (Pr.07-20) 19: Digital up command	

	Pr.	Parameter Name	Settings	Default
			20: Digital down command	
			22: Clear the counter	
			23: Input the counter value (MI4)	
			24: FWD JOG command	
			25: REV JOG command	
			38: Disable writing EEPROM function	
			41: HAND switch	
			42: AUTO switch	
			51: Selection for PLC mode bit 0	
			52: Selection for PLC mode bit 1	
			56: Local / Remote selection	
			58: Enable fire mode (with RUN command)	
			59: Enable fire mode (without RUN command)	
			69: Enable preheating function	
			97: Multi-pump manual / auto switch	
			100: Enable clean function	
			0: UP / DOWN by the acceleration / deceleration time	
N	02-09	UP / DOWN Key Mode	1: UP / DOWN constant speed (Pr.02-10)	0
		Ţ	2: Pulse signal (Pr.02-10)	
-		Constant Consol Assolution /	3: External terminals UP / DOWN key mode	
	02-10	Constant Speed, Acceleration / Deceleration Speed of the UP /	0.001–1.000 Hz / ms	0.001
~	02-10	DOWN Key	0.001-1.00011271115	0.001
-		Multi-function Input Response		
×	02-11	Time	0.000–30.000 sec.	0.005
.,	00.40	Multi-function Input Mode	0000h FFFFh (0, N O , 4, N C)	0000
*	02-12	Selection	0000h–FFFFh (0: N.O.; 1: N.C.)	0000
×	02-13	Multi-function Output 1 (RY1)	0: No Function	11
×	02-14	Multi-function Output 2 (RY2)	1: Indication during RUN	0
×	02-16	Multi-function Output 3 (MO)	2: Operation speed reached	0
			3: Desired frequency reached 1 (Pr.02-22)	
			4: Desired frequency reached 2 (Pr.02-24)	
			7: Over-torque 1 (Pr.06-06-08)	
			9: Drive is ready	
			10: Low voltage warning (Lv) (Pr.06-00) 11: Malfunction indication	
			13: Overheat warning (Pr.06-15)	
			15: Abnormal PID feedback	
			17: Count value reached, does not return to 0	
			(Pr.02-20)	
			18: Count value reached, return to 0 (Pr.02-19)	
			19: External interrupt B.B. input (Base Block)	
			20: Warning output	
			21: Over-voltage	
			22: Over-current stall prevention	
			23: Over-voltage stall prevention	
			24: Operation source	
_			25: Forward command	

	Pr.	Parameter Name	Settings	Default
			26: Reverse command	
			29: Output when frequency ≥ Pr.02-34	
			30: Output when frequency < Pr.02-34	
			35: Error output selection 1 (Pr.06-23)	
			36: Error output selection 2 (Pr.06-24)	
			37: Error output selection 3 (Pr.06-25)	
			38: Error output selection 4 (Pr.06-26)	
			40: Speed reached (including STOP)	
			44: Low current output (use with Pr.06-71–Pr.06-73)	
			51: Analog output control for RS-485 interface	
			52: Output control for communication cards	
			53: Fire mode indication	
			67: Analog input level reached	
			69: Indication of preheating operation	
			75: Forward RUN status	
			76: Reverse RUN status	
-			81: Indication of multi-pump system error (only Master)	
*	02-18	Multi-function Output Direction	0000h–FFFFh (0: N.O.; 1: N.C.)	0000
*	02-19	Terminal Counting Value Reached (returns to 0)	0–65500	0
×	02-20	Preliminary Counting Value Reached (does not return to 0)	0–65500	0
×	02-22	Desired Frequency Reached 1	0.00–599.00 Hz	150.00
	00.00	The Width of the Desired	0.00 500 00 11	0.00
~ [02-23	Frequency Reached 1	0.00–599.00 Hz	2.00
*	02-24	Desired Frequency Reached 2	0.00–599.00 Hz	150.00
N	02-25	The Width of the Desired	0.00-599.00 Hz	2.00
	02 20	Frequency Reached 2		
	02-34	Output Frequency Setting for Multi-function Output Terminal	0.00-599.00 Hz	0.00
ŀ			0: Disabled	
			1: Drive runs if the RUN command remains after reset	
N	02-35	External Operation Control	or reboot.	0
·		Selection after Reset and Reboot	2: After re-powering ON, execute the drive according	
			to the operating status before it was OFF.	
Ī	00.50	Display the Status of Multi-	·	Read
	02-50	function Input Terminal	Monitor the status of the Multi-function Input Terminal	only
	02-51	Display the Status of Multi- function Output Terminal	Monitor the status of the Multi-function Output Terminal	Read only
		Display the External Multi-		
	02-52	function Input Terminals Used by	0–65535	0
		PLC		
	00.50	Display the External Multi-function	0.05505	_
	02-53	Output Terminals Used by PLC	0–65535	0
Ī		Display the Frequency		Bood
	02-54	Command Executed by External	Read only	Read
		Terminal		only
*	02-72	Preheating DC current level	0–100%	0

Chapter 11 Summary of Parameter Settings | MPD

Pr.	Parameter Name	Settings	Default
02-73	Preheating DC Current Duty	0–100%	0

03 Analog Input / Output Parameters

	Pr.	Parameter Name	Settings	Default
			0: No Function	
			1: Frequency command	
*	03-00	Al1 Analog Input Selection	4: PID target value	5
			5: PID feedback signal	
			6: Thermistor input value (PTC-130 / KTY-84-130)	
			11: PT100 thermistor input value	
			13: PID compensation value	
×	03-01	Al2 Analog Input Selection	21: Pressure inputs (outlet side)	0
			22: Pressure inputs (inlet side)	
			23: Flow inputs	
×	03-03	Al1 analog input bias	-100.0–100.0%	0
×	03-04	Al2 analog input bias	-100.0–100.0%	0
	03-07	Al1 Positive / Negative Bias		
_	03-07	Mode	0: No bias	0
	03-08	Al2 Positive / Negative Bias	4: Bias serves as the center	
^	03-00	Mode		
×	03-11	Al1 analog input gain	-500.0–500.0%	100.0
×	03-12	Al2 analog input gain	-500.0–500.0%	100.0
×	03-15	Al1 Analog Input Filter Time	0.00–20.00 sec.	0.01
×	03-16	Al2 Analog Input Filter Time	0.00–20.00 sec.	0.01
			0: Disabled	
~	03-19	Signal Loss Selection for Al1	1: Continue operation at the last frequency	0
,	00 10	Analog Input 4–20 mA	2: Decelerate to 0 Hz	
			3: Stop immediately and display ACE	
			0: Output frequency (Hz)	
			1: Frequency command (Hz)	
			2: Motor speed (Hz)	
			3: Output current (rms)	
			4: Output voltage	
	03-20	Multi function Quitnut (AFM)	5: DC bus voltage 6: Power factor	
/	03-20	Multi-function Output (AFM)	7: Power	0
			9: Al1 analog input	
			10: Al2 analog input	
			21: RS-485 analog output	
			22: Communication card analog output	
			23: Constant voltage output	
N	03-21	AFM Analog Output Gain	0–500.0%	100.0
,	 ·		0: Absolute value in output voltage	133.0
N	03-22	AFM Analog Output in REV	1: Reverse output 0 V; forward output 0–10 V	0
		Direction	2: Reverse output 5-0 V; forward output 5–10 V	
N	03-27	AFM Output Bias	-100.00–100.00%	0.00
			0: 0–10 V	
×	03-28	Al1 Terminal Input Selection	1: 0–20 mA	2
′			2: 4–20 mA	

	Pr.	Parameter Name	Settings	Default
			0: 0–10 V	
	03-29	Al2 Terminal Input Selection	1: 0–20 mA	2
			2: 4–20 mA	
	00.00	PLC Analog Output Terminal	bit 0: Reserved	0
×	03-30	Status	bit 1: AFM	0
×	03-32	AFM DC Output Setting Level	0.00-100.00%	0.00
×	03-35	AFM Output Filter Time	0.00-20.00 sec.	0.01
	00.44	Multi-function Output (MO) by AI	0: Al1	
×	03-44	Level Source	1: Al2	0
×	03-45	Al1 Upper Level 1	-100.00–100.00%	50
×	03-46	Al1 Lower Level 2	-100.00–100.00%	10
×	03-47	Al2 Upper Level 1	-100.00–100.00%	50
×	03-48	Al2 Lower Level 2	-100.00–100.00%	10
			0: Normal curve	
×	03-50	Analog Input Curve Selection	1: Three-point curve of AI1	0
			2: Three-point curve of AI2	
			Pr.03-28 = 0.00–10.00 V	
×	03-51	Al1 Lowest Point	Pr.03-28 =1, 0.00–20.00 mA	4.00
			Pr.03-28 =2, 4.00–20.00 mA	
×	03-52	Al1 Proportional Lowest Point	0.00-100.00%	0.00
			Pr.03-28 = 0.00–10.00 V	
×	03-53	Al1 Mid-point	Pr.03-28 =1, 0.00–20.00 mA	12.00
			Pr.03-28 =2, 4.00–20.00 mA	
×	03-54	Al1 Proportional Mid-point	0.00-100.00%	50.00
			Pr.03-28 = 0, 0.00–10.00 V	
×	03-55	Al1 Highest Point	Pr.03-28 =1, 0.00–20.00 mA	20.00
			Pr.03-28 =2, 4.00–20.00 mA	
×	03-56	Al1 Proportional Highest Point	0.00-100.00%	100.00
			Pr.03-29 = 0, 0.00–10.00 V	
×	03-57	Al2 Lowest Point	Pr.03-29 =1, 0.00–20.00 mA	4.00
			Pr.03-29 =2, 4.00–20.00 mA	
×	03-58	Al2 Proportional Lowest Point	0.00-100.00%	0.00
			Pr.03-29 = 0, 0.00–10.00 V	
×	03-59	Al2 Mid-point	Pr.03-29 =1, 0.00–20.00 mA	12.00
			Pr.03-29 =2, 4.00–20.00 mA	
×	03-60	Al2 Proportional Mid-point	0.00-100.00%	50.00
			Pr.03-29 = 0, 0.00–10.00 V	
×	03-61	Al2 Highest Point	Pr.03-29 =1, 0.00–20.00 mA	20.00
			Pr.03-29 =2, 4.00–20.00 mA	
×	03-62	Al2 Proportional Highest Point	0.00-100.00%	100.00
			0: Disabled	
.	03-69	Signal Loss Selection For Al2	1: Continue operation at the last frequency	0
~	03-08	Analog Input 4-20 mA	2: Decelerate to 0 Hz	
			3: Stop immediately and display ACE	

04 Multi-Step Speed Parameters

Pr.04-50 to Pr.04-99 listed below are the settings when built-in PLC function is ON. If the built-in PLC function is not loaded into the drive, Pr.04-50 to Pr.04-99 are PLC buffer 0 to PLC buffer 50, and the setting range is 0–65535, the default is 0.

But if the built-in PLC function is loaded into the drive, see the explanation below:

	Pr.	Parameter Name	Settings	Default
×	04-00	1st Step Speed Frequency	0.00-599.00 Hz	0.00
×	04-01	2nd Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-02	3rd Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-03	4th Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-04	5th Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-05	6th Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-06	7th Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-07	8th Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-08	9th Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-09	10th Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-10	11th Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-11	12th Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-12	13th Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-13	14th Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-14	15th Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-50	PLC Buffer 0	0–65535	0
×	04-51	PLC Buffer 1	0–65535	0
×	04-52	PLC Buffer 2	0–65535	0
×	04-53	PLC Buffer 3	0–65535	0
×	04-54	PLC Buffer 4	0–65535	0
×	04-55	PLC Buffer 5	0–65535	0
×	04-56	PLC Buffer 6	0–65535	0
*	04-57	Pump System Configuration Setting	bit 0–3, source of frequency 00x0h: Digital keypad 00x1h: RS-485 communication (COM2) 00x8h: Communication card (does not include CANopen card) bit 4–7, source of operation 000xh: Digital keypad 001xh: RS-485 communication (COM2) 002xh: External terminals (MI1) 005xh: Communication card (does not include CANopen card) bit 8, set to be the backup master bit 9, display a PL00 warning when the backup master becomes the master.	0
*	04-58	Weekdays, weekend, specific day schedule	bit 0: 1 (duty day) bit 1: 1 (weekend) bit 2: 1 (specific date)	0
×	04-59	Weekend Setting	0: Saturday, Sunday 1: Sunday	0

	Pr.	Parameter Name	Settings	Default
N	04-60	Duty day start time 1	00:00~23:59	00:00
×	04-61	Duty day set point pressure 1	0–65535	0
×	04-62	Duty day start time 2	00:00~23:59	00:00
×	04-63	Duty day set point pressure 2	0–65535	0
×	04-64	Duty day start time 3	00:00~23:59	00:00
×	04-65	Duty day set point pressure 3	0–65535	0
×	04-66	Duty day start time 4	00:00~23:59	00:00
×	04-67	Duty day set point pressure 4	0–65535	0
×	04-68	Duty day start time 5	00:00~23:59	00:00
×	04-69	Duty day set point pressure 5	0–65535	0
×	04-70	Weekend start time 1	00:00~23:59	00:00
×	04-71	Weekend set point pressure 1	0–65535	0
×	04-72	Weekend start time 2	00:00~23:59	00:00
×	04-73	Weekend set point pressure 2	0–65535	0
×	04-74	Weekend start time 3	00:00~23:59	00:00
×	04-75	Weekend set point pressure 3	0–65535	0
×	04-76	Weekend start time 4	00:00~23:59	00:00
×	04-77	Weekend set point pressure 4	0–65535	0
×	04-78	Weekend start time 5	00:00~23:59	00:00
×	04-79	Weekend set point pressure 5	0–65535	0
×	04-80	Specific date start date 1	MM.DD (MM = month, 01–12; DD = date, 01–31)	00.00
×	04-81	Specific Day End Date 1	MM.DD (MM = month, 01–12; DD = date, 01–31)	00.00
×	04-82	Specific date start date 2	MM.DD (MM = month, 01–12; DD = date, 01–31)	00.00
×	04-83	Specific Day End Date 2	MM.DD (MM = month, 01–12; DD = date, 01–31)	00.00
×	04-84	Specific date start date 3	MM.DD (MM = month, 01–12; DD = date, 01–31)	00.00
×	04-85	Specific Day End Date 3	MM.DD (MM = month, 01–12; DD = date, 01–31)	00.00
×	04-86	Specific date start date 4	MM.DD (MM = month, 01–12; DD = date, 01–31)	00.00
×	04-87	Specific Day End Date 4	MM.DD (MM = month, 01–12; DD = date, 01–31)	00.00
×	04-88	Specific date start date 5	MM.DD (MM = month, 01–12; DD = date, 01–31)	00.00
×	04-89	Specific Day End Date 5	MM.DD (MM = month, 01–12; DD = date, 01–31)	00.00
×	04-90	Specific date start time 1	00:00~23:59	00:00
×	04-91	Specific date set point pressure 1	0–65535	0
×	04-92	Specific date start time 2	00:00~23:59	00:00
×	04-93	Specific date set point pressure 2	0–65535	0
×	04-94	Specific date start time 3	00:00~23:59	00:00
×	04-95	Specific date set point pressure 3	0–65535	0
×	04-96	Specific date start time 4	00:00~23:59	00:00
×	04-97	Specific date set point pressure 4	0–65535	0
×	04-98	Specific date start time 5	00:00~23:59	00:00
×	04-99	Specific date set point pressure 5	0–65535	0

05 Motor Parameters

	Pr.	Parameter Name	Settings	Default
	05-00	Motor Parameter Auto-tuning	0: No Function 5: Rolling auto-tuning for motor	0
-			13: High frequency stall test for motor	
				Depend
	05-01	Full-Load Current for Induction	10–120% of the drive's rated current	on the
		Motor 1 (A)		model
-				power
				Depend
~	05-02	Rated Power for Induction Motor	0.00-655.35 kW	on the
	00 02	1 (kW)	0.00 000.00 KW	model
				power
				Depend
		Rated Speed for Induction Motor	0-xxxxx rpm (Depend on the motor's number of	on the
*	05-03	1 (rpm)	poles)	motor's
		i (ipiii)	1710 (60 Hz 4 poles); 1410 (50 Hz 4 poles)	number
				of poles
	05-04	Number of Poles for Induction Motor 1	2–20	4
				Depend
	05-05	No-Load Current for Induction	0.00-Pr.05-01 default	on the
	05-05	Motor 1 (A)		model
_				power
				Depend
	05-06	Stator Resistance (Rs) for Induction Motor 1	0.000 – $65.535~\Omega$	on the
	03-00			model
				on the
	05-07	Rotor Resistance (Rr) for	$0.000-65.535~\Omega$	0.000
-	05-07	Induction Motor 1	0.000-03.333 \$2	0.000
	05-08	Magnetizing Inductance (Lm) for Induction Motor 1	0.0-6553.5 mH	0.0
Ī	05.00	Stator Inductance (Lx) for	0.0 CEE2 E mU	Depend on the model power Depend on the motor's number of poles 4 Depend on the model power O.000
	05-09	Induction Motor 1	0.0–6553.5 mH	0.0
×	05-26	Motor Accumulated Watt in Every Millisecond (W-msec.)	Read only	0.0
	05-27	Motor Accumulated Watt in Every Second (W-sec.)	Read only	0.0
,	05.00	Motor Accumulated Watt In	Backet	0.0
×	05-28	Every Hour (W-hour)	Read only	0.0
ļ	05.00	Motor Accumulated Kilowatt in	Deed only	0.0
	05-29	Every Hour (kW-hour)	Read only	0.0
ŀ	05.00	Motor Accumulated Megawatt in	Decited.	0.0
	05-30	Every Hour (MW-hour)	Read only	0.0
ļ	05.01	Accumulated Motor Operation	0.4400	_
	05-31	Time (minutes)	0–1439	U
	05.20	Accumulated Motor Operation	0.65525	
	05-32	Time (days)	0–65535	U

Chapter 11 Summary of Parameter Settings | MPD

Pr.	Parameter Name	Settings	Default
05-33	Induction Motor (IM) or Permanent Magnet Synchronous AC Motor (PM) Selection	O: IM (Induction motor) 1: SPM (Surface permanent magnet synchronous AC motor) 2: IPM (Interior permanent magnet synchronous AC motor) Delta MSI series motor	3
05-34	Motor Full-load Current	0–120% of the drive's rated current	#.#
05-35	Motor Rated Power	0.00–655.35 kW	#.#
05-36	Motor Rated Speed	0–65535 rpm	3000
05-37	Number of Poles for A Motor	0–65535	Differs from models (6 / 8)
05-39	Stator Resistance for A Motor	0.000 – 65.535Ω	0.000
05-40	Motor Ld	0.00-655.35 mH	0.00
05-41	Motor Lq	0.00-655.35 mH	0.00
05-43	Ke Parameter of a Motor	0.0–6553.5 V/krpm	0

06 Protection Parameters (1)

	Pr.	Parameter Name	Settings	Defaul t
×	06-00	Low Voltage Level	300.0-440.0 V _{DC}	360.0
*	06-01	Over-voltage Stall Prevention	0: No Function 0.0–900.0 V _{DC}	760.0
*	06-02	Selection for Over-voltage Stall Prevention	Traditional over-voltage stall prevention Smart over-voltage stall prevention	0
*	06-03	Over-current Stall Prevention during Acceleration	Normal duty: 0–150% (100% corresponds to the rated current of the drive)	120
*	06-04	Over-current Stall Prevention during Operation	Normal duty: 0–150% (100% corresponds to the rated current of the drive)	120
*	06-05	Acceleration / Deceleration Time Selection for Stall Prevention at Constant Speed	0: By current acceleration / deceleration time 1: By the first acceleration / deceleration time 2: By the second acceleration / deceleration time 3: By the third acceleration / deceleration time 4: By the fourth acceleration / deceleration time 5: By auto-acceleration / auto-deceleration	0
*	06-06	Over-torque Detection Selection (Motor 1)	O: No function 1: Continue operation after over-torque detection during constant speed operation 2: Stop after over-torque detection during constant speed operation 3: Continue operation after over-torque detection during RUN 4: Stop after over-torque detection during RUN	0
*	06-07	Over-torque detection level (motor 1)	10-250% (100% corresponds to the rated current of the drive)	120
*	06-08	Over-torque Detection Time (Motor 1)	0.0–60.0 sec.	0.1
*	06-13	Electronic Thermal Relay Selection 1 (Motor 1)	Standard motor (motor with fan on the shaft) Disabled	2
*	06-14	Electronic Thermal Relay Action Time 1 (Motor 1)	30.0–600.0 sec.	60.0
*	06-15	Temperature Level Overheat (OH) Warning	0.0-110.0°C	105.0
*	06-16	Stall Prevention Limit Level (Weak Magnetic Field Current Stall Prevention Level)	0-100% (Refer to Pr.06-03)	100
	06-17	Fault Record 1	0: No fault record	0
	06-18	Fault Record 2	1: Over-current during acceleration (ocA)	0
	06-19	Fault Record 3	2: Over-current during deceleration (ocd)	0
	06-20	Fault Record 4	Over-current during steady operation (ocn) Ground fault (GFF)	0
	06-21	Fault Record 5	6: Over-current at stop (ocS)	0
	06-22	Fault Record 6	7: Over-voltage during acceleration (ovA)	0
		Fault Record 7 (Pr.14-70)	8: Over-voltage during deceleration (ovd) 9: Over-voltage during constant speed (ovn) 10: Over-voltage at stop (ovS)	

Pr.	Parameter Name	Settings	Defaul t
	Fault Record 8	11: Low-voltage during acceleration (LvA)	
	(Pr.14-71)	12: Low-voltage during deceleration (Lvd)	
	Fault Record 9	13: Low-voltage at constant speed (Lvn)	
	(Pr.14-72)	14: Low-voltage at stop (LvS)	
	Fault Record 10	15: Phase loss protection (orP)	
	(Pr.14-73)	16: IGBT overheating (oH1)	
		17: Heatsink overheating (oH2)	
		18: IGBT temperature detection failure (tH1o)	
		19: Capacitor hardware error (tH2o)	
		21: Over load (oL)	
		22: Electronics thermal relay 1 protection (EoL1)	
		24: Motor overheating (PTC-130 / KTY-84-130 / PT100)(oH3)	
		26: Over torque 1 (ot1)	
		28: Under current (uC)	
		31: EEPROM read error (cF2)	
		33: U-phase error (cd1)	
		34: V-phase error (cd2)	
		35: W-phase error (cd3)	
		36: cc hardware error (Hd0)	
		37: oc hardware error (Hd1)	
		40: Auto-tuning error (AUE)	
		41: PID loss ACI (AFE)	
		48: ACI loss (ACE)	
		49: External fault (EF)	
		51: External base block (bb)	
		52: Password is locked (Pcod)	
		54: Illegal command (CE1)	
		55: Illegal data address (CE2)	
		56: Illegal data value (CE3)	
		57: Data is written to read-only address (CE4)	
		58: Modbus transmission time-out (CE10)	
		79: U-phase over-current before run (Aoc)	
		80: V-phase over-current before run (boc)	
		81: W-phase over-current before run (coc)	
		82: U-phase output phase loss (oPL1)	
		83: V-phase output phase loss (oPL2)	
		84: W-phase output phase loss (oPL3)	
		87: Low frequency overload protection (oL3)	
		89: Rotor position detection error (roPd)	
		90: Force to stop (FStp)	
		98: Fire mode output (Fire)	
		140: oc hardware error (Hd6)	
		141: GFF occurs before run (b4GFF)	
		142: Auto-tune error 1 (AuE1) (DC test stage)	
		143: Auto-tune error 2 (AuE2) (high frequency stall	
		stage)	
		144: Auto-tune error 3 (AuE3) (rotation test stage)	

	Pr.	Parameter Name	Settings	Defaul t
•			221: High water pressure (HPS)	
			222: Low water pressure (LPSE)	
			223: Dry pump (dryE)	
			224: Water leaking (pipe explosion) (LEKE)	
			225: Clogged pipe (JAME)	
			226: RTC error (rtF)	
			227: Dry pump curve auto-measuring (dAUE)	
×	06-23	Fault Output Option 1	0-65535 (refer to bit table for fault code)	0
×	06-24	Fault Output Option 2	0-65535 (refer to bit table for fault code)	0
×	06-25	Fault Output Option 3	0-65535 (refer to bit table for fault code)	0
×	06-26	Fault Output Option 4	0–65535 (refer to bit table for fault code)	0
			0: Warn and continue operation	
	00.00	PTC-130 / KTY84-130 / PT100	1: Fault and ramp to stop	
*	06-29	Action	2: Fault and coast to stop	0
			3: No warning	
×	06-30	PTC-130 / KTY84-130 Level	0.0–100.0%	50.0
		Frequency Command at		Read
	06-31	Malfunction	0.00–599.00 Hz	only
•				Read
	06-32	Output Frequency at Malfunction	0.00–599.00 Hz	only
				Read
	06-33	Output Voltage at Malfunction	0.0–6553.5 V	only
				Read
	06-34	DC bus Voltage at Malfunction	0.0–6553.5 V	only
•				Read
	06-35	Output Current at Malfunction	0.00–655.35 Amps	only
				Read
	06-36	IGBT Temperature at Malfunction	0.0-6553.5°C	only
				Read
	06-38	Motor Speed at Malfunction	0–65535 rpm	only
				Read
	06-39	Torque Command at Malfunction	-32768–32767	only
		Status of the Multi-function Input		Read
	06-40	Terminal at Malfunction	0000h-FFFFh	only
	00.00	Status of the Multi-function		Read
	06-41	Output Terminal at Malfunction	0000h-FFFFh	only
		-		Read
	06-42	Drive Status at Malfunction	0000h-FFFFh	only
			0: Warn and continue operation	
	00.1=	Output Phase Loss Detection	1: Fault and ramp to stop	
×	06-45	Action (OPHL)	2: Fault and coast to stop	3
		, ,	3: No warning	
,	06-46	Detection Time for Output Phase	0.000–65.535 sec.	0.500
~	00-40	Loss	0.000-00.000 300.	0.500
*	06-47	Current Detection Level for Output Phase Loss	0.00-100.00%	1.00

	Pr.	Parameter Name	Settings	Defaul t
*	06-48	DC Brake Time for Output Phase Loss	0.000-65.535 sec.	0.000
*	06-49	LvX Auto-reset	0: Disabled 1: Enabled	0
*	06-53	Input Phase Loss Detection Action (OrP)	O: Fault and ramp to stop 1: Fault and coast to stop	0
*	06-55	Derating Protection	 0: Constant rated current and limit carrier frequency by load current and temperature 1: Constant carrier frequency and limit load current by setting carrier frequency 2: Constant rated current (same as setting 0), but close current limit 	0
N	06-56	PT100 Voltage Level 1	0.000–10.000 V	5.000
N	06-57	PT100 Voltage Level 2	0.000–10.000 V	7.000
×	06-58	PT100 Level 1 Frequency Protection	0.00–599.00 Hz	0.00
*	06-59	PT100 Activation Level 1 Protection Frequency Delay Time	0–6000 sec.	60
*	06-60	Software Detection GFF Current Level	0.0–6553.5%	60.0
*	06-61	Software Detection GFF Filter Time	0.00-655.35 sec.	0.10
	06-63	Operation Time of Fault Record 1 (Day)	0–65535 days	Read only
	06-64	Operation Time of Fault Record 1 (Min.)	0–1439 min.	Read only
	06-65	Operation Time of Fault Record 2 (Day)	0–65535 days	Read only
	06-66	Operation Time of Fault Record 2 (Min.)	0–1439 min.	Read only
	06-67	Operation Time of Fault Record 3 (Day)	0–65535 days	Read only
	06-68	Operation Time of Fault Record 3 (Min.)	0–1439 min.	Read only
	06-69	Operation Time of Fault Record 4 (Day)	0–65535 days	Read only
	06-70	Operation Time of Fault Record 4 (Min.)	0–1439 min.	Read only
N	06-71	Low Current Setting Level	0.0–100.0%	0.0
N	06-72	Low Current Detection Time	0.00-360.00 sec.	0.00
*	06-73	Low Current Action	0: No Function1: Fault and coast to stop2: Fault and ramp to stop by the 2nd deceleration time3: Warn and continue operation	0
	06-80	Fire Mode	0: Disabled1: Forward operation (counterclockwise)2: Reverse operation (clockwise)	0

Chapter 11 Summary of Parameter Settings | MPD

Pr.	Parameter Name	Settings	Defaul t
06-81	Operating Frequency in Fire Mode	0.00–180.00 Hz	150.00
06-86	РТС Туре	0: PTC-130 1: KTY84-130	0
06-88	Operation Times in Fire Mode	0–65535 times	Read only
06-90	Operation Time of Fault Record 5 (Day)	0–65535 days	Read only
06-91	Operation Time of Fault Record 5 (Min.)	0–1439 min.	Read only
06-92	Operation Time of Fault Record 6 (Day)	0–65535 days	Read only
06-93	Operation Time of Fault Record 6 (Min.)	0–1439 min.	Read only

07 Special Parameters

	Pr.	Parameter Name	Settings	Default
×	07-01	DC Brake Current Level	0–100%	0
N	07-02	DC Brake Time At Start-up	0.0-60.0 sec.	0.0
N	07-03	DC Brake Time at STOP	0.0-60.0 sec.	0.0
×	07-05	Voltage Increasing Gain	1–200%	100
×	07-06	Restart After Momentary Power Loss	Stop operation Speed tracking by the speed before the power loss	0
N	07-07	Allowed Power Loss Duration	0.0–20.0 sec.	2.0
N	07-08	Base Block Time	0.1–5.0 sec.	0.5
N	07-09	Current Limit of Speed Tracking	20–200%	100
×	07-10	Restart after Fault Action	Stop operation Speed tracking by current speed	0
*	07-11	Number of Times of Restart After Fault	0–10	0
×	07-12	Speed Tracking During Start-up	O: No function 1: Speed tracking by the maximum output frequency 2: Speed tracking by the current frequency command at start-up 3: Speed tracking by the minimum output frequency	0
	07-19	Fan Cooling Control	 0: Fan is always ON 1: Fan is OFF after the AC motor drive stops for one minute. 2: Fan is ON when the AC motor drive runs; fan is OFF when the AC motor drive stops 3: Fan turns ON when temperature (IGBT) reaches around 60°C. 	3
*	07-20	Emergency Stop (EF) & Force to Stop Selection	0: Coast to stop 1: Stop by the first deceleration time 2: Stop by the second deceleration time 3: Stop by the third deceleration time 4: Stop by the fourth deceleration time 5: System deceleration 6: Automatic deceleration	0
*	07-21	Automatic Energy Saving (AES) Setting	Disabled 1: AES optimization (for VF, SVC control modes)	0
*	07-23	Automatic Voltage Regulation (AVR) Function	O: Enable AVR 1: Disable AVR 2: Disable AVR during deceleration	0
N	07-24	Torque Command Filter Time	0.001-10.000 sec.	0.050
N	07-25	Slip Compensation Filter Time	0.0001-10.000 sec.	0.100
N	07-26	Torque Compensation Gain	0–5000	1
*	07-27	Slip Compensation Gain	0.00-10.00	0.00 Default value is 1.00 in SVC mode)
*	07-29	Slip Deviation Level	0.0–100.0% 0: No detection	0

Chapter 11 Summary of Parameter Settings | MPD

	Pr.	Parameter Name	Settings	Default
×	07-30	Over-Slip Deviation Detection Time	0.0–10.0	1.0
*	07-31	Over-Slip Deviation Treatment	0: Warn and continue operation1: Fault and ramp to stop2: Fault and coast to stop3: No warning	0
*	07-32	Motor Oscillation Compensation Factor	0–10000	1000
×	07-33	Auto-restart Interval of Fault	0.0–6000.0	60.0
	07-35	Status Record When the Drive Is Powered Off	0–65535	Read only
*	07-36	Restart Delay Time after Power Off	1–10 sec.	5
	07-38	Voltage Feed Forward Gain	0.50-2.00	1.00
×	07-41	AES Minimum Frequency	0.00–40.00 Hz	10.00
×	07-42	AES Delay Time	0–600 sec.	5
×	07-44	AES Maximum Voltage Drop	0.00-70.00%	60.00
×	07-45	AES Coefficient	0–10000%	100
×	07-82	AES Kp Gain	0–65535 pu	500
×	07-83	AES Ki Gain	0–65535 pu	500

08 High-function PID Parameters

	Pr.	Parameter Name	Settings	Default
	00.00	Terminal selection of PID	0: No Function	0
×	08-00	feedback	1: Negative PID feedback: by analog input (Pr.03-00)	0
	00 01	Proportional gain (P)	0.0-500.0 (when Pr.08-23 set bit1 = 0)	1.00
_	08-01	Proportional gain (P)	0.00-5000.0 (when Pr.08-23 set bit1 = 1)	1.00
×	08-02	Integral Time (I)	0.00-100.00 sec.	1.00
×	08-03	Differential Time (D)	0.00-1.00 sec.	0.00
×	08-04	Upper Limit of Integral Control	0.0–100.0%	100.0
×	08-05	PID Output Command Limit (Positive Limit)	0.0–100.0%	100.0
×	08-08	Feedback Signal Detection Time	0.0–3600.0 sec.	0.0
			0: Warn and continue operation	
	08-09	Treatment of Feedback Signal	1: Fault and ramp to stop	0
_	00-09	08-09 Treatment of Feedback Signal	2: Fault and coast to stop	
			3: Warn and operate at last frequency	
	08-20	PID Mode Selection	0: Serial connection	0
	00-20	1 1D Wode Gelection	1: Parallel connection	
~	08-23	PID Control Flag	bit 1 = 1, two decimal places for PID Kp	2
^	00 20	T ID Control Flag	bit 1 = 0, one decimal place for PID Kp	
		08-55 PID Feedback Mathematics	0: Al1	
			1: Al1 + k*Al2	
			2: Al1 - k*Al2	
			3: Al1 * k*Al2	
			4: Al1 / k*Al2	
			5: MIN(AI1, AI2)	
			6: MAX(AI1, AI2)	
N	08-55		7: AVE(AI1, AI2)	0
,			8: sqrt(Al1)	
			9: sqrt(Al1 – Al2)	
			10: sqrt(Al1 + Al2)	
			11: sqrt(Al1) + sqrt(Al2)	
			12: k * sqrt(Al1)	
			13: k * sqrt(Al1 – Al2)	
			14: (Al1 - Al2) ²	
			15: (Al1) ² + (Al2) ²	
×	08-56	PID Feedback Mathematics Gain	-300.0–300.0	1.0
N	08-57	PID Feedback Mathematics	0–999	0
		Upper Limit		

09 Communication Parameters

	Pr.	Parameter Name	Settings	Default
×	09-00	Communication Address	1–254	1
×	09-01	COM1 Transmission Speed	4.8–115.2 Kbps	115.2
			0: Warn and continue operation	
	00.00	COM1 Transmission Fault	1: Fault and ramp to stop	
×	09-02	Treatment	2: Fault and coast to stop	3
			3: No warning, no fault, and continue operation	
×	09-03	COM1 Time-out Detection	0.0-100.0 sec.	0.0
			1: 7, N, 2 (ASCII)	
			2: 7, E, 1 (ASCII)	
			3: 7, O, 1 (ASCII)	
			4: 7, E, 2 (ASCII)	
			5: 7, O, 2 (ASCII)	
			6: 8, N, 1 (ASCII)	
			7: 8, N, 2 (ASCII)	
			8: 8, E, 1 (ASCII)	
×	09-04	COM1 Communication Protocol	9: 8, O, 1 (ASCII)	12
			10: 8, E, 2 (ASCII)	
			11: 8, O, 2 (ASCII)	
			12: 8, N, 1 (RTU)	
			13: 8, N, 2 (RTU)	
			14: 8, E, 1 (RTU)	
			15: 8, O, 1 (RTU)	
			16: 8, E, 2 (RTU)	
			17: 8, O 2 (RTU)	
×	09-05	COM2 Transmission Speed	4.8–115.2 Kbps	9.6
			0: Warn and continue operation	
N	09-06	COM2 Transmission Fault	1: Fault and ramp to stop	3
,		Treatment	2: Fault and coast to stop	
			3: No warning, no fault, and continue operation	
×	09-07	COM2 Time-out Detection	0.0–100.0 sec.	0.0
			1: 7, N, 2 (ASCII)	
			2: 7, E, 1 (ASCII)	
			3: 7, O, 1 (ASCII)	
			4: 7, E, 2 (ASCII)	
			5: 7, O, 2 (ASCII)	
			6: 8, N, 1 (ASCII)	
			7: 8, N, 2 (ASCII)	
	00.00	OOMO O	8: 8, E, 1 (ASCII)	4
×	09-08	COM2 Communication Protocol	9: 8, O, 1 (ASCII)	1 1
			10: 8, E, 2 (ASCII)	
			11: 8, O, 2 (ASCII)	
			12: 8, N, 1 (RTU)	
			13: 8, N, 2 (RTU)	
			14: 8, E, 1 (RTU)	
			15: 8, O, 1 (RTU)	
			16: 8, E, 2 (RTU)	
			17: 8, O 2 (RTU)	

	Pr.	Parameter Name	Settings	Default
*	09-09	Communication Response Delay Time	0.0–200.0 ms	2.0
	09-10	Communication Main Frequency	0.00-599.00 Hz	150.00
N	09-11	Block Transfer 1	0–65535	0
N	09-12	Block Transfer 2	0–65535	0
N	09-13	Block Transfer 3	0–65535	0
N	09-14	Block Transfer 4	0–65535	0
N	09-15	Block Transfer 5	0–65535	0
N	09-16	Block Transfer 6	0–65535	0
N	09-17	Block Transfer 7	0–65535	0
N	09-18	Block Transfer 8	0–65535	0
N	09-19	Block Transfer 9	0–65535	0
N	09-20	Block Transfer 10	0–65535	0
N	09-21	Block Transfer 11	0–65535	0
N	09-22	Block Transfer 12	0–65535	0
N	09-23	Block Transfer 13	0–65535	0
N	09-24	Block Transfer 14	0–65535	0
N	09-25	Block Transfer 15	0–65535	0
N	09-26	Block Transfer 16	0–65535	0
		Communication Decoding	0: Decoding method 1	
	09-30	Method	1: Decoding method 2	0
	09-31	COM1 internal communication protocol	0: Modbus 485 -12: Modbus master (for PLC) -21: ID1 (Pump Master) -22: ID2 (Pump Slave) -23: ID3 (Pump Slave) -24: ID4 (Pump Slave) -25: ID5 (Pump Slave) -26: ID6 (Pump Slave) -27: ID7 (Pump Slave) -28: ID8 (Pump Slave)	0
×	09-32	SG2 COM Protocol	0: Modbus 1: BACnet MS/TP	0
*	09-33	PLC Command force to 0	bit 0: every time before PLC scan, set the PLC target frequency = 0 bit 1: every time before PLC scan, set the PLC target torque = 0 bit 2: every time before PLC scan, set the speed limit of torque mode = 0	0
	09-34	PLC program ID	0–65535	0
	09-35	PLC Address	1–254	100
×	09-45	BACnet MAC ID	0–127	10
×	09-46	BACnet MAC ID Maximum	0–127	127
×	09-47	BACnet Device ID	0–127	55
×	09-48	BACnet Password	0–65535	0
	09-60	Communication card identification	No communication card DeviceNet Slave Profibus-DP Slave	Read only

	Pr.	Parameter Name	Settings	Default
			5: EtherNet/IP Slave	
			12: Profinet	
			13: Bluetooth	
	09-61	Firmware Version of Communication Card	0–655.35 (read only)	Read only
	09-62	Product Code	0-655.35 (read only)	Read only
	09-63	Fault code	0-655.35 (read only)	Read only
~	09-70	Communication Card Address (for DeviceNet or Profibus)	DeviceNet: 0–63 Profibus-DP: 1–125	1
~	09-71	Communication card speed setting (for DeviceNet)	Standard DeviceNet: 0: 125 Kbps 1: 250 Kbps 2: 500 Kbps 3: 1 Mbps (Delta Only) Non-standard DeviceNet: (Delta only) 0: 10 Kbps 1: 20 Kbps 2: 50 Kbps 3: 100 Kbps 4: 125 Kbps 5: 250 Kbps 6: 500 Kbps 7: 800 Kbps 8: 1 Mbps	2
*	09-72	Additional Settings for Communication Card Speed (for DeviceNet)	Standard DeviceNet Non-standard DeviceNet	0
~	09-75	Communication card IP configuration (for EtherNet)	0: Static IP 1: Dynamic IP (DHCP)	0
~	09-76	Communication card IP address 1 (for EtherNet)	0–255	0
~	09-77	Communication card IP address 2 (for EtherNet)	0–255	0
×	09-78	Communication card IP address 3 (for EtherNet)	0–255	0
*	09-79	Communication card IP address 4 (for EtherNet)	0–255	0
×	09-80	Communication card address mask 1 (for EtherNet)	0–255	0
×	09-81	Communication card address mask 2 (for EtherNet)	0–255	0
×	09-82	Communication card address mask 3 (for EtherNet)	0–255	0
*	09-83	Communication card address mask 4 (for EtherNet)	0–255	0

Chapter 11 Summary of Parameter Settings | MPD

	Pr.	Parameter Name	Settings	Default
*	09-84	Communication card gateway address 1 (for EtherNet)	0–255	0
*	09-85	Communication card gateway address 2 (for EtherNet)	0–255	0
*	09-86	Communication card gateway address 3 (for EtherNet)	0–255	0
*	09-87	Communication card gateway address 4 (for EtherNet)	0–255	0
*	09-88	Communication Card Password (Low Word) (for EtherNet)	0–99	
*	09-89	Communication Card Password (High Word) (for EtherNet)	0–99	0
*	09-90	Reset Communication Card (for EtherNet)	No function Reset to defaults	0
*	09-91	Additional setting for the communication card (for EtherNet)	bit 0: enable IP filter bit 1: enable internet parameters bit 2: enable login password	0
	09-92	Communication card status (for EtherNet)	bit 0: enable password	Read only

10 Speed Feedback Control Parameters

	Pr.	Parameter Name	Settings	Default
×	10-29	Upper Limit of Frequency Deviation	0.00–200.00 Hz	20.00
×	10-31	MSI motor control current compensation command	0–150% rated current of the motor	40
×	10-32	Speed Estimator Bandwidth	0.00–600.00 Hz	5.00
×	10-34	Speed Estimator Low-pass Filter Gain	0.00–655.35	
*	10-39	MSI Motor Control Current Compensation Frequency Point	0.00-599.00 Hz	
\mathcal{M}	10-42	Initial angle detection pulse value	0.0–3.0	1.0
*	10-49	Zero Voltage Time During Start- up	00.000–60.000 sec.	00.000
×	10-51	Injection Frequency	0–1200 Hz	500
×	10-52	Injection Magnitude	0.0~200.0 V	30.0
*	10-53	0: Disabled 1: Force attracting the rotor to zero degree		0

11 Advanced Parameters

	Pr.	Parameter Name	Settings	Default
	11-00	System Central	bit 3: Dead time compensation closed	
	11-00	System Control	bit 7: Save or do not save the frequency	U
	11 11	DWM Made Salection	0: Two-phase modulation mode	0
	11-41 PWM Mode Selection		2: Space vector modulation mode	U
*	11-42	System control flag	0000-FFFFh	0000

12 Function Parameters

	Pr.	Parameter Name	Settings	Default
×	12-00	Set Point Deviation Level	0–50%	0
*	12-01	Detection Time of Set Point Deviation Level	1–9999 sec.	10
*	12-02	Offset Level of Low Water Consumption	0–50%	10
×	12-03	Offset Level of High Water Consumption	0: No Function 0–100%	0
×	12-04	High Water Consumption Delay Time	0: No function 0.1–10.0 sec.	0.5
	12-06	Color of LCD	 Blue: running, MP300 is outputting frequency Green: standby, MP300 powers ON without any errors Blue: standby, MP300 powers ON without any errors Green: running, MP300 is outputting frequency 	0
	12-07	Disallowed from Outputting	0: Disabled1: PWM output is OFF (display a warning called NOut)	0
*	12-08	Frequency to Start Switching Pumps	0-the maximum operation frequency	Max. Operation Frequenc y
*	12-09	Time Detected When Pump Reaches the Starting Frequency	0.0-3600.0 sec.	1.0
*	12-12	Pump's Frequency at Time-Out (Disconnection)	0.00–599.0 Hz	0.00
	12-13	Pump's Error Treatment	bit 0: When the operating pump is failed, whether switch to the substitute pump or not 0: Stop all pumps' action 1: Switch to an alternative pump bit 1: During the operation, stop or standby after resetting from error 0: Standby after resetting 1: Stop after resetting bit 2: Before the operation, whether the system can run or not if the pump has an error 0: The system cannot activate the operation 1: The system selects another pump to operate	1
	12-14	Selection of pump start-up sequence	O: According to the serial numbers of the pumps 1: According to the operating time	1
	12-18	Cavitation Detection Method	bit 0–3 00x0h: not using cavitation 00x1h: use Al1 to flow 00x2h: use flow estimation Q-H method	0

	Pr.	Parameter Name	Settings	Default
			bit 4–7	
			000xh: no warning when cavitation	
			001xh: warning when cavitation, but continue	
-			operating	
-	12-19	Cavitation Detection Tolerance	0.00-655.00	1.00
			0: not using	
	12-20 Flow Estimation Method 1:		1: Q-H method	1
ļ			2: P-Q method	
	12-21	Accumulated Flow-Units Digit	0–999.9 m³ (read only)	Read
-			(only
	12-22	Accumulated Flow-Thousands	0–65535 km ³ (read only)	Read
-		Digit	· · · · · · · · · · · · · · · · · · ·	only
			0: not reset	
	12-23	Reset accumulated flow	1: When powering the AC motor drive on, reset	0
		immediately	volume flow	
-			2: Reset volume flow	
*	12-24	Diameter of The Pump Inlet	5.0–6500.0 mm	0.0
^	12-25	Diameter of The Pump Outlet	5.0–6500.0 mm	0.0
×	12-26	The Rated Rotation Speed of Pump	0–65535 rpm	3000
×	12-27	Fluid Density	0.0–6550.0 kg/m ³	995.7
	12-28	Fluid Temperature During	0.00-600.00°C	30.00
~ [12-20	Operation	0.00-800.00 C	30.00
×	12-29	Height Difference of Inlet / Outlet	-30.00–30.00 m	0.00
_	12-23	Pump Pressure Sensor	-30.00-30.00 III	0.00
×	12-30	Pump Curve Head 1	0.00–655.00 m	0.00
×	12-31	Pump Curve Head 2	0.00–655.00 m	0.00
×	12-32	Pump Curve Head 3	0.00–655.00 m	0.00
×	12-33	Pump Curve Head 4	0.00–655.00 m	0.00
×	12-34	Pump Curve Head 5	0.00–655.00 m	0.00
×	12-35	Pump Curve Flow 1	0.00–655.00 m ³ /hr	0.00
×	12-36	Pump Curve Flow 2	0.00–655.00 m ³ /hr	0.00
×	12-37	Pump Curve Flow 3	0.00–655.00 m ³ /hr	0.00
×	12-38	Pump Curve Flow 4	0.00–655.00 m ³ /hr	0.00
×	12-39	Pump Curve Flow 5	0.00–655.00 m ³ /hr	0.00
×	12-40	Pump Curve Point 1 Power	0.00–655.35 kW	0.00
×	12-41	Pump Curve Point 2 Power	0.00–655.35 kW	0.00
×	12-42	Pump Curve Point 3 Power	0.00–655.35 kW	0.00
×	12-43	Pump Curve Point 4 Power	0.00–655.35 kW	0.00
×	12-44	Pump Curve Point 5 Power	0.00–655.35 kW	0.00
×	12-45	Pump curve 1 Npshr	0.00–655.00 m	0.00
~	12-46	Pump curve 2 Npshr	0.00-655.00 m	0.00
×	12-47	Pump curve 3 Npshr	0.00–655.00 m	0.00
×	12-48	Pump curve 4 Npshr	0.00–655.00 m	0.00
×	12-49	Pump curve 5 Npshr	0.00–655.00 m	0.00
			0: No Function	
	12-50	Cycle Time Selection	1: Absolute time	2
			2: Fixed time	

	Pr.	Parameter Name	Settings	Default	
	12-51	Multi-pump's Real Time	00:00~23:59	00:00	
	12-51	Circulation Period	00.00~23.39	00.00	
	12-52	Multi-pump's Fixed Time	0.0–3000.0 hours	5.0	
	12-32	Circulation Period	0.0-3000.0 Hours	3.0	
	12-53	Clean Function	O: Disabled 1: Enabled (trigger the clean function when DI works) 2: Enabled (trigger the clean function when current exceeds stall current and the operation is restricted) 3: Enabled (trigger the clean function when the counting time is up)	0	
	40.54	Ctall Commant Catting Males		400	
	12-54	Stall Current Setting Value	0- the smallest one of Pr.06-03 and Pr.06-04	120	
	12-55	Stall Current Delay Time	0.0–300.0 sec.	60.0	
	12-56 Auto Clean Day		0: Sunday 1: Monday 2: Tuesday 3: Wednesday 4: Thursday 5: Friday 6: Saturday		
	12-57 Cleaning Time of a Day		00:00~23:59	00:00	
	12-58 Cleaning Cycle Times		1–30		
	12-59	Clean Forward Frequency	•		
	12-60	Clean Forward Time	0.0-300.0 sec.	2.0	
	12-61	Clean Reverse Frequency	0.00–50.00 Hz	40.00	
	12-62	Clean Reverse Time	0.0-300.0 sec.	2.0	
	12-63	Cleaning Acceleration Time	1.0-300.0 sec.	1.0	
	12-64	Cleaning Deceleration Time	1.0-300.0 sec.	1.0	
	12-65	Load Auto-tuning Curve	0: Disabled 1: Enabled	0	
	12-66	50% power consumption point	0–65535 kW	0	
	12-67	100% power consumption point	0–65535 kW	0	
•	12-68	Dry Pump Function	0: Disabled 1: Enabled	0	
ŀ	12-69	Dry Pump Check Time	0-300.0 sec.	15.0	
ľ	12-70	Dry Pump Restart Delay Time	0–1000 min.	30	
	12-71	Number of Restart Times Limitation of Dry Pump	0–20	5	
ŀ	12-72	The Treatment of Dry Pump Fault	1: Fault and coast to stop 2: Fault and ramp to stop	1	
	12-73	Heavy Water Leakage Abnormal Pressure Detection	0: No Function 1–50%	15	
	12-74	Heavy Water Leakage Abnormal Detection Time	0.1–300.0 sec.	15.0	
•	12-75	Heavy Water Leakage Load Setting	0–100%	20	

	Pr.	Parameter Name	Settings	Default	
		Heavy Water Leakage	0: Warn and continue operation		
	12-76	Treatment	1: Fault and coast to stop		
		Treatment	2: Fault and ramp to stop		
	12-77	Sleep Boost Pressure Setting	0–50%	0	
	12-78	Sleep Boost Pressure Delay Time	0.0-600.0 sec.	10.0	
	12-79 Level Of High Pressure Alarm		0: No Function 0–50%	25	
			0.1–300.0 sec.	5.0	
	12-81	Ligh Drocours Alorm Treatment	1: Fault and coast to stop	4	
	12-81 High Pressure Alarm Treatment 12-82 Level of Low Pressure Alarm 12-83 Low Pressure Time Delay		2: Fault and ramp to stop	1	
			0: No Function	25	
			0–50%	25	
			0.1–300.0 sec.	5.0	
			0: Warn and continue operation		
	12-84	Low Pressure Alarm Treatment	1: Fault and coast to stop	1	
-			2: Fault and ramp to stop		
	12-88	Dry Pump Detection Tolerance	0–50%	10	
×	12-93	Year Setting	2022–2099	2022	
×	12-94	Date Setting	1.01–12.31	1.01	
×	12-95	Time Setting	00:00~23:59	00:00	
			0: Sunday		
			1: Monday		
			2: Tuesday		
×	12-96	Week Setting	3: Wednesday	0	
			4: Thursday		
			5: Friday		
			6: Saturday		

13 Macro / User-defined Macro

Pr.	Parameter Name	Settings	Default
13-00	Macro Selection	00: Disabled 01: User-defined	00
13-01 - 13-50	Application Parameters (User-defined)		

14 Protection Parameters (2)

Pr.	Parameter Name	Settings	Default
44.50	Output Frequency at Malfunction	0.00 500 00 11-	Read
14-50	2	0.00–599.00 Hz	only
44.54	DC has Voltage at Malfringtion 2	0.0 0552.5.V	Read
14-51	DC bus Voltage at Malfunction 2	0.0–6553.5 V	only
14-52	Output Current at Malfunction 2	0.00–655.35 Amps	Read
14-52	Output Guiterit at Manufiction 2	0.00-033.33 Amps	only
14-53	IGBT Temperature at Malfunction	-3276.8–3276.7°C	Read
14 00	2	0210.0 0210.1 0	only
14-54	Output Frequency at Malfunction	0.00–599.00 Hz	Read
	3	0.00 000.00 112	only
14-55	DC bus Voltage at Malfunction 3	0.0–6553.5 V	Read
	- De bae remage at mamanement		only
14-56	Output Current at Malfunction 3	0.00-655.35 Amps	Read
	•		only
14-57	IGBT Temperature at Malfunction	-3276.8–3276.7°C	Read
	3		only
14-58	Output Frequency at Malfunction	0.00–599.00 Hz	Read
	4		only
14-59	DC bus Voltage at Malfunction 4	0.0–6553.5 V	Read
			only Read
14-60	Output Current at Malfunction 4	0.00-655.35 Amps	
	IGBT Temperature at Malfunction		only Read
14-61	4	-3276.8–3276.7°C	only
	Output Frequency at Malfunction		Read
14-62	5	0.00–599.00 Hz	only
			Read
14-63	DC bus Voltage at Malfunction 5	0.0–6553.5 V	only
			Read
14-64	Output Current at Malfunction 5	0.00–655.35 Amps	only
	IGBT Temperature at Malfunction		Read
14-65	5	-3276.8–3276.7°C	only
44.00	Output Frequency at Malfunction		Read
14-66	6	0.00–599.00 Hz	only
44.07	DOL - Valta Malf tia - O	0.0 0550 5.77	Read
14-67	DC bus Voltage at Malfunction 6	0.0–6553.5 V	only
14.00	Output Current at Malfornation C	0.00 655 25 Ampa	Read
14-68	Output Current at Malfunction 6	0.00–655.35 Amps	only
14-69	IGBT Temperature at Malfunction	-3276.8–3276.7°C	Read
14-69	6	-3210.0-3210.1-0	only
14-70	Fault Record 7	Refer to fault record Pr.06-17-06-22	0
14-71	Fault Record 8	Refer to fault record Pr.06-17-06-22	0
14-72	Fault Record 9	Refer to fault record Pr.06-17-06-22	0
14-73	Fault Record 10	Refer to fault record Pr.06-17-06-22	0

[This page intentionally left blank]

- 12-1 Descriptions of Parameter Settings
- 12-2 Adjustment & Application

12-1 Descriptions of Parameter Settings

00 Drive Parameters

✓ You can set this parameter during operation.

00-00 AC Motor Drive Identity Code

Default: Read only

Settings Read only

00-01 AC Motor Drive Rated Current Display

Default: Read only

Settings Read only

Pr.00-00 displays the AC motor drive identity code. Use the following specification table to check if Pr.00-01 setting is the rated current of the AC motor drive.

Pr.00-01 corresponds to the identity code of Pr.00-00.

460V models - Three-phase											
Frame			Α			A/B	В		()	
Power (kW)	0.75	1.5	2.2	3	4	5.5	7.5	11	15	18.5	22
Power (HP)	1	2	3	4	5.5	7.5	10	15	20	25	30
Identity Code	404	405	406	482	483	408	409	410	411	412	413
Rated Current	1.6	3.3	4.7	6.2	8.5	11.7	15.6	24.4	31.8	39.2	45.6

For the 5.5 kW / 7.5 HP models

Frame A: VFD11AMP43JNNAA, model without filter Frame B: VFD11AMP43JFNAA, model with filter

00-02 Parameter Reset

Default: 0

Settings 0: No function

- 1: Write protection for parameters
- 5: Return kWh displays to 0
- 6: Reset PLC
- 8: Keypad does not respond
- 9: Reset all parameters to defaults (go back to IM V/F control, base frequency is 50 Hz, carrier frequency is 15 kHz)
- Reset all parameters to defaults (go back to PMSVC control, base frequency is 150 Hz, carrier frequency is 4 kHz)
- 12: Reset all parameters to defaults (go back to PMSVC control, base frequency is 150 Hz, carrier frequency is 4 kHz, and preserve the userdefined parameter values Pr.13-01–Pr.13-50)
- 1: All parameters are read only except Pr.00-02, Pr.00-07, and Pr.00-08. Set Pr.00-02 to 0 before changing other parameter settings.
- 5: You can return the kWh displayed value to 0 even during drive operation. For example, you can set Pr.05-26–Pr.05-30 to 0.
- 6: Clear the internal PLC program.
- During parameters reset, if you have set a password in Pr.00-08, then you must unlock the password in Pr.00-07 first and clear the password before returning to default.

- 9: Return to default, and go back to V/F control mode, the base frequency is 50 Hz, carrier frequency is 15 kHz.
 10: Return to default, and go back to SVC control mode, the base frequency is 150 Hz, carrier frequency is 4 kHz.
 12: Return to default, and go back to SVC control mode, the base frequency is 150 Hz, carrier frequency is 4 kHz. User-defined parameters Pr.13-01-Pr.13-50 and their settings will not be reset.
 For the setting of 9, 10 and 12, you must reboot the motor drive after you finish the setting.
 00-03 Start-up Display
 Default: 4
 Settings 0: F (frequency command)
 1: H (output frequency)
- 4: P (display the setting value and the feedback of PID control)

 Determine the start-up display page after power is applied to the drive. The user-defined

O0-04 Content of Multi-function Display (User-Defined)

contents display according to the Pr.00-04 settings.

3: A (output current)

2: U (user-defined) see Pr.00-04

Default: 7

Settings

- 0: Display output current (A) (Unit: Amp)
- 1: Display counter value (c) (Unit: CNT)
- 2: Display the drive's actual output frequency (H.) (Unit: Hz)
- 3: Display the drive's DC bus voltage (v) (Unit: V_{DC})
- 4: Display the drive's output voltage (E) (Unit: V_{AC})
- 5: Display the drive's output power angle (n) (Unit: deg)
- 6: Display the drive's output power (P) (Unit: kW)
- 7: Display the motor speed (r) (Unit: rpm)
- 10: Display PID feedback (b) (Unit: %)
- 11: Display Al1 analog input terminal signal (1.) (Unit: %)
- 12: Display Al2 analog input terminal signal (2.) (Unit: %)
- 14: Display the drive's IGBT temperature (i.) (Unit: °C)
- 15: Display the drive's internal temperature (c.) (Unit: °C)
- 16: The digital input status (ON / OFF) (i)
- 17: The digital output status (ON / OFF) (o)
- 18: Display multi-step speed (S)
- 19: The corresponding CPU digital input pin status (d)
- 20: The corresponding CPU digital output pin status (0.)
- 25: Overload count (0.00–100.00%) (o.) (Unit: %)
- 26: Ground Fault GFF (G.) (Unit: %)
- 27: DC bus voltage ripple (r.) (Unit: V_{DC})
- 28: Display PLC register D1043 data (C)

- 30: Display the output of User-defined (U)
- 31: Display Pr.00-05 user gain (K)
- 36: Present operating carrier frequency of the drive (J.) (Unit: Hz)
- 38: Display the drive status (6.) (See Explanation 5)
- 41: kWh display (J) (Unit: kWh)
- 42: PID target value (h.) (Unit: %)
- 43: PID compensation (C.) (Unit: %)
- 44: PID output frequency (b.) (Unit: Hz)
- 49: Display the motor's temperature (M) (PTC-130, PT100, KTY84-130)
- 51: PMSVC torque offset (T.)
- 60: Display the setting value and the feedback of PID control (P)
- 65: Accumulated motor operation record (day) (r.) (Refer to Pr.05-32)
- 112: Estimated flow rate (F) (Unit: m³/hr)
- 113: Display the inlet pressure (I) (Unit: according to Pr.00-38 setting)
- 114: Display the outlet pressure (O) (Unit: according to Pr.00-25 setting)
- 115: Cavitation detection index (V) (See Pr.12-18 for more details)

Explanation 1

- Setting value 11, 12: display the percentage corresponds to Al1, Al2, and 0–10 V / 0–20 mA / 4–20 mA correspond to 0.00–100.00%.
- It can also display negative values when setting analog input bias (Pr.03-03-03-10).
 Example:

Assume that Al1 input voltage is 0 V, Pr.03-03 is 10.0%, Pr.03-07 is 4 (Bias serves as the center).

Explanation 2

If MI1 and MI4 are ON, the following table shows the status of the terminals.

Normally opened contact (N.O.): (0: OFF, 1: ON)

Terminal	MI4	MI3	MI2	MI1
Status	1	0	0	1

- The value is 0000 0000 0000 1001 in binary system. And converts to 0009H in hexadecimal system. When Pr.00-04 is set to 16 or 19, the u page on the keypad displays 0009h.
- The setting 16 is the ON / OFF status of digital input according to Pr.02-12 setting and the setting 19 is the corresponding CPU pin ON / OFF status of the digital input.
- When MI1 / MI2 default setting is two-wire / three-wire operation control (Pr.02-00 ≠ 0), and MI3 is set to three-wire, it is not affected by Pr.02-12.
- You can set 16 to monitor the digital input ON / OFF status, and then set 19 to check if the circuit is normal.

Explanation 3

Example: Assume that RY: Pr.02-13 is set to 9 (Drive is ready). After powering the drive on, if there is no other abnormal status, the contact is close. The display status is shown below.

Normally opened contact (N.O.):

Terminal	MO	RY2	RY1
Status	0	0	1

- If Pr.00-04 is set to 17 or 20, it displays in hexadecimal "0001h" with LED u page is ON in the keypad.
- The setting 17 is the ON / OFF status of digital output according to Pr.02-18 setting and the setting 20 is the corresponding CPU pin ON / OFF status of the digital output.
- You can set 17 to monitor the digital output ON / OFF status, and then set 20 to check if the circuit is normal.

Explanation 4

Setting value 25: when displayed value reaches 100.00%, the drive shows "oL" as an overload warning.

Explanation 5

Setting value 38:

bit 0: The drive is running forward. bit 3: Errors occurred on the drive.

bit 1: The drive is running backward. bit 4: The drive is running.


bit 2: The drive is ready. bit 5: Warnings occurred on the drive.

Explanation 6

Setting value 60:

Read from left to right, the second and the third digit display the maximum target value, and it's limited by Pr.00-26 setting; the forth and the fifth digit display pressure feedback value. Users can use the UP / DOWN button on the keypad to adjust the maximum target value.


Example: In water pump system, the maximum target value is 4 bar, and the maximum range can be detected by the pressure sensor is 10 bar. Set Pr.00-25 = 353 to define the unit as bar and in one decimal place; set Pr.00-26 = 10.0 to define the maximum pressure to be 10 bar. And then use keypad to adjust the second and the third digit from 10 to 4, finish the setting of the target value.



Explanation 7

- Setting value 113, 114: Set pressure unit in Pr.00-38 and Pr.00-25, otherwise the display shows 0.
- The pressure unit: 003xh: kg/cm², 015xh: mbar, 016xh: bar, 017xh: Pa, 018xh: kPa, 0x19xh: mWG, 0x1Axh: inWG, 0x1Bxh: ftWG, 01Cxh: psi

00-05 Coefficient Gain in Actual Output Frequency Default: 1.00 Settings 0.00-160.00 Sets the user-defined unit coefficient gain. Set Pr.00-04 = 31 to display the calculation result on the screen (calculation = output frequency * Pr.00-05). 00-06 Firmware Version Default: Read only Settings Read only 00-07 Parameter Protection Password Input Default: 0 Settings 0–65535 Display 0–4 (the number of password attempts) Pr.00-07 and Pr.00-08 are used to prevent personnel from setting other parameters by accident. ☐ This parameter allows you to enter your password (which is set in Pr.00-08) to unlock the parameter protection and to make changes to the parameter. To avoid problems in the future, be sure to write down the password after you set this parameter. If you forget the password, clear the password setting by entering 9999 and pressing the ENTER key, then enter 9999 again and press ENTER within 10 seconds. After decoding, all the settings return to default. When setting is under password protection, all the parameters read 0, except Pr.00-08. 80-00 Parameter Protection Password Setting Default: 0 Settings 0-65535 0: No password protection or password is entered correctly (Pr.00-07) Display 1: Password has been set This parameter is for setting the password protection. Password can be set directly the first time. After you set the password, the value of Pr.00-08 is 1, which means password protection is activated. At this time, if you want to change any of the parameter settings, you must enter the correct password in Pr.00-07 to deactivate the password temporarily, and this would make Pr.00-08 become 0. After you finish setting the parameters, reboot the motor drive and the password is activated again. Entering the correct password in Pr.00-07 only temporarily deactivates the password. To permanently deactivate password protection, set Pr.00-08 to 0 manually. Otherwise, password protection is always reactivated after you reboot the motor drive. The keypad copy function works only when the password protection is deactivated (temporarily or permanently), and the password set in Pr.00-08 cannot be copied to the keypad. So when copying parameters from the keypad to the motor drive, set the password manually again in the motor drive to activate password protection.



00-11 Speed Control Mode

Default:


If Pr.00-02 = 9, then the default is 0; if Pr.00-02 = 10 or 12, then the default is 2

Settings 0: IMVF (IM V/F control)

2: PM SVC (PM space vector control)


- Determine the control mode of the AC motor drive:
 - 0: IM V/F control, you can set the proportion of V/F as required and control multiple motors simultaneously.
 - 2: PM space vector control, gets the optimal control by auto-tuning the motor parameters.

 \square Pr.00-11 = 0, the V/F control diagram is as shown below:



Pr.00-11 = 2, the space vector control diagram is as shown below:

PM space vector control (PMSVC):



00-17 Carrier Frequency

Default: 4

Settings 2-15 kHz

Determines the PWM carrier frequency for the AC motor drive.

Models	Model	Settings	Normal Duty Default
460V	1-30 HP [0.75-22kW]	02–15 kHz	4 kHz

Carrier Frequency	Acoustic Noise	Electromagnetic Noise or Leakage Current	Heat Dissipation	Current Wave
2 kHz	Significant	Minimal	Minimal	
8 kHz				/
15 kHz	Minimal	Significant	Significant	─ \\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\

- From the table, you see that the PWM carrier frequency has significant influences on the electromagnetic noise, From the table, you see that the PWM carrier frequency has significant influences on the electromagnetic noise, the AC motor drive heat dissipation, and the motor acoustic noise. Therefore, if the surrounding noise is greater than the motor noise, lower the carrier frequency to reduce the temperature rise. Although the motor has quiet operation in the higher carrier frequency, consider the entire wiring and interference.
- When the carrier frequency is higher than the default, decrease the carrier frequency to protect the drive. Refer to Pr.06-55 for the related setting and details.

00-19 PLC Command Mask

Default: Read only

Display bit 0: Control command is forced by PLC control

value bit 1: Frequency command is forced by PLC control

Determines if the frequency command or control command is locked by PLC.

00-20 Master frequency command source (AUTO, REMOTE)

Default: 0

Settings 0: Digital keypad

1: RS-485 communication (COM1)

2: External analog input (Refer to Pr.03-00)

3: External UP / DOWN terminal (multi-function input terminals)

8: Communication card (does not include CANopen card)

NOTE: HOA (Hand-Off-Auto) function is valid only when this parameter uses

with MO function setting 42 and 56.

- Determines the master frequency source in the "AUTO, REMOTE "mode. The default is AUTO mode.
- You can switch the AUTO, REMOTE modes with the multi-function input terminal (MI) to set the master frequency source.

- It returns to AUTO or REMOTE mode whenever you cycle the power. If you use a multi-function input terminal to switch between HAND (LOCAL) and AUTO (REMOTE) mode, the highest priority is the multi-function input terminal.
- If the built-in PLC function is ON, refer to Pr.04-57 details for the settings of Pr.00-20 and Pr.00-21.

✓ 00-21 Operation command source (AUTO, REMOTE)

Default: 0

Settings 0: Digital keypad

1: External terminals

2: RS-485 communication (COM1)

5: Communication card (does not include CANopen card)

NOTE: HOA (Hand-Off-Auto) function is valid only when this parameter uses

with MO function setting 42 and 56.

- Determines the operation frequency source in the "AUTO, REMOTE" mode.
- In the HOA mode, if the multi-function input terminal (MI) function setting 41 and 42 are OFF, the drive does not receive any operation command and JOG is invalid.
- If the built-in PLC function is ON, refer to Pr.04-57 details for the settings of Pr.00-20 and Pr.00-21.


Output Stop method

Default: 0

Settings 0: Ramp to stop

1: Coast to stop

Determine how the motor is stopped when the AC motor drive receives the Stop command.



Ramp to Stop and Coast to Stop

- Ramp to stop: According to the set deceleration time, the AC motor drive decelerates to 0
 Hz or the minimum output frequency (Pr.01-07), and then stop.
- 2. Coast to stop: According to the load inertia, the AC motor drive stops output immediately, and the motor coasts to stop.
 - Use "ramp to stop" for the safety of personnel or to prevent material from being wasted in applications where the motor must stop immediately after the drive stops. You must set the deceleration time accordingly.

Default: 0

Settings 0: Enable forward / reverse

Disable reverse
 Disable forward

- This parameter can prevent the equipment to be broken from a malfunction caused by the forward and reverse rotation of the motor. To limit the motor to run in the forward or reverse direction when only one running direction is allowed for the motor load.
- Refer to Pr.00-47 for the definition of motor running direction, and refer to Chapter 5 for schematic diagram of motor running direction.

00-24 Digital Operator (Keypad) Frequency Command Memory

Default: Read only

Settings Read only

If the keypad is the frequency command source, when Lv or fault occurs, this parameter stores the current frequency command.

00-25 User-defined Characteristics 1

Default: 353

Settings bit 0–3: user-defined decimal places

0000h-0000b: no decimal place 0001h-0001b: one decimal place 0002h-0010b: two decimal places 0003h-0011b: three decimal places

bit 4-15: user-defined unit

000xh: Hz 001xh: rpm 002xh: %

003xh: kg/cm²

004xh: m/s

005xh: kW

006xh: HP

007xh: PPM

008xh: 1/m

009xh: kg/s

00Axh: kg/m

00Bxh: kg/h

00Cxh: lb/s

00Dxh: lb/m

00Exh: lb/h


00Fxh: ft/s

010xh: ft/m

011xh: m 012xh: ft 013xh: degC 014xh: degF 015xh: mbar 016xh: bar 017xh: Pa 018xh: kPa 019xh: mWG 01Axh: inWG 01Bxh: ftWG 01Cxh: psi 01Dxh: atm 01Exh: L/s 01Fxh: L/m 020xh: L/h 021xh: m3/s 022xh: m3/h 023xh: GPM

024xh: CFM xxxxh: Hz

- User-defined characteristic 1 is applicable to the setting of Al1 and the system; user-defined characteristic 2 is applicable to be inlet pressure only when Pr.03-01=22.
- The default is in one decimal place (xxx1h), and the unit is bar (016xh). 0161h in hexadecimal system equals 353 in decimal system, so set Pr.00-25 to 353 via the keypad will be succeed.
- When Pr.03-00=21 (the outlet pressure), the unit of Pr.00-25 should be the pressure unit, otherwise the function cannot work correctly.
- When Pr.03-00=23 (the input flow), the unit of Pr.00-25 should be the flow unit, otherwise the function cannot work correctly.
- bit 0~3: The displayed units for the control frequency F page and user-defined (Pr.00-04 = d10, PID feedback), and the displayed number of decimal places for Pr.00-26 (support up to three decimal places).
- bit 4~15: The displayed units for the control frequency F page, user-defined (Pr.00-04 = 10, PID feedback) and Pr.00-26.



You must convert the setting value to decimal system when using the keypad to set parameters. Example: Assume that the user-defined unit is inWG and user-defined decimal place is the third decimal point.

According to the information above, the corresponding unit to inWG is 01Axh (x is the set decimal point), and the corresponding unit to the third decimal place is 0003h, then inWG and the third decimal point displayed in hexadecimal is 01A3h, that is 419 in decimal system. Thus, set Pr.00-25 = 419 to complete the setting.

The unit conversion table of pressure

Refer to the table below to set the corresponding decimal value according to the unit and the decimal point.

For example, if it's two decimal points and the unit is bar, then set Pr.00-25 = 354.

	003xh: kg/cm ²	015xh: mbar	016xh: bar
0000h	Hex: 0030h	Hex: 0150h	Hex: 0160h
no decimal place	Decimal: 48	Decimal: 336	Decimal: 352
0001h	Hex: 0031h	Hex: 0151h	Hex: 0161h
one decimal place	Decimal: 49	Decimal: 337	Decimal: 353
0002h	Hex: 0032h	Hex: 0152h	Hex: 0162h
two decimal places	Decimal: 50	Decimal: 338	Decimal: 354
0003h	Hex: 0033h	Hex: 0153h	Hex: 0163h
three decimal places	Decimal: 51	Decimal: 339	Decimal: 355

Maximum User-defined Value 1

Default: 0

Settings 0: No function

0-65535 (when Pr.00-25 is set to no decimal place)

0.0–6553.5 (when Pr.00-25 is set to one decimal place)

0.00-655.35 (when Pr.00-25 is set to two decimal places)

When Pr.00-26 is NOT 0, the user-defined value is enabled. After selecting the displayed unit and number of decimal places with Pr.00-25, the setting value of Pr.00-26 corresponds to Pr.01-00 (drive's maximum operating frequency).

Example: When the frequency set in Pr.01-00 = 150.00 Hz, the maximum user-defined value for Pr.00-26 is 100.0. This also means that Pr.00-25 is set at 33 (0021h) to select % as the unit.

Note: Set Pr.00-25 before using Pr.00-26. After you finish setting, when Pr.00-26 is not 0, the display(F) on the keypad shows correctly according to Pr.00-25 settings.

✓ 00-38 User-defined Characteristics 2

Default: 353

Settings bit 0–3: user-defined decimal places

0000h-0000b: no decimal place 0001h-0001b: one decimal place 0002h-0010b: two decimal places 0003h-0011b: three decimal places bit 4-15: user-defined unit

003xh: kg/cm²
015xh: mbar
016xh: bar
017xh: Pa
018xh: kPa
019xh: mWG
01Axh: inWG
01Bxh: ftWG

01Cxh: psi

User-defined characteristic 1 is applicable to the setting of Al1 and the system; user-defined characteristic 2 is applicable to be inlet pressure only when Pr.03-01=22.

When Pr.03-01=22 (the inlet pressure), the unit of Pr.00-38 should be the pressure unit, otherwise the function cannot work correctly.

- The default is in one decimal place (xxx1h), and the unit is bar (016xh). 0161h in hexadecimal system equals 353 in decimal system, so set Pr.00-38 to 353 via the keypad will be succeed.
- You must convert the setting value to decimal system when using the keypad to set parameters.
- The unit conversion table of pressure

Refer to the table below to set the corresponding decimal value according to the unit and the decimal point.

For example, if it's two decimal points and the unit is bar, then set Pr.00-25 = 354.

	003xh: kg/cm ²	015xh: mbar	016xh: bar
0xx0h	Hex: 0030h	Hex: 0150h	Hex: 0160h
no decimal place	Decimal: 48	Decimal: 336	Decimal: 352
0xx1h	Hex: 0031h	Hex: 0151h	Hex: 0161h
one decimal place	Decimal: 49	Decimal: 337	Decimal: 353
0xx2h	Hex: 0032h	Hex: 0152h	Hex: 0162h
two decimal places	Decimal: 50	Decimal: 338	Decimal: 354
0xx3h	Hex: 0033h	Hex: 0153h	Hex: 0163h
three decimal places	Decimal: 51	Decimal: 339	Decimal: 355

Default: 0

Settings 0: No function

0-65535 (when Pr.00-25 is set to no decimal place)

0.0-6553.5 (when Pr.00-25 is set to one decimal place)

0.00-655.35 (when Pr.00-25 is set to two decimal places)

0.000-65.535 (when Pr.00-25 is set to three decimal places)

- Pr.00-27 displays the user-defined value when Pr.00-38 is not 0.
- Note: Set Pr.00-38 before using Pr.00-39. After you finish setting, when Pr.00-26 is not 0, the displayed unit on the keypad shows correctly according to Pr.00-38 settings [Pr.00-04=74, display the inlet pressure (I)].

User-defined Value 1 00-27

Default: Read only

Settings Read only

Pr.00-27 displays the user-defined value when Pr.00-26 is not 0.

LOCAL / REMOTE Selection

Default: 0

Settinas

- 0: Standard HOA function
- 1: When switching between local and remote, the drive stops.
- 2: When switching between local and remote, the drive runs with REMOTE settings for frequency and operating status.
- 3: When switching between local and remote, the drive runs with LOCAL settings for frequency and operating status.
- 4: When switching between local and remote, the drive runs with LOCAL settings when switched to Local and runs with REMOTE settings when switched to Remote for frequency and operating status.
- The default for Pr.00-29 is 0, that is, the standard HOA (Hand-Off-Auto) function. Set the AUTO and HAND frequency and operation source with Pr.00-20, 00-21 and Pr.00-30, 00-31. The external terminal function (MI) = 56 for LOC / REM mode selection is disabled when Pr.00-29=0.
- If Pr.00-29 is not 0, that is, Local / Remote functions. Set the REMOTE and LOCAL frequency and operation source with Pr.00-20, 00-21 and Pr.00-30, 00-31.
 - Set the multi-function input terminal (MI) = 56 to set the LOC / REM selection.
- If Pr.00-29 is not set to 0, the AUTO / HAND keys are disabled. In this case, the external terminal (MI) setting = 56 (local / remote selection) has the highest command priority.

00-30 Master frequency command source (HAND, LOCAL)

Default: 0

- Settings 0: Digital keypad
 - 1: RS-485 communication input
 - 2: External analog input (Refer to Pr.03-00)
 - 3: External UP / DOWN terminal (multi-function input terminals)
 - 8: Communication card (does not include CANopen card)

Note: HOA (Hand-Off-Auto) function is valid only when you use with MO function setting 41 and 56.


- Determine the master frequency source in the "HAND, LOCAL" mode.
- You can switch the HAND, LOCAL mode with the multi-function input terminal (MI) to set the master frequency source.
- It returns to AUTO or REMOTE mode whenever you cycle the power. If you use a multi-function input terminal to switch between HAND (LOCAL) and AUTO (REMOTE) mode, the highest priority is the multi-function input terminal.

Operation command source (HAND, LOCAL) Default: 0 Settings 0: Digital keypad 1: External terminals 2: RS-485 communication input 5: Communication card (does not include CANopen card) Note: HOA (Hand-Off-Auto) function is valid only when you use with MO function setting 41 and 56. Determine the operation frequency source in the "HAND, LOCAL" mode. In the HOA mode, if the multi-function input terminal (MI) function setting 41 and 42 are OFF, the drive does not receive any operation command and JOG is invalid. 00-32 Digital Keypad STOP Function Default: 0 Settings 0: STOP key disabled 1: STOP key enabled \square Valid when the operation command source is not the digital keypad (Pr.00-21 \neq 0). When Pr.00-21=0, the STOP key on the digital keypad is not affected by this parameter. **RPWM Mode Selection** Default: 0 Settings 0: Disabled 1: RPWM mode 1 2: RPWM mode 2 3: RPWM mode 3 When activate RPWM function, the carrier wave of the drive is randomly distributed according to the carrier frequency (Pr.00-17) which is at the center The RPWM function is applicable to all control modes. After activating RPWM function, decrease the shrill noise which focuses on a specific high frequency, and change the sound frequency of the motor (usually change the sound from shill to a little deep and low). The AC motor drive supports three kinds of RPWM modes for different applications. Each mode has its own frequency distribution, the corresponding electromagnetic noise distribution and the pitch are also different. Generally, the load bearing capacity: RPWM mode 2 > RPWM mode 1 > RPWM mode 3; the capacity of decreasing the high frequency sound: RPWM mode 3 > RPWM mode 1 > RPWM mode 2. RPWM carrier frequency variation Default: 0.0 kHz Settings 0.0–4.0 kHz When activate RPWM function, the lowest carrier wave can be set in Pr.00-17 is 4 kHz, and the highest is 8 kHz.


 \square Pr.00-34 is valid only when RPWM function is activating (Pr.00-33 \neq 0).

Example: When the carrier wave (Pr.00-17) is 4 kHz, activate RPWM function (Pr.00-33 = 1, 2, or 3), and the RPWM range (Pr.00-34) is 2.0 kHz, the output carrier wave is based on 4 kHz, the random frequency range is \pm 1 kHz, thus the carrier wave changes randomly within 3 kHz to 5 kHz.

When Pr.00-17 = 4 or 8 kHz, the maximum setting value of Pr.00-34 can be 2.0 kHz (+/-1 kHz). The carrier wave range to change is as the figure shown below:



When Pr.00-17 = 5, 6, or 7 kHz, the maximum setting value of Pr.00-34 can be 4.0 kHz (+/-2 kHz). The carrier wave range to change is as the figure shown below:



Motor Direction Setting

Default: 0

Settings 0: Motor does not change running direction

1: Motor changes running direction

- This parameter can be used to change the running direction from forward to reverse or from reverse to forward, and the light don't change.
- Pay more attention that the parameter influences the definition of running direction such as Pr.00-23, Pr.06-80.
- Refer to Chapter 5 for schematic diagram of motor running direction

N 00-48 Display Filter Time (Current)

Default: 0.100

Settings 0.001-65.535 sec.

Minimize the current fluctuation displayed by the digital keypad.

00-49 Display Filter Time (Keypad)

Default: 0.100

Settings 0.001-65.535 sec.

Minimize the value fluctuation displayed by the digital keypad.

00-50 Software Version (Date)

Default: Read only

Settings Read only

Display the current drive software version by date.

N 00-61 PLC Software Version
Default: Read only

Settings Read only

Display the current PLC version code of MP300.

Default: Read only

Settings Read only

Display the current drive software version by date.

[This page intentionally left blank]

01 Basic Parameters

✓ You can set this parameter during operation.

01-00 Motor 1 Maximum Operation Frequency

Default:150.00

Settings 0.00–599.00 Hz

Determines the AC motor drive's maximum operation frequency. All the AC motor drive frequency command sources (analog inputs 0–10 V, 4–20 mA, 0–20 mA) are scaled to correspond to the output frequency range.

01-01 Motor 1 Rated / Base Frequency

Default:150.00

Settings 0.00–599.00 Hz

Set this parameter according to the motor's rated frequency on the motor nameplate. The motor for MPD is 150.00 Hz.

01-02 Motor 1 Rated / Base Voltage

Default:380.0

Settings 0.0–510.0 V

- Set this parameter according to the rated voltage on the motor nameplate. The motor for MPD is 380.0 V
- There are many motor types in the market and the power system for each country is also different. The economical and convenient solution is to install an AC motor drive. Then there is no problem using the motor with different voltage and frequency inputs, and the motor drive can improve the original motor characteristics and useful life.

01-03 Motor 1 Mid-Point Frequency 1

Default: 3.00

Settings 0.00-599.00 Hz

01-04 Motor 1 Mid-Point Voltage 1

Default: 22.0

Settings 0.0~480.0 V

01-05 Motor 1 Mid-Point Frequency 2

Default: 1.50

Settings 0.00-599.00 Hz

✓ 01-06 Motor 1 Mid-Point Voltage 2

Default: 10.0

Settings 0.0–480.0 V

01-07 Motor 1 Minimum Output Frequency

Default: 0.50


Settings 0.00-599.00 Hz

01-08 Motor 1 Minimum Output Voltage

Default: 2.0

Settings 0.0–480.0 V


- You usually set the V/F curve according to the motor's allowable loading characteristics. Pay special attention to the motor's heat dissipation, dynamic balance, and bearing lubrication when the loading characteristics exceed the loading limit of the motor.
- There is no limit for the voltage setting, but a high voltage at a low frequency may cause motor damage, overheating, and trigger the stall prevention or the over-current protection; therefore, use low voltage at low frequency to prevent motor damage or drive error.
- The V/F curve for motor 1 is as shown below.




V/F Curve and The Related Parameters

Common settings for the V/F curve

(1) General purpose




Pr.	Setting	
01-00	60.0	
01-01	60.0	
01-02	380.0	
01-03	1.50	
01-05	1.50	
01-04	10.0	
01-06	10.0	
01-07	1.50	
01-08	10.0	
-	•	



Pr.	Setting
01-00	50.0
01-01	50.0
01-02	380.0
01-03	1.30
01-05	1.30
01-04	10.0
01-06	10.0
01-07	1.30
01-08	10.0

(2) Fan and hydraulic machinery




Pr.	Setting
01-00	60.0
01-01	60.0
01-02	380.0
01-03	30.0
01-05	30.0
01-04	50.0
01-06	50.0
01-07	1.50
01-08	10.0
•	


Motor spec. 50Hz				
380				
50			!	
10				
	1.3	25	50.0 F	

Pr.	Setting	
01-00	50.0	
01-01	50.0	
01-02	380.0	
01-03	25.0	
01-05	25.0	
01-04	50.0	
01-06	50.0	
01-07	1.30	
01-08	10.0	

(3) High starting torque



Pr.	Setting
01-00	60.0
01-01	60.0
01-02	380.0
01-03	3.00
01-05	3.00
01-04	23.0
01-06	25.0
01-07	1.50
01-08	18.0



Pr.	Setting
01-00	50.0
01-01	50.0
01-02	380.0
01-03	2.20
01-05	2.20
01-04	23.0
01-06	23.0
01-07	1.30
01-08	14.0


01-09 Start-up Frequency

Default: 0.50

Settings 0.00-599.00 Hz

- At the moment of the startup, the drive's frequency output starts from the start-up frequency until reaching the F command.
- After starting up, if frequency command (Fcmd) > output frequency lower limit (Flow, Pr.01-11), the drive outputs according to the frequency command (Fcmd); if frequency command (Fcmd) < output frequency lower limit (Flow, Pr.01-11), the drive outputs according to the output frequency lower limit (Flow, Pr.01-11).

Refer to the figure shown below:



01-10 Output Frequency Upper Limit

Default: 599.00

Settings 0.00-599.00 Hz

O1-11 Output Frequency Lower Limit

Default: 0.00


Settings 0.0–Pr.01-10 Hz

Auto-deceleration Setting.

		e upper and lower limit output frequency settings to limit the actual output frequency. If the
	•	frequency setting is higher than the upper limit (Pr.01-10), the drive runs with the upper
		quency. If the output frequency setting is lower than the lower limit (Pr.01-11) but higher
		e minimum output frequency. Set the upper limit frequency > the lower limit frequency
	•	10 setting value must be > Pr.01-11 setting value).
	• •	per output frequency limits the drive's maximum output frequency. If the frequency setting
		frequency command is higher than Pr.01-10, the drive runs with the Pr.01-10 setting.
		ID feedback control is enabled for the drive, the drive's output frequency may exceed the
	•	cy command but is still limited by this setting.
		I parameters: Pr.01-00 Maximum Operation Frequency, Pr.01-11 Output Frequency
	Lower L	
		ver output frequency limits the drive's minimum output frequency. If the frequency setting
		frequency command is lower than Pr.01-11, the drive runs with the Pr.01-11 setting.
		e output frequency upper and lower limit settings to prevent operator misuse, overheating
		by the motor's operating at a too low frequency, or mechanical wear due to a too high
	speed.	output frequency upper limit setting is 50 Hz and the frequency setting is 150 Hz, the
		um output frequency is 50 Hz.
		equency output upper limit is 150 Hz and the frequency setting is also 150 Hz, only the
		ncy command is limited at 150 Hz. The actual output frequency may be higher than 150
	•	ed for slip compensation.
~	01-12	Acceleration Time 1
~	01-13	Deceleration Time 1
~		Acceleration Time 2
~	01-15	Deceleration Time 2
~	01-16	Acceleration Time 3
~	01-17	Deceleration Time 3
~	01-18	Acceleration Time 4
~	01-19	Deceleration Time 4
~		JOG Acceleration Time
~	01-21	JOG Deceleration Time
		Default: 10.00 /10.0
		Settings Pr.01-45 = 0: 0.00-6000.0 sec.
		Pr.01-45 = 1: 0.0–6000.0 sec.
		celeration time determines the time required for the AC motor drive to ramp from 0.00 Hz
		maximum operation frequency (Pr.01-00). The deceleration time determines the time
	•	d for the AC motor drive to decelerate from the maximum operation frequency (Pr.01-00)
	down to	0.00 Hz.

☐ The acceleration and deceleration time are invalid when using Pr.01-44 Auto-acceleration and

- Select the Acceleration / Deceleration Time 1, 2, 3, 4 with the multi-function input terminal settings. The defaults are Acceleration Time 1 and Deceleration Time 1.
- With the enabled torque limits and stall prevention functions, the actual acceleration and deceleration time are longer than the above action time.
- Note that set the acceleration and deceleration time too short may trigger the drive's protection function (Pr.06-03 Over-current Stall Prevention during Acceleration or Pr.06-01 Over-voltage Stall Prevention), and the actual acceleration and deceleration time are longer than this setting.
- Note that set the acceleration time too short may cause motor damage or trigger drive protection due to over-current during the drive's acceleration.
- Note that set the deceleration time too short may cause motor damage or trigger drive protection due to over-current during the drive's deceleration or over-voltage.
- When you enable Pr.01-24—Pr.01-27 (S-curve acceleration and deceleration begin and arrival time), the actual acceleration and deceleration time are longer than the setting.



√ 01-22 JOG Frequency

Default:6.00

Settings 0.00-599.00 Hz

You can use the external terminal JOG to set the JOG function. When the JOG command is ON, the AC motor drive accelerates from 0 Hz to the JOG frequency (Pr.01-22). When the JOG command is OFF, the AC motor drive decelerates from the JOG frequency to stop. The JOG acceleration and deceleration time (Pr.01-20, Pr.01-21) are the time to accelerate from 0.0 Hz to the JOG frequency (Pr.01-22). You cannot execute the JOG command when the AC motor drive is running. When the JOG command is executing, other operation commands are invalid.


✓ 01-23 Switch Frequency between First and Fourth Accel./Decel.

Default:0.00

Settings 0.00-599.00 Hz

This function does not require the external terminal switching function; it switches the acceleration and deceleration time automatically according to the Pr.01-23 setting. If you set the external terminal, the external terminal has priority over Pr.01-23.

When using this function, set the S-curve acceleration time to 0 if the fourth acceleration time is short.




1st/4th Acceleration/Deceleration Frequency Switching

×	01-24	S-curve Acceleration Begin Time 1
×	01-25	S-curve Acceleration Arrival Time 2
×	01-26	S-curve Deceleration Begin Time 1
×	01-27	S-curve Deceleration Arrival Time 2

Default: 0.20 / 0.2

Settings Pr.01-45 = 0: 0.00-25.00 sec.Pr.01-45 = 1: 0.0-250.0 sec.

- Using an S-curve gives the smoothest transition between speed changes. The acceleration and deceleration curve adjusts the acceleration and deceleration S-curve. When enabled, the drive produces a different acceleration and deceleration curve according to the acceleration and deceleration time.
- The S-curve function is invalid when you set the acceleration and deceleration time to 0.
- When Pr.01-12, 01-14, 01-16, 01-18 ≥ Pr.01-24 and Pr.01-25, the actual acceleration time = Pr.01-12, 01-14, 01-16, 01-18 + (Pr.01-24 + Pr.01-25) / 2.
- When Pr.01-13, 01-15, 01-17, 01-19 \geq Pr.01-26 and Pr.01-27, the actual deceleration time = Pr.01-13, 01-15, 01-17, 01-19 + (Pr.01-26 + Pr.01-27) / 2.




01-28	Skip Frequency 1 (Upper Limit)
01-29	Skip Frequency 1 (Lower Limit)
01-30	Skip Frequency 2 (Upper Limit)
01-31	Skip Frequency 2 (Lower Limit)
01-32	Skip Frequency 3 (Upper Limit)

01-33 Skip Frequency 3 (Lower Limit)

Default:0.00

Settings 0.00-599.00 Hz

- Sets the AC motor drive's skip frequency. The drive's frequency setting skips these frequency ranges. However, the frequency output is continuous.
 - There are no limits for these six parameters and you can combine them. Pr.01-28 does not need to be greater than Pr.01-29; Pr.01-30 does not need to be greater than Pr.01-31; Pr.01-32 does not need to be greater than Pr.01-33. You can set Pr.01-28–01-33 as you required. There is no size distinction among these six parameters.
- These parameters set the skip frequency ranges for the AC motor drive. You can use this function to avoid frequencies that cause mechanical resonance. The skip frequencies are useful when a motor has resonance vibration at a specific frequency bandwidth. Skipping this frequency avoids the vibration. There are three frequency skip zones available.
- You can set the Frequency command (F) within the range of skip frequencies. Then the output frequency (H) is limited to the lower limit of skip frequency ranges.
- During acceleration and deceleration, the output frequency still passes through the skip frequency ranges.



01-43 V/F Curve Selection

Default: 0


Settings 0: Determined by Pr.01-00-01-08

1: V/F curve to the power of 1.5

2: V/F curve to the power of 2

- When the setting is 0, refer to Pr.01-01-08 for the motor 1 V/F curve.
- When the setting is 1 or 2, the second and third voltage frequency settings are invalid.
- If the load of the motor is a variable torque load (torque is in direct proportion to the rotating speed, such as the load of a fan or a pump), the load torque is low at low rotating speed. You can decrease the input voltage appropriately to make the magnetic field of the input current smaller and reduce flux loss and iron loss for the motor to increase efficiency.
- When you set the V/F curve to high power, it has lower torque at low frequency, and the drive is not suitable for rapid acceleration and deceleration. Do NOT use this parameter for rapid acceleration and deceleration.

Chapter 12 Descriptions of Parameter Settings | MPD



N 01-44 Auto-acceleration and Auto-deceleration Setting

Default: 0

Settings 0: Linear acceleration and deceleration

1: Auto-acceleration and linear deceleration

2: Linear acceleration and auto-deceleration


3: Auto-acceleration and auto-deceleration

4: Stall prevention by auto-acceleration and auto-deceleration (limited by Pr.01-12–01-21)

0: Linear acceleration and deceleration:

the drive accelerates and decelerates according to the setting for Pr.01-12-01-19.

- 1 or 2 (auto / linear acceleration and auto / linear deceleration):
 - the drive auto-tunes the acceleration and deceleration to effectively reduce the mechanical vibration during the load start-up and stop and make the auto-tuning process easier. It does not stall during acceleration and does not need a brake resistor during deceleration to stop. It can also improve operation efficiency and save energy.
- 3 (auto-acceleration and auto-deceleration—decelerating by the actual load):
 the drive auto-detects the load torque and automatically accelerates from the fastest acceleration time and smoothest start-up current to the setting frequency. During deceleration, the drive automatically determines the loaded regenerative energy to steadily and smoothly stop the motor in the fastest deceleration time.
- 4: Auto-acceleration and auto-deceleration (set by acceleration/ deceleration time setting) if the acceleration and deceleration time are within a reasonable range, the actual acceleration and deceleration time refer to the Pr.01-12–01-19 settings. If the acceleration and deceleration time are too short, the actual acceleration and deceleration time are greater than the acceleration and deceleration time settings.



Acceleration / Deceleration Time

- 1 Optimize the acceleration / deceleration time when Pr.01-44 is set to 0.
- 2 Optimize the acceleration / deceleration time which load needs actually when Pr.01-44 is set to 3.

01-45 Time Unit for Acceleration and Deceleration and S-Curve

Default: 0

Settings 0: Unit 0.01 sec.

1: Unit 0.1 sec.

[This page intentionally left blank]

02 Digital Input / Output Parameters

✓ You can set this parameter during operation.

02-00 Two-wire / Three-wire Operation Control

Default:1

Settings 0: No function

1: Two-wire mode 1, power ON for operation control

(M1: FWD / STOP, M2: REV / STOP)

2: Two-wire mode 2, power ON for operation control

(M1: RUN / STOP, M2: REV / FWD)

3: Three-wire, power ON for operation control

(M1: RUN, M2: REV / FWD, M3: STOP)

4: Two-wire mode 1, Quick Start

(M1: FWD / STOP, M2: REV / STOP)


5: Two-wire mode 2, Quick Start


(M1: RUN / STOP, M2: REV / FWD)

6: Three-wire, Quick Start

(M1: RUN, M2: REV / FWD, M3: STOP)

- After enabling built-in PLC function, Pr.02-00 has no function. MI1 has no function when Pr.04-57 bit0 = 0; MI1 is fixed in the mode that open is stop and close is run when Pr.04-57 bit0 = 1. Users can set MI2, MI3 according to Pr.02-02 and Pr.02-03.
- In the Quick Start function, the output remains ready for operation. The drive responds to the Start command immediately.
- When using Quick Start function, the output terminals UVW are with driving voltages in order to output and respond immediately if a Start command is given. Do NOT touch the terminals or modify the motor wiring to prevent electric shocks.
- This parameter sets the configuration of the external drive operation control and the Quick Start function. There are six different control modes listed in the following table.





02-01	Multi-function Input Command 1 (MI1)		
02-02	Multi-function Input Command 2 (MI2)		
		Default: 0	
02-03	Multi-function Input Command 3 (MI3)		
		Default:1	
02-04	Multi-function Input Command 4 (MI4)		
		Default:2	

Settings

- 0: No function
- 1: Multi-step speed command 1 / multi-step position command 1
- 2: Multi-step speed command 2 / multi-step position command 2
- 3: Multi-step speed command 3 / multi-step position command 3
- 4: Multi-step speed command 4 / multi-step position command 4
- 5: Reset
- 6: JOG command
- 7: Acceleration / deceleration speed inhibit
- 8: 1st and 2nd acceleration / deceleration time selection
- 9: 3rd and 4th acceleration / deceleration time selection
- 10: External Fault (EF) input (Pr.07-20)

- 11: Base Block (B.B.) input from external
- 13: Cancel the setting of auto-acceleration / auto-deceleration time
- 15: Rotating speed command from Al1
- 16: Rotating speed command from AI2
- 18: Force to stop (Pr.07-20)
- 19: Digital up command
- 20: Digital down command
- 22: Clear the counter
- 23: Input the counter value (MI4)
- 24: FWD JOG command
- 25: REV JOG command
- 38: Disable writing EEPROM function
- 41: HAND switch
- 42: AUTO switch
- 51: Selection for PLC mode bit 0
- 52: Selection for PLC mode bit 1
- 56: Local / Remote selection
- 58: Enable fire mode (with RUN command)
- 59: Enable fire mode (without RUN command)
- 69: Enable preheating function
- 97: Multi-pump manual / auto switch
- 100: Enable clean function
- Use this parameter to set the function of multi-function terminals.
- When Pr.02-00 = 0, you can set multi-function options with multi-function input terminals MI1, MI2.
- When Pr.02-00 ≠ 0, the multi-function input terminals MI1, MI2 work in accordance with the setting values for Pr.02-00.

Example: If Pr.02-00 = 1: multi-function input terminal MI1 = FWD / STOP, MI2 = REV / STOP.

If Pr.02-00 = 2: multi-function input terminal MI1 = RUN / STOP, MI2 = FWD / REV.

- If Pr.02-00 is set to three-wire operation control, terminal MI3 is for the STOP contact. The function set previously for this terminal is automatically invalid.
- When the built-in PLC function is enabled, MI is not regulated by Pr.02-00, and users can set MI2, MI3 according to Pr.02-02 and Pr.02-03. And when Pr.04-67 bit0 = 1, MI1 is fixed in the mode that open is stop and close is run.

Summary of function settings (Take the normally open contact (N.O.) for example, ON: contact is closed, OFF: contact is open)

ID*	Functions	Descriptions	
0	No function		
		You can set 15 steps of speed or 15 positions with the digital	
	multi-step position command 1	status of these four terminals. You can use 16-steps of	

ID*	Functions	Descriptions	
	Multi-step speed command 2 /	speed if you include the master speed when setting as 15	
2 multi-step position command 2 s		steps of speed.	
	Multi-step speed command 3 /	(refer to Parameter Group 04 Multi-step Speed Parameters).	
3	multi-step position command 3		
4	Multi-step speed command 4 /		
4	multi-step position command 4		
5	Reset	Use this terminal to reset the drive after clearing a drive fault.	
6	JOG command	This function is valid when the source of the operation command is the external terminal. The JOG operation executes when the drive stops completely. While running, you can still change the operation direction, and the STOP key on the keypad* and the STOP command from communications are valid. Note *: This function is valid when Pr.00-32 is set to 1. Once the external terminal receives the OFF command, the motor stops in the JOG deceleration time. Refer to Pr.01-20–01-22 for details. Pr.01-22 JOG frequency Pr.01-20 JOG decel. time MIx-GND ON OFF Mix: External terminal	
7	Acceleration / deceleration speed inhibit	When you enable this function, the drive stops acceleration or deceleration immediately. After you disable this function, the AC motor drive starts to accelerate or decelerate from the inhibit point. Frequency Setting frequency Accel. inhibit area Actual operation frequency Decel. inhibit area Actual operation frequency Decel. inhibit area Actual operation frequency Decel. inhibit area ON OPER	

ID*	Functions	Descriptio	ons	
		You can select the acceleration ar	nd deceleration time of the	
		drive with this function, or from the	-	
8		terminals; there are four accelerat	ion and deceleration	
	deceleration time selection	selections.	Ix = 8	
		1st acceleration /		
		deceleration time	0 0	
		2nd acceleration / deceleration time	1 0	
9	3rd and 4th acceleration /	3rd acceleration / deceleration time	0 1	
	deceleration time selection	4th acceleration / deceleration time	1 1	
		For external fault input. The drive	e decelerates according to	
		the Pr.07-20 setting, and the key	. ,	
		the fault record when an externa	•	
		keeps running until the fault is	cleared (terminal status	
		restored) after RESET.		
		Voltage		
10	EF inputs (EF: External Fault)	Setting	<u> </u>	
		frequency		
			/ Time	
		MIX-GND ON	OFF ON	
		Reset On ON	OFF	
		Operation ON Command	ON	
	B.B. inputs from external	ON: the output of the drive stops	•	
11	(B.B.: Base Block)	in free run and the keypad display Pr.07-08 for details.	ys the B.B. signal. Refer to	
	Cancel the setting of auto-	Set Pr.01-44 to one of the 01–04 s	eatting modes before using	
13	acceleration / auto-	this function. When this function is		
	deceleration time	mode and ON is for linear accelera	•	
		ON: force the source of the drive's		
15	IAI1	(If the rotating speed commands a	•	
		the same time, the priority is AI1 > AI2.)		
	Rotating speed command from	ON: force the source of the drive's	•	
16	AI2	(If the rotating speed commands a		
		the same time, the priority is Al1 >	•	
18	Force to stop	ON: the drive ramps to a stop acco	ording to the Pr.07-20	
		setting.		
	Digital up command	ON: the frequency of the drive incl	•	
19	(Up Command)	one unit. If this function remains ON continuously, the frequency increases or decreases according to Pr.02-09 /		
	,	rrequency increases or decreases	according to Pr.02-09 /	

ID*	Functions	Descriptions				
		Pr.02-10.				
20	Digital down command (Down Command)	The Frequency command returns to zero when the drive stops and the displayed frequency is 0.00 Hz. If you select Pr.11-00, bit 7 = 1, the frequency is not saved.				
22	Clear the counter	ON: the current counter value is cleared and displays 0. The drive counts up when this function is disabled.				
23	Input the counter value (MI4)	ON: the counter value increases by one. Use the function with Pr.02-19.				
24	FWD JOG command	This function is valid when the source of the operation command is the external terminal. ON: the drive executes forward JOG. When executing the JOG command in torque mode, the drive automatically switches to speed mode. The drive returns to torque mode after the JOG command is complete.				
25	REV JOG command	This function is valid when the source of the operation command is the external terminal. ON: the drive executes reverse JOG. When executing the JOG command in torque mode, the drive automatically switches to speed mode. The drive returns to torque mode after the JOG command is complete.				
	Disable writing EEPROM	·				
38	function (parameter memory is disabled)	ON: writing to EEPROM is disabled. (Changed parameters are not saved after powering off.)				
41	HAND switch	 When the MI terminal switches to OFF, it executes a STOP command. Therefore, if the MI terminal switches to OFF during operation, the drive stops. Use the optional keypad KPC-CC01 to switch between HAND and AUTO. The drive stops first, and then switches to HAND or AUTO status. 				
42	AUTO switch	☑ The optional digital keypad KPC-CC01 displays the current status of the drive (HAND / OFF / AUTO). ☐				
51	Selection for PLC mode (bit 0)	PLC status bit 1 bit 0 Disable PLC function (PLC 0) 0 0 Trigger PLC to operate (PLC 1) 0 1 Trigger PLC to stop (PLC 2) 1 0				
52	Selection for PLC mode (bit 1)	No function 1 1				

ID*	Functions	Descriptions		
56	Local / Remote selection	Use Pr.00-29 to select for LOCAL / REMOTE mode (refer to Pr.00-29). When Pr.00-29 is not set to 0, the digital keypad KPC-CC01 displays the LOC / REM status.		
58	Enable fire mode (with RUN command)	When fire occurs, enable this terminal to make the drive enter the fire mode to force the drive to run. If the drive is in stop status, enable this terminal to make the drive enter the fire mode to force the drive to run according to Pr.06-80 settings. (Refer to Pr.06-80, 06-81, 06-88 for details)		
59	Enable fire mode (without RUN command)	When fire occurs, enable this terminal to make the drive enter the fire mode. If the drive is in stop status, enable this terminal to make the drive enter the fire mode, but the drive does not run. If the drive is in running status, enable this terminal to run the drive according to Pr.06-80 settings. (Refer to Pr.06-80, 06-81, 06-88 for details)		
69	Enable preheating function	When you set MI = 69, MI determines the preheating function whether is enabled or disabled.		
97	Multi-pump manual / auto switch	When you set MI = 97, you can use manual mode to select whether it's controlled by multi-pump system.		
100	Enable clean function	When you set MI = 100, you can enable clean function. Refer to Pr.12-53–12-64 for the clean function setting.		

02-09 UP / DOWN key mode

Default: 0

Settings 0: UP / DOWN by the acceleration / deceleration time

1: UP / DOWN constant speed (Pr.02-10)

2: Pulse signal (Pr.02-10)

3: External terminals UP / DOWN key mode


02-10 Constant Speed, Acceleration / Deceleration Speed of the UP / DOWN Key

Default:0.001


Settings 0.001–1.000 Hz / ms

- Use when the multi-function input terminals are set to 19, 20 (Digital UP / DOWN command). The frequency increases or decreases according to Pr.02-09 and Pr.02-10.
- When Pr.11-00 bit 7 = 1, the frequency is not saved. The Frequency command returns to zero when the drive stops, and the displayed frequency is 0.00 Hz. At this time, increasing or decreasing the Frequency command (F) by using the UP or DOWN key is valid only when the drive is running.
- When Pr.02-09 is set to 0: The increasing or decreasing Frequency command (F) operates according to the setting for acceleration or deceleration time (refer to Pr.01-12-01-19).


Chapter 12 Descriptions of Parameter Settings | MPD




When Pr.02-09 is set to 1: The increasing or decreasing Frequency command (F) operates according to the setting of Pr.02-10 (0.01-1.000 Hz/ms).



When Pr.02-09 is set to 2: The increasing or decreasing Frequency command (F) operates according to the setting of Pr.02-10.



When Pr.02-09 is set to 3: The increasing or decreasing Frequency command (F) operates according to the exponential curve.



Multi-function Input Response Time

Default: 0.005

Settings 0.000-30.000 sec.

- Use this parameter to set the response time of the digital input terminals MI1–MI7.
- To prevent interference from causing malfunction in the input of the digital terminals, executes operation after delaying the time set in this parameter when the terminal is triggered.

Multi-function Input Mode Selection

Default:0000

Settings 0000h-FFFFh

- The parameter setting is in hexadecimal.
- © 0: normally open (N.O.); 1: normally closed (N.C.)
- This parameter sets the status of the multi-function input signal (0: normally open; 1: normally closed) and it is not affected by the status of SINK / SOURCE.
- □ bit 0-bit 3 correspond to MI1-MI4.
- The default for bit 0 (MI1) is FWD terminal, and the default for bit 1 (MI2) is REV terminal. You cannot use this parameter to change the input mode when Pr.02-00 ≠ 0.
- Pou can change the terminal ON / OFF status through communications.

For example: MI3 is set to 1 (multi-step speed command 1) and MI4 is set to 2 (multi-step speed command 2).

Then the forward + second step speed command = $1001_2 = 9_{10}$.

As long as Pr.02-12 = 9 is set through communications, there is no need to wire any multifunction terminal to run forward with the second step speed.

bit 3	bit 2	bit 1	bit 0
MI4	MI3	MI2	MI1

Use Pr.11-42 bit 1 to select whether FWD / REV terminal is controlled by Pr.02-12 bit 0 and bit 1.

Multi-function Output 1 (RY1) Default:11 Multi-function Output 2 (RY2) Default: 0 Multi-function Output 3 (MO) Default: 0

Settings

- 0: No function
- 1: Indication during RUN
- 2: Operation speed reached
- 3: Desired frequency reached 1 (Pr.02-22)
- 4: Desired frequency reached 2 (Pr.02-24)
- 7: Over-torque 1 (Pr.06-06-08)
- 9: Drive is ready
- 10: Low voltage warning (Lv) (Pr.06-00)
- 11: Malfunction indication
- 13: Overheat warning (Pr.06-15)
- 15: Abnormal PID feedback
- 17: Count value reached, does not return to 0 (Pr.02-20)
- 18: Count value reached, return to 0 (Pr.02-19)
- 19: External interrupt B.B. input (Base Block)
- 20: Warning output
- 21: Over-voltage
- 22: Over-current stall prevention
- 23: Over-voltage stall prevention
- 24: Operation source
- 25: Forward command
- 26: Reverse command
- 29: Output when frequency ≥ Pr.02-34
- 30: Output when frequency < Pr.02-34
- 35: Error output selection 1 (Pr.06-23)
- 36: Error output selection 2 (Pr.06-24)
- 37: Error output selection 3 (Pr.06-25)
- 38: Error output selection 4 (Pr.06-26)
- 40: Speed reached (including STOP)
- 44: Low current output (use with Pr.06-71–Pr.06-73)
- 51: Analog output control for RS-485 interface
- 52: Output control for communication cards
- 53: Fire mode indication
- 67: Analog input level reached
- 69: Indication of preheating operation
- 75: Forward RUN status

76: Reverse RUN status

81: Indication of multi-pump system error (only Master)

☐ Use this parameter to set the function of multi-function terminals.

Summary of Function Settings (Take the normally open contact (N.O.) for example, closed: contacts are conducted)

ID*	Functions	Descriptions	
0	No function	Output terminal with no function	
1	Indication during RUN	Activate when the drive is not in STOP.	
2	Operation speed reached	Activate when output frequency of drive reaches to the setting frequency.	
3	Desired frequency reached 1 (Pr.02-22)	Activate when the desired frequency (Pr.02-22) is reached.	
4	Desired frequency reached 2 (Pr.02-24)	Activate when the desired frequency (Pr.02-24) is reached.	
7	Over torque 1	Activate when the drive detects over-torque. Pr.06-07 sets the over-torque detection level, and Pr.06-08 sets the over-torque detection time. (Refer to Pr.06-06-06-08)	
9	Drive is ready	Activate when the drive is ON with no error detected.	
10	Low voltage warning (Lv)	Activate when an extremely low voltage at DC side is detected. Activate when the DC bus voltage is too low. (refer to Pr.06-00 Low Voltage Level)	
11	Malfunction indication	Activate when fault occurs (except Lv stop).	
13	Overheat warning	Activate when IGBT or heat sink overheats to prevent the drive from shutting down due to overheating. (Refer to Pr.06-15)	
15	Abnormal PID feedback	Activate when the PID feedback signal error is detected.	
17	Count value reached (Pr.02-20)	When the drive executes external counter, this contact activates if the count value is equal to the setting value for Pr.02-20. This contact deactivates when the setting value of Pr.02-20 > the setting value of Pr.02-19.	
18	Count value reached (Pr.02-19)	When the drive executes the external counter, this contact activates if the count value is equal to the setting value for Pr.02-19.	
19	External interrupt B.B. Input (Base Block)	Activate when external interrupt (B.B.) occurs in the drive and stops outputting.	
20	Warning output	Activate when a warning is detected.	
21	Over-voltage	Activate when over-voltage is detected.	
22	Over-current stall prevention	Activate when the over-current stall prevention is detected.	
23	Over-voltage stall prevention	Activate when over-voltage stall prevention is detected. Activate when the source of operation command is n controlled by the digital keypad (Pr.00-21 ≠ 0).	
24	Operation source		
25 Forward command Activate when the operation direction is forward.		Activate when the operation direction is forward.	
26	Reverse command	Activate when the operation direction is reverse.	

ID*	Functions	Descriptions			
	Output when frequency ≥	Activate when frequency is ≥ Pr.02-34 (actual output H ≥ Pr.02-			
29	Pr.02-34	34).			
30	Output when frequency <	Activate when frequency is < Pr.02-34 (actual output H < Pr.02-			
- 30	Pr.02-34	34).			
35	Error output selection 1 (Pr.06-23)	Activate when Pr.06-23 is ON.			
36	Error output selection 2 (Pr.06-23)	Activate when Pr.06-24 is ON.			
37	Error output selection 3 (Pr.06-23)	Activate when Pr.06-25 is ON.			
38	Error output selection 4 (Pr.06-23)	Activate when Pr.06-26 is ON.			
40	Speed reached (including	Activate when	the drive's output	frequency	y reaches the setting
40	Stop)	frequency or s	topped.		
44	Low current output	Use this functi	on with Pr.06-71-P	r.06-73.	
51	51: Analog output control	For RS-485 communication control output.			
	for RS-485 interface				
			tput through the co		
		Physical	, CMM-PD02, CMM Related	I-DINUZ, CI	VIIVI-EIPUZ)
52	Output control for	terminal	Parameters	Attribute	Address
	communication cards	RY1	Pr.02-13 = 52	RW	The bit0 of 2640H
		RY2	Pr.02-14 = 52	RW	The bit1 of 2640H
		MO	Pr.02-16 = 52	RW	The bit3 of 2640H
53	Fire mode indication		MI setting 58 or 59		
		The multi-function output terminals operate when the analog			
		input level is between the high level and the low level.			
		Pr.03-44: Select one of the analog input channels (Al1, Al2) to			
		be compared. Pr.03-45: The high level for the analog input, default is 50%.			
67	Analog input level reached	Pr.03-46: The low level for the analog input, default is 30%.			
		If analog input > Pr.03-45, the multi-function output terminal			
		operates.			
		If analog input < Pr.03-46, the multi-function output terminal			
		stops outputtir	ng.		·
69	Indication of preheating operation	Activate when enabling the function.			
		When the drive runs FWD, the output terminal for forward			
75	Forward RUN status	running is closed; when the drive stops, the output terminal for			
		forward running is open.			
		When the drive runs REV, the output terminal for reverse			
76	Reverse RUN status	running is closed; when the drive stops, the output terminal for			
		reverse running is open.			
81	Indication of multi-pump				system are failed, the
	system error (only Master)	contact is closed.			

Multi-function Output Direction

Default:0000

Settings 0000h-FFFFh

- The parameter setting is in hexadecimal.
- (0: N.O.; 1: N.C.)
- This parameter is set by a bit. If the bit is 1, the corresponding multi-function output acts in an opposite way. Example: Assume Pr.02-13 = 1 (indication when the drive is operating). If the output is positive, and the bit is set to 0, then Relay is ON when the drive runs and is OFF when the drive stops. On the contrary, if the output is negative, and the bit is set to 1, then the Relay is OFF when the drive runs and is ON when the drive stops.

bit3	bit2	bit1	bit0
MO	Reserved	Reserved	RY


7 Terminal Counting Value Reached (returns to 0)

Default: 0

Settings 0-65500

- ☐ The counting function is enabled when Pr.02-19≠0.
- You can set the input point for the counter using the multi-function terminal MI4 as a trigger terminal (set Pr.02-04 to 23). When counting is completed, the specified multi-function output terminal is activated (Pr.02-13 or Pr.02-16 is set to 18).

The timing diagram below shows that when counting to 5, RY1 activates and displays 0.



The timing diagram of the external counting terminals and the counting value reached


Preliminary Counting Value Reached (does not return to 0)

Default: 0

Settings 0-65500

- Use this parameter with Pr.02-19.
- When the count value counts from 1 to reach this value, the corresponding multi-function output terminal is activated (Pr.02-13 and Pr.02-16 are set to 17) and keeps counting to the last count value.
- You can use this parameter as the end of counting to make the drive run from the low speed to stop.

The timing diagram is RY1 activates when the count value is three, and the display returns to zero when counts to five:



The timing diagram of the external counting terminals and the counting value reached

O2-22 Desired Frequency Reached 1

Default:150.00

Settings 0.00-599.00 Hz

O2-24 Desired Frequency Reached 2

Default:150.00

Settings 0.00-599.00 Hz

Default:2.00


Settings 0.00-599.00 Hz

7 02-25 The Width of the Desired Frequency Reached 2

Default:2.00

Settings 0.00–599.00 Hz

Once the output speed (frequency) reaches the desired speed (frequency), if the corresponding multi-function output terminal is set to 3 or 4 (Pr.02-13, Pr.02-14, and Pr.02-16), this multi-function output terminal is "closed".



Output Frequency Setting for Multi-function Output Terminal

Default:0.00

Settings 0.00-599.00 Hz

O2-35 External Operation Control Selection after Reset and Reboot

Default: 0

Settings 0: Disabled

- 1: Drive runs if the RUN command remains after reset or reboot.
- 2: After re-powering ON, execute the drive according to the operating status before it was OFF.

Setting value 1:

- Situation 1-1: After powering ON the drive, if the external terminal for RUN stays ON and Pr.00-21 = 1 which operation source is from external terminals, then the drive runs. This is the setting of the operation with power ON.
- Situation 1-2: As mentioned above, if the built-in PLC function is enabled, then you have to set Pr.04-57 bit0 = 1.
- Situation 2: After clearing a fault once a fault is detected and the external terminal for RUN stays ON, you can run the drive by pressing the RESET key.


Setting value 2:

This parameter is when the drive is powered ON, the drive executes running if the RUN command (Pr.07-35) remains in the running state and after the delay time set by Pr.07-36. That is the setting of power-on operation requirements.

02-50 Display the Status of Multi-function Input Terminal


Default: Read only

Settings Monitor the status of the Multi-function Input Terminal



Example:


When Pr.02-50 is 0004h (hex), that is, the value is 4 (decimal), and displays 0100 (binary). It means that MI3 is ON.



02-51 Display the Status of Multi-function Output Terminal


Default: Read only

Settings Monitor the status of the Multi-function Output Terminal



Example:


When Pr.02-51 is 0009h (hex), that is, the value is 9 (decimal), and displays 1001 (binary). It means that RY1 and MO are ON.



02-52 Display the External Multi-function Input Terminals Used by PLC


Default: 0

Settings 0-65535



Example:


When Pr.02-52 Is 0009h (hex), that is, the value is 9 (decimal), and displays 1001 (binary). It means that MI1 and MI4 are used by PLC.



02-53 Display the External Multi-function Output Terminals Used by PLC


Default: 0

Settings 0-65535



Example:

When Pr.02-53 is 0009h (hex), that is, the value is 9 (decimal), and displays 1001 (binary). It means that RY1 and MO are used by PLC.



02-54 Display the Frequency Command Executed by External Terminal

Default: Read only

Settings Read only

When you set the source of the Frequency command as the external terminal, if Lv or Fault occurs, the external terminal Frequency command is saved in this parameter.

Preheating DC current level

Default: 0

Settings 0–100%

- This parameter controls the level of the preheating DC current input to the motor. The percentage of the preheating DC current equals to the percentage of motor rated current (Pr.00-01). Therefore, when you set this parameter, increase the level slowly to reach the desired preheating temperature.
- \square Pr.02-72 is defined as direct current, so the actual output current is Pr.02-72 x $\sqrt{2}$.
- Related parameters: Pr.02-73 Preheating DC Current Duty Cycle, Pr.02-13 and Pr.02-16 Multifunction Output Relay 69: Indication of Preheating Function, Pr.02-01–02-05 Multi-function Input Terminal 69: Auto-activate preheating function.

Preheating DC Current Duty Cycle


Default: 0

Settings 0-100%


This parameter is to set up the duty cycle of the preheating DC current input to the motor. 0–100% corresponds to 0–10 sec. If the setting is 0%, there is no output current from the motor

drive; if the setting is 100%, there is continuous output DC current. For example, when the setting of this parameter is 50%, the cycle time is the time spent to input current to motor for 5 seconds and stop inputting for 5 seconds. When MI #69 is enabled, this parameter operates periodically with MI#69 until the motor drive starts to run the motor or until MI#69 is disabled.


- Preheating function works only when the setting value for Pr.02-72 and Pr.02-73 are not 0.
- If user doesn't set MI=69 (enable preheating function), this function activates when the first operation stops, or immediately activates after rebooting.
- When MI=69 (enable preheating function) is enabled, MI=69 controls the start and stop of preheating function.
- The figure below shows the timing relationship when MI=69 enable preheating function is disabled and when preheating DC current is enabled and cycle time is 50%. When the motor drive is stopped, the preheating function starts to output DC current continuously.



The figure below shows the timing relationship when MI=69 enable preheating function is enabled and when preheating DC current is enabled and cycle time is 50%.



☐ The figure below shows the timing relationship between preheating function and enabling DC brake.



[This page intentionally left blank]

03 Analog Input / Output Parameters

✓ You can set this parameter during operation.

\mathcal{M}	03-00	Al1 Analog Input Selection
		Default:5
\mathcal{M}	03-01	AI2 Analog Input Selection
		Default: 0

Settings

- 0: No function
- 1: Frequency command
- 4: PID target value
- 5: PID feedback signal
- 6: Thermistor input value (PTC-130 / KTY-84-130)
- 11: PT100 thermistor input value
- 13: PID compensation value
- 21: Pressure inputs (outlet side)
- 22: Pressure inputs (inlet side)
- 23: Flow inputs
- When you use analog input as the PID reference target input, you must set Pr.00-20 to 2 (external analog input).
 - Pr.03-00 = 1: To be frequency command when PID uses frequency as target value.
 - Pr.03-00 = 5: To be PID feedback signal when PID uses the pressure feedback signal as reference value, and Pr.08-00 = 1 (negative PID feedback) at the same time.
- When using the frequency command, the corresponding value for 0–10 V / 4–20 mA is 0–maximum operation frequency (Pr.01-00).
- Pr.00-25 should set as the unit of pressure when Pr.03-00 = 21 (outlet pressure), and Pr.00-38 should set as the unit of pressure when Pr.03-01 = 22 (inlet pressure), otherwise flow estimation module cannot work correctly.
- Pr.00-25 should set as the unit of flow when Pr.03-00 = 23 (flow inputs), otherwise cavitation detection module cannot work correctly.
- When using water pump related functions, connect Al1 to outlet pressure, connect Al2 to inlet pressure. The settings are as follows:

Selections of control	Pr.03-00: Al1 (outlet pressure)	Pr.03-01: Al2 (inlet pressure)
Pressure feedback control	5: PID feedback signal	
Q-H method (Pr.12-20 = 1)	21: Pressure inputs (outlet side)	22: Pressure inputs (inlet side)
Q-H method (Pr.12-20 = 1) + Pressure feedback control	5: PID feedback signal	22: Pressure inputs (inlet side)
Cavitation detection (Pr.12-18 = 2)	23: Flow inputs	22: Pressure inputs (inlet side)
Cavitation detection (Pr.12-18 = 1) + Q-H method (Pr.12-20 = 1) + Pressure feedback control	5: PID feedback signal (If use with pressure feedback control at the same time, the flow meter cannot be used directly, but can estimate by Q-H method.	22: Pressure inputs (inlet side)


Pr.03-11 = 200%

Al1 Analog Input Bias 03-03 Default: 0 Settings -100.0-100.0% Sets the corresponding AI1 voltage for the external analog input 0. Refer to Pr.03-11 for details. **03-04** Al2 Analog Input Bias Default: 0 Settings -100.0–100.0% Sets the corresponding Al2 voltage for the external analog input 0. Refer to Pr.03-12 for details. Al1 Positive / Negative Bias Mode 03-08 Al2 Positive / Negative Bias Mode Default: 0 Settings 0: No bias 4: Bias serves as the center Using negative bias to set the frequency greatly reduces the noise interference. In a noisy environment, do NOT use signals less than 1V to set the drive's operation frequency. Al1 Analog Input Gain 03-11 03-12 AI2 Analog Input Gain Default:100.0 Settings -500.0-500.0% Pr.03-03-03-12 are used when the Frequency command source is the analog voltage or current signal. Use this function when user's pressure sensor have to detect negative value For example: if Al1 needs to use a pressure sensor 0–10 V of voltage type, and the detection range is -1.0–9.0 bar that the total is10 bar, then follow the steps below: Setting: 0.0-10.0 bar, Pr.00-25 = 353, Pr.00-26 = 10.02. Set the bias: 10%, to make the corresponding point of 0.0 bar change from 0V to 1V, the detection range of pressure sensor changes to -1.0-9.0 bar, and Pr.03-03 = 10% 3. Set the bias mode: Bias serves as the center, Pr.03-07 = 4

4. If you want the pressure sensor to respond more quickly, then set the gain to be 200%,


Refer to the graphic expression below:

1. Step1: Pr.00-25 = 353, Pr.00-26 = 10.0




2. Step2: Pr.03-03 = 10%

Step3: Pr.03-07 = 4



3. Step4: Pr.03-11 = 200%



Chapter 12 Descriptions of Parameter Settings MPD
W 03-15 Al1 Analog Input Filter Time
M 03-16 Al2 Analog Input Filter Time
Default:0.01
Settings 0.00–20.00 sec.
Analog signals inputted by the control terminals Al1 and Al2 mostly have noise. Noise affects the
stability to control. Use the Input Noise Filter to create a more stable system.
When the time constant setting is too large, the control is stable, but the control response is slow.
When the time constant setting is too small, the control response is faster, but the control may
be unstable. For optimal setting, adjust the setting based on the control stability or the control
response.
√ 03-19 Signal Loss Selection For Al1 Analog Input 4–20 mA
Default: 0
Settings 0: Disabled
Settings 0: Disabled 1: Continue operation at the last frequency
g .
1: Continue operation at the last frequency
1: Continue operation at the last frequency 2: Decelerate to 0 Hz
1: Continue operation at the last frequency 2: Decelerate to 0 Hz 3: Stop immediately and display ACE
1: Continue operation at the last frequency 2: Decelerate to 0 Hz 3: Stop immediately and display ACE Determines the treatment when the 4–20 mA signal is lost (Al1 (Pr.03-28 = 2)).
1: Continue operation at the last frequency 2: Decelerate to 0 Hz 3: Stop immediately and display ACE Determines the treatment when the 4–20 mA signal is lost (Al1 (Pr.03-28 = 2)). When the setting is 1 or 2, the keypad displays the warning code "ANL". It keeps blinking until
1: Continue operation at the last frequency 2: Decelerate to 0 Hz 3: Stop immediately and display ACE Determines the treatment when the 4–20 mA signal is lost (AI1 (Pr.03-28 = 2)). When the setting is 1 or 2, the keypad displays the warning code "ANL". It keeps blinking until the AI2 signal is recovered.
1: Continue operation at the last frequency 2: Decelerate to 0 Hz 3: Stop immediately and display ACE Determines the treatment when the 4–20 mA signal is lost (AI1 (Pr.03-28 = 2)). When the setting is 1 or 2, the keypad displays the warning code "ANL". It keeps blinking until the AI2 signal is recovered. When the drive stops, the condition that causes the warning does not exist, so the warning
1: Continue operation at the last frequency 2: Decelerate to 0 Hz 3: Stop immediately and display ACE Determines the treatment when the 4–20 mA signal is lost (AI1 (Pr.03-28 = 2)). When the setting is 1 or 2, the keypad displays the warning code "ANL". It keeps blinking until the AI2 signal is recovered. When the drive stops, the condition that causes the warning does not exist, so the warning automatically disappears.

1: Continue operation at the last frequency

2: Decelerate to 0 Hz

3: Stop immediately and display ACE

- Determines the treatment when the 4–20 mA signal is lost (Al2 (Pr.03-29 = 2)).
- When the setting is 1 or 2, the keypad displays the warning code "ANL". It keeps blinking until the Al2 signal is recovered.
- When the drive stops, the condition that causes the warning does not exist, so the warning automatically disappears.

03-20 Multi-function Output (AFM)

Default: 0

Settings 0-23

Summary of Function Settings

ID*	Functions	Descriptions
0	Output frequency (Hz)	Maximum frequency Pr.01-00 is processed as 100%.
1	Frequency command (Hz)	Maximum frequency Pr.01-00 is processed as 100%.
2	Motor speed (Hz)	Maximum frequency Pr.01-00 is processed as 100%.

ID*	Functions	Descriptions	
3	Output current (rms)	(2.5 X drive rated current) is processed as 100%.	
4	Output voltage	(2 X motor rated voltage) is processed as 100%.	
5	DC bus voltage	450 V (900 V) = 100%	
6	Power factor	-1.000–1.000 = 100%	
7	Power	(2 X drive rated power) is processed as 100%.	
9	Al1 Analog input	0–10 V = 0–100%	
10	AI2 Analog input	0–10 V = 0–100%	
21	RS-485 analog output	For InnerCOM analog output	
22	Communication card analog output	Communication analog output for CMMP-BT01, CMM-PD02, CMM-DN02, CMM-EIP02 Terminal Address AFM 26A0H	
23	Constant voltage output	Pr.03-32 controls the voltage output level. 0–100% of Pr.03-32 corresponds to 0–10 V for AFM.	

∧ 03-21 AFM Analog Output Gain

Default:100.0

Settings 0-500.0%

Adjusts the voltage level outputted to the analog meter from the analog signal (Pr.03-20) output terminal AFM of the drive.


∧ 03-22 AFM Analog Output in REV Direction

Default: 0

Settings 0: Absolute value in output voltage

1: Reverse output 0 V; forward output 0-10 V

2: Reverse output 5-0 V; forward output 5-10 V



Selections for the analog output direction

W 03-27 AFM Output Bias

Default:0.00

Settings -100.00-100.00%

- \square Example 1: AFM 0-10 V is set to the output frequency, the output equation is 10V \times (output frequency / Pr.01-00) x Pr.03-21 + 10V x Pr.03-27
- This parameter sets the corresponding voltage of the analog output 0.

∧ 03-28 Al1 Terminal Input Selection

Default: 2

Settings 0: 0-10 V

1: 0–20 mA 2: 4–20 mA

Use DIP switch to change voltage mode and current mode, refer to Chapter 06 for Al1 terminal instruction.

03-29 Al2 Terminal Input Selection

Default: 2

Settings 0: 0-10 V

1: 0–20 mA

2: 4-20 mA

Use DIP switch to change voltage mode and current mode, refer to Chapter 06 for AI2 terminal instruction.

03-30 PLC Analog Output Terminal Status

Default: 0

Settings bit 0: Reserved

bit 1: AFM

- Displays the external multi-function output terminals used by PLC.
- Use DIP switch to change voltage mode and current mode, refer to Chapter 06 for Al1 terminal instruction.

Weights
$$2^{15}$$
 2^{14} 2^{13} 2^{12} 2^{11} 2^{10} 2^{9} 2^{8} 2^{7} 2^{6} 2^{5} 2^{4} 2^{3} 2^{2} 2^{1} 2^{0}

NOTE
$$2^7 = 128$$
 $2^6 = 64$ $2^5 = 32$ $2^4 = 16$ $2^3 = 8$ $2^2 = 4$ $2^1 = 2$ $2^0 = 1$

Example: When Pr.03-30 displays 0001h (hex), it means that AFM is used by PLC.

Display value=bit $0x2^{\circ}$ = $1x2^{\circ}$ = 1

∧ 03-32 AFM DC Output Setting Level

Default:0.00

Settings 0.00-100.00%

N U	3-35 AFM Ou	tput Filter Time	
			Default:0.01
	Settings	0.00-20.00 sec.	
// 0	3-44 Multi-fun	ction Output (MO) by AI Level Sou	rce
		· · · · · ·	Default: 0
	Settings	0: Al1	
	· ·	1: AI2	
// 0	3-45 Al1 Uppe	er Level 1	
			Default:50
	Settings	-100–100%	
« 0		er Level 2	
,	-		Default:10
	Settings	-100–100%	Doladiii 10
~ 0		er Level 1	
<i>/</i>	7 112 Oppo	01 20 001 1	Default:50
	Settings	-100–100%	Default.00
~		er Level 2	
<i>></i>	3-40 AIZ LOW	ei Levei Z	Default:10
	Cottingo	100 1000/	Delauit. 10
m		-100–100%	ouroe in Dr 02 44
	•	input level reached, to choose Al level so	
		e MO activates when the AI input level	is higher than the Pl.03-45, the MO
	•	input is lower than the Pr.03-46.	is higher than the Dr.O.2 47; the MO
	If $Pr.03-44 = 1$, th	e MO activates when the AI input level	is higher than the Pr.03-47: the MO
	If Pr.03-44 = 1, th stops when the AI	e MO activates when the AI input level input is lower than the Pr.03-48.	
	If Pr.03-44 = 1, th stops when the AI	e MO activates when the AI input level	
Д	If Pr.03-44 = 1, th stops when the Al When setting level	e MO activates when the AI input level input is lower than the Pr.03-48.	
Д	If Pr.03-44 = 1, th stops when the Al When setting level	e MO activates when the AI input level input is lower than the Pr.03-48. s, Pr.03-45 > Pr.03-46, Pr.03-47 > Pr.03-	
Д	If Pr.03-44 = 1, th stops when the Al When setting level 3-50 Analog I	e MO activates when the AI input level input is lower than the Pr.03-48. s, Pr.03-45 > Pr.03-46, Pr.03-47 > Pr.03-	48
Д	If Pr.03-44 = 1, th stops when the Al When setting level	e MO activates when the AI input level input is lower than the Pr.03-48. s, Pr.03-45 > Pr.03-46, Pr.03-47 > Pr.03-47 nput Curve Selection 0: Normal curve	48
Д	If Pr.03-44 = 1, th stops when the Al When setting level 3-50 Analog I	e MO activates when the AI input level input is lower than the Pr.03-48. s, Pr.03-45 > Pr.03-46, Pr.03-47 > Pr.03-47 nput Curve Selection 0: Normal curve 1: Three-point curve of AI1	48
₩ 0	If Pr.03-44 = 1, th stops when the Al When setting level 3-50 Analog I Settings	e MO activates when the AI input level input is lower than the Pr.03-48. s, Pr.03-45 > Pr.03-46, Pr.03-47 > Pr.03-47 pr.	48
₩ 0	If Pr.03-44 = 1, th stops when the Al When setting level 3-50 Analog I Settings	e MO activates when the AI input level input is lower than the Pr.03-48. s, Pr.03-45 > Pr.03-46, Pr.03-47 > Pr.03-47 nput Curve Selection 0: Normal curve 1: Three-point curve of AI1	48 Default: 0
₩ 0	If Pr.03-44 = 1, th stops when the Al When setting level 3-50 Analog I Settings All Lower	e MO activates when the AI input level input is lower than the Pr.03-48. s, Pr.03-45 > Pr.03-46, Pr.03-47 > Pr.03-47 nput Curve Selection 0: Normal curve 1: Three-point curve of AI1 2: Three-point curve of AI2 est Point	48
₩ 0	If Pr.03-44 = 1, th stops when the Al When setting level 3-50 Analog I Settings All Lower	e MO activates when the AI input level input is lower than the Pr.03-48. s, Pr.03-45 > Pr.03-46, Pr.03-47 > Pr.03-48 = Pr.03-46, Pr.03-48 = Pr.03-46, Pr.03-48 = Pr.	48 Default: 0
₩ 0	If Pr.03-44 = 1, th stops when the Al When setting level 3-50 Analog I Settings All Lower	e MO activates when the AI input level input is lower than the Pr.03-48. s, Pr.03-45 > Pr.03-46, Pr.03-47 > Pr.03-48 = 0, 0.00-10.00 V Pr.03-28 = 1, 0.00-20.00 mA	48 Default: 0
₩ 0	If Pr.03-44 = 1, th stops when the Al When setting level 3-50 Analog I Settings 3-51 Al1 Lower Settings	e MO activates when the AI input level input is lower than the Pr.03-48. s, Pr.03-45 > Pr.03-46, Pr.03-47 > Pr.03-45. nput Curve Selection 0: Normal curve 1: Three-point curve of AI1 2: Three-point curve of AI2 est Point Pr.03-28 = 0, 0.00–10.00 V Pr.03-28 = 1, 0.00–20.00 mA Pr.03-28 = 2, 4.00–20.00 mA	48 Default: 0
₩ 0	If Pr.03-44 = 1, th stops when the Al When setting level 3-50 Analog I Settings 3-51 Al1 Lower Settings	e MO activates when the AI input level input is lower than the Pr.03-48. s, Pr.03-45 > Pr.03-46, Pr.03-47 > Pr.03-48 = 0, 0.00-10.00 V Pr.03-28 = 1, 0.00-20.00 mA	Default: 0 Default: 4.00
₩ 0	If Pr.03-44 = 1, th stops when the AI When setting level 3-50 Analog I Settings 3-51 Al1 Low Settings	e MO activates when the AI input level input is lower than the Pr.03-48. s, Pr.03-45 > Pr.03-46, Pr.03-47 > Pr.03-48 = Qr.000-10.00 V Pr.03-28 = Qr.000-10.00 V Pr.03-28 = Qr.000-20.00 mA Pr.000-20.00 mA Pr.0	48 Default: 0
 □ ✓ ✓ ✓ ✓ ✓ 	If Pr.03-44 = 1, th stops when the AI When setting level 3-50 Analog I Settings 3-51 Al1 Low Settings 3-52 Al1 Prop	e MO activates when the AI input level input is lower than the Pr.03-48. s, Pr.03-45 > Pr.03-46, Pr.03-47 > Pr.03-48 = 0, 0.00-10.00 V Pr.03-28 = 0, 0.00-10.00 V Pr.03-28 = 1, 0.00-20.00 mA Pr.03-28 = 2, 4.00-20.00 mA Pr.03-20.00 mA Pr.03-20.0	Default: 0 Default: 4.00
 □ ✓ ✓ ✓ ✓ ✓ 	If Pr.03-44 = 1, th stops when the AI When setting level 3-50 Analog I Settings 3-51 Al1 Low Settings	e MO activates when the AI input level input is lower than the Pr.03-48. s, Pr.03-45 > Pr.03-46, Pr.03-47 > Pr.03-48 = 0, 0.00-10.00 V Pr.03-28 = 0, 0.00-10.00 V Pr.03-28 = 1, 0.00-20.00 mA Pr.03-28 = 2, 4.00-20.00 mA Pr.03-20.00 mA Pr.03-20.0	Default: 4.00 Default: 0.00
 □ ✓ ✓ ✓ ✓ ✓ 	If Pr.03-44 = 1, th stops when the Al When setting level 3-50 Analog I Settings 3-51 Al1 Low Settings 3-52 Al1 Prop Settings 3-53 Al1 Mid-	e MO activates when the AI input level input is lower than the Pr.03-48. s, Pr.03-45 > Pr.03-46, Pr.03-47 > Pr.03-48 = 0, 0.00-10.00 V Pr.03-28 = 0, 0.00-10.00 V Pr.03-28 = 1, 0.00-20.00 mA Pr.03-28 = 2, 4.00-20.00 mA Pr.03-20.00 mA Pr.03-20.0	Default: 0 Default: 4.00

Pr.03-28 = 1, 0.00–20.00 mA Pr.03-28 = 2, 4.00–20.00 mA

Default:50.00

Settings 0.00-100.00%

03-55 All Highest Point

Default:20.00

Settings Pr.03-28 = 0, 0.00–10.00 V Pr.03-28 = 1, 0.00–20.00 mA Pr.03-28 = 2, 4.00–20.00 mA

All Proportional Highest Point

Default:100.00

Settings 0.00-100.00%


- When Pr.03-28 = 0, the Al1 setting is 0–10 V and the unit is voltage (V). When Pr.03-28 \neq 0, the Al1 setting is 0–20 mA or 4–20 mA and the unit is current (mA).
- When you set the analog input Al1 to the frequency command, 100% corresponds to Fmax (Pr.01-00 Maximum Operation Frequency).
- Setting range: Pr.03-51 < Pr.03-53 < Pr.03-55

 The values for three proportional points (Pr.03-52, Pr.03-54 and Pr.03-56) have no limits. There is a linear calculation between two points.
- The output percentage becomes 0% when the Al1 input value is lower than the lowest point setting.

Example:

Pr.03-51 = 1V, Pr.03-52 = 10% The output is 0 % when Al1 input is lower than 1V. If the Al1 input swings between 1 V and 1.1 V, the drive's output frequency oscillates between 0% and 10%.

Pr.03-51 = 1 V; Pr.03-52 = 10% Pr.03-53 = 5 V; Pr.03-54 = 50% Pr.03-55 = 10 V; Pr.03-56 = 100%



√ 03-57 Al2 Lowest Point

Default:4.00

Settings Pr.03-29 = 0, 0.00-10.00 V

Pr.03-29 = 1, 0.00-20.00 mA

Pr.03-29 = 2, 4.00-20.00 mA

\varkappa	03-58 Al2 Prop	portional Lowest Point	
			Default:0.00
	Settings	0.00-100.00%	
\varkappa	03-59 Al2 Mid-	point	
			Default:12.000
	Settings	Pr.03-29 = 0, 0.00–10.00 V	
		Pr.03-29 = 1, 0.00–20.00 mA	
		Pr.03-29 = 2, 4.00–20.00 mA	
\varkappa	03-60 Al2 Prop	portional Mid-point	
			Default:50.00
	Settings	0.00-100.00%	
\mathcal{M}	03-61 Al2 High	nest Point	
			Default:20.00
	Settings	Pr.03-29 = 0, 0.00–10.00 V	
		Pr.03-29 = 1, 0.00–20.00 mA	
		Pr.03-29 = 2, 4.00–20.00 mA	
\varkappa	03-62 Al2 Prop	portional Highest Point	
			Default:100.00
	Settings	0.00-100.00%	
	When Pr.03-29 ≠ 0), the AI2 is 0–20 mA or 4–20 mA	and the unit is current (mA).
	When you set the	analog input Al2 to be the frequency	uency command, 100% corresponds to Fmax
	(Pr.01-00 Maximur	m Operation Frequency).	
	Setting range: Pr.0	03-57 < Pr.03-59 < Pr.03-61	
	The values for three	ee proportional points (Pr.03-58,	$\mbox{Pr.03-60}$ and $\mbox{Pr.03-62)}$ have no limits. There
	is a linear calculati	on between two points.	
	The output percer	ntage becomes 0% when the A	12 input value is lower than the lowest point
	setting.		
	Example:		
	Pr.03-57 = 2 mA, F	Pr.03-58 = 10% The output is 0 %	when Al2 input is lower than 2 mA.
	If the ACI input s	swings between 2 mA and 2.1	$\ensuremath{mA},$ the drive's output frequency oscillates

between 0% and 10%.

[This page intentionally left blank]

04 Multi-step Speed Parameters


✓ You can	set this	parameter	during	operation.
/ IOU OUII		parameter	auiiiia	operation.

×	04-00	1st Step Speed Frequency
N	04-01	2nd Step Speed Frequency
×	04-02	3rd Step Speed Frequency
×	04-03	4th Step Speed Frequency
×	04-04	5th Step Speed Frequency
×	04-05	6th Step Speed Frequency
×	04-06	7th Step Speed Frequency
×	04-07	8th Step Speed Frequency
×	04-08	9th Step Speed Frequency
×	04-09	10th Step Speed Frequency
×	04-10	11th Step Speed Frequency
×	04-11	12th Step Speed Frequency
×	04-12	13th Step Speed Frequency
×	04-13	14th Step Speed Frequency
N	04-14	15th Step Speed Frequency

Default: 0.00

Settings 0.00–599.00 Hz

- Use the multi-step speed command 1–4 / multi-step position command 1–4 of the multi-function input terminals (refer to the setting 1–4 of Pr.02-01–02-04 Multi-function Input Command) to select the multi-step speed command (the maximum is 15th step speed). Pr.04-00 to Pr.04-14 set the multi-step speed (frequency) as shown in the following diagram.
- The external terminal / digital keypad / communication controls the RUN and STOP commands with Pr.00-21.
- You can set each multi-step speed (frequency) between 0.00–180.00 Hz during operation.
- Explanation for the timing diagram of the multi-step speed and external terminals: The related parameter settings are:
 - 1. Pr.04-00–Pr.04-14: set the 1st–15th multi-step speed (to set the frequency of each step speed).
 - 2. Pr.02-01–Pr.02-04: set the multi-function input terminals (multi-step speed command 1–4).
- Related parameters:
 - Pr.01-22 JOG frequency setting
 - Pr.02-01 multi-function input command 1 (MI1)
 - Pr.02-02 multi-function input command 2 (MI2)
 - Pr.02-03 multi-function input command 3 (MI3)
 - Pr.02-04 multi-function input command 4 (MI4)



×	04-50	PLC Buffer 0
×	04-51	PLC Buffer 1
×	04-52	PLC Buffer 2
×	04-53	PLC Buffer 3
×	04-54	PLC Buffer 4
×	04-55	PLC Buffer 5
×	04-56	PLC Buffer 6

Default: 0

Settings 0-65535

- If the built-in PLC function is not loaded in, then PLC buffer 0–19 (Pr.04-50–04-69) and PLC application parameters (Pr.04-70–04-99) can be flexibly used for PLC function, its setting range is 0–65535, and the default is 0.
- If the built-in PLC function is loaded in, Pr.04-50–04-99 become the settings for the built-in PLC function which is enabled. See the following pages for the explanations.
- After enabling the built-in PLC function, PLC buffer 0-6 are disabled.
- Refer to chapter 15 PLC Function Applications for the way to enable the built-in PLC function.

Default: 0

04-57 Pump System Configuration Setting

	Settings	Source of frequency bit 0–3	00x0h: Digital keypad 00x1h: RS-485 communication (COM2) 00x8h: Communication card (does not include CANopen card)
		Source of operation bit 4–7	000xh: Digital keypad 001xh: RS-485 communication (COM2) 002xh: External terminals (MI1) 005xh: Communication card (does not include CANopen card)
		bit 8	Set to be backup master.
		bit 9	Display a PL00 warning when the backup master becomes the master.
Thi	e naramete	ar ie to eat th	se multi-nump configuration of the built-in PLC function. Refer to

This parameter is to set the multi-pump configuration of the built-in PLC function. Refer to chapter 15 PLC Function Applications for the way to enable the built-in PLC function.

Do the settings according to the different system statuses, refer to the table below.

Because the backup master continues the pressure command from the master, it's invalid to set

the source of frequency.

Pr.04-57	Suitable system
bit 0–3, source of frequency	The master (station address is 1)
bit 4–7, source of operation	The master (station address is 1), the backup master
bit 8, set to be the backup master	Backup master
bit 9, display a PL00 warning when the backup master becomes the master.	Backup master

Example: When a multi-pump system is established, the AC motor drives connect with each other by Modbus communication, thus Pr.00-20, Pr.00-21 have to be RS-485 (COM1). The default of Pr.04-57 for the master of the multi-pump system is by using digital keypad, users press RUN, STOP button to control system, and press UP / DOWN to set target pressure. If the master has to connect with HMI, then set Pr.04-57 to be RS-485 (COM2), and connect with HMI and the COM2 of the master, now HMI can control the operation and frequency command of the master. Take notice of this, you cannot control the system by pressing RUN and STOP when using HMI.

When switching frequency command, the system takes the present source of frequency as a reference of target pressure. For example, if the frequency command is from the communication card, the system operates with 10 bar according to the target pressure of the communication card; but when the frequency command is from Modbus, the system operates with 4 bar according to the target pressure of Modbus.

Switch the operation or stop by using MI1 when bit 4–7 set to be 002xh, refer to Pr.02-00 for more details.

Source of operation Source of frequency	000xh: Digital keypad	001xh: RS-485 communication	002xh: External terminal (MI1)	005xh: Communication card (does not include CANopen card)
00x0h:	Hex: 0000h	Hex: 0010h	Hex: 0020h	Hex: 0050h
Digital keypad	Decimal: 0	Decimal: 16	Decimal: 32	Decimal: 80
00x1h: RS-485 communication	Hex: 0001h Decimal: 1	Hex: 011h Decimal: 17	Hex: 021h Decimal: 33	Hex: 051h Decimal: 81
00x8h: Communication card (does not include CANopen card)	Hex: 0008h Decimal: 8	Hex: 0018h Decimal: 24	Hex: 0028h Decimal: 40	Hex: 0058h Decimal: 88

bit 8: Set to be backup master. If you want the station address to be backup master, then set bit 8 to be 1, and key in 256.

If you want a warning is displayed on the digital keypad when the backup master switches, then set bit 9 to be 768 to display PL00 warning.

04-58 Weekdays, weekend, specific day schedule

Default: 0


Settings bit 0: 1 (weekdays)

bit 1: 1 (weekend)

bit 2: 1 (specific day)


- This function is built-in scheduled function of PLC. Refer to chapter 15 PLC Function Applications for the way to enable the built-in PLC function.
- Before using the scheduled function, adjust time in Pr.12-93–12-96 and install a battery. If not doing so, the AC motor drive displays warnings to adjust the RTC (rCAL) and has low battery voltage (LBAt).
- Refer to section 7-7 RTC Function and Battery
- To meet water requirements at different time, use this scheduled function to arrange the target pressure in the specific time interval for saving energy. The schedule can be divided into three phases: weekdays, weekend, specific day. Set them individually and:
 - 1. The priority is specific day > weekend > weekdays.
 - 2. The next time interval has to be larger than the previous one, otherwise the following time intervals are invalid, and the pump only operates during the valid time interval.
 - 3. These parameters can not been set randomly, if there is any blank in the middle, then the settings after the blank are invalid.
 - 4. This can be less than five time intervals.
 - In case of crossing day, follow the operating pressure setting in the last valid time interval of the previous day.

The schematic diagrams



Example:

Example.														
Setting		Weekdays				14/00	drand	Modedovo	Specific day				Weekend	
Range		۷۱	теекаа	y S		vvee	ekend	Weekdays	2/1	2/2	2/3	2/4	2/5	vveekend
Time	Mon.	Tue.	Wed.	Thur.	Fri.	Sat.	Sun.	Mon.	Tue.	Wed.	Thur.	Fri.	Sat.	Sun.
00:00	4	10	10	10	10	10	4	4	10	8	8	8	8	8
1:00 AM	4	10	10	10	10	5	5	4	10	8	8	8	8	5
2:00 AM	2	2	2	2	2	5	5	2	10	8	8	8	8	5
3:00 AM	2	2	2	2	2	5	5	2	1	1	1	1	1	5
4:00 AM	2	2	2	2	2	5	5	2	1	1	1	1	1	5
9:00 PM	10	10	10	10	10	7	7	10	6	6	6	6	6	7
10:00 PM	10	10	10	10	10	7	7	10	8	8	8	8	8	7
11:00 PM	10	10	10	10	10	4	4	10	8	8	8	8	8	4
00:00	10	10	10	10	10	4	4	10	8	8	8	8	8	4



Weekend Setting

Default: 0

Settings 0: Saturday, Sunday

1: Sunday

Define the days of weekend according to requirements. Set 0 means the weekdays are from Monday to Friday; set 1 means the weekdays are from Monday to Saturday.

×	04-60	Weekdays Start Time 1
×	04-62	Weekdays Start Time 2
×	04-64	Weekdays Start Time 3
×	04-66	Weekdays Start Time 4
×	04-68	Weekdays Start Time 5
×	04-70	Weekend Start Time 1
×	04-72	Weekend Start Time 2
×	04-74	Weekend Start Time 3
×	04-76	Weekend Start Time 4
×	04-78	Weekend Start Time 5
×	04-90	Specific Day Start Time 1

×	04-92	Specific Day Start Time 2
×	04-94	Specific Day Start Time 3
×	04-96	Specific Day Start Time 4
×	04-98	Specific Day Start Time 5

Default: 00:00

Settings 00:00~23:59

×	04-61	Weekdays Target Pressure 1
×	04-63	Weekdays Target Pressure 2
×	04-65	Weekdays Target Pressure 3
×	04-67	Weekdays Target Pressure 4
×	04-69	Weekdays Target Pressure 5
×	04-71	Weekend Target Pressure 1
×	04-73	Weekend Target Pressure 2
×	04-75	Weekend Target Pressure 3
×	04-77	Weekend Target Pressure 4
×	04-79	Weekend Target Pressure 5
×	04-91	Specific Day Target Pressure 1
×	04-93	Specific Day Target Pressure 2
×	04-95	Specific Day Target Pressure 3
×	04-97	Specific Day Target Pressure 4
×	04-99	Specific Day Target Pressure 5

Default: 0

Settings 0–65535

The pressure unit is converted according to the decimal point setting of Pr.00-25.

Example: 0-65535 (when Pr.00-25 is set to no decimal place)

0.0–6553.5 (when Pr.00-25 is set to one decimal place)

0.00-655.35 (when Pr.00-25 is set to two decimal places)

0.000-65.535 (when Pr.00-25 is set to three decimal places)

☐ The maximum of the system pressure value is Pr.00-26.

×	04-80	Specific Day Start Date 1
×	04-81	Specific Day End Date 1
×	04-82	Specific Day Start Date 2
×	04-83	Specific Day End Date 2
×	04-84	Specific Day Start Date 3
×	04-85	Specific Day End Date 3
×	04-86	Specific Day Start Date 4
×	04-87	Specific Day End Date 4
×	04-88	Specific Day Start Date 5

N 04-89 Specific Day End Date 5

specific days for operation.

Default: 00.00

Settings MM.DD (MM = month, 01–12; DD = date, 01–31)

All the specific days operate the same scheduled time and pressure. That means when time is the specific days which set in Pr.04-80–04-89, the schedule executes according to Pr.04-90–04-99 settings.

Set the date to be 00.00 means the parameter is invalid.

The setting of the specific days start from the start date and end on the end date.

Example: If the setting starts from 1/2 and ends on 1/3, then both 1/2 and 1/3 are the specific days for operation.

If the end date is smaller than the start date, then this operation continues to a new year.

Example: If the setting starts from 12/30 and ends on 1/2, then 12/30, 12/31, 1/1, 1/2 are the

05 Motor Parameters

✓ You can set this parameter during operation.

05-00 Motor Parameter Auto-tuning

Default: 0

Settings 0: No function

5: Rolling auto-tuning for motor

13: High frequency stall test for motor

05-01 Full-Load Current for Induction Motor 1 (A)

Default: Depend on the model

power

Settings 10–120% of the drive's rated current

Set this value according to the rated current of the motor as indicated on the motor nameplate.

The default is 90% of the drive's rated current.

Example: The rated current for a 7.5 HP (5.5 kW) is 25 A. The default is 22.5 A.

The setting range is between 2.5–30 A of the rated current.

 $25 \times 10\% = 2.5 \text{ A}$ $25 \times 120\% = 30 \text{ A}$

Default: Depend on the model

power

Settings 0.00-655.35 kW

Sets the rated power for the motor. The default is the drive's power value.

No. 105-03 Rated Speed for Induction Motor 1 (rpm)

Default: Depend on the motor's

number of poles

Settings 0~xxxxx rpm (Depend on the motor's number of poles)

1710 (60 Hz 4 poles); 1410 (50 Hz 4 poles)

Set the rated speed for the motor as indicated on the motor nameplate.

05-04 Number of Poles for Induction Motor 1

Default: 4

Settings 2–20

- Set the number poles for the motor (must be an even number).
- Set up Pr.01-01 and Pr.05-03 before setting up Pr.05-04 to make sure the motor operates normally.

05-05 No-Load Current for Induction Motor 1 (A)

Default: Depend on the model

power

Settings 0.00–Pr.05-01 default

The default is 40% of motor rated current.

	05-06	Stator R	tesistance (Rs) for Induction Motor 1	
	05-07	Rotor R	esistance (Rr) for Induction Motor 1	
				Default: Depend on the model
				power
		Settings	0.000–65.535 Ω	
	05-08	Magneti	zing Inductance (Lm) for Induction Mo	tor 1
	05-09	Stator In	nductance (Lx) for Induction Motor 1	
				Default: 0.0
		Settings	0.0-6553.5 mH	
×	05-26	Motor Ad	ccumulated Watt in Every Millisecond (W-msec.)
	05-27	Motor A	ccumulated Watt in Every Second (W-s	sec.)
N	05-28	Motor Ad	ccumulated Watt in Every Hour (W-hoเ	ır)
	05-29	Motor Ad	ccumulated Kilowatt in Every Hour (kW	/-hour)
	05-30	Motor A	ccumulated Megawatt in Every Hour (N	//W-hour)
			•	Default: 0.0
		Settings	Read only	
	Pr.05-20	6–05-30 re	cords the amount of power the motors con	sume. The accumulation begins
	when th	ne drive is	activated and the record is saved when the	e drive stops or turns OFF. The
	amount	of consum	ned watts continues to accumulate when the	drive is activated again. To clear
	the acc	umulation,	set Pr.00-02 to 5 to return the accumulation re	ecord to 0.
	The acc	cumulated t	total kilowatts of the motor per hour = Pr.05-3	0 x 1000000 + Pr.05-28 x 1000 +
	Pr.05-28	8 Wh		
	Exampl	e: When P	r.05-30 = 76 MWh, Pr.05-29 = 150 kWh, Pr.0	5-28 = 400 Wh (or 0.4 kWh), the
	motor a	ccumulate	d watt in every hour = 76 x 1000000 + 150	x 1000 + 400 = 76150400 Wh =
	76150.4	1 kWh		
	05-31	Accumu	lated Motor Operation Time (Minutes)	
				Default: 0
		Settings	0–1439	
	05-32	Accumu	lated Motor Operation Time (Days)	
				Default: 0
		Settings	0–65535	
			Pr.05-32 to record the motor operation time.	•
	Pr.05-3	1 and Pr.05	5-32 to 00. An operation time shorter than 60 s	seconds is not recorded.
	05.00	Inductio	n Motor (IM) or Permanent Magnet Sy	nchronous AC Motor (PM)
	05-33	Selectio	n	
				Default: 3
		Settings	0: IM (Induction motor)	
		-	1: SPM (Surface permanent magnet synchr	onous AC motor)
			2: IPM (Interior permanent magnet synchror	nous AC motor)
			3: Delta MSI series motor	

05-34	Motor F	ull-load Current	
			Default: #.#
	Settings	0–120% of the drive's rated current	
05-35	Motor R	ated Power	
			Default: #.#
	Settings	0.00–655.35 kW	
☐ Sets the		ver for the motor. The default is the drive's pow	ver value.
	-	рото по	
05-36	Motor R	ated Speed	
			Default: 3000
	Settings	0–65535 rpm	
05-37	Number	Of Poles for A Motor	
			Default: Differs from models (6
			/8)
	Settings	0–65535	,
05-39	Ţ.	Resistance for A Motor	
			Default: 0.000
	Settings	0.000–65.535 Ω	Deladit. 0.000
05-40	Motor L		
03-40	IVIOLOI L	u	Defectity 0.00
	0 :	0.00 055 05 11	Default: 0.00
05.44		0.00–655.35 mH	
05-41	Motor L	q	
			Default: 0.00
	Settings	0.00–655.35 mH	
05-43	Ke Para	meter of a Motor	
			Default: 0
		0.0~6553.5 V/krpm	
Pr.05-34	4–05-43 w	hich are related with the MSI motor that	corresponds with MPD enter

Pr.05-34-05-43 which are related with the MSI motor that corresponds with MPD enter automatically.

[This page intentionally left blank]


06 Protection Parameters (1)

✓ You can set this parameter during operation.

Default: 360.0

Settings 300.0–440.0 V_{DC}

- Set the Low Voltage (LV) level. When the DC bus voltage is lower than Pr.06-00, a LV fault is triggered, and the drive stops output then the motor coasts to a stop.
- If the Lv fault is triggered during operation, the drive stops output and the motor coasts to a stop. There are three Lv faults: LvA (Lv during acceleration), Lvd (Lv during deceleration), and Lvn (Lv in constant speed) that are triggered according to the status of acceleration or deceleration. You must press RESET to clear the Lv fault. The drive automatically restarts if you set to restart after momentary power loss (refer to Pr.07-06 Restart after Momentary Power Loss and Pr.07-07 Allowed Power Loss Duration for details).
- If the Lv fault is triggered when the drive is in STOP status, the drive displays LvS (Lv during stop). The error will not be recorded, and the drive restarts automatically when input voltage is higher than the low voltage level 60V (460V models).



Default: 760.0

Settings 0: No function $0.0-900.0\ V_{DC}$

- Setting Pr.06-01 to 0.0 disables the over-voltage stall prevention function.
- Setting Pr.06-01 to a value > 0.0 enables the over-voltage stall prevention. This setting refers to the power supply system and loading. If the setting is too low, then over-voltage stall prevention is easily activated, which may increase deceleration time.
- If the value exceeds OV level (see the table below), then OV stall function is disabled.

Voltage	OV Stall	OV	Settings
460V Models	760 V _{DC}	820 V _{DC}	0-900 V _{DC}

Related parameters:

- Pr.01-13, Pr.01-15, Pr.01-17, Pr.01-19 Deceleration Time 1–4
- Pr.02-13 multi-function output terminal 1 (RY1) MOx = 23: over-voltage stall prevention
- Pr.02-14 multi-function output terminal 2 (RY2) MOx = 23: over-voltage stall prevention
- Pr.02-16 multi-function output terminal 3 (MO) MOx = 23: over-voltage stall prevention
- Pr.06-02 Selection for Over-voltage Stall Prevention.


✓ 06-02 Selection for Over-voltage Stall Prevention

Default: 0


Settings 0: Traditional over-voltage stall prevention

1: Smart over-voltage stall prevention

- Use this function when you are unsure about the load inertia. When stopping under normal load, the over-voltage does not occur during deceleration and meet the deceleration time setting. Sometimes it may not stop due to over-voltage during decelerating to STOP when the load regenerative inertia increases. In this case, the AC motor drive extends the deceleration time automatically until the drive stops.
- When you set Pr.06-02 to 0, during deceleration the motor exceeds the synchronous speed due to load inertia. In this case, the motor becomes an electrical generator. The DC bus voltage may exceed its maximum allowable value due to motor regeneration in some situations, such as motor's loading inertia being too high or drive's deceleration time being set too short. When you enable traditional over-voltage stall prevention and the DC bus voltage detected is too high, the drive stops decelerating (output frequency remains unchanged) until the DC bus voltage drops below the setting value.



When you set Pr.06-02 to 1 to use smart over-voltage stall prevention during deceleration, the drive maintains the DC bus voltage when decelerating and prevents the drive from OV.



- When you enable the over-voltage stall prevention, the drive's deceleration time is longer than the setting.
- If the deceleration time affects your application, it is not recommended to use this function. See the following guides for troubleshooting.
 - Increase the deceleration time to a proper value.

Related parameters:

- Pr.01-13, Pr.01-15, Pr.01-17, Pr.01-19 Deceleration Time 1-4
- Pr.02-13 multi-function output terminal 1 (RY1) MOx = 23: over-voltage stall prevention
- Pr.02-14 multi-function output terminal 2 (RY2) MOx = 23: over-voltage stall prevention
- Pr.02-16 multi-function output terminal 3 (MO) MOx = 23: over-voltage stall prevention
- Pr.06-01 Over-voltage Stall Prevention


Over-current Stall Prevention during Acceleration 06-03

Default: 120

Settings Normal duty: 0-150%


(100% corresponds to the rated current of the drive)

- If the motor load is too large or the drive's acceleration time is too short, the output current of the drive may be too high during acceleration, and it may cause motor damage or trigger protection functions (OL or OC). Use this parameter to prevent these situations.
- During acceleration, the output current of the drive may increase abruptly and exceed the setting value of Pr.06-03. In this case, the drive stops accelerating and keeps the output frequency constant, and then continues to accelerate until the output current decreases.



prevention is enabled.

Refer to Pr.06-16 for more details of stall level in flux weakening region. The protection curve is as shown below:



- When you enable the over-current stall prevention, the drive's acceleration time is longer than the setting.
- When the over-current stall prevention occurs because the motor capacity is too small or operates in the default, decrease the Pr.06-03 setting value.
- If you encounter any problem with the acceleration time, refer to the following guides for troubleshooting.
 - Increase the acceleration time to a proper value.
 - Set Pr.01-44 Auto-Acceleration and Auto-Deceleration Setting to 1, 3 or 4. (auto-acceleration)

Related parameters:

- Pr.01-12, 01-14, 01-16, 01-18 Acceleration Time 1–4
- Pr.01-44 Auto-Acceleration and Auto-Deceleration Setting
- Pr.02-13 multi-function output terminal 1 (RY1) MOx = 23: over-voltage stall prevention
- Pr.02-14 multi-function output terminal 2 (RY2) MOx = 23: over-voltage stall prevention
- Pr.02-16 multi-function output terminal 3 (MO) MOx = 23: over-voltage stall prevention

Default: 120


Settings Normal duty: 0–150%

(100% corresponds to the rated current of the drive)

- This is a protection for the drive to decrease output frequency automatically when the motor overloads abruptly during constant motor operation.
- If the output current exceeds the setting value for Pr.06-04 when the drive is operating, the drive decelerates according to the Pr.06-05 setting to prevent the motor from stalling. The lower limit for the over-current stall prevention is determined by the maximum value among 0.5 Hz, Pr.01-07 and Pr.01-11.
- If the output current is lower than the setting value for Pr.06-04, the drive accelerates (according to Pr.06-05) again to the setting frequency.

Pr.06-04
Over-current stall prevention level during operation

Settings



Acceleration / Deceleration Time Selection for Stall Prevention at Constant Speed

0: By current acceleration / deceleration time

1: By the first acceleration / deceleration time

2: By the second acceleration / deceleration time

3: By the third acceleration / deceleration time

4: By the fourth acceleration / deceleration time

5: By auto-acceleration / auto-deceleration

Set the acceleration / deceleration time selection when stall prevention occurs at constant speed.

O6-06 Over-torque Detection Selection (Motor 1)

Default: 0

Default: 0

Settings 0: No function

1: Continue operation after over-torque detection during constant speed operation

2: Stop after over-torque detection during constant speed operation

3: Continue operation after over-torque detection during RUN

4: Stop after over-torque detection during RUN

Over-torque detection level (motor 1)

Default: 120

Settings 10–250% (100% corresponds to the rated current of the drive)


06-08 Over-torque Detection Time (Motor 1)

Default: 0.1


Settings 0.0–60.0 sec.

When the output current exceeds the over-torque detection level (Pr.06-07) and also exceeds the over-torque detection time (Pr.06-08), the over-torque detection follows the setting of Pr.06-06.

When you set Pr.06-06 to 1 or 3, an ot1 warning displays while the drive keeps running. The warning remains on until the output current is smaller than 5% of the over-torque detection level.



When you set Pr.06-06 to 2 or 4, an ot1 warning displays and the drive stops running after overtorque detection. The drive keeps running after you manually reset it.



✓ 06-13 Electronic Thermal Relay Selection 1 (Motor 1)

Default: 2

Settings 1: Standard motor (motor with fan on the shaft)

2: Disabled


- Prevent self-cooled motor from overheating under low speed. Use an electronic thermal relay to limit the drive's output power.
- Setting the parameter to 1 is suitable for standard motor (motor fan is fixed on the rotor shaft). For this kind of motor, the cooling capacity is lower in low speed; therefore, the action of an electronic thermal relay reduces the action time to ensure the life of motor.
- When the power is cycled frequently, if the power is switched OFF, the electronic thermal relay protection is reset; therefore, even setting the parameter to 0 or 1 may not protect the motor well. If there are several motors connected to one drive, install an electronic thermal relay in each motor.

06-14 Electronic Thermal Relay Action Time 1 (Motor 1)

Default: 60.0

Settings 30.0-600.0 sec.

- Set the parameter to 150% of motor rated current and use with the setting of Pr.06-14 to prevent motor damage due to overheating. When it reaches the setting, the drive displays "EoL1", and the motor free runs to stop.
- Use this parameter to set the action time of the electronic thermal relay. It works based on the I2t characteristic curve of electronic thermal relay, the output frequency and current of the drive, and the operation time to prevent the motor from overheating.




The action of the electronic thermal relay depends on the settings for Pr.06-13.

Pr.06-13 sets to 1 (using standard motor):

When the output current of the drive is higher than 150% of the motor rated current (refer to the motor cooling curve with shaft-fixed fan), the drive starts to count the time. The electronic thermal relay acts when the accumulated time exceeds Pr.06-14.

The actual electronic thermal relay action time adjusts according to the drive output current (shown as the motor loading rate %). The action time is short when the current is high, and the action time is long when the current is low. Refer to the following chart:



√ 06-15 Temperature Level Overheat (OH) Warning

Default: 105.0

Settings 0.0-110.0°C

The trigger level of oH1, oH2 are as shown below.

Level	oH1: IGBT overheating	oH2: Heatsink overheating
Trigger the alarm level	Pr.06-15	-
Auto-reset alarm level	Pr.06-15 - 5°C	-
Trigger the fault level	115°C	95°C
Manual reset fault level	115 °C - 10 °C = 105°C	95°C - 10°C = 85°C

06-16

Stall Prevention Limit Level (Weak Magnetic Field Current Stall Prevention Level)

Default: 100

Settings 0–100% (Refer to Pr.06-03)

- Set the over-current stall prevention level when operation frequency is larger than Pr.01-01.
- \square Example: When Pr.06-03 = 150%, Pr.06-04 = 100% and Pr.06-16 = 80%.
- When the operation frequency is larger than Pr.01-01, the lowest over-current stall prevention level during acceleration is:
- \square Pr.06-03 x Pr.06-16 = 150 x 80% = 120%. (Refer to Pr.06-03 diagram for the protection curve.)
- Pr.06-16 is invalid when the over-current stall prevention activates according to Pr.06-04 at constant speed.

06-17	Fault Record 1
06-18	Fault Record 2
06-19	Fault Record 3
06-20	Fault Record 4
06-21	Fault Record 5
06-22	Fault Record 6

Default: 0

Display

- 0: No fault record
- 1: Over-current during acceleration (ocA)
- 2: Over-current during deceleration (ocd)
- 3: Over-current during steady operation (ocn)
- 4: Ground fault (GFF)
- 6: Over-current at stop (ocS)
- 7: Over-voltage during acceleration (ovA)
- 8: Over-voltage during deceleration (ovd)
- 9: Over-voltage during constant speed (ovn)
- 10: Over-voltage at stop (ovS)
- 11: Low-voltage during acceleration (LvA)
- 12: Low-voltage during deceleration (Lvd)

- 13: Low-voltage at constant speed (Lvn)
- 14: Low-voltage at stop (LvS)
- 15: Phase loss protection (orP)
- 16: IGBT overheating (oH1)
- 17: Heatsink overheating (oH2)
- 18: IGBT temperature detection failure (tH1o)
- 19: Capacitor hardware error (tH2o)
- 21: Over load (oL)
- 22: Electronics thermal relay 1 protection (EoL1)
- 24: Motor overheating PTC-130 / PT100 / KTY-84-130 (oH3)
- 26: Over torque 1 (ot1)
- 28: Under current (uC)
- 31: EEPROM read error (cF2)
- 33: U-phase error (cd1)
- 34: V-phase error (cd2)
- 35: W-phase error (cd3)
- 36: cc hardware error (Hd0)
- 37: oc hardware error (Hd1)
- 40: Auto-tuning error (AUE)
- 41: PID loss ACI (AFE)
- 48: ACI loss (ACE)
- 49: External fault (EF)
- 51: External base block (bb)
- 52: Password is locked (Pcod)
- 54: Illegal command (CE1)
- 55: Illegal data address (CE2)
- 56: Illegal data value (CE3)
- 57: Data is written to read-only address (CE4)
- 58: Modbus transmission time-out (CE10)
- 79: U-phase over-current before run (Aoc)
- 80: V-phase over-current before run (boc)
- 81: W-phase over-current before run (coc)
- 82: U-phase output phase loss (oPL1)
- 83: V-phase output phase loss (oPL2)
- 84: W-phase output phase loss (oPL3)
- 87: Low frequency overload protection (oL3)
- 89: Rotor position detection error (RoPd)
- 90: Force to stop (FStp)
- 98: Fire mode output (Fire)
- 140: oc hardware error (Hd6)
- 141: GFF occurs before run (b4GFF)
- 142: Auto-tune error 1 (AuE1) (DC test stage)

143: Auto-tune error 2 (AuE2) (high frequency stall stage)

144: Auto-tune error 3 (AuE3) (rotation test stage)

221: High water pressure (HPS)

222: Low water pressure (LPS)

223: Dry pump (dryE)

224: Water leaking (pipe explosion) (LEKE)

225: Clogged pipe (JAME)

226: RTC error (rtF)

227: Dry pump curve auto-measuring (dAUE)

- The parameters record when the fault occurs and forces a stop.
- When low-voltage at stop fault (LvS) occurs, the fault is not recorded. When low-voltage during operation faults (LvA, Lvd, Lvn) occur, the faults are recorded.

×	06-23	Fault Output Option 1
×	06-24	Fault Output Option 2
×	06-25	Fault Output Option 3
N	06-26	Fault Output Option 4

Default: 0

Settings 0–65535 (refer to bit table for fault code)

Use these parameters with multi-function output terminal (set Pr.06-23–Pr.06-26 to 35–38) for the specific requirement. When the fault occurs, the corresponding terminals activate. Convert the binary value to decimal value before you enter the value for Pr.06-23–Pr.06-26.

Fault Code	bit0	bit1	bit2	bit3	bit4	bit5	bit6
		Volt.	OL	SYS	FBK	EXI	CE
0: No fault record							
1: Over-current during acceleration (ocA)	•						
2: Over-current during deceleration (ocd)	•						
3: Over-current during steady operation							
(ocn)							
4: Ground fault (GFF)	•						
6: Over-current at stop (ocS)	•						
7: Over-voltage during acceleration (ovA)		•					
8: Over-voltage during deceleration (ovd)		•					
9: Over-voltage during constant speed (ovn)		•					
10: Over-voltage at stop (ovS)		•					
11: Low-voltage during acceleration (LvA)		•					
12: Low-voltage during deceleration (Lvd)		•					
13: Low-voltage at constant speed (Lvn)		•					
14: Low-voltage at stop (LvS)		•					
15: Phase loss protection (orP)		•					
16: IGBT overheating (oH1)			•				
17: Heatsink overheating (oH2)			•				
18: IGBT temperature detection failure							
(tH1o)			•				

Fault Code	bit0	bit1	bit2	bit3	bit4	bit5	bit6
i aut code	current	Volt.	OL	SYS	FBK	EXI	CE
19: Capacitor hardware error (tH2o)			•				
21: Over load (oL)			•				
22: Electronics thermal relay 1 protection			_				
(EoL1)			•				
23: Electronics thermal relay 2 protection							
(EoL2)			•				
24: Motor overheating PTC-130 / PT100 /							
KTY-84-130 (oH3)			•				
26: Over torque 1 (ot1)			•				
28: Under current (uC)	•						
31: EEPROM read error (cF2)				•			
33: U-phase error (cd1)				•			
34: V-phase error (cd2)				•			
35: W-phase error (cd3)				•			
36: cc hardware error (Hd0)				•			
37: oc hardware error (Hd1)				•			
40: Auto-tuning error (AUE)				•			
41: PID loss ACI (AFE)					•		
48: ACI loss (ACE)					•		
49: External fault (EF)						•	
51: External base block (bb)						•	
52: Password is locked (Pcod)				•			
54: Illegal command (CE1)							•
55: Illegal data address (CE2)							•
56: Illegal data value (CE3)							•
57: Data is written to read-only address							
(CE4)							
58: Modbus transmission time-out (CE10)							•
79: U-phase over-current before run (Aoc)	•						
80: V-phase over-current before run (boc)	•						
81: W-phase over-current before run (coc)	•						
82: U-phase output phase loss (OPL1)	•						
83: V-phase output phase loss (OPL2)	•						
84: W-phase output phase loss (OPL3)	•						
87: Low frequency overload protection (oL3)			•				
89: Rotor position detection error (RoPd)					•		
90: Force to stop (FStp)				•			
98: Fire mode output (Fire)				•			
140: oc hardware error (Hd6)				•			
141: GFF occurs before run (b4GFF)				•			
142: Auto-tune error 1 (AuE1) (DC test							
stage)							
143: Auto-tune error 2 (AuE2) (high							
frequency stall stage)							
144: Auto-tune error 3 (AuE3) (rotation test				•			
stage)							

Fault Code		bit1	bit2	bit3	bit4	bit5	bit6
		Volt.	OL	SYS	FBK	EXI	CE
221: High water pressure (HPS)				•			
222: Low water pressure (LPS)				•			
223: Dry pump (dryE)				•			
224: Water leaking (pipe explosion) (LEKE)				•			
225: Clogged pipe (JAME)				•			
226: RTC error (rtF)				•			
227: Dry pump curve auto-measuring (dAUE)				•			

(4, 10 =)									
06-29	РТС-130	/ KTY84 -130 / PT100	Action						
						Default:	0		
9	Settings	0: Warn and continu	ue operation						
		1: Fault and ramp to	stop						
		2: Fault and coast to	o stop						
		3: No warning							
MSI moto	or has two	kinds of built-in PTC	2-130 and KT	Y84-1	30 the	mistors.	ı		
Refer to s	section 4-	3 for the installation of	of motor and	drive.					
Set the	operation	mode of a drive a	fter you set	Pr.06	6-29 to	define	PTC-13	0 / KT	/ 84-130
detection									
Running t	the motor	at low frequency for	a long time r	reduce	es the c	ooling fu	unction o	of the mo	otor fan.
To preve	nt overhe	ating, use a Positiv	e Temperatu	ire Co	efficien	t thermi	stor on	the mo	tor, and
connect t	he thermi	stor output signal to	the drive's ar	nalog i	nput te	rminals.			
06-30	PTC-130) / KTY84-130 Lev	vel						
						Default:	50.0		
5	Settings	0.0-100.0%							
MSI moto	or has two	kinds of built-in PTC	C-130 and KT	Y84-1	30 the	mistors.			
Set Al1 /	Al2 ana	og input function Pr	:03-00 to 6	[Positi	ve tem	perature	coeffic	ient (PT	C-130 /
KTY84-13	30) therm	istor input value].							
Use this t	to set the	PTC-130 / KTY84-1	30) level; the	corre	spondi	ng value	for 100	% is the	analog


When using the Al1 terminal:

input maximum value.

- 1. You must set Pr.03-28 to 1 and switch Al1 voltage to 0–10 V. At this time, the AVI input impedance is 20 K Ω .
- 2. If the temperature reaches to the set protection level, the motor acts according to the settings for Pr.06-29 and displays warning "oH3" (if Pr.06-29 = 1–3). When the temperature is lower than the set protection level, you can press RESET key to clear the fault.
- 3. The PTC uses the AVI-input and is connected via resistor-divider as shown below:
 - (1) The voltage between +10V to ACM: lies within 10–11.2 V.
 - (2) The impedance for Al1 is around 20 K Ω . The recommended value for resistor-divider is 1K–10 K Ω .
 - (3) Contact your motor dealer for the curve of temperature and resistance value for PTC.


Protection level (Pr.06-30) = V+10 *(RPTC//20K)/[R1+(RPTC//20K)]

- V+10: voltage between +10V-ACM actual value
- RPTC: motor PTC overheat protection level
- 20 KΩ: is AVI input impedance
- R1: PTC-130 resistor-divider (recommended value: 1–10kΩ); KTY84-130 resistor-divider connects to 2 kΩ



Take the standard PTC-130 thermistor as example:

if protection level is 4000 Ω , the voltage between +10V-ACM is 10.5V and resistor-divider R1 is 4.4 k Ω .



Refer to the following calculation when Pr.06-30 is set to 45% and motor temperature overheating protection level is 4000 Ω :

 $4000/20000 = (4000 \times 20000) \div (4000 + 20000) = 3333.33 \Omega$

 $10.5 \times 3333.33 \div (4400 + 3333.33) = 4.52 \text{ (V)} = 4.5 \text{ (V)}$

Pr.06-30 should be set to $4.5 \div 10V \times 100\% = 45\%$

06-31 Frequency Command at Malfunction

Default: Read only

Display 0.00–599.00 Hz

When a malfunction occurs, check the current Frequency command. If the error happens again, this parameter overwrites the previous record.

06-32 Output Frequency at Malfunction

Default: Read only

Display 0.00–599.00 Hz

When an error occurs, you can check the output frequency for the malfunction. If the error happens again, this parameter overwrites the previous record.


06-33 **Output Voltage at Malfunction** Default: Read only Display 0.0-6553.5 V When a malfunction occurs, check the current output voltage. If the error happens again, this parameter overwrites the previous record. DC bus Voltage at Malfunction Default: Read only Display 0.0-6553.5 V When an error occurs, you can check the DC bus voltage for the malfunction. If the error happens again, this parameter overwrites the previous record. 06-35 Output Current at Malfunction Default: Read only Display 0.00-655.35 Amps When an error occurs, you can check the output current for the malfunction. If the error happens again, this parameter overwrites the previous record. 06-36 **IGBT** Temperature at Malfunction Default: Read only Display 0.0-6553.5°C When an error occurs, you can check the IGBT temperature for the malfunction. If the error happens again, this parameter overwrites the previous record. **06-38** Motor Speed at Malfunction Default: Read only Display 0.0-65535 rpm When a malfunction occurs, check the current motor speed in rpm. If the error happens again, this parameter overwrites the previous record. 06-39 **Torque Command at Malfunction** Default: Read only Display -32768-32767 When a malfunction occurs, check the current torque command. If the error happens again, this parameter overwrites the previous record. Status of the Multi-function Input Terminal at Malfunction 06-40 06-41 Status of the Multi-function Output Terminal at Malfunction Default: Read only Display 0000h-FFFFh When a malfunction occurs, check the current status of the multi-function input/output terminals.

If the error happens again, this parameter overwrites the previous record.

	06-42	Drive St	atus at Malfunction	
				Default: Read only
		Display	0000h-FFFFh	
	When a	a malfuncti	ion occurs, check the current drive status (co	ommunication address 2101H). If
	the erro	or happens	again, this parameter overwrites the previous	s record.
×	06-45	Output I	Phase Loss Detection Action (OPHL)	
				Default: 3
		Settings	0: Warn and continue operation	
			1: Fault and ramp to stop	
			2: Fault and coast to stop	
			3: No warning	
	Pr.06-4	5 = 0: Wh	nen phase loss protection is triggered, the l	keypad displays OPL1 (U-phase
	output p	hase loss)), OL2 (U-phase output phase loss), OPL3 (W	-phase output phase loss).
	Pr.06-4	5 = 1, 2: W	hen phase loss protection is triggered, the ke	ypad displays OPHL.
N	06-46	Detection	on Time for Output Phase Loss	
			•	Default: 0.500
		Settings	0.000-65.535 sec.	
N	06-47		0.000–65.535 sec. Detection Level for Output Phase Loss	S
×	06-47			S Default: 1.00
×	06-47			
*	06-47	Current Settings	Detection Level for Output Phase Loss	
*		Current Settings	Detection Level for Output Phase Loss 0.00–100.00%	
*		Current Settings DC Brak	Detection Level for Output Phase Loss 0.00–100.00%	Default: 1.00
N	06-48	Current Settings DC Brak Settings	Detection Level for Output Phase Loss 0.00–100.00% Re Time for Output Phase Loss	Default: 1.00
*	06-48 ☐ The bas	Current Settings DC Brake Settings se of Pr.06	Detection Level for Output Phase Loss 0.00–100.00% Re Time for Output Phase Loss 0.000–65.535 sec.	Default: 1.00
*	06-48 ☐ The bas	Current Settings DC Brake Settings se of Pr.06 8 = 0 disab	Detection Level for Output Phase Loss 0.00–100.00% Re Time for Output Phase Loss 0.000–65.535 sec. -47 is rated current (Pr.00-01).	Default: 1.00
*	□ The bas □ Pr.06-48 □ Exampl	Settings DC Brake Settings se of Pr.06 8 = 0 disable:	Detection Level for Output Phase Loss 0.00–100.00% Re Time for Output Phase Loss 0.000–65.535 sec. -47 is rated current (Pr.00-01).	Default: 1.00 Default: 0.000
*	□ The bas □ Pr.06-48 □ Example	Current Settings DC Brake Settings Se of Pr.06 8 = 0 disable: ated curre	Detection Level for Output Phase Loss 0.00–100.00% Re Time for Output Phase Loss 0.000–65.535 sec. -47 is rated current (Pr.00-01). oles the OPHL detection function.	Default: 1.00 Default: 0.000 conds, then triggers phase loss


Status 1: The drive is in operation

When any phase is less than the Pr.06-47 setting, and exceeds the Pr.06-46 setting time, the drive executes according to the Pr.06-45 setting.




Status 2: The drive is in STOP; Pr.06-48 ≠ 0; Pr.07-02 ≠ 0
When the drive starts, it executes Pr.06-48 first, and then executes Pr.07-02 (DC brake).
The DC brake current level in this state includes two parts: one is 20 times the Pr.06-47 setting value in Pr.06-48 setting time; the other is the Pr.07-01 setting value in Pr.07-02 setting time. The total DC brake time T = Pr.06-48 + Pr.07-02.

Status 2-1: Pr.06-48 \neq 0, Pr.07-02 \neq 0 (No OPHL detected before the operation)




Status 2-2: Pr.06-48 \neq 0, Pr.07-02 \neq 0 (OPHL detected before the operation) In this period, if an OPHL happens within the time for Pr.06-48, the drive executes the Pr.06-45 setting after the drive starts counting for half the time of Pr.06-48.




Status 3: The drive is in STOP; Pr.06-48 ≠ 0; Pr.07-02 = 0
 When the drive starts, it executes Pr.06-48 as the DC brake. The DC brake current level is 20 times the Pr.06-47 setting value.

Status 3-1: Pr.06-48 ≠ 0, Pr.07-02 = 0 (No OPHL detected before the operation)



Status 3-2: $Pr.06-48 \neq 0$, Pr.07-02 = 0 (OPHL detected before the operation) In this period, if an OPHL happens within the time for Pr.06-48, the drive executes the Pr.06-45 setting after the drive starts counting for half the time of Pr.06-48.



V 06-49 LvX Auto-reset

Default: 0

Settings 0: Disabled

1: Enabled

Market Market

Default: 0

Settings 0: Fault and ramp to stop

1: Fault and coast to stop

The drive executes the input phase loss protection according to Pr.06-53.

O6-55 Derating Protection

Default: 0

Settings 0: Constant rated current and limit carrier frequency by load current and temperature

1: Constant carrier frequency and limit load current by setting carrier frequency

2: Constant rated current (same as setting 0), but close current limit

- Refer to section 9-4-2 for the carrier frequency of derating.
- Setting 0:

When the operating point is greater than the derating curve (when the operating carrier wave is greater than the rated carrier wave), the rated current is constant, and carrier frequency (Fc) output by the drive decreases automatically according to the ambient temperature, overload output current and overload time. If overloads are not frequent, and the concern is only about

the carrier frequency operating with the rated current for a long time, and changes to the carrier wave due to short overload are acceptable, set to 0.

Take VFD8A5MP43JNNAA for example:

Ambient temperature 40°C, 100% duty, and independent installation. When the carrier frequency is set to 8 kHz, it corresponds to 85% of the rated output current. When the output current is higher than this value, it automatically decreases the carrier wave according to the ambient temperature, output current and overload time. At this time, the overload capacity of the drive is still 150% of the rated current.

Setting 1:

When the operating point exceeds the derating curve 1, the carrier frequency is the setting value. Select this mode if the change of carrier wave and motor noise caused by ambient temperature and frequent overload are not acceptable. Refer to Pr.00-17.

Take VFD8A5MP43JNNAA for example:

When the carrier frequency is to be maintained at 8 kHz, the rated current decreases to 85%. The OL protection executes when the current is $120\% \times 85\% = 102\%$ for one minute; therefore, it must operate by the curve to keep the carrier frequency.

Setting 2:

The protection method and action are the same as setting it to 0, but this disables the current limit when output current is the derating ratio ×120% (default value). The advantage is that it provides a higher starting output current when the carrier frequency setting is higher than the default. However, the carrier frequency derates easily when it overloads.

Example:

When Pr.06-55 = 0 or 1, over-current stall prevention level = ratio x Pr.06-03. When Pr.06-55 = 2, the over-current stall prevention level = Pr.06-03.

- Use this parameter with Pr.00-16 and Pr.00-17.
- The ambient temperature also affects the derating; refer to section 9-4-1 for ambient temperature derating curve.

Take VFD8A5MP43JNNAA for example:

Ambient temperature 40° C, and independent installation. When the carrier frequency is set to 8 kHz, it corresponds to 85% of the rated output current. The ambient temperature 50° C corresponds to $75\% \times 75\%$ of the rated output current.

Condition settings: Pr.06-57 > Pr.06-56.

Default: 0.00

Settings 0.00-599.00 Hz


06-59 PT100 Activation Level 1 Protection Frequency Delay Time

Default: 60

Settings 0-6000 sec.

PT100 operation instructions

- 1. Use voltage type analog input (Al1 voltage 0–10 V) and select PT100 mode.
- 2. When selecting Pr.03-00 = 11 and Pr.03-28 = 0, you must switch Al1 to 0–10 V.
- 3. The AFM outputs constant voltage or current, then Pr.03-20 = 23.
- Use Pr.03-32 to adjust the constant voltage or constant current of the AFM output; the setting range is 0–100.00%.
- 5. There are two types of action levels for PT100. The diagram below shows the PT100 protecting action.



\square When Pr.06-58 = 0.00 Hz, PT100 function is disabled.

Example:

When using PT100, if the motor temperature is higher than 135°C (275°F), the drive starts to count the delay time for auto-deceleration (Pr.06-59). The drive decreases the motor frequency to the setting for Pr.06-58 when it reaches the delay time count value. The drive operates at the frequency set for Pr.06-58 until the motor temperature is lower than 135°C (275°F). If the motor temperature is higher than 150°C (302°F), the drive automatically decelerates to STOP and displays the warning "OH3".

Setting process is as follows:

- 1. Wiring: Connect external terminal AFM to "+"; Connect external terminal ACM to "-" Connect AFM and AVI to "short-circuit"
- 2. Pr.03-00 = 11, Pr.03-20 = 23, Pr.03-32 = 45% (9 mA)

- 3. Refer to the RTD temperature and resistance comparison table
 - Temperature = 135°C, resistance = 151.71 , input current: 9 mA, voltage: about 1.37
 V_{DC}
 - Temperature = 150°C, resistance = 157.33 , input current: 9 mA, voltage: about 1.42 V_{DC}
- 4. When the RTD temperature > 135°C, the drive decelerates to the specified operation frequency automatically. Then, Pr.06-56 = 1.37 and Pr.06-58 = 10 Hz
- 5. When RTD temperature > 150°C, the drive outputs a fault, decelerates to STOP, and displays the warning "OH3".

Then, Pr.06-57 = 1.42 and Pr.06-29 = 1 (warn and ramp to stop).

M 06-60 Software Detection GFF Current Level Default: 60.0 Settings 0.0–6553.5%

✓ 06-61 Software Detection GFF Filter Time

Default: 0.10

Settings 0.00-655.35 sec.

When the drive detects that the unbalanced three-phase output current is higher than the setting for Pr.06-60, GFF protection activates. The drive then stops output.

06-63	Operation Time of Fault Record 1 (Day)
06-65	Operation Time of Fault Record 2 (Day)
06-67	Operation Time of Fault Record 3 (Day)
06-69	Operation Time of Fault Record 4 (Day)
06-90	Operation Time of Fault Record 5 (Day)
06-92	Operation Time of Fault Record 6 (Day)

Default: Read only

Display 0-65535 days

06-64 Operation Time of Fault Record 1 (Min.)	
06-66 Operation Time of Fault Record 2 (Min.)	
06-68 Operation Time of Fault Record 3 (Min.)	
06-70 Operation Time of Fault Record 4 (Min.)	
06-91 Operation Time of Fault Record 5 (Min.)	
06-93 Operation Time of Fault Record 6 (Min.)	

Default: Read only

Display 0–1439 min.

- If there is any malfunction when the drive operates, Pr.06-17–06-22 records the malfunctions, and Pr.06-63–06-70 records the operation time for four sequential malfunctions. Check if there is any problem with the drive according to the interval of the recorded fault.
- Example:

The first error: ocA occurs after motor drive operates for 1000 minutes.

The second error: ocd occurs after another 1000 minutes.

The third error: ocn occurs after another 1000 minutes.

The fourth error: ocA occurs after another 1000 minutes. The fifth error: ocd occurs after another 1000 minutes. The sixth error: ocn occurs after another 1000 minutes.

Then Pr.06-17-06-22 and Pr.06-63-06-70 are recorded as follows:

Parameter	1st fault	2 nd fault	3 rd fault	4 th fault	5 th fault	6 th fault
06-17	ocA	ocd	ocn	ocA	ocd	ocn
06-18	0	ocA	ocd	ocn	ocA	ocd
06-19	0	0	ocA	ocd	ocn	ocA
06-20	0	0	0	ocA	ocd	ocn
06-21	0	0	0	0	ocA	ocd
06-22	0	0	0	0	0	ocA
06-63	1000	560	120	1120	680	240
06-64	0	1	2	2	3	4
06-65	0	1000	560	120	1120	680
06-66	0	0	1	2	2	3
06-67	0	0	1000	560	120	1120
06-68	0	0	0	1	2	2
06-69	0	0	0	1000	560	120
06-70	0	0	0	0	1	2

NOTE: By examining the time record, you can see that that the last fault (Pr.06-17) happened after the drive ran for 4 days and 240 minutes.

Default: 0.0

Settings 0.0-100.0%

Low Current Detection Time

Default: 0.00

Settings 0.00-360.00 sec.

✓ 06-73 Low Current Action

Default: 0

Settings 0: No function

1: Fault and coast to stop

2: Fault and ramp to stop by the 2nd deceleration time

3: Warn and continue operation

- The drive operates according to the setting for Pr.06-73 when the output current is lower than the setting for Pr.06-71 and when the time of the low current exceeds the detection time for Pr.06-72. Use this parameter with the external multi-function output terminal 44 (for low current output).
- The low current detection function does not execute when drive is in sleep or standby status.

06-80 Fire Mode

Default: 0

Settings 0: Disabled

1: Forward operation (counterclockwise)

2: Reverse operation (clockwise)

Use this parameter with multi-function input terminal setting 58 or 59, and multi-function output

terminal setting 53.

- 0: Fire detection is invalid.
- 1: The motor operates in a counterclockwise direction (U, V, W).
- 2: The motor operates in a clockwise direction (U, W, V).

Operating Frequency in Fire Mode

Default: 150.00


Settings 0.00-180.00 Hz


06-86 PTC Type

Default: 0

Settings 0: PTC-130 1: KTY84-130

- When using KTY84-130, users have to select the fixed resistor-divider 2 k Ω (the power cannot smaller than 1/4W) \pm 0.1%
- The thermistor and the corresponding resistor-divider are as shown below:





- The drive occurs oH3 fault when the value is over the setting level. When the temperature is lower than the trigger level -5°C, oH3 fault can be cleared.
- If the drive does not connect to KTY84-130 or KTY84-130 is broken and the temperature is not within -40~150°C, then the temperature can only display the upper limit or lower limit, and does not display any information about the fault. The drive still displays oH3 fault, then check if KTY84-130 is installed correctly.

Chapter 12 Descriptions of Parameter Settings | MPD

07 Special Parameters

✓ You can set this parameter during operation.

N 07-01 DC Brake Current Level

Default: 0

Settings 0-100%

Sets the level of the DC brake current output to the motor at start-up and stop. When setting the DC brake current, the rated current is 100%. It is recommended that you start with a low DC brake current level and then increase until you reach the proper holding torque. However, the DC brake current cannot exceed the motor's rated current to prevent the motor from burnout. Therefore, DO NOT use the DC brake for mechanical retention, otherwise injury or accident may occur.

O7-02 DC Brake Time At Start-up

Default: 0.0

Settings 0.0-60.0 sec.

The motor may continue rotating due to external forces or the inertia of the motor itself. If you use the drive with the motor rotating, it may cause motor damage or trigger drive protection due to over-current. This parameter outputs DC current, generating torque to force the motor stop to get a stable start before motor operation. This parameter determines the duration of the DC brake current output to the motor when the drive starts up. Set this parameter to 0.0 to disable the DC brake at start-up.


O7-03 DC Brake Time At STOP

Default: 0.0

Settings 0.0–60.0 sec.

- The motor may continue rotating after the drive stops output due to external forces or the inertia of the motor itself. This parameter outputs DC current, generating torque to force the motor stop after the drive stops output to make sure that the motor stops.
- This parameter determines the duration of the DC Brake current output to the motor when braking. To enable the DC brake at STOP, you must set Pr.00-22 (Stop Method) to 0 (ramp to stop). Set this parameter to 0.0 to disable the DC brake at stop.
- Related parameters: Pr.00-22 Stop Method, Pr.07-04 DC Brake Frequency at STOP.

Output frequency



DC Brake Output Timing Diagram

Voltage Increasing Gain Default: 100 Settings 1–200% When using speed tracking, adjust Pr.07-05 to slow down the increasing voltage gain if there are errors such as oL or oc; however, the speed tracking time will be longer. Notage Increasing Gain Default: 100 Restart After Momentary Pr.07-05 to slow down the increasing voltage gain if there are errors such as oL or oc; however, the speed tracking time will be longer. Default: 0 Settings 0: Stop operation 1: Speed tracking by the speed before the power loss Determines the operation mode when the drive restarts from a momentary power loss.

1: Frequency tracking begins before momentary power loss and accelerates to the master Frequency command after the drive output frequency and motor rotator speed are synchronous. Use this setting when there is a lot of inertia with little resistance on the motor load. For example, in equipment with a large inertia flywheel, there is NO need to wait until the flywheel stops completely after a restart to execute the operation command; therefore, it saves time.

The power system connected to the drive may power off momentarily for many reasons. This function allows the drive to keep outputting voltages after the drive is re-powered and does not

cause the drive to stop.

Default: 2.0

Settings 0.0-20.0 sec.


- Determines the maximum time of allowable power loss. If the duration of a power loss exceeds this parameter setting, the AC motor drive stops output after the power recovers.
- Pr.07-06 is valid when the AC motor drive displays "Lv" during the maximum allowable power loss time. If the AC motor drive powers off due to overload which even does not exceed the allowed power loss duration, Pr.07-06 is invalid after the power recovers.


W 07-08 Base Block Time


Default: 0.5

Settings 0.1–5.0 sec.

When momentary power loss is detected, the AC motor drive blocks its output and then waits for a specified period of time (determined by Pr.07-08, called Base Block Time) before resuming operation. Set this parameter to the time that allows the residual voltage at the output side to decrease to 0 V before activating the drive again.







07-09 Current Limit of Speed Tracking

Default: 100

Settings 20-200%

- The AC motor drive executes speed tracking only when the output current is greater than the value set in Pr.07-09.
- The maximum current for speed tracking affects the synchronous time. The larger the parameter setting, the faster the synchronization occurs. However, if the parameter setting is too large, the overload protection function may be activated.

N 07-10 Restart after Fault Action

Default: 0

Settings 0: Stop operation

1: Speed tracking by current speed

- As long as Pr.07-10 is set to 1, the drive will track the speed automatically according to the current speed.
- Faults include: bb, oc, ov, occ. To restart after oc, ov, occ, you can NOT set Pr.07-11 to 0.

07-11 Number of Times of Restart After Fault

Default: 0

Settings 0–10

- After fault (allowed fault: oc, ov, occ) occurs, the AC motor drive can reset and restart automatically up to 10 times. If Pr.07-11 is set to 0, the drive does not reset or restart automatically after faults occur. The drive starts according to the Pr.07-10 setting after restarting after fault.
- If the number of faults exceeds the Pr.07-11 setting, the drive does not reset and restart until you press "RESET" manually and execute the operation command again.

07-12 Speed T	racking During Start-up
	Default: 0
Settings	0: No function
	1: Speed tracking by the maximum output frequency
	2: Speed tracking by the current frequency command at start-up
	3: Speed tracking by the minimum output frequency
mechanical punch stop. If it needs to parameter setting flywheel stops com	
	mode, the AC motor drive executes the speed tracking function automatically urrent speed of motor when this setting is NOT 0.
07-19 Fan Coo	oling Control
	Default: 3
Settings	0: Fan is always ON
	1: Fan is OFF after the AC motor drive stops for one minute.
	2: Fan is ON when the AC motor drive runs; fan is OFF when the AC motor drive stops
	3: Fan turns ON when temperature (IGBT) reaches around 60°C.
Use this paramete	r to control the fan.
🕮 0: Fan runs immed	diately when the drive power is turned ON.
1: Fan runs when to OFF.	the AC motor drive runs. One minute after the AC motor drive stops, the fan is
2: Fan runs when	the AC motor drive runs and stops immediately when AC motor drive stops.
	en IGBT or capacitance temperature is > 60°C; Fan is OFF when IGBT and erature are both < 40°C, and the drive stops running.
07-20 Emerge	ncy Stop (EF) & Force to Stop Selection
	Default: 0
Settings	0: Coast to stop
	1: Stop by the first deceleration time
	2: Stop by the second deceleration time
	3: Stop by the third deceleration time
	4: Stop by the fourth deceleration time
	5: System deceleration
	6: Automatic deceleration
When the multi-fur	nction input terminal setting is set to 10 (EF input) or 18 (force to stop) and the

terminal contact is ON, the drive stops according to the setting of this parameter.

Automatic Energy Saving (AES) Setting

Default: 0

Settings 0: Disabled


1: AES optimization (for VF, SVC control modes)

Different control modes for Pr.07-21:

Setting value / Control Mode	Induction Motor (IM)			nt Magnet s Motor (PM)	Synchronous Reluctance Motor (SynRM)	
	VF	SVC	PMSVC	PMFOC	FOC	
1: AES optimization	✓	✓				


\square AES optimization (Pr.07-21 = 1):

- Controls the output voltage to minimize the motor's losses for optimal energy-saving. The
 motor's losses are calculated by motor parameter auto-tuning and energy-saving coefficient.
- Automatic energy-saving optimization control is according to the block diagram below:



Pr.07-21 Auto Energy-saving (AES) Selection Pr.07-41 Minimum Frequency for AES Pr.07-42 Delay Time for AES

- The prerequisites for valid AES optimization (Pr.07-21 = 2) are:
 - A. Output frequency is larger than Pr.07-41 (Minimum Frequency for AES)
 - B. The drive is in a steady-state output frequency status.
 - C. Time for steady-state output frequency is larger than Pr.07-42 (Delay Time for AES)
- The prerequisites for invalid AES optimization (Pr.07-21 = 2) are:
 - 1. A changing output frequency
 - The loss model automatically determines the voltage drops when the drive is in normal and heavy duty. If there is no more voltage that can be adjusted, that is, the voltage drop is already optimized, AES is invalid.



The energy-saving function is invalid during the drive's acceleration and deceleration. To make it valid, the prerequisites need to be verified again.

07-23 Automatic Voltage Regulation (AVR) Function

Default: 0

Settings 0: Enable AVR

1: Disable AVR

2: Disable AVR during deceleration

- The rated voltage of a 220V motor is usually 200 VAC, 60 Hz / 50 Hz, and the input voltage of the AC motor drive may vary from 180–264 VAC, 50 Hz / 60 Hz. Therefore, when the AC motor drive is used without the AVR function, the output voltage is the same as the input voltage. When the motor runs at the voltage exceeding 12–20% of the rated voltage, it causes higher temperatures, damaged insulation, and unstable torque output, which result in losses due to shorter motor lifetime.
- The AVR function automatically regulates the output voltage of the AC motor drive to the motor's rated voltage when the input voltage exceeds the motor's rated voltage. For example, if the V/F curve is set at 200 V_{AC}, 50 Hz and the input voltage is at 200–264 V_{AC}, then the drive automatically reduces the output voltage to the motor to a maximum of 200 V_{AC}, 50 Hz. If the input voltage is at 180–200 V_{AC}, the output voltage to motor is in direct proportion to the input voltage.
- © 0: When the AVR function is enabled, the drive calculates the output voltage according to the actual DC bus voltage. The output voltage does NOT change when the DC bus voltage changes.
- 1: When the AVR function is disabled, the drive calculates the output voltage according to the actual DC bus voltage. The output voltage changes with the DC bus voltage, and may cause insufficient current, over-current or oscillation.

2: The drive disables the AVR function only during deceleration to stop, and at this time, you can accelerate the braking to achieve the same result. When the motor ramps to stop, disable the AVR function to shorten the deceleration time. Then, use with the auto-acceleration and auto-deceleration functions to make the motor's deceleration more stable and quicker. Torque Command Filter Time 07-24 Default: 0.050 Settings 0.001-10.000 sec. When the time constant setting is too large, the control is stable but the control response is slow. When the time constant setting is too small, the control response is faster but the control may be unstable. For optimal setting, adjust the setting based on the control stability or the control response. 07-25 Slip Compensation Filter Time Default: 0.100 Settings 0.001-10.000 sec. Change the compensation response time with Pr.07-24 and Pr.07-25. If you set Pr.07-24 and Pr.07-25 to 10 seconds, the compensation response time is the slowest; however, the system may be unstable if you set the time too short. Torque Compensation Gain Default: 1 Settings 0–5000 When the compensation gain is set too high, it may cause motor over-flux and result in a too large output current of the drive, motor overheating or trigger the drive's protection function. In this parameter affects the output current when the drive runs. The effect is smaller at the lowspeed area. Set this parameter higher when the no-load current is too large. But the motor may vibrate if the setting is too high. If the motor vibrates when operating, reduce the setting. Slip Compensation Gain Default: 0.00 (Default value is 1.00 in SVC mode) Settings 0.00–10.00 The induction motor needs constant slip to produce electromagnetic torque. It can be ignored at higher motor speeds, such as rated speed or 2-3% of slip. However, during the drive operation, the slip and the synchronous frequency are in reverse proportion to produce the same electromagnetic torque. The slip is larger with the reduction of synchronous frequency. Moreover, the motor may stop when the synchronous frequency decreases to a specific value. Therefore, the slip seriously affects the motor speed accuracy at low speed.

Chapter 12 Descriptions of Parameter Settings | MPD


In another situation, when you use an induction motor with the drive, the slip increases when the
 □ Use this parameter to set the compensation frequency, and reduce the slip to maintain the synchronous speed when the motor runs at the rated current in order to improve the accuracy of the drive. When the drive output current is higher than Pr.05-05 (No-load Current for Induction Motor 1 (A)), the drive compensates the frequency according to this parameter. □ Apply the slip compensation after load and acceleration. Increase the compensation value from small to large gradually. If the actual speed ratio is slower than expected, increase the parameter setting value; otherwise, decrease the setting value.
07-29 Slip Deviation Level
Default: 0 Settings 0.0–100.0% 0: No detection
07-30 Over-slip Deviation Detection Time
Default: 1.0 Settings 0.0–10.0 sec.
Cettings 0.0 10.0 sec.
07-31 Over-Slip Deviation Treatment
Default: 0 Settings 0: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning
Pr.07-29 to Pr.07-31 set the allowable slip level / time and the over-slip treatment when the drive
is running.
07-32 Motor Oscillation Compensation Factor
Default: 1000 Settings 0–10000
If there are current wave motions which cause severe motor oscillation in some specific area
setting this parameter can effectively improve this situation.
When the current wave motion occurs in low frequency and high power, increase the value for Pr.07-32.
07-33 Auto-restart Interval of Fault
Default: 60.0 Settings 0.0–6000.0
When a reset / restart occurs after a fault, the drive uses Pr.07-33 as a timer and starts counting
the number of faults within this time period. Within this period, if the number of faults does no

exceed the setting for Pr.07-11, the counting clears and starts from 0 when the next fault occurs.

07-35 Status Record When the Drive Is Powered Off	
	Default: Read only
Settings 0–65535	
☐ Use this parameter with Pr.02-35 = 2. After powering on aga	ain, it will be confirmed whether
Pr.07-35 is in the running state. The drive will be started after the	e delay time set by Pr.07-36.
Restart Delay Time after Power Off	
	Default: 5
Settings 1–10 sec.	
07-38 Voltage Feed Forward Gain	
	Default: 1.00
Settings 0.50–2.00	
Adjusts the voltage feedback forward gain under MSI control, a	and to meet the demand of rapid
feedback application.	
Pr.07-38 = 1.00 means forward feedback = Ke x motor rotor spe	eed
AES Minimum Frequency	
	Default: 10.00
Settings	
The drive output frequency must be higher than Pr.07-41 to make	ke the drive determine whether to
run in a steady-state output frequency.	
\square The power and voltage of high-frequency fields are larger and y	ield obvious energy-saving
effects. A larger start-up current is needed for the low-speed zor	ne, reducing voltage is
unfavorable to low-speed zone. Therefore, you can use Pr.07-4	1 to limit the minimum frequency
when AES is enabled (Pr.07-41 to Pr.01-00 is the frequency ran	ge that you can use for the AES
function).	
AES Delay Time	
	Default: 5
Settings 0-600 sec.	
When the drive runs in a steady-state output frequency, and ex	xceeds Pr.07-42 setting time, the
drive enters the energy-saving mode.	
07-44 AES Maximum Voltage Drop	
	Default: 60.00
Settings 0.00–70.00%	
Define the maximum allowed voltage drop when the drive is in e	energy-saving mode.
The energy-saving effect is most obvious when the drive runs a	at no load or light load. However,
the output voltage cannot drop indefinitely. You can use this par-	ameter as the upper limit ratio (%)
of the maximum voltage drop of the output voltage.	
☐ Maximum voltage drop = voltage command corresponding to the	e frequency command in the VF
table (take Motor 1 VF curve as an example, Pr.01-01-08) ×	: Pr.07-44 (%)
For example:	

Default: 100


- (1) Pr.01-01 = 60 Hz, Pr.01-02 = 380 V_{AC} , current frequency command is 60 Hz, the actual motor output is 371.2 V_{AC} , and Pr.07-44 = 60%, then The maximum voltage drop = 380 V (voltage command corresponding to the frequency command in the VF table: 60 Hz corresponds to 380V) × 60% = 228 V_{AC}
- (2) If the current frequency command is 30 Hz, the corresponded voltage in the VF table is 200 V_{AC} , and Pr.07-44 = 60%, then The maximum voltage drop = 200V × 60% = 120 V_{AC}




✓ 07-45 AES Coefficient

Settings 0–10000%

- Define the motor power loss constant. Default 100% corresponds to the drive's iron loss constant that is calculated by motor parameter auto-tuning or motor nameplate information.
- Pr.07-45 affects the final steady-state output voltage value for the energy-saving control. The larger the Pr.07-45 setting value, the higher the steady-state output voltage (smaller voltage drop). The smaller the Pr.07-45 setting value, the lower the steady-state output voltage (larger voltage drop).
- See below for the flowchart of AES adjustment with motor parameter auto-tuning (recommended):



See below for the flowchart of AES adjustment without motor parameter auto-tuning (not recommended):



№ 07-82 AES Kp Gain

Default: 500

Settings 0-65535 pu

- This parameter can be used to adjust the AES gain. The default is 500%, if the energy saving effect is not good, you can adjust it downward; if the motor oscillates, you can adjust it upward.
- In some applications, such as high-speed spindles, you have to pay more attention to the temperature rise of the motor. If the motor is not in the operation state, the current of the motor can be reduced to a lower current. Lower the parameter setting can achieve this requirement.

√ 07-83 AES Ki Gain

Default: 500

Settings 0-65535 pu

[This page intentionally left blank]

08 High-function PID Parameters

✓ You can set this parameter during operation.

✓ 08-00 Terminal selection of PID feedback


Default: 0

Settings 0: Disabled

1: Negative PID feedback: by analog input (Pr.03-00)

- Negative feedback: Error = Target value (set point) Feedback. Use negative feedback when the detection value increases if the output frequency increases.
- 1. Common applications for PID control:
 - Flow control: Use a flow sensor to feedback the flow data and perform accurate flow control.
 - Pressure control: Use a pressure sensor to feedback the pressure data and perform precise pressure control.
 - Air volume control: Use an air volume sensor to feedback the air volume data to achieve excellent air volume regulation.
 - Temperature control: Use a thermocouple or thermistor to feedback temperature data for comfortable temperature control.
 - Speed control: Use a speed sensor to feedback motor shaft speed or input another machine speed as a target value for synchronous control.

2. PID control loop:



K_P Proportional Gain (P), T_i Integral Time (I), T_d Differential Time (D), S Calculation

3. Concept of PID control:

(1) Proportional gain (P):

The output is proportional to input. With only a proportional gain control, there is always a steady-state error.

(2) Integral time (I):

The controller output is proportional to the integral of the controller input. When an automatic control system is in a steady state and a steady-state error occurs, the system is called a System with Steady-state Error. To eliminate the steady-state error, add an "integral part" to the controller. The integral time controls the relation between the integral part and the error. The integral part increases over time even if the error is small. It gradually increases the controller output to eliminate the error until it is zero. This stabilizes the system without a steady-state error by using proportional gain control and integral time control.


(3) Differential control (D):

The controller output is proportional to the differential of the controller input. During

elimination of the error, oscillation or instability may occur. Use the differential control to suppress these effects by acting before the error. That is, when the error is near 0, the differential control should be 0. Use proportional gain (P) and differential control (D) to improve the system state during PID adjustment.

4. Using PID control in a constant pressure pump feedback application:

Set the application's constant pressure value (bar) to be the set point of PID control. The pressure sensor sends the actual value as the PID feedback value. After comparing the PID set point and PID feedback, an error display. The PID controller calculates the output by using proportional gain (P), integral time (I) and differential time (D) to control the pump. It controls the drive to use a different pump speed and achieves constant pressure control by using a 4–20 mA signal corresponding to 0–10 bar as feedback to the drive.



- Pr.00-03 = 4 (displays PID target value and analog feedback signal value)
- Pr.01-12 Acceleration Time is set according to actual conditions.
- Pr.01-13 Deceleration Time is set according to actual conditions.
- Pr.00-21 = 0, operate through the digital keypad
- Pr.00-20 = 0, the digital keypad controls the set point.
- Pr.00-25 = 353, set user-defined AI signal unit to be one decimal place.
- Pr.00-26 = 10, set user-defined AI signal maximum is 10.0 bar.
- Pr.08-00 = 1 (negative PID feedback from analog input)
- Al1 analog input Pr.03-00 = 5, PID feedback signal.
- Set Pr.03-28 as 2 to be current type sensor 4–20 mA, and make sure DIP switch is on current type side.
- Set Pr.08-01-08-03 according to actual conditions.

 If there is no oscillation in the system, increase Pr.08-01 (Proportional Gain (P))

 If there is no oscillation in the system, decrease Pr.08-02 (Integral Time (I))

 If there is no oscillation in the system, increase Pr.08-03 (Differential Time (D))
- Refer to Pr.08-00–08-21 for PID parameter settings.

		Chapter 12 Descriptions of Parameter Settings MPD
/	08	Proportional Gain (P)
		Default: 1.00
		Settings 0.0–500.0 (when Pr.08-23 setting bit 1=0)
		0.00-500.00 (when Pr.08-23 setting bit 1=1)
		1.0: Kp gain is 100%; if the setting is 0.5, Kp gain is 50%.
		Sets the proportional gain to determine the deviation response speed. The higher the
	ŗ	proportional gain, the faster the response speed, and causes oscillation. The lower the
	ţ	proportional gain, the slower the response speed. Eliminate the system deviation; usually used
	t	to decrease the deviation and get faster response speed. If you set the value too high,
	C	overshoot occurs and it may cause system oscillation and instability.
		If you set the other two gains (I and D) to zero, proportional control is the only effective
	ŗ	parameter.
/	08	8-02 Integral Time (I)
		Default: 1.00
		Settings 0.00–100.00 sec.
	Q (Use the integral controller to eliminate the deviation during stable system operation. The integral
	C	control does not stop working until the deviation is zero. The integral is affected by the integral
	t	time. The smaller the integral time, the stronger the integral action. It is helpful to reduce
		overshoot and oscillation for a stable system. Accordingly, the speed to lower the steady-state
	-	deviation decreases. The integral control is often used with the other two controls for the Pl
	C	controller or PID controller.
		Sets the integral time of the I controller. When the integral time is long, there is a small I
		Sets the integral time of the I controller. When the integral time is long, there is a small I controller gain, with slower response and slow external control. When the integral time is short,
	Q S	Sets the integral time of the I controller. When the integral time is long, there is a small I controller gain, with slower response and slow external control. When the integral time is short, there is a large I controller gain, with faster response and rapid external control.
		Sets the integral time of the I controller. When the integral time is long, there is a small I controller gain, with slower response and slow external control. When the integral time is short,

08-03 Differential Time (D)

Default: 0.00

Settings 0.00–1.00 sec.

Set Integral Time to 0.00 to disable the I controller.

- Use the differential controller to show the system deviation change, as well as to preview the change in the deviation. You can use the differential controller to eliminate the deviation in order to improve the system state. Using a suitable differential time can reduce overshoot and shorten adjustment time; however, the differential operation increases noise interference. Note that a too large differential causes more noise interference. In addition, the differential shows the change and the differential output is 0 when there is no change. Note that you cannot use the differential control independently. You must use it with the other two controllers for the PD controller or PID controller.
- sets the D controller gain to determine the deviation change response. Using a suitable differential time reduces the P and I controllers overshoot to decrease the oscillation for a stable system. A differential time that is too long may cause system oscillation.

Chapter 12 Descriptions of Parameter Settings | MPD


The differential controller acts on the change in the deviation and cannot reduce the interference. Do not use this function when there is significant interference. 08-04 **Upper Limit Of Integral Control** Default: 100.0 Settings 0.0-100.0% Defines an upper bound for the integral gain (I) and therefore limits the master frequency. The formula is: Integral upper bound = Maximum Operation Frequency (Pr.01-00) x (Pr.08-04%). An excessive integral value causes a slow response due to sudden load changes and may cause motor stall or machine damage. If so, decrease it to a proper value. PID Output Command Limit (Positive Limit) Default: 100.0 Settings 0.0-100.0% Define the percentage of the output frequency limit during the PID control. The formula is Output Frequency Limit = Maximum Operation Frequency (Pr.01-00) x Pr.08-05%. 08-20 PID Mode Selection Default: 0 0: Serial connection Settings 1: Parallel connection 0: Use conventional PID control structure. 1: The proportional gain, integral gain and differential gain are independent. You can customize the P, I and D value to fit your application. This parameter determines the primary low pass filter time when in PID control. Setting a large time constant may slow down the drive's response speed. PID control output frequency is filtered with a primary low pass function. This function can filter a mix of frequencies. A long primary low pass time means the filter degree is high and a short primary low pass time means the filter degree is low. Inappropriate delay time setting may cause system oscillation. PI Control: Controlled only by the P action, so the deviation cannot be entirely eliminated. In general, to eliminate residual deviations, use the P + I controls. When you use the PI control, it eliminates the deviation caused by the targeted value changes and the constant external interferences. However, if the I action is too powerful, it delays the response when there is rapid variation. You can use the P action by itself to control the loading system with the integral components. PD Control: When deviation occurs, the system immediately generates an operation load that is greater than the load generated only by the D action to restrain the deviation increment. If the deviation is small, the effectiveness of the P action decreases as well. The control objects include applications with integral component loads, which are controlled by the P action only. Sometimes, if the integral component is functioning, the whole system may oscillate. In this case, use the PD control to reduce the P action's oscillation and stabilize the system. In other words, this control is

useful with no brake function's loading over the processes.


PID Control:

Use the I action to eliminate the deviation and the D action to reduce oscillation; then combine this with the P action for the PID control. Use the PID method for a control process with no deviations, high accuracy, and a stable system.

Serial connection



Parallel connection



Default: 0.0

Settings 0.0–3600.0 sec.

- \square Valid only when the feedback signal is 4–20 mA (Pr.03-28 = 2).
- This parameter sets the detection time for abnormal PID signal feedback. You can also use it when the system feedback signal response is extremely slow. (Setting the detection time to 0.0 disables the detection function.)

Default: 0

Settings 0: Warn and continue operation

1: Fault and ramp to stop

2: Fault and coast to stop

3: Warn and operate at last frequency

- \square Valid only when the feedback signal is 4–20 mA (Pr.03-28 = 2).
- Set the treatments when the PID feedback signal is abnormal.

№ 08-23 PID Control Flag

Default: 2

Settings bit 1 = 1, two decimal places for PID Kp bit 1 = 0, one decimal place for PID Kp

When the bit1 setting changes, the Kp gain does not change.

For example: Kp = 6. When Pr.08-23 bit 1 = 0, Kp = 6.0; when Pr.08-23 bit 1 = 1, Kp = 6.00.

N 08-55 PID Feedback Mathematics

Default: 0

Settings 0: Al1

1: AI1 + k*AI2

2: Al1 - k*Al2

3: Al1 * k*Al2

4: AI1 / k*AI2

5: MIN(AI1, AI2)

6: MAX(AI1, AI2)

7: AVE(AI1, AI2)

8: sqrt(Al1)

9: sqrt(Al1 – Al2)

10: sqrt(AI1 + AI2)

11: sqrt(AI1) + sqrt(AI2)


12: k * sqrt(Al1)

13: k * sqrt(Al1 – Al2)

14: (AI1 - AI2)²

15: $(AI1)^2 + (AI2)^2$

When executing PID control, the feedback source can be the value calculated from different mathematical source. k is the value set by Pr.08-56.



×	08-56 PID Feedback Mathematics Gain	
		Default: 1.0
	Settings -300.0-300.0	
	Define the k value for the mathematics of Pr.08-55.	
×	08-57 PID Feedback Mathematics Upper Limit	
		Default: 0
	Settings 0-999	

 \square This parameter limits the PID feedback mathematical operation value of when Pr.08-55 \neq 0.

[This page intentionally left blank]

09 Communication Parameters

Using communication interface, it's recommended that uses Delta's IFD6530 or IFD6500 as communication adapter, and uses terminal SG+, SG- to connect the drive and PC.

✓ You can set this parameter during operation.

Default: 1

O9-00 Communication Address

Settings 1–254

- Set the communication address for the drive if the AC motor drive is controlled through RS-485 serial communication. The communication address for each AC motor drive must be unique.
- When multi-master function of PLC is enabled, every drive has to set the parameter for distinguishing station address.

√ 09-01 COM1 Transmission Speed

Default: 115.2

Settings 4.8-115.2 Kbps

- Set the transmission speed between the computer and the AC motor drive.
- Options are 4.8 Kbps, 9.6 Kbps, 19.2 Kbps, 38.4 Kbps, or 115.2 Kbps; if the setting value is not to be one of the transmission speeds mentioned above, then the drive uses 9.6 Kbps.

N 09-02 COM1 Transmission Fault Treatment

Default: 3

Settings 0: Warn and continue operation

1: Fault and ramp to stop

2: Fault and coast to stop

3: No warning, no fault, and continue operation

- Determines the treatment when an error is detected that the host controller does not continuously transmit data to the AC motor drive during Modbus communication. The detection time is based on the Pr.09-03 setting.
- When a transmission error occurs (for example, the error code CE10 is displayed), the error remains even if the transmission status returns to normal, and does not clear automatically. In this case, set a reset command (Reset) to clear the error.

Default: 0.0

Settings 0.0-100.0 sec.

- Set the communication time-out.
- lt's recommended that sets the value to be 10.0 seconds under multi-master mode (enables built-in PLC function).

Default: 12

Settings 1: 7, N, 2 (ASCII)

2: 7, E, 1 (ASCII)

3: 7, O, 1 (ASCII) 4: 7, E, 2 (ASCII) 5: 7, O, 2 (ASCII) 6: 8, N, 1 (ASCII) 7: 8, N, 2 (ASCII) 8: 8, E, 1 (ASCII) 9: 8, O, 1 (ASCII) 10: 8, E, 2 (ASCII) 11: 8, O, 2 (ASCII) 12: 8, N, 1 (RTU) 13: 8, N, 2 (RTU) 14: 8, E, 1 (RTU) 15: 8, O, 1 (RTU) 16: 8, E, 2 (RTU) 17: 8, O 2 (RTU) COM1 is for multi-pump control of MPD. COM2 is for writing in PLC, connecting to upper device. COM2 Transmission Speed Default: 9.6 Settings 4.8–115.2 Kbps Set the transmission speed between the computer and the AC motor drive. Options are 4.8 Kbps, 9.6 Kbps, 19.2 Kbps, 38.4 Kbps, or 115.2 Kbps; if the setting value is not to be one of the transmission speeds mentioned above, then the drive uses 9.6 Kbps. Default: 3 0: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning, no fault, and continue operation

09-06 COM2 Transmission Fault Treatment

09-05

Settings

- Determines the treatment when an error is detected that the host controller does not continuously transmit data to the AC motor drive during Modbus communication. The detection time is based on the Pr.09-07 setting.
- When a transmission error occurs (for example, the error code CE10 is displayed), the error remains even if the transmission status returns to normal, and does not clear automatically. In this case, set a reset command (Reset) to clear the error.

09-07 COM2 Time-out Detection

Default: 0.0

Settings 0.0–100.0 sec.

Set the communication time-out.

09-08 COM2 Communication Protocol

Default: 1

Settings 1: 7, N, 2 (ASCII)

2: 7, E, 1 (ASCII)

3: 7, O, 1 (ASCII)

4: 7, E, 2 (ASCII)

5: 7, O, 2 (ASCII)

6: 8, N, 1 (ASCII)

7: 8, N, 2 (ASCII)

8: 8, E, 1 (ASCII)

9: 8, O, 1 (ASCII)

10: 8, E, 2 (ASCII)

11: 8, O, 2 (ASCII)

12: 8, N, 1 (RTU)

13: 8, N, 2 (RTU)

14: 8, E, 1 (RTU)

15: 8, O, 1 (RTU)

16: 8, E, 2 (RTU)

17: 8, O 2 (RTU)

Control by PC (Computer Link)

When using the RS-485 serial communication interface, you must specify each drive's communication address in Pr.09-00. The computer then implements control using the drives' individual addresses.

Modbus ASCII (American Standard Code for Information Interchange): Each byte of data is the combination of two ASCII characters. For example, one byte of data: 64 Hex, shown as '64' in ASCII, consists of '6' (36Hex) and '4' (34Hex).

1. Code Description


The communication protocol is in hexadecimal, ASCII: "0" ... "9", "A" ... "F", every hexadecimal value represents an ASCII code. The following table shows some examples. Example:


Character	'0'	'1'	'2'	'3'	'4'	' 5'	'6'	'7'
ASCII code	30H	31H	32H	33H	34H	35H	36H	37H
Character	'8'	'9'	'A'	'B'	'C'	'D'	'E'	'F'
ASCII code	38H	39H	41H	42H	43H	44H	45H	46H


2. Data Format


10-bit character frame (For ASCII):

(Format: 7, N, 2)









11-bits character frame

3. Communication Protocol

3.1 Communication Data Frame

ASCII mode:

STX	Start character = ':' (3AH)
Address Hi	Communication address:
Address Lo	one 8-bit address consists of 2 ASCII codes
Function Hi	Command code:
Function Lo	one 8-bit command consists of 2 ASCII codes
DATA (n-1)	Contents of data:
	n x 8-bit data consists of 2n ASCII codes
DATA 0	n ≤ 16, maximum of 32 ASCII codes (20 sets of data)
LRC CHK Hi	LRC checksum:

LRC CHK Lo	one 8-bit checksum consists of 2 ASCII codes
END Hi	End characters:
END Lo	END Hi = CR (0DH), END Lo = LF (0AH)

RTU mode:

START	Defined by a silent interval of more than 10 ms	
Address	Communication address: 8-bit binary address	
Function	Command code: 8-bit binary command	
DATA (n-1)	Contents of data:	
	Contents of data:	
DATA 0	N × 8-bit data, n ≤16	
LRC Check Low	CRC checksum:	
LPC Chook High	one 16-bit CRC checksum consists of 2 8-bit binary	
LRC Check High	characters	
END	Defined by a silent interval of more than 10 ms	

Communication Address (Address)

00H: Broadcast to all AC motor drives

01H: AC motor drive at address 01 0FH: AC motor drive at address 15

10H: AC motor drive at address 16, and so on... FEH: AC motor drive of address 254

Function (Function code) and DATA (Data characters)

03H: Read data from register

06H: Write a single data to register

Example: Reading two continuous data from register address 2102H. AMD address is 01H.

ASCII mode:

Command Message

Response Message

Command Wessage		1/csponse Message	
STX	· . ,	STX	. ,
A ddro o o	'0'	A dalago o	'0'
Address	'1'	Address	'1'
Function	'0'	Function	' 0'
Function	'3'	Function	'3'
	'2'	Number of register	' 0'
Ctauting upgister	'1'	(count by byte)	'4'
Starting register	'0'		'1'
	'2'	Content of starting	'7'
	'0'	register 2102H	'7'
Number of register	'0'		' 0'
(count by word)	'0'		'0'
	'2'	Content of register 2102U	' 0'
LDC Chook	'D'	Content of register 2103H	' 0'
LRC Check	'7'		' 0'
END	CR	LDC Charle	'7'
END	LF	LRC Check	'1'
		END	CR
		EIND	LF

RTU mode:

Command Message

Response Message	
Address	
Function	
NI I C ' C	

	~
Address	01H
Function	03H
Starting data register	21H
Starting data register	02H
Number of register	00H
(count by world)	02H
LRC Check Low	6FH
LRC Check High	F7H

Address	01H
Function	03H
Number of register (count by byte)	04H
Content of register	17H
address 2102H	70H
Content of register	00H
address 2103H	00H
LRC Check Low	FEH
LRC Check High	5CH

06H: Write a single data to register

Example: Writing data 6000 (1770H) to register 0100H. AMD address is 01H.

ASCII mode:

Command Message

Response	Message
----------	---------

Command Wessage		Nesponse Message		
STX	·.,	STX	· · ·	
A alabas a a	'0'	A dalaa a a	'0'	
Address	'1'	Address	'1'	
C atia	'0'		'0'	
Function	'6'	Function	·6'	
	'0'		'0'	
Toward we minter	'1'	Townst us sister	'1'	
Target register	'0'	Target register	'0'	
	'0'		'0'	
	'1'	Dogistor content	'1'	
Dogistor content	'7'		'7'	
Register content	'7'	Register content	'7'	
	'0'		'0'	
L DC Chook	'7'	LDC Chook	'7'	
LRC Check	'1'	LRC Check	'1'	
END	CR	END	CR	
EIND	LF	EIND	LF	

RTU mode:

Command Message

Response Message

Address	01H	Address	01H
Function	06H	Function	06H
Torget register	01H	Torget register	01H
Target register	00H	Target register	00H
Degister content	17H	Degister centent	17H
Register content	70H	Register content	70H
LRC Check Low	86H	LRC Check Low	86H
LRC Check High	22H	LRC Check High	22H

10H: write multiple registers (write multiple data to registers). The system can write up to 20 sets of data simultaneously.

Example: Set the multi-step speed of an AC motor drive (address is 01H):

'0' '1'

'1'

'0'

'0' '5'

'0' '0' '0'

'0'

'0' '2'

'0' '4'

'1' '3'

'8' '8' '0' 'F'

'A' '0' '9'

'A' CR

LF

Pr.04-00 = 50.00 (1388H), Pr.04-01 = 40.00 (0FA0H)

0FA0H

ASCII mode:

Command N	Лessage
-----------	---------

STX ADR 1

ADR 0

CMD 1

CMD 0

Target register

Number of register

(count by word)

Number of register

(count by Byte)

The first data content

The second data content

LRC Check

END

Response Message

STX	· ·
ADR 1	' 0'
ADR 0	'1'
CMD 1	'1'
CMD 0	'0'
	'0'
Townst up winter	' 5'
Target register	' 0'
	' 0'
	' 0'
Number of register	' 0'
(count by word)	' 0'
	'2'
I DO Obask	'E'
LRC Check	'8'
END	CR
END	LF

RTU mode:

Command Message

ADR	01H
CMD	10H
Torget register	05H
Target register	00H
Number of register	00H
(Count by word)	02H
Quantity of data (bytes)	04
The first data content	13H
The first data content	88H
The enemy date content	0FH
The second data content	A0H
CRC Check Low	' 9'
CRC Check High	'A'

Response Message

01H
10H
05H
00H
00H
02H
41H
04H

ASCII mode (LRC Check):

LRC (Longitudinal Redundancy Check) is calculated by summing up the values of the bytes from ADR1 to the last data character then calculating the hexadecimal representation of the 2'scomplement negation of the sum.

Example:

01H + 03H + 21H + 02H + 00H + 02H = 29H, the 2's-complement negation of 29H is D7H.

RTU mode (CRC Check):

CRC (Cyclical Redundancy Check) starts from Address and ends at Data Content. It is calculated by the following steps:

- Step 1: Load a 16-bit register (called CRC register) with FFFFH.
- Step 2: Exclusive OR the first 8-bit byte of the command message with the low order byte of the 16-bit CRC register, and put the result in the CRC register.
- Step 3: Examine the LSB of CRC register.
- Step 4: If the LSB of CRC register is 0, shift the CRC register one bit to the right, fill MSB with zero, then repeat step 3. If the LSB of CRC register is 1, shift the CRC register one bit to the right, fill MSB with zero, Exclusive OR the CRC register with the polynomial value A001H, then repeat step 3.
- Step 5: Repeat step 3 and 4 until you perform eight shifts. This processes a complete 8-bit byte.
- Step 6: Repeat step 2 through 5 for the next 8-bit byte of the command message. Continue doing this until all bytes are processed. The final contents of the CRC register are the CRC value. When transmitting the CRC value in the message, the upper and lower bytes of the CRC value must be swapped, that is, the lower order byte is transmitted first.

The following is an example of CRC generation using C language. The function takes two arguments: Unsigned char* data ← a pointer to the message buffer

Unsigned char length ← the quantity of bytes in the message buffer

The function returns the CRC value as a type of unsigned integer. Unsigned int crc chk(unsigned char* data, unsigned char length)

```
{
      int j;
      unsigned int reg_crc=0Xffff;
      while(length--){
           reg_crc ^= *data++;
           for(j=0;j<8;j++){
                if(reg_crc & 0x01){ /* LSB(b0)=1 */
                     reg_crc=(reg_crc>>1) ^ 0Xa001;
                }else{
                     reg_crc=reg_crc >>1;
                }
           }
      }
                                         // return register CRC
      return reg_crc;
}
```

4. Address list

Definition	Register	Function	
AC motor drive	GGnnH	•	arameter group, nn is the parameter number.
parameters	GGIIIII	For example	e, the address of Pr.04-10 is 0401H.
			00B: No function
		bit 1–0	01B: Stop
		Dit 1—0	10B: Run
			11B: JOG Enable
		bit 3–2	Reserved
			00B: No function
		bit 5–4	01B: FWD
			10B: REV
			11B: Change direction
			00B: 1st accel. / decel.
		bit 7–6	01B: 2nd accel. / decel
		DIL 7—6	10B: 3rd accel. / decel.
			11B: 4th accel. / decel.
			0000B: Master speed
			0001B: 1st Step speed frequency
			0010B: 2 nd Step speed frequency
			0011B: 3 rd Step speed frequency
	2000H		0100B: 4 th Step speed frequency
			0101B: 5 th Step speed frequency
		bit 11–8	0110B: 6 th Step speed frequency
			0111B: 7 th Step speed frequency
Command write only			1000B: 8 th Step speed frequency
Command write only			1001B: 9th Step speed frequency
			1010B: 10th Step speed frequency
			1011B: 11 th Step speed frequency
			1100B: 12 th Step speed frequency
			1101B: 13 th Step speed frequency
			1110B: 14 th Step speed frequency
			1111B: 15 th Step speed frequency
		bit 12	1: Enable bit 06–11 function
			00B: No function
		hit 14 12	01B: Operated by digital keypad
		bit 14–13	10B: Operated by Pr.00-21 setting
			11B: Switch the operation command source
		bit 15	Reserved
	2001H	Frequency	command (XXX.XX Hz)
		bit 0	1: E.F. ON
		bit 1	1: Reset
	2002H	bit 2	1: Base Block (B.B) ON
		bit 4–3	Reserved
		bit 5	1: Trigger fire mode
			0: Does not trigger fire mode
			NOTE: Clear bit 5 = 1, issues STOP command
			to clear by communication

Definition	Register	Function		
	-	bit 15–6 Reserved		
	0100::	High Byte: V		
	2100H	Low Byte: E		
			AC motor drive operation status	
			00B: Drive stops	
		bit 1-0	01B: Drive decelerating	
			10B: Drive standby	
			11B: Drive operating	
		bit 2	1: JOG command	
			Operation direction	
			00B: FWD run	
		bit 4-3	01B: From REV run to FWD run	
	2101H		10B: REV run	
	210111		11B: From FWD run to REV run	
		bit 8	1: Master frequency controlled by the	
		Dit 0	communication interface	
		bit 9	1: Master Frequency command controlled by	
			analog / external signal	
		bit 10	1: Operation command controlled by the	
			communication interface	
		bit 11	1: Parameter lock	
		bit 12	1: Enable to copy parameters from keypad	
	040011	bit 15–13	Reserved	
Status monitor read	2102H	Frequency command (XXX.XX Hz) Output frequency (XXX.XX Hz)		
only	2103H		· · · · · · · · · · · · · · · · · · ·	
	2104H	Output current (XX.XX A). When current is higher than 655.35, it shifts the decimal as (XXX.X A).		
	210411	•	I can refer to High byte of 211F.	
	2105H	DC bus voltage (XXX.X V)		
	2106H	Output voltage (XXX.X V)		
	2107H	Current step for the multi-step speed operation		
	2108H	Reserved		
	2109H	Counter value		
	210AH		r angle (XXX.X)	
	210BH	Output torqu	ue (XXX.X %)	
	210CH	Motor speed	d (XXXXX rpm)	
	210DH	Reserved		
	210EH	Reserved		
	210FH	Prompt Pow	ver output (XX.XXX kW)	
	2116H	Multi-function	on display (Pr.00-04)	
		Maximum Operation Frequency (Pr.01-00) or Maximum		
		User-defined Value (Pr.00-26)		
		• When Pr.00-26 is 0, this value is equal to Pr.01-00 setting.		
	211BH	When Pr.00-26 is not 0, and the command source is		
		keypad, this value = Pr.00-24 * Pr.00-26 / Pr.01-00.		
		 When Pr.00-26 is not 0, and the command source is 485, 		
	044=::	this value = Pr.09-10 * Pr.00-26 / Pr.01-00.		
	211FH	High byte: decimal of current value (display)		

Definition	Register	Function		
	2200H	Display output current (A). When current is higher than 655.35, it shifts the decimal as (XXX.X A). The decimal can refer to High byte of 211F.		
	2201H	Counter value		
	2202H	Actual output frequency (XXXXX Hz)		
	2203H	DC bus voltage (XXX.X V)		
	2204H	Output voltage (XXX.X V)		
	2205H	Power angle (XXX.X)		
	2206H	Display actual motor speed kW of U, V, W (XXXX.X kW)		
	2207H	Display motor speed in rpm estimated by the drive (XXXX		
		rpm) Dipplay positive / pogetive output torque in 9/ estimated by		
	2208H	Display positive / negative output torque in %, estimated by the drive (+0.0: positive torque, -0.0: negative torque) (XXX.X%)		
	2209H	Reserved		
	220AH	PID feedback value after enabling PID function (XXX.XX%)		
	220BH	Display signal of Al1 analog input terminal, 0–10 V / 0–20 mA / 4–20 mA correspond to 0.00–100.00% (see NOTE 1 in Pr.00-04)		
	220CH	Display signal of Al2 analog input terminal, 0–10 V / 0–20 m / 4–20 mA correspond to 0.00–100.00% (see NOTE 1 in Pr.00-04)		
	220DH	Reserved		
Status monitor read	220EH	IGBT temperature of drive power module (XXX.X °C)		
only	220FH	The temperature of capacitor (TH2)		
	2210H	The status of digital input (ON / OFF), refer to Pr.02-12 (see NOTE 3 in Pr.00-04)		
	2211H	The status of digital output (ON / OFF), refer to Pr.02-18 (see NOTE 4 in Pr.00-04)		
	2212H	Current step for the multi-step speed operation		
	2213H	The corresponding CPU pin status of digital input (d.) (see NOTE 3 in Pr.00-04)		
	2214H	The corresponding CPU pin status of digital output (O.) (see NOTE 4 in Pr.00-04)		
	2215H	Reserved		
	2217H	Reserved		
	2218H	Reserved		
	2219H	Display times of counter overload (XXX.XX%)		
	221AH	GFF (XXX.XX%)		
	221BH	DC bus voltage ripples (XXX.X V)		
	221CH	Display the PLC register D1043 data		
	221DH	Reserved		
	221EH	User page displays the value in physical measure		
	221FH	Output value of Pr.00-05 (XXX.XX Hz)		
	2220H	Reserved		
	2221H	Reserved		
	2222H	Reserved		
	2223H	Control mode of the drive 0: speed mode		

Definition	Register	Function		
	2224H	Carrier frequency of the drive (XX kHz)		
	2225H	Reserved		
		Motor drive status		
			00b: No direction	
		bit 1-0	01b: Forward	
			10b: Reverse	
	2226H	P:+ 0 0	01b: Driver ready	
	222011	bit 3–2	10b: Error	
		hit 1	0b: Motor drive does not output	
		bit 4	1b: Motor drive outputs	
		h:+ F	0b: No warning	
		bit 5	1b: Warning	
	2227H	Drive's estir	nated output torque (positive or negative	
	222111	direction) (X	(XXX Nt-m)	
	2228H	Reserved		
	2229H	Accumulate	KWH display (XXXX.X)	
	222AH	Reserved		
	222BH	Reserved		
	222CH	Reserved		
Status monitor read	222DH	Reserved		
only	222EH	PID referen	ce (XXX.XX%)	
	222FH	PID offset (2	XXX.XX%)	
	2230H	PID output f	requency (XXX.XX Hz)	
	2231H	The value o	f thermocouple-PT100	
	2232H	Display the	auxiliary frequency	
	2233H	Display the	master frequency	
	2234H	Display the frequency after adding and subtracting of the master and auxiliary frequencies.		
	2260H	Flow rate es	stimation (unit: m³/hr, one decimal place)	
	2270H	Flow rate es	stimation (unit: m³/hr, two decimal places)	
	2261H	Inlet pressu	re (unit: bar, two decimal place)	
	2271H	Inlet pressure (unit: bar, the decimal place determined by Pr.00-38)		
	2262H	Outlet pressure (unit: bar, two decimal places)		
	2272H	Outlet pressure (unit: bar, the decimal place determined by Pr.00-26)		
		Cavitation status		
	2273H	0: The estimation does not start.		
		1: Execute cavitation detection		
		2: Cavitation occurs		

5. Exception response:

When the drive is using the communication connection, if an error occurs, the drive responds to the error code and sets the highest bit (bit 7) of the command code to 1 (function code AND 80H) then responds to the control system to signal that an error occurred. If the keypad displays "CE-XX" as a warning message, "XX" is the error code at that time. Refer to the table of error codes for communication error for reference.

Example:

ASCII mode:

RTU mode:

STX	· ·
Addroop	'0'
Address	'1'
Function	'8'
Function	' 6'
Formation and	'0'
Exception code	'2'
LDC Chook	'7'
LRC Check	'7'
END	CR
END	LF

Address	01H
Function	86H
Exception code	02H
LRC Check Low	СЗН
LRC Check High	A1H

The explanation of error codes


Fault codes	Descriptions
1	Function code is not supported or unrecognized
2	Address is not supported or unrecognized.
3	Data is not correct or unrecognized.
4	Failure to execute this function code

N 09-09 Communication Response Delay Time

Default: 2.0

Settings 0.0–200.0 ms

If the host controller does not finish the transmitting/receiving process, you can use this parameter to set the response delay time after the AC motor drive receives communication command as shown in the following picture.



09-10 Communication Main Frequency

Default: 60.00

Settings 0.00–599.00 Hz

When you set Pr.00-20 to 1 (RS-485 serial communication), the AC motor drive saves the last Frequency command into Pr.09-10 when there is abnormal power off or momentary power loss. When power is restored, the AC motor drive operates with the frequency in Pr.09-10 if there is no new Frequency command input. When a Frequency command of 485 changes (the Frequency command source must be set as Modbus), this parameter also changes.

×	09-11	Block Transfer 1
×	09-12	Block Transfer 2
×	09-13	Block Transfer 3
×	09-14	Block Transfer 4
×	09-15	Block Transfer 5
×	09-16	Block Transfer 6
×	09-17	Block Transfer 7
×	09-18	Block Transfer 8
×	09-19	Block Transfer 9
×	09-20	Block Transfer 10
×	09-21	Block Transfer 11
×	09-22	Block Transfer 12
×	09-23	Block Transfer 13
×	09-24	Block Transfer 14
×	09-25	Block Transfer 15
×	09-26	Block Transfer 16

Settings 0-65535

There is a group of block transfer parameters available in the AC motor drive (Pr.09-11–Pr.09-26). Using communication code 03H, you can store the parameters (Pr.09-11–Pr.09-26) that you want to read.

09-30 Communication Decoding Method

Default: 0

Default: 0

Settings 0: Decoding method 1
1: Decoding method 2

The EtherCAT communication card only supports Decoding Method 2 (60xx).

	munication ding Method	Decoding Method 1 Decoding Method 2			
	Digital Keypad	Digital keypad controls the drive as method 1 or 2.	d controls the drive action regardless of decoding 2.		
Source	External Terminal	External terminal controls the drive action regardless of decoding method 1 or 2.			
operation control	RS-485	Refer to address: 2000h–20FFh	No support for 6000h decoding		
	Communication Card	Refer to address: 2000h–20FFh	Refer to address: 6000h–60FFh		

09-31 COM1 internal communication protocol

Default: 0

Settings 0: Modbus 485

-12: Modbus master (for PLC)

-21: ID1 (Pump Master)

-23: ID3 (Pump Slave) -24: ID4 (Pump Slave) -25: ID5 (Pump Slave) -26: ID6 (Pump Slave) -27: ID7 (Pump Slave) -28: ID8 (Pump Slave) 09-32 SG2 COM Protocol Default: 0 Settings 0: Modbus 1: BACnet/TP 09 - 33PLC command force to 0 Default: 0 Settings bit 0: every time before PLC scan, set the PLC target frequency = 0 bit 1: every time before PLC scan, set the PLC target torque = 0 bit 2: every time before PLC scan, set the speed limit of torque mode = 0 Define whether the Frequency command or the Speed command must be cleared to zero or not before the PLC starts the next scan. PLC Program ID 09-34 Default: 0 Settings 0-65535 **PLC Address** 09-35 Default: 100 Settings 1-254 09 - 45**BACnet MAC ID** Default: 10 Settings 0-127 **BACnet MAC ID Macimum** Default: 127 Settings 0-127 09-47 **BACnet Device ID** Default: 55 Settings 0-127 09-48 **BACnet Password** Default: 0 Settings 0-65535 09-60 Communication card identification Default: Read only 0: No communication card Settings 1: DeviceNet Slave 2: Profibus-DP Slave

-22: ID2 (Pump Slave)

5: EtherNet/IP Slave

12: Profinet 13: Bluetooth 09-61 Firmware Version of Communication Card Default: Read only Settings 0-65535 **Product Code** 09-62 Default: Read only Settings 0–65535 09 - 63Fault code Default: Read only Settings 0-65535 09-70 Communication Card Address (for DeviceNet or Profibus) Default: 1 Settings DeviceNet: 0-63 Profibus-DP: 1-125 Communication card speed setting (for DeviceNet) 09-71 Default: 2 Standard DeviceNet: Settings 0: 125 Kbps 1: 250 Kbps 2: 500 Kbps 3: 1 Mbps (Delta Only) Non-standard DeviceNet: (Delta only) 0: 10 Kbps 1: 20 Kbps 2: 50 Kbps 3: 100 Kbps 4: 125 Kbps 5: 250 Kbps 6: 500 Kbps 7: 800 Kbps 8: 1 Mbps 09-72 Additional Settings for Communication Card Speed (for DeviceNet) Default: 0 Settings 0: Standard DeviceNet 1: Non-standard DeviceNet Use this parameter with Pr.09-71. 0: The baud rate can only be set to 125 Kbps, 250 Kbps and 500 Kbps as a standard DeviceNet speed. 1: The DeviceNet communication rate can be the same as that for CANopen (setting 0-8).

N	09-75	Commu	unication Card IP Configuration (for EtherN	et)	
			De	efault: 0	
		Settings	0: Static IP		
		•	1: Dynamic IP (DHCP)		
	0: Set t	he IP addre	ess manually.		
	🕮 1: IP ac	dress is dy	ynamically set by the host controller.		
,	00.70	0	orization Open ID Address 4 (for EthanNat)		
×	09-76		unication Card IP Address 1 (for EtherNet)		
N	09-77		unication Card IP Address 2 (for EtherNet)		
M	09-78		unication Card IP Address 3 (for EtherNet)		
M	09-79	Commu	unication Card IP Address 4 (for EtherNet)		
				efault: 0	
	~	Settings	0–255		
	Use Pr.	09-76–09-	79 with a communication card.		
N	09-80	Commu	inication Card Address Mask 1 (for EtherNo	et)	
N	09-81	Commu	inication Card Address Mask 2 (for EtherNo	et)	
N	09-82	Commu	inication Card Address Mask 3 (for EtherNo	et)	
N	09-83	Commu	inication Card Address Mask 4 (for EtherNo	et)	
			De	efault: 0	
		Settings	0–255		
×	09-84	Commu	inication Card Gateway Address 1 (for Ethe	erNet)	
×	09-85	09-85 Communication Card Gateway Address 2 (for EtherNet)			
×	09-86	Commu	inication Card Gateway Address 3 (for Ethe	erNet)	
×	09-87 Communication Card Gateway Address 4 (for EtherNet)				
			De	efault: 0	
		Settings	0–255		
M	09-88		inication Card Password (Low Word) (for E	<i>'</i>	
M	09-89	Commu	ınication Card Password (High Word) (for E	•	
		•		efault: 0	
,	00.00	Settings	0–99		
×	09-90	Reset C	Communication Card (for EtherNet)	.folt. O	
		Cattings		efault: 0	
		Settings	0: No function 1: Reset to defaults		
.	09-91	Addition	nal setting for the communication card (for	EtherNet)	
,	00 01	Addition	· · · · · · · · · · · · · · · · · · ·	efault: 0	
		Settings	bit 0: Enable IP filter	ndan. 0	
		- 5 190	bit 1: Enable internet parameters		
			bit 2: Enable login password		
	🕮 bit0: Se	et this bit as	s 1 to enable IP filter function; sets this bit as 0 to c	lisable IP filter function.	
			s 1, this function updates the parameter settings		
	The second of th				

disable it.

09-87) to communication card. After communication card finishes the update, sets this bit as 0 to

Chapter 12 Descriptions of Parameter Settings | MPD

bit2: Set this bit as 1, this function updates the login password (Pr.09-88–09-89) to communication card. After communication card finishes the update, sets this bit as 0 to be disable.

09-92 Communication card status (for EtherNet)

Default: Read only

Settings bit 0: Enable password

bit0: This bit is set as 1 to be enable if communication card sets a password (Pr.09-91, bit2 =1). After clearing the password of communication card, sets this bit as 0 to be disable.

10 Speed Feedback Control Parameters

✓ You can set this parameter during operation.

V 10-29 Upper Limit of Frequency Deviation

Default: 20.00

Settings 0.00-200.00 Hz

- Limit the maximum frequency deviation.
- If you set this parameter too high, an abnormal feedback malfunction will occurs.

MSI Motor Control Current Compensation Command

Default:40

Settings 0–150% rated current of the motor

Set the current command for the drive in low speed area.

When the motor stalls on heavy duty start-up or forward / reverse with load, increase the parameter value. If the inrush current is too high and causes oc stall, then decrease the parameter value.

10-32 Speed Estimator Bandwidth

Default:5.00

Settings 0.00-600.00 Hz

- Set the speed estimator bandwidth. Adjust the parameter to influence the stability and the accuracy of the motor speed.
- If there is low frequency vibration (the waveform is similar to a sine wave) during the process, then increase the bandwidth. If there is high frequency vibration (the waveform shows extreme vibration and is like a spur), then decrease the bandwidth.

X 10-34 Speed Estimator Low-pass Filter Gain

Default: 1.00

Settings 0.00-655.35

- Influences the response speed of the speed estimator.
- If there is low frequency vibration (the waveform is similar to a sine wave) during the process, then increase the gain.
- If there is high frequency vibration (the waveform shows extreme vibration and is like a spur), then decrease the gain.

MSI Motor Control Current Compensation Frequency Point

Default:15.00

Settings 0.00-599.00

If the compensation point is too high, the drive easily runs in the frequency area of current compensation for a long time, which generates a larger current and cannot save energy.

10-42 Initial Angle Detection Pulse Value

Default:1.0

Settings 0.0–3.0

 \square It's valid when Pr.10-53 = 3.

Activate the function by using pulse injection method. The parameter influences the value of the pulse during the angle detection. The larger the pulse, the higher the accuracy of rotor's position. A larger pulse might cause oc. Increase the parameter when the running direction and the command are opposite during startup. If oc occurs at start-up, then decrease the parameter. Zero Voltage Time During Start-up Default: 00.000 Settings 00.000–60.000 sec. This parameter is valid when the setting of Pr.07-12 (Speed Tracking during Start-up) = 0. When the motor is in static state at start-up, this increases the accuracy when estimating angles. In order to put the motor in static state, set the three-phase of the drive output to the motor to 0 V. The Pr.10-49 setting time is the length of time for three-phase output at 0 V. It is possible that even when you apply this parameter, the motor cannot go in to the static state because of inertia or some external force. If the motor does not go into a complete static state in 0.2 seconds, increase this setting value appropriately. 🚇 If Pr.10-49 is set too high, the start-up time is longer. If it is too low, then the braking performance is weak. **10-51** Injection Frequency Default:500 Settings 0–1200 Hz \square It's valid when Pr.10-53 = 2. I This parameter is a high frequency injection command in MSI control, and usually you do not need to adjust it. But if a motor's rated frequency (for example, 400 Hz) is too close to the frequency setting for this parameter (that is, the default of 500 Hz), it affects the accuracy of the angle detection. Refer to the setting for Pr.01-01 before you adjust this parameter. If the setting value for Pr.00-17 is lower than Pr.10-51 x 10, then increase the frequency of the carrier frequency. 10-52 Injection Magnitude Default:30.0 Settings 0.0–200.0 V \square It's valid when Pr.10-53 = 2. The parameter is the magnitude command for the high frequency injection signal when detecting MSI angle at start-up. \square Increasing the parameter can increase the accuracy of the angle estimation, but the electromagnetic noise might be louder if the setting value is too high. In the system uses this parameter when the motor's parameter is "Auto". This parameter influences the angle estimation accuracy. When the ratio of the salient pole (Lq / Ld) is lower, increase Pr.10-52 to make the angle detection accurate.

Chapter 12 Descriptions of Parameter Settings | MPD

10-53 Angle Detection Method

Default: 0

Settings 0: No function

1: Force attracting the rotor to zero degree

2: High frequency injection

3: Pulse injection

Use this parameter to adjust initial angle detection when the motor runs abnormally or has large current at startup.

[This page intentionally left blank]

11 Advanced Parameters

✓ You can set this parameter during operation.

11-00 System Control

Default: 0

Settings bit 3: Dead time compensation closed

bit 7: Save or do not save the frequency

- \square bit 3 = 0: Enable dead time compensation
- \square bit 3 = 1: Disable dead time compensation
- bit 7 = 0: Save the frequency before power is OFF. When power is ON again, the saved frequency is displayed.
- bit 7 = 1: Do not save the frequency before power is OFF. When power is ON again, 0.00 Hz is the displayed frequency.

11-41 PWM Mode Selection

Default: 0

Settings 0: Two-phase modulation mode

2: Space vector modulation mode

- Two-phase modulation mode: effectively reduces the drive power component losses and provides better performance in long wiring applications.
- Space vector modulation mode: effectively reduces the power loss and electromagnetic noise of the motor.

11-42 System control flag

Default: 0000

Settings 0000-FFFFh

bit No.	Functions	Descriptions
0	Reserved	
4	FWD / REV action	0: FWD / REV cannot be controlled by Pr.02-12 bit 0 & 1.
'	control	1: FWD / REV can be controlled by Pr.02-12 bit 0 & 1.
2–15	Reserved	

[This page intentionally left blank]

12 Function Parameters

✓ You can set this parameter during operation.

X 12-00 Set Point Deviation Level

Default: 0

Settings 0-50%

The base of the parameter is the set point of PID control setting (the set point displays on the keypad when Pr.00-03 = 4)

12-01 Detection Time of Set Point Deviation Level

Default: 10

Settings 1–9999 sec.

- If the deviation keeps within the range of Pr.12-00 and exceeds the time set in Pr.12-01, the AC motor drive decelerates to stop to be constant pressure status (this deceleration time is the setting for Pr.01-15). The system is in standby status when the deviation is within the range of PID set point (Pr.12-00) during deceleration. In the standby status, when the system pressure is lower than high / low water consumption conditions, the AC motor drive will start operating to pressurize the system.
- Refer to Pr.12-02–12-04 for the settings of high and low water consumption conditions.

12-02 Offset Level of Low Water Consumption

Default:10

Settings 0–50%

- The base of the parameter is the set point of PID control setting.
- When the system is in standby status, if the pressure exceeds the deviation of low water consumption setting, the AC motor drive starts pressurizing.

12-03 Offset Level of High Water Consumption

Default: 0

Settings 0: No function

0-100%

The base of the parameter is the set point of PID control setting.

12-04 High Water Consumption Delay Time

Default: 0.5

Settings 0: No function

0.1-10.0 sec.


When the system is in standby status, if the pressure change exceeds the deviation within the time set in Pr.12-03 and 12-04, the AC motor drive starts pressurizing.

Example:

If the set point of constant pressure control of a pump is 4 bar, Pr.12-00 is set to 5%, Pr.12-01 is set to 15 seconds, Pr.12-02 is set to 25%, Pr.12-03 is set to 3% and Pr.12-04 is set to 0.5 seconds, then the deviation is 0.2 bar (4 bar x 5% = 0.2 bar). It means when the feedback value is higher than 3.8 bar for a time exceeding 15 seconds, the AC motor drive decelerates to stop, this deceleration time acts according to Pr.01-15.


Status 1: Low water consumption restart detection

When the AC motor drive is in constant pressure status, it does not operate until the feedback change value is ≥ 1 bar than set point deviation (4 bar x 25% = 1 bar), which means the AC motor drive starts operating when the feedback value is less than 3 bar.



Status 2: High water consumption restart detection

When the AC motor drive is in constant pressure status, it does not operate until the feedback change value exceeds 0.12 bar within 0.5 seconds, which means the AC motor drive starts operating when the feedback value is less than 3.88 bar within 0.5 seconds.



12-06 Color of LCD

Default: 0

Settings 0: Blue: running, MP300 is outputting frequency

Green: standby, MP300 powers ON without any errors 1: Blue: standby, MP300 powers ON without any errors

Green: running, MP300 is outputting frequency

12-07 Disallowed from Outputting

Default: 0

Settings 0: No function

1: PWM output is OFF (display a warning called NOut)

When building the system, using this parameter will make the motor (PWM) turn off outputting, to avoid malfunctioning during the test; a warning called NOut is generated when starting the function.

12-08 Frequency to Start Switching Pumps

Default: Max. operation

frequency


Settings 0-the maximum operation frequency

12-09 Time Detected When Pump Reaches the Starting Frequency

Default: 1.0

Settings 0.0-3600.0 sec.

- This parameter is valid for master pump.
- Refer to Pr.01-00 for maximum operation frequency.
- Pump adding mechanism of multi-pump: When master pump operation frequency ≥ Pr.12-08 and the time exceeds the setting in Pr.12-09, activate the next pump; if the water is still insufficient, activate the third, fourth pump according to the same conditions.
- Pump reducing mechanism of multi-pump: The AC motor drive confirms the stable operation according to Pr.12-00 and Pr.12-01, and reduce pumps according to the deceleration time (Pr.01-15).



Pump's Frequency At Time-Out (Disconnection)

Default: 0.00 Settings 0.00–599.00 Hz This parameter is valid for salve pump. Refer to Pr.09-02 (COM1 transmission fault handling) and Pr.09-03 (COM1 time-out detection) for the communication failure conditions and fault handling. If a disconnection occurs in the multi-pump circumstances, the frequency command of slave pump is Pr.12-12; the slave pump is in standalone mode after STOP commend is given. Set the RUN command and operation frequency by the slave pump parameters. The master pump has the function to re-detect if a slave pump is time-out. 12-13 Pump's Error Handling Default: 1 Settings bit 0: When the operating pump is failed, whether it switches to an alternative pump or not. 0: Stop all pumps' action 1: Switch to an alternative pump bit 1: During the operation, stop or standby after resetting from error. 0: Standby after resetting 1: Stop after resetting bit 2: Before the operation, whether the system can run or not if the pump has an error. 0: The system cannot activate the operation 1: The system selects another pump to operate This parameter is valid for master pump. If enable built-in PLC function, the value of the parameter is fixed on 1 (default). This parameter only works under auto mode. If the pump switches to manual mode by setting MIx = 97 (multi-pump manual / auto switch) or press STOP button on the keypad to be not controlled by multi-pump, then the parameter setting does not affect the pump. When a pump is failed in the multi-pump system, the master pump deals with system behavior of during and before the operation and the operation of the failed pump according to this parameter setting. bit 0: When the operating pump is failed, whether it switches to an alternative pump or not. • bit 0 = 0: Stop all pumps bit 0 = 1: Stop the failed pump, and select another pump to operate according to the principle of activation. bit 1: During the operation, stop or standby after resetting from error. • bit 1 = 0, Standby: After resetting the failed pump, this pump can accept master pump's command to operate. bit 1 = 1, Stop: After resetting the failed pump, this pump cannot accept master pump's

bit 2: Before the operation, whether the system can run or not if the pump has an error.

command until restart the system.

- bit 2 = 0: Any pump of the system is failed, the master pump cannot accept RUN command.
- bit2 = 1: Any pump of the system is failed, the master pump can accept RUN command, and select another pump to operate according to the principle of activation.

12-14 Selection of pump start-up sequence

Default: 1

Settings 0: According to the serial numbers of the pumps

1: According to the operating time

- \square 0: According to the serial numbers of the pumps $(1 \rightarrow 2 \rightarrow 3 \rightarrow 4 \rightarrow 5 \rightarrow 6 \rightarrow 7 \rightarrow 8 \rightarrow 1)$.
- 1: According to the shortest operating time.

12-18 Cavitation Detection Method

Default: 0

Settings bit 0-3 00x0h: not using cavitation

00x1h: use Al1 to flow

00x2h: use flow estimation Q-H method

bit 4–7 000xh: no warning when cavitation

001xh: warning when cavitation, but continue operating

- Use this parameter to define the required flow whether is detected by flow meter or flow estimation Q-H method, refer to Pr.03-00 for more details.
- The AC motor drive displays Cavi warning when a cavitation is detected. To warn users that there is probably a cavitation occurred in the pipe, check and repair it early before it is malfunctioned.
- Refer to the table below, set the corresponding decimal value according to ON / OFF of cavitation and cavitation warning setting.


Example: If you want the required flow detected by flow estimation Q-H method, and receive a waring when a cavitation occurred but the pump continues operating, then set Pr.12-18 = 18

Settings	000xh: no warning when cavitation	001xh: warning when cavitation, but continue operating
00x0h: not using cavitation	Hex: 0000h	Hex: 0010h
OOXON. Not using cavitation	Decimal: 0	Decimal: 16
00x1h: use Al1 to flow	Hex: 0001h	Hex: 011h
OOX III. USE ATT to now	Decimal: 1	Decimal: 17
00x2h: use flow estimation Q-H	Hex: 0002h	Hex: 0012h
method	Decimal: 2	Decimal: 18

Read the information below by using Pr.00-04 and communication address:

Indication of cavitation status	User-defined (Pr.00-04)	Communication Address
 0: Disable cavitation module: possible reasons are incorrect analog module setting (refer to the setting procedure below), low rotation speed. 1: Start detecting cavitation 2: Discover cavitation (the keypad displays cavitation warning if you select warning at this moment) 	Pr.00-04 = 115	2273H

The setting procedure and related parameters of cavitation detection:



12-19 Cavitation Detection Tolerance

Default: 1.00

Settings 0.00–655.00

The larger the setting value is, the easier a cavitation warning occurs. This means that increase NPSHr value (Pr.12-45–12-49) can protect it in advance before a cavitation occurs.

12-20 Flow Estimation Method

Default: 1

Settings 0: Not using


1: Q-H method

2: P-Q method


- Use these two flow estimation methods mentioned below can assist users to estimate the system flow without a flow meter.
 - 1. Q-H method: Install two pressure sensors, one is at the inlet side and another one is at the outlet side, and set Pr.12-24–12-39.
 - 2. P-Q method: Set Pr.12-24-12-26, Pr.12-35-12-44.
- When using Q-H method, it's recommended that do not install any pressure reducing devices (e.g. non-return valve) between the pressure sensors and the pumps, because this will affect the estimation accuracy. If there is any pressure reducing devices between the pumps and the pressure sensors, the deviation could be over 5% but differs from pressure reducing devices. The deviation caused by the pressure reducing devices can be adjusted by head point related parameters.
- Read the information below by using Pr.00-04 and communication address:

	User-defined (Pr.00-04)	Communication Address
Estimated flow rate	Pr.00-04 = 112	2270H
Inlet pressure	Pr.00-04 = 113	2271H
Outlet pressure	Pr.00-04 = 114	2272H

The setting procedure and related parameters of flow estimation-Q-H method:



The setting procedure and related parameters of flow estimation-P-Q method:



12-21 Accumulated Flow-Units Digit

Default: Read only

Settings 0–999.9 m³ (read only)

12-22 Accumulated Flow-Thousands Digit

Default: Read only

Settings 0–65535 km³ (read only)

- To execute flow estimation, you have to enable the flow estimation function and follow the instruction in Pr.12-20, the estimated accumulated flow displays in Pr.12-21 and Pr.12-22.
- Refer to Pr.12-23 for details if the accumulated flow has to being reset.

	12-23	Reset a	ccumulated flow immediately	
				Default: 0
		Settings	0: Not reset	
			1: When powering the AC motor drive on, re	eset volume flow
			2: Reset volume flow	
	This pa	rameter m	emorizes the setting before powering off.	
	Refer to	Pr.12-21,	12-22 for the volume flow.	
	□ 0: not re	eset, this n	neans every time when activating the pump,	the volume flow (Pr.12-21, Pr.12-
	22) is a	ccumulate	d from the last time, and it stops accumulatin	g while reaching the limit.
,	40.04	D:	a of The Documental of	
×	12-24		er of The Pump Inlet	
×	12-25	Diamete	r of The Pump Outlet	
				Default: 0.0
	~ -· ·	Settings	5.0–6500.0 mm	
			at the pressure sensor.	
	If it does	s not instal	ll a pressure sensor, enter the pipe diameter	of the pump inlet / outlet.
N	12-26	The Rat	ed Rotation Speed of Pump	
				Default: 3000
		Settings	0–65535 rpm	
	12-27	Fluid De	ensity	
				Default: 995.7
		Settings	0.0–6550.0 kg/m³	
	The der		the operation temperature for the fluid in pip	ee.
			•	
×	12-28	Fluid Tei	mperature During Operation	D (14 00 00
		0		Default: 30.00
		Settings	00.00-600.00°C	
	42.20		Sifference of Inlat / Outlet Duran Bress	····· Canaar
×	12-29	Height L	Difference of Inlet / Outlet Pump Press	
		0 "	00.00.00.00	Default: 0.00
	── T b a b a:		-30.00–30.00 m	
	i ne nei	gnt ailterer -	nce is between the outlet and the inlet.	
N	12-30	Pump C	curve Head 1	
N	12-31	Pump C	curve Head 2	
N	12-32	Pump C	curve Head 3	
N	12-33	Pump C	curve Head 4	
N	12-34	Pump C	Curve Head 5	
				Default: 0.00
		Settings	0.00–655.00 m	
N	12-35	Pump C	curve Flow 1	
N	12-36	•	curve Flow 2	

×	12-37	Pump Curve Flow 3		
×	12-38	Pump Curve Flow 4		
*	12-39	Pump Curve Flow 5		
		Default: 0.00		
		Settings 0.00–655.00 m³/hr		
×	12-40	Pump Curve Point 1 Power		
×	12-41	Pump Curve Point 2 Power		
×	12-42	Pump Curve Point 3 Power		
×	12-43	Pump Curve Point 4 Power		
×	12-44	Pump Curve Point 5 Power		
		Default: 0.00		
		Settings 0.00–655.00 kW		
×	12-45	Pump Curve 1 Npshr		
×	12-46	Pump Curve 2 Npshr		
×	12-47	Pump Curve 3 Npshr		

Default: 0.00

Settings 0.00-655.00 m

12-48 Pump Curve 4 Npshr12-49 Pump Curve 5 Npshr

- Refer to the chosen pump characteristic curve, select five points and ensure it includes the suggested working range of pump. See the table below for more about the functions and the related pump characteristic curves.
- Note: Pr.12-34 > Pr.12-33 > Pr.12-32 > Pr.12-31 > Pr.12-30, and set these parameters that starts from Pr.12-34 to Pr.12-30.

Functions	Pump characteristic curve	Flow (Pr.12-35-12-39)
Flow estimation Q-H method	Head (H) Pr.12-30–12-34	H(m) 5 4 3 2
Flow estimation P-Q method	Power (P) Pr.12-40–12-44	P(kW) Pmax 4 3 2 5 4 3 2
Cavitation detection	NPSHr Pr.12-45–12-49	NPSHr (m) Recommended Pump Working Range Q(m³/hr)

Chapter 12 Descriptions of Parameter Settings | MPD 12-50 Cycle Time Selection Default: 2 Settings 0: No function 1: Absolute time 2: Fixed time 12-51 Multi-pump's Real Time Circulation Period Default: 00:00 Settings 00:00~23:59 12-52 Multi-pump's Fixed Time Circulation Period Default: 5.0 Settings 0.0–3000.0 hours This parameter is valid for master pump. Set cycle time in Pr.12-50, master pump and slave pump switches when the absolute time is equal to Pr.12-51 or the operation time of master pump is larger than Pr.12-52. If Pr.12-50 = 1, adjust RTC in Pr.12-93-12-96 before setting this parameter. Clean Function 12-53 Default: 0

Settings 0: Disabled

- 1: Enabled (trigger the clean function when DI works)
- 2: Enabled (trigger the clean function when current exceeds stall current and the operation is restricted)
- 3: Enabled (trigger the clean function when the counting time is up)
- If Pr.00-23 = 1 or 2 (only single direction is allowed), the clean function cannot work.
- The clean function makes the pump runs in forward and reverse direction. Some pumps run in single direction that the function does not support. Take notice of this, otherwise the pump breaks down.
- Three types of clean function:
 - Pr.12-53 = 1, 3: DI (set Mix = 100 synchronously) and scheduled trigger (set Pr.12-56, 12-57 synchronously) is for daily maintenance.
 - Pr.12-53 = 2: the clean function triggered by high stall current (set Pr.12-54, 12-55 synchronously) is for protection.
- ☐ The clean procedures are according to the setting of Pr.12-58–12-64.
- When Pr.12-53 = 3, adjust RTC in Pr.12-93–12-96 before setting this parameter.
- During the clean process, the AC motor drive displays CLE means the clean function is running. Return to the original control mode after finishing the clean. After finishing the clean process, which is triggered by stall current, if there is still stall current, the display shows a JAME fault and coasts to stop.

Stall Current Setting Value

Default: 120

Settings 0- the smallest one of Pr.06-03 and Pr.06-04

12-55 Stall Current Delay Time

Default: 60.0

Settings 0.0-300.0 sec.

Trigger the clean function when the output current is larger than Pr.12-54 and continues for the time set in Pr.12-55. The AC motor drive displays CLE means the clean function is running. After finishing the clean process, if there is still stall current, the display shows a JAME fault and coasts to stop.

12-56 Auto Clean Day

Default: 0

Settings 0: Sunday

1: Monday

2: Tuesday

3: Wednesday

4: Thursday

5: Friday

6: Saturday


12-57 Cleaning Time of a Day

Default: 00:00

Settings 00:00~23:59

Scheduled clean function is triggered by Pr.12-56 and Pr.12-57.

Example: Pr.12-56 = 2, Pr.12-57 = 12:00



12-58 Cleaning Cycle Times

Default: 5

Settings 1-30

12-59 Clean Forward Frequency

Default: 40.00

Settings 0.00-50.00 Hz

12-60 Clean Forward Time

Default: 2.0

Settings 0.0-300.0 sec.

12-61 Clean Reverse Frequency

Default: 40.00

Settings 0.00-50.00 Hz

12-62 Clean Reverse Time

Default: 2.0

Settings 0.0–300.0 sec.

12-63 Cleaning Acceleration Time

Default: 1.0


Settings 1.0–300.0 sec.

12-64 Cleaning Deceleration Time

Default: 1.0

Settings 1.0–300.0 sec.

- The clean procedures below are according to the setting of Pr.12-58–12-64.
- If the AC motor drive is running or in acceleration / deceleration state while triggering the clean function, the clean function starts after it returns to 0 Hz.




12-65 Load Auto-tuning Curve

Default: 0


Settings 0: Disabled

1: Enabled

- Set a state without water at the beginning, enable load auto-tuning curve (Pr.12-65 = 1) and press RUN button, and then the AC motor drive displays tUn to run to 50% and 100% of the rated frequency (Pr.01-01). Their output powers are recorded (see Pr.00-04 = 6 for output power) and enter into Pr.12-66, Pr.12-67.
- If there is a fault of the curve by auto-detection, the AC motor drive displays a dAUE warning to re-detect.
- The range below the load curve is the area that dry pump occurs.



	_		
12-66 50% Power Consumption Point			
			Default: 0
	Settings	0–65535 kW	
12-67	100% P	ower Consumption Point	
			Default: 0
	Settings	0–65535 kW	
		1 enables load auto-tuning curve, the auto-tu	uning is according to the settings
of Pr.12	2-66 and P	r.12-67.	
12-68	Dry Pun	np Function	
			Default: 0
	Settings	0: Disabled	
		1: Enabled	
To lear	n load auto	-tuning curve before enabling dry pump functi	on.
12-69	Dry Pun	np Check Time	
			Default: 15.0
	Settings	0-300.0 sec.	
When '	the load is	lower than the load curve and continues for	the time set in Pr.12-69, a dryn
warning	g occurs ar	nd handles this situation according to Pr.12-72)
12-70	Dry Pum	np Restart Delay Time	
			Default: 30
	Settings	0–1000 min.	
12-71	Number	of Restart Times Limitation of Dry Pun	np
			Default: 5
	Settings	0–20	
12-72	-		
	The Trea	atment of Dry Pump Fault	
	The Trea	atment of Dry Pump Fault	Default: 1
	Settings	atment of Dry Pump Fault 1: Fault and coast to stop	Default: 1
			Default: 1
☐ To che	Settings	1: Fault and coast to stop	
	Settings	1: Fault and coast to stop 2: Fault and ramp to stop	assing the time set in Pr.12-70. If
it's clea	Settings ck again if it ared, elimin	1: Fault and coast to stop 2: Fault and ramp to stop it's still in condition to trigger dry pump after p	assing the time set in Pr.12-70. If



12-88 Dry Pump Detection Tolerance

Default: 10

Settings 0-50%

- This parameter determines the response speed of detecting dry pump, the larger the setting value is, the harder a dryn warning occurs; the smaller the setting value is, the easier a dryn warning occurs.
- Easy to trigger dry pump warning if water consumption is too low. Adjust this parameter to prevent from misinformation of dry pump.

12-73 Heavy Water Leakage Abnormal Pressure Detection

Default: 15

Settings 0: No function

0-50%

- The base of the parameter is the set point of PID control setting.
- This parameter is to set the gap between the pressure level of water leakage and the set point of PID control setting.

12-74 Heavy Water Leakage Abnormal Detection Time

Default: 15.0

Settings 0.1-300.0 sec.

12-75 Heavy Water Leakage Load Setting

Default: 20

Settings 0–100%

12-76 Heavy Water Leakage Treatment


Default: 0

Settings 0: Warn and continue operation

1: Fault and coast to stop

2: Fault and ramp to stop

If the feedback pressure is not higher than Pr.12-73 after passing the time set in Pr.12-74, and the output load is higher than Pr.12-75, then trigger heavy water leakage event. At the moment, the pump handles this situation according to Pr.12-76, and the AC motor drive displays a LEKn warning or a LEKE fault.



12-77 Sleep Boost Pressure Setting

Default: 0 Settings 0–50%


- The base of the parameter is the set point of PID control setting.
- When it's going to be constant pressure mode, you can increase the pressure (Pr.12-77) to reach the set point pressure (%) for increasing sleep time.

12-78 Sleep Boost Pressure Delay Time

Default: 10.0

Settings 0.0-600.0 sec.

If the pump has still not reached the sleep boost pressure after passing the time set in Pr.12-78, then it returns to the normal control state.



12-79 Level Of High Pressure Alarm

Default: 25

Settings 0: No function

0-50%

The base of the parameter is the set point of PID control setting.

12-80 High Pressure Time Delay

Default: 5.0

Settings 0.1-300.0 sec.

12-81 High Pressure Alarm Treatment

Default: 1

Settings 1: Fault and coast to stop

2: Fault and ramp to stop

If the feedback pressure is higher than Pr.12-79 after passing the time set in Pr.12-80, then a HiPE fault occurs according to Pr.12-81.

1	2-82	Level of	Low Pressure Alarm	
				Default: 25
		Settings	0: No function	
			0–50%	
	The bas	se of the pa	arameter is the set point of PID control setting.	
1	2-83	Low Pre	ssure Time Delay	
				Default: 5.0
		Settings	0.1-300.0 sec.	
1	2-84	Low Pre	ssure Alarm Treatment	
				Default: 1
		Settings	0: Warn and continue operation	
			1: Fault and coast to stop	
			2: Fault and ramp to stop	
	If the fe	edback pr	essure is higher than Pr.12-82 after passing	the time set in Pr.12-83, then a
	LoPn w	aring or a l	LoPE fault occurs according to Pr.12-84.	
4	2.02	Voor Cot	tin a	
1	2-93	Year Set	ung	D (1/ 0000
		6		Default: 2022
, 4	0.04	_	2022–2099	
1	2-94	Date Set	tting	
				Default: 1.01
	0.05		1.01–12.31	
1	2-95	Time Se	tting	
				Default: 00:00
			00:00~23:59	
1	2-96	Week Se	etting	
				Default: 0
		Settings	0: Sunday	
			1: Monday	
			2: Tuesday	
			3: Wednesday	
			4: Thursday	
			5: Friday	
			6: Saturday	
	Install	a battery b	pefore using RTC function, refer to section	7-7 for more details about the
	installat	tion.		
	Set Pr.	12-93–12-9	6 first to ensure time accuracy for using RTC	related functions, such as Pr.12-
	50 =1 (cycle time	selection), Pr.12-53 = 3 (clean function), and	Pr.04-58 (weekdays, weekend,

specific day schedule).

[This page intentionally left blank]

13 Macro / User-defined Macro

13-00 Macro Selection

Default:00

Settings 00: Disabled

01: User-defined

Note: After you select the macro, some of the default values adjust automatically according to the application selection.

13-01 -13-50

Application Parameters (User-defined)

Refer to Chapter 10 for the setting methods of the user-defined parameters.

[This page intentionally left blank]

14 Protection Parameters (2)

✓ You can set this parameter during operation.

14-50 Output Frequency at Malfunction 2	
14-54 Output Frequency at Malfunction 3	
14-58 Output Frequency at Malfunction 4	
14-62 Output Frequency at Malfunction 5	
14-66 Output Frequency at Malfunction 6	

Default: Read only

Settings 0.00–599.00 Hz

When an error occurs, you can check the output frequency for the malfunction. If the error happens again, this parameter overwrites the previous record.

14-51	DC bus Voltage at Malfunction 2
14-55	DC bus Voltage at Malfunction 3
14-59	DC bus Voltage at Malfunction 4
14-63	DC bus Voltage at Malfunction 5
14-67	DC bus Voltage at Malfunction 6

Default: Read only

Display 0.0–6553.5 V

When an error occurs, you can check the DC bus voltage for the malfunction. If the error happens again, this parameter overwrites the previous record.

14-52 Output Current at Malfunction 2	
14-56 Output Current at Malfunction 3	
14-60 Output Current at Malfunction 4	
14-64 Output Current at Malfunction 5	
14-68 Output Current at Malfunction 6	

Default: Read only

Display 0.00–655.35 Amps

When an error occurs, you can check the output current for the malfunction. If the error happens again, this parameter overwrites the previous record.

14-53	IGBT Temperature at Malfunction 2
14-57	IGBT Temperature at Malfunction 3
14-61	IGBT Temperature at Malfunction 4
14-65	IGBT Temperature at Malfunction 5
14-69	IGBT Temperature at Malfunction 6

Default: Read only

Display -3276.8–3276.7 °C

When an error occurs, you can check the IGBT temperature for the malfunction. If the error happens again, this parameter overwrites the previous record.

14-70 Fault Record 7	
14-71 Fault Record 8	
14-72 Fault Record 9	
14-73 Fault Record 10	

Default: 0

Display

- 0: No fault record
- 1: Over-current during acceleration (ocA)
- 2: Over-current during deceleration (ocd)
- 3: Over-current during steady operation (ocn)
- 4: Ground fault (GFF)
- 6: Over-current at stop (ocS)
- 7: Over-voltage during acceleration (ovA)
- 8: Over-voltage during deceleration (ovd)
- 9: Over-voltage during constant speed (ovn)
- 10: Over-voltage at stop (ovS)
- 11: Low-voltage during acceleration (LvA)
- 12: Low-voltage during deceleration (Lvd)
- 13: Low-voltage at constant speed (Lvn)
- 14: Low-voltage at stop (LvS)
- 15: Phase loss protection (orP)
- 16: IGBT overheating (oH1)
- 17: Heatsink overheating (oH2)
- 18: IGBT temperature detection failure (tH1o)
- 19: Capacitor hardware error (tH2o)
- 21: Over load (oL)
- 22: Electronics thermal relay 1 protection (EoL1)
- 24: Motor overheating PTC-130 / KTY-84-130 / PT100

(oH3)

- 26: Over torque 1 (ot1)
- 28: Under current (uC)
- 31: EEPROM read error (cF2)
- 33: U-phase error (cd1)
- 34: V-phase error (cd2)
- 35: W-phase error (cd3)
- 36: cc hardware error (Hd0)
- 37: oc hardware error (Hd1)
- 40: Auto-tuning error (AUE)
- 41: PID loss ACI (AFE)
- 48: ACI loss (ACE)
- 49: External fault (EF)

- 51: External base block (bb)
- 52: Password is locked (Pcod)
- 54: Illegal command (CE1)
- 55: Illegal data address (CE2)
- 56: Illegal data value (CE3)
- 57: Data is written to read-only address (CE4)
- 58: Modbus transmission time-out (CE10)
- 74: Fire mode output (Fire)
- 79: U-phase over-current before run (Aoc)
- 80: V-phase over-current before run (boc)
- 81: W-phase over-current before run (coc)
- 82: U-phase output phase loss (oPL1)
- 83: V-phase output phase loss (oPL2)
- 84: W-phase output phase loss (oPL3)
- 87: Low frequency overload protection (oL3)
- 89: Rotor position detection error (roPd)
- 90: Force to stop (FStp)
- 140: oc hardware error (Hd6)
- 141: GFF occurs before run (b4GFF)
- 142: Auto-tune error 1 (AuE1) (DC test stage)
- 143: Auto-tune error 2 (AuE2) (high frequency stall stage)
- 144: Auto-tune error 3 (AuE3) (rotation test stage)
- 221: High water pressure (HPS)
- 222: Low water pressure (LPSE)
- 223: Dry pump (dryE)
- 224: Water leaking (pipe explosion) (LEKE)
- 225: Clogged pipe (JAME)
- 226: RTC error (rtF)
- 227: Dry pump curve auto-measuring (dAUE)
- The system records the fault codes to Pr.06-17-06-22, Pr.14-70-14-73 as long as the fault is forced to stop.
- When low-voltage at stop fault (LvS) occurs, the fault is not recorded. When low-voltage during operation faults (LvA, Lvd, Lvn) occur, the faults are recorded.


[This page intentionally left blank]

12-2 Adjustment & Application

12-2-1 Water pump system related parameters:

For different water pump systems (single pump, multi-pump, multi-master), users can follow the procedures below to set up the related parameters. Refer to section 12-1 for more details about parameter settings.

- Single pump, multi-pump: sets by parameters in the drive.
- Multi-master: sets by the built-in PLC function that goes with the parameters in the drive.



Note: All the AC motor drives should enable PLC1 for using multi-master function.

Single-pump parameters

- ☑ The default pressure sensor sets as 4–20 mA, the unit is bar.
- ☑ The mark " * " represents the parameters must be set and confirmed.

The station address of master pump

Pr.	Parameter Name	Default
09-00*	Communication Address	1
09-31*	COM1 Internal Communication Protocol	0

Single-pump / multi-pump: Pr.09-31 = -21

Multi-master: Pr.09-31 = -12 (PLC auto-setting), Pr.09-00 = 1

Al terminal setting

Pr.	Parameter Name	Default
03-00	Al1 Analog Input Selection	5
03-28*	Al1 Terminal Input Selection	2
08-00*	Terminal Selection of PID Feedback	0

Precision of sensor

Pr.	Parameter Name	Default
00-25*	User-Defined Characteristics	353
00-26*	Maximum User-Defined Value	0

Set point level

Pr.	Parameter Name	Default
12-00*	Set Point Deviation Level	0
12-01	Detection Time of Set Point Deviation Level	10

Wake-up function (low / high water consumption)

Pr.	Parameter Name	Default
12-02	Offset Level of Low Water Consumption	10
12-03	Offset Level of High water Consumption	0
12-04	High Water Consumption Delay Time	0.5

Master of multi-pump / backup master parameters

- ☑ The default pressure sensor sets as 4–20 mA, the unit is bar.
- \square Before using pressure sensor, sets Pr.08-00 = 1, and sets the maximum value of pressure sensor in Pr.00-26.
- ☑ The mark " * " represents the parameters must be set and confirmed.
- After enabling the water pump function, the default enables auto-change function (starts up from the pump has the shortest operation time, and alternates every 5 hours), pump-adding function.

The station address of master pump

Pr.	Parameter Name	Default
09-00*	Communication Address	1
09-31*	COM1 Internal Communication Protocol	0

Single-pump / multi-pump: Pr.09-31 = -21

Multi-master: Pr.09-31 = -12 (PLC auto-setting), Pr.09-00 = 1

Al terminal setting

Pr.	Parameter Name	Default
03-00	Al1 Analog Input Selection	5
03-28*	Al1 Terminal Input Selection	2
08-00*	Terminal Selection of PID Feedback	0

Precision of sensor

Pr.	Parameter Name	Default
00-25*	User-Defined Characteristics	353
00-26*	Maximum User-Defined Value	0

Set point level

Pr.	Parameter Name	Default
12-00*	Set Point Deviation Level	0
12-01	Detection Time of Set Point Deviation Level	10

Wake-up function (low / high water consumption)

Pr.	Parameter Name	Default
12-02	Offset Level of Low Water Consumption	10
12-03	Offset Level of High water Consumption	0
12-04	High Water Consumption Delay Time	0.5

Auto-change pump setting

Pr.	Parameter Name	Default
12-14	Selection of pump start-up sequence	1
12-50	Cycle Time Selection	2
12-51	Multi-pump's Real Time Circulation Period	00:00
12-52	Multi-pump's Fixed Time Circulation Period	5.0

Adding pump setting

•	· ·	
Pr.	Parameter Name	Default
12-14	Selection of pump start-up sequence	1
12-08	Frequency to Start Switching Pumps	FMAX
12-09	Time Detected When Pump Reaches The Starting Frequency	1.0

Pump reducing mechanism executes according to Pr.12-00, Pr.12-01.

Chapter 12 Descriptions of Parameter Settings | MPD

Multi-pump COM1 time-out detection

Pr.	Parameter Name	Default
09-02	COM1 Transmission Fault Treatment	3
09-03	COM1 Time-out Detection	0.0

Treatment of pump disconnection

Pr.	Parameter Name	Default
12-13	Pump's Error Handling	1

Multi-master: Pr.12-13 fixes to 1.

Pump System Configuration Setting

Pr.	Parameter Name	Default
04-57	Pump System Configuration Setting	0

This parameter is to set the multi-pump configuration of the built-in PLC function. Refer to user manual for more details.

Backup master: Pr.04-57 bit8 = 1

Slave of multi-pump parameters

Enable constant pressure function

Pr.	Parameter Name	Default
12-00*	Set Point Deviation Level	0
12-01	Detection Time of Set Point Deviation Level	10

Same setting as the master pump.

Station address of slave pump

Pr.	Parameter Name	Default
09-00*	Communication Address	1
09-31*	COM1 Internal Communication Protocol	0

Multi-pump: Pr.09-31 = -22 - -28

Multi-master: Pr.09-31 = 0 (PLC auto-setting), Pr.09-00 should set station address to be 2–8

Precision of pressure sensor

Pr.	Parameter Name	Default
00-25*	User-Defined Characteristics	353
00-26*	Maximum User-Defined Value	0

Operation frequency of disconnected pump

Pr.	Parameter Name	Default
12-12	Pump's Frequency at Time-Out (Disconnection)	0.00

Water pump function parameters

☑ The default enables heavy water leakage related function.

Dry pump

Pr.	Parameter Name	Default
12-65	Load Auto-tuning Curve	0
12-66	50% Power Consumption	0
12-67	85% Power Consumption	0
12-68	Dry Pump Function	0
12-69	Dry Pump Check Time	15.0
12-70	Dry Pump Restart Delay Time	30

Pr.	Parameter Name	Default
12-71	Number of Restart Times Limitation of Dry Pump	5
12-72	The Treatment of Dry Pump Fault	1

Flying start

Pr.	Parameter Name	Default
07-06	Restart After Momentary Power Loss	0
07-07	Allowed Power Loss Duration	2.0
07-08	Base Block Time	0.5
07-09	Current Limit of Speed Tracking	100
07-10	Restart after Fault	0
07-11	Number of Times of Restart After Fault	0
07-12	Speed Tracking During Start-up	0
06-88	Operation Times in Fire Mode	Read only

Level Of High Pressure Alarm

Pr.	Parameter Name	Default
12-79	Level Of High Pressure Alarm	25
12-80	High Pressure Time Delay	5.0
12-81	Level Of High Pressure Alarm	1

When Pr.12-79 = 0, disables high water pressure alarm.

Level of Low Pressure Alarm

Pr.	Parameter Name	Default
12-82	Level Of Low Pressure Alarm (%)	25
12-83	Low Pressure Time Delay	5.0
12-84	Level of Low Pressure Alarm	0

When Pr.12-82 = 0, disables low water pressure alarm.

Clean Function

Pr.	Parameter Name	Default
12-53	Clean Function	0
12-54	Stall Current Setting Value	120
12-55	Stall Current Delay Time	60.0
12-56	Auto Clean Day	0
12-57	Cleaning Time of A Day	00:00
12-58	Cleaning Cycle Times	5
12-59	Clean Forward Frequency	40.00
12-60	Clean Forward Time	2.0
12-61	Clean Reverse Frequency	40.00
12-62	Clean Reverse Time	2.0
12-63	Cleaning Acceleration Time	1.0
12-64	Cleaning Deceleration Time	1.0
02-01-02-04	Multi-function Input Command (MI1–MI4)	0

Pr.02-01-02-04: sets 100 to enable clean function by external trigger

Refer to Pr.12-53 for more details.

Fire Mode

Pr.	Parameter Name	Default
06-80	Fire Mode	0
06-81	Operating Frequency in Fire Mode (Hz)	150.00

If you need to use the timer clean trigger, sets the RTC (Pr.12-93–12-96) and install battery (section 7-7).

Anti-frost function

Pr.	Parameter Name	Default
02-72	Preheating DC current level	0
02-73	Preheating DC Current Duty Cycle	0
02-01-02-04	Multi-function Input Command (MI1–MI4)	0
02-13–2-14,	Multi-function Output	0
02-16	ividiti-furiction Output	0

Pr.02-01-02-04: set as 69 to enable preheating function.

Pr.02-13, 02-14, 02-16: set 69 to enable the indication of multi-pump system error.

Sleep boost pressure function

Pr.	Parameter Name	Default
12-77	Sleep Boost Pressure Setting	0
12-78	Sleep Boost Pressure Delay Time	10.0

Heavy Water Leakage

Pr.	Parameter Name	Default
12-73	Heavy Water Leakage Abnormal Pressure Detection	15
12-74	Heavy Water Leakage Abnormal Detection Time	15.0
12-75	Heavy Water Leakage Load Setting	20.0
12-76	Heavy Water Leakage Treatment	0

When Pr.12-73 = 0, disables heavy water leakage alarm.

• Scheduled function (enables the built-in PLC function before using this function)

Pr.	Parameter Name	Default
04-58	Weekdays, Weekend, Specific Day Schedule	0
04-59	Weekend Setting	0
04-60	Duty Day Start Time 1	0
04-61	Duty Day Set Point Pressure 1	00:00
04-62	Duty Day Start Time 2	0
04-63	Duty Day Set Point Pressure 2	00:00
04-64	Duty Day Start Time 3	0
04-65	Duty Day Set Point Pressure 3	00:00
04-66	Duty Day Start Time 4	0
04-67	Duty Day Set Point Pressure 4	00:00
04-68	Duty Day Start Time 5	0
04-69	Duty Day Set Point Pressure 5	00:00
04-70	Weekend Start Time 1	0
04-71	Weekend Set Point Pressure 1	00:00
04-72	Weekend Start Time 2	0
04-73	Weekend Set Point Pressure 2	00:00
04-74	Weekend Start Time 3	0
04-75	Weekend Set Point Pressure 3	00:00
04-76	Weekend Start Time 4	0
04-77	Weekend Set Point Pressure 4	00:00
04-78	Weekend Start Time 5	0
04-79	Weekend Set Point Pressure 5	00:00
04-80	Specific Date Start Date 1	00.00
04-81	Specific Day End Date 1	00.00
04-82	Specific Date Start Date 2	00.00
04-83	Specific Day End Date 2	00.00
04-84	Specific Date Start Date 3	00.00
04-85	Specific Day End Date 3	00.00
04-86	Specific Date Start Date 4	00.00
04-87	Specific Day End Date 4	00.00
04-88	Specific Date Start Date 5	00.00

Pr.	Parameter Name	Default
04-89	Specific Day End Date 5	00.00
04-90	Specific Date Start Time 1	00:00
04-91	Specific Date Set Point Pressure 1	0
04-92	Specific Date Start Time 2	00:00
04-93	Specific Date Set Point Pressure 2	0
04-94	Specific Date Start Time 3	00:00
04-95	Specific Date Set Point Pressure 3	0
04-96	Specific Date Start Time 4	00:00
04-97	Specific Date Set Point Pressure 4	0
04-98	Specific Date Start Time 5	00:00
04-99	Specific Date Set Point Pressure 5	0

Before using scheduled function, sets the RTC (Pr.12-93–12-96) and install battery (section 7-7).

Flow estimation P-Q method

Pr.	Parameter Name	Default
12-20	Flow Estimation Method	1
12-21	Accumulated Flow-Units Digit (m³)	Read only
12-22	Accumulated Flow-Thousands Digit (km³)	Read only
12-23	Reset accumulated flow immediately	0
12-24	Diameter of the Pump Inlet (mm)	0.0
12-25	Diameter of the Pump Outlet (mm)	0.0
12-26	The Rated Rotation Speed of Pump	3000
12-35	Pump Curve Flow 1	0
12-36	Pump Curve Flow 2	0
12-37	Pump Curve Flow 3	0
12-38	Pump Curve Flow 4	0
12-39	Pump Curve Flow 5	0
12-40	Pump Curve Point 1 Power	0
12-41	Pump Curve Point 2 Power	0
12-42	Pump Curve Point 3 Power	0
12-43	Pump Curve Point 4 Power	0
12-44	Pump Curve Point 5 Power	0

Refer to Pr.12-20 for more details.

Flow estimation Q-H method

Pr.	Parameter Name	Default
12-20	Flow Estimation Method	1
12-21	Accumulated Flow-Units Digit (m³)	Read only
12-22	Accumulated Flow-Thousands Digit (km³)	Read only
12-23	Reset accumulated flow immediately	0
12-24	Diameter of the Pump Inlet (mm)	0.0
12-25	Diameter of the Pump Outlet (mm)	0.0
12-26	The Rated Rotation Speed of Pump	3000
12-27	Fluid Density	995.7
12-28	Fluid Temperature During Operation (°C)	30.00
12-29	Height Difference of Inlet / Outlet Pump Pressure Sensor	0
12-30	Pump Curve Head 1	0
12-31	Pump Curve Head 2	0
12-32	Pump Curve Head 3	0
12-33	Pump Curve Head 4	0
12-34	Pump Curve Head 5	0
12-35	Pump Curve Flow 1	0

Refer to Pr.04-58 for more details.

Chapter 12 Descriptions of Parameter Settings | MPD

Pr.	Parameter Name	Default
12-36	Pump Curve Flow 2	0
12-37	Pump Curve Flow 3	0
12-38	Pump Curve Flow 4	0
12-39	Pump Curve Flow 5	0

Before using this method, user has to set outlet / inlet pressure sensor related parameters.

Cavitation detection


Pr.	Parameter Name	Default
12-18	Cavitation Detection Method	0
12-19	Cavitation Detection Tolerance	0
12-24	Diameter of The Pump Inlet	0.0
12-25	Diameter of The Pump Outlet	0.0
12-26	The Rated Rotation Speed of Pump	3000
12-27	Fluid Density	995.7
12-28	Fluid Temperature During Operation (°C)	30.00
12-35	Pump Curve Flow 1	0
12-36	Pump Curve Flow 2	0
12-37	Pump Curve Flow 3	0
12-38	Pump Curve Flow 4	0
12-39	Pump Curve Flow 5	0
12-45	Pump Curve Npshr 1	0
12-46	Pump Curve Npshr 2	0
12-47	Pump Curve Npshr 3	0
12-48	Pump Curve Npshr 4	0
12-49	Pump Curve Npshr 5	0

Refer to Pr.12-20 for more details.


Refer to Pr.12-20 for more details.

12-2-2 Induction Motor VF Control Adjustment Procedure (IMVF Sensorless, Pr.00-11 = 0)

Control diagram



Adjustment procedure



- Basic motor parameter adjustment
- 1. Parameter reset

Pr.00-02 = 9, reset to be the default of IM.

2. Select IM motor type

Pr.05-33 = 0 (IM)

3. Motor nameplate parameter setting

Parameter	Description	
Pr.01-01	Motor 1 Rated / Base Frequency	
Pr.01-02	Motor 1 Rated / Base Voltage	
Pr.05-01	Full-Load Current for Induction Motor 1 (A)	
Pr.05-02	Rated Power for Induction Motor 1 (kW)	
Pr.05-03	Rated Speed for Induction Motor 1 (rpm)	
Pr.05-04	Number of Poles for Induction Motor 1 (poles)	

- 4. If the motor is shaking or not smooth after start-up, then adjust the setting of torque compensation related parameters.
 - Pr.07-24, torque command filter time (when the time constant setting is too small, the response is faster but the control may be unstable.
 - Pr.07-26, torque compensation gain (set this parameter higher when the no-load current is too large. But the motor may vibrate if the setting is too high. If the motor shakes when operating, reduce the setting.)
- IMVF Sensorless related parameters

Refer to Section 12-1 Description of Parameter Settings for more details.


Parameter	Description	Unit	Default	Setting Range
00-11	Speed Control Mode	N/A	0	0, 2
01-01	Motor 1 Rated / Base Frequency	Hz	60.00 / 50.00	0.00-599.00
01-02	Motor 1 Rated / Base Voltage	V	Depend on the model power	Depend on the model power

Chapter 12 Descriptions of Parameter Settings | MPD

Parameter	Description	Unit	Default	Setting Range	
05-02	Rated Power for Induction Motor 1	kW	Depend on the model power	0.00–655.35	
05-03	D5-03 Rated Speed for Induction Motor 1		Depend on the motor's number of poles	0–xxxx (Depend on the motor's number of poles)	
05-04	Number of Poles for Induction Motor 1	N/A	4	2–64	
07-24	Torque Command Filter Time	sec.	0.5	0.001–10.000	
07-26	-26 Torque Compensation Gain		0	0–10	
07-25	Slip Compensation Filter Time	sec.	0.1	0.001–10.000	
07-27	Slip Compensation Gain	N/A	000	0.00-10.00	

12-2-3 Permanent-Magnet Synchronous Motor, Space Vector Control Adjustment Procedure (PM SVC, Pr.00-11 = 2)


Control diagram



PM SVC adjustment procedure

(NOTE: The number marked on the procedure corresponds to the number of following adjustment explanations)

(1) PM SVC motor parameters adjustment flowchart



Basic motor parameter adjustment

1. Parameter reset

Pr.00-02 = 10 or 12, reset the parameter to the default.

2. Select PM motor type:

Pr.05-33 = 1 (SPM) or 2 (IPM)

3. Motor nameplate parameter setting

Parameter	Description	
Pr.01-01	Motor 1 Rated / Base Frequency	
Pr.01-02	Motor 1 Rated / Base Voltage	
Pr.05-34	Motor Full-load Current (A)	
Pr.05-35	Motor Rated Power (kW)	
Pr.05-36	Motor Rated Speed (rpm)	
Pr.05-37	Number of Poles in the Motor (poles)	

4. PM parameter auto-tuning:

Set Pr.05-00 = 5 (rolling auto-tuning for PM, with no load) or 13 (static auto-tuning for PM) and press RUN key to finish motor auto-tuning, then you will get the following parameters:

Parameter	Description		
Pr.05-39	Stator Resistance For A Motor (Ω)		
Pr.05-40	Motor Ld (mH)		
Pr.05-41	Motor Lq (mH)		
Pr.05-43	Ke parameter of a permanent magnet motor (V _{phase · rms} / krpm) (When Pr.05-00 = 5, the Ke parameter is measured based on the actual motor rotation.) (When Pr.05-00 = 13, the Ke parameter is automatically calculated based on the motor power, current and rotor speed.)		

If an auto-tuning error (AUE) occurs, refer to Chapter 14 "Fault Codes and Descriptions" for further treatment.

AUE Error (code)	Description		
AUE (40)	Motor auto-tuning error		
AUE 1 (142)	Auto-tuning error 1 (No feedback current error)		
AUE 2 (143)	Auto-tuning error 2 (Motor phase loss error)		

5. Set control mode


Control mode for the motor: Pr. 00-11 = 2: PM SVC mode

- 6. Power ON again after power OFF.
- 7. Measure the initial magnetic pole angle of PM.

Set Pr.10-53 PM initial rotor position detection method:

- 0: Disabled
- 1: Force attracting the rotor to zero degrees
- 2: High frequency injection (for IPM)
- 3: Pulse injection (for SPM / IPM)
- * For IPM, the setting value is suggested to be 2; for SPM, the setting value is suggested to be 3. You can choose the setting 1 if the result is not good of setting as 2 or 3.

(2) PM SVC adjustment flowchart for operation with no load / light load



- Adjustment for operation with light load
 - 8. Start the motor without load / with light load and operate to 1/2 of the rated rotor speed A1. Start operation direction:

a. If the start operation direction is wrong

When Pr.10-53 = 3, increase the current proportion for Pr.10-42 (initial angle detection pulse value) to improve the accuracy of the angle detection.


When Pr.10-53 = 2, increase the voltage for Pr.10-52 (injection magnitude) to improve the accuracy of the angle detection.

- b. If an ocA error occurs when pressing RUN to start the motor, decrease the current proportion for Pr.10-42 (initial angle detection pulse value).
- A2. Operates the motor in 1/2 of the rated rotor speed, adjust the no-load operating current

If the no-load operating current exceeds 20% of the rated current, increase Pr.07-26 (torque compensation gain) and observe the no-load operating current.

- A3. Accelerate to the rated frequency and observe if the motor operates stably.
- a. If the motor output rotor speed presents periodic low-frequency wave, increase Pr.10-34 (PM sensorless speed estimator low-pass filter gain), or increase Pr.10-32 (PM FOC sensorless speed estimator bandwidth).
- b. If the output frequency reflects high frequency vibration, decrease Pr.10-34 or decrease Pr.10-32.
- A4. Accelerate the motor to the maximum rotor speed, and observe if it operates stably. If the motor stalls when accelerating to the maximum rotor speed, then increase Pr.10-34 (PM sensorless speed estimator low-pass filter gain), or increase Pr.00-17 (carrier frequency, you must set the carrier frequency larger than 10 times of the maximum output frequency)

(3) PM SVC adjustment flowchart for operation starts with load



Adjustment for operation with load

- 9. Load operating test
 - B1. Low-frequency loading performance is below 1/10 of rated frequency:
 - a. If the low-frequency loading performance is insufficient, or the rotor speed is not smooth, increase Pr.10-31 (current command of I/F mode).
 - b. If the low-frequency current is large, decrease Pr.10-31 (current command of I/F mode).
 - B2. Test the with-load accelerating performance:

When the motor operates in 1/10 of rotor speed and above, if the speed cannot follow the acceleration time during accelerating, or the current stalls, increase Pr.07-38 (PMSVC voltage feedback forward gain).

- 10. Stability test at constant speed operation: the motor operates stably at constant speed
 - a. If the motor output rotor speed presents periodic low-frequency wave, increase Pr.10-34 (PM sensorless speed estimator low-pass filter gain), or increase Pr.10-32 (PM FOC sensorless speed estimator bandwidth).
 - b. If the output frequency reflects high frequency vibration, decrease Pr.10-34 or decrease Pr.10-32.

PM SVC related parameters

Refer to Section 12-1 Description of Parameter Settings for more details.

Parameter	Description	Unit	Default	Settings
Pr.07-24	Torque Command Filter Time	sec.	0.050	0.001-10.000
Pr.07-26	Torque Compensation Gain	N/A	0	0–5000
Pr.10-31	MSI motor control current compensation command	%	40	0–150
Pr.10-32	Speed Estimator Bandwidth	Hz	5.00	0.00-600.00
Pr.10-34	Speed Estimator Low-pass Filter Gain	N/A	1.00	0.00-655.35
Pr.10-39	MSI Motor Control Current Compensation Frequency Point	Hz	20.00	0.00-599.00
	Initial Angle Estimating Para	meters		
Pr.10-42	Initial Angle Detection Pulse Value	N/A	1.0	0.0–3.0
Pr.10-51	Injection Frequency (when Pr.10-53 = 2)	Hz	500	0–1200
Pr.10-52	Injection Magnitude (when Pr.10-53 = 2)	V	30.0	0.0–200.0
Pr.10-53	Angle Detection Method 0: Disabled 1: Force attracting the rotor to zero degrees 2: High frequency injection 3: Pulse injection	N/A	0	0–3

Chapter 13 Warning Codes

Summary of Warning Codes

ID No.	Warning Name	ID No.	Warning Name
0	0: No record	71	ExCom power loss (ECLv)
1	Communication error 1 (CE1)	72	ExCom test mode (ECtt)
2	Communication error 2 (CE2)	73	ExCom BUS off (ECbF)
3	Communication error 3 (CE3)	74	ExCom no power (ECnP)
4	Communication error 4 (CE4)	75	ExCom factory defect (ECFF)
5	Communication error 10 (CE10)	76	ExCom inner error (ECiF)
9	IGBT overheating warning (oH1)	78	ExCom Parameter data error (ECPP)
11	PID feedback error (PID)	79	ExCom configuration data error (ECPi)
12	ACI analog signal loss (AnL)	80	Ethernet link fail (ECEF)
13	Under current (uC)	81	Communication time-out (ECto)
20	Over-torque 1 (ot1)	82	Checksum error (ECCS)
22	Motor overheating (oH3)	83	Return defect (ECrF)
22	PTC-130 / KTY-84-130 / PT100	84	Modbus TCP over (Eco0)
24	Over slip warning (oSL)	85	Modbus TCP over (ECo1)
25	Auto tuning (tUn)	86	IP fail (ECiP)
28	Output phase loss (OPHL)	87	Mail fail (EC3F)
33	No output (NOut)	88	ExCom busy (ECbY)
50	PLC opposite defect (PLod)	89	ExCom card break (ECCb)
51	PLC save memory error (PLSv)	91	Copy PLC: Read mode error (CPL0)
52	Data defect (PLdA)	92	Copy PLC: Write mode (CPL1)
53	Function defect (PLFn)	98	Fire mode output (Fire)
54	PLC buffer overflow (PLor)	101	InrCOM time-out (ictn)
55	Function defect (PLFF)	134	Battery low voltage (LBAt)
56	Checksum error (PLSn)	135	Perpetual calendar adjustment (rCAL)
57	No end command (PLEd)	222	Low water pressure (LPSn)
58	PLC MCR error (PLCr)	223	Dry pump (dryn)
59	PLC download fail (PLdF)	224	Heavy water leakage (LEKn)
60	PLC scan time fail (PLSF)	225	Cavitation (CAvi)
70	ExCom ID fail (ECid)		

ID No.	Display on LED Keypad	Warning Name	Description		
1	I.E.	Communication error 1 (CE1)	RS-485 Modbus illegal function code		
		Action and Reset			
	Action condition	When the function code	is not 03, 06, 10 and 63.		
	Action time	Immediately act			
War	ning setting parameter	N/A			
Reset method		"Warning" occurs when Pr.09-02 = 0 and the motor drive keeps running. The drive resets automatically when receiving the correct function code.			
	Reset condition	Immediately reset			
	Record	N/A			
	Cause		Corrective Actions		
Incorrect communication command from upper unit		Check if the communication command is correct.			
Malfunction caused by interference		Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degrees for effective anti-interference performance.			
Differen	t communication setting	Check if the setting for Pr.09-01, Pr.09-04 are the same as the setting for the			
from the upper unit		upper unit.			
Disconnection or bad connection of the cable		Check the cable and replace it if necessary.			

ID No.	Display on LED Keypad	Warning Name	Description			
2		Communication error 2 (CE2)	RS-485 Modbus illegal data address (00H–254H)			
		Action and Reset				
	Action condition	When the input data ad	dress is incorrect.			
	Action time	Immediately act				
War	ning setting parameter	No function				
Reset method		"Warning" occurs when Pr.09-02 = 0 and the motor drive keeps running. The drive resets automatically when receiving the correct data address.				
	Reset condition	Immediately reset				
	Record	N/A				
	Cause	Corrective Actions				
Incorrect communication command from upper unit		Check if the communication command is correct.				
Malfunc interfere	tion caused by ence	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degrees for effective anti-interference performance.				
Different	t communication setting	Check if the setting for Pr.09-01, Pr.09-04 are the same as the setting for the				
from the upper unit		upper unit.				
Disconn of the ca	ection or bad connection able	Check the cable and replace it if necessary.				

ID No.	Display on LED Keypad	Warning Name	Description			
3		Communication error 3 (CE3)	RS-485 Modbus illegal data value			
		Action and I	Reset			
	Action condition	When the length of comm	nunication data is too long.			
	Action time	Immediately act				
War	ning setting parameter	No function				
		"Warning" occurs when P	r.09-02=0 and the motor drive keeps running.			
	Reset method	The drive resets automatically when receiving the correct communication data				
		value.				
	Reset condition	Immediately reset				
	Record	N/A				
	Cause		Corrective Actions			
Incorrect communication command from upper unit		Check if the communication command is correct.				
Malfunctinterfere	tion caused by ence	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degrees for effective anti-interference performance.				
	t communication setting upper unit	on setting Check if the setting for Pr.09-01, Pr.09-04 are the same as the setting for tupper unit.				
	ection or bad connection	Check the cable and replace it if necessary.				

ID No.	Display on LED Keypad	Warning Name	Description			
4		Communication error 4 (CE4)	RS-485 Modbus data is written to read-only address			
		Action and F	Reset			
	Action condition	When the data is written to read-only address.				
	Action time	Immediately act				
War	ning setting parameter	No function				
		"Warning" occurs when P	r.09-02=0 and the motor drive keeps running.			
	Reset method	The drive resets automatically when receiving the correct written address of				
		communication data.				
	Reset condition	Immediately reset				
	Record	N/A				
	Cause	Corrective Actions				
Incorrect communication command from upper unit		Check if the communication command is correct.				
Malfuna	tion caused by	Verify the wiring and grou	inding of the communication circuit. It is			
interfere	•	recommended to separate the communication circuit from the main circuit, or				
Interierence		wire in 90 degrees for effective anti-interference performance.				
Different communication setting Check if the setting for Pr.09-01, Pr.09-04 are the same as the setting						
from the upper unit		upper unit.				
Disconnection or bad connection of the cable		Check the cable and replace it if necessary.				

ID No.	Display on LED Koypad	Warning Name	Description			
ID No.	Display on LED Keypad	Warning Name	Description			
5		Communication error 10 (CE10)	RS-485 Modbus transmission time-out			
		Action and Reset				
	Action condition	When the communication time exceeds the detection time for Pr.09-33 communication time-out.				
	Action time	Pr.09-03				
War	ning setting parameter	No function				
Reset method		"Warning" occurs when Pr.09-02=0 and the motor drive keeps running. The drive resets automatically when receiving the next communication packet.				
	Reset condition	Immediately reset				
	Record	N/A				
Cause		Corrective Actions				
The upper unit does not transmit the communication command within Pr.09-03 setting time.		Check if the upper unit transmits the communication command within the setting time for Pr.09-03.				
Malfunc interfere	tion caused by ence	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degrees for effective anti-interference performance.				
	t communication setting upper unit	Check if the setting for Pr.09-02 is the same as the setting for the upper unit.				
Disconn of the ca	ection or bad connection able	Check the cable and replace it if necessary.				

ID No.	Display on LED Keypad	Warning Name	Description		
9		IGBT over-heating warning (oH1)	The AC motor drive detects over-heating of IGBT, and over the protection level of oH1 warning. (When Pr.06-15 is higher than the IGBT over-heating level, the drive shows oH1 error without displaying oH1 warning.)		
		Action and	Reset		
	Action condition	Pr.06-15			
	Action time	"oH1" warning occurs value.	when IGBT temperature is higher than Pr.06-15 setting		
War	ning setting parameter	No function			
	Reset method	Auto-reset			
Reset condition		The drive auto-resets when IGBT temperature is lower than oH1 warning level minus (–) 5°C.			
Record		N/A			
	Cause	Corrective Actions			
Check if the ambient temperature or temperature inside the cabinet is too high, or if there is obstruction in the ventilation hole of the control cabinet.		 Check the ambient temperature. Regularly inspect the ventilation hole of the control cabinet. Change the installed place if there are heating objects, such as brake resistors, in the surroundings. Install / add cooling a fan or air conditioner to lower the temperature inside the cabinet. 			
Check if there is any obstruction on the heat sink or if the fan is running.		Remove the obstruction	or replace the cooling fan.		
Insufficie	ent ventilation space	Increase ventilation space of the drive.			
Check if the drive matches the corresponded loading.		 Decrease the load. Decrease the carrier wave. Replace with a drive with larger capacity. 			
	e has run 100% or more 0% of the rated output for me.	Replace with a drive wi	th larger capacity.		

ID No.	Display on LED Keypad	Warr	ning Name	Description		
11	p (II	PID feedback error (PID)		PID feedback loss (A warning for analog feedback signal; it works only when PID enables)		
		\.\.\.\.\.\.\.\.\.\.\.\.\.\.\.\.\.\.\.	Action and			
	Action condition	mA).	e analog input	is lower than 4 mA (only detects analog input 4–20		
	Action time	Pr.08-08				
		Pr.08-09				
		0: Warn a	and continue o	peration		
War	ning setting parameter	1: Fault and ramp to stop				
			2: Fault and coast to stop			
		3: Warn and operate at last frequency				
			"Warning" occurs when Pr.08-09 = 0 or 3.			
	Reset method	Auto The "Warning" automatically clears when the feedback signal is				
	Reset method	larger than 4 mA.				
		Manual "Error" occurs when Pr.08-09 = 1 or 2. You must reset manually.				
	Reset condition	Immediat	tely reset			
	Record	Records when Pr.08-09 = 1 or 2 ("Error").				
	Record	Does not record when Pr.08-09 = 0 or 3 ("Warning").				
	Cause		Corrective Actions			
Loose o	r broken PID feedback	O feedback Tighten the terminals again.				
wiring Replace with a new cable.		ole.				
Feedba	ck device malfunction	Replace with a new feedback device.				
Hardware error		If the PID error still occurs after checking all the wiring, return to the factory for				
		repair.				

	5:			5		
ID No.	Display on LED Keypad		ning Name	Description		
12		ACI anal	log signal loss	Analog input current loss (including all analog 4–20 mA		
12	<u> </u>		(AnL)	signals)		
			Action and	d Reset		
	A ation condition	When the	e analog input	is lower than 4 mA (only detects analog input 4–20		
	Action condition	mA).				
	Action time	Immedia	tely act			
		Pr.03-19				
		0: Disabl	ed			
		1: Contin	ue operation a	t the last frequency (warning, the keypad displays		
war	ning setting parameter	"ANL")				
		2: Decelerate to 0 Hz (warning, the keypad displays "ANL")				
		3: Stop immediately and display ACE				
			"Warning" occurs when Pr.03-19 = 1 or 2.			
		Auto The "Warning automatically clears when the analog input signal is				
	Reset method		larger than 4 r			
		Manual		when Pr.03-19 = 3. You must reset manually.		
	Reset condition		tely reset	,		
		Records when Pr.03-19 = 3 ("Error").				
	Record	Does not record when Pr.03-19 = 1 or 2 ("Warning").				
	Cause	Corrective Actions				
		Tighten the terminals again.				
Loose of	Loose or broken ACI wiring		Replace with a new cable.			
External	device error	Replace with a new device.				
Hardware error		If the AnL error still occurs after checking all the wiring, return to the factory for				
		repair.				

ID No.	Display on LED Keypad	Warr	ning Name	Description	
13	F-	Und	er current (uC)	Low current	
			Action and	I Reset	
	Action condition	Pr.06-71			
	Action time	Pr.06-72			
Warning setting parameter		Pr.06-73 0: Disabled 1: Fault and coast to stop 2: Fault and ramp to stop by the 2 nd deceleration time			
Reset method		3: Warn and continue operation "Warning" occurs when Pr.06-73 = 3. Auto The "Warning" automatically clears when the output current is > (Pr.06-71+0.1 A).			
		Manual "Error" occurs when Pr.06-73 = 1 and 2. You must reset manually.			
	Reset condition	Immediately reset			
	Record		Records when Pr.06-73 = 1 or 2 ("Error"). Does not record when Pr.06-73 = 3 ("Warning").		
	Cause	Corrective Actions			
Broken	motor cable	Troubles	hoot the conne	ection between the motor and the load.	
	Improper setting for the low current protection		roper settings	for Pr.06-71, Pr.06-72 and Pr.06-73.	
The load is too low		Check the loading status. Make sure the loading matches the motor capacity.			

ID No	Display on LED	Koypad	Warning Nama	Description	
ID No.	Display on LED	кеураа	Warning Name	Description	
20			Over-torque 1	Over-torque 1 warning	
	bd b a	•	ot1	·	
			Action and	Reset	
	Action condition	1	Pr.06-07		
	Action time		Pr.06-08		
			Pr.06-06 = 1 or 3		
			0: Disabled		
			1: Continue operation	after over-torque detection during constant speed	
War	rning setting parai	meter	operation		
			2: Stop after over-torqu	e detection during constant speed operation	
			3: Continue operation a	fter over-torque detection during RUN	
			4: Stop after over-torqu	e detection during RUN	
	Reset method		When output current <	(Pr.06-07 – 5%), the ot1 warning automatically clears.	
	Reset condition		When input current < (F	Pr.06-07 – 5%), the ot1 warning automatically clears.	
Record		N/A			
	Cause		Corrective Actions		
Incorrec	t parameter settir	ng	Configure the settings for Pr.06-07 and 06-08 again.		
Mechan	ical error				
(e.g. Me	echanical lock due	to over-	Remove the causes of malfunction.		
torque)					
The loss	d is too large		Decrease the load.		
THE IDA	u is too large		Replace with a motor with larger capacity.		
Accel./	Decel. time and w	orking	Increase the setting values for Pr.01-12–01-19 (accel./ decel. time).		
cycle is	too short.		morease the setting var	ues ioi Fi.01-12-01-19 (accel./ decel. little).	
			Adjust the settings for I	Pr.01-01–01-08 (V/F curve), especially the setting value	
V/F volta	age is too high		for the mid-point voltage (if the mid-point voltage is set too small, the load		
			capacity decreases at low-speed).		
The mot	tor capacity is too	small	Replace with a motor w	ith larger capacity.	
Over-loa	ad during low-spe	ed	Decrease the load durir	ng low-speed operation.	
operatio	n.		Increase the motor capa	acity.	
The torque compensation is too Readjust the torque compensation value (Pr.07-26 torque compens		mpensation value (Pr.07-26 torque compensation gain)			
large.			till the output current de	creases and the motor does not stall.	
	er parameter settir	ngs for	O	attin va fan an and tanalin v	
the spee	ed tracking function	n	· ·	settings for speed tracking.	
-	ng restart after mo		Start the speed tracking function.		
power loss and restart after fault)		Adjust the maximum current for Pr.07-09 speed tracking.			

ID N	Disale and ED Keeper	Manada a Mana	D d. C	
ID No.	Display on LED Keypad	Warning Name	Description The AC and a line between the standard and a line	
			The AC motor drive detects the temperature inside the	
	1137	Motor overheating	motor is too high.	
22		oH3	Situation 1: Motor over-heating warning for PTC / KTY-	
			84	
		A -4:	Situation 2: Motor over-heating warning for PT100	
		Action and		
	Action condition		4-130: Pr.03-00 = 6 The input level > Pr.06-30 (default =	
	Action condition	50%). ● PT100: Pr.03-00 = 11 The input level > Pr.06-57 (default = 7V)		
	Action time	Immediately act	- 11 The input level > F1.00-37 (default = 7 V)	
	Action time	Error treatment: Pr.06-2	29	
		0: Warn and continue o		
		1: Fault and ramp to sto		
		2: Fault and coast to sto	•	
		3: No warning		
		● Use PTC-130 / KT	TY-84-130	
			0 and when the temperature is ≤ Pr.06-30 level, the	
War	rning setting parameter		tomatically cleared.	
		_	0 ("Warning"), it automatically resets.	
		• Use PT100	o (Warning), it dutomatically resets.	
			0 and when the temperature is < Pr 06-56 level, the	
		When Pr.06-29 = 0 and when the temperature is < Pr.06-56 level, the oH3 warning is automatically cleared.		
		If the temperature is between the value of Pr.06-56 and Pr.06-57, the		
		operation follows Pr.06-58 setting.		
		 Use PTC-130 / KT 		
		When Pr.06-29 = 0, oH3 displays "Warning". When the temperature is ≤		
		Pr.06-30 level, the oH3 warning is automatically cleared.		
	Reset method	● Use PT100:		
		When Pr.06-29 = 0, oH3 displays "Warning". When the temperature is <		
			e oH3 warning is automatically cleared.	
			TY-84-130: When the temperature is ≤ Pr.06-30 level,	
			s automatically cleared.	
	Reset condition	_	n the temperature is ≤ Pr.06-56 level, the oH3 warning is	
		automatically clea		
	Record	N/A		
	Cause		Corrective Actions	
Motor lo	ocked.	Clear the motor lock status.		
The lead	dia tao lawa	Decrease the load.		
The load	d is too large	Replace with a motor w	ith larger capacity.	
A l- :	t ta man amatuma la ta a lalah	Change the installed place if there are heating devices in the surroundings.		
Ambient temperature is too high		Install / add cooling a fan or air conditioner to lower the ambient temperature.		
Motor co	ooling system error	Check the cooling system to make it work normally.		
Motor fa	an error	Replace the fan.		
		Decrease low-speed op	peration time.	
Operate	es at low-speed too long.	Change to the dedicated motor for the drive.		
		Increase the motor capacity.		
Accel / Decel_time and working				
Accel./ [Decel. time and working	Increase the security of	ues for Pr.01-12–01-19 (accel./ decel. time).	

V/F voltage is too high	Adjust the settings for Pr.01-01-01-02 (V/F curve), especially the setting value for the mid-point voltage (if the mid-point voltage is set too small, the load capacity decreases at low-speed).
Check if the motor rated current matches the motor nameplate	Configure the correct rated current value of the motor again.
Check if the PTC is properly set and wired.	Situation 1: Check the connection between PTC-130 / KTY-84-130 and the heat protection. Situation 2: Check the connection between PT100 and the heat protection.
Check if the setting for stall prevention is correct	Set the stall prevention to the proper value.
Unbalanced three-phase impedance of the motor	Replace the motor.
Use remedies to reduce harmonics.	Use remedies to reduce harmonics.

ID No.	Display on LCD Keypad	Warning Name	Description	
ID NO.	Display on LOD Reypau	vvairiii g rvairie	Over slip warning.	
	,		By using the maximum slip (Pr.10-29) as the base,	
		Over alip arror	, , , ,	
24		Over slip error	when the drive outputs at constant speed, and the FV > H or F < H	
		(oSL)		
			exceeds Pr.07-29 level and Pr.07-30 setting time,	
		A 4'	100% Pr.07-29 = Pr.10-29.	
		Action and		
	Action level	·	s at constant speed, and F > H or F < H exceeds the	
		Pr.07-29 level		
	Action time	Pr.07-30		
		Pr.07-31 = 0 Warning		
		0: Warn and continue operation		
Wai	rning setting parameter	1: Fault and ramp to stop		
		2: Fault and coast to stop		
		3: No warning		
		When Pr.07-31 = 0 and	when the drive outputs at constant speed, and F > H or	
	Reset method	F < H no longer exceeds the Pr.07-29 level, the oSL warning automatically		
		clears.		
	Reset condition	No function		
	Record	N/A		
	Cause	Corrective Actions		
Any of t	he motor parameters in			
parameter group 5 may be		Check the motor parameter.		
incorrect		·		
The load	d is too large	Reduce the load.		
Check if	the settings for Pr.07-29,			
Pr.07-30	and Pr.10-29 are properly	Check the parameter se	ettings for oSL protection.	
set				

ID No.	Display on LED Keypad	Warning Name	Description	
25	<u>}- } } </u>	Auto tuning	Parameter auto-tuning is processing.	
25		(tUn)	When running auto-tuning, the keypad displays "tUn".	
		Action and	Reset	
Action condition		When running Pr.05-00 motor parameter auto-tuning, the keypad displays "tUn".		
	Action time	No function		
War	ning setting parameter	No function		
	Reset method	When auto-tuning is finished and no error occurs, the warning automatically		
	Reset method	clears.		
	Reset condition	When auto-tuning is finished and no error occurs.		
	Record	N/A		
Cause		Corrective Actions		
The motor parameter is running auto-tuning		When the auto-tuning is	finished, the warning automatically clears.	

ID No.	Display on LED Keypad	Warning Name	Description	
28		Output phase loss (OPHL)	Output phase loss of the drive	
		Action and	Reset	
	Action condition	Pr.06-47		
	Action time	No function		
Warning setting parameter		Pr.06-45 0: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning		
	Reset method	If Pr.06-45 is set to 0, the OPHL warning automatically clears after the drive stops.		
	Reset condition	No function		
	Record	N/A		
	Cause		Corrective Actions	
	nced three-phase nce of the motor	Replace the motor.		
Check if	the wiring is incorrect.	Check the cable. Replace the cable.		
Check if the motor is a single-phase motor. Choose a three-phase r		Choose a three-phase r	motor.	
Check if the control board cable is loose. If yes, reconnect the cable the drive to test. Check if the current sensor is broken. Check if the error still occurs, send the drive back to the factory for repair. Check if the three-phase current is balanced with a current clamp mete current is balanced and the OPHL error still shows on the display, s drive back to the factory for repair.		send the drive back to the factory for repair. The current is balanced with a current clamp meter. If the display, send the		
Check if the drive capacity is larger than the motor capacity			natches the motor capacity.	

ID No.	Display on LED Keypad	Warning Name	Description	
33	NOLE	No output (NOut)	Warn when the PWM output of the drive is disabled	
		Action and	Reset	
	Action condition	When Pr.12-07 = 1, the	function of stopping PWM output is enabled	
	Action time	Immediately displays when the fault is detected		
Warning setting parameter		Pr.12-07 0: No warning 1: Warn but continue operation		
	Reset method	Auto-reset when the trigger condition is clear.		
	Reset condition	Auto-reset when the trigger condition is clear.		
	Record	N/A		
	Cause Corrective Actions			
Incorrect parameter setting		Check Pr.12-07		

ID No.	Display on LED Keypad	Warning Name	Description	
50		PLC opposite defect (PLod)	PLC download error warning	
		Action and	Reset	
	A ation agaition	During PLC downloadir	ng, the program source code detects incorrect address	
	Action condition	(e.g. the address exceeds the range), then the PLod warning shows.		
	Action time	Immediately displays when the fault is detected		
War	ning setting parameter	No function		
	Decet weetherd	Check if the program is correct and re-download the program. If the fault does		
	Reset method	not exist, the warning automatically clears.		
	Reset condition	No function		
	Record	N/A		
Cause		Corrective Actions		
Incorrect data number is found				
when do	ownloading the PLC	Use the correct data nu	mber.	
program				

ID No.	Display on LED Keypad	Warning Name	Description	
51		PLC save memory error (PLSv)	Data error during PLC operation	
		Action and	Reset	
Action condition		The program detects incorrect written address (e.g., the address has exceeded the range) during PLC operation, then the PLSv warning shows.		
	Action time	Immediately displays when the fault is detected		
War	ning setting parameter	No function		
Reset method		Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset condition	No function		
Record		N/A		
Cause		Corrective Actions		
An incorrect written address is detected during PLC operation		Make sure the written a	ddress is correct and download the program again.	

ID No.	Display on LED Keypad	Warning Name	Description	
52	FILGF	Data defect (PLdA)	Data error during PLC operation	
		Action and	Reset	
		The program detects in	ncorrect write-in address when decoding the program	
	Action condition	source code and dow	nloading the PLC program (e.g., the address has	
		exceeded the range), then PLdA warning acts.		
	Action time	Immediately displays when the fault is detected		
War	ning setting parameter	No function		
	Reset method	Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset condition	No function		
	Record	N/A		
Cause		Corrective Actions		
During F	PLC operation, the external			
Modbus	has written/read incorrect	Check if the upper unit transmits the correct command		
data to i	nternal PLC program			

ID No.	Display on LED Keypad	Warning Name	Description	
53	FIF	Function defect (PLFn)	PLC download function code error	
		Action and	Reset	
	Action condition	PLC download function	code error	
	Action time	Immediately displays when the fault is detected		
War	ning setting parameter	No function		
	Reset method	Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset condition	No function		
	Record	N/A		
Cause		Corrective Actions		
Unsupported command has used while downloading the program		Check if the firmware of	the drive is the old version. If yes, contact Delta.	

ID No.	Display on LED Keypad	Warning Name	Description	
54	Flar	PLC buffer overflow (PLor)	PLC register overflow	
		Action and	l Reset	
Action condition		When PLC runs the last command and the command exceeds the maximum capacity of the program, the PLor warning shows.		
	Action time	Immediately displays w	hen the fault is detected	
War	ning setting parameter	No function		
Reset method		Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset condition	No function		
	Record	N/A		
Cause		Corrective Actions		
The program detects internal source code error during PLC operation		 Disable PLC function Delete PLC program (Pr.00-02 = 6) Enable PLC function. Re-download the PLC program 		

ID No.	Display on LED Keypad	Warning Name	Description	
55		Function defect (PLFF)	Function code error during PLC operation	
		Action and	Reset	
Action condition		The program detects incorrect command (unsupported command) during PLC operation, then PLFF warning shows.		
	Action time	Immediately displays when the fault is detected		
Wa	rning setting parameter	No function		
Reset method		Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset condition	No function		
Record		N/A		
Cause		Corrective Actions		
The F	PLC runs an incorrect	When starting the PLC	function and there is no program in the PLC, the PLFF	
command during operation		warning occurs. This is a normal warning, please download the program.		

ID No.	Display on LED Keypad	Warning Name	Description	
56	Flan	Checksum error (PLSn)	PLC checksum error	
		Action and	Reset	
	Action condition	PLC checksum error is	detected after power on, then PLSn warning shows	
	Action time	Immediately displays w	nen the fault is detected	
War	ning setting parameter	No function		
Reset method		Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset condition	No function		
Record		N/A		
Cause		Corrective Actions		
		1. Disable PLC		
The program detects checksum		2. Delete PLC program (Pr.00-02 = 6)		
error du	ring PLC operation	3. Enable PLC function.		
		4. Re-download the PLC program		

ID No.	Display on LED Keypad	Warning Name	Description	
57	FILES	No end command (PLEd)	PLC end command is missing	
		Action and	l Reset	
Action condition		The "End" command is missing until the last command is executed, the PLEd warning shows		
	Action time	Immediately displays when the fault is detected		
War	ning setting parameter	No function		
Reset method		Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset condition	No function		
	Record	N/A		
Cause		Corrective Actions		
There is no "END" command 2. Dele during PLC operation 3. Enab		 Delete PLC prograr Enable PLC functio 	n.	

ID No.	Display on LED Keypad	Warning Name	Description	
58		PLC MCR error (PLCr)	PLC MCR command error	
		Action and	Reset	
Action condition		The MC command is detected during PLC operation, but there is no corresponded MCR command, then the PLCr warning shows.		
	Action time	Immediately displays when the fault is detected		
Warning setting parameter		No function		
Reset method		Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
Reset condition		No function		
Record		N/A		
	Cause	Corrective Actions		
The MC	command is continuously	The MC command cannot be used continuously for 9 times. Check and reset		
used for more than 9 times the program, then re-download the program.		wnload the program.		

ID No.	Display on LED Keypad	Warning Name	Description	
59		PLC opposite defect (PLdF)	PLC download failure	
		Action and	l Reset	
Action condition		PLC download fail due to momentary power loss during the downloading, when power is ON again, PLdF warning shows.		
	Action time	Immediately displays when the fault is detected		
War	ning setting parameter	No function		
Reset method		Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset condition	No function		
Record		N/A		
Cause		Corrective Actions		
PLC download is forced to stop, so the written program is incomplete		Check if there is any er	ror in the program and re-download the PLC program.	

ID No.	Display on LED Keypad	Warning Name	Description	
60		PLC scan time fail (PLSF)	PLC scan time exceeds the maximum allowable time	
		Action and	Reset	
CANopen Status		When the PLC scan time exceeds the maximum allowable time (400 ms), PLSF warning shows.		
	Action time	Immediately displays when the fault is detected		
War	ning setting parameter	No function		
Reset method		Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset condition	No function		
Record		N/A		
Cause Corrective Actions		Corrective Actions		
The PLC scan time exceeds the maximum allowable time (400ms)		Check if the source code is correct and re-download the program.		

ID No.	Display on LED K	eypad	Warning Name	Description	
70		_1	ExCom ID fail	Duplicate MAC ID error	
70			(ECid)	Node address setting error	
1			Action and	Reset	
	Action condition		Duplicate setting of MA	C ID	
	7 totion contaition		Node address setting e	rror	
	Action time		No function		
War	ning setting parame	eter	No function		
	Reset method		Correct the setting and cycle the power		
	Reset condition		No function		
	Record		N/A		
	Cause		Corrective Actions		
The sett	ing address exceed	ds the	Check the address action of the communication cord (Dr.00.70)		
range (0-63)		Check the address setting of the communication card (Pr.09-70)			
The speed setting exceeds the		Standard: 0–2; non-standard: 0–7			
range			Staridard. 0–2, Hori-Star	ndard: U-7	
The address is duplicated with		Reset the address			
other nodes on the BUS		IVESET THE AUDIESS			

ID No.	Display on LED Keypad	Warning Name	Description	
71		ExCom power loss (ECLv)	Low voltage of the communication card	
		Action and	Reset	
	Action condition	The 5V power that drive	provides to communication card is too low	
	Action time	Immediately act		
War	rning setting parameter	No function		
	Reset method	Cycle the power		
	Reset condition	No function		
	Record	N/A		
	Cause	Corrective Actions		
	power that the drive s to the communication oo low	 Switch the communication card to other drives and observe if there is ECLv warning shown. If yes, replace with a new communication card; if not, replace the drive. in not, replace the drive. Use another communication card to test if the ECLv warning still occurs or the same drive. If not, replace the card; if not, replace the drive. 		
The card is loose Make sure the communication card is well inserted.		ication card is well inserted.		

ID No.	Display on LED Keypad	Warning Name	Description	
72		ExCom test mode (ECtt)	The communication card is in the test mode	
		Action and	l Reset	
	Action condition	Communication card is	in the test mode	
	Action time	Immediately act		
War	ning setting parameter	No function		
	Reset method	Cycle the power and enter the normal mode		
	Reset condition	No function		
Record		N/A		
Cause		Corrective Actions		
Communication command error		Cycle the power		

ID No.	Display on LED Keypad	Warning Name	Description	
73	EChF	ExCom BUS off (ECbF)	The communication card detects too many errors in the BUS, then enters the bus-off status and stop communicating	
		Action and	d Reset	
	Action condition	When the drive detects bus-off (for DeviceNet)		
Action time		Immediately act		
War	ning setting parameter	No function		
	Reset method	Cycle the power		
	Reset condition	No function		
	Record	N/A		
Cause		Corrective Actions		
Poor connection of the cable		Re-connect the cable		
Bad quality of the cable		Replace the cable		

ID No.	Display on LED Keypad	Warning Name	Description	
74	EInf	ExCom no power (ECnP)	There is no power supply on the DeviceNet	
		Action and	Reset	
	Action condition	There is no power supp	ly on the DeviceNet	
	Action time	Immediately act		
War	ning setting parameter	No function		
	Reset method	Cycle the power		
	Reset condition	No function		
	Record	N/A		
Cause		Corrective Actions		
The driv	e detects that DeviceNet	Check if the cable and power is normal.		
has no power		If yes, return to the factory for repair.		

ID No.	Display on LED Keypad	Warning Name	Description	
75		ExCom factory defect (ECFF)	Factory default setting error	
		Action and	Reset	
	Action condition	Factory default setting error		
	Action time	Immediately act		
War	ning setting parameter	No function		
	Reset method	Cycle the power		
	Reset condition	No function		
Record		N/A		
Cause		Corrective Actions		
Factory default setting error		Use DCISoft to reset to the default value.		

ID No.	Display on LED Keypad	Warning Name	Description	
76		ExCom inner error (ECiF)	Serious internal error	
		Action and	l Reset	
	Action condition	Internal memory saving	error	
	Action time	Immediately act		
War	ning setting parameter	No function		
	Reset method	Cycle the power		
	Reset condition	No function		
	Record	N/A		
	Cause	Corrective Actions		
Noise interference		Verify wiring of the control circuit, and wiring/grounding of the main circuit to prevent interference. Cycle the power.		
The memory is broken		Reset to the default value and check if the error still exists. If yes, replace the communication card.		

ID No.	Display on LED Keypad	Warning Name	Description	
78		ExCom Parameter data error (ECPP)	Profibus parameter data error	
		Action and	Reset	
	Action condition	No function		
	Action time	No function		
War	ning setting parameter	No function		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
Record		N/A		
Cause		Corrective Actions		
Incorrect GSD file		Get the correct GSD file from the software		

ID No.	Display on LED Keypad	Warning Name	Description	
		ExCom configuration		
79		data error	Profibus configuration data error	
		(ECPi)		
		Action and	l Reset	
	Action condition	No function		
	Action time	No function		
War	ning setting parameter	No function		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
Record		N/A		
Cause		Corrective Actions		
Incorrect GSD file		Get the correct GSD file from the software		

ID No.	Display on LED Keypad	Warning Name	Description	
80		Ethernet link fail (ECEF)	Ethernet cable is not connected	
		Action and	Reset	
	Action condition	Hardware detection		
	Action time	Immediately act		
War	ning setting parameter	No function		
	Reset method	Manual reset		
	Reset condition	No function		
	Record	N/A		
Cause		Corrective Actions		
The Ethernet cable is loose		Re-connect the cable		
Bad quality of the cable		Replace the cable		

ID No.	Display on LED Keypad	Warning Name	Description		
81	Elka	Communication time- out (ECto)	Communication time-out for the communication card and the upper unit		
		Action and	Action and Reset		
	Action condition	No function			
	Action time	No function			
War	ning setting parameter	No function			
	Reset method	No function			
	Reset condition	CMC-EC01: auto resets when the communication with the upper unit is back to normal.			
	Record	N/A			
	Cause	Corrective Actions			
Communication card is not connected with the upper unit		Check if the connection of the communication cable is correct			
Communication error of the upper unit		Check if the communication of the upper unit is normal			

ID No.	Display on LED Keypad	Warning Name	Description	
82		Checksum error (ECCS)	Checksum error for communication card and the drive	
		Action and	Reset	
	Action condition	Software detection		
	Action time	No function		
War	ning setting parameter	No function		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	N/A		
Cause		Corrective Actions		
Noise interference		Verify wiring of the control circuit, and wiring/grounding of the main circuit to prevent interference.		

ID No.	Display on LED Keypad	Warning Name	Description		
83		Return defect (ECrF)	Communication card returns to the default setting		
		Action and	l Reset		
	Action condition	Communication card re	turns to the default setting		
	Action time	No function			
War	ning setting parameter	No function			
	Reset method	Manual reset			
	Reset condition	Immediately reset			
	Record	N/A			
Cause		Corrective Actions			
Communication card is returning to default setting		No actions required.			

ID No.	Display on LED Keypad	Warning Name	Description
84	Elall		Modbus TCP exceeds the maximum communication value
		Action and	Reset
Action condition		Hardware detection	
	Action time	Immediately act	
War	ning setting parameter	No function	
	Reset method	Manual reset	
	Reset condition	Immediately reset	
	Record	N/A	
	Cause	Corrective Actions	
The Master communication value exceeds the allowable number of the communication cards		Decrease the Master communication value	
Connection occupied due to not disconnecting the Modbus TPC while the upper unit is connected without communicating.		Revise the program of communication is not us	the upper unit to disconnect the connection while the sed for a long time.
Iconnected to the communication		· -	he upper unit to use the same Modbus TCP connection same communication card.

ID No.	Display on LED Keypad	Warning Name	Description	
85		Modbus TCP over	Ethernet/IP exceeds the maximum communication	
00		(ECo1)	value	
		Action and	Reset	
	Action condition	Hardware detection	Hardware detection	
	Action time	Immediately act		
Wai	rning setting parameter	No function		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	N/A		
	Cause	Corrective Actions		
The Master communication value				
exceeds	s the allowable number of	Decrease the Master communication value		
the com	munication cards			
Connec	tion occupied due to not			
disconn	ecting the Modbus TPC	Revise the program of the upper unit to disconnect the connection while the		
while the	e upper unit is connected	communication is not used for a long time.		
without communicating.				
A new N	Modbus TCP connection is			
built who	enever the upper unit is	Revise the program of the upper unit to use the same Modbus TCP connection when connecting to the same communication card.		
connect	ed to the communication			
card, wh	nich causes connection			
occupied.				

ID No.	Display on LED Keypad	Warning Name	Description	
86		IP fail (ECiP)	IP setting error	
		Action and	Reset	
	Action condition	Software detection		
	Action time	Immediately act		
War	ning setting parameter	No function		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	N/A		
Cause		Corrective Actions		
IP conflict		Reset IP		
DHCP IP configuration error		MIS check if DHCP Server works normally		

ID No.	Display on LED Keypad	Warning Name	Description	
ID NO.	Display on LLD Reypau	Wairing Name	Description	
87		Mail fail	Mail warning: Alarm mail is sent when the condition	
01		(EC3F)	that the alarm set for the communication card was met.	
		Action and	Reset	
	Action condition	Communication card es	stablishes alarm conditions	
	Action time	Immediately act		
War	ning setting parameter	No function		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	N/A		
Cause		Corrective Actions		
Communication card establishes alarm conditions		No actions required		

ID No.	Display on LED Keypad	Warning Name	Description			
88	ECHH	ExCom busy (ECbY)	Communication card busy: too many packets are received			
		Action and	Reset			
	Action condition	Software detection				
	Action time	No function				
War	ning setting parameter	No function				
	Reset method	Manual reset				
	Reset condition	No function				
	Record	N/A				
Cause		Corrective Actions				
Too many communication packets						
for the communication card to		Decrease communication packets				
process						

ID No.	Display on LED Keypad	Warning Name	Description	
89		ExCom card break (ECCb)	Communication card break off warning	
		Action and	Reset	
	Action condition	Communication card break off		
	Action time	No function		
War	ning setting parameter	No function		
	Reset method	Auto resets after communication card is re-installed		
	Reset condition	Immediately reset		
Record		N/A		
Cause		Corrective Actions		
The card is loose		Re-install the communication card		

ID No.	Display on LED Keypad	Warning Name	Description	
91		Copy PLC: Read mode error (CPL0)	Copy PLC Read mode error	
		Action and	Reset	
	Action condition	When copy PLC read m	node with incorrect process	
	Action time	Immediately act		
War	ning setting parameter	No function		
	Reset method	Manual reset		
	Reset condition	Directly reset		
Record		N/A		
Cause		Corrective Actions		
When copy PLC read mode and the process is incorrect		Cycle the power and copy PLC read mode again.		

ID No.	Display on LED Keypad	Warning Name	Description		
92		Copy PLC: Write mode (CPL1)	Copy PLC write mode error		
		Action and	Action and Reset		
	Action condition	Copy PLC write mode v	Copy PLC write mode with incorrect process		
	Action time	Immediately act			
War	ning setting parameter	No function			
	Reset method	Manual reset			
	Reset condition	Directly reset			
	Record	N/A			
Cause		Corrective Actions			
When copy PLC write mode and the process is incorrect		Cycle the power and copy PLC read mode again			

ID No.	Display on LED Keypad	Fault Name	Description		
98		Fire mode output (Fire)	Display when fire mode is triggered		
		Action and	l Reset		
	Action level	MIx = 58 is triggered an	d run, or MIx = 59 is triggered		
	Action time	Immediately act			
Гои	ult traatmant naramatar	Refer to Pr.06-81, Pr.06-88 to set the operating frequency and the operation			
rau	ılt treatment parameter	times in fire mode			
	Reset method	Manual reset			
	Reset condition	Reset in five seconds after the fault is cleared			
Record		Yes			
Cause		Corrective Actions			
MIx = 58	3 is triggered and run, or	If it is triggered in four minutes, then cancel MI setting.			
MIx = 59 is triggered					

ID No.	Display on LED Keypad	Warning Name	Description	
101	ickn	InrCOM time-out (ictn)	Internal communication time-out	
		Action and	Reset	
Action condition		When Pr.09-31= (-1) - (-10) (no -9) and the internal communication between		
	Action time	Immediately act	normal, the ictn warning shows.	
War	ning setting parameter	No function		
	Reset method	Auto-reset		
Reset condition		The warning automatically clears when the communication is back to normal condition		
	Record	N/A		
	Cause	Corrective Actions		
Malfunction caused by interference		Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degrees for effective anti-interference performance.		
	t communication setting c upper unit Check if the setting for Pr.09-02 is the same as the setting for the upper u		Pr.09-02 is the same as the setting for the upper unit.	
Disconnection or bad connection of the cable		Check the cable and replace it if necessary.		

ID No.	Display on LED Keypad	Warning Name	Description		
104		Battery low voltage	Remind user to change the battery of perpetual		
134		(LBAt) calendar			
		Action and	l Reset		
	Action condition	No function			
	Action time	Immediately displays when the fault is detected			
Warning setting parameter		No function			
	Reset method	No function			
	Reset condition	Need to change the battery			
Record		N/A			
Cause		Corrective Actions			
The battery is dying		Change the battery			

ID No.	Display on LED Keypad	Warning Name	Description	
		Perpetual calendar		
135		adjustment	Remind user to adjust the perpetual calendar	
	/ ba / lba	(rCAL)		
		Action and	d Reset	
	Action condition	Time has not been adjusted.		
	Action time	Immediately displays when the fault is detected		
Fau	It treatment parameter	No function		
	Reset method	Manual reset		
	Reset condition	Need to adjust the perpetual calendar		
Record		N/A		
Cause		Corrective Actions		
Time has not been adjusted yet		Adjust time by Pr.12-93–Pr.12-96		

ID No.	Display on LED Keypad	Warning Name	Description		
222		Low water pressure (LPSn)	The water pressure is lower than the setting		
		Action and	Reset		
		The feedback pressure	is lower than the difference of Pr.12-82 and the target		
	Action condition	pressure, and the condi	tion continues as the time value set in Pr.12-83.		
	Action time	Pr.12-83			
— 11 to 2 t		Pr.12-84			
rau	ılt treatment parameter	0: Warn and continue operation			
	Reset method	Auto-reset when the triggered condition is clear.			
	Reset condition	Immediately reset			
Record		N/A			
	Cause Corrective Actions				
No water pressure		Check if water leakage occurs in pipe, or no water inputs			
Pressure sensor is broken		Change the pressure sensor.			

ID No.	Display on LED Keypad	Warning Name	Description	
223	drum	Dry pump (dryn)	Dry pump condition is detected.	
		Action and	d Reset	
	Action condition	The power corresponds	to the target frequency is under the dry pump curve.	
	Action time	Pr.12-69		
Warning setting parameter		Pr.12-72 1: Fault and coast to stop 2: Fault and ramp to stop		
	Reset method	Auto-reset when the trigger condition is clear.		
	Reset condition	Auto-reset		
	Record	N/A		
Cause		Corrective Actions		
The inlet of the water pump is broken		Check if the pipe is broken, or no water input.		

ID No.	Display on LED Keypad	Warning Name	Description	
224	EHM	Heavy water leakage (LEKn)	Triggered when heavy water leakage is detected	
		Action and	l Reset	
Action level		When the feedback is lower than Plow and the load current is larger than Pr.12-75		
	Action time	Pr.12-74		
Warning setting parameter		Pr.12-76 0: Warn and continue operation		
	Reset method	Auto-reset when the trigger condition is clear.		
Reset condition		When the feedback is lower than Plow and the load current is larger than Pr.12-75		
Record		N/A		
Cause		Corrective Actions		
The outlet of the water pump is broken		Check if the pipe is broken.		

ID No.	Display on LED Keypad	Warning Name	Description	
225		Cavitation (CAvi)	Warning occurs when the drive is in cavitation status	
		Action and	I Reset	
Action level		When the rotational speed is over 100rpm, starts to detect NPSHr and the corresponding flow, and also Pr.12-19 (tolerance) is above the cavitation curve.		
	Action time	Immediately displays w	hen the fault is detected	
Warning setting parameter		Pr.12-18 000xh: No warning when cavitation occurs 001xh: Warn when cavitation occurs and continue operation		
	Reset method	Auto-reset when the trigger condition is clear.		
	Reset condition	Auto-reset		
	Record	N/A		
Cause		Corrective Actions		
Incorrect parameter setting		Check NPSHr (Pr.12-45–Pr.12-49) and the flow (Pr.12-35–Pr.12-39)		
Design of the piping and water pump		Reduce the speed and the tolerance of pump (Pr.12-19)		

[This page intentionally left blank]

Chapter 14 Fault Codes

Summary of Fault Codes

ID No.	Fault Name	ID No.	Fault Name
0	No record	48	ACI loss (ACE)
1	Over-current during acceleration (ocA)	49	External fault (EF)
2	Over-current during deceleration (ocd)	51	External base block (bb)
3	Over-current during steady operation (ocn)	52	Password is locked (Pcod)
4	Ground fault (GFF)	54	Illegal command (CE1)
6	Over-current at stop (ocS)	55	Illegal data address (CE2)
7	Over-voltage during acceleration (ovA)	56	Illegal data value (CE3)
8	Over-voltage during deceleration (ovd)	57	Data is written to read-only address (CE4)
9	Over-voltage at constant speed (ovn)	58	Modbus transmission time-out (CE10)
10	Over-voltage at stop (ovS)	63	Over slip error (oSL)
11	Low-voltage during acceleration (LvA)	79	U-phase over-current before run (Aoc)
12	Low-voltage during deceleration (Lvd)	80	V-phase over-current before run (boc)
13	Low-voltage at constant speed (Lvn)	81	W-phase over-current before run (coc)
14	Low-voltage at stop (LvS)	82	Output phase loss U phase (OPL1)
15	Phase loss protection (OrP)	83	Output phase loss V phase (OPL2)
16	IGBT overheating (oH1)	84	Output phase loss W phase (OPL3)
17	Internal key parts overheating (oH2)	87	Overload protection at low frequency (oL3)
18	IGBT temperature detection failure (tH1o)	89	Rotor position detection error (RoPd)
19	Capacitor hardware error (tH2o)	90	Force to stop (FStp)
21	Over load (oL)	98	Fire mode output (Fire)
22	Electronic thermal relay 1 protection (EoL1)	140	oc hardware error (Hd6)
24	Motor overheating (oH3) PTC-130 /KTY-84-130/PT100	141	GFF occurs before run (b4GFF)
26	Over torque 1 (ot1)	142	Auto-tune error 1 (AUE1)
28	Under current (uC)	143	Auto-tune error 2 (AUE2)
31	EEPROM read error (cF2)	144	Auto-tune error 3 (AUE3)
33	U-phase error (cd1)	221	High water pressure (HPS)
34	V-phase error (cd2)	222	Low water pressure (LPSE)
35	W-phase error (cd3)	223	Dry pump (dryE)
36	cc hardware failure (Hd0)	224	Water leaking (pipe explosion) (LEKE)
37	oc hardware error (Hd1)	225	Clogged pipe (JAME)
40	Auto-tuning error (AUE)	226	RTC error (rtF)
41	PID loss ACI (AFE)	227	Dry pump curve auto-measuring (dAUE)

ID No.	Display on LED Keypad	Fault Name	Description	
	ah ah a ah an		Output current exceeds 2.5 times of the rated current	
		Over-current during	during acceleration.	
1		acceleration	When ocA occurs, the drive closes the gate of the	
	bal ba / \	(ocA)	output immediately, the motor runs freely, and the	
			display shows an ocA error.	
		Action and	d Reset	
Action condition		250% of the rated curre	ent (software)	
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds a	fter the fault is cleared	
	Record	Yes		
	Cause	Corrective Actions		
		Increase the accele		
Accelera	ation time setting is too		eration time of S-curve	
short.	J		on and auto-deceleration parameter (Pr.01-44)	
		_	tall prevention (Pr.06-03).	
01		5. Replace the drive with a larger capacity model.		
	·		and remove causes of the short circuits, or replace the	
	ulation wiring	cable before turning on	•	
	or possible burnout or	Check the motor insulation value with megger. Replace the motor if the insulation is poor.		
aging in	sulation of the motor	· · · · · · · · · · · · · · · · · · ·		
The load	d is too large	Check if the output current during the whole working process exceeds the AC		
The load	a is too large	motor drive's rated current. If yes, replace the AC motor drive with a larger capacity model.		
Impulsiv	re change of the load	Reduce the load or increase the capacity of AC motor drive.		
	cial motor or motor with	Check the motor capacity (the rated current on the motor's nameplate should ≤		
	apacity than the drive	the rated current of the drive)		
	/ OFF controller of an		<u> </u>	
electron	nagnetic contactor at the	Check the action timing of the contactor and make sure it is not turned		
output (l	U/V/W) of the drive	ON/OFF when the drive	e outputs the voltage.	
\//E aum	o acting arror	Adjust the V/F curve se	etting and frequency/voltage. When the fault occurs, and	
V/F Curv	re setting error	the frequency voltage is	s too high, reduce the voltage.	
The torq	ue compensation is too	Readjust the torque co	mpensation value (Pr.07-26 torque compensation gain)	
large.		till the output current de	ecreases and the motor does not stall.	
Malfunc	tion caused by	Verify wiring of the cor	ntrol circuit, and wiring/grounding of the main circuit to	
interfere	ence	prevent interference.		
The motor starts when in free run Enable the speed tracking during start-up of Pr.07-12.		ing during start-up of Pr.07-12.		
	r parameter settings for	Correct the parameter s	settings for speed tracking.	
	ed tracking function	·		
(including restart after momentary		 Start the speed tracking function. Adjust the maximum current for Pr.07-09 speed tracking. 		
power lo	oss and restart after fault)	•	·	
mode and used motor		Check the settings for F		
		1. For IM motor, Pr.00-11=0, 2, Pr.05-33=0		
The last	ath of motor cable is too		0-11=2, Pr.05-33=1, 2	
	gth of motor cable is too	Increase the drive capa	•	
long		Install AC reactor(s) on	the output side (U/V/W).	

	The ocA occurs due to the short circuit or ground fault at the output side of the	
	drive.	
Hardware error	Check for possible short circuits between terminals with the electric meter. If	
Tardware error	short circuits occur, return to the factory for repair.	
	B1 corresponds to U, V and W; DC- corresponds to U, V and W; corresponds to U, V and W.	
Check if the setting for stall	Cot the stell presention to the preparation	
prevention is correct	Set the stall prevention to the proper value.	

ID No.	Display on LED Keypad	Fault Name	Description	
ID NO.	Display of LLD Reypau	i aut Name	Output current exceeds 2.5 times of the rated current	
		Over-current during	during deceleration. When ocd occurs, the drive closes	
2		deceleration	the gate of the output immediately, the motor runs	
		(ocd)		
		Action and	freely, and the display shows an ocd error.	
	Action condition	250% of the rated curre		
	Action time		ait.	
Faul		Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset Reset in five seconds a	fter the foult is elegand	
	Reset condition		ner the fault is cleared	
	Record	Yes Corrective Actions		
	Cause			
Accelera	ation time setting is too		eration time of S-curve	
short.			on and auto-deceleration parameter (Pr.01-44)	
			tall prevention (Pr.06-03).	
Choole if	the mechanical budge of	5. Replace the drive w	vith a larger capacity model.	
	the mechanical brake of or activates too early	Check the action timing	of the mechanical brake	
Short-cir	cuit at motor output due to	Check the motor cable	and remove causes of the short circuits, or replace the	
poor insu	ulation wiring	cable before turning on the power.		
Check fo	or possible burnout or	Check the motor insu	lation value with megger. Replace the motor if the	
aging ins	sulation of the motor	insulation is poor.		
		Check if the output current during the whole working process exceeds the AC		
The load	I is too large	motor drive's rated current. If yes, replace the AC motor drive with a larger capacity model.		
Impulciv	e change of the load		ease the capacity of AC motor drive.	
	cial motor or motor with			
'	pacity than the drive	Check the motor capacity (the rated current on the motor's nameplate should ≤ the rated current of the drive)		
	/ OFF controller of an	the rated current of the	unve)	
	agnetic contactor at the	Check the action timin	ng of the contactor and make sure it is not turned	
	J/V/W) of the drive	ON/OFF when the drive	e outputs the voltage.	
output (c	or the drive	Adjust the V/F curve s	etting and frequency / voltage. When the fault occurs,	
V/F curv	e setting error	_	ge is too high, reduce the voltage.	
The torq	ue compensation is too	Readjust the torque co	mpensation value (Pr.07-26 torque compensation gain)	
large.		till the output current de	creases and the motor does not stall.	
Malfunct	ion caused by	Verify wiring of the con	trol circuit, and wiring / grounding of the main circuit to	
interfere	nce	prevent interference.		
The leng	th of motor cable is too	Increase the drive capacity.		
long		Install AC reactor(s) on	the output side (U/V/W).	
		The ocd occurs due to	the short circuit or ground fault at the output side of the	
		drive.		
Hardwar	e error	Check for possible short circuits between terminals with the electric meter. If		
2		short circuits occur, return to the factory for repair.		
		B1 corresponds to U, corresponds to U, V and	, V and W; DC- corresponds to U, V and W; 🖨	
Check if	the setting for stall			
Set the stall prevention to the proper value.			to the proper value.	

ID No.	Display on LED Keypad	Fault Name	Description	
3	מונו וו	Over-current during steady operation (ocn)	Output current exceeds 2.5 times of the rated current during constant speed. When ocn occurs, the drive closes the gate of the output immediately, the motor runs freely, and the display shows an ocn error.	
		Action and	l Reset	
	Action condition	250% of the rated curre	ent	
	Action time	Immediately act		
Fau	ılt treatment parameter	No function		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds a	fter the fault is cleared	
	Record	Yes		
	Cause		Corrective Actions	
Short-ci	rcuit at motor output due to	Check the motor cable	and remove causes of the short circuits, or replace the	
poor ins	ulation wiring	cable before turning on	the power.	
Check for	or possible shaft lock,	Troubleshoot the motor	shaft lock.	
burnout	or aging insulation of the	Check the motor insulation value with megger. Replace the motor if the		
motor		insulation is poor.		
	e change of the load	Reduce the load or increase the capacity of AC motor drive.		
Use spe	ecial motor or motor with	Check the motor capacity (the rated current on the motor's nameplate should ≤		
	apacity than the drive	the rated current of the	drive)	
Use ON / OFF controller of an electromagnetic contactor at the output (U/V/W) of the drive		Check the action timing ON/OFF when the drive	ng of the contactor and make sure it is not turned e outputs the voltage.	
V/F curv	ve setting error	=	tting and frequency/voltage. When the fault occurs, and too high, reduce the voltage.	
The tord	que compensation is too	Readjust the torque co	mpensation value (Pr.07-26 torque compensation gain)	
large.		till the output current de	creases and the motor does not stall.	
Malfunc	tion caused by	Verify wiring of the control circuit, and wiring/grounding of the main circuit to		
interfere	ence	prevent interference.		
The leng	gth of motor cable is too	Increase the drive capa	city.	
long		Install AC reactor(s) on the output side (U/V/W).		
Hardware error		The ocn occurs due to short circuit or ground fault at the output side of the drive. Check for possible short circuits between terminals with the electric meter. If short circuits occur, return to the factory for repair.		
		B1 corresponds to U, corresponds to U,	, V and W; DC- corresponds to U, V and W; $\stackrel{ ext{(b)}}{=}$ d W.	

ID No.	Display on LED Keypad	Fault Name	Description	
4	55 FF	Ground fault (GFF)	When (one of) the output terminal(s) is grounded, short circuit current is larger than Pr.06-60 setting value, and the detection time is longer than Pr.06-61 time setting, GFF occurs. NOTE: the short circuit protection is provided for AC motor drive protection, not to protect you.	
		Action and	I Reset	
	Action condition	Pr.06-60 (Default = 60%	(o)	
	Action time	Pr.06-61 (Default = 0.10) sec.)	
Fau	Ilt treatment parameter	No function		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds after the fault is cleared		
	Record	Yes		
Cause			Corrective Actions	
Motor bu	urnout or aging insulation	Check the motor insulation value with megger. Replace the motor if the insulation is poor.		
Short cir	rcuit due to broken cable	Troubleshoot the short circuit. Replace the cable.		
Larger stray capacitance in the cable and terminal cable and terminal Take remedies to reduce stray capacitance.				
	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, of wire in 90 degrees for effective anti-interference performance.			
Hardwai	re error		necking the status of motor, cable and cable length. If	

ID No.	Display on LED Keypad	Fault Name	Description	
			Over-current or hardware failure in current detection at	
6		Over-current at stop	stop.	
	ach	(ocS)	Cycle the power after ocS occurs. If the hardware	
			failure occurs, the display shows cd1, cd2 or cd3.	
		Action and	d Reset	
	Action condition	240% of the rated curre	ent	
	Action time	Immediately act		
Fau	It treatment parameter	No function		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds after the fault is cleared		
	Record	Yes		
	Cause	Corrective Actions		
Malfunc	tion caused by	Verify wiring of the control circuit, and wiring / grounding of the main circuit to		
interfere	ence	prevent interference.		
Hardwa	ro orror	Check if other error co	des such as cd1-cd3 occur after cycling the power. If	
пагима	ie eiioi	yes, return to the factory for repair.		

ID No.	Display on LED Keypad	Fault Name	Description	
	ziopiaj en 222 nejpaa		DC bus over-voltage during acceleration.	
	pg	Over-voltage during	When ovA occurs, the drive closes the gate of the	
7		acceleration.	output, the motor runs freely, and the display shows an	
		(ovA)	ovA error.	
		Action and	I Reset	
		230V models: 410V _{DC}		
	Action condition	460V models: 820V _{DC}		
	Action time	Immediately act when the	he DC bus voltage is higher than the level	
Fau	ılt treatment parameter	No function		
	Reset method	Manual reset		
	Deact condition	Reset only when the D	OC bus voltage is lower than 90% of the over-voltage	
	Reset condition	level		
	Record	Yes		
	Cause		Corrective Actions	
Accelera	ation is too slow	Decrease the accelerat	ion time.	
	nen elevator is going down)	Replace the drive with a	a larger capacity model.	
(c.g. vvi		Replace with a drive with	th larger capacity.	
	ting for stall prevention			
level is s	smaller than no-load	The setting for stall prevention level should be larger than no-load current.		
current.				
Power v	oltage is too high	Check if the input voltage is within the rated AC motor drive input voltage		
		range, and check for po		
	switch action of phase-in	If the phase-in capacitor or active power supply unit acts in the same power		
	or in the same power	system, the input voltage may surge abnormally in a short time. In this case,		
system		install an AC reactor.	d (
Regene	rative voltage of motor	Use over-voltage stall prevention function (Pr.06-01)		
inertia	-		nd auto-deceleration parameter (Pr.01-44)	
			a larger capacity model.	
			ge warning occurs after acceleration stops. When the	
A	ation time is too short	warning occurs, do the following: 1. Increase the acceleration time		
Accelera	ation time is too short			
			roltage stall prevention	
			y value for Pr.01-25 S-curve acceleration arrival time 2 uit current charges the capacitor in the main circuit	
		_	-	
Motor ground fault		through the power. Check if there is ground fault on the motor cable, wiring box and its internal terminals.		
		Troubleshoot the groun		
Incorrec	et wiring of brake resistor or			
brake ur	=	Check the wiring of bral	ke resistor or brake unit.	
	tion caused by	Verify wiring of the cor	ntrol circuit, and wiring/grounding of the main circuit to	
interfere	•	prevent interference.	a, as a grant same as a second to	

ID No.	Display on LED Keypad	Fault Name	Description
8		Over-voltage during deceleration (ovd)	DC bus over-voltage during deceleration. When ovd occurs, the drive closes the gate of the output immediately, the motor runs freely, and the display shows an ovd error.
Action and Reset		l Reset	
	Action condition	230V models: 410V _{DC} 460V models: 820V _{DC}	
	Action time	Immediately act when the	he DC bus voltage is higher than the level
Fau	It treatment parameter	N/A	
	Reset method	Manual reset	
	Reset condition	Reset only when the Devel	DC bus voltage is lower than 90% of the over-voltage
	Record	Yes	
	Cause		Corrective Actions
Deceleration time is too short, causing too large regenerative energy of the load		(deceleration time). 2. Connect brake resis 3. Reduce the brake f 4. Replace with a drive 5. Use S-curve accele 6. Use over-voltage st 7. Set auto-acceleration	stor, brake unit or DC bus to the drive. requency. e with larger capacity.
	ing for stall prevention smaller than no-load	The setting for stall prev	vention level should be larger than no-load current.
Power v	oltage is too high	Check if the input volt range, and check for po	tage is within the rated AC motor drive input voltage ossible voltage spikes.
	switch action of phase-in or in the same power	· · · · · · · · · · · · · · · · · · ·	
Motor ground fault th		_	
Incorrect wiring of brake resistor or brake unit Check the wiring of brake resistor or brake unit.			
Malfunctinterfere	tion caused by nce	Verify wiring of the control circuit, and wiring/grounding of the main circuit to prevent interference.	

ID No.	Display on LED Keypad	Fault Name	Description	
9	נונונו	Over-voltage at constant speed (ovn)	DC bus over-voltage at constant speed. When ovn occurs, the drive closes the gate of the output immediately, the motor runs freely, and the display shows an ovn error.	
		Action and	d Reset	
Action condition		230V models: 410V _{DC} 460V models: 820V _{DC}		
	Action time	Immediately act when the	he DC bus voltage is higher than the level	
Fau	Ilt treatment parameter	No function		
	Reset method	Manual reset		
	Reset condition	Reset only when the Dilevel	OC bus voltage is lower than 90% of the over-voltage	
	Record	Yes		
	Cause		Corrective Actions	
Impulsive change of the load		 Connect brake resistor, brake unit or DC bus to the drive. Reduce the load. Replace with a drive with larger capacity. Adjust braking level (Pr.07-01 or the bolt position of the brake unit). 		
The setting for stall prevention level is smaller than no-load current.		The setting for stall prevention level should be larger than no-load current.		
Regene inertia	rative voltage of motor	Use over-voltage stall prevention function (Pr.06-01) Replace the drive with a larger capacity model.		
Power v	oltage is too high	Check if the input voltage is within the rated AC motor drive input voltage range, and check for possible voltage spikes.		
	switch action of phase-in or in the same power			
Motor ground fault		The ground short circuit current charges the capacitor in the main circuit through the power. Check if there is ground fault on the motor cable, wiring box and its internal terminals. Troubleshoot the ground fault.		
Incorrec brake ur	t wiring of brake resistor or nit			
	tion caused by	, ,	ntrol circuit, and wiring/grounding of the main circuit to	
interference prevent interference.				

ID No.	Display on LED Keypad	Fault Name	Description
10		Over-voltage at stop (ovS)	The drive has over-voltage at stop
		Action and	l Reset
Action condition		230V models: 410V _{DC} 460V models: 820V _{DC}	
	Action time	Immediately act when the DC bus voltage is higher than the level	
Fau	It treatment parameter	N/A	
	Reset method	Manual reset	
	Reset condition	Reset only when the Dilevel	OC bus voltage is lower than 90% of the over-voltage
	Record	Yes	
	Cause	Corrective Actions	
Power v	oltage is too high	Check if the input voltage is within the rated AC motor drive input voltage range, and check for possible voltage spikes.	
ON/OFF switch action of phase-in capacitor in the same power system		If the phase-in capacitor or active power supply unit acts in the same power system, the input voltage may surge abnormally in a short time. In this case, install an AC reactor.	
Incorrec brake ur	t wiring of brake resistor or nit	Check the wiring of bral	ke resistor or brake unit.
Malfunctinterfere	tion caused by nce	Verify wiring of the control circuit, and wiring/grounding of the main circuit to prevent interference.	
Hardware error Hardware failure in voltage detection Check if other error codes such as cd1–cd3 occur after cycling the properties of the			
Motor ground fault		_	

ID No.	Display on LED Keypad	Fault Name	Description	
11		Low-voltage during acceleration (LvA)	DC bus voltage is lower than Pr.06-00 setting value during acceleration.	
		Action and	Reset	
	Action condition	Pr.06-00 (Default = dep	end on the model)	
	Action time	Immediately act when the DC bus voltage is lower than Pr.06-00		
Fau	Ilt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset when DC bus voltage is higher than Pr.06-00 + 30 V (230V series) / + 60 V (460V series).		
	Record	N/A		
	Cause		Corrective Actions	
Power-off		Improve power supply condition.		
Power voltage changes		Adjust voltage to the power range of the drive.		
Start up the motor with large		Check the power system.		
capacity	1	Increase the capacity of power equipment.		
		Reduce the load.		
The load	d is too large	Increase the drive capacity.		
		Increase the acceleration time.		
DC bus		Install DC reactor(s).		
Check if there is short circuit plate or any DC reactor installed between terminal +1 and +2		·	ate or DC reactor between terminal +1 and +2. eturn to the factory for repair.	

ID No.	Display on LED Keypad	Fault Name	Description	
12		Low-voltage during deceleration (Lvd)	DC bus voltage is lower than Pr.06-00 setting value during deceleration.	
		Action and	l Reset	
	Action condition	Pr.06-00 (Default = depend on the model)		
	Action time	Immediately act when t	he DC bus voltage is lower than Pr.06-00	
Fau	It treatment parameter	No function		
	Reset method	Manual reset		
	Reset condition	Reset when DC bus voltage is higher than Pr.06-00 + 30 V (230V series) / + 60 V (460V series).		
Record		N/A		
Cause		Corrective Actions		
Power-c	off	Improve power supply condition.		
Power v	oltage changes	Adjust voltage to the power range of the drive.		
Start up	the motor with large	Check the power system.		
capacity		Increase the capacity of power equipment.		
Sudden load		Reduce the load. Increase the drive capacity.		
DC bus		Install DC reactor(s).		

ID No.	Display on LED Keypad	Fault Name	Description	
13	LLIN	Low-voltage at constant speed (Lvn)	DC bus voltage is lower than Pr.06-00 setting value at constant speed.	
		Action and	Reset	
	Action condition	Pr.06-00 (Default = dep	end on the model)	
	Action time	Immediately act when t	he DC bus voltage is lower than Pr.06-00	
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
Reset condition		Reset when DC bus voltage is higher than Pr.06-00 + 30 V (230V series) / + 60 V (460V series).		
Record		N/A		
Cause			Corrective Actions	
Power-o	off	Improve power supply condition.		
Power v	oltage changes	Adjust voltage to the power range of the drive.		
Start up	the motor with large	Check the power system.		
capacity		Increase the capacity of power equipment.		
Sudden	load	Reduce the load. Increase the drive capacity.		
DC bus		Install DC reactor(s).		

ID No.	Display on LED Keypad	Fault Name	Description	
14		14: Low-voltage at stop (LvS)	 DC bus voltage is lower than Pr.06-00 setting value at stop. Hardware failure in voltage detection 	
		Action and	Reset	
	Action condition	Pr.06-00 (Default = dep	end on the model)	
	Action time	Immediately act when the	ne DC bus voltage is lower than Pr.06-00	
Fau	It treatment parameter	N/A		
	Reset method	Manual / Auto 230V series: Lv level + 30 V _{DC} + 500 ms 460V series: Lv level + 60V _{DC} + 500 ms		
Reset condition		500ms		
	Record	Yes		
	Cause		Corrective Actions	
Power-c	off	Improve power supply of	condition.	
Incorrec	t drive models	Check if the power specification matches the drive.		
Adjust voltage to the power range of the drive. Power voltage changes Cycle the power after checking the power. If LvS error still exists, return factory for repair.		-		
Start up	the motor with large	Check the power system.		
capacity	,	Increase the capacity of	f power equipment.	
DC bus Install DC reactor(s).				

ID No.	Display on LED Keypad	Fault Name	Description	
15	ar F	Phase loss protection (OrP)	Phase loss of power input	
		Action and	l Reset	
	Action condition	DC bus is lower than Pr.07-00, and DC bus ripple is too high.		
	Action time	N/A		
Fau	It treatment parameter	Pr.06-53		
	Reset method	Manual reset		
	Reset condition	Immediately reset wher	DC bus is higher than Pr.07-00	
	Record	Yes		
	Cause	Corrective Actions		
Phase Id	oss of input power	Correctly install the wiring of the main circuit power.		
Single phase power input to three- phase models		Use the model with voltage that matches the power.		
Power voltage changes		If the main circuit power works normally, verify the main circuit. Cycle the power after checking the power. If OrP error still exists, return to the factory for repair.		
Loose wiring terminal of input power		Tighten the terminal screws according to the torque described in the user manual.		
The inpu	ut cable of three-phase	Wire correctly.		
power is cut off.		Replace the cut off cable.		
Unbalanced three-phase of input power Check the power three-phase status.		phase status.		
Use open delta connection system (V-V system)		Install reactors or use drives with higher power.		

ID No.	Display on LED Keypad	Fault Name	Description	
15 110.) (IGBT overheating	IGBT temperature exceeds the protection level.	
16		oH1	(Refer to Pr.06-15)	
		Action and		
	Action condition	The fault level of oH1 is		
		IGBT temperature exceeds the protection level for more than 100 ms, oH1		
	Action time	error occurs.		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
		Reset only when IGBT	temperature is lower than oH1 error level minus (-)	
	Reset condition	10°C.		
	Record	Yes		
	Cause	Corrective Actions		
Check if the ambient temperature or temperature inside the cabinet is too high, or if there is obstruction in the ventilation hole of the control cabinet.		Change the installed plain the surroundings.	perature. entilation hole of the control cabinet. ace if there are heating objects, such as brake resistors, an or air conditioner to lower the temperature inside the	
Check if there is any obstruction on the heat sink or if the fan is running. Remove the obstruction or replace to running.		or replace the cooling fan.		
Insuffici	ent ventilation space	Increase ventilation spa	ace of the drive.	
Check if the drive matches the		 Reduce the load. Decrease the carrier wave. Replace with a drive with larger capacity. 		
	re has run 100% or more 0% of the rated output for me.	Replace with a drive with larger capacity.		

ID No.	Display on LCD Keypad	Fault Name	Description	
17	aHB	Internal key parts overheating (oH2)	The drive has detected the key components are overheat	
		Action and	Reset	
	Action condition	The fault level of oH2 is 95°C		
Action time		The oH2 fault occurs when the temperature sensor of key components detects the temperature is higher than the protection level for 100ms.		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition		hen the temperature sensor of key components detects r than oH2 error level minus (–) 10°C.	
	Record	Yes		
	Cause		Corrective Actions	
Check if the ambient temperature or temperature inside the cabiner is too high, or if there is obstruction in the ventilation hole of the control cabinet.		Change the installed plain the surroundings.	perature. entilation hole of the control cabinet. ace if there are heating objects, such as brake resistors, an or air conditioner to lower the temperature inside the	
	there is any obstruction eat sink or if the fan is	Remove the obstruction or replace the cooling fan.		
Insufficie	ent ventilation space	Increase ventilation spa	ce of the drive.	
Check if the drive matches the corresponded loading.		 Reduce the load. Decrease the carrier wave. Replace with a drive with larger capacity. 		
than 100	The drive has run 100% or more than 100% of the rated output for a long time. Replace with a drive with larger capacity.		h larger capacity.	
Unstable	e power	Install reactor(s)		
Load changes frequently		Reduce load changes		

ID No.	Display on LED Keypad	Fault Name	Description	
18		IGBT temperature detection failure (tH1o)	IGBT hardware failure in temperature detection	
		Action and	Reset	
	Action condition	NTC broken or wiring fa	ilure	
	Action time	When the IGBT temperature is higher than the protection level, and detection time exceeds 100 ms, the tH1o protection activates.		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
Cause		Corrective Actions		
Hardware error		Wait for 10 minutes, an exists. If yes, return to the	nd then cycle the power. Check if tH1o protection still he factory for repair.	

ID No.	Display on LED Keypad	Fault Name	Description	
		Capacitor hardware		
19		error	Hardware failure in capacitor temperature detection	
		(tH2o)		
		Action and	l Reset	
	Action condition	NTC broken or wiring fa	ailure	
	A ation times	When the IGBT temperature is higher than the protection level, and detection		
	Action time	time exceeds 100ms, the tH2o protection occurs.		
Fau	Ilt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
Record		Yes		
Cause		Corrective Actions		
Hardware error		Wait for 10 minutes, and then cycle the power. Check if tH2o protection still		
		exists. If yes, return to the factory for repair.		

ID No.	Display on LED Keypad	Fault Name	Description	
21		Over load (oL)	 The AC motor drive detects excessive drive output current. Normal duty: 120 % of rated current can endure for 1 minute during every 5 minutes; 150 % of rated current can endure for 3 seconds during every 30 seconds Heavy duty: 150 % of rated current can endure for 1 minute during every 5 minutes; 200 % of rated current can endure for 3 seconds during every 30 seconds 	
		Action and	d Reset	
	Action condition	Based on overload curv	ve and derating curve (Pr.06-55)	
	Action time	When the load is highe the oL protection activa	er than the protection level and exceeds allowable time, tes.	
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds after the fault is cleared		
	Record	Yes		
	Cause	Corrective Actions		
The load is too large		Decrease the loading.		
Accel./ Decel. time and working cycle is too short.		Increase the setting val	ues for Pr.01-12-01-19 (accel./ decel. time).	
V/F voltage is too high		Adjust the settings for Pr.01-01-01-02 (V/F curve), especially the setting value for the mid-point voltage (if the mid-point voltage is set too small, the load capacity decreases at low-speed). Refer to the V/F curve selection of Pr.01-43.		
The cap small	acity of the drive is too	Replace the drive with a	a larger capacity model.	
Over-loa	nd during low-speed n.	Decrease the load during low-speed operation. Increase the drive capacity. Decrease the carrier frequency of Pr.00-17.		
The torq	ue compensation is too	Readjust the torque compensation value (Pr.07-26 torque compensation gain) till the output current decreases and the motor does not stall.		
Check if the setting for stall prevention is correct		Set the stall prevention to the proper value.		
Output phase loss		Check the status of three-phase motor. Check if the cable is broken or the screws are loose.		
Improper parameter settings for the speed tracking function (including restart after momentary power loss and restart after fault)		Correct the parameter s	settings for speed tracking.	

ID No.	Display on LED Keypad	Fault Name	Description	
22	Eal (Electronic thermal relay 1 protection (EoL1)	Electronic thermal relay 1 protection. The drive coasts to stop once it activates.	
		Action and Reset		
	Action condition	Start counting when output current > 150% of motor 1 rated current.		
Action time		Pr.06-14 (if the output current is larger than 105% of motor 1 rated current again within 60 sec., the counting time reduces and is less than Pr.06-14.)		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds a	fter the fault is cleared	
	Record	Yes		
	Cause		Corrective Actions	
The load	d is too large	Decrease the loading.		
	Decel. time and working too short.	Increase the setting val	ues for Pr.01-12-01-19 (accel./ decel. time).	
V/F volta	age is too high	Adjust the settings for Pr.01-01-01-02 (V/F curve), especially the setting value for the mid-point voltage (if the mid-point voltage is set too small, the load capacity decreases at low-speed).		
Over-load during low-speed operation. When using a general motor, even it operates below rated current, an overload may still occur during low-speed operation.		Decrease low-speed operation time. Change to the dedicated motor for the drive. Increase the motor capacity.		
When using VFD dedicated motors, Pr.06-13=0 (electronic thermal relay selection motor 1 = 0 inverter motor)			nermal relay selection motor 1 = standard motor (motor	
Incorrect thermal	t value of electronic relay	Configure the correct ra	ated current value of the motor again.	
The max	kimum motor frequency is	Reset to the correct motor rated frequency.		
One driv	re to multiple motors	Set Pr.06-13=2 electronic thermal relay selection motor 1 = disable, and install thermal relay on each motor.		
Check if the setting for stall prevention is correct		Set the stall prevention to the proper value.		
The torque compensation is too		Readjust the torque compensation value (Pr.07-26 torque compensation gain		
large.		till the output current decreases and the motor does not stall.		
Motor fa	n error	Check the status of the fan, or replace the fan.		
Unbalanced three-phase impedance of the motor		Replace the motor.		

ID No.	Display on LED Keypad	Fault Name	Description	
12 1101	Diopidy on LLB Hoypad	T dant Hamo	The AC motor drive detects the temperature inside the	
24	aH I	Motor overheating (oH3)	motor is too high. Situation 1: Motor over-heating warning for PTC-130 / KTY-84-130 Situation 2: Motor over-heating warning for PT100 ■ When using motor with PTC-130 / KTY-84-130, and enable the function (Pr.03-00–03-02 = 6 PTC-130 / KTY-84-130) The input of PTC-130 / KTY-84-130 > Pr.06-30, then treats with the Pr.06-29 setting. ■ When using motor with PT100, and enable the function (Pr.03-00–03-02 = 11 PT100) The input of PT100 > Pr.06-57 (default = 7V), then treats with the Pr.06-29 setting.	
		Action and		
			-130: Pr.03-00 = 6, the input level > Pr.06-30 (default =	
	Action condition	50%).	11, the input level > Pr.06-57 (default = 7V)	
	Action time	Immediately act		
Fau	It treatment parameter	Error treatment: Pr.06-29 0: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning		
	Reset method	Use PTC-1 When the automatica Use PT100 When the automatica	temperature is < Pr.06-56 level, the oH3 warning is lly cleared.	
		"Error" occurs when Pr.06-29 = 1 or 2. You must reset manually.		
	Reset condition	Immediately reset		
	Record	When Pr.06-29=1 or 2,	oH3 is a fault, and the fault is recorded	
	Cause	Corrective Actions		
Motor lo	cked.	Clear the motor lock status.		
The load	d is too large	Reduce the load. Increase the motor capacity.		
Ambient temperature is too high			ace if there are heating devices in the surroundings. an or air conditioner to lower the ambient temperature.	
Motor co	ooling system error	Check the cooling system to make it work normally.		
Motor fa	n error	Replace the fan.		
Operates at low-speed too long.		Decrease low-speed operation time. Change to the dedicated motor for the drive.		
Accel./ Decel. time and working cycle is too short.		Increase the motor cap	lues for Pr.01-12–01-19 (accel./ decel. time).	

V/F voltage is too high	Adjust the settings for Pr.01-01-02 (V/F curve), especially the setting value for the mid-point voltage (if the mid-point voltage is set too small, the load capacity decreases at low-speed).
Check if the motor rated current matches that on the motor nameplate.	Configure the correct rated current value of the motor again.
Check if the PTC is properly set and wired.	Situation 1: Check the connection between PTC-130 / KTY-84-130 and the heat protection. Situation 2: Check the connection between PT100 and the heat protection.
Check if the setting for stall prevention is correct	Set the stall prevention to the proper value.
Unbalanced three-phase impedance of the motor	Replace the motor.
Use remedies to reduce harmonics.	Use remedies to reduce harmonics.

ID No.	Display on LED Keypad	Fault Name	Description		
			When output current exceeds the over-torque		
	1	Over torque 1	detection level (Pr.06-07) and exceeds over-torque		
26		(ot1)	detection time (Pr.06-08), and when Pr.06-06 or Pr.06-		
		, ,	09 is set to 2 or 4, the ot1 error displays.		
•		Action and			
	Action condition	Pr.06-07			
	Action time	Pr.06-08			
		Pr.06-06			
		0: Disabled			
		1: Continue operation	after over-torque detection during constant speed		
Faul	t treatment parameter	operation			
		2: Stop after over-torque	e detection during constant speed operation		
		3: Continue operation a	fter over-torque detection during RUN		
		4: Stop after over-torque	e detection during RUN		
		"Warning" occu	urs when Pr.06-06 = 1 or 3. When output current <		
		I AUTO I), the ot1 warning automatically clears.		
	Reset method	Manua "Error" occurs when Pr.06-06 = 2 or 4. You must reset manually.			
	Reset condition	Immediately reset			
	Record	•	ot1 is a fault, and the fault is recorded		
	Cause	,	Corrective Actions		
Incorrect	parameter setting	Configure the settings for	or Pr.06-07 and 06-08 again.		
Mechani	·	<u> </u>	J		
		Remove the causes of malfunction.			
torque)					
		Decrease the loading.			
The load	is too large	Replace with a motor with larger capacity.			
Accel./ D	ecel. time and working	,			
cycle is t	=	Increase the setting val	ues for Pr.01-12–01-19 (accel./ decel. time).		
		Adjust the settings for F	Pr.01-01-01-02 (V/F curve), especially the setting value		
V/F volta	ge is too high	for the mid-point voltage (if the mid-point voltage is set too small, the load			
		capacity decreases at low-speed).			
The moto	or capacity is too small	Replace with a motor with larger capacity.			
Over-loa	d during low-speed	Decrease the load during low-speed operation.			
operation	٦.	Increase the motor capacity.			
The torqu	ue compensation is too	Readjust the torque compensation value (Pr.07-26 torque compensation gain)			
large.		till the output current decreases and the motor does not stall.			
Improper	parameter settings for				
the spee	d tracking function	•	settings for speed tracking.		
(including	g restart after momentary	Start the speed tracking function.			
power lo	ss and restart after fault)	Adjust the maximum current for Pr.07-09 speed tracking.			

ID No.	Display on LED Keypad	Fa	ult Name	Description		
28	F-	Und	ler current (uC)	Low current detection		
			Action and	Reset		
	Action condition	Pr.06-71				
	Action time	Pr.06-72				
		Pr.06-73				
		0: Disabl	ed			
Fau	It treatment parameter	1: Fault and coast to stop				
		2: Fault and ramp to stop by the 2nd deceleration time				
		3: Warn and continue operation				
	Reset method		Auto "Warning" occurs when Pr.06-73 = 3. The "Warning" automatically clears when the output current is > (Pr.06-71+0.1A).			
		Manual "Error" occurs when Pr.06-73 = 1 or 2. You must reset manually.				
	Reset condition	Immedia	tely reset			
	Record	When Pr	.06-71=1 or 2,	uC is a fault, and the fault is recorded		
	Cause Corrective Actions		Corrective Actions			
Broken motor cable		Troubleshoot the connection between the motor and the load.				
Improper setting for the low current protection Set the proper settings for Pr.06-71, Pr.06-7		for Pr.06-71, Pr.06-72 and Pr.06-73.				
The load	d is too low	Check the loading status. Make sure the loading matches the motor capacity.				

ID No.	Display on LED Keypad	Fault Name	Description			
31		EEPROM read error (cF2)	Internal EEPROM cannot be read			
		Action and	I Reset			
	Action condition	Firmware internal detec	tion			
	Action time	cF2 acts immediately w	hen the drive detects the fault			
Fau	It treatment parameter	No function				
	Reset method	Manual reset				
	Reset condition	Immediately reset				
	Record	Yes				
	Cause	Corrective Actions				
		Press RESET key. If cF2 error still displays on the keypad, return to the factory				
		for repair.				
Internal EEPROM cannot be read		Reset the parameter to the default setting. If cF2 error still displays on the				
		keypad, return to the factory for repair.				
		Cycle the power, if cF2 error still exists, return to the factory for repair.				

ID No.	Display on LED Keypad	Fault Name	Description		
33		U-phase error (cd1)	U-phase current detection error when power is ON.		
		Action and	Reset		
	Action condition	Hardware detection			
	Action time	cd1 acts immediately when the drive detects the fault			
Fau	ılt treatment parameter	N/A			
	Reset method	Power-off			
	Reset condition	No function			
	Record	Yes			
Cause		Corrective Actions			
Hardware error		Cycle the power. If cd1 still exists, return to the factory for repair.			

ID No.	Display on LED Keypad	Fault Name	Description		
34		V-phase error (cd2)	V-phase current detection error when power is ON.		
		Action and	Reset		
	Action condition	Hardware detection			
	Action time	cd2 acts immediately when the drive detects the fault			
Fau	ılt treatment parameter	N/A			
	Reset method	Power-off			
	Reset condition	No function			
	Record	Yes			
	Cause Corrective Actions				
Hardware error		Cycle the power. If cd1 still exists, return to the factory for repair.			

ID No.	Display on LED Keypad	Fault Name	Description		
35		W-phase error (cd3)	W-phase current detection error when power is ON.		
		Action and	Reset		
	Action condition	Hardware detection			
	Action time	cd3 acts immediately when the drive detects the fault			
Fau	It treatment parameter	N/A			
	Reset method	Power-off			
	Reset condition	No function			
	Record	Yes			
Cause Corrective Actions		Corrective Actions			
Hardware error		Cycle the power. If cd1 still exists, return to the factory for repair.			

ID No.	Display on LED Keypad	Fault Name	Description			
36	HdI	cc hardware failure (Hd0)	cc (current clamp) power is ON.	hardware protection	error whe	
		Action and	Reset			
	Action condition	Hardware detection				
	Action time	Hd0 acts immediately when the drive detects the fault				
Fau	ılt treatment parameter	N/A				
	Reset method	Power-off				
	Reset condition	No function				
	Record	Yes				
	Cause	Corrective Actions				
Hardware error		Cycle the power. If cd1 still exists, return to the factory for repair.				

ID No.	Display on LED Keypad	Fault Name	Description		
37		oc hardware error (Hd1)	oc hardware protection error when power is ON.		
		Action and	Reset		
	Action condition	Hardware detection			
	Action time	Hd1 acts immediately when the drive detects the fault			
Fau	It treatment parameter	N/A			
	Reset method	Power-off			
	Reset condition	No function			
Record Yes					
Cause		Corrective Actions			
Hardware error		Cycle the power. If cd1 still exists, return to the factory for repair.			

ID No.	Display on LED Keypad	Fault Name	Description				
40	FILIE	Auto-tuning error (AUE)	Motor auto-tuning error				
		Action and	Reset				
	Action condition	Hardware detection					
	Action time	Immediately act					
Fau	It treatment parameter	N/A					
	Reset method	Manual reset					
	Reset condition	Immediately reset					
	Record	Yes					
	Cause	Corrective Actions					
Press STOP key during auto-tuning.		Re-execute auto-tuning.					
Incorrec	t motor capacity (too large	Check motor capacity and related parameters.					
or too sr	nall) and parameter	Set the correct parameters, that is Pr.01-01–Pr.01-02.					
setting		Set Pr.01-00 larger than the motor rated frequency.					
Incorrec	t motor wiring	Check the wiring.					
Motor lo	cked.	Troubleshoot the motor shaft lock.					
The electromagnetic contactor is							
ON at output side (U/V/W) of the		Make sure the electromagnetic valve is OFF.					
drive							
The load	l is too large	Decrease the loading. Replace with a motor with larger capacity.					
Accel./D	ecel. time is too short	Increase the setting values for Pr.01-12–01-19 (accel./ decel. time).					

ID No.	Display on LED Keypad	Fai	ult Name	Description
41	RFE		loss ACI (AFE)	PID feedback loss (analog feedback signal is only valid when the PID function is enabled.)
			Action and	Reset
	Action condition	When the analog input is lower than 4 mA (only detects analog input 4-20 mA).		
	Action time	Pr.08-08		
Fault treatment parameter 1: Fault and 2: Fault and			and continue o and ramp to sto and coast to sto and operate at	pp
	Reset method	"Warning" occurs when Pr.08-09 = 3 or 4. Auto The "Warning" automatically clears when the feedback signal larger than 4 mA. Manual "Error" occurs when Pr.08-09 = 1 or 2. You must reset manually.		
	Reset condition		tely reset	
	Record	Records when Pr.08-09 = 1 or 2 ("Error").		
	Cause Corrective Actions			Corrective Actions
Loose o	r broken PID feedback	Tighten the terminals again. Replace with a new cable.		
Feedbad	ck device malfunction	Replace with a new feedback device.		
Hardwai	re error	Check all the wiring. If AFE fault still exists, return to the factory for repair.		

ID No.	Display on LED Keypad	For	ult Name	Description		
ID NO.				·		
48			CI loss	Analog input current loss (including all analog 4–20 mA		
	/		(ACE)	signals)		
		ı	Action and	Reset		
	Action condition	When the	e analog inpu	t is lower than 4 mA (only detects analog input 4-20		
	Action condition	mA).				
	Action time	Immedia	tely act			
		Pr.03-19				
		0: Disabl	ed			
		1: Continue operation at the last frequency (a warning, the keypad displays)				
Fau	It treatment parameter	"ANL")				
		2: Decelerate to 0 Hz (warning, the keypad displays "ANL")				
		3: Stop immediately and display ACE (an error)				
		"Warning" occurs when Pr.03-19 = 1 or 2.				
		Auto	Auto The "Warning automatically clears when the analog input signal is			
	Reset method		larger than 4 mA.			
		Manual "Error" occurs when Pr.03-19 = 3. You must reset manually.				
	Reset condition		tely reset			
		Records when Pr.03-19 = 3 ("Error").				
	Record		Does not record when Pr.03-19 = 1 or 2 ("Warning").			
	Cause	, , ,				
		Tighten the terminals again.				
Loose of	Loose or broken ACI wiring		Replace with a new cable.			
External	device error	Replace with a new device.				
Hardwar	re error	Check all the wiring. If ACE still exists, return to the factory for repair.				

ID No.	Display on LED Keypad	Fault Name	Description			
49	EF	External Fault (EF)	External fault. When the drive decelerates based on the setting of Pr.07-20, the EF fault displays on the keypad			
		Action and	Reset			
	Action condition	MI = EF and the MI tern	ninal is ON.			
	Action time	Immediately act				
		Pr.07-20				
		0: Coast to stop				
		1: Stop by the first deceleration time				
Fau	ılt treatment parameter	2: Stop by the second deceleration time				
i ac	iit treatment parameter	3: Stop by the third deceleration time				
		4: Stop by the fourth deceleration time				
		5: System deceleration (according to the original deceleration time setting)				
		6: Automatic deceleration (Pr.01-46)				
	Reset method	Manual reset				
	Reset condition	Manual reset only after the external fault is cleared (terminal status is				
	Reset condition	recovered).				
	Record	ord Yes				
	Cause	Corrective Actions				
External fault Press RESET key a			the fault is cleared.			

ID No.	Display on LED Keypad	Fault Name	Description	
51	h h	External base block (bb)	When the contact of MI = bb is ON, the output stops immediately and displays bb on the keypad. The motor is in free running.	
		Action and	l Reset	
	Action condition	MI=bb and the MI terminal is ON.		
Action time		Immediately act		
Fault treatment parameter		N/A		
	Reset method	The display "bb" is automatically cleared after the fault is cleared.		
	Reset condition	No function		
Record		N/A		
Cause		Corrective Actions		
MIx = bb activates		Verify if the system is back to normal condition, and then press RESET key to return to the default.		

ID No.	Display on LED Keypad	Fault Name	Description	
52	Faad	Password is locked (Pcod)	Enter the wrong password three consecutive times	
		Action and	Reset	
	Action condition	Entering the wrong pas	sword three consecutive times	
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Power-off		
	Record	Yes		
	Cause	Corrective Actions		
		Input the correct password after rebooting the motor drive.		
		2. If you forget the password, enter 9999.		
Incorrect password input through		3. Press ENTER, and then enter 9999 again.		
Pr.00-07		4. You must finish pressing ENTER within 10 seconds. If not, you must repeat		
		the entering. After you successfully unlock the password, the parameter		
		settings return to the default.		

ID No.	Display on LED Keypad	Fault Name	Description	
54		Illegal command (CE1)	Communication command is illegal	
		Action and	Reset	
	Action condition	When the function code	is not 03, 06, 10 and 63.	
	Action time	Immediately act		
Fau	Ilt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	N/A		
	Cause	Corrective Actions		
Incorrect communication command from upper unit		Check if the communication command is correct.		
Malfunction caused by interference		Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degrees for effective anti-interference performance.		
Different communication setting Check if the setting for Pr.		Check if the setting for	Pr.09-01, Pr.09-04 are the same as the setting for the	
from the upper unit		upper unit.		
Disconnection or bad connection of the cable		Check the cable and replace it if necessary.		

ID No.	Display on LED Keypad	Fault Name	Description	
55		Illegal data address (CE2)	Data address is illegal.	
		Action and	Reset	
	Action condition	When the data address	is correct.	
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	N/A		
	Cause	Corrective Actions		
Incorrect communication command from upper unit		Check if the communication command is correct.		
Malfunc interfere	tion caused by ence	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, owire in 90 degrees for effective anti-interference performance.		
Differen	t communication setting	Check if the setting for Pr.09-01, Pr.09-04 are the same as the setting for the		
from the upper unit		upper unit.		
Disconnection or bad connection of the cable		Check the cable and replace it if necessary.		

ID No.	Display on LED Keypad	Fault Name	Description	
56		Illegal data value (CE3)	Data value is illegal	
		Action and	Reset	
	Action condition	When the length of com	munication data is too long.	
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	N/A		
	Cause	Corrective Actions		
Incorrect communication command from upper unit		Check if the communication command is correct.		
Malfunction caused by interference		Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degrees for effective anti-interference performance.		
Different communication setting Check if the setting for Pr.09-01, Pr.09-04 are the same as the setting		Pr.09-01, Pr.09-04 are the same as the setting for the		
from the upper unit		upper unit.		
Disconnection or bad connection of the cable		Check the cable and replace it if necessary.		

ID No.	Display on LED Keypad	Fault Name	Description	
	P= P= \ \	Data is written to read-		
57		only address	Data is written to read-only address.	
		(CE4)		
		Action and	d Reset	
	Action condition	When the data is writte	n to read-only address.	
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	N/A		
	Cause	Corrective Actions		
Incorrec	et communication	Check if the communication command is correct.		
commar	nd from upper unit	Check if the communication command is correct.		
Molfuno	tion caused by	Verify the wiring and gr	ounding of the communication circuit. It is	
	•	recommended to separate the communication circuit from the main circuit, or		
interference		wire in 90 degrees for effective anti-interference performance.		
Different communication setting Check if the setting for Pr.09-01, Pr.09-04 are the same as		Pr.09-01, Pr.09-04 are the same as the setting for the		
from the upper unit		upper unit.		
Disconn	ection or bad connection	Chack the cable and replace it if pagescary		
of the cable		Check the cable and replace it if necessary.		

ID No.	Display on LED Keypad	Fault Name	Description	
58		Modbus transmission time-out (CE10)	Modbus transmission time-out occurs	
		Action and	Reset	
Action condition		When the communication time exceeds the detection time for Pr.09-03 communication time-out.		
	Action time	Pr.09-03		
Fau	lt treatment parameter	Pr.09-02 0: Warn and continue of the state o		
T du	it treatment parameter	2: Fault and coast to stop 3: No Warn and continue operation		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
	Cause		Corrective Actions	
The upper unit does not transmit the communication command within Pr.09-03 setting time.		Check if the upper unit transmits the communication command within the setting time for Pr.09-03.		
Malfunction caused by interference		Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degrees for effective anti-interference performance.		
Different communication setting from the upper unit Check if the setting for Pr.09-01, Pr.09-04 are the same as the setting from the upper unit.		Pr.09-01, Pr.09-04 are the same as the setting for the		
Disconnection or bad connection		Check the cable and replace it if necessary.		

ID No.	Display on LED Keypad	Fault Name	Description	
			The slip is abnormal that use the maximum slip (Pr.10-	
	>- /		29) as the base. oSL occurs when the drive outputs at	
63		Over slip error (oSL)	the constant speed, F > H or F < H is over the level of	
			Pr.07-29, and exceed the time set by Pr.07-30. oSL	
			only occurs when using general induction motors.	
		Action and	Reset	
	Action condition	Pr.07-29 (100% of Pr.07	7-29 = Pr.10-29 upper limit of frequency deviation)	
	Action time	Pr.07-30		
		Pr. 07-31		
		0: Warn and continue operation		
Fau	It treatment parameter	1: Fault and ramp to stop		
		2: Fault and coast to stop		
		3: No warning		
	Reset method	When Pr.07-31 = 1 or 2, oSL is a "fault" and need to reset manually.		
	Reset condition	Immediately reset		
	Record	Yes		
	Cause	Corrective Actions		
Motor pa	arameter is incorrect	Check the motor parameter		
The load is too large		Reduce the load		
Check if the settings for Pr.07-29,				
Pr.07-30 and Pr.10-29 are properly		Check the parameter settings for oSL protection		
set				

ID No.	Display on LED Keypad	Fault Name	Description	
79		U-phase over-current	U-phase short circuit detected when output wiring	
79		before run (Aoc)	detection is performed before the drive runs.	
		Action and Reset		
	Action condition	240% of the rated current		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds a	fter the fault is cleared	
	Record	Yes		
	Cause		Corrective Actions	
Incorrec	t wiring for the motor	Check if the motor's internal wiring and the UVW wiring of the drive output		
incorrec	t wiring for the motor	terminal are correct.		
Short-ci	rcuit at motor output due to	Check the motor cable and remove causes of the short circuits, or replace the		
poor ins	ulation wiring	cable before turning on the power.		
Check for	or possible burnout or	Check the motor insulation value with megger. Replace the motor if the		
aging in	sulation of the motor	insulation is poor.		
Malfunc	tion caused by	Verify wiring of the control circuit, and wiring / grounding of the main circuit to		
interfere	ence	prevent interference.		
The leng	gth of motor cable is too	Increase the drive capacity.		
long		Install AC reactor(s) on the output side (U/V/W).		
		The Aoc occurs due to the short circuit or ground fault at the output side of the		
		drive.		
Hardwa	re error	Check for possible short circuits between terminals with the electric meter:		
larawa		B1 corresponds to U, V corresponds to U, V and	and W; DC- corresponds to U, V and W; 🖨 d W.	
		If short circuit occurs, re	eturn to the factory for repair.	

ID No.	Display on LED Keypad	Fault Name	Description	
80	baaa	V-phase over-current before run (boc)	V-phase short circuit detected when output wiring detection is performed before the drive runs.	
		Action and	Reset	
	Action condition	240% of the rated curre	nt	
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds a	fter the fault is cleared	
	Record	Yes		
	Cause		Corrective Actions	
Incorrec	t wiring for the motor	Check if the motor's internal wiring and the UVW wiring of the drive output		
IIICOITEC	t willing for the motor	terminal are correct.		
Short-cii	rcuit at motor output due to	Check the motor cable and remove causes of the short circuits, or replace the		
•	ulation wiring	cable before turning on the power.		
Check for	or possible burnout or	Check the motor insulation value with megger. Replace the motor if the		
	sulation of the motor	insulation is poor.		
Malfunc	tion caused by	Verify wiring of the control circuit, and wiring/grounding of the main circuit to		
interfere	ence	prevent interference.		
The leng	gth of motor cable is too	Increase the drive capacity.		
long		Install AC reactor(s) on the output side (U/V/W).		
		The Boc occurs due to the short circuit or ground fault at the output side of the		
		drive.		
Hardwai	re error	Check for possible shor	t circuits between terminals with the electric meter:	
		B1 corresponds to U, corresponds to U, V and	V and W; DC- corresponds to U, V and W; $\stackrel{\left(\stackrel{\cdot}{\Longrightarrow}\right)}{\Longrightarrow}$ d W.	
		If short circuit occurs, return to the factory for repair.		

ID No.	Display on LED Keypad	Fault Name	Description	
81		W-phase over-current before run (Coc)	W-phase short circuit detected when output wiring detection is performed before the drive runs.	
		Action and	l Reset	
	Action condition	240% of the rated curre	nt	
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds a	fter the fault is cleared	
	Record	Yes		
	Cause	Corrective Actions		
Incorrec	t wiring for the motor	Check if the motor's internal wiring and the UVW wiring of the drive output terminal are correct.		
Short-cii	cuit at motor output due to	Check the motor cable and remove causes of the short circuits, or replace the		
poor ins	ulation wiring	cable before turning on the power.		
Check fo	or possible burnout or	Check the motor insulation value with megger. Replace the motor if the		
aging in	sulation of the motor	insulation is poor.		
Malfunctinterfere	tion caused by nce	Verify wiring of the control circuit, and wiring/grounding of the main circuit to prevent interference.		
The leng	gth of motor cable is too	Increase the drive capacity.		
long		Install AC reactor(s) on the output side (U/V/W).		
Hardware error		The Coc occurs due to the short circuit or ground fault at the output side of the drive. Check for possible short circuits between terminals with the electric meter: B1 corresponds to U, V and W; DC- corresponds to U, V and W;		
		corresponds to U, V and If short circuit occurs, re	d W. eturn to the factory for repair.	

ID No.	Display on LED Keypad	Fault Name	Description	
82	mFL (Output phase loss U phase (oPL1)	U phase output phase loss	
		Action and Reset		
	Action condition	Pr.06-47		
		Pr.06-46		
	Action time	Pr.06-48: Use the set activates, use that of Pr	tting value of Pr.06-48 first. If DC braking function :06-46.	
		Pr.06-45		
		0: Warn and continue o	peration	
Fau	Ilt treatment parameter	1: Fault and ramp to sto		
		2: Fault and coast to stop		
		3: No warning		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	When Pr.06-45=1 or 2, OPL1 is a "Fault", and the fault is recorded.		
	Cause	Corrective Actions		
	nced three-phase nce of the motor	Replace the motor.		
Check if	the wiring is incorrect.	Check the cable. Replace the cable. Check the motor's internal wiring. If the fault still exists, replace the motor.		
	Check if the motor is a single- phase motor. Choose a three-phase motor.		motor.	
Check if broken.	the current sensor is	Check if the control board cable is loose. If yes, reconnect the cable and run the drive to test. If the error still occurs, send the drive back to the factory for repair. Check if the three-phase current is balanced with a current clamp meter. If the current is balanced and the OPHL error still shows on the display, send the drive back to the factory for repair.		
Check if the drive capacity is larger than the motor capacity drive back to the factory for repair. Choose the drive that matches the motor capacity.				

ID No.	Display on LED Keypad	Fault Name	Description	
83	afili	Output phase loss V phase (oPL2)	V phase output phase loss	
		Action and Reset		
	Action condition	Pr.06-47		
	Action time	Pr.06-46 Pr.06-48: Use the setting value of Pr.06-48 first. If DC braking function activates, use that of Pr.06-46.		
Fault treatment parameter		Pr.06-45 0: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	When Pr.06-45 = 1 or 2, OPL1 is a "Fault", and the fault is recorded.		
	Cause	Corrective Actions		
	ced three-phase	Replace the motor.		
Check if	the wiring is incorrect.	Check the cable. Replace Check the motor's interest	ce the cable. nal wiring. If the fault still exists, replace the motor.	
Check if phase m	the motor is a single- notor.	Choose a three-phase motor.		
Check if broken.	the current sensor is	Check if the control board cable is loose. If yes, reconnect the cable and runthe drive to test. If the error still occurs, send the drive back to the factory for repair. Check if the three-phase current is balanced with a current clamp meter. If the current is balanced and the OPHL error still shows on the display, send the drive back to the factory for repair.		
Check if the drive capacity is larger than the motor capacity Choose the drive that matches the motor capacity.				

ID No.	Display on LED Keypad	Fault Name	Description	
ID NO.	Display on LED Reypau	Output phase loss W	Description	
84	of L H	• •	W phase output phase loss	
04		phase	W phase output phase loss	
		(oPL3) Action and	I Ponet	
	A stice condition		reset	
	Action condition	Pr.06-47		
	A	Pr.06-46	W	
	Action time		tting value of Pr.06-48 first. If DC braking function	
		activates, use that of Pr	:06-46.	
		Pr.06-45		
		0: Warn and continue of		
Fau	It treatment parameter	1: Fault and ramp to sto	•	
		2: Fault and coast to stop		
		3: No warning		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	When Pr.06-45 = 1 or 2, OPL1 is a "Fault", and the fault is recorded.		
	Cause		Corrective Actions	
	ced three-phase	Replace the motor.		
impedar	nce of the motor			
Check if	the wiring is incorrect.	Check the cable. Replace the cable.		
Officer ii	the willing is incorrect.	Check the motor's internal wiring. If the fault still exists, replace the motor.		
Check if	the motor is a single-	Choose a three-phase motor.		
phase m	notor.			
		Check if the control box	ard cable is loose. If yes, reconnect the cable and run	
Check if the current sensor is broken.		the drive to test. If the error still occurs, send the drive back to the factory for		
		repair.		
		Check if the three-phase current is balanced with a current clamp meter. If the		
		current is balanced and the OPHL error still shows on the display, send the		
		drive back to the factory for repair.		
Check if the drive capacity is		Choose the drive that m	natches the motor canacity	
larger than the motor capacity		Choose the drive that matches the motor capacity.		

ID No.	Display on LED Keypad	Fault Name	Description	
87	al A	Low frequency overload protection (oL3)	Low frequency and high current protection	
		Action and	Reset	
	Action condition	Software detection		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
	Cause	Corrective Actions		
		Reduce the motor drive's load.		
		2. Decrease the carrier frequency (Pr.00-17).		
Power n	Power module overload	3. Enhance the heat dissipation capacity for the cabinet.		
I OWEI III		4. Increases acceleration time.		
		5. Choose motor drives with lager power.		
		6. Lower the limited value of current (Pr.06-03, 06-04).		

ID No.	Display on LED Keypad	Fault Name	Description	
89	rafid	Rotor position detection error (RoPd)	Rotor position detection error protection	
		Action and	Reset	
	Action condition	Reset the software		
	Action time	Immediately act		
Fau	Ilt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
Cause		Corrective Actions		
Check if the motor cable is abnormal or broken		Check or replace the cable.		
Motor coil error		Replace the motor.		
Hardware error		IGBT broken. Return to the factory for repair.		
Drive's current feedback line error		Cycle the power. If RoPd still occurs during operation, return to the factory for repair.		

ID No.	Display on LED Keypad	Warning Name	Description	
90		Force to stop (FStp)	Keypad forces PLC to Stop	
		Action and	d Reset	
Action condition		When Pr. 00-32=1, STOP button on the keypad is valid. When giving the STOP command during the PLC operation, FStp fault occurs.		
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Can be reset after shutdown		
	Record	Yes		
	Detection time	Detect when powering ON		
Cause		Corrective Actions		
Pr. 00-32=1:		Check if it is necessary to set Pr. 00-32=0, so the keypad STOP button is		
keypad STOP button is valid		invalid.		
Press STOP button during PLC operation		Verify the timing of STOP function.		

ID No.	Display on LED Keypad	Fault Name	Description	
98	F- 1 - 12	Fire mode output (Fire)	Display when fire mode is triggered	
		Action and	Reset	
	Action level	MIx = 58 is triggered an	d run, or MIx = 59 is triggered	
	Action time	Immediately act		
Гои	It to almost a area at a	Refer to Pr.06-81, Pr.06-88 to set the operating frequency and the operation		
Fau	It treatment parameter	times in fire mode		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds after the fault is cleared		
Record		Yes		
Cause		Corrective Actions		
MIx = 58 is triggered and run, or		If it is triggered in four minutes, then cancel MI setting.		
MIx = 59 is triggered		If it is triggered over four minutes, then re-power ON.		

ID No.	Display on LED Keypad	Fault Name	Description	
140	HdE	oc hardware error (Hd6)	The ground current short circuit detected when power is ON.	
		Action and	Reset	
	Action condition	Software detection		
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
	Cause		Corrective Actions	
The length of motor cable is too long.		Use a shorter cable or install an output reactor.		
Check if the motor cable is abnormal or broken Check or replace the cable.		able.		
Hardware error		IGBT broken. Return to the factory for repair.		
Drive's current feedback line error		Cycle the power. If Hd6 still occurs during operation, return to the factory for repair.		

ID No.	Display on LED Keypad	Fault Name	Description	
4.44		GFF occurs before run	The ground short circuit detected when output wiring	
141		(b4GFF)	detection is performed before the drive runs.	
		Action and	Reset	
	Action condition	240% of the rated curre	nt	
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds after the fault is cleared		
	Record	Yes		
	Cause		Corrective Actions	
In an area	A wining for the meeter	Check if the motor's internal wiring and the UVW wiring of the drive output		
Incorrect wiring for the motor		terminal are correct.		
Short-circuit at motor output due to		Check the motor cable and remove causes of the short circuits, or replace the		
poor insulation wiring		cable before turning on the power.		
Check for possible burnout or		Check the motor insulation value with megger. Replace the motor if the		
aging insulation of the motor		insulation is poor.		

ID No.	Display on LED Keypad	Fault Name	Description	
142		Auto-tuning error (AUE1)	No feedback current error when motor parameter automatically detects.	
		Action and	Reset	
	Action condition	Software detection		
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
	Cause		Corrective Actions	
Motor is not wired		Check the wiring.		
The electromagnetic contactor is				
ON at output side (U/V/W) of the		Make sure the electromagnetic valve is OFF.		
drive				

ID No.	Display on LED Keypad	Fault Name	Description	
143		_	Motor phase loss error when motor parameter automatically detects.	
		Action and	Reset	
	Action condition	Software detection		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
	Cause	Corrective Actions		
Incorrec	t motor wiring	Check the wiring.		
Motor e	rror	Check if the motor works normally.		
The electromagnetic contactor is				
ON at output side (U/V/W) of the		Verify that the three-phases of the electromagnetic valve are all closed.		
drive				
Motor U/V/W wire error		Check if the wires are broken.		

ID No.	Display on LED Keypad	Fault Name	Description	
144	AUEE	l	No load current I0 measurement error when motor parameter automatically detects.	
		Action and	Reset	
	Action condition	Software detection		
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
Cause		Corrective Actions		
Incorrect settings for the motor parameter (rated current)		Check the settings for Pr.05-01 / Pr.05-13 / Pr.05-34.		
Motor error		Check if the motor works normally.		

ID No.	Display on LED Keypad	Fault Name	Description	
221	HPG	High water pressure (HPS)	The water pressure is Higher than the setting	
		Action and	Reset	
	Action condition	The feedback pressure is higher than the setting in Pr.12-79, and continues as the time setting in Pr.12-79.		
	Action time	Pr.12-80		
Warr	ning setting parameter	Pr.12-81 1: Fault and coast to stop 2: Fault and ramp to stop		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
Record		Yes		
Cause		Corrective Actions		
Pressure sensor is broken		Change the pressure sensor.		
The disconnection frequency setting of pump is too high		Decrease the setting value in Pr.12-12		

ID No.	Display on LED Keypad	Fault Name	Description	
222		Low water pressure (LPSE)	The water pressure is lower than the setting	
		Action and I	Reset	
	Action condition	The feedback pressure is lower than the setting in Pr.12-82, and continues as the time setting in Pr.12-83.		
	Action time	Pr.12-83		
Fault treatment parameter		Pr.12-84 1: Fault and coast to stop 2: Fault and ramp to stop		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
Record		Yes		
Cause		Corrective Actions		
No water	pressure	Check if water leakage occurs in pipe, or no water inputs		
Pressure sensor is broken		Change the pressure sensor.		

Chapter 14 Fault Codes | MPD

ID No.	Display on LED Keypad	Fault Name	Description	
223	druE	Dry pump (dryE)	Dry pump continues when the restart times is larger than the setting in Pr.12-71	
		Action and	Reset	
	Action condition	The power corresponds	s to the target frequency is under the dry pump curve.	
	Action time	Pr.12-69		
Faul	t treatment parameter	Fault and coast to stop		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
Record		Yes		
Cause		Corrective Actions		
The inlet of the water pump is broken		Check if the pipe is brol	ken, or no water input.	

ID No.	Display on LED Keypad	Fault Name	Description	
224		Water leaking (pipe explosion) (LEKE)	Triggered when heavy water leakage is detected	
		Action and	Reset	
	Action condition	The feedback pressure current is larger than the	e is lower than the setting in Pr.12-73, and the load e setting in Pr.12-75	
	Action time	Pr.12-74		
Faul	t treatment parameter	Pr.12-76 1: Fault and coast to stop 2: Fault and ramp to stop		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
Record		Yes		
	Cause	Corrective Actions		
The outlet of the water pump is broken		Check if the pipe is broken.		

Chapter 14 Fault Codes | MPD

			T	
ID No.	Display on LED Keypad	Fault Name	Description	
225		Clogged pipe (JAME)	The jam current is still higher than Pr.12-54 after finishing the cleaning process	
		Action and	Reset	
Action condition		The current is still larger than then setting in Pr.12-54 when the cleaning times reaches the setting in Pr.12-58.		
Action time		No function		
Faul	t treatment parameter	Immediately coast to stop		
	Reset method	Manual reset		
Reset condition		Immediately reset		
Record		Yes		
Cause		Corrective Actions		
The pump vane is stuck by foreign matter		The clean function cannot clear the foreign matter, you have to clear it manually.		
matter		inandany.		

ID No.	Display on LED Keypad	Fault Name	Description	
226		RTC error	Remind user that there is hardware problem of the	
		(rtF)	perpetual calendar	
		Action and	Reset	
	Action level	No function		
	Action time	Immediately displays when the fault is detected		
Faul	t treatment parameter	N/A		
	Reset method	No function		
	Reset condition	Power OFF and then power ON again		
Record		Yes		
Cause		Corrective Actions		
Hardware problem of the perpetual		Power ON again, if it doesn't work, contact with dealer or original		
calendar		manufacturer.		

Chapter 14 Fault Codes | MPD

ID No.	Display on LED Keypad	Fault Name	Description	
227		Dry pump curve auto- measuring (dAUE)	The high speed power cannot lower than the low speed power, and cannot over the drive power. Give STOP command when fault occurs during autodetection. High speed power Pr.12-67; low speed power Pr.12-66	
		Action and	Reset	
Action condition		The power after adjusting does not comply with the power value		
Action time		Immediately act		
Faul	t treatment parameter	Fault and coast to stop		
	Reset method	Manual reset		
Reset condition		Immediately reset, does not memorize parameter		
Record		Yes		
	Cause	Corrective Actions		
The value auto-detect by the dry		Restart the auto-tuning load curve, set Pr.12-65 = 1 to execute the auto-		
pump curve is abnormal		tuning.		

Chapter 15 PLC Function Applications

- 15-1 PLC Summary
- 15-2 Notes before Using PLC
- 15-3 Start-up
- 15-4 Basic Principles of PLC Ladder Diagrams
- 15-5 Functions of Various PLC Devices
- 15-6 Introduction to the Functions of Instructions
- 15-7 Fault Display and Treatment
- 15-8 Explanation of Speed Mode Control with PLC
- 15-9 The Applications for Remote IO Control of Modbus (Use MODRW)
- 15-10 RTC (real-time clock)
- 15-11 Enable The Built-in PLC Function of MPD
- (Scheduled Function, Multi-master Function)
- 15-12 Function Block Diagram (FBD)

15-1 PLC Summary

15-1-1 Introduction

The commands provided by the MP300's built-in PLC functions, including the ladder diagram editing tool WPLSoft, as well as the usage of basic commands and applications commands, mainly retain the operating methods of Delta's PLC DVP series.

15-1-2 WPLSoft Ladder Diagram Editing Tool

WPLSoft is a program editing software used under WINDOWS operating system in Delta's DVP Series PLC for MP300. WPLSoft not only provides functions of PLC program planning and Windows editing (such as cut, paste, copy, multi-window, etc.), but also Chinese / English notes editing function and other useful functions like register editing & setting, file reading & saving, as well as points diagram monitoring and setting, and so on.

Minimum system requirements for installing WPLSoft software:


Item	System Requirements		
Operating System	Windows 95 / 98 / 2000 / NT / ME / XP		
CPU	Pentium 90 above		
Storage	16MB above (32MB above recommended)		
Duine	Disk space: 100MB above at a minimum		
Drive	An optical disc drive (for installing WPLSoft)		
Dioploy	Resolution: 640 × 480, 16 colors above. It is recommended to set screen		
Display	width × height to 800 × 600 pixels.		
Mouse	Mouse for general purposes or compatible with Windows		
Printer	Printers with Windows drivers		
RS-485 Port	At least one RS-485 port that can be connected with PLC		

15-2 Notes before Using PLC

1. MP300 provides COM2 port to upload / download PLC programs. See the figure below.

The PLC has a preset communications format of 7, N, 2, 9600, with node 100; the PLC node can be changed in Pr. 09-35, but this address may not be the same as the drive's address setting of Pr. 09-00.

When the built-in PLC is ON, the communication format of COM1 automatically sets as 115200, 8, E, 1 RTU for connecting multi-pump in serial.



- 2. The client can simultaneously access data from the converter and internal PLC, which is performed through identification of the node. For instance, if the converter node is 1 and the internal PLC node is 2, then the client command will be
 - 01 (node) 03 (read) 0400 (address) 0001 (1 data item), indicating that it must read the data in converter Pr. 04-00
 - 02 (node) 03 (read) 0400 (address) 0001 (1 data item), indicating that it must read the data in internal PLC X0
- 3. The PLC program will be disabled when uploading / downloading programs.
- 4. When using WPR commands to write in parameters, note that allowable maximum number of times to change is 10⁹. Otherwise, a memory writing error may occur. The number of times to change depends on the writing value to be changed. If the writing value is not changed, the number of times will not be counted accumulatively; if the writing value is different from the last time, it will be counted as one time.
- 5. When Pr. 00-04 is set as 28, the displayed value will be the value of PLC register D1043.
- 6. In the PLC Run (PLC1) and PLC Stop (PLC1) mode, the content 9 and 10 of Pr. 00-02 cannot be set and cannot be reset to the default value.
- 7. If PLC function is OFF (PLC0), PLC can return to the default when Pr.00-02 = 6.
- 8. The corresponding MI function will be disabled when the PLC writes to input contact X.

Chapter 15 PLC Function Applications | MPD


- 9. When the PLC controls converter operation, control commands will be entirely controlled by the PLC and will not be affected by the setting of Pr. 00-21.
- 10. When the PLC controls converter frequency commands (FREQ commands), frequency commands will be entirely controlled by the PLC, and will not be affected by the setting of Pr.00-20 or the Hand ON / OFF configuration.
- 11. When the PLC controls converter operation, if the keypad Stop setting is valid, this will trigger an FStP error and cause stoppage.

15-3 Start-up

15-3-1 Connect to PC

Start operation of PLC functions in accordance with the following steps

1. Wiring: Connect the drive's RJ45 communications interface to a PC via the RS-485.



2. PLC function usage



Enter to PLC mode to set PLC1 PLC0: Disable PLC function

PLC1: Trigger PLC RUN PLC2: Trigger PLC STOP

• When the external multifunctional input terminals (MI1–MI4) are in PLC Mode select bit0 (51) or PLC Mode select bit1 (52), and the terminal contact is closed or opened, it will compulsorily switch to the PLC mode, and keypad switching will be ineffective. Corresponding actions are as follows:

PLC mode	PLC Mode select bit1 (52)	PLC Mode select bit0 (51)
Disable	OFF	OFF
PLC Run	OFF	ON
PLC Stop	ON	OFF
Maintain previous state	ON	ON

Note:

- 1. When input / output terminals (MI1–MI4, Relay1, Relay2, MO) are included in the PLC program, these input / output terminals will only be used by the PLC. As an example, when the PLC program controls Y0 during PLC operation (PLC1 or PLC2), the corresponding output terminal relay (RA / RB / RC) will operate in accordance with the program. At this moment, the multifunctional input/ output terminal setting will be ineffective. Because these terminal functions are already being used by the PLC, the DI / DO / AO in use by the PLC can be determined by looking at Pr.02-52, Pr.02-53, and Pr.03-30.
- 2. When the PLC's procedures use special register D1040, the corresponding AO contact AFM1 will be occupied.
- 3. Pr. 03-30 monitors the state of action of the PLC function analog output terminal.

15-3-2 I/O Device Correspondence


Input devices:

PLC Input relay	X0	X1	X2	Х3
AC motor drive input terminal	MI1	MI2	MI3	MI4

Output devices

PLC Output relay	Y0	Y1	Y2	Y3
AC motor drive output terminal	RY1	RY2		МО

RY1 / RY2



15-3-3 WPLSoft Installation

Visit the download center at Delta's website to download and install the software WPLSoft: After finishing installation, WPLSoft program will be created in the specified default sub-directory under "C:\Program Files\Delta Industrial Automation\WPLSoft x.xx".

15-3-4 Program Writing

Step 1. Click on the WPLSoft icon to start the editing software (see Figure 15-1).






Figure 15-1 (Left: WPLSoft icon; right: WPLSoft starting page)

Step 2: **WPLsoft Editor** window appears (see Figure 15-2). When running WPLSoft for the first time, as there is no existing file, only **File (F)**, **Communication (C)**, **View (V)**, **Options (O)**, and **Help (H)** are available on the function menu.




Figure 15-2

NOTE: When starting WPLSoft for the second time, the last editing file will be opened directly and displayed in the editor window. WPLSoft editor window is described as Figure 15-3.




Figure 15-3

Step 3. Click on the button on the toolbar: **New (Ctrl+N)** to open a new file, as Figure 15-4 shows.



Figure 15-4

NOTE: You can also select New (Ctr+N) under function menu File (F) to open a new file.



Figure 15-5

Step 4. **Select a PLC Model** window will then appear (see Figure 15-6). Set **Program Title**, **File Name**, **Model Type**, **VFD Type**, and **Communication Setting**.



Figure 15-6

Communication Setting: Set the communication method as required (see Figure 15-7).




Figure 15-7

Step 5. After settings are finished, click **OK** to start editing the programs. Methods of editing programs: 1. **Instruction List Mode** and 2. **Ladder Diagram Mode**, as Figure 15-8 shows. Use the method as required.




Figure 15-8

NOTE: In the ladder diagram mode, you can edit programs using buttons on the ladder diagram toolbar (see Figure 15-9).




Figure 15-9

Example of Basic Operation

Input a ladder diagram as Figure shows below. The following steps show how to use mouse and keypad functions (F1 to F12) to edit programs.

```
M10 ( Y0 ) END
```

Figure 15-10

Step 1. Create a new file, and then the page below appears.




Figure 15-11

Step 2. Click Normally Open Contact button or press function key F1. Input Device Instruction window appears. Select Device Name (e.g. M), Device Number (e.g. 10), and type Comment (e.g. Auxiliary coil). Then, click OK to finish settings, as Figure 15-12, 15-13 shows.




Figure 15-12




Figure 15-13

Step 3. Click Output Coils button or press function key F7. Input Device Instruction window appears. Select Device Name (e.g., M), Device Number (e.g., 0), and type Comment (e.g., Auxiliary coil). Then, click OK to finish settings, as Figure 15-14, 15-15 shows.




Figure 15-14




Figure 15-15

Step 4. Press ENTER key, and then an Input Instruction window appears. Type "END" in the field, and then click **OK**, as Figure 15-16, 15-17 shows.




Figure 15-16




Figure 15-17

Step 5. Click Ladder Diagram=>Command button to convert the edited ladder diagram to the commands. After compiling is finished, the number of rungs (steps) appear on the left side of the busbar, as Figure 15-18 shows.




Figure 15-18

15-3-5 Program Downloading

After a program was input using WPLSoft, click **Compile** button. After compiling is finished, click **Download** button to download the programs. WPLSoft downloads the program to the online PLC in the communication format that you specified for the communication settings.

15-3-6 Program Monitoring


After downloading the program, make sure that the PLC is in Run mode. On the Communications menu, click Online Mode button, and then click Start Ladder Diagram Control, as the figure below shows. This allows you to monitor and operate the ladder diagram while online.



15-4 Basic Principles of PLC Ladder Diagrams

15-4-1 Schematic diagram of PLC ladder diagram program scanning

Output results are calculated on the basis of the ladder diagram configuration (internal devices will have real-time output before results are sent to an external output point)



Implement the program repeatedly

15-4-2 Introduction to ladder diagrams

Ladder diagrams comprise a graphic language widely applied in automatic control, and employs common electrical control circuit symbols. After a ladder diagram editor has been used to create a ladder pattern, PLC program designed is completed. The use of a graphic format to control processes is very intuitive, and is readily accepted by personnel who are familiar with electrical control circuit technology. Many of the basic symbols and actions in a ladder diagram comprise commonly seen electrical devices in conventional automatic control power distribution panels, such as buttons, switches, relays, timers, and counters.

Internal PLC devices: The types and quantities of internal PLC devices vary in different brands of products. Although these internal devices use the same names as conventional electrical control circuit elements such as relays, coils, and contacts, a PLC does not actually contain these physical devices, and they instead correspond to basic elements in the PLC's internal memory (bits). For instance, if a bit is 1, this may indicate that a coil is electrified, and if that bit is 0, it will indicate that the coil is not electrified. An N.O. contact (Normal Open, or contact a) can be used to directly read the value of the corresponding bit, and an N.C. contact (Normal Close, or contact b) can be used to obtain the inverse of the bit's value. Multiple relays occupy multiple bits, and 8 bits comprise one byte; two bytes comprise one word, and two words comprise a double word. When multiple relays are processing at the same time (such as addition / subtraction or displacement, etc.), a byte, word, or double word can be used. Furthermore, a PLC contains two types of internal devices: a timer and a counter. It not only has a coil, but can count time and numerical values. Because of this, when it is necessary to process some numerical values, these values are usually in the form of bytes, words, or double words.

The various internal devices in a PLC all account for a certain quantity of storage units in the PLC's storage area. When these devices are used, the content of the corresponding storage area is read in the form of bits, bytes, or words.

Device type	Function
Input relay	An input relay constitutes the basic unit of storage in a PLC's internal memory corresponding to an external input point (which serves as a terminal connecting with an external input switch and receiving external input signals). It is driven by external input signals, to which it assigns values of 0 or 1. A program design method cannot change the input relay status, and therefore cannot rewrite the corresponding basic units of an input relay, and WPLSoft cannot be used to perform compulsory ON / OFF actions. A relay's contacts (contacts a and b) can be used an unlimited number of times. An input relay with no input signal must be left idle and cannot be used for some other purpose. Device indicated as: X0, X1, X7, X10, X11, etc. This device is expressed with the symbol "X", and a device's order is indicated with an octal number. Refer to Chapter 15-3-2 I/O device explanation for input point numbers.
Output relay	An output relay constitutes the basic unit of storage in a PLC's internal memory corresponding to an external output point (which connects with an external load). It may be driven by an input relay contact, a contact on another internal device, or its own contacts. It uses one NO contact to connect with external loads or other contacts, and, like input contacts, can use the contact an unlimited number of times. An output relay with no input signal will be idle, but may be used an internal relay if needed. Device indicated as: Y0, Y1,Y7, Y10, Y11,etc. This device is expressed with the symbol "Y", and a device's order is indicated with an octal number.
Internal auxiliary relay	Refer to Chapter 15-3-2 I/O device explanation for output point numbers. Internal relays have no direct connection with the outside. These relays are auxiliary relays inside a PLC. Their function is the same as that of an auxiliary (central) relay in an electrical control circuit: Each auxiliary relay corresponding to a basic unit of internal storage; they can be driven by input relay contacts, output relay contacts, and the contacts of other internal devices. An internal auxiliary relay's contact can also be used an unlimited number of times. Internal auxiliary relays have no outputs to outside, and must output via an output point. Device indicated as: M0, M1 to M799, etc. This device is expressed as the symbol "M", and its order is expressed as a decimal number.
Counter	A counter is used to perform counting operations. A count setting value (such as the number of pulses to be counted) must be assigned when a counter is used. A counter contains a coil, contact, and a counting storage device. When the coil goes from OFF to ON, this indicates that the counter has an input pulse, and the count value plus one. There are 16 bits that can be employed by the user.

	 Device indicated as: C0, C1 to C79, etc. This device is expressed as the symbol "C", and its order is expressed as a decimal number.
Timer	A timer is used to complete control of timing. The timer contains a coil, contact, and a time value register. When the coil is electrified, if the preset time is reached, the contact will be actuated (contact a will close, contact b will open), and the timer's fixed value will be given by the set value. Timer has a regulated clock cycle (timing units: 100 ms). As soon as power to the coil is cut off, the contact will no longer be actuated (contact a will open, contact b will close), and the original timing value will return to zero.
	 Device indicated as: T0, T1 to T159, etc. The device is expressed as the symbol "T", and its order is expressed as a decimal number.
Data register	When a PLC is used to perform various types of sequence control and set time value and count value control, it most commonly perform data processing and numerical operations, and data registers are used exclusively for storage of data and various parameters. Each data register contains 16 bits of binary data, which means that it can store one word. Two data registers with adjacent numbers can be used to process double words. • Device indicated as: D0, D1 to D399, etc. The device is expressed as the symbol "D", and its order is expressed as a decimal number.

Ladder diagram images and their explanation


Ladder diagram structures	Explanations	PLC instructions	Device for using
	NO switch, contact a	LD	X, Y, M, T, C
N	NC switch, contact b	LDI	X, Y, M, T, C
	Series NO	AND	X, Y, M, T, C
	Series NC	ANI	X, Y, M, T, C
	Parallel NO	OR	X, Y, M, T, C
	Parallel NC	ORI	X, Y, M, T, C
	Positive edge-triggered switch	LDP	X, Y, M, T, C
	Negative edge-triggered switch	LDF	X, Y, M, T, C
	Positive edge-triggered series	ANDP	X, Y, M, T, C
	Negative edge-triggered series	ANDF	X, Y, M, T, C
	Positive edge-triggered parallel	ORP	X, Y, M, T, C


Negative edge-triggered parallel	ORF	X, Y, M, T, C
Block series	ANB	N/A
Block parallel	ORB	N/A
Multiple outputs	MPS MRD MPP	N/A
 Coil driven output commands	OUT	Y, M
Some basic commands, applications commands	Some are PLC basic instructions, some are PLC application instructions	Refer to the descriptions of each application
Inverted logic	INV	N/A

15-4-3 Key points for editing PLC ladder diagram

The program editing method begins from the left busbar and proceeds to the right busbar (the right busbar is omitted when editing using WPLSoft). Continue to the next row after completing each row; there is a maximum of 11 contacts on each row. If this is not sufficient, a continuous line will be generated to indicate the continued connection and more devices can be added. A continuous series of numbers will be generated automatically and identical input points can be used repeatedly. See diagram below.


The ladder diagram programming method involves scanning from the upper left corner to the lower right corner. The coils and applications command-computing box are handled in the output, and the ladder diagram is placed on the farthest right. Take the figure below as an example, we can gradually analyze the procedural sequence of the ladder diagram. The number in the upper right corner gives the sequential order.






Explanations of basic structure of ladder diagrams

LD (LDI) command: a command that gives LD or LDI at the beginning of a block



LDP and LDF have the same command structure, but there are differences in their action state. LDP, LDF only act at the rising or falling edge of a conducting contact. See diagram below.




AND (ANI) command: a series configuration in which a single device is connected with one device or a block.




ANDP and ANDF have the same command structure, but their action occurs at the rising and falling edge.

OR (ORI) command: a single device is connected with one device or a block.




ORP and ORF have the same command structure, but their action occurs at the rising and falling edge.

ANB command: A configuration in which one block is in series with one device or block.



ORB command: A configuration in which one block is in parallel with one device or block.



In the case of ANB and ORB operations, if a number of blocks are connected, they should be combined to form a block or network from the top down or from left to right.


MPS, MRD, MPP commands: Branching point memory for multiple outputs, enabling multiple, different outputs.

MPS command begins at a branching point, where the so-called branching point refers to the intersection of horizontal and vertical lines. We have to rely on the contact status along a single vertical line to determine whether the next contact can give a memory command. While each contact is basically able to give memory commands, in view of convenience and the PLC's capacity restrictions, this can be omitted from some places when converting a ladder diagram. The structure of the ladder diagram can be used to judge what kinds of contact memory commands are used.

MPS can be distinguished by use of the "T" symbol; this command can be used consecutively for up to 8 times. MRD command is read from branching point memory; because logic states along any one vertical line must be the same, in order to continue analysis of other ladder diagrams, the original contact status must be read.

MRD can be distinguished by use of the " |-" symbol. MPP command is read from the starting state of the uppermost branching point, and it is read from the stack (pop); because it is the final command along a vertical line, it indicates that the state of the vertical line can be concluded.

MPP can be distinguished by use of the "L" symbol. Although there should basically be no errors when using the foregoing analytical approach, the compiling program may sometimes omit identical state output, as shown in the following figure:




15-4-4 Commonly used basic program design examples

Start, stop, and protection

Some applications may require a brief close or brief break using the buttons to start and stop equipment. A protective circuit must therefore be designed to maintain continued operation in these situations; this protective circuit may employ one of the following methods:


Example 1: Priority stop protective circuit

When the start NO contact X1 = ON, and the stop NC contact X2 = OFF, Y1 = ON; if X2 = ON at this time, coil Y1 will no longer be electrified, and this is therefore referred to as priority stop.



Example 2: Priority start protective circuit

When start NO contact X1 = ON, and the stop NC contact X2 = OFF, Y1 = ON, and coil Y1 will be electrified and protected. At this time, if X2 = ON, coil Y1 will still protect the contact and continue to be electrified, and this is therefore priority start.




Example 3: Setting (SET) and reset (RST) command protective circuit

The following figure shows a protective circuit composed of RST and SET commands.

Priority stop occurs when the RST command is placed after the SET command. Because the PLC executes programs from the top down, at the end of the program, the state of Y1 will indicate whether coil Y1 is electrified. When X1 and X2 are both actuated, Y1 will lose power, and this is therefore priority stop.


Priority start occurs when the SET command is placed after the RST command. When X1 and X2 are both actuated, Y1 will be electrified, and this is therefore priority start.



Commonly used control circuits


Example 4: Conditional control

X1, X3 are respectively start/ stop Y1, and X2 & X4 are respectively start / stop Y2; all have protective circuits. Because Y1's NO contact is in series with Y2's circuit, it becomes an AND condition for the actuation of Y2. The action of Y1 is therefore a condition for the action of Y2, and Y1 must be actuated before Y2 can be actuated.




Example 5: Interlocking control

The figure below shows an interlocking control circuit. Depending on which of the start contacts X1, X2 is valid first, the corresponding output Y1 or Y2 will be actuated, and when one is actuated, the other will not be actuated. This implies that Y1 and Y2 cannot be actuated at the same time (interlocking effect). Even if both X1 and X2 are valid at the same time, because the ladder diagram program is scanned from the top down, it is impossible for Y1 and Y2 to be actuated at same time. This ladder diagram assigns priority only to Y1.



Example 6: Sequence control


If the NC contact of Y2 in the interlocking control configuration of example 5 is put in series with the Y1 circuit, so that it is an AND condition for actuation of Y1 (see figure below), not only is Y1 a condition for the actuation of Y2 in this circuit, the actuation of Y2 will also stop the actuation of Y1. This configuration confirms the actuation order of Y1 and Y2.



Example 7: Oscillating circuit


Oscillating circuit with a period of $\Delta T + \Delta T$

The figure below shows a very simple ladder diagram. When starting to scan the Y1 NC contact, because the Y1 coil has lost power, the Y1 NC contact will be closed. When the Y1 coil is then scanned, it will be electrified, and the output will be 1. When the Y1 NC contact is scanned in the scanning cycle, because Y1 coil is electrified, the Y1 NC contact will be opened, the Y1 coil will then lose power, and the output will be 0. Following repeated scanning, the output of Y1 coil will have an oscillating waveform with a period of ΔT (ON) $+\Delta T$ (OFF).




Oscillating circuit with a period of nT+ΔT

The program of the ladder diagram shown below uses timer T0 to control coil Y1's electrified time. After Y1 is electrified, it causes timer T0 to close during the next scanning cycle, which will cause the output from Y1 to have the oscillating waveform shown in the figure below. Here n is the timer's decimal setting value, and T is the clock cycle of the timer.



Example 8: Flashing circuit


The following figure shows an oscillating circuit of a type commonly used to cause an indicator light to flash or a buzzer to buzz. It uses two timers to control the On and Off time of Y1 coil. Here n1, n2 are the timing set values of T1 and T2, and T is the clock cycle of the timer.



Example 9: Triggering circuit


In the figure below, a command consisting of the differential of the rising edge of X0 causes coil M0 to generate a single pulse for ΔT (length of one scanning cycle), and coil Y1 is electrified during this scanning cycle. Coil M0 loses power during the next scanning cycle, and NC contact M0 and NC contact Y1 are both closed. This causes coil Y1 to stay in an electrified state until there is another rising edge in input X0, which again causes the

electrification of coil M0 and the start of another scanning cycle, while also causing coil Y1 to lose power, etc. The sequence of these actions can be seen in the figure below. This type of circuit is commonly used to enable one input to perform two actions in alternation. It can be seen from the time sequence in the figure below that when input X0 is a square wave signal with a period of T, the output of coil Y1 will be a square wave signal with a period of 2T.




Example 10: Delay circuit

When input X0 is On, because the corresponding NC contact will be OFF, the timer T10 will be in no power status, and output coil Y1 will be electrified. T10 will receive power and begin timing only after input X0 is OFF, and output coil Y1 will be delayed for 100 sec. (K1000*0.1 sec. =100 sec.) before losing power; please refer to the sequence of actions in the figure below.




Example 11: The open / close delay circuit is composed of two timers; output Y4 will have a delay whether input X0 is ON or OFF.



Example 12: Extended timing circuit

In the circuit in the figure on the left, the total delay time from the moment input X0 closes to the time output Y1 is electrified is (n1+n2)*T, where T is the clock cycle. Timers: T11, T12; clock cycle: T.



15-5 Functions of Various PLC Devices

Item	Specifications	Note
Algorithmic control method	Program stored internally, alternating back-and-forth scanning method	
Input / output control method	When it starts again after ending (after execution to the END command), the input / output has an immediate refresh command	
Algorithmic processing speed	Basic commands (several µs)	Application commands (1 to several tens of µs)
Programming language	Instruction list (IL) + ladder diagram (LD) + function block diagram (FBD)	
Inputs / outputs contacts	Digital input (X): 4, digital output (Y): 3 Analog input (AI): 2, analog output (AO): 1	This number of contacts constitutes MP300 input / output contacts; other devices have different correspondences

Туре	Device	Item		Range		Functions
	Х	External input relay		X0-X17, 16 points, octal		Corresponds to external
				number	Total	input points
	Υ	External output relay		Y0-Y17, 16 points, octal	32 points	Corresponds to external
	ī	Exteri	iai output reiay	number		output points
		Auxiliary	General purpose	M0-M799, 800 points	Total	Contacts can be used as
	M	relay	Special purpose	M1000–M1359, 360	1160	ON / OFF switch in the
		leiay	Special pulpose	points	points	program
Relay bit						Timer indicated by TMR
form			100m		Total	instruction. If timing
101111	Т	Timer	Timer	T0-T159, 160 points	160 points	reaches its target, the T
			Tillei		Too pointo	contact of the same
						number will be ON.
	С	Counter	16-bit counting up (general purpose)	C0-C79, 80 points	Total 80 points	Counter indicated by CNT
						(DCNT) instruction. If
						counting reaches its
						target, the C contact of the
						same number will be ON.
	Т	Current value of timer				When the timing reaches
				T0-T159, 160 points		the target, the contact of
						the timer will be ON.
	С					When the counting
Register		Current value of counter		C0–C79, 16-bit counter, 80 points		reaches the target, the
word data						contact of the counter will
						be ON.
	D	Data register	Latching	D0-D399, 400 points	Total 1620	
			Non-latching	D400–D999, 600 points		Memory area for data
			Special purpose	D1000–D1619 · 620 points	points	storage
Constant	V	Docimal	Single byte	Setting Range: K-32,768-	-K32,767	
Constant	K	Decimal	Double-byte	Setting Range: K-2,147,4	83,648–K2	,147,483,647

		Hexade	Single byte	Setting Range:H0000–HFFFF	
	Н	cimal	Double-byte	Setting Range: H00000000—HFFFFFFF	
Serial communication port (program write/read)		•	RS-485_1 (SG1) & 2 (SG2)		
	Analog input / output		utput	Built-in two sets of analog inputs and one set of analog outputs	
I/O fund	tion exp	ansion	Optional	NI/A	
	module		accessories	N/A	
Communi	cation e	xpansion	Optional	Device Net Drefibus DR Medbus TCR EtherNet/IR Rive To	
	module		accessories	DeviceNet, Profibus-DP, Modbus-TCP, EtherNet/IP, Blue Tooth	


15-5-1 Introduction to The Command Window

Functions of inputs / outputs contacts

Input contact X functions: Input contact X is connected with an input device, and reads input signals entering the PLC. The number of times that contact a or b of input contact X is used in the program is not subject to restrictions. The ON / OFF state of input contact X will change as the input device switches ON and OFF; a peripheral device (WPLSoft) cannot be used to force contact X ON or OFF.

Functions of the output contact Y

The job of output contact Y is to send an ON / OFF signal to drive the load connected with output contact Y. Output contacts consist of two types: relays and transistors. While number of times that contact a or b of each output contact Y is used in the program is not subject to restrictions, it is recommended that the number of output coil Y be used only once in a program, otherwise the right to determine the output state when the PLC performs program scanning will be assigned to the program's final output Y circuit.



The output of Y0 will be decided by circuit **2**, i.e. decided by ON/OFF of X10.

Numerical value, constant [K] / [H]

Constant	Single byte Double-	К	Decimal	K-32,768 to K32,767 K-2,147,483,648 to K2,147,483,647
	byte Single byte		Hexadecimal	H0000-HFFFF
	Double- byte	Н		H0000000—HFFFFFFF


The PLC can use five types of numerical values to implement calculations based on its control tasks; the following is an explanation of the missions and functions of different numerical values.

Binary Number, BIN

The PLC's numerical operations and memory employ binary numbers. Binary nibbles and relevant terms are explained as follows:

bit	Bit is the fundamental units of binary values, and have a state of either 1 or 0.
Nibble	Comprised of a series of 4 bits (such as b3-b0); can be used to express a
Nibbie	one-nibble decimal number 0–9 or hexadecimal number: 0–F.
Byte	Comprised of a series of two nibbles (i.e., 8 bits, b7-b0); can express a
Буце	hexadecimal number: 00–FF.
Word	Comprised of a series of two bytes (i.e., 16 bits, b15-b0); can express a
vvoid	hexadecimal number with four nibbles: 0000–FFFF.
Double word	Comprised of a series of two words (i.e., 32 bits, b31-b0); can express a
	hexadecimal number with eight nibbles: 00000000–FFFFFFF

Relation between bits, digits, nibbles, words, and double words in a binary system (see figure below):



Octal Number, OCT

The external input and output terminals of a DVP-PLC are numbered using octal numbers Example: External input: X0–X7 , X10–X17...(Device number table);

External output: Y0–Y7 , Y10–Y17...(Device number table)

Decimal Number, DEC

Decimal numbers are used for the following purposes in a PLC system:

- 1. The setting values of timer T or counter C, such as TMR C0 K50. (K constant)
- 2. The numbers of devices including M, T, C, or D, such as M10 or T30. (device number)
- 3. Used as an operand in an application command, such as MOV K123 D0. (K constant)

Binary Code Decimal, BCD

Use one nibble or 4 bits to express the data in a decimal number; a series of 16 bits can therefore express a decimal number with 4 nibbles. Chiefly used to read the input value of a fingerwheel numerical switch input or output a numerical value to a seven-segment display drive.

Hexadecimal Number, HEX

Applications of hexadecimal numbers in a PLC system: Used as operands in application commands, such as MOV H1A2B D0. (H constant)

Constant K

Decimal numbers are usually prefixed with a "K" in a PLC system, such as K100. This indicates that it is a decimal number with a numerical value of 100.

Exceptions: K can be combined with bit device X, Y, M, or S to produce data in the form of a nibble, byte, word, or double word, such as in the case of K2Y10 or K4M100. Here K1 represents a 4-bit combination, and K2–K4 variously represent 8, 12, and 16-bit combinations.

Constant H

Hexadecimal numbers are usually prefixed with the letter "H" in a PLC system, such as in the case of H100, which indicates a hexadecimal number with a numerical value of 100.

Functions of auxiliary relays

Like an output relay Y, an auxiliary relay M has an output coil and contacts a and b, and the number of times they can be used in a program is unrestricted. Users can use an auxiliary relay M to configure the control circuit, but cannot use it to directly drive an external load. Auxiliary relays have the following two types of characteristics:

- Ordinary auxiliary relays: Ordinary auxiliary relays will all revert to the OFF state if a power outage occurs while the PLC is running, and will remain in the Off state if power is again turned down.
- Special purpose auxiliary relays: Each special purpose auxiliary relay has its own specific use.
 Do not use any undefined special purpose auxiliary relays.

Functions of timer

Timers take 100 ms as their timing units. When the timing method is an upper time limit, when the current timer value = set value, power will be sent to the output coil. Timer setting values consist of decimal K values, and the data register D can also serve as a setting value.

Actual timer setting time = timing units x set value

Features of counter

Item	16-bit counter
Туре	General type
CT direction	Counting up
Setting	0–32,767
Designation of set value	Constant K or data register D
Change in current value	When the count reaches the set value, there is no longer a count
Output contact	When the count reaches the set value, the contact comes ON and stays ON
Reset	The current value reverts to 0 when an RST command is executed, and the
Keset	contact reverts to OFF
Action of contacts	All are actuated after the end of scanning

Functions of counter


When a counter's counting pulse input signal goes OFF→ON, if the counter's current value is equal to the set value, the output coil will come ON. The setting value will be a decimal K values, and the data register D can also serve as a setting value.

16-bit counter C0-C79:


- 16-bit counter setting range: K0–K32,767. (when K0 and K1 are identical, the output contact will immediately be On during the first count.)
- The current counter value will be cleared from an ordinary counter when power is shut off to the PLC.
- If the MOV command or WPLSoft is used to transmit a value greater than the set value to the C0 current value register, when the next X1 goes from OFF→ON, the C0 counter contact will change to ON, and the current value will change to the set value.

- A counter's setting value may be directly set using a constant K or indirectly set using the value in register D (not including special data registers D1000–D1199 or D2000–D2799).
- If the set value employs a constant K, it may only be a positive number; the set value may be either a positive or a negative number if the value in data register D is used. The current counter value will change from 32,767 to -32,768 as the count continues to accumulate.

Example:



- When X0 = ON and the RST command is executed, the current value of C0 will revert to 0, and the output contact will revert to OFF.
- When X1 changes from OFF→ON, the current value of the counter will execute an increase (plus one).
- When the count of counter C0 reaches the set value K5, the contact C0 will come ON, and the current value of C0 = set value = K5. Afterwards, signal C0 triggered by X1 cannot be received, and the current value of C0 will remain K5.



15-5-2 Introduction to special relay functions (special M)

R/W items: RO: read only function; RW: read and write function

Special M	Function	R/W *
M1000	Operates monitor NO contact (contact a). NO while RUN, contact a. This contact	
IVITOOO	is ON while in the RUN state.	RO
M1001	Operates monitor NC contact (contact b). NC while RUN, contact b. This contact	RO
WHOOT	is OFF while in the RUN state.	KO
M1002	Initiates a forward (the instant RUN is On) pulse. Initial pulse, contact a.	
W1002	Produces a forward pulse the moment RUN begins; its width = scan cycle	RO
M1003	Initiates a reverse (the instant RUN is Off) pulse. Initial pulse, contact a.	
WHOOS	Produces a reverse pulse the moment RUN ends; the pulse width = scan cycle	
M1004	Reserved	RO
M1005	Drive malfunction instructions	RO
M1006	Converter has no output (1 = no output, 0 = output)	RO
M1007	Drive direction FWD(0) / REV(1)	RO
M1011	10 ms clock pulse, 5ms ON / 5ms OFF	RO
M1012	100 ms clock pulse, 50ms ON / 50ms OFF	RO
M1013	1 sec. clock pulse, 0.5s ON / 0.5s OFF	RO
M1014	1 min. clock pulse, 30s ON / 30s OFF	RO
M1015	Frequency attained (when used together with M1025)	RO

Special M	Function	R/W *
•	Parameter read / write error	RO
M1017	Parameter write successful	RO
M1019	Instruction to the warning of AC motor drive	RO
M1020	Zero flag	RO
M1021	Borrow flag	RO
M1022	Carry flag	RO
M1023	Divisor is 0	RO
M1025	Target drive frequency = set frequency (ON)	RW
	Target drive frequency =0 (OFF)	
M1026	Drive operating direction FWD(OFF) / REV(ON)	RW
M1027	Drive Reset	RW
M1040	Excitation (Servo ON)	RW
M1042	Quick stop	RW
M1044	Pause (Halt)	RW
	Lock frequency (lock, frequency locked at the current operating frequency)	RW
M1056	Excitation ready (Servo ON Ready)	RO
M1058	In the process of Quick Stopping	RO
	485 read / write completed	RO
M1078	485 read / write error	RO
M1079	485 Communications time out	RO
M1080	485 exception error	RO
M1081	485 check sum or data format is wrong	RO
M1090	OFF (Refer to Pr.00-29 for more information)	RO
M1091	HAND (Refer to Pr.00-29 for more information)	RO
M1092	AUTO (Refer to Pr.00-29 for more information)	RO
M1100	LOCAL (Refer to Pr.00-29 for more information)	RO
M1101	REMOTE (Refer to Pr.00-29 for more information)	RO
M1168	Switch SMOV, BCD and BIN mode	RW
M1260	PLC PID1 enable	RW
M1261	The initial value of integration presets when enable PLC PID1	RW
201	PLC PID1	
M1262	The setting to assign the initial value of integration, 0: assign as the minimum; 1:	RW
	assign as the maximum.	
144000	PLC PID1	DIM
M1263	The value of integration is forced to be D1208.	RW
M1264	Assign the last value of integration when enable PLC PID1.	RW
	PLC PID1	
M1265	The setting to assign the initial value of integration, 0: according to M1262; 1:	
	assign as D1208.	
M1270	PLC PID2 enable	RW
M1271	The initial value of integration presets when enable PLC PID2	RW
	PLC PID2	
M1272	e setting to assign the initial value of integration, 0: assign as the minimum; 1:	
	assign as the maximum.	
M1273	PLC PID2	RW
IVIIZIJ	The value of integration is forced to be D1228.	1744

Special M	Function	R/W *
M1274	Assign the last value of integration when enable PLC PID2.	RW
M1275	PLC PID2 The setting to assign the initial value of integration, 0: according to M1272; 1: assign as D1228.	RW
M1280	PLC PID3 enable	RW
M1281	The initial value of integration presets when enable PLC PID3	RW
M1282	PLC PID3 The setting to assign the initial value of integration, 0: assign as the minimum; 1: assign as the maximum.	RW
M1283	PLC PID3 The value of integration is forced to be D1248.	RW
M1284	Assign the last value of integration when enable PLC PID3.	RW
M1285	PLC PID3 The setting to assign the initial value of integration, 0: According to M1282; 1: Preset as D1248	RW
M1290	PLC PID4 enable	RW
M1291	The initial value of integration presets when enable PLC PID4	RW
M1292	PLC PID4 The setting to assign the initial value of integration, 0: assign as the minimum; 1: assign as the maximum.	RW
M1293	PLC PID4 The value of integration is forced to be D1268.	
M1294	Assign the last value of integration when enable PLC PID4.	
M1295	PLC PID4 The setting to assign the initial value of integration, 0: according to M1292; 1: assign as D1268.	
M1300	PLC PID5 enable	RW
M1301	The initial value of integration presets when enable PLC PID5	RW
M1302	PLC PID5 The setting to assign the initial value of integration, 0: assign as the minimum; 1: assign as the maximum.	RW
M1303	PLC PID5 The value of integration is forced to be D1288.	RW
M1304	Assign the last value of integration when enable PLC PID5.	RW
M1305	PLC PID5 The setting to assign the initial value of integration, 0: according to M1302; 1: assign as D1288.	RW
M1310	PLC PID6 enable	
M1311	The initial value of integration presets when enable PLC PID6	RW
M1312	PLC PID6 The setting to assign the initial value of integration, 0: assign as the minimum; 1: assign as the maximum.	RW
M1313	PLC PID6 The value of integration is forced to be D1308.	RW
M1314	Assign the last value of integration when enable PLC PID6.	RW

Special M	Function	R/W *		
M1315	PLC PID6 The setting to assign the initial value of integration, 0: according to M1312; 1: assign as D1308.	RW		
M1320	PLC PID7 enable	RW		
M1321	The initial value of integration presets when enable PLC PID7	RW		
M1322	PLC PID7 The setting to assign the initial value of integration, 0: assign as the minimum; 1: assign as the maximum.	RW		
M1323	PLC PID7 The value of integration is forced to be D1328.	RW		
M1324	Assign the last value of integration when enable PLC PID7.			
M1325	PLC PID7 The setting to assign the initial value of integration, 0: According to M1322; 1: Preset as D1328.	RW		
M1330	PLC PID8 enable	RW		
M1331	The initial value of integration presets when enable PLC PID8	RW		
M1332	PLC PID8 The setting to assign the initial value of integration, 0: assign as the minimum; 1: assign as the maximum.	RW		
M1333	PLC PID8 The value of integration is forced to be D1348.			
M1334	Assign the last value of integration when enable PLC PID8.			
M1335	PLC PID8 The setting to assign the initial value of integration, 0: According to M1332; 1: Preset as D1348.	RW		


15-5-3 Introduction to special register functions (special D)

Special D	Function	R/W *
D1010	Current scan time (units: 0.1 ms)	
D1011	Minimum scan time (units: 0.1 ms)	RO
D1012	Maximum scan time (units: 0.1 ms)	RO
D1018	Current integral value	RO
D1019	Compulsory setting of PID I integral	RW
D1020	Output frequency (0.000–600.00Hz)	RO
D1021	Output current (####.#A)	RO
D1023	Communication expansion card number 0: No expansion card 1: DeviceNet Slave (CMC-DN01) 2: Profibus-DP Slave (CMC-PD01) 4: Modbus-TCP Slave (CMC-MOD01) 5: EtherNet/IP Slave (CMC-EIP01) 13: Bluetooth	RO
D1027	PID calculation frequency command (frequency command after PID calculation)	RO
D1028	AVI value (0.00–100.00%)	RO
D1029	ACI value (0.0–100.00%)	RO
D1036	Servo error bit	RO

Special D	Function	R/W *	
D1037	Drive output frequency	RO	
D1038	DC bus voltage	RO	
D1039	Output voltage	RO	
D1040	Output voltage		
	Can be user-defined (will be displayed on panel when Pr. 00-04 is set as 28;	RW B; RW	
D1043	display method is C xxx)		
D1061	485 COM1 communications time out time (ms)	RW	
D1062	Torque command (torque limit in speed mode)	RW	
D1064	Week (display range 1–7)	RO	
D1065	Month (display range 1–12)	RO	
D1066	Day (display range 1–31)	RO	
D1067	Hour (display range 0–23)	RO	
D1068	Minute (display range 0–59)	RO	
D1069	Second (display range 0–59)	RO	
D1100	Target frequency	RO	
D1101	Target frequency (must be operating)	RO	
D1102	Reference frequency	RO	
D1107	π(Pi) Low word	RO	
D1108	π(Pi) High word	RO	
D1109	Random number	RO	
D1200	PID1 Mode	RW	
	PID1 Target selection:		
D	0: Refer to D1202		
D1201	1: AI1	RW	
	2: AI2		
D1202	PID1 Target value (0.00%–100.00%)	RW	
	PID1 Feedback selection:		
D4202	0: Refer to D1204	DW	
D1203	1: AI1	RW	
	2: AI2		
D1204	PID1 Feedback value (0.00%–100.00%)	RW	
D1205	P value of PID1 (two decimal places)	RW	
D1206	I value of PID1 (two decimal places)	RW	
D1207	D value of PID1 (two decimal places)	RW	
D1208	Forced to assign a value to PID 1 integral value	RW	
D1209	PID1 Max. limit	RW	
D1215	PID1 calculation	RO	
D1216	PID1 present I value	RW	
D1220	PID2 Mode	RW	
	PID 2 Target selection:		
D1221	0: Refer to D1222	RW	
01221	1: AI1	1744	
	2: AI2		
D1222	PID2 Target value (0.00%–100.00%)	RW	
	PID2 Feedback selection:		
D1223	0: Refer to D1224	RW	
	1: AI1		
	2: AI2		

Special D	Function	R/W *
D1224	PID2 Feedback value (0.00%–100.00%)	RW
D1225	P value of PID2 (two decimal places)	RW
D1226	I value of PID2 (two decimal places)	RW
D1227	D value of PID2 (two decimal places)	RW
D1228	PID2 Max. limit	RW
D1229	PID2 Max. limit	RW
D1235	PID2 calculation	RO
D1236	PID2 present I value	RW
D1240	PID3 Mode	RW
D1241	PID3 target selection (0: refer to D1242; 1: AI1; 2: AI2)	RW
D1242	PID3 Target value (0.00%–100.00%)	RW
D1243	PID3 feedback selection (0: refer to D1244; 1: AI1; 2: AI2)	RW
D1244	PID3 Feedback value (0.00%–100.00%)	RW
D1245	P value of PID3 (two decimal places)	RW
D1246	I value of PID3 (two decimal places)	RW
D1247	D value of PID3 (two decimal places)	RW
D1248	Forced to assign a value to PID3 integral value	RW
D1249	PID3 Max. limit	RW
D1255	PID3 calculation	RO
D1256	PID3 present I value	RW
D1260	PID4 Mode	RW
D1261	PID4 target selection (0: refer to D1262; 1: AI1; 2: AI2)	RW
D1262	PID4 Target value (0.00%–100.00%)	RW
D1263	PID4 feedback selection (0: refer to D1264; 1: AI1; 2: AI2)	RW
D1264	PID4 Feedback value (0.00%–100.00%)	RW
D1265	P value of PID4 (two decimal places)	RW
D1266	I value of PID4 (two decimal places)	RW
D1267	D value of PID4 (two decimal places)	RW
D1268	Forced to assign a value to PID4 integral value	RW
D1269	PID4 Max. limit	RW
D1275	PID4 calculation	RO
D1276	PID4 present I value	RW
D1280	PID5 Mode	RW
D1281	PID5 target selection (0: refer to D1282; 1: AI1; 2: AI2)	RW
D1282	PID5 Target value (0.00%–100.00%)	RW
D1283	PID5 feedback selection (0: refer to D1284; 1: AI1; 2: AI2)	RW
D1284	PID5 Feedback value (0.00%–100.00%)	RW
D1285	P value of PID5 (two decimal places)	RW
D1286	I value of PID5 (two decimal places)	RW
D1287	D value of PID5 (two decimal places)	RW
D1288	Forced to assign a value to PID5 integral value	RW
D1289	PID5 Max. limit	RW
D1295	PID5 calculation	RO
D1296	PID5 present I value	RW
D1300	PID6 Mode	RW
D1301	PID6 target selection (0: refer to D1302; 1: AI1; 2: AI2)	RW
D1302	PID6 Target value (0.00%–100.00%)	RW
• • •	((1

Special D	Function	R/W *
D1303	PID6 feedback selection (0: refer to D1304; 1: Al1; 2: Al2)	RW
D1304	PID6 Feedback value (0.00%–100.00%)	RW
D1305	P value of PID6 (two decimal places)	RW
D1306	I value of PID6 (two decimal places)	RW
D1307	D value of PID6 (two decimal places)	RW
D1308	Forced to assign a value to PID6 integral value	RW
D1309	PID6 Max. limit	RW
D1315	PID6 calculation	RO
D1316	PID6 present I value	RW
D1320	PID7 Mode	RW
D1321	PID7 target selection (0: refer to D1322; 1: Al1; 2: Al2)	RW
D1322	PID7 Target value (0.00%–100.00%)	RW
D1323	PID7 feedback selection (0: refer to D1324; 1: Al1; 2: Al2)	RW
D1324	PID7 Feedback value (0.00%–100.00%)	RW
D1325	P value of PID7 (two decimal places)	RW
D1326	I value of PID7 (two decimal places)	RW
D1327	D value of PID7 (two decimal places)	RW
D1328	Forced to assign a value to PID7 integral value	RW
D1329	PID7 Max. limit	RW
D1335	PID7 calculation	RO
D1336	PID7 present I value	RW
D1340	PID8 Mode	RW
D1341	PID8 target selection (0: refer to D1342; 1: Al1; 2: Al2)	RW
D1342	PID8 Target value (0.00%–100.00%)	RW
D1343	PID8 feedback selection (0: refer to D1344; 1: Al1; 2: Al2)	RW
D1344	PID8 Feedback value (0.00%–100.00%)	RW
D1345	P value of PID8 (two decimal places)	RW
D1346	I value of PID8 (two decimal places)	RW
D1347	D value of PID8 (two decimal places)	RW
D1348	Forced to assign a value to PID8 integral value	RW
D1349	PID8 Max. limit	RW
D1355	PID8 calculation	RO
D1356	PID8 present I value	RW



15-5-4 PLC Communication address

Device	Range	Туре	Address (Hex)
X	00-37 (Octal)	bit	0400-041F
Υ	00-37 (Octal)	bit	0500-051F
Т	00–159	bit / word	0600-069F
М	000–799	bit	0800-0B1F
М	1000–1359	bit	0BE8-0C7F
С	0–79	bit / word	0E00-0E47
D	00–1000	word	1000-13E7
D	1000–1619	word	13E8-1653

Command code that can be used

Function Code	Function	Function target
01	Read coil status	Y, M, T, C
02	Read input status	X, Y, M, T, C
03	Read single unit of data	T, C, D
05	Compulsory single coil status change	Y, M, T, C
06	Write single unit of data	T, C, D
0F	Compulsory multiple coils status change	Y, M, T, C
10	Write multiple units of data	T, C, D

NOTE:

- 1: When PLC function enables, MP300 can correspond to parameters of PLC and the drive by the PLC communication addresses mentioned above.
- 2: The default station address of drive is 1, and the default station address of PLC is 100.

15-6 Introduction to the Functions of Instructions

15-6-1 Overview of basic instructions

General instructions

Instruction code	Function	OPERAND	Execution speed (µs)
LD	Load contact a	X, Y, M, T, C	0.8
LDI	Load contact b	X, Y, M, T, C	0.8
AND	Connect contact a in serial	X, Y, M, T, C	0.8
ANI	Connect contact b in serial	X, Y, M, T, C	0.8
OR	Connect contact a in parallel	X, Y, M, T, C	0.8
ORI	Connect contact b in parallel	X, Y, M, T, C	0.8
ANB	Series circuit block	N/A	0.3
ORB	Parallel circuit block	N/A	0.3
MPS	Save to stack	N/A	0.3
MRD	Stack read (pointer does not change)	N/A	0.3
MPP	Read stack	N/A	0.3

Output instructions

Instruction code	Function	OPERAND	Execution speed (µs)
OUT	Drive coil	Y, M	1
SET	Action continues (ON)	Y, M	1
RST	Clear contact or register	Y, M, T, C, D	1.2

Timer, counter

Instruction code	Function	OPERAND	Execution speed
motraction code	1 diletien	01 210 110	(µs)
TMR	16-bit timer	T-K or T-D	1.1
CNT	16-bit counter	C-K or C-D (16 bit)	0.5

Main control instructions

Instruction code	Function	OPERAND	Execution speed (µs)
MC	Common series contact connection	N0-N7	0.4
MCR	Common series contact release	N0-N7	0.4

Rising edge / falling edge contact detection instructions

Instruction code	Function	OPERAND	Execution speed (µs)
LDP	Rising edge detection	X, Y, M, T, C	1.1
LDF	Falling edge detection	X, Y, M, T, C	1.1
ANDP	Detect serial connection at rising edge	X, Y, M, T, C	1.1
ANDF	Detect serial connection at falling edge	X, Y, M, T, C	1.1
ORP	Detect parallel connection at rising edge	X, Y, M, T, C	1.1
ORF	Detect parallel connection at falling edge	X, Y, M, T, C	1.1

Upper / lower differential output instructions

Instruction code	Function	OPERAND	Execution speed
mstruction code	1 diletion	OI EIVAND	(µs)
PLS	Upper differential output	Y, M	1.2
PLF	Lower differential output	Y, M	1.2

End instruction

Instruction code	Function	OPERAND	Execution speed (µs)
END	End the program	N/A	0.2

Other instructions

Instruction code	Function	OPERAND	Execution speed (µs)
NOP	No operation	N/A	0.2
INV	Inverse of operation results	N/A	0.2
Р	Pointer	Р	0.3

15-6-2 Instructions of basic instructions

Instruction	Function									
LD	Load contact A									
	X0-X17	Y0-Y17	M0-M799	T0-15	9 C	CO-C79	D0-D399			
Operand	✓	✓	✓	✓		✓	-			
Description	that is the star	LD instruction is used on the contact A that has its start from the left BUS bar or contact A that is the start of a contact circuit. The functions are to save the present contents and store the acquired contact status into the accumulative register.								
	Ladder diagrar	n:		Instructi	on code	Or	peration			
Evample				LD	X0	Load X0 A)	(the contact			
Example		1 1		AND	X1	Connect 2 A) in seria	X1 (the contact			
				OUT	Y1	Drive Coil	Y1			

Instruction	Function									
LDI	Load contact B									
	X0-X17	Y0-Y17	M0-M799	T0-15	9 (CO-C79	D0-D399			
Operand	✓	✓	✓	✓		✓	-			
Description	A that is the st	LDI instruction is used on the contact B that has its start from the left BUS bar or contact A that is the start of a contact circuit. The functions are to save the present contents and store the acquired contact status into the accumulative register.								
	Ladder diagrar	n:		Instructi	on code	Or	peration			
Evample				LDI	X0	Load X0 B)	(the contact			
Example		1 1		AND	X1	Connect 2 A) in seria	X1 (the contact			
				OUT	Y1	Drive Coil	Y1			

Instruction	Functions									
AND	Connect contact A in serial									
	X0-X17	Y0-Y17	M0-M799	T0-15	i9 C	CO-C79	D0-D399			
Operand	✓	✓	✓	✓		✓	-			
Description	out the contact	AND instruction is used in the serial connection of contact A. The functions are to read out the contacts' status of present serial connection and perform "AND" operation with the logical operation result obtained. The final result will be stored in the accumulative register.								
	Ladder diagrar	n:		Instructi	on code	Op	peration			
				LDI	X1	Load X1 ((the contact B)			
Example			Y	AND	X0	Connect contact A	X0 (the A) in serial			
				OUT	Y1	Drive Coil	Y1			

Instruction	Function									
ANI	Connect conta	Connect contact B in serial								
	X0-X17	Y0-Y17	M0-M799	T0-15	i9 C	0-C79	D0-D399			
Operand	✓	✓	✓	✓		✓	-			
Description	the contacts' s	ANI instruction is used in the serial connection of contact B. The functions are to read out the contacts' status of present serial connection and perform "AND" operation with the ogical operation result obtained. The final result will be stored in the accumulative register.								
	Ladder diagrar	n:		Instructi	on code	Or	peration			
				LD	X1	Load X1 ((the contact A)			
Example		VI		ANI	ХO	Connect contact E	X0 (the 3) in serial			
				OUT	Y1	Drive Coi	I Y1			

Instruction	Functions									
OR	Connect contact A in parallel									
	X0-X17	Y0-Y17	M0-M799	T0-15	i9 C	CO-C79	D0-D399			
Operand	✓	✓	✓	✓		✓	-			
Description	out the contact	OR instruction is used in the parallel connection of contact A. The functions are to read out the contacts' status of present serial connection and perform "OR" operation with the logical operation result obtained. The final result will be stored in the accumulative register.								
	Ladder diagrar			Instructi	on code	Op	peration			
			<u> Y1</u>	LD	X0	Load X0 ((the contact A)			
Example	X	1		OR	X1	Connect contact A	X1 (the A) in serial			
				OUT	Y1	Drive Coi	Y1			

Instruction	Function									
ORI	Connect contact B in parallel									
	X0-X17	Y0-Y17	M0-M799	T0-15	i9 C	CO-C79	D0-D399			
Operand	✓	✓	✓	✓		✓	-			
Description	out the contact	ORI instruction is used in the parallel connection of contact B. The functions are to read out the contacts' status of present serial connection and perform "OR" operation with the ogical operation result obtained. The final result will be stored in the accumulative egister.								
	Ladder diagrar			Instructi	on code	Or	peration			
			<u> Y1</u>	LD	X0	Load X0 ((the contact A)			
Example	ORI X1 Connect X1 (th						•			
				OUT	Y1	Drive Coil	I Y1			

Instruction	Function									
ANB	Series circuit block									
Operand	N.	N/A								
Description	To perform "AND" operation of the previous in the accumulative register.	saved log	ical result	and the present content						
	Ladder diagram:	Instructi	on code	Operation						
	ANB YI	LD	X0	Load X0 (the contact A)						
		ORI	X2	Connect X2 (the contact B) in parallel						
Example		LDI	X1	Load X1 (the contact B)						
	Blook A Blook B	OR	Х3	Connect X3 (the contact A) in parallel						
		ANB		Series circuit block						
		OUT	Y1	Drive Coil Y1						

Instruction	Fund	ction							
ORB	Parallel circuit block								
Operand	N/A								
Description	To perform "OR" operation of the previous sathe accumulative register.	To perform "OR" operation of the previous saved logical result and the present content in the accumulative register.							
	Ladder diagram: ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓	Instructi	on code	Operation					
		LD	X0	Load X0 (the contact A)					
	* * * *	ANI	X1	Connect X1 (the contact B) in parallel					
Example	Fire B	LDI	X2	Load X2 (the contact B)					
		AND	Х3	Connect X3 (the contact A) in parallel					
		ORB		Parallel circuit block					
		OUT	Y1	Drive Coil Y1					

Instruction	Function
MPS	Save to stack
Operand	N/A
Description	To save the content in the accumulative register into the stack. (the stack pointer plus 1)

Instruction	Function
MRD	POP operation to stack (the stack pointer stays intact)
Operand	N/A
Description	To read the stack and store it into the accumulative register. POP operation to stack (the stack pointer stays intact)

Instruction	Function									
MPP	Read stack									
Operand	N/A									
Description	To retrieve the previous saved logical result and store it into the accumulative register. (the stack pointer minus 1)									
	Ladder diagram:	Instructi	on code	Operation						
	X0 MPS X1	LD	X0	Load X0 (the contact A)						
		MPS		Save to stack						
	MRD MD	AND	X1	Connect X1 (the contact A) in serial						
	Y2)	OUT	Y1	Drive Coil Y1						
Example	MPP END	MRD		POP operation to stack (the stack pointer stays intact)						
		AND	X2	Connect X2 (the contact A) in serial						
		OUT	MO	Drive Coil M0						
		MPP		Read stack						
		OUT	Y2	Drive Coil Y2						
		END		End the program						

Instruction	Function										
OUT	Drive coil										
	X0-X17	Y0-Y17	M0-M	1799	T0-15	9 (CO-C79	D0-D399			
Operand	-	✓	✓		-		-	-			
	To output the logical operation result before OUT instruction into a designated device. Action of the Coil contact:										
				C	OUT instruc	tion					
Danamintian		Operation			Co	ontact					
Description		result		Contact A			ntact B				
				(Norn	<u> </u>		ally Close)				
		FALSE	OFF	Not conducting			nducting				
		TRUE	ON	Co	nducting	Not co	onducting				
	Ladder diag	ram:			Instruction	on code	Ор	eration			
					LDI	X0	Load X0 (the contact B)			
Example					AND	X1	Connect X1 (the contact A) in parallel				
					OUT	Y1	Drive Coi	I Y1			

Instruction	Function										
SET	Action continues (ON)										
	X0-X17	Y0-Y17	M0-M799	T0-15	9 (CO-C79	D0-D399				
Operand	-	✓	✓	-		-	-				
Description	When the SET instruction is driven, its designated device will be "ON" and keep being ON both when SET instruction is still being driven or not driven. Use RST instruction to set the device to be OFF.										
	Ladder diagran	n:		Instructi	on code	O	peration				
					X0	Load X0 ((the contact A)				
Example				ANI	Y0	Connect `B) in para	Y0 (the contact				
				SET	Y1	Action co	ontinues (ON)				

Instruction	Function											
RST	Clea	Clear contact or register										
	>	(0–X17	Y0-Y17	M0-M799	T0-15	9 C	CO-C79	D0-D399				
Operand		-	✓	✓	✓		✓	✓				
	Whe	en the RST	instruction is d	Iriven, the actio	ns of the c	lesignated	d devices a	are:				
		Device			Status							
		Y, M	Coil and contacts are set to "OFF".									
Description		T, C	The current value of the timer or the counter are set to "0", the coil and the									
		1, 0	contacts are set to "OFF".									
		D	Γhe value is set to "0".									
	If RS	ST instruct	ion is not being	executed, the	status of th	ne designa	ated device	e stays intact.				
	Lad	der diagrar	_		Instructi	on code	Op	peration				
Example			RST Y5		LD	X0	Load X0 (the contact A)				
		1 '			RST	Y5	Clear cor register	ntact or				

Instruction	Function									
TMR	16-bit timer									
Operand	T-K	T0-T159, K0-K32,767								
Operand	T-D	T0-T159, D0-D399								
Description	the timer starts setting value),	When TMR instruction is executed, the designated coil of the timer receives power, and he timer starts to count. When the counting reaches the setting value (current value ≥ setting value), the contact will be: Normally Open (NO) contact Closed Normally Close (NC) contact Open								
Example	Ladder diagran	on is not being executed, the		ction code X0	Operation Load X0 (the contact A)					
			TMR	T5 K1000	T5 Timer Setting value is K1000					

Instruction	Functions									
CNT	16-bit counter									
Operand	C-K	C0-	C79, K0-K32,767							
Operand	C-D	C0-	C79, D0-D399							
Description	power→receiving reaches the se	When CNT instruction goes from OFF→ON, the designated counter coil is from losing power→receiving power, and the current value in the counter plus 1. When the counting reaches the setting value (current value = setting value), the contact will be: Normally Open (NO) contact Closed Normally Close (NC) contact Open								
	Ladder diagrar	n:		Instructi	ion code	Operation				
Example	X			LD		Load X0 (the contact A)				
				CNT	C2 K100	C2 Counter Setting value is K100				

Instruction	Function									
MC / MCR	The connection / disconnection between the contacts of common lists									
Operand	N0–N7									
Description	MC instruction is master-control start instruction. When MC instruction is executed, the execution of instructions between MC and MCR are not be interrupted. When MC instruction is OFF, the execution of instructions between MC and MCR are: Instruction type									
	Ladder diagram:		Instructi	on code	Description					
		N0	LD	X0	Load X0 (the contact A)					
	X1 Y0 X2 MC I	N1	МС	N0	The connection of the NO common serial contacts					
	X3 Y1		LD	X1	Load X1 (the contact A)					
			OUT	Y0	Drive Coil Y0					
Example	MCR I	N1	1							
		NO	LD	X2	Load X2 (the contact A)					
	X10 MC 1	NO	МС	N1	The connection of the N1 common serial contacts					
		NO .	LD	Х3	Load X3 (the contact A)					
	MCR	INU	OUT	Y1	Drive Coil Y1					
			i							

MCR	N1	Remove the connection of the N1 common serial contacts
1		
MCR	N0	Remove the connection of the N0 common serial contacts
i		
LD	X10	Load X10 (the contact A)
МС	N0	The connection of the NO common serial contacts
LD	X11	Load X11 (the contact A)
OUT	Y10	Drive Coil Y10
i		
MCR	N0	Remove the connection of the N0 common serial contacts

Instruction	Function											
LDP	Rising edge detection											
	X0-X17	Y0-Y17	M0-M799	T0-15	9 (CO-C79	D0-D399					
Operand	✓	✓	✓	✓		✓	-					
Description	The method of using LDP is the same as using LD, but the actions of the two instructions differ. LDP saves the current content and store the detected status of rising-edge to the accumulative register.											
	Ladder diagrar	n:		Instructi	on code	De	scription					
				LDP	X0	Rising ed detection	_					
Example				AND	X1	Connect X A) in seria	K1 (the contact					
				OUT	Y1	Drive Coil	Y1					
Remark	If the status of	See the specification of each model for the range of operands. If the status of a designated rising-edge is ON before the PLC is powered, the contact of the rising-edge is TRUE after PLC is powered.										

Instruction	Function									
LDF	Falling edge detection									
	X0-X17	Y0-Y17	M0-M799	T0-15	i9 C	CO-C79	D0-D399			
Operand	✓	✓	✓	✓		✓	-			
Description	differ. LDF sav accumulative r	The method of using LDF is the same as using LD, but the actions of the two instructions differ. LDF saves the current content and store the detected status of falling-edge to the accumulative register.								
	Ladder diagrar	n:		Instructi	on code	De	scription			
Example			A	LDF	X0	Falling ed				
Lxample	,			AND	X1	Connect 2 A) in seria	X1 (the contact			
				OUT	Y1	Drive Coil	Y1			

Instruction	Function										
ANDP	Detect serial co	Detect serial connection at rising edge									
	X0-X17	Y0-Y17	M0–M799 T0–159		9 (C0-C79	D0-D399				
Operand	✓	✓	✓	✓		✓	-				
Description	ANDP instructi	NDP instruction is used in the serial connection of the contacts' rising-edge detection									
	Ladder diagram:			Instructi	on code	Description					
	X3 X			LD	X0	Load X0 (the contact A)				
Example			<u></u>	ANDP	X1	Detect se connection edge of X	on at rising				
				OUT	Y1	Drive Coil	Y1				

Instruction	Function										
ANDF	Detect serial co	etect serial connection at falling edge									
0	X0-X17	Y0-Y17	M0-M799	T0-159 C		CO-C79	D0-D399				
Operand	✓	✓	✓	✓		✓	-				
Description	ANDP instructi	NDP instruction is used in the serial connection of the contacts' rising-edge detection									
	Ladder diagram:			Instructi	on code	Description					
	X)X			LD	X0	Load X0 (the contact A)					
Example		1 11	<u></u>	ANDF	X1	Detect se connection edge of X	on at falling				
				OUT	Y1	Drive Coil	Y1				

Instruction	Function									
ORP	Detect parallel connection at rising edge									
	X0-X17	Y0-Y17	Y0-Y17 M0-M799 T0-159		C0-C79	D0-D399				
Operand	✓	✓	✓	✓ ✓		-				
Description	ORP instruction	ORP instruction is used in the parallel connection of the contacts' rising-edge detection								
	Ladder diagrar	n:		Instructi	on code	De	scription			
	X	0	—(Y1)	LD	X0	Load X0 ((the contact A)			
Example	X 1	1		ORP	X1	Detect pa connection edge of X	on at rising			
				OUT	Y1	Drive Coi	Y1			

Instruction	Function										
ORF	Detect parallel	Detect parallel connection at falling edge									
	X0–X17 Y0–Y17		M0-M799	T0-15	9 0	CO-C79	D0-D399				
Operand	✓	✓	✓	✓ ✓		✓	-				
Description	ORF instruction	ORF instruction is used in the parallel connection of the contacts' falling-edge detection									
•	Ladder diagrar	n:		Instructi	on code	De	scription				
		()	$\overline{\mathbf{Y}}$	LD	X0	Load X0 (Load X0 (the contact A)				
Example		4		ORF	X1	Detect pa connection edge of X	on at falling				
		1		OUT	Y1	Drive Coil	Y1				

Instruction	Function										
PLS	Upper different	Upper differential output									
	X0-X17	Y0-Y17	M0-M799	T0-15	9	C0-C79	D0-D399				
Operand	-	✓	✓	-		-	-				
Description		red), PLS instr					ON (the rising- and the pulse				
	Ladder diagrar	n:		Instructi	on code	De	scription				
		PLS	NØ	LD	X0	Load X0 (_oad X0 (the contact A)				
		SEI	YO	PLS	МО	Differenti rising ed	al output at ge of M0				
	Sequence diag	ıram:		LD	MO	Load M0	(the contact A)				
Example	X0 O	oon ovele	One seen surele	SET	Y0	Maintain Y0 (ON)	the action of				
	M0 Y0	can cycle	One scan cycle								

Instruction			Fund	ction							
PLF	Lower different	ower differential output									
	X0-X17	Y0-Y17	M0-M799	T0-15	i9 C	0-C79	D0-D399				
Operand	-	✓	✓	1		-	-				
Description		red), PLF instr	dge instruction. ruction is execu		•		FF (the falling- and the pulse				
	Ladder diagran			Instructi	on code	De	scription				
	X	0 PLF	MO	LD	X0	Load X0 (the contact A)				
	M0 SET Y0			PLF	МО	Differential output at falling edge of M0					
	Sequence diag	LD	MO	Load M0	(the contact A)						
Example	x ₀			SET	Y0	Maintain Y0 (ON)	the action of				
	M0	e scan cycle	One scan cycle								

Instruction	Function
END	End the program
Operand	N/A
	END instruction has to be placed in the end of a ladder diagram or instruction program. PLC scans from address 0 to END instruction, and then return to address 0 to restart the scan.

Instruction	Function									
NOP	No operation									
Operand	N/A									
Description	NOP instruction does not perform any operations in the program; therefore, after the execution of NOP, the existing logical operation result will be kept. If you want to delete a certain instruction without altering the length of the program, you can use NOP instruction.									
	Ladder diagram: NOP command will be simplified and not	Instructi	on code	Description						
	displayed when the ladder diagram is	LD	X0	Load X0 (the contact B)						
Example	displayed.	NOP		No operation						
	NOP Y1	OUT	Y1	Drive Coil Y1						

Instruction	Function								
INV	Inverse of operation results								
Operand	N/A								
Description	nvert the logical operation result before INV instruction, and store it in the accumulative egister.								
	Ladder diagram:	Instructi	on code	Description					
		LD	X0	Load X0 (the contact B)					
Example		INV		Inverse operation result					
		OUT	Y1	Drive Coil Y1					

Instruction	Function									
Р	Pointer									
Operand	P0–P255									
Description	pinter P is used for call instruction API 01 CALL of subprogram. The use of P does not seed to start from number 0, and the number cannot be used repeatedly; otherwise, nexpected errors may occur.									
	Ladder diagram:	Instructi	on code	Description						
	X0 CALL P10	LD	X0	Load X0 (the contact A)						
	X1	CALL	P10	CALL instruction reaches P10						
Example	P10 Y1	i.								
		P10		Pointer P10						
		LD	X1	Load X1 (the contact A)						
		OUT	Y1	Drive Coil Y1						

15-6-3 Overview of application instructions

5-6-3 Overvie		1	ion code	Р		STE	EPS
Category	API	16-bit	32-bit	instruction	Function	16-bit	32-bit
	01	CALL	-	✓	Call subprograms	3	-
Loop Control	02	SRET	-	-	Subprograms end	1	-
	06	FEND	-	-	Main programs end	1	-
	10	CMP	DCMP	✓	Compare output value	7	13
Transmission	11	ZCP	DZCP	✓	Zone comparison	9	17
Comparison	12	MOV	DMOV	✓	Move	5	9
Companion	13	SMOV	DSMOV	✓	Shift move	11	21
	15	BMOV		√	Block move	7	
	18	BCD	DBCD	√	Convert BIN to BCD	5	9
	19	BIN	DBIN	√	Convert BCD to BIN	5	9
Arithmetic and	20	ADD	DADD	√	BIN addition	7	13
Logical	21	SUB	DSUB	√	BIN subtraction	7	13
Operations	22	MUL	DMUL	√	BIN multiplication	7	13
	23	DIV	DDIV	√	BIN division	7	13
•	24	INC	DINC	√	BIN increment (plus one)	3	5
Datation	25	DEC	DDEC	√	BIN decrement (minus one)	3	5
Rotation &	30	ROR	DROR	✓ ✓	Rotate right	5	
Displacement	31	ROL	DROL		Rotate left	5	_
	40	ZRST	_	✓	Zone reset	5	-
	41	DECO	DDECO	✓	Decode	7	13
Data	42	ENCO	DENCO	✓	Encode	7	13
processing	43	SUM	DSUM	✓	Sum of active bits	5	9
	44	BON	DBON	✓	Check specified bit status	7	13
	49	FLT	DFLT	✓	Convert BIN integer to binary floating-point number	5	9
	110	_	DECMP	✓	Binary floating-point number comparison	_	13
	111	_	DEZCP	✓	Binary floating-point number zone comparison	_	17
	116	_	DRAD	✓	Degree → Radian	_	9
	117	_	DDEG	✓	Radian → Degree	_	9
	120	_	DEADD	✓	Binary floating-point number addition	_	13
	121	_	DESUB	✓	Binary floating-point number subtraction	_	13
	122	_	DEMUL	✓	Binary floating-point number multiplication	_	13
	123	_	DEDIV	✓	Binary floating-point number division	_	13
Floating point	124	_	DEXP	✓	Binary floating-point number exponentiation	_	9
operation	125	_	DLN	✓	Binary floating-point number natural logarithm operation	_	9
	127	_	DESQR	✓	Binary floating-point number square root	_	9
	129	INT	DINT	✓	Binary floating-point number → BIN integer	5	9
	130	-	DSIN	✓	Binary floating-point number sine operation		9
	131	-	DCOS	✓	Binary floating-point number cosine operation	_	9
	132	_	DTAN	✓	Binary floating-point number tangent operation	_	9
	133	_	DASIN	✓	Binary floating-point number arcsine operation	_	9
	134	_	DACOS	✓	Binary floating-point number arccosine operation	_	9

		Instructi	ion code	Р		STF	EPS
Category	API	16-bit	32-bit	instruction	Function	16-bit	32-bit
	135	-	DATAN	√	Binary floating-point number arctangent operation	-	9
	136	_	DSINH	✓	Binary floating-point number hyperbolic sine operation	_	9
	137	_	DCOSH	✓	Binary floating-point number hyperbolic cosine operation	_	9
	138	_	DTANH	✓	Binary floating-point number hyperbolic tangent operation	_	9
Others	147	SWAP	DSWAP	✓	Exchange the up / down 8 bits	3	5
Communication	150	MODRW	_	√	Read / write Modbus data	7	_
-	160	TCMP	_	✓	Real-time data comparison	11	_
RTC (real-time	161	TZCP	_	√	Zone comparison of real- time data	9	-
clock)	162	TADD	_	✓ ✓	Real-time data addition	7	_
-	163	TSUB TRD	_	✓	Real-time data subtraction	7	_
	166		DCBV	V ✓	Read real-time data	3	-
Gray code	170	GRY	DGRY	✓	Binary code → Gray code	5 5	9
-	171	GBIN	DGBIN	v	Gray code → Binary code Contact type logical		9
	215	LD&	DLD&	-	operation LD#	5	9
	216	LD	DLD	-	Contact type logical operation LD#	5	9
	217	LD^	DLD^	-	Contact type logical operation LD#	5	9
Contact type	218	AND&	DAND&	-	Contact type logical operation AND#	5	9
logical operation	219	ANDI	DANDI	-	Contact type logical operation AND#	5	9
operation	220	AND^	DAND^	-	Contact type logical operation AND#	5	9
	221	OR&	DOR&	-	Contact type logical operation OR#	5	9
	222	OR	DOR	-	Contact type logical operation OR#	5	9
	223	OR^	DOR^	-	Contact type logical operation OR#	5	9
	224	LD=	DLD=	-	Contact type comparison LDX	5	9
	225	LD>	DLD>	-	Contact type comparison LDX	5	9
	226	LD<	DLD<	-	Contact type comparison LDX	5	9
	228	LD<>	DLD<>	-	Contact type comparison LDX	5	9
Contact type	229	LD<=	DLD<=	-	Contact type comparison LDX	5	9
comparison	230	LD>=	DLD>=	-	Contact type comparison LDX	5	9
	232	AND=	DAND=	-	Contact type comparison AND	5	9
	233	AND>	DAND>	-	Contact type comparison ANDЖ	5	9
	234	AND<	DAND<	-	Contact type comparison ANDЖ	5	9
	236	AND<>	DAND<>	-	Contact type comparison ANDX	5	9

0.1	4 D.I	Instruct	ion code	Р	- ··	STE	EPS
Category	API	16-bit	32-bit	instruction	Function	16-bit	32-bit
	237	AND<=	DAND<=	-	Contact type comparison ANDЖ	5	9
	238	AND>=	DAND>=	-	Contact type comparison ANDX	5	9
	240	OR=	DOR=	-	Contact type comparison ORX	5	9
	241	OR>	DOR>	-	Contact type comparison ORX	5	9
	242	OR<	DOR<	-	Contact type comparison ORX	5	9
	244	OR<>	DOR<>	-	Contact type comparison ORX	5	9
	245	OR<=	DOR<=	-	Contact type comparison ORX	5	9
	246	OR>=	DOR>=	-	Contact type comparison ORX	5	9
	275	-	FLD=	-	Floating-point number contact type comparison LDX	-	9
	276	-	FLD>	-	Floating-point number contact type comparison LDX	-	9
	277	-	FLD<	-	Floating-point number contact type comparison LDX	-	9
	278	-	FLD<>	-	Floating-point number contact type comparison LD%	-	9
	279	-	FLD<=	-	Floating-point number contact type comparison LDX	-	9
Floating-point	280	-	FLD>=	-	Floating-point number contact type comparison LDX	-	9
contact type comparison	281	-	FAND=	-	Floating-point number contact type comparison AND%	-	9
	282	-	FAND>	-	Floating-point number contact type comparison AND%	-	9
	283	-	FAND<	-	Floating-point number contact type comparison AND%	-	9
	284	-	FAND<>	-	Floating-point number contact type comparison AND%	-	9
	285	-	FAND<=	-	Floating-point number contact type comparison AND%	-	9
	286	-	FAND>=	-	Floating-point number contact type comparison AND%	-	9

Cotogony	API	Instructi	on code	Р	Function	STE	PS
Category	API	16-bit	32-bit	instruction	Function	16-bit	32-bit
	287	-	FOR=	-	Floating-point number contact type comparison ORX	-	9
	288	-	FOR>	-	Floating-point number contact type comparison ORX	-	9
	289	-	FOR<	-	Floating-point number contact type comparison ORX	-	9
	290	-	FOR<>	-	Floating-point number contact type comparison ORX	-	9
	291	-	FOR<=	-	Floating-point number contact type comparison ORX	-	9
	292	-	FOR>=	-	Floating-point number contact type comparison ORX	-	9
	139	RPR	-	✓	Read parameters of drive	5	_
Special	140	WPR	_	✓	Write parameters of drive	5	_
instructions for	141	FPID	_	✓	Drive PID control mode	9	_
drive	142	FREQ	_	✓	Operation control for drive	7	_
3	323	WPRA	_	-	Write the drive parameters in RAM	5	-

15-6-4 Instructions of application instructions

Instruction codes can be divided into 16-bit and 32-bit instructions. We prefix "D" to instruction code to indicate 32-bit instruction, and suffix "P" to instruction code to indicate a pulse executing instruction.

API	Ir	nstruct code					Ope	rand					Fund	ction	
01		CALI	_ P				;	S				Call sub	programs		
Туре	Е	Bit devi	ces			١	Nord (devices	3			16-bit iı	nstruction (3	steps)	
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	1	CALLP	Pulse execution				
Caution for u	ısing	opera	and:		K H KnX KnY KnM T C D CALL execution type call type										
Operand 3	S ca	n assi	gn P									32-bit iı	nstruction		
Operand :	S of	MP30	0 can	assig	n P0-	-P63						-	-	-	-
												Associat	ed flag: none		
	• 8	S: the	pointe	r of th	ne cal	l subp	rogra	am							
Description	• 5	Subpro	gram	must	be p	laced	after	FEND	instr	uctior	١.				
Description	• 5	Subpro	gram	must	end	with S	RET	instru	ction.						
	• F	Refer t	o the	descr	iption	and e	exam	ple of	FENI) insti	ructio	n for mo	re details.		

API	ı	nstructi code	on				Ope	rand					Fund	tions	
02		SRET						-				Subprog	rams end		
Туре	I	Bit devic	es			١	Word o	devices	3			16-bit in	struction (1	step)	
Operand	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	SRET	Continuous execution	-	-
Caution for u	sin	g opera	nd:								L	type		<u> </u>	
 No opera 	nd			struction											
No contains	ct to	drive t	he in	struct	ion is	requi	ired.					-	-	-	-
												Associate	ed flag: none	9	
		No con addres						is red	quired	l. Aut	omati	cally retu	ırns progra	m execu	tion to the
Description	•	This in	struc	tion o	ode	indica	ates t	he en	d of	subp	rogra	m. The	subprograr	n returns	s to main
		progra	n and	d begi	ns the	e exe	cution	with t	he in	struct	ion af	ter CALL	. instruction	١.	
	•	Refer t	the the	descr	iption	and	exam	ple of	FEN	O inst	ructio	n for mor	e details.		

PLC Program End

END


API	Instruction code	n				Ope	rand					Fun	ction	
06	FEND						-				Main pr	ograms en	d	
Туре	Bit device	s			\	Nord o	devices					nstruction (1		
Operand	Х Ү	М	K	Н	KnX	KnY	KnM	Т	С	D	FEND	Continuous execution		-
Caution for ι	ising operar	nd:									L	type	<u> </u>	
 No opera 	nd										32-bit ii	nstruction		
 No conta 		ne ins	struct	ion is	requi	red.					-	-		-
					•						Associat	ed flag: non	└ e	
	• This ins	truct	ion co	ode i	ndicat	es the	e end	of ma	in pr	ogran	n. It's th	e same as	END instruction	on i
	PLC								·	Ū				
		•		•		instru	ıction	must	be i	olace	d after	FFND ins	truction, and e	eac'
Description		•	-				T inst			Jiaco	u u	. 2.120	ara c	Juo
	•	•								ENID	inatruoti	on Dut EN	ID instruction r	~
						-			-			OII. DUL EI	IIISHUCHON I	Hus
	be place	eu ai	ter ma	am p	rogran	n and	Subpi	ogran	i to ti	ie ias	il.			
	ı				M0 M1			2	CALL		1	lain Progr ain Progr		
CALL instruction program flow		\times	× P() 1s	//1013 	pulse,	OFF			(Y RY1 SRE		ubroutine	P0	
			P.	1 1s	//1013 	pulse,	OFF			(Y RY2 SRE		ubroutine	P1	

API	Ins	structi	on				Ope	rand					Fun	ction	
10	D	code CMP	Р				S ₁ , S	S ₂ , D				Compa	re output va	alue	
Type		devic				\		devices	3				nstruction (7		
Operand	Х	Υ	М	K	Н	KnX	KnY		Т	С	D	CMP	Continuous execution		Pulse execution
S ₁				*	*	*	*	*	*	*	*	<u> </u>	type		type
S ₂				*	*	*	*	*	*	*	*	32-bit i	nstruction (1	3 steps)	
D		*	*										Continuous		Pulse
Caution for to Operand	_	•		nsecı	utive (device	es.					DCMP Associat	execution type ed flag: none		executior type
escription	S D C C T V	he two	nparis parisone re op o com	on va on res erand nparis en b1	alue 2 sult IS₁ a son va	nd S ₂	are co	ompar	ed al	gebra	ically		d in D. two value: egards the	_	
	• If	•	need veen \			com	pariso	on res	ult wi	th ≥,	≤, ar	nd ≠, mal	ke a serial-	parallel o	connectio
						10	C Y0 _ -	MP	K10			Y0 , Y0 = O1	N		
Example						10			- If K - If K	(10 >	D10,		N		
Example	■ To	o clea	r the	comp			Y0 		- If K - If K - If K	(10 > (10 = (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (10 < (D10,	, Y0 = ON , Y1 = ON , Y2 = ON	N		

ADI	In	struct	ion				0.50						F	ation.	
API		code						rand						ction	
11	D	ZCP	P				S ₁ , S ₂	<u>,</u> S, □)				mparison		
Туре	Bi	t devic	ces			\	Word o	device	S		I	<u>16-bit ir</u>	nstruction (9	·	Pulse
Operand	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	ZCP	Continuous execution	ZCPP	execution
S ₁				*	*	*	*	*	*	*	*	<u> </u>	type		type
S ₂				*	*	*	*	*	*	*	*	32-bit ir	nstruction (1	7 steps)	
S		_		*	*	*	*	*	*	*	*	4:	Continuous		Pulse
D		*	*									DZCP	execution type	DZCPP	execution type
Caution for u	ısing	opera	and:									Associate	ed flag: none	e	.:
The conte	ent in	S ₁ sh	nould	be sn	naller	than t	the co	ntent	in S ₂ .						
 Operand 	D oc	cupie	s 3 co	nsec	utive	device	es.								
Description	 D occupies 3 consecutive devices. S₁: lower bound of zone comparison S₂: upper bound of zone comparison S: comparison value D: comparison result S is compared with its S₁ and S₂, and the result is stored in D. When S₁ > S₂, the instruction performs comparison by using S₁ as the lower / upper bound. The two comparison values are compared algebraically, and the two values are signed binary values. When b15 = 1 in 16-bit instruction, the comparison regards the value as negative binary values. Designate device M0, and operand D automatically occupies M0, M1 and M2. When X0 = ON, ZCP instruction is executed, and one of M0, M1, and M2 will be ON. When 														
Example	• V >= • If	Vhen (0 = 0 - OFF you betv	X0 = DFF, Z need veen I	ON, ZCP into ob	zcp instruction at the struction at the struction at the struction at the structure at the	nstruction is	zcp zcp zcp ult, us M0	K10 If K1 If C1 E RS7	ecuted ted, a	, and Mond Mond Mond Mond Mond Mond Mond Mo	one), M1 ≤, an M0 = ON 00, M1 = ON	of M0, N, and M2 d ≠, mak	11, and M2 remain the ke a serial-	will be eir status	ON. When a before X0 connection

API	lı	nstructi code	on				Ope	erand					Fun	ction	
12	D	MOV	Р				S	, D				Move			
Туре	Е	Bit devic	es			١	Nord o	devices	3			<u>16-bit i</u>	nstruction (5	steps)	
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	MOV	Continuous execution	MOVP	Pulse execution
S				*	*	*	*	*	*	*	*	_ L	type		type
D							*	*	*	*	*	32-bit i	nstruction (9	steps)	
Caution for u	ısinç	g operand: none Continuous Pulse DMOV execution DMOVP execution type Associated flag: none													
Description															
Example		to D10 When	data X1 =	regis OFF,	ter. the c		t in D				nange		= ON, the v		

API	Ins	struct code					Оре	rand				Function
13		SMOV	′ P			S	, m ₁ , ı	m ₂ , D	n			Shift move
Туре	Bi	t devic	es			١	Word o	device	S		T	16-bit instruction (11 steps)
Operand	Х	Υ	М	K	Н	KnX	1	KnM	T	С	D	SMOV Continuous execution type Pulse execution type
S D				*	*	*	*	*	*	*	*	
	ioina	opore	nd: r	one			_ ^	_ ^	^	•	^	32-bit instruction (21 steps) Continuous Pulse
Caution for u	ısırıg	opera	aria. i	ione								DSMOV execution DSMOVP execution type type Associated flag: M1168
Description	• E c c c c c c c c c c c c c c c c c c	perati nstruc ne ope BIN me	mber tination t digit mode ton is tion of erand ode (ecima t data of ma	of dig on dev of the (M11 s simi copies D (al M116 al nur on th : 1-4	vice e desi 68 = ilar to the o so a 4 8 = 0 mber) he targ	tination OFF the design 4-digit ON): the get re cann	n pos i): in way nated BCD nis ins send gister	of the ition for this second digit of number struction to the will be large	or the mode, DV opof the per). on cohe oper	move SMO perate opera pies foerand perand perand perand	ed dig DV es des and s	gits enables to operate BCD number, the ecimal numbers. That is to say, this S (a 4-digit BCD number), and send to designated digit of the operand S (a 4- (also a 4-digit decimal number). The
Example	C	alcula ontent	M116 ting fi that	rom the starts 20 real	e 4 th from	digit (a) the Councha	mean 3 rd dig anged	is the git (me	thous eans t this ir	ands he hu nstruc K2	D10 digit) D10 digit) D10 digit)	nsfer the two-digit content that starts of D10's decimal value to the two digit ds digit) of D20's decimal number. 10 ³ s executed. D20 K3 (16-bit binary number) utomatic conversion (4-digit binary-coded decimal) ransferring the digits (4-digit binary-coded decimal) sutomatic conversion (16-bit binary number)



API		tructi code	on				Ope	rand				Function	
15		BMOV	/ P				S, I	D, n				Block move	
Туре	Bit	devic	es			١	Nord o	devices	3			16-bit instruction (7 steps)	
Operand	Χ	Υ	М	K	Н	KnX		KnM	Т	С	D	BMOV execution BMOVP execution type	11
S						*	*	*	*	*	*	i type i type	
D n				*	*		*	*	*	*	*	32-bit instruction	
Caution for u	sina (opera	nd:	**	**				**	**		Associated flag: none	
Scope of i	•	•										Associated flag. Hone	
Description	D n: • Th st	: start numl ne co arting evices	t of deber of the office of th	f data s in n i the o	tion of to be registed	levice move sters s e desi	ed startin gnate	d by	D. If ı	n exce	eeds	signated by S is moved to n registe the actual number of available sour will be used.	I
Example	• Ex As S	xamplessume and [X10 = 23. X10 le 2 le the D has d coinconful le 3 le 3 le conful le 5 > D	bit de to be M1000—	nce or be avenued.	f the covare continuing	KnY, that i	and kes, their kessee D19	D20 KnM a ir n ha ir	M M M M M M M M M M M M M M M M M M M	signal be the control of the control	(2) D12	of

API	In	structi code	on				Ope	rand					Fun	ction	
18	D	BCD	Р				S,	D				Conver	t BIN to BC	D	
Туре	В	t devic	es			\	Nord o	devices	3			16-bit i	instruction (5	steps)	
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	BCD	Continuous execution	BCDP	Pulse execution
S					* * * * * * type type										
D					* * * * 32-bit instruction (9 steps)										
Caution for u	sing	opera	nd: n	<u>32-bit instruction (9 steps)</u>											
Description	T		inatio	on of o	BIN ν							3CD valu	ue and store	ed in D.	
Example	• V	Vhen 2	X0 = sion ı	ON, t	he bii	nary v	K1Y	of D10) is co	onver he 4-l	ted in	vices).	value, and		Ç

API	lr	nstruct					Ope	rand					Fun	ction		
19	D	BIN	Р				S,	, D				Conver	t BCD to BI	N		
Туре	Е	Bit device	ces			,	Word o	device	S			16-bit	nstruction (5	steps)		
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	BIN	Continuous execution	BINP	Pulse execution	
S				* * * * * * type type												
D			32-bit instruction (9 steps)													
Caution for u	ısinç	g operand: none * * * * * 32-bit instruction (9 steps)														
Description	•	D: con The co	versio Intent	n res in S	(BCD		•	,				BIN valı)–99,999	ue and store 9,999	ed in D.		
Example	•	When :	X0 = 0	ON, th	ne BC	D val	ue of		0 is c	onver	ted to	BIN va	lue and stor	ed in D1	0.	
Remark													, BIN instrudata in PLC.	ction has	s to be first	

API		structi code	on	Operand								Function						
20		ADD	Р				S ₁ , S	S ₂ , D				BIN addition						
Type	Bit	devic	es			1	Nord o	device	S			16-bit	instruction (7	steps)				
	Х	Υ	М	К	Н	KnX	KnY	KnM	Т	С	D	ADD	Continuous	A D D D	Pulse			
Operand S ₁				*	*	*	*	*	*	*	*	ADD	execution type	ADDP	execution type			
S ₂				*	*	*	*	*	*	*	*							
D				**		 "	*	*	*	*	*	<u>32-bit instruction (13 steps)</u>						
Caution for using operand: none DADD execution type												i — i	execution					
	• \$		nman	d								M102 M102 M102	ted flag: 20: Zero flag 21: Borrow fla 22: Carry flag he following	J	type ons.			
Description	S D T (-	2: addo : sum his in: he hig 9) = - lag ch . If the	struct ghest 6. nange e ope	ion ad bit is es in bration ration	syml inary resu resu		oit 0 (- ion: zero 2,768	+) and flag N	d 1 (-) 11020 ow fla	, which = ON g M1	ch is I. 021 =	= ON.		ic additio	on, e.g. 3 +			
				l addi		11 > 32	_,/0/,	Carry	ilay i	VIIUZ	2 – 0	/IN.						
Example						_	in D0	<u>.</u>	the co	ntent	in D	10 and th	ne sum is st	tored in I	D20.			
Remark	● F	16 -2	-bit: 2, -1, Borro 2-bit: 2, -1,	Zero f	lag 32,76 / - g 1	/ nega 58 The higher data 483,6 The higher data	ghest! 48 ←	bit of (negation)	ero fla 0, vive)	g 1 — The h the da The	ighes ata = 0	→ 32,7 st bit of 0 (positiv	Zero fla 483,647, 0	▼ ag				

API	ı	nstruct code		Operand								Function				
21	Δ	SUB	Р	S ₁ , S ₂ , D							BIN subtraction					
Type		Bit devi	ces	Word devices							16-bit instruction (7 steps)					
Operand	X	Y	М	K	Н	KnX	KnY	KnM	Т	С	D	Continuous SUBP	Pulse execution			
S ₁				*	*	*	*	*	*	*	*	type	type			
S ₂				*	*	*	*	*	*	*	*	32-bit instruction (13 steps)				
D							*	*	*	*	*	Continuous	Pulse			
Caution for u	ion for using operang, none												execution type			
Associated flag: M1020: Zero flag M1021: Borrow flag M1022: Carry flag See the following descriptions.												ons.				
Description	 S₁: minuend S₂: subtrahend D: difference This instruction subtracts S₁ and S₂ in BIN format and stores the result in D. The highest bit is symbolic bit 0 (+) and 1 (-), which is suitable for algebraic subtraction. Flag changes in binary subtraction: If the operation result = 0, zero flag M1020 = ON. If the operation result < -32,768, borrow flag M1021 = ON. If the operation result > 32,767, carry flag M1022 = ON. 												iion.			
Example	•	In 16-b When D20.					t in D	00 min	nus th	e cor	ntent	in D10 and the difference i	s stored in			

API	Ins	struct		Operand									Function				
22	D	MUL	Р		S ₁ , S ₂ , D BIN multipl												
Type	Bi	t devic	es	Word devices							16-bit instruction (7 steps)						
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	MUL	Continuous execution	MULP	Pulse execution		
S ₁				*	*	*	*	*	*	*	*	T	type	<u> </u>	type		
S ₂				*	*	*	*	*	*	*	*	32-bit instruction (13 steps)					
D							*	*	*	*	*	JZ-DIL	Continuous	o steps)	Pulse		
Caution for u	sing operand: DMUL execution DMULP execution													execution			
	t instruction, operand D occupies 2 consecutive devices. Let type type type type Associated flag: none																
Description	 S1: Multiplicand S2: Multiplicator D: Product This instruction multiplies S1 by S2 in BIN format and stores the result in D. In 16-bit BIN multiplication, S1 S2 D+1 D b15b0 b31b16b15b0 b31 is a symbol bit (b15 of D+1) Symbol bit = 0 refers to a positive value Symbol bit = 1 refers to a negative vlalue When D serves as a bit device, it can designate K1-K4 and construct a 16-bit result, occupying consecutive 2 groups of 16-bit data. 																
Example	b	its ar	e stoi	ed in	D21	and t	he lo	wer 1	6-bit a	are st	valu	in D20.	ON / OFF		Ū		


API	In	structi code		Operand									Function				
23	D	DIV	Р	S ₁ , S ₂ , D								BIN division					
Туре	Bi	t devic	es			١	Nord o	devices	S			16-bit instruction (7 steps)					
Operand	Х	Υ	М	К	Н	KnX	KnY	KnM	Т	С	D	DIV	Continuous execution	DIVP	Pulse execution		
S ₁				*	*	*	*	*	*	*	*	<u> </u>	type	<u> </u>	type		
S ₂				*	*	*	*	*	*	*	*	32-bit i	nstruction (1	3 steps)			
D							*	*	*	*	*		Continuous		Pulse		
Caution for u													execution type				
• In 16-bit i	instruction, operand D occupies 2 consecutive devices. Instruction Instruction Associated flag: none Instruction Instructio													<u> </u>			
Description	• T p	S ₂ : Divisor D: Quotient and remainder This instruction divides S ₁ and S ₂ in BIN format and stores the result in D. Be careful with the positive / negative signs of S ₁ , S ₂ and D when doing 16-bit operation. In 16-bit BIN division, Quotient Remainder S1 b15b0 b15b0 b15b0 cupying consecutive 2 groups of 16-bit data and bringing forth the quotient and remainder.															
Example				-			•			•	tive /		tored in D2 e status of t				

API	lı	nstructi		Operand								Function			
24	D	INC	Р		D							BIN increment (plus one)			
Type	Е	Bit devic	it devices Word devices									16-bit instruction (3 steps)			
Operand	Х	Y	М	K	Н	KnX	X KnY KnM T C D					INC	Continuous execution	INCP	Pulse execution
D							*	*	*	*	*	<u> </u>	type	<u> </u>	type
Caution for u	Caution for using operand: none												instruction (5	steps)	
DINC execution DINCP execution type type Associated flag: none													execution		
Description	 D: destination devices If the instruction is not a pulse execution one, the content in the designated device D will plus "1" in every scan period whenever the instruction is executed. This instruction generally adopts pulse execution instructions (INCP). 												·		
	 In 16-bit operation, 32,767 plus 1 and obtains -32,768. In 32-bit operation, 2,147,483,647 plus 1 and obtains -2,147,483,648. 													70,017 pido	
Example	•	● When X0 = OFF→ON, the content in D0 plus 1 automatically.													

API	I	nstruct					Ope	rand					Fun	ction	
25	D	DEC	Р				[)				BIN de	crement (mi	inus one)
Туре	E	3it devi	ces			١	Nord o	devices	3			16-bit	instruction (3	steps)	
Operand	Х	Y	М	К	Н	KnX	KnY	KnM	Т	С	D	DEC	Continuous execution	DECP	Pulse execution
D							*	*				<u> </u>	type	<u> </u>	type
Caution for u	ısin	g oper	and: r	none								32-bit	instruction (5	steps)	
												DECC	Continuous execution type	DDECP	Pulse execution type
		D: des	tinotic	on dos	/i000							ASSOCIA	ted flag: none	е	
Description	•	If the min This ir	instru us "1" nstruct	ction in ev	is no ery so enera	an pe	eriod v opts p	whene oulse e	ever the execu	ne ins tion ir	truction estruc	on is exections (D	ECP).		
	•								nd obt	ains	32,76	57. In 32	2-bit operati	on, -2,1	47,483,648
		minus	1 and	d obta	ins 2,	147,4	83,64	17.							
	•	When	X0 =	OFF-	>ON,	the c	onten	t in DO) minu	ıs 1 a	utom	atically.			
Example								X		Ю					

Operand X Y M K H KnX KnY KnM T C D ROR execution type execution for using operand: Operand X Y M K H KnX KnY KnM T C D ROR execution type execution for using operand: Operand X Y M K H KnX KnY KnM T C D ROR execution type execution for using operand: Operand X Y M K H KnX KnY KnM T C D ROR execution type execution for using operand: Operand X Y M K H KnX KnY KnM T C D ROR execution type execution for using operand: Operand X Y M K H KnX KnY KnM T C D ROR execution type execution for using operand: Operand X Y M K H KnX KnY KnM T C D ROR execution type execution for using operand: Operand X Y M Kn KnY KnM T C D ROR execution type execution for using operand: Operand X Y M Kn KnY KnM T C D ROR execution type execution for using operand: Operand X Y M Kn KnY KnM T C D ROR execution type execution for using operand: Operand X Y M Kn KnY KnM T C D D ROR execution type execution for using operand: Operand X Y M Kn KnY KnM T C D D ROR execution type execution for using operand: Operand X Y M Kn KnY KnM T C D D ROR execution type execu	API	ļ	nstructi code					Ope	rand					Fun	nction		
Operand X Y M K H KnX KnY KnM T C D ROR Continuous execution type D 32-bit instruction (9 steps) Caution for using operand: If D is designated as KnY, KnM, only K4 (16-bit) is valid. Scope of n = K1-K16 (16-bit) Description Description Description Description Description Description Description Operand A Sociated flag: M1022, Carry flag Description Description ROR RORP Pulse execution instruction (9 steps) Continuous execution instruction (9 steps) Continuous execution instruction (9 steps) Continuous execution instruction (9 steps) Pulse execution in RORP Associated flag: M1022, Carry flag Description Normal Rore Normal R	30	D	ROR	Р				D,	, n				Rotate	right			
Operand X Y M K H KnX KnY KnM T C D ROR ROR RORP RORP Pute execution type n	Type	F	Bit devic	es			1	Nord o	devices	3			16-bit	instruction (5	steps)		
Caution for using operand: If D is designated as KnY, KnM, only K4 (16-bit) is valid. Description Description Description Description Description Description Description Description Description This instruction rotates the device content designated by D to the right for n bits. This instruction generally adopts pulse execution instructions (RORP). When X0 = OFF→ON, the 16 bits (4 bits as a group) in D10 rotates to the right, as show the figure below. The bit marked with ※ is sent to carry flag M1022. Rore D10 K4 Rotate to the right Higher bit D10 0 1 1 1 1 1 0 1 1 0 1 0 0 1 1 0 1 M1022 Carry flag Example		Х	Y	М	К	Н	KnX	KnY	KnM	Т	С	D	ROR	execution	RORP	Pulse execution	
Caution for using operand: If D is designated as KnY, KnM, only K4 (16-bit) is valid. Description Descript	D							*	*	*	*	*	<u> </u>	type		type	
Caution for using operand: If D is designated as KnY, KnM, only K4 (16-bit) is valid. Scope of n = K1–K16 (16-bit) Description Desc	n				*	*							32-bit	instruction (9	steps)		
• If D is designated as KnY, KnM, only K4 (16-bit) is valid. • Scope of n = K1–K16 (16-bit) Description Description Description Description Description This instruction rotates the device content designated by D to the right for n bits. This instruction generally adopts pulse execution instructions (RORP). When X0 = OFF→ON, the 16 bits (4 bits as a group) in D10 rotates to the right, as shown the figure below. The bit marked with ※ is sent to carry flag M1022. X0	Caution for u	ısin	g opera	ınd:										Continuous		Pulse	
 Scope of n = K1–K16 (16-bit) D: device to be rotated n: number of bits to be rotated in 1 rotation This instruction rotates the device content designated by D to the right for n bits. This instruction generally adopts pulse execution instructions (RORP). When X0 = OFF→ON, the 16 bits (4 bits as a group) in D10 rotates to the right, as show the figure below. The bit marked with ※ is sent to carry flag M1022. RORP D10 K4 Rotate to the right Higher bit Lower bit D10 0 1 1 1 1 0 1 0 1 0 0 1 0 1 M1022 Carry flag 	If D is des	sign	ated as	KnY	, KnM	, only	K4 (1	(6-bit	is va	lid.			DROR	1	DRORP	execution type	
n: number of bits to be rotated in 1 rotation This instruction rotates the device content designated by D to the right for n bits. This instruction generally adopts pulse execution instructions (RORP). When X0 = OFF→ON, the 16 bits (4 bits as a group) in D10 rotates to the right, as shown the figure below. The bit marked with ※ is sent to carry flag M1022. X0	Scope of	n =	K1-K1	6 (16	-bit)								Associa)22, Carr		
 This instruction rotates the device content designated by D to the right for n bits. This instruction generally adopts pulse execution instructions (RORP). When X0 = OFF→ON, the 16 bits (4 bits as a group) in D10 rotates to the right, as show the figure below. The bit marked with ※ is sent to carry flag M1022. Rore D10 K4 Rotate to the right Higher bit Lower bit D10 0 1 1 1 1 0 1 0 0 0 1 0 1 M1022 Carry flag 16 bits 	-	•	D: devi	vice to be rotated													
 This instruction rotates the device content designated by D to the right for n bits. This instruction generally adopts pulse execution instructions (RORP). When X0 = OFF→ON, the 16 bits (4 bits as a group) in D10 rotates to the right, as shown the figure below. The bit marked with ※ is sent to carry flag M1022. RORP D10 K4 Rotate to the right Higher bit Lower bit D10 0111110101000101 M1022 Carry flag 16 bits 			n: num	number of bits to be rotated in 1 rotation													
 This instruction generally adopts pulse execution instructions (RORP). When X0 = OFF→ON, the 16 bits (4 bits as a group) in D10 rotates to the right, as shown the figure below. The bit marked with ※ is sent to carry flag M1022. RORP D10 K4 Rotate to the right Higher bit Lower bit D10 01111101101001101 M1022 Carry flag 	Description																
When X0 = OFF→ON, the 16 bits (4 bits as a group) in D10 rotates to the right, as show the figure below. The bit marked with ※ is sent to carry flag M1022. X0				his instruction rotates the device content designated by D to the right for n bits.													
the figure below. The bit marked with $\%$ is sent to carry flag M1022. X0							•						,		e right, a	s shown in	
Rorp D10 K4 Rotate to the right Higher bit Lower bit D10 0 1 1 1 1 0 1 0 0 0 1 0 1 Example To bits Carry flag									•		•	• ′			,g, o		
It to the right Lower bit D10 1 1 1 1 0 M1022 Image: Size of the content of the conten	Example		ino ngc			D10	High	R er bit	ORP otate 0 1 1 16bits After o the	to the	K4 e righ Lov	t werb	oit 1 C	M1022 Carry flag	022		

API		structi code					Ope	rand				Function				
31	D	ROL	P				D	n				Rotate left				
Туре	Bi	t devic	es			١	Nord o	levices	3			16-bit instruction (5 steps)				
Operand	Χ	Υ	М	К	Н	KnX	KnY		Т	С	D	ROL execution ROLP execution				
D							*	*	*	*	*	type type				
n				*	*							32-bit instruction (9 steps)				
Caution for u	ısing	opera	and:									Continuous Pulse DROL execution DROLP execution				
If D is dea	signa	ited as	s KnY	∕, KnN	1, only	/ K4 (16-bit) is va	ılid.			DROL execution DROLP execution type				
 Scope of 	n = k	<1–K1	6 (16	S-bit)								Associated flag: M1022, Carry flag				
	• [): dev	ice to	be ro	tated											
Description	n	: num														
Description	• T	: number of bits to be rotated in 1 rotation														
	• T	This instruction rotates the device content designated by D to the left for n bits. This instruction generally adopts pulse execution instructions (ROLP).														
	• V	Vhen 2	X0 =	OFF-	>ON,	the 10	6 bits	(4 bits	s as a	grou	p) in l	D10 rotates to the left, as shown in the				
	fi	gure l	elow	. The	bit m	arked	with	∦ is s	ent to	carry	/ flag	M1022.				
						X0 	[F	ROLF	P D1	0 K	4					
									I	Rota	te to	the left				
								High	er bi	- ◀		Lower bit				
Example					M1	022 y flag		1 1	1 1 1 			0000000 D10				
						,	, [!	16 b	_	fter 1 rotation to the left				
			M	1022		1· **			ner bi		00	Lower bit 000011111 D10				




41 DECO P S, D, n Decode Type Bit devices Word devices 16-bit instruction (7 steps) V Y M K H KnX KnM T C D DECO Continuous execution type DECOP execution type Pulse execution type D * * * * * * * * 32-bit instruction (13 steps) Continuous execution DDECOP execution DDECOP execution DDECOP execution and the color of the color of type Pulse execution DDECOP execution DD	API	I		tructi code	on				Ope	rand				Function
Operand X Y M K H KnX KnY KnM T C D DECO Continuous execution type D	41		D	ECO	Р				S, I	D, n				Decode
Operand X Y M K H KnX KnY KnM T C D DECO Continuous execution type DECOP execution type S *	Type	ı	Bit	devic	es			١	Nord o	devices	3			
D * * * * * * * * * 32-bit instruction (13 steps) Caution for using operand: none DDECO DDECO Execution DDECO Execution DDECO DDECO Execution DDECOP		X		Υ	М	K	Н	KnX	KnY	KnM	Т	С	ii : : : : : : : : : : : : : : : : : :	
n	S	*		*	*	*	* * * * *							type type
n	D			*	*				*	*	*	*	32-bit instruction (13 steps)	
ICaulion for using operang, none	n					*	*							
type n type	Caution for u	sin	g c	pera	ınd: n	one							DDECO execution DDECOP executio type n type	
Associated flag: none														Associated flag: none

S: source device to be decoded

D: device for storing the decoded result

n: length of decoded bits

- The instruction decodes the lower "n" bits of S and stores the result of "2" bits in D.
- This instruction generally adopts pulse execution instructions (DECOP).
- When operand D is bit device, n = 1-8, and when operand D is word device, n = 1-4.
- Example 1
 - 1. When D is used as a bit device, the valid range is $0 < n \le 8$. Error occurs when n = 0 or n > 8.
 - 2. When n = 8, the maximum points to decode is $2^8 = 256$ points.
 - 3. When M200 = OFF→ON, this instruction decodes the content in X0–X2 to M100–M107
 - 4. If S = 3, M103 (third bit from M100) = ON.
 - 5. After executing the instruction, M200 becomes OFF. The decoded results have been output retain their operation.




Example


Description

Example 2

- 1. When D is used as a word device, the valid range is $0 < n \le 4$. Error occurs when n = 0 or n > 4
- 2. When n = 4, the maximum points to decode is $2^4 = 16$ points.
- 3. When M200 = OFF→ON, this instruction decodes the content in D10 (b2–b0) to D20 (b7–b0). The unused bits in D20 (b15–b8) become 0.
- 4. The lower 3 bits of D10 are decoded and stored in the lower 8 bits of D20. The higher 8 bits of D20 are all 0.
- 5. After executing the instruction, M200 becomes OFF. The decoded results have been output retain their operation.



Chapter 15 PLC Function Applications | MPD



API	lr	nstruc		n				Ope	rand				Function
42		ENC	0	Р				S, I	D, n				Decode
Туре	Е	Bit dev	ice	s			١	Nord o	devices	3			16-bit instruction (7 steps)
Operand	Х	Y		М	K	Н	KnX	KnY	KnM	Т	С	D	Continuous Pulse ENCO execution
S	*	*		*						*	*	*	type type
D								*	*	*	*	*	32-bit instruction (13 steps)
n					*	*							Continuous Pulse
Caution for t	usin	g ope	rar	nd: n	one								DENCO execution DENCOP execution type type
													Associated flag: none
		٥٠ ٥٥	ııra	م طر	vioo :	to ho	doco	404					


- S: source device to be decoded
 - D: device for storing the decoded result
 - n: length of decoded bits

Description

- The instruction decodes the lower "n" bits of S and stores the result in D.
- If several bits of S are 1, the first bit that is 1 will be processed orderly from high bit to low bit.
- This instruction generally adopts pulse execution instructions (ENCOP).
- When operand S is bit device, n = 1−8, and when operand S is word device, n = 1−4.

• Example 1


- 1. When S is used as a bit device, the valid range is $0 < n \le 8$. Error occurs when n = 0 or n > 1
- 2. When n = 8, the maximum points to encode is $2^8 = 256$ points.
- 3. When X0 = OFF→ON, this instruction encodes the content in 2³ bits (M0–M7) and stores in the lower 3-bit (b2-b0) of D0. The unused bits in D0 (b15-b3) become 0.
- 4. After the execution is completed, X0 becomes OFF, and the data in D remains unchanged.




Example

• Example 2

- 1. When S is used as a word device, the valid range is $0 < n \le 4$. Error occurs when n = 0 or n > 4.
- 2. When n = 4, the points to encode can be $2^4 = 16$ points.
- 3. When X0 = OFF→ON, this instruction encodes the content in 2³ bits (b0-b7) of D10 and stores in the lower 3-bit (b2-b0) of D0. The unused bits in D20 (b15-b3) become 0. (b8b15 in D10 are invalid data)
- 4. After the execution is completed, X0 becomes OFF, and the data in D remains unchanged.



Chapter 15 PLC Function Applications | MPD



API	Ins	structi code	on				Ope	rand					Fun	ction	
43	D	SUM	Р				S,	D				Sum of	active bits		
Type	Bi	t devic	es			١	Nord o	devices	8			<u>16-bit</u>	instruction (5	steps)	
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	SUM	Continuous execution	SUMP	Pulse execution
S				*	*	*	*	*	*	*	*	<u> </u>	type	<u> </u>	type
D									*	*	*	32-bit	instruction (9	steps)	
Caution for u	ısing	g operand: none * * * * 32-bit instruction (9 steps) Continuous DSUMP execution type Associated flag: M1020													execution
Description	• T	he su Vhen u Operar	tination m of using	on devall bits 32-bi D use	s who t insti e devi	se co uction ce F, a	ntents n, D o and th	ccupie	'1" in es two in only	S will regis use	sters. 16-bi	it instruc			
Example	fi	gure b /hen l	M200 H200	. The	bit m	arked sum o	with	is sose co	ent to	carry	/ flag "1" in	M1022.	of D0 will b	e stored	

API	In	structi code					Ope	rand					Fun	oction	
44	D	BON	Р				S, I	D, n				Check	specified bit	status	
Type	Bi	t devic	ces			1	Word o	devices	6			16-bit	instruction (7	steps)	
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	BON	Continuous execution	BONP	Pulse execution
S				*	*	*	*	*	*	*	*		type	<u> </u>	type
D		*	*						*	*	*	32-bit	instruction (9	 (steps)	
n				*	*				*	*			Continuous		Pulse
Caution for t	using	opera	and: r	none								DBON	type	DBONP	execution type
	1	Associated flag: none S: source device D: device for storing check result n: bit number to be checked (numbered from 0)													
Description	• T • C • V	o: dev : bit n he ins o. Operai alid ra	ice for sumber struct and S cange X0 = comes 0 b15 b15	r stori er to b ion ch uses o of ope	device erand the k	ecked the st e F, ar n: n = bit15 c remair	(num tatus of the second of th	ey can 5 (16-lis "1", its pre	ignat only oit), n then	ed bit use 1 = 0-3 M0 = statu	6-bit i 31 (32 ON; i	instruction (2-bit) f it's "0",	n) in S and ons. then M0 =		ff

API	l	nstru					Ope	rand					Fun	ction	
49	D	FL	Г				S,	D				BIN inte	eger → binar r	y floatin	g-point
Туре	E	Bit de	/ices			1	Nord o	devices	3			16-bit	instruction (5	steps)	
Operand	Х	Y	М	К	Н	KnX	KnY	KnM	Т	С	D	FLT	Continuous execution	FLTP	Pulse execution
S									*	*	*	İ	type	<u> </u>	type
D									*	*	*	32-bit	instruction (9	steps)	
Caution for u Operand		•		consec	utive	device	es.					DFLT	Continuous execution type		Pulse execution type
See the s	pec	ificat	ion of	each r	nodel	for th	e sco	pe of	device	e's us	age.	Associa	ited flag: none	ь е	
	•	S: sc	urce	device	for co	nvers	ion								
Description		D: de	vice f	or stor	ing th	e con	versio	n resi	ult						
	•	Conv	ert Bl	N integ	ger to	binary	/ float	ing-po	oint nu	ımbei	r.				
	•	Whe	n M20	00 = C	N, co	nvert	the	BIN ir	teger	s cor	respo	nding t	o D0 and [O1 to flo	pating-point
		numl	ers a	nd put	into E)20 ar	nd D2	1.	_						
Example				M	200 		DF	LT	D	0	С	020			

API	I	nstruct code					Ope	rand					Fun	ection	
110	D	ECMF	Р				S ₁ , S	S ₂ , D				Binary flo	oating-poin son	t number	
Туре	E	3it devic	ces			١	Nord o	devices	3			16-bit ir	nstruction		
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	-	-	-	-
S ₁				*	*						*	22 hit in		2 otopo)	
S ₂				*	*						*	32-011 11	nstruction (1 Continuous		Pulse
D											*	DECMP	execution		execution
Caution for u	sin	g opera	and:									Associate	type ed flag: non		type
Operand I	Dο	ccupie	s 3 cc	nsec	utive	device	es.					7 tooooiat	od nag. non	·	
See the s	pec	ificatio	n of e	ach n	nodel	for th	e sco	pe of o	devic	e's us	age.				
	•	S₁: bin	ary flo	oating	-poin	t num	ber co	ompar	ison \	/alue	1				
		S ₂ : bin	,												
		D: com	binary floating-point number comparison value 2 comparison result, occupies 3 consecutive devices												
Description	•	The bi	comparison result, occupies 3 consecutive devices e binary floating-point value 1 and 2 are compared with each other. The comparison result												
		(>, =, <	<) is s	tored	in D.									·	
						ated	const	ant K	or H	, the	instru	uction wi	Il convert	the const	ant into a
		binary			_										
	•										cally	occupies	M10 to M1	12.	
	•	When	X0 =	ON, I	DECN	1P ins	tructi	on is e	execu	ted, a	and o	ne of M1	I0, M11, ar	nd M12 w	ill be ON.
		When	X0 =	OFF,	DEC	MP ir	nstruc	tion is	not	execu	uted,	and M10), M11, and	d M12 rei	main their
		status													
	•	If you	need	to ob	tain a	a com	paris	on res	sult w	ith ≥,:	≤, an	d ≠, mak	e a serial-	parallel c	onnection
		betwee					•								
	•	To clea	ar the	comp	ariso	n resu	ılt, us	e RST	or ZI	RST i	nstru	ction.			
Example				•	_I X		,								
						Ĭ—	DE	СМР	D)	D10	0 M1	0		
					,	`	M10		ı						
							1		ON w	nen (E	01, D	0) > (D10	1, D100)		
							M11								
							+		ON w	nen ([01, D	0) = (D10	1, D100)		
							M12		ON	20p/F	34 D	0) ~ (D40	1 D100\		
							1		ON W	ien (L	יט, וע	0) < (D10	ו, טוטט)		

API	In	struction	on				Ope	rand				Function				
111	D	EZCP	Р			,	S ₁ , S ₂	2, S, D				Binary floating-point number zone comparison				
Туре	В	it devic	es			١	Nord o	devices	3			16-bit instruction				
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	- -				
S ₁				*	*						*	32-bit instruction (17 steps)				
S ₂				*	*						*	Continuous Pulse				
S				*	*						*	DEZCP execution DEZCPP execution type type				
D		*	*									Associated flag: none				
Caution for u	ısing	opera	ınd:													
Operand	D oc	cupies														
See the s	peci	fication	of each model for the scope of device's usage. er bound of binary floating-point in zone comparison													
Description		S ₂ : upp S: bina D: com S is coi f S ₁ oi binai When S	cation of each model for the scope of device's usage. I lower bound of binary floating-point in zone comparison I upper bound of binary floating-point in zone comparison binary floating-point number comparison value comparison result, occupies 3 consecutive devices s compared with S_1 and S_2 , and the result is stored in D. S_1 or S_2 is a designated constant K or H, the instruction will convert the constant into a binary floating-point value before the comparison. Then $S_1 > S_2$, the instruction uses S_1 as upper / lower bound for comparison. The signate the device to be M0, and this automatically occupies M0 to M2.													
Example	• \	When >	K0 = ()FF, E FF.	ON, E	DEZC instru ariso	P instruction	ructio is no ult, use	n is ex t exec e RST ON wi	recution of the control of the contr	ed, and, and RST in D10	d one M0, N nstruc 0)) > (I 0)) ≤ (I	e of M0, M1, and M2 will be ON. When M1, and M2 remain their status before				

API	In	structi code	on				Ope	rand				Function
116	D	RAD	Р				S,	D				Degree → Radian
Type	В	t devic	es			١	Nord o	devices	3			16-bit instruction
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	
S				*	*						*	32-bit instruction (9 steps)
D											*	Continuous Pulse
Caution for t	using	opera	and:									DRAD execution DRADP execution type
• See the s	peci	ficatio	n of e	ach n	nodel	for th	e sco	pe of	devic	e's us	age.	Associated flag: none
Description	• V	Vhen :	ılt (rade) e follo adian X0 =	dian) owing = Deg ON, o	form gree :	ula to x (π / ·	180) he de	egree	of bir	nary flary floa	oatin	ng-point number (D1, D0). Convert the point in (D11, D10).
Example			S		D1		D0	B A	inar	in ra	ting	ees point ns = degrees X (π / 180) point

API	Ins	structi code	on				Ope	rand				Function					
117	D	DEG	Р				S,	D				Radian → Degree					
Type	Bit	t devic	es			١	Nord o	devices	6			16-bit instruction					
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Τ	С	D						
S				*	*						*	32-bit instruction (9 steps)					
D											*	Continuous Pulse					
Caution for u	ısing	opera	ınd:									DDEG execution DDEGP execution type type					
• See the sp	pecifi	cation	of ea	ach m	n model for the scope of device's usage. Associated flag: none ata (radian)												
Description	D	: resu Ise the	ılt (de e follo	each model for the scope of device's usage. Associated flag: none degree) llowing formula to convert radian to degree. e = Radian x (π / 180)													
Example			into c		e and	store		A E	n bina	in rac	ating dians ting p	s = radians X (180 / π)					

API	Ir	nstruct code					Ope	rand				Function
120	D	EADI) P				S ₁ , S	S ₂ , D				Binary floating-point number addition
Туре	Е	Bit devi	ces			١	Nord o	devices	3			16-bit instruction
Operand	Х	Υ	М	К	Н	KnX	KnY	KnM	Т	С	D	
S ₁				*	*						*	32-bit instruction (13 steps)
S ₂				*	*						*	Continuous Pulse
D											*	DEADD execution DEADDP execution
Caution for u	ısing	g oper	and:	•				'				Associated flag: none
See the s	•	•		ach m	nodel	for the	e sco	oe of o	device	e's us	age.	5
Description	•	desigrin the If S_1 of binary S_1 an "contile the dr	n content nates, form of S ₂ in floating d S ₂ in the content of	and in a sand in	ts sur ary flo desig int va lesigr ution	m is sing- pating- nated alue be nate the type"	tored point cons efore ne sa instru	in the numb tant ket action me restriction	regisers. Cor Holditionegiste	ter th d, the n. r. In t	instration	s the content of the register that S ₂ designates. This addition is performed auction will convert the constant into a case, if the instruction is specified as a type DEADDP is generally used) and in every scan.
Example	r	numbe Exam _l When	X0 = ers (D3 oble 2	3, D2) ON, th	, and	store:	s the	result	in (D	11, D1	D11,	D1, D0) add the binary floating-point D10) add K1234 (convert to binary alt in (D21, D20).

											Спар	iler 13 FL	C Function	і Арріісац	OIIS WIFD	
API	In	struct					Ope	rand					Fun	nction		
121	D	ESUB					S ₁ , S	S ₂ , D				Binary flo	pating-poin	t number s	subtraction	
Туре	В	it devi	es			\	Nord o	devices	6			16-bit in	nstruction			
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	-	-	-	-	
S ₁				*	*						*	32-bit in	nstruction (1	3 steps)		
S ₂				*	*						*		Continuous		Pulse	
D			DESUB execution type type Description type type Associated flag: none													
Caution for u	ısing	opera	perand: type type Associated flag: none													
See the s	peci	ficatio														
Description		design perform f S ₁ opinary S ₁ and continute driving the driving	erence ct the ates, med in S ₂ floating S ₂ uous ve co	e cont and in the tis a cong-po- can deexec	its difform of designation to the different contraction of the different c	ference of binated lue be late the type"	ce is any floconstant constant	stored ating- ant K the su me re	in the point or Hobersteen the best point of the point of	e regnumb, the ion.	ister pers. instru this coution	that D do uction will case, if the type DE	content of esignates. Il convert one instruct of subprise gery scan.	This sub	traction is ant into a ecified as	
Example	v r	Examp	X0 = rs (D3 ble 2 X2 = 0	3, D2)	, and	store:	s the	result	in (D	oint n	10).	ers (D1, D	otract the k	1234 (con		

API	Ir	nstructi code					Ope	rand				Function		
122	D	EMUL					S ₁ , S	S ₂ , D				Binary floating-point number multiplication		
Туре	Е	Bit devic	es		ı	١	Nord o	devices	3			16-bit instruction		
Operand	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	- - -		
S ₁				*	*						*	32-bit instruction (13 steps)		
S ₂				*	*						*	Continuous Pulse		
D											*	DEMUL execution DEMULP execution type		
Caution for u	ısinç	g opera	and:									Associated flag: none		
• See the s	peci	ficatior	and: Associated flag: none n of each model for the scope of device's usage.											
Description	•	design perforn If S ₁ o binary S ₁ and "contin	duct entent ates, ned in r S ₂ if floatin I S ₂ i	t of the and in the fision of	its proform of lesign int valuesign ution	oduct of bina nated lue be ate th type"	is sto ary flo const fore t ne sa instru	ored ir ating- ant K he mu me re ction	n the point or H ultiplic egister (pulse	regist numb , the ation : In t	er the ers. instru	es the content of the register that S ₂ at D designates. This multiplication is uction will convert the constant into a case, if the instruction is specified as a type DEMULP is generally used) and ce in every scan.		
Example	t	he pro Examp When >	(1 = 0 duct t le 2 (2 = 0	o the	regis	ter that	34 (cc (D1,	1, D2	to bir	nary fl	e.	g-point number automatically) and the esult in (D11, D10).		

API	Ins	structi code					Ope	rand				Function
123	D	EDIV	Р				S ₁ , S	S ₂ , D				Binary floating-point number division
Туре	Bit	devic	es			١	Nord o	devices	3			16-bit instruction
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	- - -
S ₁				*	*						*	32-bit instruction (13 steps)
S ₂				*	*						*	Continuous Pulse
D											*	DEDIV execution DEDIVP execution type type
Caution for ι	ısing	opera	and:									Associated flag: none
• See the s	pecif	icatio	n of e	ach n	nodel	for the	e sco	pe of o	device	e's us	age.	
Description	• T de	he co esign erforn S ₁ o	otient ontent ates, ned ir r S ₂ i	of the and the first the first the first and	its q form of lesign	gister in uotien of binated	t is s ary flo const	stored ating- _l	in tooint or H	ne re numb , the	gister ers.	by the content of the register that S_2 that D designates. This division is uction will convert the constant into a
Example	• E	umbe xamp /hen)	(1 = (r (D11 le 2 (2 = (), D10)), and	d store	e the	quotie	nt to	pers (gister	o) divides by the binary floating-point rethat (D21, D20) designate. o) divides by K1234 (convert to binary lit in (D11, D10).

API	ı	nstructi code	on				Ope	rand					Fun	ection	
124	D	EXP	Р				S,	D				Binary f	floating-poin ntiation	t number	
Type	E	Bit devic	es			١	Nord o	devices	5			<u>16-bit</u>	<u>instruction</u>		
Operand	Х	Υ	М	К	Н	KnX	KnY	KnM	Т	С	D	-	-	-	-
S				*	*						*	32-hit	instruction (9	stens)	
D											*		Continuous		Pulse
Caution for u	ısin	g opera	ınd:	1						U.		DEXP	execution type	DEXPP	execution type
• See the s	pec	ificatior	of e	ach m	nodel	for the	e scor	oe of o	device	's usa	age.	Associa	ted flag: non	<u> </u>	урс
Description	•	Both portion of the converse o	ce of 1828 [D + ositive r D. T ted in	opera is as - 1, D e and The op	ation a bas a bas] = e nega peration	result se nur [S+1, S tive value on is o	nber, alues execu	are varted in	alid fo float ore e	r S. T ng-po xpone	The 3. pint nent op	2-bit for umbers, peration.	EXP operation mat must be so the valuated source	e used to ue in S r	ŭ
Example	•	When I (D11	M0 = , D1(M1 =	ON, ()). : ON,	(D11 obers	rt (D0	, D1)) are	to be	binar expon	y floa ent to	ting-r o do :1, D2	EXP op 20).	mbers and speration. The DO D10 D20 D10 D20 END	store in t	

API	In	struction code	on				Ope	rand						ction		
125	D	LN	Р				S,	D					floating-point m operation	numbei	r natural	
Type	В	it device	es			١	Nord o	devices	3			<u>16-bit</u>	instruction			
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	<u>-</u>	-	-	-	
S				*	*						*	32-bit	instruction (9	steps)		
D											*		Continuous		Pulse	
Caution for u	ısing	opera	nd:									DLN	execution	DLNP	execution	
See the s	pecit	ication	of e	ach m	type type th model for the scope of device's usage. Associated flag: none											
Description	• E r c c · T	Both po egister convert he cor Vhen M	ce of 1828 [D + ositive D. T ted in ntent M0 = , D10	opera is as - 1, D e and The op to floa of op ON, c	ation a bas] = In nega perati ating- erance conve	result se nur [$S+1$, ative value on is a point d $D=1$ ert (D0 1, D10	mber, s] alues execu numb (n s = 1, D1)	are valued in er before Solution to be	alid for float for e e for e f	or S. T ing-po xpone 2.7182 ry floa	the 32 int not op 28, ar ting-p	2-bit for umbers, peration, and S is to point numbers. LN op 20).	he designat mbers and s eration. The	e used to le in S r ed sourcestore in	ce data.	

API	Ins	structi code					Ope	rand					Fur	nction	
127	D E	SQR	Р				S,	D				Binary flo	oating-poin	t number s	square root
Туре	Bit	devid	es			١	Nord o	devices	3			16-bit ir	<u>nstruction</u>		
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	-	-	-	-
S				*	*						*	00 bit is			
D											*	32-DIT II	nstruction (9 Continuous		Pulse
Caution for u	sing	opera	ınd:									DESQR			1
• See the s	_	•		ach m	odel 1	or the	scop	e of c	levice	's usa	age.	\	type	<u> </u>	type
												Associate	ed flag: non	е	
		S: the source device for calculating square root D: operation result Calculate square root of the content in register that S designates, the result will be stored in													
		D: operation result Calculate square root of the content in register that S designates, the result will be stored in													
		Calculate square root of the content in register that S designates, the result will be stored in													
Description	tl	·													
	fl	oating	g-poir	nt nun	nbers										
	• If	S is	a de	signa	ted co	onstai	nt K d	or H,	the ir	struc	tion v	will conve	ert the cor	nstant into	a binary
	fl	oatin	g-poir	nt valu	ıe bef	ore th	ne squ	are ro	oot op	eratio	on.				
	● E	xamp	le 1												
				ON. ca	alcula	te the	saua	re roc	ot of th	ne bin	arv fl	oating-po	oint numbe	er (D1. D0), and
							•	1, D10			•	31		(, -	,,
		0.0.0	ouit t	0 11.0	. og.o.	.01 1110	(5 .	.,	<i>3</i> , 400	-igi iat	.				
					×	S				П					
							┪╹	\lesssim	3		> I	T			
				I					!						
					4 (D	1 . D	<u></u>	→ (D1	14 . D	10)					
Example			_												
			В	ınary	noat	ing po	oint	Bir	nary f	oatır	ig po	int			
			I- 0												
		xamp									,		.		
											(con	vert to bi	nary floatir	ng-point n	umber
	aı	utoma	tically	/), and	d stor	es the	eresu	It in ([D11, [010).					
						>	×			_		1	_		
						$\vdash\vdash\vdash$		⊣ ı	ΙK	3 3					

API	I	nstruct code					Ope	rand					Fun	ction	
129	D	INT	Р				S,	D				Binary intege	r floating-poin r	t number	r → BIN
Туре	ı	Bit devi	ces			١	Nord o	devices	6			16-bi	t instruction (5	steps)	
Operand	Х	Y	М	K	Н	KnX	KnY	KnM	Т	С	D	INT	Continuous execution	INTP	Pulse execution
S											*	_	type		type
D											*	32-bi	t instruction (9	steps)	
Caution for u • See the sp	•	•		ach m	odel	for the	e scop	oe of c	levice	's us	age.	DINT	Continuous execution type	DINTP	Pulse execution type
												Assoc	ated flag: non	е	
Description	•		conv onten nteger will b	ersior t in th r, and e left	resune reg store	lt gister e then	that S	ne reg	ister	that [) des	ignate	om binary flo s. The decim	٠.	
Example				-				•	٠.			vill be l	1, D0) to BINeft out.	l integer	r, and store

API	I	nstruction code	on				Ope	rand					Fun	ction	
130	D	SIN	Р				S,	D				Binary f	floating-poin	t numbei	r sine
Туре	E	Bit device	es			١	Nord o	devices	3			16-bit	instruction	·	
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	-	-	-	-
S				*	*						*	32-bit	instruction (9	steps)	
D											*	DSIN	Continuous execution	DSINP	Pulse execution
Caution for u	sin	g opera	nd:									DOIN	type	DOINE	type
See the sp	oec	ification	of e	ach m	nodel	for the	e scop	oe of o	device	's usa	age.	Associa	ted flag: non	е	
Description	•	design See the	ration urce alue = ne v ates.	resu desig desig alue alue	nated ree x from ow fo	by S π / 18 the s r the r	ource relatio	value on between $\frac{1}{2}$	R 1 0	the rate $\frac{1}{\frac{\pi}{2}}$	dian S: R:	and the Radian Result (S $\frac{3}{2}\pi$ 2π	d store in to operation residue) SIN value) SS	esult:	
Example				ue an	d stor			D10).	D0	RAD valinary	D10	binary flo	oating-point × π / 180) nt		D0) to find

	In	structi	on									
API		code	-				Ope	rand				Function
131	D	cos	Р				S,	D				Binary floating-point number cosine operation
Туре	Bi	t devic	es			١	Nord o	devices	3			16-bit instruction
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	
S				*	*						*	32-bit instruction (9 steps)
D											*	Continuous Pulse
Caution for t	using	opera	and:									DCOS execution DCOSP execution type type
See the s	pecif	ication	n of e	ach n	nodel	for the	e sco	pe of o	device	e's us	age.	
Description	• T • N • N • If	M1018 M1018 M1018 the o Tind co design ee the	ration urce 3. = Of = ON perat osine ates. e figur	resulvalue F, rac N, deg ion re value re bel	designation distribution designation desig	node, node, s 0, M n the r	RAD range 1020 source elation	value e: $0^{\circ} \le$ = ON ce value in betw	= degree de degree de degree d	gree x ee < 3 esigna the ra	απ/1 360° ated badian S: R:	by S, and store in the register that D and the operation result: Radian Result (COS value) $\frac{3}{2}\pi$ 2π
Example					d stor		DSI	D10).	D0 RA Bir	D val	nt is to the distribution of the distribution	floating-point number (D1, D0) to find binary floating-point number. Ingle ×π / 180) g point

Example

S

D

D 1

D 11

API		nstruct code					Ope	rand						nction	
132	D	TAN	Р				S,	D				Binary f	loating-poin on	it numbei	tangent
Туре		Bit devi	ces				Word o	devices	3			16-bit i	nstruction		
Operand	Х	Y	М	K	Н	KnX	KnY	KnM	Т	С	D	-	-		-
S				*	*						*	22 hit i	instruction (9) ctops)	
											*	32-011	Continuous		Pulse
Caution for u	usir	ıg oper	and:	I		1	1					DTAN	execution type	DTANP	executior type
• See the s				each n	nodel	for th	e sco	pe of	devic	e's us	age.	Associa	ted flag: non	е	турс
Description	•	M1018 M1018 M1018 If the c Find to design See th	ource 8. 8 = OI 9 = OI pperate anger nates e figu	value FF, rac N, dec tion re nt value	design dian regree nesult is use from the control of the control	mode, node, s 0, M m the r the r	RAD range 1020 e sour relation	value e: 0° ≤ = ON ce va n betv	= degradegradegradegradegradegradegradegra	esignathe ra	ated adian	by S, and the S: F R: F	ree, and thing and store in operation operatio	the regineresult:	ster that

D 0

D 10

RAD value (angle $\times \pi$ / 180) Binary floating point

TAN value

Binary floating point

API	Ins	struction code	on				Ope	rand				Function
133	D .	ASIN	Р				S,	D				Binary floating-point number arcsine operation
Туре	Bi	t devic	es			1	Vord o	devices	3			16-bit instruction
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	O	D	- - - -
S				*	*						*	32-bit instruction (9 steps)
D											*	Continuous Pulse
Caution for t	using	opera	and:			•						DASIN execution DASINP execution type type
• See the s				ach n	nodel	for th	e sco	pe of o	device	e's us	age.	
Description	• A S		alue :	= sin-	ow fo	r the r	elatio		$\frac{\pi}{2}$	S R	: Input	alue and the operation result: (SIN value) ult (ASIN value) 1,0 S
Example				n (D1 ⁻	1, D1		e con		Bin	ry floa	ating- pating	point point

API	ı		ruction	on				Оре	rand				Function
134	D		cos	Р				S,	D				Binary floating-point number arccosine operation
Туре		Bit (device	es			١	Nord c	devices	}			16-bit instruction
Operand	Х		Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	
S					*	*						*	32-bit instruction (9 steps)
D												*	Continuous Pulse
Caution for i	usir	ıg c	pera	ınd:									DACOS execution DACOSP executio type type
See the s	pe	cific	ation	of e	ach n	nodel	for the	e sco	pe of c	device	e's us	age.	Associated flag: none
Description					e = co re bel		r the r		n betv	veen R π π 2	S	: Inpu	alue and the operation result: It (COS value) Ult (ACOS value)
Example	•					in (D1	•	0). Th	-	B A	inary COS	ary flo floatir	umber (D1, D0) to find the arccosing pating-point number. Ing point

	In	structi	on									
API	IFIS	code	On				Ope	rand				Function
135	D	ATAN	Р				S,	D				Binary floating-point number arctangent operation
Туре	Bi	t devic	es			١	Vord o	devices	,			16-bit instruction
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	
S				*	*						*	32-bit instruction (9 steps)
D											*	Continuous Pulse
Caution for t	using	opera	and:									DATAN execution DATANP execution type
See the s	pecif	icatior	n of e	ach n	nodel	for the	e sco	pe of o	device	e's us	age.	
Description	• A S		value e figui	= tan		r the r	elatio		π ₂ -π ₂	S: R:	Input: Resu	ralue and the operation result: (TAN value) It (ATAN value) S S
Example					in (D1				E A	binas binas binas binary	float	umber (D1, D0) to find the arctangent pating-point number. ting point eting point

API	I	Instru		n				Ope	rand					Fun	ction	
136	D	SIN	Н	Р				S,	D				Binary f	loating-poin eration	t number	hyperbolic
Туре		Bit de	/ice	s			١	Nord o	devices	3			16-bit i	nstruction		
Operand	X	Y		М	K	Н	KnX	KnY	KnM	Т	С	D	-	-	-	-
S					*	*						*	32-bit i	nstruction (9	steps)	
D												*		Continuous		Pulse
Caution for u	usir	ng op														
See the s	pe	cificat	ion	of e	each model for the scope of device's usage. Associated flag: none											
Description		S: source value (binary floating-point number) D: operation result of hyperbolic sine sinh value = (e ^s -e ^{-s}) / 2 When X0 = ON, designate the binary floating-point number (D1, D0) to find the hyperbolic sine value and stores in (D11, D10). The content is binary floating-point number.														
Example		valu	e ar	nd st	ores i	<u></u>			D 0	B SI	inary i	floatin	ating-point	oint number.		

API			tructi code	on				Ope	rand					Fun	ction	
137	D	С	OSH	Р			* 32-bit instruction (9 steps) * DCOSH execution DCOSHP execution type									
Туре		Bit	devic	es			١	Word o	devices	3			16-bit ir	nstruction		
Operand	Х	Š	Υ	М	K	Ι	KnX	KnY	KnM	Т	С	D	-	-	-	-
S					*	*						*	32-bit ir	nstruction (9	steps)	
D												*		Continuous		Pulse
Caution for u	ısin	g	opera	nd:			•						DCOSH		DCOSHP	execution type
• See the s	pec	cification of each model for the scope of device's usage. Associated flag: none														
Description Example	•	D C	: oper OSH 'hen :	ration value X0 =	resule = (e ^s ON,	t of h	yperb) / 2 Inate s in ([the b	inary 010). T	floatir The co	ng-pointent ary fl	oating	nary floa			nyperbolic

API			ructio	on				Ope	rand				Function			
138	D	TA	NH	Р	P S, D Binary floating-point number I tangent operation						Binary floating-point number hyperbolic tangent operation					
Type		Bit d	levice	es			١	Nord o	devices	3			16-bit instruction			
Operand	Х		Υ	М	Κ	Н	KnX	KnY	KnM	Т	С	D				
S					*	*						*	32-bit instruction (9 steps)			
D												*	Continuous Pulse			
Caution for u	ısir	ng o	pera	nd:									DTANH execution DTANHP execution type			
• See the s	pe	cifica	ation	of e	ach n	n model for the scope of device's usage. Associated flag: none										
Description		D: o	S: source value (binary floating-point number) D: operation result of hyperbolic tangent tanh value= (e ^s - e ^{-s}) / (e ^s + e ^{-s})													
Example	•					_			•	The o	> I	floatii	number (D1, D0) to find the hyperbolic binary floating-point number. ing point ing point			

API	In	structi code		Operand						Function			
147	D S	SWAP	Р				(S				Exchange the up / down 8 bits	
Туре	Bi	t devic	es	Word devices						16-bit instruction (3 steps)			
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	SWAP Continuous Pulse execution	
S						*	*	*	*	*	*	type type	
	specification of each model for the scope of device's usage. 32-bit instruction (5 steps) Continuous DSWAPP execution type Type Execution type Associated flag: none												
Description	• V • V	Vhen of the Vhen registe	using using ers wi	16-bi 32-b Il exch	t instr oit ins nange	uctior truction	n, the on, th	ie cor	nt of t	the up	per 8 upp	8-bit and lower 8-bit will exchange. Der 8-bit and lower 8-bit in these two ctions (SWAPP, DSWAPP).	

API		struct					Ope	rand				Function			
150	MO	DRW	/		S ₁ , S ₂ , S ₃ , S, n						Read / write Modbus data				
Туре	Bit	devic	ces		Word devices							16-bit instruction (11 steps)			
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	Continuous Pulse MODRW execution			
S ₁				*	*						*	type type			
S ₂				*	*						*	32-bit instruction			
S ₃				*	*						*				
S											*	Associated flag: M1077, M1078, M1079			
n				*	*						*				
Caution for u	ısing	opera	and: r	none											

S₁: address of communication device

S₂: function code

S₃: device address of data to be read / written

S: register for storing read / written data

n: length of read / written data

Before using this instruction, COM1 must be defined as being controlled by PLC (set Pr.09-31 = -12). After that, set the corresponding communication speed and format (Pr.09-01 and Pr.09-04). For function code (S₂), only these function codes listed below are available currently, others are still not executable.

Function	Description
H02	Read input
H03	Read word
H06	Write single word
H0F	Write multiple coil
H10	Write single word

- After executing the instruction, M1077, M1078, and M1079 become 0 immediately.
- For example, if you want the PLC master of the drive to control another drive slave and PLC slave, assume the station number of drive slave is 10, and the one of PLC slave is 20. See explanation below:

The drive to control slave devices

			MOE	RW instru	uction	
No.	Example	S ₁	S ₂	S ₃	S	n
INO.	Example	Station	Function code	Address	Register	Length
	Read the parameters Pr.01-00–Pr.01-	number	code			
1	03 of drive slave, 4 records in total. And store the data to D0–D3.	K10	НЗ	H100	D0	K4
2	Read the address H2100–H2102 of drive slave, 3 records in total. And store the data to D5–D7.	K10	H3	H2100	D5	КЗ
3	Write the parameters Pr.05-00–Pr.05-03 of drive slave, 3 records in total. And the written values are D10, D11, and D12.	K10	H10	H500	D10	КЗ
4	Write the address H2000–H2001of drive slave, 2 records in total. And the written values are D15 and D16.	K10	H10	H2000	D15	K2

Description

			MOD	RW instru	ıction	
NIa	Evenne	S ₁	S ₂	S ₃	S	n
No.	Example	Station	Function	A -l -l	Danistan	l
		number	code	Address	Register	Lengt
	Read X0-X3 status of PLC slave, 4					
1	records in total. And store the read	K20	H2	H400	D0	K4
	data in bit0-bit3 of D0.					
	Read Y0-Y3 status of PLC slave, 4					
2	records in total. And store the read	K20	H2	H500	D1	K4
	data in bit0-bit3 of D1.					
	Read M0-M3 status of PLC slave, 4					
3	records in total. And store the read	K20	H2	H800	D2	K4
	data in bit0-bit3 of D2.					
	Read T0-T3 status of PLC slave, 4					
4	records in total. And store the read	K20	H2	H600	D3	K4
	data in bit0-bit3 of D3.					
	Read C0-C3 status of PLC slave, 4					
5	records in total. And store the read	K20	H2	HE00	D4	K4
	data in bit0-bit3 of D4.					
	Read T0-T3 count values of PLC					
6	slave, 4 records in total. And store the	K20	H3	H600	D10	K4
	read data in D10-D13.					
	Read C0-C3 count values of PLC					
7	slave, 4 records in total. And store the	K20	H3	HE00	D20	K4
	read data in D20-D23.					
	Read D0-D3 count values of PLC					
8	slave, 4 records in total. And store the	K20	H3	H1000	D30	K4
	read data in D30-D33.					
	Write Y0-Y3 status of PLC slave, 4					
9	records in total. And the written values	K20	HF	H500	D1	K4
	are bit0-bit3 of D1.					
	Write M0–M3 status of PLC slave, 4					
10	records in total. And the written data	K20	HF	H800	D2	K4
	are bit0-bit3 of D2.					
	Write T0-T3 status of PLC slave, 4					
11	records in total. And the written data	K20	HF	H600	D3	K4
	are bit0-bit3 of D3.					
	Write C0–C3 status of PLC slave, 4					
12	records in total. And the written data	K20	HF	HE00	D4	K4
	are bit0-bit3 of D4.					
	Write T0-T3 count values of PLC					
13	slave, 4 records in total. And the	K20	H10	H600	D10	K4
	written data are D10-D13.					
	Write C0–C3 count values of PLC					
14	slave, 4 records in total. And the	K20	H10	HE00	D20	K4
	written data are D20-D23.					
15	Write D0-D3 count values of PLC					
13	slave, 4 records in total. And the	K20	H10	H1000	D30	K4
	written data are D30-D33.					

Example

[•] PLC triggers M0 to be ON when it starts, and sends the instruction to execute one MODRW.

[•] After receiving a response from the slave device, if the instruction is correct, then ROL is executed once, and M1 becomes ON.


[•] After receiving a response from the slave device, delays 10 PLC scan cycles, trigger M50 = 1,

and then MODRW is executed once again.

■ After receiving a response from the slave device again, if the instruction is correct, then ROL is executed once, and M2 becomes ON (M2 can be defined as repeat M), K4M0 becomes K1 again, that is, only M0 is 1, and the instructions can be sent cyclically. If you want to add instructions to be sent, you just have to add instructions in the dotted line box, and replace the M of repeat M to be Mn+1.

M1002

MOV K1 K4M0



API	In	structi code					Ope	rand					Fur	nction		
160	•	ГСМР	P			S	1, S ₂ ,	S3, S,	D			Time co	mparison			
Туре	Bi	t devic	es			,	Word o	devices	5			16-bit	instruction (1	I1 steps)		
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	T	С	D	ТСМР	Continuous execution	TCMPP	Pulse execution	
S ₁				*	*	*	*	*	*	*	*	<u> </u>	type	<u> </u>	type	
S ₂				*	*	*	*	*	*	*	*	32-bit	instruction			
S ₃				*	*	*	*	*	*	*	*	_	-	-	-	
S									*	*	*	Associa	ted flag: non	. <u>-</u>		
D		*	*									_				
Caution for u	sing	opera	ınd:													
See the specified in the specified	oecifi	cation	ation of each model for the scope of device's usage. : hour setting for time comparison, setting range: K0–K23 : minute setting for time comparison, setting range: K0–K59													
	• S	ն₁: hoւ	ır set	ting fo	or time	e com	pariso	on, se	tting r	ange	: K0–	K23				
				•			•		_	-						
				_			•	-		•	_					
		2: minute setting for time comparison, setting range: K0–K59 3: second setting for time comparison, setting range: K0–K59 : current time of RTC														
	S															
): com	paris	on re	sult											
Description	• C	S: current time of RTC D: comparison result Compare the setting value of S_1 , S_2 , S_3 and the current value of start of S , and the comparison														
Description	r	esult	is sto	red in	D.											
	• S	is th	e "ho	ur" of	f the	currer	nt time	e (K0-	-K23)	in R	TC. S	S+1 is th	ne "minute"	of the cu	urrent time	
								•	•				(59) in RTC			
	,		•									•	•		and than	
									_				sing TRD i			
		_			-							eds the	available ı	range, it's	operation	
	E	error, s	so the	e instr	uctio	n is no	ot exe	cuted,	M10	68 = 0	ON.					
	• V	/hen	X10 :	= ON	, the	instru	ction	is exe	ecuted	d to c	ompa	are the	current time	e of RTC	D20-D22	
	а	nd the	e sett	ting va	alue 1	2:20:	45. Tł	ne cor	nparis	on re	sult i	s stored	in M10-M	12. When	X10 goes	
	fı	rom C)N→(OFF, t	he in	structi	on is	not ex	xecut	ed, bu	ut the	previou	ıs ON / OF	F statuse	s of M10-	
		/112 re										•				
	-															
			\	10	Γ.		$\overline{}$	1/40	Ι,	<u> </u>		(45	D20	M40		
				П	\sqcap	ГСМР		K12	r	(20		(45	D20	M10		
			ı		M10						Г	D20 (hr)	٦			
Example				L	-M 0	<u> </u>	N w	nen 12	2 · 20	. 45		021 (min	<u>)</u>			
					11		J14 VV1	1011 12	20	. 40		022 (sec				
					M11						-		<u></u>			
				L	-W111 - -	(NI wi	nen 12	2 · 20	. 15		020 (hr) 021 (min	<u> </u>			
					71	(JIN WI	1011 12	2.20	. 43		021 (IIIIII 022 (sec				
					1440						<u> </u>	· ·	=			
					M12		7NI4	on 10		. 15		020 (hr)				
				Γ	$\dashv\vdash$		אוע Wľ	nen 12	∠.∠∪	. 45	_	021 (min	_			
				I								D22 (sec)			

API		tructio	on				Ope	rand					Fun	ction	
161	T	ZCP	Р			,	S1, S2	, S, D)			Time zo	ne comparis	on	
Type	Bit o	device	es			١	Nord o	devices	8			16-bit i	nstruction (9	steps)	
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	TZCP	Continuous execution	TZCPP	Pulse execution
S ₁									*	*	*	_L	type	<u> </u>	type
S ₂									*	*	*	32-bit i	nstruction		
S		_							*	*	*		-	-	-
D		*	*									Associat	ed flag: none)	
Caution for u	•	•													
See the sp	pecific	ation	of ea	ach m	odel 1	for the	scop	e of c	levice	's usa	age.				
Description	S2: S: D: Co sto S1, S2, D0 tho it's	curre componed in ored in , S ₁ + , S ₂ + S + 1 that en do	uppeent tir parise re th in D. - 1, S - 1, S	r bou me of on res e cur $i_1 + 2:$ $i_2 + 2:$ the esign compa n erro	nd se RTC sult rent t the h the h e hou ates i	tting value of the court, resourt, resourt, resourt, mires usure to by The institute of the	value of RTo minute minute, s ually r ZCP istruction	e, secono secono ead the nstruction is r	t S do	esignates the If the current of S1, ecute	ower upper rent time S2 ared, M2	bound so bou	by using Tlue exceed the	for come for	parison. nparison. uction and ble range,
Example	WI	hen >	X10 :		F, TZ 10 = 0	CP in OFF.	ZCP /hen /hen	D0 D1 D2 D0 D1	not e		D10 D11 D12 D10 D11 D12	D10 (hr) (min) (sec) (hr) (min) (sec) (hr)	D20 (hr D21 (m D22 (se	M12 re	

API		structi code					Ope	rand					Fun	ection	
162		ADD	_				S ₁ , S	S ₂ , D				Real-tin	ne data addi	tion	
Type	Bit	devic	es			١	Nord o	devices	5			16-bit	instruction (7	steps)	
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	TADD	Continuous execution	TADDP	Pulse execution
S ₁									*	*	*	ļĿ	type	<u> </u>	type
S ₂									*	*	*	32-bit	instruction		
D									*	*	*	-	-	-	-
• See the s	_	cation of each model for the scope of device's usage. M1020: Zero flag M1022: Carry flag M1068 RTC error													
Description	S D A de	M1022: Carry flag													
Example	• W	/hen esign	X10 ate p	= OI lus th	N, TA le hou ond c	ADD in arr, mir of the in erest of the	nstruction the structure of the structur	er that	s exe d that D20	6(hr) 6(see	d. Th -D12 desig	e hour, designates.		sult is st	hat D0-D2 cored in the

API	Ins	structi code					Ope	rand					Fur	oction			
163	1	ΓSUB	Р				S ₁ , S	S ₂ , D				Real-tin	ne data subt	raction			
Туре	Bit	t devic	es			١	Word o	devices	6			16-bit	nstruction (7	steps)			
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	TSUB	Continuous execution	TSUBP	Pulse execution		
S ₁									*	*	*	L	type	<u> </u>	type		
S ₂									*	*	*	32-bit i	nstruction				
D									*	*	*	_	_	_	-		
See the s	_	-		of each model for the scope of device's usage. M1020: Zero flag M1022: Carry flag M1068 RTC error minuend e subtrahend													
Description	• A co	D: time design S ₁ , S ₁ , S ₂ M1068 the design the design the design section of the de	e difference differen	erence our, m the reced N, and nce is ars wil	esult the r d reco a ne l be d	is stor ange, ord face gative isplay	red in it's out cooper, borved in (00:00	the hoperated one of the office of the results.	our, m ion e 1A (H ag M1 egister zero f	inuet, rror, s EX) in 021 = D de lag M	seconomics seconomics of the s	ond of the instruction of the instruction of the and the ates.	e register to	hat D de execute ne negat	ed. M1067, ive number		
Example	d	esign	ate m	D D	the he -D22 -D22 	our, m desig	nates	, seco	10 1/11 30	4(hr) 0(min 8(sec)_D12	2 design	-	esult is s	nat D0–D2 tored in the		

API	Ir	struct					Ope	rand					Fun	ction	
166		TRD	Р				[)				Read r	eal-time data	l	
Туре	В	it devic	es			1	Nord o	devices	3			16-bit	instruction (3	steps)	
Operand	Х	Υ	М	К	Н	KnX	KnY	KnM	Т	С	D	TRD	Continuous execution	TRDP	Pulse execution
D									*	*	*	<u> </u>	type	<u> </u>	type
Caution for t	using	opera	and:									32-bit	<u>instruction</u>		
• See the s	peci	ficatio	n of e	ach m	odel	for the	e scop	oe of c	device	e's usa	age.	-	-	-	-
												Associa	ated flag: none	9	
Description	i 1		63–D RTC	1069. and s	The store	functin the	tion o desig	f TRE inated	inst 7 rec	ructio gisters	n allo		a total of 7 s		
	• 7	Γhe co	ntent -	of D10	'	1 = M	onday	Ī	Tueso	day	7 = \$	Sunday			
			5	Specia	al D	Itei	m	Con	tent		G	eneral D	Item		
				D106	33	Yea (A.E		00-	-99	→		D0	Year (A.D.)	1	
Example				D106	64	We	ek	1-	-7	-		D1	Week		
				D106	35	Mor	nth	1–	12	→		D2	Month		
				D106	66	Da	ıy	1–3	31	-		D3	Day		
				D106	67	Но	ur	0-2	23	→		D4	Hour		
				D106	88	Min	ute	0-	59	→		D5	Minute		
				D106	30	Seco	and _	0-	F0			D6	Second		

API	Ins	structi code					Ope	rand					Fun	ction		
170	D	GRY	Р				S,	D				Binary o	code → Gray	y code		
Type	Bi	t devic	es			١	Nord o	device	s			16-bit	instruction (5	steps)		
Operand	Х	Υ	М	K	Н	KnX		KnM	Т	С	D	GRY	Continuous execution	GRYP	Pulse execution	
S				*	*	*	*	*	*	*	*	L	type	<u> </u>	type	
D							*	*	*	*	*	32-bit	instruction (9	steps)		
• See the s	·	•	ation of each model for the scope of device's usage. DGRY execution type DGRYP execution type execution type													
			Associated flag: none													
Description	• C ti															
Example	• V	/hen ː	X0 =	F	(0 −− K6	513=	GRY H197	K65	513 5 0 0 0	D0 D0	01		b0 1 0 0 0 1 b0 1 0 0 1			

API	Ins	structi code					Ope	rand					Fun	oction			
171	D (GBIN					S,	D				Gray co	de → Binar	y code			
Туре	Bit	t devic	es			\	Nord o	devices	6			16-bit i	nstruction (5	steps)			
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	GBIN	Continuous execution	GBINP	Pulse execution		
S				*	*	*	*	*	*	*	*	Ĺ	type	<u> </u>	type		
D							*	*	*	*	*	32-bit i	nstruction (9	steps)			
• See the s	_	•		ach model for the scope of device's usage. 32-bit instruction (9 steps) Continuous DGBINP Execution type DGBINP Execution type													
Description	• C th	conver the develope in alue in tore in the averror, a 6-bit in	rt the vice the structure of the value of the value of the metrude of the value of	contended to conte	ent (G designs to G Gray nated nage o truction	Gray conversions of the conversion of the conver	ode) rt the e) wh ter. as s not ex	of the conte ich co hown ecuted	ent of nnec	the a	absol n inpu	ute posi ut side o	S to binary tion type e if PLC to be eeds the ra	ncoder (e binary	(the output value, and		
Example			0–X1	7 inpu	ut side	e to be	bina 513	X17 0 0 0) 1 (hd sto		D10.	x0 1 0 0 1 b0 0 0 0 1	der whicl	h connects		

API	Ins	structi code	on				Ope	rand					Fu	ınction		
215–217	D	LD#					S1,	S ₂				Contac	t type logic	al opera	ation L	_D#
Type	Bit	devic	es			1	Nord o	device	s			16-bit	instruction ((5 steps)	<u> </u>	
\'\'	Х	Υ	М	К	Н	KnX	KnY	KnM	Т	С	D		Continuou	- :		
Operand		'	IVI								ļ	LD#	execution type	-		-
S ₁				*	*	*	*	*	*	*	*	<u>-</u>	уро	<u>L</u>		
S ₂				*	*	*	*	*	*	*	*	32-bit	instruction (<u> </u>	
Caution for u	ısing	opera	and: 🥫	# : &	^							DI D#	Continuou			
See the s	pecif	icatio	า of e	ach n	nodel	for th	e sco	pe of	devic	e's us	age.	DLD#	type	-		-
												Associa	ated flag: no	ne		
	• S	1: SOU	rce d	evice	1											
	S	2: SO U	irce d	evice	2											
	• T	- his in	struct	ion is	s to co	ompa	re S₁	and S	S ₂ . if	the re	esult :	≠ 0. the	continuity	of the	instr	uction is
												n is disa	-			
								-								
		D# (#	. œ, ,		Struction S-bit		32-bit		ect ct	mec	uon v	vith bus	Dai			
Description		API	No.				tructic	n (Contir	uity (condit	ion	Discontinu	ity cond	dition	
		21	15		LD&		DLD&		S₁	&	S ₂	≠0	S ₁ &	S ₂	=0	
		21	16		LD		D LD		S₁		S ₂	≠0	S ₁	S ₂	=0	
		21	7		LD^		DLD^		S₁	٨	S ₂	≠0	S ₁ ^	S ₂	=0	
	• &	: logic	al op	eratio	n with	n AND	oper	ator								
	• :	Logic	al op	eratio	n with	OR	opera	tor								
		•					R ope									
									ation	if the	racii	It is not	0, Y10 = C	NI		
				•			-								ıl tha	n V11 -
					enon	II OF	t logi	cai o	perali	JII, II	the re	suit is i	not 0 and 2	X I – OI	v, uie	#II Y II —
	C	ON an	d hol	d.												
Example				Γ					040				7/10			
					LD ,	&	C0		C10			$\overline{}$	Y10			
				Г							X1				1	
			\vdash	-	LD	ı	D200)	D300		I		SET	Y11		

API	I	nstruc cod					Ope	erand				Function
218–220	D	AND	#				S ₁	, S ₂				Contact type logical operation AND#
Туре	Е	Bit devi	ices			,	Word o	devices	3			16-bit instruction (5 steps)
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	Continuous AND# execution
S ₁				*	*	*	*	*	*	*	*	type
S ₂				*	*	*	*	*	*	*	*	32-bit instruction (9 steps)
• See the s		• .			•	for th	e sco	pe of	devic	e's us	age.	Continuous DAND# execution type
												Associated flag: none
	•	S ₁ : sc	urce o	device	1							


- - S₂: source device 2
- This instruction is to compare S_1 and S_2 , if the result $\neq 0$, the continuity of the instruction is enabled; if the result = 0, the continuity of the instruction is disabled.
- AND# (#: &, |, ^) instruction is used for serial connection with contacts

Description

API No.	16-bit instruction	32-bit instruction	Cont	inuity	cond	lition	Disco	ntinui	ty cond	dition
218	AND&	D AND&	S ₁	&	S ₂	≠ 0	S ₁	&	S ₂	=0
219	AND	D AND	S ₁		S ₂	≠ 0	S ₁		S ₂	=0
220	AND^	D AND^	S ₁	٨	S ₂	≠0	S ₁	٨	S ₂	=0

- &: logical operation with AND operator
- |: Logical operation with OR operator
- ^: Logical operation with XOR operator
- When X0 =ON, and C1 and C10 perform "AND" logical operation with the result is not 0, then
- When X1 = OFF, and D10 and D0 perform "OR" logical operation with the result is not 0, then Y11 = ON and hold.
- When X2 = ON, and 32-bit registers D200 (D201) and D100 (D101) perform "XOR" logical operation with the result is not 0 or M3 = ON, then M50 = ON.

Example



API	Ins	structi code					Ope	rand					Fun	ction		
221–223	D	OR#					S ₁ ,	, S ₂				Contac	t type logica	l operation	n OR#	
Туре	Bi	t devic	es			1	Word o	devices	3			16-bit	instruction (5	steps)		
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	OR#	Continuous execution		-	
S ₁				*	*	*	*	*	*	*	*		type	<u> </u>		
S ₂				*	*	*	*	*	*	*	*	32-bit	instruction (9	stens)		
Caution for υ See the s	•	•				or the	e scop	oe of d	levice	's usa	age.	DOR#	Continuous	-	-	
	S • T e	nable	rce destructed; if the	evice ion is he res	2 to co sult =	0, the	conti	inuity (of the	instru	uction	is disa	bled.	of the in	structior	
Description	• 0		is instruction is to compare S_1 and S_2 , if the result $\neq 0$, the continuity of the instruction is habled; if the result = 0, the continuity of the instruction is disabled. R# (#: &, , ^) instruction is used for parallel connection with contacts API No. 16-bit 32-bit Continuity condition Discontinuity condition													
		22	21	(OR&	D	OR&	5	S 1	& 5	S ₂	≠0	S ₁ &	S ₂ =	=0	
		22	22		OR	D	OR		S ₁			≠ 0	S ₁	S ₂ =	=0	
		22	23	(OR^	D	OR^		S ₁	^ (S_2	≠0	S ₁ ^	S ₂ =	=0	
	• &	: logic	al op	eratio	n with	n AND	oper)	ator								
	• :	Logic	al op	eratio	n with	OR o	opera	tor								
	• ^:	Logic	cal op	eratio	n with	n XOF	R ope	rator								
	=	:ON					·						with the res			
										-		` ') and D20 (
		-											235 and 3	_	jister D2	
	(1	D201)) perfo	orm "ኦ	(OR"	logica	al ope	ration	with	he re	sult is	s not 0,	then M60 =	ON.		
				X	1											
Example					OR 2	& И30	C0		C10							
				H	<u> </u>	-							—(M60	$\overline{)}$		

DOR ^

D25

D200

API	I	nstruct code					Ope	rand				Function
224–230	D	LD%					S ₁	, S ₂				Contact type comparison LDX
Type	E	Bit devi	ces			\	Word o	devices	5			16-bit instruction (5 steps)
Operand	Х	Υ	М	K	Η	KnX	KnY	KnM	Т	С	D	Continuous LD※ execution
S ₁				*	*	*	*	*	*	*	*	type
S ₂				*	*	*	*	*	*	*	*	32-bit instruction (9 steps)
• See the s								pe of	devic	e's us	sage.	Continuous execution type
												Associated flag: none
	•	S ₁ : so	urce c	levice	1							

S₂: source device 2


• This instruction is to compare S₁ and S₂, take API 224 (LD=) as an example, if the result is "equal to", the continuity of the instruction is enabled; if the result is "not equal to", the continuity of the instruction is disabled.

• LD% (%: =, >, <, <>, \leq , \geq) instruction is used for direct connection with busbar

Description

API No.	16-bit instruction	32-bit instruction	Continuity condition	Discontinuity condition
224	LD=	D LD=	$S_1 = S_2$	S ₁ ≠ S ₂
225	LD>	D LD>	$S_1 > S_2$	$\boldsymbol{S_1} \leq \boldsymbol{S_2}$
226	LD<	D LD<	$S_1 < S_2$	$\boldsymbol{S_1} \geq \boldsymbol{S_2}$
228	LD<>	D LD<>	$S_1 \neq S_2$	$S_1 = S_2$
229	LD<=	D LD<=	$\boldsymbol{S_1} \leq \boldsymbol{S_2}$	$S_1 > S_2$
230	LD>=	D LD>=	$\boldsymbol{S_1} \geq \boldsymbol{S_2}$	$S_1 < S_2$

- When C10 = K200, Y10 = ON.
- When D200 > K-30 and X1 = ON, Y11 = ON and hold.




API	I	nstruct code					Ope	rand				Function	
232–238	D	AND%	•				S ₁ ,	, S ₂				Contact type comparison AND%	
Туре		Bit devi	ces			\	Word o	devices	3			16-bit instruction (5 steps)	
Operand	Х	Y	М	K	Н	KnX	KnY	KnM	Т	С	D	Continuous AND※ execution -	-
S ₁				*	*	*	*	*	*	*	*	type	
S ₂				*	*	*	*	*	*	*	*	32-bit instruction (9 steps)]
Caution for using operand: $orall: = , >, <, <>, \le , \ge$ • See the specification of each model for the scope of device's usage. $\begin{array}{c ccccccccccccccccccccccccccccccccccc$													
	Associated flag: none												
● S ₁ : source device 1													
	S ₂ : source device 2												

- This instruction is to compare S₁ and S₂, take API 232 (AND=) as an example, if the result is "equal to", the continuity of the instruction is enabled; if the result is "not equal to", the continuity of the instruction is disabled.
- AND% (%: =, >, <, <>, \leq , \geq) instruction is used for serial connection with contacts

Description

API No.	16-bit instruction	32-bit instruction	Continuity condition	Discontinuity condition
232	AND=	D AND=	$S_1 = S_2$	$S_1 \neq S_2$
233	AND>	D AND>	$S_1 > S_2$	$\boldsymbol{S_1} \leq \boldsymbol{S_2}$
234	AND<	D AND<	$S_1 < S_2$	$\boldsymbol{S_1} \geq \boldsymbol{S_2}$
236	AND<>	D AND<>	$S_1 \neq S_2$	$S_1 = S_2$
237	AND<=	D AND<=	$\boldsymbol{S_1} \leq \boldsymbol{S_2}$	$S_1 > S_2$
238	AND>=	D AND>=	$S_1 \ge S_2$	S ₁ < S ₂

- When X0 = ON, and the current value of C10 = K200, then Y10 = ON
- When X1 = OFF, and D0 \neq K-10, then Y11 = ON and hold.
- When X2 = ON, the 32-bit register D0 (D11) is less than 678,493 or M3 = ON, then M50 = ON.



API	I	_	tructio	on				Ope	rand				Function					
240–246	D	•	OR※					S ₁ ,	, S ₂				Contact type comparison ORX					
Туре		Bit	device	es			١	Nord o	devices	3			16-bit instruction (5 steps)					
Operand	Х		Υ	М	K	Η	KnX	KnY	KnM	Т	С	D	ORX execution					
S ₁					*	*	*	*	*	*	*	*	type					
S ₂					*	*	*	*	*	*	*	*	32-bit instruction (9 steps)					
Caution for u	ısin	g	opera	nd: 🕅	%∶= ,∶	>, <, ·	<>, ≦	, ≧					Continuous					
See the s	pec	ific	cation	of e	ach m	nodel	for th	e sco _l	pe of o	device	DORX execution							
	As											Associated flag: none						
Caution for using operand: ※: =, >, <, <>, ≦, ≧ • See the specification of each model for the scope of device's usage. Continuous execution type											DORX Execution type							

S₁: source device 1

S₂: source device 2


• This instruction is to compare S₁ and S₂, take API 240 (OR=) as an example, if the result is "equal to", the continuity of the instruction is enabled; if the result is "not equal to", the continuity of the instruction is disabled.

• OR % (%: =, >, <, <>, \leq , \geq) instruction is used for parallel connection with contacts

Description

API No.	16-bit instruction	32-bit instruction	Continuity condition	Discontinuity condition
240	OR=	D OR=	$S_1 = S_2$	$S_1 \neq S_2$
241	OR>	D OR>	$S_1 > S_2$	$\boldsymbol{S_1} \leq \boldsymbol{S_2}$
242	OR<	D OR<	$S_1 < S_2$	$\boldsymbol{S_1} \geq \boldsymbol{S_2}$
244	OR<>	DOR<>	$S_1 \neq S_2$	$S_1 = S_2$
245	OR<=	DOR<=	$\boldsymbol{S_1} \leq \boldsymbol{S_2}$	$S_1 > S_2$
246	OR>=	DOR>=	$\pmb{S_1} \geq \pmb{S_2}$	$S_1 < S_2$

- When X0 = ON, and the current value of C10 = K200, then Y10 = ON
- When X1 = OFF, and D0 \neq K-10, then Y11 = ON and hold.
- When X2 = ON, the 32-bit register D0 (D11) is less than 678,493 or M3 = ON, then M50 = ON.



API	ı		ructio	n				Ope	rand				Fu	ınction			
275–280	D	FL	_D※					S ₁ ,	, S ₂				_	j-point nu ison LD:		ontac	t type
Туре		Bit c	device	s			V	Nord o	devices	3			16-bit ii	nstruction			
Operand	Х		Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	<u>-</u>	-	-		-
S ₁										*	*	*	32-hit ii	nstruction	(0 stens)		
S ₂										*	*	*	OZ DICII	Continuo			
Caution for the	ıcir	na 0	nerar	od: ‡	<u>+</u> ۰ ۶.	1 ^							FLD%	execution	- ۱		-
See the s		-				•	for the	2 500	ne of (dovice	a'e 11e	200	Associat	type ed flag: no	ne	<u> </u>	
- 000 the 5	pot	JIIIO	ation	01 00	2011 1	nouci	101 111	0 000	pc or v	<u> </u>	<i>3</i> 0 00	age.					
	•	S ₁ :	sour	ce d	evice	1											
		S ₂ :	sour	ce d	evice	2											
	•						es the	e con	tent in	S ₁ a	nd Sa	Tak	- "FI D="	as an ex	amnle	if the	result is
						•									•		
	"equal to", the continuity of the instruction is enabled; if the result is "not equal to", the																
	continuity of the instruction is disabled. • Use FLD% instruction, users can execute operation directly by inputting floating-point value																
	•	Us	e FLI	D‰	instru	uction,	user	s can	exec	ute o	perati	ion d	irectly by	/ inputting	g floatin	g-po	int value
		(e.	.g. F1	.2) ir	ո S ₁ ,	S ₂ or	storin	g floa	iting-p	oint v	alue i	n the	register	D.			
Description	•	The	e inst	ructi	on is	used	for di	rect c	onnec	tion v	vith b	usbar	•				
										ontinu			iscontinu	ıit∨			
			API	l No.	3	2-bit i	nstruc	ction		onditio	-		conditio	-			
			2	75			FLD=		S	$S_1 = S$	2		S ₁ ≠ S ₂	2			
			2	76			FLD>	1	(S ₁ > S	2		$S_1 \leq S_2$	2			
			2	77			FLD<		(S ₁ < S	2		S ₁ ≥ S ₂	2			
			2	78		F	FLD<>	>		S ₁ ≠ S			$S_1 = S_2$				
			2	79		F	-LD<	=		S ₁ ≤ S			S ₁ > S ₂				
		280 FLD>= $S_1 \ge S_2$ $S_1 < S_2$															
	- WI - I - II - I - P000 (B004) 4 F4 0 - LV4 1 - ON - II - V04 1 - L i																
	● When the floating-point value in D200 (D201) ≤ F1.2 and X1 is ON, then Y21 is being																
	triggered and hold.																
Example				1													
Lxample					_		_				X1					1	
i	1			- 1	FLD<= D200 F1.2 SET Y21												

API	Ir	nstructi code					Ope	rand			Fund	ction			
281–286	D	FAND	*				S ₁ ,	S ₂				Floating-p		er conta	ct type
Туре	Е	it devic	es			١	Nord o	devices	3			16-bit ins	truction		
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	O	D	-	- 1	-	-
S ₁									*	*	*	32-bit ins	truction (9	steps)	
S ₂									*	*	*	С	Continuous		
Caution for u	using	opera	and: #	# : &	^		•					FANDЖ 6	execution type	-	-
See the s	peci	fication	n of e	ach n	nodel	for the	e sco	pe of o	device	's us	age.	Associated			LI
Description	 This instruction compares the content in S₁ and S₂. Take "FAND=" as an example, if the result is "equal to", the continuity of the instruction is enabled; if the result is "not equal to", the continuity of the instruction is disabled. Use FAND% instruction, users can execute operation directly by inputting floating-point value (e.g. F1.2) in S₁, S₂ or storing floating-point value in the register D. The instruction is used for direct connection with busbar API No. 32-bit instruction Continuity condition Discontinuity condition 														
			281		F	AND:	=	S	S ₁ = S	2		S ₁ ≠ S ₂			
			282			-AND			$S_1 > S_2$			$\boldsymbol{S_1} \leq \boldsymbol{S_2}$			
			283			AND			S ₁ < S			$S_1 \geq S_2$			
			284			AND<			$S_1 \neq S_2$			$S_1 = S_2$			
		-	285 286			AND<			$S_1 \leq S_2$			$S_1 > S_2$			
Example	 When X1 = OFF, and D100 (D101) ≠ F1.2, then Y21 = ON and hold. 														

API	I	nstruc code					Ope	rand			Functions				
287–292		FOR	*				S ₁ ,	S ₂				Floating-point number contact type comparison ORX			
Туре		Bit devi	ces Word devices									16-bit instruction			
Operand	Х	Y	М	K	Н	KnX	KnY	KnM	Т	С	D				
S ₁									*	*	*	32-bit instruction (9 steps)			
S ₂										*	Continuous				
Caution for u	ısin	g oper	and:	d: # : & ^								FORX execution type			
• See the s	pec	ificatio	n of e	each n	nodel	for the	e sco	pe of c	device	e's us	age.	Associated flag: none			

• S₁: source device 1

S₂: source device 2

- This instruction compares the content in S₁ and S₂. Take "FOR=" as an example, if the result is "equal to", the continuity of the instruction is enabled; if the result is "not equal to", the continuity of the instruction is disabled.
- Use FOR instruction, users can execute operation directly by inputting floating-point value (e.g., F1.2) in S₁, S₂ or storing floating-point value in the register D.


Description

• The instruction is used for direct connection with busbar

API No.	32-bit instruction	Continuity condition	Discontinuity condition
287	FOR=	$S_1 = S_2$	$S_1 \neq S_2$
288	FOR>	$S_1 > S_2$	$\boldsymbol{S_1} \leq \boldsymbol{S_2}$
289	FOR<	$S_1 < S_2$	$\boldsymbol{S_1} \geq \boldsymbol{S_2}$
290	FOR<>	$S_1 \neq S_2$	$S_1 = S_2$
291	FOR<=	$\boldsymbol{S_1} \leq \boldsymbol{S_2}$	$S_1 > S_2$
292	FOR>=	$\boldsymbol{S_1} \geq \boldsymbol{S_2}$	$S_1 < S_2$

• When both X2 and M30 are ON, or the content in D100 (D101) ≥ F1.234, then M60 = ON.

Example



15-6-5 Instructions of special application instructions for AC motor drives

API		structi code					Ope	rand					Fun	ction	
139	D	RPR	Р				S ₁ ,	, S 2				Read p	arameters o	of drive	
Туре	Bit	t devic	es		Word devices								instruction (5	steps)	
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	RPR	Continuous execution		Pulse execution
S ₁				*	*						*	<u> </u>	type		type
S ₂											*	32-bit	instruction		
Caution for u	ısing	opera	and: r	one								-	-	-	-
										Associated flag: none					
Description	• S	S ₁ : the parameter address for reading data													
Description	S	2: the register for storing the read data													

API	Ins	structi code			Operand Functions S ₁ , S ₂ Write parameters of drive Word devices 16-bit instruction (5 steps)												
140	D '	WPR	Р				S ₁ ,	S ₂				Write p	arameters o	of drive			
Туре	Bit	devic	es		1	١	Nord o	devices	3		1	16-bit		steps)			
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	WPR	Continuous execution type	WPRP	Pulse execution type		
S ₁				*	*						*			<u>i</u>			
Caution for u	ısina	onera	and: n									32-bit	instruction -	_			
	ion ig	оро.с		.0110								Associa	ited flag: none	e			
Description				to be meter			or writ	ing da	ıta								
Example	 \(\text{V} \) \(\text{If} \)	/hen parai /PR hstruc	M0 = meter instruction s 11000	ON, vers are action suppo	write t writte uses rts rea	he coen such sin I ading	ntent cessf MP30	of D1 ully, M	0 into 11017 es no X.	MP3 = ON	00's F N. oport	Pr.04-00 writing 00 01 0	ta and write (multi-spee) to 20XX a D0 D1 I400	ed 1).			
Suggestion	T to F P P P P P P P P P P P P P P P P P P	ecord nemo he fol o the Pr.00- Pr.01- Pr.01- Pr.01- Pr.01- Pr.01- Pr.02- Pr.02- Pr.08- Pr.08- Pr.08- Pr.08- Pr.08-	led at ry writed ry writed ry writed ry writed ry	the site errors of control of the co	same or ma nmon write l cont define eratio e	time by occ ly use times rol m ed va n tim n tim n tim n tim n tim on ti	of writed particular if ped particular if ped particular if ped particular if ped	node s mode conti l limit eased e 100	selecters before partitions on the times	tion ection aram itive I e write	parar ritten een s eter (imit) ten v e san	meters a more the pecially 0–19 value when time	nan 10 ⁹ time	imes for s. so there	ged or not.		

API		structi code	on				Ope	rand					F	unct	tion	
141		FPID	Р				S ₁ , S ₂ ,	S3, S	4			Drive F	PID contro	ol mo	ode	
Туре	Bi	t devic	es			١ ١	Word o	devices	3			16-bit	instruction	า (9 st	teps)	
Operand	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	FPID	Continuo	1	PIDP	Pulse execution
S ₁				*	*						*	_l	type			type
S ₂				*	*						*	32-bit	instruction	<u>1</u>		
S ₃				*	*						*	-	-		-	-
S ₄				*	*						*	Associa	ated flag: r	none		
Caution for u	T -															
		1: PID					:-	(D)								
						rtional	•	(P)								
December					_	al time	` '	- \								
Description						ntial t	•	•								
							-									e, such as
	Pr.08-00 (terminal selection of PID feedback), Pr.08-01 (proportional gain, P), Pr.08-02 (integral time, I), and Pr.08-03 (differential time, D).															
							•									
											ction	disable	ed), Pr.08	3-01 :	= 0, Pr	:.08-02 = 1
	,			,				•		1 sec.).						
	• V	Vhen I	M1 =	ON,	set F	Pr.08-0	00 =	0 (me	ans	PID fu	nctio	n disab	led), Pr.0	08-01	I = 1 (unit: 0.01),
	F	Pr.08-0	02 = 0	o, and	l Pr.0	8-03 =	= 0.									
	• V	Vhen I	M2 =	ON, s	set Pi	r.08-00	0 = 1	(nega	tive	PID fee	dba	ck: by a	nalog inp	ut), F	Pr.08-0	1 = 1 (unit:
	C).01),	Pr.08	-02 =	0, ar	nd Pr.0	08-03	= 0.								
	• D	1027:	freq	uency	com	mand	after	PID c	alcu	lation						
			N	10			Г				_					
			H	<u> </u>				FPI)	H0		H0	H1	Н	l1	
Example			N	<i>/</i> 11			-									
			Н	<u> </u>				FPI	>	H0		H1	H0	Н	0	
				12			-									
				<u> </u>				FPI	>	H1		H1	H0	Н	0	
			$ _{M_1}$	1000									l			
								MOV	/	D1027		D1				
			-					END	>							
							L									

API	Ins	structi code		Operand							Fur	nction			
142	F	REQ					S ₁ , S	S ₂ , S ₃				AC mo	tor drive sp	eed cont	rol
Туре	Bit	devic	es			١	Nord o		3			16-bit	instruction (7	steps)	
perand	Х	Υ	М	К	Н	KnX	KnY	KnM	Т	С	D	FREQ	Continuous execution type	FREQP	Pulse execution type
S ₁				*	*						*	_ <u> </u>	і іуре		туре
S ₂				*	*						*	32-bit	instruction		
aution for u	eina	onera	nd: n		•						•	-	ted flag: M10	-	-
Description	S S S S S S S S S S S S S S S S S S S	2: acco 3: deco 2, S ₃ : leterm For ex See th 0.6 sec he FF and deco 1. 2. 3. 4. 5.	celera celera for the nined ample ample conds REQ i eceler as: M102 M104 M104 M104	by Pre, who der dis. nstructation 25: con 16: RUN 26: con 20: con 20: trig 4: pa	me ting o ting o ting o tine agrar time. htrol f htrol s gger q use (0	f acce 5. 01-45 n belo can co ; and i RUN (alid wh he dir servo luick s	5 = 0 (bw, if some one of some one of some of	unit: (set S ₂) AC m can concorrection of operion (STO) / second	otor decontrol OF (OF ON (Moerations of the control OF (OF) ON (Moerations of the control ec.) rive's I ope 1040 on FW OFF t trigg	eans frequentiation AC m = ON /D (O) (OFFicer qu	0.5 secondency confidence of the confidence of t	EV (ON) of (OFF)	S ₃ as 60 cceleration	o, it mean	
Example	M M • W ti	11025 11026 11015 /hen ime al /hen ccele	c confiction confictio	trol Rittrol the luency and colored time	UN (Control of the control of the co	DN) / Section ched AC motime of AC motime of AC (0.5 section)	of operation of operations of	(OFF erational control of the contro	rive's	frequation / com	tor dr F) / F comn uency time	REV (ON mand K3 y commof 60 (0 d becom	N) of AC most and K300 .6 sec.). (wheel of the K0	z) with a	cceleratio

Pr.09-33 is defined as whether the reference command before PLC execution is cleared.

bit 0: before the PLC scan, whether the target frequency is cleared to be 0.

(PLC is ON, and FREQ instruction is in the program)

bit 1: before the PLC scan, whether the target torque is cleared to be 0.

(PLC is ON, and TORQ instruction is in the program)

bit 2: before the PLC scan, whether the speed limit in torque mode is cleared to be 0.

(PLC is ON, and TORQ instruction is in the program)

For example: when a user is writing a program

```
FREQ K2000 K1000 K1000 END
```

If we force M0 to be 1, then the frequency command is 20.00 Hz. If M0 = 0, it has different situations:

Case1: when Pr.09-33 bit0 is 0, and M0 = 0, then the frequency command remains at 20.00 Hz.

Case2: when Pr.09-33 bit0 is 1, and M0=0, then the frequency command becomes 0.00 Hz. This is because that before the PLC scans the programs, when Pr.09-33 bit0 = 1, the frequency will be cleared to be 0 first; when Pr.09-33 bit0 = 0, the action to clear the frequency to be 0 is not performed.

API	I	nstructio code	on	Operand								Function			
323	D	WPRA	Р		S ₁ , S ₂							Write parameters of drive (in RAM only)			
Type		Bit device	es			١	Nord o	devices	3			16-bit i	nstruction (5	steps)	
Operand	Х	Y	М	K	Н	KnX	KnY	KnM	Т	ТС	D	WPRA	Continuous execution		Pulse execution
S ₁				*	*						*	<u> </u>	type	<u> </u>	type
S ₂				*	*						*	32-bit i	nstruction		
Caution for t	usir	g opera	nd: n	one								-	-	-	-
												Associat	ed flag: non	e	
Description		 S₁: the data to be written S₂: the parameter address for writing data When WPRA is executed, it is only written to RAM area, and will return to the previous record value after powering OFF. 													
	 Read H01.00 data of MP300 and write into D0, read H01.01 data and write into D1. When M0 = ON, write the content of D10 into MP300's Pr.04-00 (multi-speed 1). If parameters are written successfully, M1017 = ON. WPR instruction uses in MP300 does not support writing to 20XX address, but instruction supports reading 21XX, 22XX. 								but RPR						
				M1000 Normally ppen contact of				R	PR	I	H100	D0			
Example				C	perat	ion moi	nitoring	g (a)	R	PR	I	H101	D1		
				-	М0 — -				W	PRA		D10	H400 END		

15-7 Fault Display and Treatment

Code	ID	Description	Recommended Treatment
PLod	50	Download PLC programs, the component in codes exceeds the range, for example, T component supports the range T0–T159, if there is T160 in grammar, then displays a PLod fault when downloading the programs.	Check if there are any faults in programs. Download the programs again and check after correcting.
PLSv	51	During the execution of PLC programs, discovers that the assigned address that PLC writes in is unreasonable, then displays a PLSv fault.	Check if there are any faults in programs. Download the programs again and check after correcting.
PLdA	52	During the execution of PLC programs, the external Modbus reads / writes unreasonable components to the internal PLC, then displays a PLdA fault.	Check if the upper unit transmits the correct command
PLFn	53	Unsupported command has used while downloading the program, then displays a PLFn fault.	Check if the firmware of the drive is the old version. If yes, contact with Delta.
PLor	54	The program detects internal source code error during PLC operation, then displays a PLor fault.	 PLC function disabled. Delete PLC programs (set Pr.00-02 = 6). Enable PLC function. Re-download the PLC program
PLFF	55	The corresponding instructions PLC executes during operation are unreasonably, then displays a PLFF fault.	When starting the PLC function and there is no program in the PLC, the PLFF warning occurs. This is a normal warning, please download the program.
PLSn	56	The program detects checksum error during PLC operation	 PLC function disabled. Delete PLC programs (set Pr.00-02 = 6). Enable PLC function. Re-download the PLC program
PLEd	57	There is no "END" command during PLC operation	 PLC function disabled. Delete PLC programs (set Pr.00-02 = 6). Enable PLC function. Re-download the PLC program
PLCr	58	The MC command is continuously used for more than 9 times	The MC command cannot be used continuously for 9 times. Check and correct the program, then download the program again.
PLdF	59	PLC download is forced to stop, so the written program is incomplete	Check if there is any error in the program and download the program again.
PLSF	60	PLC scan time exceeds the maximum allowable time	Check if the source code is correct and download the program again.

^{*}ID: Warning code

15-8 Explanation of Speed Mode Control with PLC

The relevant registers in speed mode are listed below:

Control special M

Special M	Function	Attribute
M1025	Frequency of AC motor drive = frequency setting (ON) / frequency of AC motor drive = 0 (OFF)	RW
M1026	The operating direction of AC motor drive, FWD (OFF) / REV (ON)	RW
M1040	Power supply by hardware (Servo ON)	RW
M1042	Quick stop	RW
M1044	Halt	RW
M1052	Lock frequency (lock, frequency locked at the current operating frequency)	RW

Status special M

Special M	Function	Attribute
M1015	Frequency reached (use with M1025)	RO
M1056	Already power supply by hardware (Servo ON ready)	RO
M1058	On quick stopping	RO

Control special D

Special D	Function	Attribute
D1060	Mode setting (speed mode = 0)	RW

Status special D

Special D	Function	Attribute
D1037	The output frequency of AC motor drive (XXX.XX)	RO
D1050	Actual operating mode (speed mode = 0)	RO

Speed mode control command:

FREQ(P) S1 S2 S3


Target speed 1st acceleration time 1st deceleration time

The example for speed mode control:

Before executing speed control, if the control method is FOC (magnetic field orientation), you have to set up the motor parameters to be used first.

- 1. Set D1060 = 0, to make the AC motor drive be speed mode (default).
- 2. Control frequency, acceleration time and deceleration time by FREQ instruction.
- 3. Set M1040 =1, AC motor drive is being magnetized, but the frequency is zero.
- 4. Set M1025 = 1, the frequency command of AC motor drive becomes the frequency that FREQ instruction designates. The acceleration and deceleration also operate according to the acceleration time and deceleration time that FREQ instruction designates.
- Available to lock the current operating frequency by controlling M1052.

- 6. Available to execute temporarily stop (halt) by controlling M1044, the deceleration method is according to the deceleration setting.
- 7. Available to execute quick stop by controlling M1042, the deceleration method will decelerate as soon as possible on the premise that no error occurs. (An error may occur if the load is too large)
- 8. The authority to control is M1040 (Servo ON) > M1042 (Quick stop) > M1044 (Halt) > M1052 (LOCK)



15-9 The Applications for Remote IO Control of Modbus (Use MODRW)

The internal PLC of MP300 supports read / write for RS-485, which can be realized using the MODRW instruction. Before writing programs, you should set Pr.09-31 = -12 (defined the serial port of RS-485 as PLC use). After the setting is completed, you can use the standard communication format defined by RS-485 to perform read and write commands to other stations. Communication speed is defined by Pr.09-01, communication format is defined by Pr.09-04, and the PLC's current station address is defined by Pr.09-35.

The communication formats currently supported by MP300 include reading Coil (0x01), reading Input (0x02), reading Register (0x03), writing a single Register (0x06), writing multiple Coils (0x0F) and writing multiple Registers (0x10). The explanations and their usages are as follows:

	MOE	DRW instruc	ction				
S1	S2	S3	S4	S5	General	Defined Delta's PLC as the	Defined Delta's AC motor
Station number	Command	Address	Correspond to Dx	Length	meaning	slave device	drive as the slave device
К3	H01	H500	D0	K18	Read Coil (bit)	Read 18 bits of data corresponding to slave station 3 PLC Y0 to Y21. This data is stored by bit 0 to 15 of this station's D0 and bit 0 to bit 3 of D1.	Does not support this function.
КЗ	H02	H400	D10	K10	Read Input (bit)	Read 10 bits of data corresponding to slave station 3 PLC X0 to X11. This data is stored by bit 0 to 9 of this station's D10.	Does not support this function.
КЗ	H03	H600	D20		Read Register (word)	Read 3 words of data corresponding to slave station 3 PLC T0 to T2. This data is stored by D20 to D22.	Read 3 words of data corresponding to slave station 3 converter Pr.06- 00 to 06-02. This data is stored by D20 to D22
К3	H06	H610	D30	XX	Write a single Register (word)	Write slave station 3 PLC's T16 to this station's D30 value	Write slave station 3 converter 06 to 16 parameter to this station's D30 value
К3	H0F	H509	D40	K10	Write multiple Coil (bit)	Write slave station 3 PLC's Y11 to Y22 to bit 0 to 9 of D40.	Does not support this function.
К3	H10	H602	D50	K4	Write multiple Registers (word)	Write slave station 3 PLC's T2 to T5 to D50 to D53	Write slave station 3 converter 06-02 to 06-05 parameters to this station's D50 to D53

^{*} XX indicates it doesn't matter.

After implementing MODRW, the status will be displayed in M1077 (RS-485 read / write completed), M1078 (485 read / write error), and M1079 (485 read / write time out). M1077 is defined so as to immediately revert to 0 after the MODRW command has been implemented. However, any of three situations—a report of no error, a data error report, or time out with no report—will cause the status of M1077 to change to ON.


Example: tests of functions

Let the transmission sequence switch to the first data when turning ON the drive.

```
0 M1002 MOV K1 K4M0 On only for 1 scan a
```

When the reported message indicates no error, it will switch to the next transmitted command.

If time out occurs or an error is reported, M1077 will change to ON. At this moment, after a delay of 30 scanning cycles, it will issue the original command once again.



After all instructions have been sent, and restart.

```
102 M5 MOV K1 K4M0
INC D1
121 END
```

Practical application:

To control RTU-485 module.

Step 1: set communication format. Assume that the communication format is 115200, 8,N,2, RTU MP300: the default PLC station address is set as 2 (09-35)


Pr.09-31 = -12 (COM1 is controlled by the PLC), Pr.09-01 = 115.2 (The communication speed is 115200)

Pr.09-04 = 13 (The format is 8,N,2, RTU)

RTU-485: The station address = 8 (as an example)

ID7	ID6	ID5	ID4	ID3	ID2	ID1	ID0
0	0	0	0	1	0	0	0

PA3	PA2	PA1	PA0	DR2	DR1	DR0	A/R
1	0	0	0	1	1	1	0



Communication station #: ID0~ ID7 are defined as 2°, 2¹, 2²...2⁶, 2⁷

Communication protocol

PA3	PA2	PA1	PAO	A/R	Communication Protocol
OFF	OFF	OFF	OFF	ON	7,E,1 · ASCII
OFF	OFF	OFF	ON	ON	7,0,1 · ASCII
OFF	OFF	ON	OFF	ON	7,E,2 · ASCII
OFF	OFF	ON	ON	ON	7,0,2 · ASCII
OFF	ON	OFF	OFF	ON	7,N,2 · ASCII
OFF	ON	OFF	ON	ON	8,E,1 · ASCII
OFF	ON	ON	OFF	ON	8,O,1 · ASCII
OFF	ON	ON	ON	ON	8,N,1 · ASCII
ON	OFF	OFF	OFF	ON	8,N,2 · ASCII
OFF	ON	OFF	ON	OFF	8,E,1 · RTU
OFF	ON	ON	OFF	OFF	8,O,1 · RTU
OFF	ON	ON	ON	OFF	8,N,1 - RTU
ON	OFF OFF		OFF	OFF	8,N,2 · RTU
DR	2	DR1		DR0	Communication Speed
OFF		OFF		OFF	1,200 bps

DINZ	DIVI	DINO	Communicatori opeed
OFF	OFF	OFF	1,200 bps
OFF	OFF	ON	2,400 bps
OFF	ON	OFF	4,800 bps
OFF	ON	ON	9,600 bps
ON	OFF	OFF	19,200 bps
ON	OFF	ON	38,400 bps
ON	ON	OFF	57,600 bps
ON	ON	ON	115,200 bps


Step 2: install control equipment.

We sequentially connect a DVP16-SP (8 IN 8 OUT), DVP-04AD (4 channels AD), DVP02DA (2 channels DA), and DVP-08ST (8 switches) to the RTU-485.


The following corresponding locations can be obtained from the RTU-485's configuration definitions:


Module	Terminals	485 Address	
DVP16-SP	X0-X7	0400H-0407H	
	Y0-Y7	0500H-0507H	
DVP-04AD	AD0-AD3	1600H-1603H	
DVP02DA DA0-DA		1640H-1641H	
DVP-08ST	Switch 0-7	0408H-040FH	

Step 3: physical configuration




Step 4: write PLC programs







Step 5: practical testing situation

I/O test: when the switch is activated, it can be discovered that the display corresponds to M115–M108. Furthermore, it can be seen that one output point light is added every 1 sec. (the display uses a binary format)



AD / DA test: it can be discovered that D200 and D201 are roughly twice the D300, and continue to increase progressively. For their part, D202 and D203 are roughly twice the D301, and continue to decrease progressively.





15-10 RTC (real-time clock)

The internal PLC of MP300 contains a real-time clock function. Currently supported commands include TCMP (real-time data comparison), TZCP (zone comparison of real-time data), TADD (real-time data addition), TSUB (real-time data subtraction), and TRD (read real-time data). Refer to the explanation of relevant instructions and functions for the usages.

In practical applications, the internal PLC can judge whether real-time clock function has been activated; if it has been activated, real-time clock warning codes may be displayed in some situations. The activation of the real-time clock function is judged based on whether the above-mentioned real-time clock instructions write in the program, or the program refers to the real-time clock (D1063~D1069).

The time display of the real-time clock is currently planned between D1063~D1069, and its definition is as follows:

Special D	Item	Content	Attribute
D1063	Year (A.D.)	20xx (2000–2099)	RO
D1064	Week	1–7	RO
D1065	Month	1–12	RO
D1066	Day	1–31	RO
D1067	Hour	0–23	RO
D1068	Minute	0–59	RO
D1069	Second	0–59	RO


Real-time clock related special M items are as follows:

Special D	Item	Attribute
M1026	RTC error	RO

*If the program contains TCMP, TZCP, TADD, TSUB instructions, and the value exceeds the reasonable range, then M1026 is one.


Example:

- First, adjust the time of the drive by the time setting in Pr.12-93–Pr.12-96, these settings react to the special D mentioned above.
- Second, write WPLsoft program to set the drive to be ON during the period of 08:00–17:20. See the program below:



15-11 Enable The Built-in PLC Function of MPD (Scheduled Function, Multimaster Function)

MPD supports built-in PLC function for users to write programs according to user requirements. And also supports built-in PLC water pump function (scheduled function and multi-master function). Follow the instructions below to enable the built-in PLC function for using the related functions.



15-11-1 Scheduled function

To meet water requirements at different time, use this scheduled function to arrange the target pressure in the specific time interval for saving energy. After enabling the built-in PLC function, Pr.04-58–04-99 are displayed as the parameters of the scheduled function. Refer to the instructions of group 04 in chapter 12 for more details.

15-11-2 Multi-master station function

The common multi-pump system can automatically add / reduce pumps according to water requirements, increase water-use efficiency. To keep the system stability and no water outage, use the redundancy of AC motor drive and pressure sensor that based on PLC's multi-master function to make the backup pump operates automatically when breakdown, power failure, disconnection occurs. By doing so, increase the pump's reliability, decrease the risk of water outage.

The multi-pump system with built-in PLC function use COM1 as communication interface, the communication format is fixed, the station address of the master is 1, and supports eight pumps. To provide convenience for users, the whole system stops when pressing STOP to the master, and starts to operate again after pressing RUN. Set Pr.00-32 = 1, press STOP to the slave to make it separate from multi-pump system for maintaining conveniently. At the same time, the slave displays a FSTP

fault as a reminder. After finishing the maintenance, connect the slave back to the system and press STOP again, reset for FSTP, and the slave starts to operate while connecting with multi-pump system automatically.

About the display of warnings, only the master can display the warnings when there is any pressure deviation related warnings (high / low water pressure, heavy water leakage) occur in the multi-pump system. Other else warnings (dry pump, clean, cavitation) give warnings according to each parameter setting. If systematic faults [high water pressure (HPS), low water pressure (LPS), heavy water leakage (LEKE)], RTC error (rtf) occur or when the scheduled function is ON, ensure for the safety, low battery voltage (LBAt), adjust RTC (rCAL), force to stop (FStop) make the whole system stop in the first second of powering ON .

When using multi-master function, load the built-in PLC function of all MPD (master, slave) in the system in, switch ON and set the range of the pressure sensor (Pr.00-25, Pr.00-26), station address (Pr.09-00), pump system configuration setting (Pr.04-57), refer to the section 12-2 for more details about parameters and the setting procedures. For taking over the master, the wiring of hardware and the function parameters of backup master should be the same as the master. Refer to the section 4-4 Wiring Of Multi-pump Communication Cables and section 4-5 Wiring Of Pressure Sensor for more details about the wiring of hardware.

Station definitions of the built-in PLC function

Communication master	Slave	Absolute master	Backup master
The station to send commands (Display M on LCD)	Relative communication master The station to receive commands	Station address1, and is definitely the communication master	The other station addresses that Pr.04-57 bit8 = 1

The conditions to be master, backup master, slave:

Conditions for setting		Absolute master	Backup master	Slave
Essential Sesetting max (Pruse	Enable / disable built-in PLC function	Enable (PLC1)	Enable (PLC1)	Enable (PLC1)
	Setting of CANopen station address (Pr.09-00)	1	2–8 (cannot set doubly)	1–8 (cannot set doubly)
	Setting of backup master (Pr.04-57)	-	A. Backup master is ON / OFF: bit 8 = 1 B. Warning of switching backup master to master PL00 is ON / OFF: set bit 9 according to requirement	-
	User defined (Pr.00-26) (Pr.00-39)	Should be set the same	Should be set the same	Should be set the same
	Differential pressure control (Pr.08-57)	Should be set the same	Should be set the same	Should be set the same

Chapter 15 PLC Function Applications | MPD

Condi	tions for setting	Absolute master	Backup master	Slave
	Communication setting (Pr.09-31)	-12 (auto-setting)	0 (auto-setting) NOTE: the setting changes to - 12 automatically after changing to be master station	0 (auto-setting)
Other conditions (Except FSTP, LVS)		If a malfunction occurs, then the absolute master changes to be slave, and the communication master transfers to another station address.	If a malfunction occurs, then this cannot be communication master.	-
	Others	Can not have other communication masters in communication	Can not be master if there is another communication master	-

Note: The mark " - " means it does not refer to the parameter setting.

Take notice of this, when built-in PLC function is ON, the parameters listed below are set automatically or affect the function listed below. Switch to normal multi-pump mode when built-in PLC function is OFF, and remember to adjust the parameters listed below to prevent multi-pump function from being invalid.

Parameter setting	Disable PLC	Enable PLC (for multi-master)	Enable PLC and then disable it
PID mode (Pr.08-00)	-	0: Disabled	-
Internal communication protocol (Pr.09-31)	1	Master: -12 Slave: 0	-
Communication address (Pr.09-00)	1	1–8	-
Communication speed of COM1 (Pr.09-01)	1	115.2	-
Communication format of COM1 (Pr.09-04)	-	14: 8E1 (RTU)	12: 8N1 (RTU)
Treatment of pump's fault (Pr.12-13)	-	5	-
MI1	-	MI1 is not regulated by Pr.02-00. If Pr.04-57 bit 0 = 1, MI1 fixes the mode that bit 0 = 1 (RUN) and bit 0 = 0 (STOP)	-
Signal loss selection for the Al1 4–20 mA (Pr.03-19)	-	Pr.03-19 cannot be 2. But if Pr.03-19 = 2 originally, then the value changes to be 3 automatically.	-


Note: The mark " - " means does not do any other setting, but maintain parameter's last status.

If offline communication, power failure, breakdown, or offline pressure sensor occurs, then the communication master becomes slave, and the communication master transfer to another station address.

A. The communication is offline / online:

- a. When the communication is offline, the backup master in the communication block without communication master automatically becomes the communication master. The smaller the ID is, the easier it becomes communication master.
- b. If the slave detects that it's not controlled by communication master, then the operation is according to Pr.12-12 (pump's frequency at time-out) and continues till the communication is online.
- c. After the communication is online, the absolute master re-controls the system (becomes communication master). If there is no absolute master, then the smaller the ID of backup master is, the easier it controls system. And it continues operating by the previous state.


In the system, ID1 is the absolute master, ID2 / ID3 are backup masters, ID4 is the slave.



B. Power failure, breakdown / restore power, reset:

- a. If the original communication master has power failure or breakdown, the backup master becomes communication master. The smaller the ID is, the easier it becomes communication master.
- b. When the original communication master is back to normal (after reset or re-power on), if this is absolute master, then it becomes communication master again; if this is backup master, then it keeps the slave's state.


In the system, ID1 is the absolute master, ID2 / ID3 are backup masters, ID4 is the slave.




- C. The pressure sensor is off-line / online:
 - a. When the absolute master loses the signal of pressure sensor, it cannot be communication master, but the backup master can be. The smaller the ID of backup master is, the easier it becomes communication master.
 - b. If the communication master loses the signal of pressure sensor, then it operates according to Pr.03-19 (signal loss selection for Al1 analog input 4–20 mA); if there is no communication master, then the slave operates according to Pr.12-12 till the communication master appears.

Pr.	Descriptions	Setting range of AC motor drive	Setting range of the enabled built-in PLC function
03-19	Signal loss selection for the Al1 4–20 mA	O: Disabled 1: Continue operation at the last frequency 2: Decelerate to 0 Hz 3: Stop immediately and display ACE	O: No warning 1: Occurs a ANL warning and operates according to the command from communication master. If there is no communication master, then it operates according to Pr.12-12. 2: Disabled 3: Occur an ACE fault to stop and withdraws from multi-pump system

In the system, ID1 is the absolute master, ID2 / ID3 are backup masters, ID4 is the slave.




In the system, ID1 is the absolute master, ID2 is the backup master, ID3 / ID4 are the slaves (Pr.03-19 ≠ 0)



c. When the original communication master receives the signal of pressure sensor again, if this is absolute master, then it becomes communication master again; if this is backup master, then it keeps the slave's state.

In the system, ID1 is the absolute master, ID2 / ID3 / ID4 are the backup masters (Pr.03-19 \neq 0)



The special D mentioned below is the settings for PID, you can use Pr.08-01-08-03 to set it synchronously.

N = 1 - 8

Special D	Function	Settings	R/W *
D1195 + 20N	P value of PIN N (two decimal places)	Pr.08-01	RW
D1196 + 20N	I value of PID1 (two decimal places)	Pr.08-02	RW
D1197 + 20N	D value of PID1 (two decimal places)	Pr.08-03	RW

15-12 Function Block Diagram (FBD) --- for DIADesigner

MPD provides built-in multiple master stations and scheduled function blocks. You can import function blocks via the software called DIADesigner to perform these functions, and you can also add other programs, but this don't affect the original built-in functions.



Note: For information related to DIADesigner software, please click on the link: <u>DIAStudio Downloads</u> or scan the QR code on the upper right.

15-12-1 MPD PLC multiple master station function block

15-12-1-1 Features

A. Introduction to functions

- a-1 Multi-master station function
 - Master station: the function block can be set as a master station. When set as a master station, the LCD displays M.
 - Slave station: the function block can be set as a slave station. When set as a slave station, the LCD displays the current setting value of Pr.09-00.
 - Backup master station: set the slave station as a backup master station, and this backup master station will become the master station automatically if the original master station fails or lose the connection with the original master station.
 - The definitions of these stations are as follows:

Communication	Slave station	Absolute master station	Backup master station
master station			
The station to send	The station to	Station number 1 (Pr.09-	Any other stations that
commands	receive commands	00 = 1), and is definitely	Pr.04-57 bit8 = 1
(Display M on LCD)		the communication master	
		station if there is no errors.	

a-2 Multi-pump controlling function

- Add / reduce pumps: the order of adding / reducing pumps follows Pr.12-14 setting:
 Pr.12-14 = 0, according to the serial numbers of the pumps; Pr.12-14 = 1, according to the operating time.
- Auto-change pumps: set Pr.12-50, and set the corresponding time parameters (Pr.12-51, 12-52). If Pr.12-50 = 1 (absolute time), when the RTC (Pr.12-95, 12-96) reaches the setting (Pr.12-51), then auto-change pumps has been triggered. If Pr.12-50 = 2 (fixed time), when the accumulated time reaches the setting (Pr.12-52), then auto-change pumps is been triggered.

a-3 Bluetooth function

- When the communication master station is connected to an external Bluetooth communication card, it can capture the data of each slave station and send the data to the APP through the Bluetooth card.
- Users can read the information of each station through Bluetooth APP.

15-12-1-2 Introduction to function block diagram (FBD)

A. Interface of function block diagram (FBD)

The following table introduces the function block interface, includes input and output pins.

FB/FC	FB Name	Graphic Expression
FB	DFB_MPD_MultiStationSystem	B_MultiSystem DFB_MPD_Mul EN ENO bUpdate bPumpbPumpSwitch wAddress wComm bID1 -bID1 wUserDefine wUerDe bID2 -bID2 wUserMaxValue wMaxU bID3 -bID3 bPumpControl bPump bID4 -bID4

B. Input pins

The following table explains the functions of input pins:

Name	Function	Data type	Setting value (Default value)	Note
bUpdate	Update parameters	BOOL	False / True (False)	Update parameters as follows when bUpdate = True
wAddress	Communication address	Word	N/A	Write in Pr.09-00 when bUpdate = True
wUserDefine	User-defined characteristics	Word	N/A	Write in Pr.00-25 when bUpdate = True
wUserMaxValue	Maximum user- defined value	Word	N/A	Write in Pr.00-26 when bUpdate = True
bPumpControl	External control outputs	BOOL	False / True (False)	When bPumpControl = True, the outputs of pumps are controlled by the external programs, and add / reduce pumps according to the station number (Pr.12-14 = 0).

C. Output pins

The following table explains the functions of output pins:

Name	Function	Data type	Output range (Default value)
bPumpSwitch	Display the pumps start	BOOL	False / True (False)
bID1	Display the first station is online	BOOL	False / True (False)
bID2	Display the second station is online	BOOL	False / True (False)
bID3	Display the third station is online	BOOL	False / True (False)
bID4	Display the fourth station is online	BOOL	False / True (False)


15-12-1-3 Operation instruction

- A. Operating procedures
 - a-1 Import MPD PLC function block

Step 1. Click "Library Manager"



Step 2. Click "Library Repository"




Step 3. At this moment, a dialog appears the installed libraries, click "Install"



Step 4. Select MPD PLC Library to import

Step 5. Click "Add Library"




- a-2 Set RTC time before using the scheduled function block (Pr.12-93–12-96)
- a-3 Drag and drop the function block to PLC program as shown below.Drag the function block from the left project tree, and drop in PLC program.



B. Multi-master station function

- b-1 Set communication master station
 - Set communication address Pr.09-00 = 1, it can also been set by using function block.
 For example, after performing wAddress = 1, it becomes communication master station, and M shows on the LCD.
 - After setting the communication master station, the function block will display the online status of each station. For example, bID1 = True, this means the master stations is online. Through the function block output pin, you can know the current online status of each slave station.



b-2 Set slave station

Set communication address Pr.09-00 = 2-4, this becomes slave station after performing, and LCD shows the setting value of Pr.09-00.

b-3 Set backup master station

Set Pr.04-57 bit8 = 1 for slave station, and this becomes backup master station.

- C. Multi-pump controlling function
 - c-1 Add / reduce pumps
 - Step 1. Set Pr.12-14 (selection of pump start-up sequence), to select the way to add / reduce pumps.
 - Step 2. Set Pr.12-00 (set point deviation level) and Pr.12-01 (detection time of set point deviation level).
 - Step 3. Set Pr.12-02 (offset level of low water consumption)
 - Step 4. Press RUN button of the master station keypad. If the current water pressure is less than the low water consumption level, then add pumps in sequence.
 - Step 5. When the target pressure is reached, pumps reduce sequentially.
 - c-2 Auto-change pumps
 - Step 1. Set the type of cycle time
 - 1: absolute time, refer to Pr.12-51
 - 2: fixed time, refer to Pr.12-52
 - Step 2. The auto-change pumps setting refer to the follows

12-50 Cycle Time Selection

Default: 2

Settings 0: Disabled

1: Absolute time

2: Fixed time


	12-51	Multi-pu	mp's Real Time Circulation Period	
				Default: 00:00
		Settings	00:00–23:59	
×	12-52	Multi-pu	mp's Fixed Time Circulation Period	
				Default: 5.0
		Settings	0.0-3000.0 hours	
	This pa	arameter is	valid for master pump.	
	☐ Set cyc	cle time in	Pr.12-50, master pump and slave pump swit	ches when the absolute
	time is	equal to P	r.12-51 or the operation time of master pump	is larger than Pr.12-52.
	☐ If Pr.12	2-50 = 1, ac	ljust RTC in Pr.12-93–12-96 before setting th	nis parameter.

15-12-2 MPD PLC scheduled function block

15-12-2-1 Features

A. Introduction to functions

a-1 The rules of each time interval and target pressure



a-2 Specific day schedule

- To perform the target pressure for the time interval of the specific day
- The specific day is the date specified by user

a-3 Weekend schedule

- To perform the target pressure for the time interval of weekends
- Use Pr.04-59 to define the weekends, which are Saturdays and Sundays or is just Sundays.

a-4 Weekday schedule

- Weekday schedule means that the days except specific days and weekends.
- Weekday schedule just need to specify time interval.

a-5 The priority to perform target pressure:

In the same time interval, specific day > weekend > weekday

15-12-2-2 Introduction to function block diagram (FBD)

- b. The scheduled function block is divided into: weekday scheduled function block, weekend scheduled function block, and specific day scheduled function block.
- b-1 Introduction to weekday scheduled function block

The following table introduces the function block interface of weekday schedule, includes descriptions of input and output pins, and default.

FB/FC	FB Name	Graphic Expression
FB	DFB_MPD_WeekdaysSchedule	FB_MPD_Weeks DFB_MPD_We EN ENO

Input pins

Name	Function	Data type	Setting value (Default value)	Note
bUpdate	Update parameters	BOOL	False / True (False)	Update parameters as follows when bUpdate = True
wSchedule	Schedule setting	Word	N/A	Write in Pr.04-58 when bUpdate = True

Output pins

Name	Function	Data type	Output range (Default value)
bTimeValid1	Time interval 1 is valid	BOOL	False / True (False)
bTimeValid2	Time interval 2 is valid	BOOL	False / True (False)
bTimeValid3	Time interval 3 is valid	BOOL	False / True (False)
bTimeValid4	Time interval 4 is valid	BOOL	False / True (False)
bTimeValid5	Time interval 5 is valid	BOOL	False / True (False)

b-2 Introduction to weekend scheduled function block

The following table introduces the function block interface of weekend schedule, includes descriptions of input and output pins, and default.

FB/FC	FB Name	Graphic Expression		
FB	DFB_MPD_WeekendSchedule	DFB_MPD_We EN ENC bUpdate bTimeV wSched bTimeV bTimeV bTimeV		

Input pins

Name	Function	Data type	Setting value (Default value)	Note
bUpdate	Update parameters	BOOL	False / True (False)	Update parameters as follows when bUpdate = True
wSchedule	Schedule setting	Word	N/A	Write in Pr.04-58 when bUpdate = True
wWeekendSetting	Weekend setting	Word	N/A	Write in Pr.04-59 when bUpdate = True, refer to Pr.04-59 for the setting

Parameter setting

Weekdays, weekend, specific day schedule

Default: 0

Settings bit 0: 1 (weekdays)

bit 1: 1 (weekend) bit 2: 1 (specific day)

Weekend Setting

Default: 0

Settings 0: Saturday, Sunday

1: Sunday

Output pins

Name	Function	Data type	Output range (Default value)
bTimeValid1	Time interval 1 is valid	BOOL	False / True (False)
bTimeValid2	Time interval 2 is valid	BOOL	False / True (False)
bTimeValid3	Time interval 3 is valid	BOOL	False / True (False)
bTimeValid4	Time interval 4 is valid	BOOL	False / True (False)
bTimeValid5	Time interval 5 is valid	BOOL	False / True (False)

b-3 Introduction to specific day scheduled function block

The following table introduces the function block interface of specific day schedule, includes descriptions of input and output pins, and default.

FB/FC	FB Name	Graphic Expression
FB	DFB_MPD_WeekendSchedule	DFB_MPD_Spe EN ENO- bUpdate bTimeV wSched bTimeV bTimeV bTimeV

Input pins

Name	Function	Data type	Setting value (Default value)	Note
bUpdate	Update parameters	BOOL	False / True (False)	Update parameters as follows when bUpdate = True
wSchedule	Schedule setting	Word	N/A	Write in Pr.04-58 when bUpdate = True

Output pins

Name	Function	Data type	Output range (Default value)
bTimeValid1	Time interval 1 is valid	BOOL	False / True (False)
bTimeValid2	Time interval 2 is valid	BOOL	False / True (False)
bTimeValid3	Time interval 3 is valid	BOOL	False / True (False)
bTimeValid4	Time interval 4 is valid	BOOL	False / True (False)
bTimeValid5	Time interval 5 is valid	BOOL	False / True (False)

15-12-2-3 Operation instruction of function block


A. Import function block

a-1 Import MPD PLC function block

Step 1. Click "Library Manager"



Step 2. Click "Library Repository"




Step 3. At this moment, a dialog appears the installed libraries, click "Install"



Step 4. Select MPD PLC Library to import

Step 5. Click "Add Library"




- a-2 Set RTC time before using the scheduled function block (Pr.12-93-12-96)
- a-3 Drag and drop the function block to PLC program as shown below.


 Drag the function block from the left project tree, and drop in PLC program.



a-4 The scheduled function block needs to be used with the multiple master function block. Please confirm that the multiple master function block has been imported, as shown below.




a-5 If you want to use all scheduled functions, then import the entire of them to PLC program, as shown below.




B. Weekday schedule

- b-1 Set Pr.04-58 = 1, or use function block to set wSchedule = 1.
- b-2 Set Pr.04-60-04-69.
- b-3 Start the function block, the performing status is as shown below




C. Weekend schedule

- c-1 Set Pr.04-58 = 2, or use function block to set wSchedule = 2.
- c-2 Set Pr.04-59 = 0 or 1, or use function block to set wWeekenSetting = 2
- c-3 Set Pr.04-70-04-79.
- c-4 Start the function block, the performing status is as shown below



D. Specific day schedule

- d-1 Set Pr.04-58 = 4, or use function block to set wSchedule = 4.
- d-2 Set Pr.04-80-04-99.
- d-3 Start the function block, the performing status is as shown below



[This page intentionally left blank]

Chapter 16 BACnet Instructions

16-1 Introduction to BACnet and the Steps

16-1 Introduction to BACnet and the Steps

16-1-1 Specifications of BACnet

Item		Content
Int	erface	RS-485
Type of sy	nchronization	Asynchronous
	Serial transfer rate	9.6, 19.2, 38.4 Kbps
Communication	Data bits	8-bit
parameters	Parity	None (N)
	Stop bit	1-bit
Communic	cation protocol	RTU

16-1-2 About BACnet:


BACnet is an ASHRAE communication protocol for **b**uilding **a**utomation and **c**ontrol **net**works. (ASHRAE: **A**merican **S**ociety of **H**eating, **R**efrigerating and Air-Conditioning **E**ngineers, Inc.). MP300's BACnet is based on version 2004.

BACnet's regulations are related to several kinds of physical layers' interfaces. The physical layer built inside MP300 is achieved via MS/TP interface.

The BACnet of MP300 supports a device type called B-ASC. B-ASC supports six types of services such as DS-RP-B, DS-RPM-B, DS-WP-B, DM-DDB-B, DM-DOB-B and DM-DCC-B.

16-1-3 Cable Configuration

For the communication interface and wring are as the following descriptions and figure: Pay special attention to this, when Pr.09-32 is 1, only COM2 interface supports BACnet communication. When BACnet function is enabled, COM2 port will be controlled by BACnet to transmit and receive data. In other words, COM2 port will not be able to support Modbus, DIADesigner for communication.



16-1-4 Parameter Setting for BACnet

To use MP300's BACnet, we have two parts of parameters to set.

- Part 1. Set communication parameters in the parameter group 9.
- Part 2. Set system parameters in the parameter group 0.

Part 1. Set communication parameters in the parameter group 9

- Set Pr.09-32 = 1 to define the communication interface of COM2 is BACnet (Please note that when BACnet function is enabled, Modbus, DIADesigner cannot be used on the COM2 port). After the setting, the communication format is fixed to RTU 8, N, 1, and will not consider the setting of Pr.09-04.
- 2. Set Pr.09-05 to define the communication speed of BACnet. It supports three kinds of speed which are 9600, 19200, 38400, and the default is 38400.
- 3. Set Pr.09-45 to define MS/TP station number of BACnet is 0-127, and the default is 10.
- 4. Set Pr.09-46 to define searching range of station numbers, the default is 127.
- 5. Set Pr.09-47 for Device Object_Identifier (Device Instance), the default is 55.
- 6. Set Pr.09-48 if you want to use password to lock and control, the default is 0.

Part 2. Set system parameters in the parameter group 0

- 1. Set Pr.00-20 = 1, it means the frequency source is from RS-485.
- 2. Set Pr.00-21 = 2, it means the control source is from RS-485.

Application:

After setting the parameters of those two parts through the above steps, we have enabled MP300's BACnet function. Therefore, we can control MP300's run and stop, or get the running status through BACnet's objects.

- Step1. Use write service to change Present_Value of AV_000 (Frequency command) to be 60.0 Hz.
- Step2. Use write service to change Present_Value of BV_000 (Active CMD) to be Active.
- Step3. Use read service to retrieve Present_Value of AV_050 (Output frequency).

Note: In the application of MP300, we can make the frequency command refer to different sources through different parameter settings or digital terminal settings. To understand more rules about reference sources, refer to the instructions of keypad, parameters, and digital terminals.

16-1-5 Objects and Properties of MP300

MP300's BACnet supports 3 types of objects: Device, Analog Value (AV) and Binary Value (BV). We use the following table to describe that the properties supported by each of these objects.

		Object Type			
	Property Numbers and Property Names	Device	Analog Value (AV)	Binary Value (BV)	
#4	ACTIVE_TEXT			V	
#11	APDU_TIMEOUT (APDU, Application Protocol Data Unit)	V			
#12	APPLICATION_SOFTWARE_VERSION	V			
#28	DESCRIPTION	V	V	V	

Chapter 16 BACnet Instructions | MPD

		Object Type			
	Property Numbers and Property Names	Device	Analog Value (AV)	Binary Value (BV)	
#30	DEVICE_ADDRESS_BINDING	V	V		
#36	EVENT_STATE		V	V	
#44	FIRMWARE_REVISION	V			
#46	INACTIVE_TEXT			V	
#62	MAX_APDU_LENGTH_ACCEPTED	V			
#63	MAX_INFO_FRAMES	V			
#64	MAX_MASTER	V			
#70	ODEL_NAME	V			
#73	NUMBER_OF_APDU_RETRIES	V			
#75	OBJECT_IDENTIFIER	V *1	V	V	
#76	OBJECT_LIST	V			
#77	OBJECT_NAME	V *1	V	V	
#79	OBJECT_TYPE	V	V	V	
#81	OUT_OF_SERVICE		V	V	
#85	PRESENT_VALUE		V *2	V *2	
#87	PRIORITY_ARRAY		V *3	V *3	
#96	PROTOCOL_OBJECT_TYPES_SUPPORTED	V			
#97	PROTOCOL_SERVICES_SUPPORTED	V			
#98	PROTOCOL_VERSION	V			
#104	RELINQUISH_DEFAULT		V *3	V *3	
#107	SEGMENTATION_SUPPORTED	V			
#111	STATUS_FLAGS		V	V	
#112	SYSTEM_STATUS	V			
#117	UNITS		V		
#120	VENDOR_IDENTIFIER	V			
#121	VENDOR_NAME	V			
#139	PROTOCOL_REVISION	V			
#155	DATABASE REVISION	V			

Note:

^{*1.} Both the property of the object identity code (Object_ID) and the property of the object name (Object_Name) of the Device are writeable.

^{*2.} The present values (Present_Value) of some AV and BV are commandable.

^{*3.} If the object is commandable, it also supports Priority_Array and Relinguish_Default properties.

16-1-5-1 AV objects, they can be divided into commandable objects and read-only objects

 Commandable AV objects: we can use write service to change the present values of commandable objects. Therefore, commandable AV objects are often linked to the control characters and parameters of MP300.

In MP300, the present values of the object number AV_000–AV_001 are commandable. Moreover, the object number AV_000–AV_001 also support Priority_Array and Relinquish Default properties. Therefore, we can use read service to get data.

Object Number	R/W	Object Name	Description	Unit
AV 000	RW	AV 000	Frequency command	UNITS_HERTZ
AV 001	RW	AV 001	AO Value	UNITS_PERCENT

 Read-only AV objects: we can only use read service to get data from the present value of the read-only objects. Therefore, read-only AV objects are often linked to the status characters of MP300.

In MP300, the present values of the object number AV_050-AV_075 are read-only. Therefore, the object number AV_050-AV_075 don't support Priority_Array and Relinguish_Default properties.

Object Number	R/W	Object Name	Description	Unit
AV 050	R	AV 050	Output Frequency	UNITS_HERTZ
AV 051	R	AV 051	Output Torque	UNITS_PERCENT
AV 052	R	AV 052	Warn Code	UNITS_NO_UNITS
AV 053	R	AV 053	Error Code	UNITS_NO_UNITS
AV 054	R	AV 054	Output Current	UNITS_AMPERES
AV 055	R	AV 055	Dc Bus Voltage	UNITS_VOLTS
AV 056	R	AV 056	Output Voltage	UNITS_VOLTS
AV 057	R	AV 057	Output Power Angle P.F.	UNITS_DEGREES_ANGULAR
AV 058	R	AV 058	Output Power	UNITS_KILOWATTS
AV 059	R	AV 059	IGBT Temperature	UNITS_DEGREES_CELSIUS
AV 060	R	AV 060	Capacitance Temperature	UNITS_DEGREES_CELSIUS
AV 061	R	AV 061	Real Carrier Frequency	UNITS_KILOHERTZ
AV 062	R	AV 062	OL Level	UNITS_PERCENT
AV 063	R	AV 063	GFF Detect Level	UNITS_PERCENT
AV 064	R	AV 064	Dc Bus Voltage Ripples	UNITS_VOLTS
AV 065	R	AV 065	Fan Speed	UNITS_PERCENT
AV 066	R	AV 066	Output Speed(rpm)	UNITS_REVOLUTIONS_PER _MINUTE
AV 067	R	AV 067	Kw Per Hour	UNITS_KILOWATT_HOURS
AV 068	R	AV 068	Real Multi-Speed Switch	UNITS_NO_UNITS
AV 069	R	AV 069	Digital Input Status	UNITS_NO_UNITS
AV 070	R	AV 070	Digital Output Status	UNITS_NO_UNITS
AV 071	R	AV 071	Cpu Pin Status of Digital Input	UNITS_NO_UNITS
AV 072	R	AV 072	Cpu Pin Status of Digital Output	UNITS_NO_UNITS

Object Number	R/W	Object Name	Description	Unit
AV 073	R	AV 073	PLC D1043 Value	UNITS_NO_UNITS
AV 074	R	AV 074	PID Reference	UNITS_NO_UNITS
AV 075	R	AV 075	PID Feedback	UNITS_NO_UNITS

16-1-5-2 BV objects, they can be divided into commandable objects and read-only objects

 Commandable BV objects: we can use write service to change the present values of commandable objects. Therefore, commandable BV objects are often linked to the control characters of MP300.

In MP300, the present values of the object number BV_000–BV_002 are commandable. Moreover, the object number BV_000–BV_002 also support Priority_Array and Relinguish_Default properties. Therefore, we can use read service to get data.

	· · · · · · · · · · · · · · · · · · ·	· ·	
Object Number	R/W	Object Name	Description
			Run/Stop Cmd
BV 000	RW	BV 000	(0): FreqCmd=0
			(1): FreqCmd=FreqRefValue
			Fwd/Rev Cmd
BV 001	RW	BV 001	(0): Forward
			(1): Reverse
			Reset Cmd
BV 002	RW	BV 002	(0): Do nothing
			(1): Reset Fault

 Read-only BV objects: we can only use read service to get data from the present value of the read-only objects. Therefore, read-only BV objects are often linked to the status characters of MP300.

In MP300, the present values of the object number BV_050-BV_053 are read-only. Therefore, the object number BV_050-BV_053 don't support Priority_Array and Relinguish_Default properties.

Object Number	R/W	Object Name	Description
			Run/Stop State
BV 050	R	BV 050	(0): VFD Stop
			(1): VFD Running
			Fwd/Rev State
BV 051	R	BV 051	(0): Forward
			(1): Reverse
			Warn State
BV 052	R	BV 052	(0): No Warn
			(1): Occur Warn
			Error State
BV 053	R	BV 053	(0): No Error
			(1): Occur Error

Appendix A. Revision History

Changes		
Description	Affected Chapter / Section	
Add information related to MP300 frame C models	Section 2-1, 2-4, 3-1,	
	3-2, 5-2, 7-1, 7-2, 7-	
	3, 7-8, 9-1	
Revise the minimum wire gauge information of PE terminals	Section 5-2	
Add EMC shield plate information for frame C models	Section 7-4	
Add waterproof connector for frame C models	Section 7-5	
Revise the descriptions of IFD6500 PIN4 and PIN5	Section 7-6	
Add UVW wire gauge information for the assembly of adapter plate for motor	Section 7-8	
Add information about fan and fan cord, and the steps to disassemble	Section 7-9	
Add information about communication card, CMM-PN02	Section 8-6, Pr.09-60	
Add notes for CE / RE class in the specification table	Section 9-1	
Revise the setting value of Pr.01-02 in the table and Y axis value in V/F curve	Pr.01-01, Pr.01-02,	
	Pr.01-03, Pr.01-04,	
	Pr.01-05, Pr.01-06,	
	Pr.01-07, Pr.01-08	
	Pr.02-01-02-04	
Add parameters related to PID function	(delete setting value	
	21), Pr.08-55, Pr.08-	
	56, Pr.08-57	
Add parameters related to power-off function	Pr.02-35, Pr.07-35,	
	Pr.07-36	
Add a parameter for torque command at malfunction	Pr.06-39	
Revise the description for restart after fault action	Pr.07-10	
Add parameters related to energy-saving function	Pr.07-21, Pr.07-41,	
	Pr.07-42, Pr.07-44,	
	Pr.07-45, Pr.07-82,	
	Pr.07-83	
Add parameters related to BACnet	Pr.09-32, Pr.09-45,	
	Pr.09-46, Pr.09-47,	
	Pr.09-48	
Revise the lower limit value of year setting	Pr.12-93	
Revise the lower limit value for IGBT temperature at malfunction	Pr.14-53, Pr.14-57,	
	Pr.14-61, Pr.14-65,	
	Pr.14-69	
Add / delete the parameter address of communication protocol (2157H, 220FH, 2216H, 221DH, 2231H)	Pr.09-01~09-08	

Appendix A. Revision History | MPD

Add descriptions of the decoding method that control source is communication card	Pr.09-30
Add warning code: NOut · CAvi	Chapter 13
Add fault code: oSL	Chapter 14
Revise the description of SG1-/+, SG2-/+	Section 15-2
Add a mark to show this chapter is applicable to DIADesigner, and provide DIADesigner related file paths	Section 15-12
Add descriptions for BACnet setting	Chapter 16



Industrial Automation Headquarters

Delta Electronics, Inc.

Taoyuan Technology Center No.18, Xinglong Rd., Taoyuan District, Taoyuan City 330477, Taiwan TEL: +886-3-362-6301 / FAX: +886-3-371-6301

Asia

Delta Electronics (Shanghai) Co., Ltd.

No.182 Minyu Rd., Pudong Shanghai, P.R.C. Post code: 201209

TEL: +86-21-6872-3988 / FAX: +86-21-6872-3996

Customer Service: 400-820-9595

Delta Electronics (Japan), Inc.

Industrial Automation Sales Department 2-1-14 Shibadaimon, Minato-ku Tokyo, Japan 105-0012

TEL: +81-3-5733-1155 / FAX: +81-3-5733-1255

Delta Electronics (Korea), Inc.

1511, 219, Gasan Digital 1-Ro., Geumcheon-gu, Seoul, 08501 South Korea TEL: +82-2-515-5305 / FAX: +82-2-515-5302

Delta Energy Systems (Singapore) Pte Ltd.

4 Kaki Bukit Avenue 1, #05-04, Singapore 417939 TEL: +65-6747-5155 / FAX: +65-6744-9228

Delta Electronics (India) Pvt. Ltd.

Plot No.43, Sector 35, HSIIDC Gurgaon, PIN 122001, Haryana, India TEL: +91-124-4874900 / FAX: +91-124-4874945

Delta Electronics (Thailand) PCL.

909 Soi 9, Moo 4, Bangpoo Industrial Estate (E.P.Z), Pattana 1 Rd., T.Phraksa, A.Muang, Samutprakarn 10280, Thailand TEL: +66-2709-2800 / FAX: +66-2709-2827

Delta Electronics (Australia) Pty Ltd.

Unit 2, Building A, 18-24 Ricketts Road, Mount Waverley, Victoria 3149 Australia Mail: IA.au@deltaww.com

TEL: +61-1300-335-823 / +61-3-9543-3720

Americas

Delta Electronics (Americas) Ltd.

5101 Davis Drive, Research Triangle Park, NC 27709, U.S.A. TEL: +1-919-767-3813

Delta Electronics Brazil Ltd.

Estrada Velha Rio-São Paulo, 5300 Eugênio de Melo - São José dos Campos CEP: 12247-004 - SP - Brazil TEL: +55-12-3932-2300 / FAX: +55-12-3932-237

Delta Electronics International Mexico S.A. de C.V.

Gustavo Baz No. 309 Edificio E PB 103 Colonia La Loma, CP 54060 Tlalnepantla, Estado de México TEL: +52-55-3603-9200

EMEA

Delta Electronics (Netherlands) B.V.

Sales: Sales.IA.EMEA@deltaww.com
Marketing: Marketing.IA.EMEA@deltaww.com
Technical Support: iatechnicalsupport@deltaww.com
Customer Support: Customer-Support@deltaww.com
Service: Service.IA.emea@deltaww.com

TEL: +31(0)40 800 3900

Delta Electronics (Netherlands) B.V.

Automotive Campus 260, 5708 JZ Helmond, The Netherlands

Mail: Sales.IA.Benelux@deltaww.com

TEL: +31(0)40 800 3900

Delta Electronics (Netherlands) B.V.

Coesterweg 45, D-59494 Soest, Germany Mail: Sales.IA.DACH@deltaww.com

TEL: +49 2921 987 238

Delta Electronics (France) S.A.

ZI du bois Challand 2,15 rue des Pyrénées, Lisses, 91090 Evry Cedex, France Mail: Sales.IA.FR@deltaww.com TEL: +33(0)1 69 77 82 60

Delta Electronics Solutions (Spain) S.L.U

Ctra. De Villaverde a Vallecas, 265 1º Dcha Ed. Hormigueras – P.I. de Vallecas 28031 Madrid

TEL: +34(0)91 223 74 20

Carrer Llacuna 166, 08018 Barcelona, Spain Mail: Sales.IA.Iberia@deltaww.com

Delta Electronics (Italy) S.r.l.

Via Meda 2–22060 Novedrate(CO) Piazza Grazioli 18 00186 Roma Italy Mail: Sales.IA.Italy@deltaww.com TEL: +39 039 8900365

Delta Greentech Elektronik San. Ltd. Sti. (Turkey)

Şerifali Mah. Hendem Cad. Kule Sok. No:16-A

34775 Ümraniye – İstanbul

Mail: Sales.IA.Turkey@deltaww.com

TEL: + 90 216 499 9910

Eltek Dubai (Eltek MEA DMCC)

OFFICE 2504, 25th Floor, Saba Tower 1, Jumeirah Lakes Towers, Dubai, UAE Mail: Sales.IA.MEA@deltaww.com

TEL: +971(0)4 2690148

 ${}^{*}\text{We}$ reserve the right to change the information in this manual without prior notice.