

Industrial Automation Headquarters

Delta Electronics, Inc.

Taoyuan Technology Center No.18, Xinglong Rd., Taoyuan District, Taoyuan City 330477, Taiwan TEL: +886-3-362-6301 / FAX: +886-3-371-6301

Asia

Delta Electronics (Shanghai) Co., Ltd.

No.182 Minyu Rd., Pudong Shanghai, P.R.C. Post code: 201209 TEL: +86-21-6872-3988 / FAX: +86-21-6872-3996 Customer Service: 400-820-9595

Delta Electronics (Japan), Inc.

Industrial Automation Sales Department 2-1-14 Shibadaimon, Minato-ku Tokyo, Japan 105-0012 TEL: +81-3-5733-1155 / FAX: +81-3-5733-1255

Delta Electronics (Korea), Inc.

1511, 219, Gasan Digital 1-Ro., Geumcheon-gu, Seoul, 08501 South Korea TEL: +82-2-515-5305 / FAX: +82-2-515-5302

Delta Energy Systems (Singapore) Pte Ltd.

4 Kaki Bukit Avenue 1, #05-04, Singapore 417939 TEL: +65-6747-5155 / FAX: +65-6744-9228

Delta Electronics (India) Pvt. Ltd.

Plot No.43, Sector 35, HSIIDC Gurgaon, PIN 122001, Haryana, India TEL: +91-124-4874900 / FAX: +91-124-4874945

Delta Electronics (Thailand) PCL.

909 Soi 9, Moo 4, Bangpoo Industrial Estate (E.P.Z), Pattana 1 Rd., T.Phraksa, A.Muang, Samutprakarn 10280, Thailand TEL: +66-2709-2800 / FAX: +66-2709-2827

Delta Electronics (Australia) Pty Ltd.

Unit 2, Building A, 18-24 Ricketts Road, Mount Waverley, Victoria 3149 Australia Mail: IA.au@deltaww.com TEL: +61-1300-335-823 / +61-3-9543-3720

Americas

Delta Electronics (Americas) Ltd.

5101 Davis Drive, Research Triangle Park, NC 27709, U.S.A. TEL: +1-919-767-3813 / FAX: +1-919-767-3969

Delta Electronics Brazil Ltd.

Estrada Velha Rio-São Paulo, 5300 Eugênio de Melo - São José dos Campos CEP: 12247-004 - SP - Brazil TEL: +55-12-3932-2300 / FAX: +55-12-3932-237

Delta Electronics International Mexico S.A. de C.V.

Gustavo Baz No. 309 Edificio E PB 103 Colonia La Loma, CP 54060 Tlalnepantla, Estado de México TEL: +52-55-3603-9200

EMEA

Delta Electronics (Netherlands) B.V.

Sales: Sales.IA.EMEA@deltaww.com Marketing: Marketing.IA.EMEA@deltaww.com Technical Support: iatechnical support@deltaww.com Customer Support: Customer-Support@deltaww.com Service: Service.IA.emea@deltaww.com TEL: +31(0)40 800 3900

Delta Electronics (Netherlands) B.V.

Automotive Campus 260, 5708 JZ Helmond, The Netherlands Mail: Sales.IA.Benelux@deltaww.com TEL: +31(0)40 800 3900

Delta Electronics (Netherlands) B.V.

Coesterweg 45, D-59494 Soest, Germany Mail: Sales.IA.DACH@deltaww.com TEL: +49 2921 987 238

Delta Electronics (France) S.A.

ZI du bois Challand 2,15 rue des Pyrénées, Lisses, 91090 Evry Cedex, France Mail: Sales.IA.FR@deltaww.com TEL: +33(0)1 69 77 82 60

Delta Electronics Solutions (Spain) S.L.U

Ctra. De Villaverde a Vallecas, 265 1º Dcha Ed. Hormigueras - P.I. de Vallecas 28031 Madrid TEL: +34(0)91 223 74 20

Carrer Llacuna 166, 08018 Barcelona, Spain Mail: Sales.IA.Iberia@deltaww.com

Delta Electronics (Italy) S.r.I.

Via Meda 2-22060 Novedrate(CO) Piazza Grazioli 18 00186 Roma Italy Mail: Sales.IA.Italy@deltaww.com TEL: +39 039 8900365

Delta Energy System LLC

Vereyskaya Plaza II, office 112 Vereyskaya str. 17 121357 Moscow Russia Mail: Sales.IA.RU@deltaww.com TEL: +7 495 644 3240

Delta Greentech Elektronik San. Ltd. Sti. (Turkey)

Şerifali Mah. Hendem Cad. Kule Sok. No:16-A 34775 Ümraniye – İstanbul Mail: Sales.IA.Turkey@deltaww.com TEL: + 90 216 499 9910

Eltek Dubai (Eltek MEA DMCC)

OFFICE 2504, 25th Floor, Saba Tower 1, Jumeirah Lakes Towers, Dubai, UAE Mail: Sales.IA.MEA@deltaww.com TEL: +971(0)4 2690148







Digitized Automation for a Changing World

Delta Elevator Drive VFD-ED Series User Manual











Copyright Notice

©Delta Electronics, Inc. All rights reserved.

All information contained in this user manual is the exclusive property of Delta Electronics Inc. (hereinafter referred to as "Delta") and is protected by copyright law and all other laws. Delta retains the exclusive rights of this user manual in accordance with the copyright law and all other laws. No parts in this manual may be reproduced, transmitted, transcribed, translated or used in any other ways without the prior consent of Delta.

Limitation of Liability

The contents of this user manual are only for the use of the product manufactured by Delta. Except as defined in special mandatory laws, Delta provides this user manual "as is" and does not offer any kind of warranty through this user manual for using the product, either express or implied, including but not limited to the following: (i) this product will meet your needs or expectations; (ii) the information contained in the product is current and correct; (iii) the product does not infringe any rights of any other person. You shall bear your own risk to use this product.

In no event shall Delta, its subsidiaries, affiliates, managers, employees, agents, partners and licensors be liable for any direct, indirect, incidental, special, derivative or consequential damages (including but not limited to the damages for loss of profits, goodwill, use or other intangible losses) unless the laws contains special mandatory provisions to the contrary.

Delta reserves the right to make changes to the user manual and the products described in the user manual without prior notice and afterwards.



READ PRIOR TO INSTALLATION FOR SAFETY.



- ☑ Disconnect AC input power before connecting any wiring to the AC motor drive.
- ☑ Even if the power has been turned off, a charge may still remain in the DC-link capacitors with hazardous voltages before the POWER LED is OFF. Do NOT touch the internal circuits and components.
- ☑ There are highly sensitive MOS components on the printed circuit boards. These components are especially sensitive to static electricity. Take anti-static measure before touching these components or the circuit boards.
- ☑ Never modify the internal components or wiring.
- ☑ Ground the AC motor drive by using the ground terminal. The grounding method must comply with the laws of the country where the AC motor drive is to be installed.
- ☑ Do NOT install the AC motor drive in a location with high temperature, direct sunlight or inflammable materials or gases.



- ☑ Never connect the AC motor drive output terminals U/T1, V/T2 and W/T3 directly to the AC mains circuit power supply.
- ☑ After finishing the wiring of the AC motor drive, check if U/T1, V/T2, and W/T3 are short-circuited to ground with a multimeter. Do NOT power the drive if short circuits occur. Eliminate the short circuits before the drive is powered.
- ☑ The rated voltage for AC motor drive must be \leq 240V for 230V models (480V for 460V models) and the mains supply current capacity must be \leq 5000A RMS (\leq 10000A RMS for the \geq 40HP (30kW) models).
- ☑ Only qualified persons are allowed to install, wire and maintain the AC motor drives.
- ☑ Even if the three-phase AC motor is stopped, a charge with hazardous voltages may still remain in the main circuit terminals of the AC motor drive.
- ☑ The performance of electrolytic capacitor will degrade if it is not charged for a long time. It is recommended to charge the drive which is stored in no charge condition every 2 years for 3–4 hours to restore the performance of electrolytic capacitor in the motor drive. **NOTE:** When power up the motor drive, use adjustable AC power source (e.g. AC autotransformer) to charge the drive at 70%–80% of rated voltage for 30 minutes (do not run the motor drive). Then charge the drive at 100% of rated voltage for an hour (do not run the motor drive). By doing these, restore the performance of electrolytic capacitor before starting to run the motor drive. Do NOT run the motor drive at 100% rated voltage right away.
- ☑ Pay attention to the following precautions when transporting and installing this package (including wooden crate and wood stave)
 - 1. If you need to deworm the wooden crate, do NOT use fumigation or you will damage the drive. Any damage to the drive caused by using fumigation voids the warranty.
 - 2. Use other methods, such as heat treatment or any other non-fumigation treatment, to deworm the wood packaging material.
 - 3. If you use heat treatment to deworm, leave the packaging materials in an environment of over 56°C for a minimum of thirty minutes.
- ☑ Connect the drive to a three-phase three-wire or three-phase four-wire Wye system to comply with UL standards.
- ☑ If the motor drive generates leakage current over AC 3.5 mA or over DC 10 mA on a grounding conductor, compliance with local grounding regulations or IEC61800-5-1 standard is the minimum requirement for grounding.

NOTE: The content of this manual may be revised without prior notice. Consult our distributors or download the latest version at http://www.deltaww.com/iadownload acmotordrive

Table of Contents

CHAPTE	ER 1 INTRODUCTION	1-1
1-1	Nameplate Information	1-2
1-2	Model Name	1-3
1-3	Serial Number	1-3
1-4	Apply After-sales Service by Mobile Device	1-4
1-5	RFI Switch	1-7
1-6	Dimensions	1-10
CHAPTE	ER 2 INSTALLATION	2-1
2-1	Mounting Clearance	2-2
2-2	Airflow and Power Dissipation	2-3
CHAPTE	ER 3 WIRING	3-1
3-1	System Wiring Diagram	3-3
3-2	Wiring	3-4
CHAPTE	ER 4 MAIN CIRCUIT TERMINALS	4-1
4-1	Main Circuit Diagram	4-3
4-2	Main Circuit Terminal Specifications	4-5
CHAPTE	ER 5 CONTROL TERMINALS	5-1
5-1	Remove the Cover before Wiring	5-2
5-2	Control Terminal Specifications	5-4
5-3	Control Circuit Terminals	5-5
CHAPTE	ER 6 OPTIONAL ACCESSORIES	6-1
6-1	Brake Resistors and Brake Units Used in AC Motor Drives	6-2
6-2	Non-fuse Circuit Breaker	6-7
6-3	Fuse Specification Chart	6-7
6-4	AC / DC Reactor	6-8
6-5	Zero Phase Reactor	6-33
6-6	EMC Filter	6-37
6-7	Digital Keypad	6-48
6-8	USB/RS-485 Communication Interface IFD6530	6-52
CHAPTE	ER 7 OPTION CARDS	7-1
7-1	Option Card Installation	7-2
7-2	EMED-PGABD-2	7-5
7-3	EMED-PGHSD-3	7-16
7-4	EMED-PGHSD-4	7-24
CHAPTE	ER 8 SPECIFICATIONS	8-1
8-1	230V Models	8-2

8-2	2 460V Models	8-2
8-	3 General Specifications	8-3
8-	4 Operation, Storage and Transportation Environments	8-4
8-	5 Derating Curve	8-5
CHAPT	TER 9 DIGITAL KEYPAD	9-1
9-	1 Description of Keyboard Panel	9-2
9-	2 Keypad Operation Process	9-4
9-	3 Description of the Digital Keypad KPC-CC01	9-5
9-	4 Digital Keypad KPC-CC01 Functions	9-8
9-	5 Digital Keypad KPC-CC01 Fault Codes and Descriptions	9-19
9-	6 TPEditor Installation	9-25
CHAPT	TER 10 AUTO-TUNING PROCESS	10-1
10	0-1 Tuning in Easy Steps for IM	10-2
10	0-2 Tuning in Easy Steps for PM	10-3
10	0-3 Descriptions of Tuning Steps	10-4
10	0-4 Elevator Performance Fine-tuning	10-24
CHAPT	TER 11 SUMMARY OF PARAMETER SETTINGS	11-1
CHAPT	TER 12 DESCRIPTIONS OF PARAMETER SETTINGS	12-00-1
00	Drive Parameters	12-00-2
01	Basic Parameters	12-01-1
02	2 Digital Input / Output Parameters	12-02-1
03	3 Analog Input / Output Parameters	12-03-1
04	1 Multi-step Speed Parameters	12-04-1
05	5 IM Parameters	12-05-1
06	Protection Parameters	12-06-1
07	7 Special Parameters	12-07-1
80	B PM Parameters	12-08-1
09	O Communication Parameters	12-09-1
10) Feedback Control Parameters	12-10-1
11	1 Advanced Parameters	12-11-1
12	2 User-defined Parameters	12-12-1
13	3 View User-defined Parameters	12-13-1
CHAP	TER 13 WARNING CODES	13-1
CHAP	TER 14 FAULT CODES	14-1
CHAPT	TER 15 MAINTENANCE AND TROUBLESHOOTING	15-1
15	5-1 Maintenance and Inspections	15-3
15	5-2 Greasy Dirt Problems	15-6
15	5-3 Fiber Dust Problems	15-7

15-4	Corrosion Problems	15-8
15-5	Industrial Dust Problems	15-9
15-6	Installation and Wiring Problems	15-10
15-7	Multi-function Input / Output Terminal Application Problems	15-11
CHAPTE	R 16 SAFE TORQUE OFF FUNCTION	16-1
16-1	Failure Rate of the Drives Safety Function	16-2
16-2	Description of STO's Functions	16-3
16-3	Wiring Diagram	16-4
16-4	Related Parameters	16-7
16-5	Timing Diagram Description	16-8
16-6	Fault Codes Related to STO	16-11
APPEND	IX A. EMC STANDARD INSTALLATION GUIDE	A-1
A-1	Introduction	A-3
A-2	How to Prevent EMC	A-4
A-3	Solution to EMC: Grounding	A-7
A-4	Solution to EMC: Shielding	A-14
A-5	Solution to EMC: Filter	A-18
APPEND	IX B. MODBUS PROTOCOL	B-1
B-1	Code Description	B-2
B-2	Data Format	B-2
B-3	Communication Protocol	B-3
B-4	Address List	B-8
B-5	Exception Response	B-12
ADDENID	IX C. REVISION HISTORY	C-1

Issued Edition: 00

Firmware Version: V1.11 (Refer to Pr.00-06 on the product for the firmware version.)

Issued Date: June, 2023

Chapter 1 Introduction

- 1-1 Nameplate Information
- 1-2 Model Name
- 1-3 Serial Number
- 1-4 Apply After-sales Service by Mobile Device
- 1-5 RFI Switch
- 1-6 Dimensions

After you receive the AC motor drive, check the following:

- 1. Inspect the unit after unpacking to ensure that it was not damaged during shipment. Make sure that the part number printed on the package corresponds with the part number indicated on the nameplate.
- 2. Make sure that the voltage for the wiring is in the range indicated on the nameplate. Install the AC motor drive according to this manual.
- 3. Before applying the power, make sure that all the devices, including power, motor, control board and digital keypad are connected correctly.
- 4. When wiring the AC motor drive, make sure that the wiring for input terminals "R/L1, S/L2, T/L3" and output terminals "U/T1, V/T2, W/T3" is correct to prevent drive damage.
- 5. When power is applied, select the language and set parameter groups with the digital operation panel (KPED-LE01). When executing a trial run, begin with a low speed and then gradually increase the speed until reaching the desired speed.

1-1 Nameplate Information

This example uses the 15HP/11kW 230V, three-phase motor drive.




Figure 1-1

1-2 Model Name




Figure 1-2

1-3 Serial Number




Figure 1-3

1-4 Apply After-sales Service by Mobile Device

1-4-1 Location of Service Link Label

Frame B

Figure 1-4 below shows the service link label (service label) that is located on the side of the case.



Figure 1-4

Frame C

Remove the front cover of the case to find the service link label (service label) located on the upper left corner as shown in Figure 1-5 below.




Figure 1-5

Frame D

Remove the front cover of the case to find the service link label (service label) located on the upper left corner as shown in Figure 1-6 below.




Figure 1-6

Frame E

Remove the front cover of the case to find the service link label (service label) located on the upper left corner as shown in Figure 1-7 below.




Figure 1-7

1-4-2 Service Link Label




Figure 1-8

Scan QR Code to request service

- 1. Find the QR code sticker (as Figure 1-8 shows above).
- 2. Run the QR code reader App on your smartphone.
- 3. Point your camera at the QR Code. Hold your camera steady until the QR code comes into focus.
- 4. Access the Delta After-sales Service website.
- 5. Fill in the information in the columns marked with an orange star.
- 6. Enter the CAPTCHA and click Submit to complete the request.

Cannot find the QR Code?

- 1. Open a web browser on your computer or smartphone.
- 2. Enter https://service.deltaww.com/us/Repair/Request?type=IA in the browser address bar and press the Enter key.
- 3. Fill in the information in the columns marked with an orange star.
- 4. Enter the CAPTCHA and click Submit to complete the request.

1-5 RFI Switch

The AC motor drive may emit electrical noise. You can use the RFI (Radio Frequency Interference) switch to suppress interference on the power line. The RFI switches on Frames B, C, D, E are at similar locations. Open the drive's top cover to remove the RFI switch as shown in Figure 1-9 below.

Frame E




Figure 1-9

NOTE: The RFI switches on Frame s B/C/D/E are at similar locations.


Chapter 1 Introduction | VFD-ED

Isolating main power from ground

When the power distribution system for the motor drive is a floating ground system (IT Systems) or an asymmetric ground system (Corner Grounded TN Systems), you must remove the RFI switch. Removing the switch also cuts off the internal RFI capacitor (filter capacitor) between the system's frame and the central circuits to avoid damaging the central circuits and reduces the ground leakage current.

Important points regarding ground connection

- ☑ To ensure the safety of personnel, ensure proper operation, and reduce electromagnetic radiation, you must properly ground the motor and drive during installation.
- ☑ The diameter of the grounding cables must meet the size specified by safety regulations.
- ☑ You must connect the shielded cable to the motor drive's ground to meet safety regulations.
- ☑ Only use the shielded cable as the ground for equipment when the above points are met.
- ☑ When installing multiple sets of motor drives, do not connect the motor drives' grounds in series. See the following image.



Pay particular attention to the following points

- ☑ Do not remove the RFI switch while the power is ON.
- ☑ Make sure the main power is OFF before removing the RFI switch.
- ☑ Removing the RFI switch also cuts the capacitor conductivity. Gap discharge may occur once the transient voltage exceeds 1000 V.

NOTE: If you remove the RFI switch, you remove the reliable electrical isolation. In other words, all controlled inputs and outputs become low-voltage terminals with basic electrical isolation. Also, when you remove the internal RFI switch, the motor drive is no longer electromagnetic compatible (EMC).

- ☑ Do not remove the RFI switch if the main power is a grounded power system.
- ☑ You must remove the RFI switch when conducting high voltage tests. When conducting a high voltage test for the entire facility, disconnect the main power and the motor if the leakage current is too high.

Floating Ground System (IT Systems)

A floating ground system is also called an IT system, ungrounded system, or high impedance/resistance (greater than 30 Ω) grounding system.

- ☑ Disconnect the ground cable from the internal EMC filter.
- ☑ In situations where EMC is required, check for excess electromagnetic radiation affecting nearby low-voltage circuits. In some situations, the adapter and cable naturally provide enough suppression. If in doubt, install an extra electrostatic shielded cable on the power supply side between the main circuit and the control terminals to increase shielding.
- ☑ Do not install an external RFI/EMC filter. The external EMC filter passes through a filter capacitor and connects power input to the ground. This is very dangerous and damages the motor drive.

Asymmetric Ground System (Corner Grounded TN Systems)

Caution: Do not remove the RFI switch while power to the motor drive input terminal is ON. In the following four situations, you must remove the RFI switch. This is to prevent the system from grounding through the RFI capacitor and damaging the motor drive.

Conditions for removing the RFI switch

1. Grounding at a corner in a triangle configuration |2. Grounding at a midpoint in a polygonal




Figure 1-12

Grounding at a midpoint in a polygonal configuration




Figure 1-13

Grounding at one end in a single-phase configuration




Figure 1-14

4. No stable neutral grounding in a three-phase autotransformer configuration





Figure 1-15

Using the RFI switch

In the situation as the diagram on the right shows, you can use the RFI switch to pass through RFI capacitor to make an internal grounding and reduce electromagnetic radiation. In a situation with higher requirements for electromagnetic compatibility and a symmetrical grounding power system, you can install an EMC filter. For example, Figure 1-16 on the right is a symmetrical grounding power system.



1-6 Dimensions

Frame B
VFD022ED21S, VFD037ED21S, VFD040ED23S/43S




Figure 1-17

										Unit: m	m (inch)
Frame	W	W1	Н	H1	H2	D	D1*	S1	А	В	С
В	193.5 (7.60)	162.5 (6.39)	260.0 (10.22)	247.0 (9.71)	230.0 (9.04)	133.5 (5.25)	58.0 (2.28)	6.5 (0.26)	138.6 (5.46)	67.2 (2.66)	17.6 (0.69)

^{*}D1: This dimension is for flange mounting application reference.

Frame C VFD055ED23S/43S, VFD075ED23S/43S, VFD110ED23S/43S, VFD150ED43S, VFD185ED43S




Figure 1-18

Unit: mm (inch)

													/
Frame	W	W1	W2	Н	H1	H2	D	D1*	S1	S2	S3	Ø1	Ø2
С	235.0 (9.25)	204.0 (8.03)	176.0 (6.93)	350.0 (13.78)	337.0 (13.27)	320.0 (15.60)	146.0 (5.75)	70.0 (2.76)	6.5 (0.26)	9.0 (0.35)	7.0 (0.28)	19.7 (0.78)	28.3 (1.11)

NOTE: A1–A4 and B1–B4 can be used for screwdriver installation; B1–B4 can also be used for sleeve installation *D1: This dimension is for flange mounting application reference.

Frame D

VFD150ED23S, VFD185ED23S, VFD220ED23S/43S, VFD300ED43S




Figure 1-19

Unit: mm (inch)

Frame	W	W1	Н	H1	H2	D	D1*	S1	Ø1	Ø2	ø3
D	255.0	226.0	403.8	384.0	360.0	178.0	94.0	8.5	17.5	32.0	26.0
	(10.04)	(8.90)	(15.90)	(15.12)	(14.17)	(7.01)	(3.70)	(0.33)	(0.69)	(1.26)	(1.02)

^{*}D1: This dimension is for flange mounting application reference.

Frame E VFD300ED23S, VFD370ED23S/43S, VFD450ED43S, VFD550ED43S, VFD750ED43S




Figure 1-20

									Unit: m	ım (inch)
Frame	W	W1	Н	H1	H2	D	D1*	D2	S1	S2
Е			550.0 (21.65)						11.0 (0.43)	18.0 (0.71)

^{*}D1: This dimension is for flange mounting application reference.

Built-In Keyboard Panel

KPED-LE01 Unit: mm [inch]




Figure 1-21

Chapter 2 Installation

- 2-1 Mounting Clearance
- 2-2 Airflow and Power Dissipation

2-1 Mounting Clearance

- ☑ Prevent fiber particles, scraps of paper, shredded wood, sawdust, metal particles, etc. from adhering to the heat sink.
- ☑ Install the AC motor drive in a metal cabinet to prevent the risk of fire.
- ☑ Install the AC motor drive in a Pollution Degree 2 (IEC 60664-1) environment with clean and circulating air. A clean and circulating environment means air without polluting substances and dust.

The motor drives' figures shown below are for reference only. The actual motor drives may look different.




Figure 2-1

Minimum Mounting Clearance

	meaning elea			
Frame	Capacity	Model No.	W (Width) mm (inch)	H (Height) mm (inch)
В	3.0-5.0 HP (2.2-4 kW)	VFD022ED21S, VFD037ED21S, VFD040ED23S/43S	50 (2)	150 (6)
С	7.5–15 HP (5.5–11 kW)	VFD055ED23S/43S, VFD075ED23S/43S, VFD110ED23S/43S, VFD150ED43S, VFD185ED43S	75 (3)	175 (7)
D	20–40 HP (15–30 kW)	VFD150ED23S, VFD185ED23S, VFD220ED23S/43S, VFD300ED43S	75 (3)	200 (8)
E	40–100 HP (30–75 kW)	VFD300ED23S, VFD370ED23S/43S, VFD450ED43S, VFD550ED43S, VFD750ED43S	75 (3)	200 (8)

NOTE: The minimum mounting clearances stated in Table 2-1 apply to AC motor drives frame B, C, D and E. Failure to follow the minimum mounting clearances may cause the motor drive fan to malfunction and cause heat dissipation problems.

Table 2-1

2-2 Airflow and Power Dissipation

	Airflow Rate for Cooling							ssipation fo	or
Model No.	Flov	v Rate (cfm	Flow	Rate (m³/h	r)	Power Dissipation (W)			
	External	Internal	Total	External	Internal	Total	Loss External (Heat Sink)	Internal	Total
VFD022ED21S	13.7	-	13.7	23.3	-	23.3	60	36	96
VFD037ED21S	23.9	-	23.9	40.7	-	40.7	84	46	130
VFD040ED23S	23.9	-	23.9	40.7	-	40.7	133	49	182
VFD055ED23S	48.5	-	48.5	82.4	-	82.4	212	67	279
VFD075ED23S	48.5	-	48.5	82.4	-	82.4	292	86	379
VFD110ED23S	47.9	-	47.9	81.4	-	81.4	355	121	476
VFD150ED23S	64.6	-	64.6	109.8	-	109.8	490	161	651
VFD185ED23S	102.3	-	102.3	173.8	-	173.8	638	184	822
VFD220ED23S	102.8	-	102.8	174.7	-	174.7	723	217	939
VFD300ED23S	179	30	209	304	51	355	932	186	1118
VFD370ED23S	179	30	209	304	51	355	1112	222	1334
VFD040ED43S	13.7	-	13.7	23.3	-	23.3	123	42	165
VFD055ED43S	48.5	-	48.5	82.4	-	82.4	185	55	240
VFD075ED43S	48.5	-	48.5	82.4	-	82.4	249	71	320
VFD110ED43S	47.9	-	47.9	81.4	-	81.4	337	94	431
VFD150ED43S	46.1	-	46.1	78.4	-	78.4	302	123	425
VFD185ED43S	46.1	-	46.1	78.4	-	78.4	391	139	529
VFD220ED43S	102.8	-	102.8	174.7	-	174.7	642	141	783
VFD300ED43S	83.7	-	83.7	142.2	-	142.2	839	180	1019
VFD370ED43S	179	30	209	304	51	355	803	252	1055
VFD450ED43S	179	30	209	304	51	355	1014	270	1284
VFD550ED43S	179	30	209	304	51	355	1244	275	1519
VFD750ED43S	186	30	216	316	51	367	1541	338	1878
	single d When in should be	 The required airflow shown in Table 2-2 is for installing a single drive in a confined space. When installing multiple drives, the required air volume should be the required air volume for a single drive X the number of the drives. The heat dissipation shown in Table 2-2 is for installing a sing drive in a confined space. When installing multiple drives, volume of heat dissipation should be the heat dissipated for a single drive X the number of the drives. Heat dissipation for each mode is calculated by rated voltage, current and default carrier. 							a single drives, on pated for oer of model tage,

Table 2-2

[This page intentionally left blank]

Chapter 3 Wiring

- 3-1 System Wiring Diagram
- 3-2 Wiring

Chapter 3 Wiring | VFD-ED

After removing the front cover, verify if the power and control terminals are clearly noted. Read the following precautions to avoid wiring mistakes.



- ✓ Turn off the AC motor drive power before installing any wiring. A hazardous charge may still remain in the DC bus capacitors after the power has been turned off. Measure the remaining voltage before wiring. For your safety, do not perform any wiring before the voltage drops to a safe level < 25 V_{DC}. Performing a wiring installation while voltage remains may cause sparks and short circuits.
- ☑ Only qualified personnel familiar with AC motor drives are allowed to perform installation, wiring and commissioning. Make sure the power is turned off before wiring to prevent electric shock.
- ☑ Make sure that power is only applied to the R/L1, S/L2, and T/L3 terminals. Failure to comply may result in damage to the equipment. The voltage and current should be within the range indicated on the AC motor drive nameplate (see Section 1-1 Nameplate Information).
- ☑ All the units must be grounded directly to a common ground terminal to prevent damage from a lightning strike or electric shock.
- ☑ Make sure you correctly tighten the main circuit terminal screws to prevent sparks from screws that have been loosened due to vibration.



- ☑ When wiring, choose wires that comply with local regulations for your safety.
- ☑ Check the following items after finishing the wiring:
 - 1. Are all connections correct?
 - 2. Are there any loose wires?
 - 3. Are there any short circuits between the terminals or to ground?

3-1 System Wiring Diagram




Figure 3-1

NOTE: For details, see the wiring diagrams in Section 3-2.

Supply power according to the rated power specifications indicated in the user manual (see Chapter 8 Specifications).
There may be a large inrush current during power-on. See Section 6-2 NFB to select a suitable NFB or Section 6-3 Fuse Specification Chart for a fuse.
Switching the power ON/OFF on the primary side of the magnetic contactor can turn the drive ON/OFF, but frequent switching can cause machine failure. Do not switch ON/OFF more than once an hour. Do not use the magnetic contactor as the power switch for the drive; doing so shortens the life of the drive.
When the main power supply capacity is greater than 1000 kVA, or when it switches into the phase capacitor, the instantaneous peak voltage and current generated may destroy the internal circuit of the drive. It is recommended that you install an AC reactor at input side in the drive. This also improves the power factor and reduces power harmonics. The wiring distance should be within 10 m. See Section 6-4 AC/DC Reactor for details.
Used to reduce radiated interference, especially in environments with audio devices, and reduce input and output side interference. The effective range is AM band to 10 MHz. See Section 6-5 Zero Phase Reactor for details.
Can be used to reduce electromagnetic interference. See Section 6-6 EMC Filter for details.
Used to shorten the deceleration time of the motor. See Section 6-1 Brake Resistors and Brake Units Used in AC Motor Drives for details.
The motor cable length affects the size of the reflected wave on the motor end. It is recommended that you install an AC output reactor when the motor wiring length exceeds 20 meters. See Section 6-4 AC/DC Reactor for details.

Table 2-1

3-2 Wiring

3-2-1 Wiring Diagram

Frame B Wiring Diagram




Figure 3-2




Figure 3-3




Figure 3-4

NOTE:

- 1. *1: See Section 6-1 Brake Resistors & Brake Units Used in AC Motor Drives for details
- 2. For details on EPS wiring, see Section 3-2-3 Emergency Power Supply (EPS) System Wiring Diagrams.





Figure 3-5

3-2-2 Switch between Two Modes: SINK (NPN) / SOURCE (PNP)



3-2-3 Emergency Power Supply (EPS) system wiring diagrams Frames B, C, D & E

1. Single-phase UPS or battery can only be used on the main power supply side




Figure 3-10

Frames C & D

2. When the voltage of the main power supply is lower than 140 V_{DC} (230V models) / 280 V_{DC} (460V models), connect the control power to single-phase UPS or battery.




Figure 3-11




Figure 3-12

NOTE:

When EPS is enabled (MI=43):

- Do NOT make the fan run in case voltage drops during EPS.
- Parameter settings cannot be saved and will be lost after cycling power.
- Set the running speed through Pr.06-44.
- Functions of low voltage and phase loss protection are unavailable.
- Set the DC bus voltage through Pr.06-29.

[This page intentionally left blank]

Chapter 4 Main Circuit Terminals

- 4-1 Main Circuit Diagram
- 4-2 Main Circuit Terminal Specifications



- ☑ Tighten the screws in the main circuit terminal to prevent sparks caused by screws loosened due to vibration.
- ☑ Ensure proper insulation of the main circuit wiring in accordance with the relevant safety regulations.



Main input power terminals

- ☑ Do not connect a three-phase model to single-phase power. R/L1, S/L2 and T/L3 have no phase-sequence requirement and can be connected in any sequence.
- ☑ You must install a NFB between the three-phase power input terminals and the main circuit terminals (R/L1, S/L2, T/L3). Add a magnetic contactor (MC) to the power input wiring to cut off power quickly and reduce malfunctions when the AC motor drive protection function activates. Both ends of the MC should have an R-C surge absorber.
- ☑ Use voltage and current within the specifications in Chapter 8.
- ☑ When using a general ELB (Earth Leakage Breaker), select a current sensor with sensitivity of 200 mA or above and not less than 0.1 second operation time to avoid nuisance tripping. When choosing an ELB designed for the AC motor drive, choose a current sensor with sensitivity of 30 mA or above.
- ☑ Use shielded wire or conduit for the power wiring and ground the two ends of the shielding or conduit.
- ☑ Do NOT run and stop the AC motor drives by turning the power ON and OFF. Run and stop the AC motor drives by sending the RUN and STOP commands through the control terminals or the keypad. If you still need to run and stop the AC motor drives by turning the power ON and OFF, do so no more often than ONCE per hour.

Output terminals of the main circuit

- ☑ When it is necessary to install a filter at the output side of the AC motor drive terminals U/T1, V/T2, W/T3, use an inductance filter. Do not use phase-compensation capacitors or L-C (Inductance-Capacitance) or R-C (Resistance-Capacitance) capacitors.
- ☑ DO NOT connect phase-compensation capacitors or surge absorbers at the output terminals of AC motor drives.
- ☑ Use well-insulated motors to prevent any electric leakage from the motors.

Use terminals [+1, +2] for connecting a DC reactor. Use terminals [+1, +2/B1] for connecting a DC bus.

☑ Use these terminals to connect a DC reactor to improve the power factor and reduce harmonics. A jumper is connected to these terminals at the factory. Remove that jumper before connecting to a DC reactor.




Figure 4-1

- ☑ Models above 22 kW do not have a built-in brake resistor. To improve resistance braking, connect an optional external brake resistor.
- ☑ When not in use, leave terminals +2/B1, [] open.
- ☑ Short-circuiting [B2] or [] to [+2/B1] damages the motor drive. Do NOT short-circuit those terminals.

4-1 Main Circuit Diagram

Frame B




Figure 4-2

Frames C & D




Figure 4-3

Frame E




Figure 4-4

Chapter 4 Main Circuit Terminals | VFD-ED

Terminals	Descriptions
	Backup power/ Emergency power connection terminal.
EPS (+, -)	NOTE: EPS (Emergency Power Supply) input terminal supports only Frame
	C and Frame D.
R/L1, S/L2, T/L3	AC line input terminals (three-phase)
U/T1, V/T2, W/T3	AC motor drive output terminals for connecting a three-phase induction motor.
+1, +2/B1	Connections for DC reactor to improve the power factor. Remove the jumper
11, 12/01	before installing a DC reactor (Frame E has a built-in DC reactor).
+2/B1, B2	Connections for brake resistor (optional).
	Ground connection; comply with local regulations.

Table 4-1

4-2 Main Circuit Terminal Specifications

Frame B




Figure 4-5

Model	R/L1, S/L	nin Circuit Ter 2, T/L3, U/T1 OC+), -(DC-),	, V/T2, W/T3,	Terminal =		
	Min. Wire Gauge	Max. Wire Gauge	Screw Size & Tightening Torque (±10%)	Min. Wire Gauge	Max. Wire Gauge	Screw Size & Tightening Torque (±10%)
VFD022ED21S	2.1 mm ²		M4	2.1 mm ²		M4
VFD040ED43S	(14 AWG)	5.3 mm ²	18 kg-cm	(14 AWG)	5.3 mm²	18 kg-cm
VFD037ED21S	3.3 mm ²	(40.4)4(0)		3.3 mm ²	(10 AWG)	(15.6 lb-in.)
VFD040ED23S	(12 AWG)		(1.7 N-m)	(12 AWG)	,	(1.7 N-m)

Table 4-2

- For UL installation compliance, select copper wires with voltage rating of 600V and temperature resistance of 75°C.
- Choose terminal wire size as Figure 4-6 shows.
- Use insulated heat shrink tubing that is resistant to at least 600V to comply with UL and CSA regulations (600 V, YDPU2), as Figure 4-7 shows.
- If you install at Ta 50°C environment, use copper wires with voltage rating of 600V and temperature resistance of 75°C or 90°C.
- If you install at Ta 50°C above environment, use copper wires with voltage rating of 600V and temperature resistance of 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using high-temperature resistant wire.




Figure 4-6




Figure 4-7

Frame C





Figure 4-8

Model	R/L1, S/L	ain Circuit Terr .2, T/L3, U/T1, +1, +2/B1, -,	V/T2, W/T3,		Terminal =	
modo.	l Min Wire I Max Wire I		Screw Size & Tightening Torque (±10%)	Min. Wire Max. Wire Gauge Gauge		Screw Size & Tightening Torque (±10%)
VFD055ED23S VFD110ED43S	3.3 mm² (10 AWG)			3.3 mm² (10 AWG)		
VFD055ED43S	3.3 mm ²	,	M5	3.3 mm ²		
VFD075ED43S	(12 AWG)	13.3 mm²		(12 AWG)	13.3 mm² (6 AWG)	M5 30 kg-cm (26 lb-in.)
VFD075ED23S	0.4 mm²	(6 AWG)	30 kg-cm (26 lb-in.)	8.4 mm²		
VFD150ED43S	8.4 mm² (8 AWG)	(67.11.6)	(2.9 N-m)	(8 AWG)	(67,1176)	(2.9 N-m)
VFD185ED43S	(07,000)		, ,	(07,000)		(=.5)
VFD110ED23S	13.3 mm² (6 AWG)			13.3 mm² (6 AWG)		

Table 4-3

- For UL installation compliance, select copper wires with voltage rating of 600V and temperature resistance of 75°C.
- Choose terminal wire size as Figure 4-9 shows.
- Use insulated heat shrink tubing that is resistant to at least 600V to comply with UL and CSA regulations (600 V, YDPU2), as Figure 4-10 shows.
- If you install at Ta 50°C environment, use copper wires with voltage rating of 600V and temperature resistance of 75°C or 90°C.
- If you install at Ta 50°C above environment, use copper wires with voltage rating of 600V and temperature resistance of 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using high-temperature resistant wire.








Figure 4-10

Frame D




Figure 4-11

Model	R/L1, S/L	ain Circuit Termi .2, T/L3, U/T1, \ +1, +2/B1, -, E	//T2, W/T3,	Terminal 🖶			
Wiodei	Min. Wire Gauge			Min. Wire Gauge	Max. Wire Gauge Screw Size & Tightening Torque (±10%)		
VFD150ED23S	21.1 mm ²			16 mm²			
VFD300ED43S	(4 AWG)			(6 AWG)			
VFD185ED23S	26.7 mm² (3 AWG)	33.6 mm²	M6 50 kg-cm	16 mm² (6 AWG)	33.6 mm²	M6 50 kg-cm	
VFD220ED43S	13.3 mm² (6 AWG)	(2 AWG)	(43.4 lb-in.) (4.9 N-m)	13.3 mm² (6 AWG)	(2 AWG)	(43.4 lb-in.) (4.9 N-m)	
VFD220ED23S	33.6 mm² (2 AWG)			16 mm² (6 AWG)			

Table 4-4

- For UL installation compliance, select copper wires with voltage rating of 600V and temperature resistance of 75°C.
- Choose terminal wire size as Figure 4-12 shows.
- Use insulated heat shrink tubing that is resistant to at least 600V to comply with UL and CSA regulations (600 V, YDPU2), as Figure 4-13 shows.
- If you install at Ta 50°C environment, use copper wires with voltage rating of 600V and temperature resistance of 75°C or 90°C.
- If you install at Ta 50°C above environment, use copper wires with voltage rating of 600V and temperature resistance of 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using high-temperature resistant wire.




Figure 4-12




Figure 4-13

Frame E




Figure 4-14

Model	R/L1, S/L2	in Circuit Term 2, T/L3, U/T1, ' -1(DC+), -(D0	V/T2, W/T3,	Terminal 🖶		
Wiodei	Min. Wire Gauge	Max. Wire Gauge	Screw Size & Tightening Torque (±10%)	Min. Wire Gauge	Max. Wire Gauge	Screw Size & Tightening Torque (±10%)
VFD370ED43S	53.5 mm² (1/0 AWG)			33.6 mm² (2 AWG)		
VFD450ED43S	67.4 mm² (2/0 AWG)	4502	M8	53.5 mm² (1/0 AWG)	4502	M8
VFD300ED23S	107 mm²	152 mm ² (300 MCM)	200 kg-cm (173 lb-in.)	53.5 mm ²	152 mm ² (300 MCM)	200 kg-cm (173 lb-in.)
VFD550ED43S	(4/0 AWG)	(see mem)	(19.6 N-m)	(1/0 AWG)	(SSS MOM)	(17.6 N-m)
VFD370ED23S	152 mm²			85.0 mm ²		
VFD750ED43S	(300 MCM)			(3/0 AWG)		

Table 4-5

- For UL installation compliance, select copper wires with voltage rating of 600V and temperature resistance of 75°C.
- Choose terminal wire size as Figure 4-15 shows.
- Use insulated heat shrink tubing that is resistant to at least 600V to comply with UL and CSA regulations (600 V, YDPU2), as Figure 4-16 shows.
- If you install at Ta 50°C environment, use copper wires with voltage rating of 600V and temperature resistance of 75°C or 90°C.
- If you install at Ta 50°C above environment, use copper wires with voltage rating of 600V and temperature resistance of 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using high-temperature resistant wire.




Figure 4-15




Figure 4-16

Chapter 5 Control Terminals


- 5-1 Remove the Cover before Wiring
- 5-2 Control Terminal Specifications
- 5-3 Control Circuit Terminals

5-1 Remove the Cover before Wiring

Remove the top cover before wiring the multi-function input and output terminals

NOTE: The motor drives' figures shown below are for reference only. The actual motor drives may look different.

Frame B, C and D



Step 2: Remove the top cover




Figure 5-2

Step 3: Attach the top cover, and then tighten the four screws using torque force 15 kgf-cm.




Figure 5-3




Figure 5-6

5-2 Control Terminal Specifications




Figure 5-7

Terminal Socket	Wire Gauge	Torque Force (±10 %)				
Α						
В	0.2–2.5 mm² (28–14 AWG)	2 kg-cm / (1.7 lb-in.) / (0.20 Nm)				
С						
D	-	2 kg-cm / (1.7 lb-in.) / (0.20 Nm)				
E	0.2–4.0 mm² (28–12 AWG)	5.2 kg-cm / (4.5 lb-in.) / (0.51 Nm)				

NOTE: To comply with UL standards, use copper wires in the installation that are able to withstand 600V, 75°C environments.

Table 5-1

5-3 Control Circuit Terminals

Terminals	Terminal Function	Default (NPN mode)			
+24 V /	Digital control signal common	124V 1 5% 200 m			
E24 V	terminal (Source)	+24V ± 5% 200 mA			
СОМ	Digital control signal common terminal (Sink)	Common terminal for multi-function input terminals			
		FWD-DCM:			
FWD	Forward-Stop command	ON = run in forward			
		OFF = decelerate to stop			
		REV-DCM:			
REV	Reverse-Stop command	ON = run in reverse			
		OFF = decelerate to stop			
		Refer to parameters Pr.02-01–Pr.02-08 to program			
		the multi-function inputs MI1–MI8.			
		Source mode:			
MI1		Rated load: 24 V _{DC} / 9.6 mA			
	Multi-function input 1–8	Source Mode (PNP)			
MI8	ividiti-fullotion input 1—0	N.O. (ON, 1): ≥ 17 V _{DC}			
IVIIO		N.C. (OFF, 0): ≤ 5 V _{DC}			
		Sink Mode (NPN)			
		N.O. (ON, 1): ≤ 7 V _{DC}			
		N.C. (OFF, 0): ≥ 19 V _{DC}			
DCM	Digital frequency signal common terminal				
SCM1	The default is short-circuited (E24V/	(STO1/STO2)			
SCM2	The default is short-circuited (SCM1	·			
STO1	Power cutoff safety function for EN9	•			
STO2	When STO1–SCM1 and STO2–SCM	M2 are ON, the activation current is 3.3 mA \geq 11 V _{DC} .			
+10 V	Potentiometer power supply	Power supply for analog frequency setting: +10 V_{DC} 20 mA			
-10 V	Potentiometer power supply	Power supply for analog frequency setting: -10 V_{DC} 20 mA			
	Analog voltage frequency				
AUI1	command				
	+10V	Impedance: 20 kΩ			
	AUI (-10V~+10V)	Range: -10–10 V _{DC} = 0–Maximum Output			
AUI2	ACM	Frequency (Pr.01-00)			
	-10V Internal circuit				

Chapter 5 Control Terminals | VFD-ED

Terminals	Terminal Function	Default (NPN mode)
ACM	Analog signal common terminal control	Analog signal common terminal
RA	Multi-function relay output A (N.O.)	
RB	Multi-function relay output A (N.C.)	
RC	Multi-function relay output B	User-defined function
110	(Default: error indication)	Resistive Load
MRA	Multi-function output terminal (N.O.)	3 A (N.O.) / 3 A (N.C.) 250 V _{AC}
MRB	Multi-function output terminal (N.C.)	5 A (N.O.) / 3 A (N.C.) 30 V _{DC}
MRC	Multi-function output terminal	(minimum 5 V _{DC} , 10 mA)
IVIIXO	(Default: operating indication)	(Hilliman 3 VDC, 10 HIA)
R1A	Multi-function output terminal A (N.O.)	To output different kinds of monitoring signals
	Multi-function output terminal A	such as motor drive in operation, frequency
R2A	(N.O.)	reached, and overload indication.
	Multi-function output terminal	
R12C	(Default: no function)	
SG1+	Modbus RS-485	
SG1-	Modbus RS-485	SG1+ switch: terminator 120 ohm (default) / open
		CAN Default setting 120 120 Default setting 120
CAN_L	CAN Bus	DID quitable tampinatay 120 about (dafacilt) / an an
CAN_H	CAN Bus	DIP switch: terminator 120 ohm (default) / open
MO1	Multi-function output terminal 1 (photo coupler)	The AC motor drive outputs various monitoring signals, such as drive in operation,
MO2	Multi-function output terminal 2 (photo coupler)	frequency reached, and overload indication through a transistor (open collector).
МСМ	Multi-function output common terminal (photo coupler)	Maximum 48V _{DC} 50mA
AFM1		0-10 V, max. output current: 2 mA, max. load: 5 k Ω -10–10 V, max. output current: 2 mA, max. load: 5 k Ω

Terminals	Terminal Function	Default (NPN mode)				
AFM2	AFM1 ACM AFM2 B C	Maximum output current: 2 mA Resolution: 0–10 V, corresponds to the maximum operating frequency. Range: 0–10 V→ -10–10 V				
RJ45	PINS 1, 2, 6, 7: Reserved PIN 3: SGND PIN 4: SG- PIN 5: SG+ PIN 8: EV					
SW2	Switching USB port	DIP switch: NRM (default) / PRG (use this side of the switch to update firmware). Updating firmware should be done by qualified motor drive service personnel only. Do NOT try to update the firmware by yourself.				

NOTE: NRM = Normal Table 5-2

[This page intentionally left blank]

Chapter 6 Optional Accessories

- 6-1 Brake Resistors and Brake Units Used in AC Motor Drives
- 6-2 Non-fuse Circuit Breaker
- 6-3 Fuse Specification Chart
- 6-4 AC / DC Reactor
- 6-5 Zero Phase Reactor
- 6-6 EMC Filter
- 6-7 Digital Keypad
- 6-8 USB / RS-485 Communication Interface IFD6530

Chapter 6 Optional Accessories | VFD-ED

The optional accessories listed in this chapter are available upon request. Installing additional accessories to your drive can substantially improve the drive's performance. Select accessories according to your needs or contact your local distributor for suggestions.

6-1 Brake Resistors and Brake Units Used in AC Motor Drives

Recommended Model Selection

a)	Dalkala		IM 10% ED*1			PM 30% ED*2	
Voltage	Delta's Motor Drive Model	Min. Resistor Value*³ (Ω)	Suggested Resistor Value* ⁴ (Ω)	Suggested Braking Power (kW)	Min. Resistor Value (Ω)	Suggested Resistor Value (Ω)	Suggested Braking Power (kW)
	VFD022ED21S	38.0	70.0	0.3	38.0	50.0	1.0
	VFD037ED21S	19.0	30.0	0.5	19.0	32.0	1.5
	VFD040ED23S	19.0	30.0	0.5	19.0	32.0	1.5
	VFD055ED23S	15.6	20.0	1.0	15.6	25.0	2.0
	VFD075ED23S	11.5	20.0	1.0	11.5	16.7	3.0
230V	VFD110ED23S	9.5	13.0	1.5	9.5	12.5	4.0
	VFD150ED23S	8.3	10.0	2.0	8.3	10.0	5.0
	VFD185ED23S	5.8	8.0	2.0	5.8	7.8	7.5
	VFD220ED23S	5.8	6.6	3.0	5.8	6.5	9.0
	VFD300ED23S	4.8	5.1	4.0	4.8	5.0	10.0
	VFD370ED23S	3.2	3.9	4.8	3.2	3.6	14.0
	VFD040ED43S	54.3	100.0	0.5	54.3	100.0	2.0
	VFD055ED43S	48.4	75.0	1.0	48.4	100.0	2.0
	VFD075ED43S	39.4	75.0	1.0	39.4	60.0	3.0
	VFD110ED43S	30.8	43.0	1.5	30.8	50.0	4.0
	VFD150ED43S	25.0	32.0	2.0	25	39.0	6.0
460V	VFD185ED43S	20.8	32.0	2.0	20.8	26.0	7.2
4000	VFD220ED43S	19.0	26.0	3.0	19.0	26.0	9.0
	VFD300ED43S	14.1	20.0	4.0	14.1	19.5	12.0
	VFD370ED43S	12.7	14.3	4.5	13.8	15.6	15.0
	VFD450ED43S	12.7	13.0	6.0	10.3	13.0	18.0
	VFD550ED43S	9.5	10.2	8.0	6.9	9.8	19.2
	VFD750ED43S	6.3	7.2	9.0	6.4	7.1	26.4

Table 6-1

^{*1} The brake resistor should be able to endure 10 times the overload capacity.

^{*2} The brake resistor should be able to endure 3.3 times the overload capacity.

^{*3} If you choose other brake resistors instead of Deltas, calculate the maximum power and average power of the selected braking power to ensure that they meet the requirements. Maximum power: Vb²/R; average power: Vb²/R x ED%. (Vb stands for braking voltage; R stands for brake resistor value.)

^{*4} The calculation of the brake resistor value and braking power is based on Delta's brake resistor.

IM Elevator System (Using Delta's Brake Resistor)

е	Ар	plicable Delta's Motor Drive		1	25% B	raking Torque/10	0% ED	*1		Max	k. Braking Tor	que
Voltage			Braking	Brake Unit		Delta's Bra	ake Re	sistor*3	Braking	Min.	Max. Total	Peak
>	HP	Model	Torque*2 (kg-m)	VFDB	#	Part No.	#	Configurat ion	Current (A)*4	Resistor Value (Ω)	Braking Current (A)	Power (kW)
	3	VFD022ED21S	1.5			BR300W070	1		5.4	38.0	10.0	3.8
	5	VFD037ED21S	2.5			BR500W030	1		12.7	19.0	20.0	7.6
	5	VFD040ED23S	2.5			BR500W030	1		12.7	19.0	20.0	7.6
	7.5	VFD055ED23S	3.7			BR1K0W020	1		19.0	15.6	24.4	9.3
	10	VFD075ED23S	5.1			BR1K0W020	1		19.0	11.5	33.0	12.5
	15	VFD110ED23S	7.5			BR1K5W013	1		29.2	9.5	40.0	15.2
230V	20	VFD150ED23S	10.2			BR1K0W020	2	2 parallel	38.0	8.3	46.0	17.5
	25	VFD185ED23S	12.2			BR1K0W016	2	2 parallel	47.5	5.8	66.0	25.1
	30	VFD220ED23S	14.9			BR1K5W3P3	2	2 in series	57.6	5.8	66.0	25.1
	40	VFD300ED23S	20.3	2015	0	DD4K0W5D4	4	2 in series	74.5	4.8	80.0	30.4
	40	VFD300ED233	20.3	2015	2	BR1K0W5P1	4	2 parallel	74.5	4.0	80.0	30.4
	50	VFD370ED23S	25.1	2022	2	BR1K2W3P9	4	2 in series	97.4	3.2	120.0	45.6
	30	VFD370ED233	25.1	2022	2	BIX INZWSF 9	4	2 parallel	91.4	3.2	120.0	43.0
	5	VFD040ED43S	2.7			BR500W100	1		7.6	54.3	14.0	10.6
	7.5	VFD055ED43S	3.7			BR1K0W075	1		10.1	48.4	15.7	11.9
	10	VFD075ED43S	5.1			BR1K0W075	1		10.1	39.4	19.3	14.7
	15	VFD110ED43S	7.5			BR1K5W043	1		17.7	30.8	24.7	18.8
	20	VFD150ED43S	10.1			BR1K0W016	2	2 in series	23.8	25.0	30.4	23.1
	25	VFD185ED43S	12.5			BR1K0W016	2	2 in series	23.8	20.8	36.5	27.7
	30	VFD220ED43S	14.9			BR1K5W013	2	2 in series	29.2	19.0	40.0	30.4
460V	40	VED200ED429	20.3			PB1K0W020	4	2 in series	20 N	14.1	F4.0	41.0
	40	VFD300ED43S	20.3			BR1K0W020	4	2 parallel	38.0	14.1	54.0	41.0
	50	VFD370ED43S	25.0	4045	1	BR1K5W043	3	3 parallel	53.0	12.7	60.0	45.6
	60	VFD450ED43S	30.4	4045	1	BR1K5W013	4	2 in series	58.5	12.7	60.0	45.6
	00	VI D400LD400	50.4	4040	'	BRINOWOTO	7	2 parallel	30.3	12.7	00.0	40.0
	75	VFD550ED43S	37.2	4030	2	BR1K0W5P1	8	4 in series	74.5	9.5	80.0	60.8
	,	VI D300LD430	01.2	+000		DIVINOVOIT		2 parallel	17.5	5.5	00.0	00.0
	100	VFD750ED43S	50.7	4045	2	BR1K5W043	6	6 parallel	106.0	6.3	120.0	91.2

Table 6-2

^{*1} Calculation of 125% braking torque: (kW)*125%*0.8; where 0.8 is the motor efficiency.

Since there is a resistor power consumption limit, the longest operation time for 10% ED is 10 seconds (ON: 10 seconds / OFF: 90 seconds).

^{*2} The calculation of the brake resistor is based on a four-pole motor (1800 rpm).

^{*3} To dissipate heat, mount a resistor of 400 W or lower to a frame to keep the surface temperature below 250°C (482°F). Fix a resistor of 1000 W or higher to a surface to keep the surface temperature below 600°C (1112°F). (If the resistor temperature is higher than 350°C, install extra cooling. If the resistor temperature is higher than the temperature limit, increase the size of the resistor.)

^{*4} The calculation of the braking current is based on Delta's brake resistor and default braking voltage (220V_{AC}: 380V_{DC}; 440V_{AC}: 760V_{DC}).

PM Elevator System (Using Delta's Brake Resistor)

Φ		plicable Delta's Motor Drive		1	25% B	raking Torque/30	0% ED	y * 1		Max	Max. Braking Torque		
Voltage	HP	Model	Braking Torque* ² (kg-m)	Brake VFDB	Unit #	Delta's Bra	ake Re	csistor*3 Configurat	Braking Current (A)*4	Min. Resistor Value (Ω)	Max. Total Braking Current (A)	Peak Power (kW)	
	3	VFD022ED21S	1.5			BR1K0W050	1		7.6	38.0	10.0	3.8	
	5	VFD037ED21S	2.5			BR1K0W016	2	2 in series	11.9	19.0	20.0	7.6	
	5	VFD040ED23S	2.5			BR1K0W016	2	2 in series	11.9	19.0	20.0	7.6	
	7.5	VFD055ED23S	3.7			BR1K0W050	2	2 parallel	15.2	15.6	24.4	9.3	
	10	VFD075ED23S	5.1			BR1K0W050	3	3 parallel	22.8	11.5	33.0	12.5	
230V	15	VFD110ED23S	7.5			BR1K0W050	4	4 parallel	30.4	9.5	40.0	15.2	
	20	VFD150ED23S	10.2			BR1K0W050	5	5 parallel	38.0	8.3	46.0	17.5	
	25	VFD185ED23S	12.2			BR1K5W039	5	5 parallel	48.7	5.8	66.0	25.1	
	30	VFD220ED23S	14.9			BR1K5W039	6	6 parallel	58.5	5.8	66.0	25.1	
	40	VFD300ED23S	20.3	2015	2	BR1K0W050	10	10 parallel	76.0	4.8	80.0	30.4	
	50	VFD370ED23S	25.1	2022	2	BR1K0W050	14	14 parallel	106.4	3.2	120.0	45.6	
	5	VFD040ED43S	2.7			BR1K0W050	2	2 in series	7.6	54.3	14.0	10.6	
	7.5	VFD055ED43S	3.7			BR1K0W050	2	2 in series	7.6	48.4	15.7	11.9	
	10	VFD075ED43S	5.1			BR1K0W020	3	3 in series	12.7	39.4	19.3	14.7	
	15	VFD110ED43S	7.5			BR1K0W050	4	2 in series 2 parallel	15.2	30.8	24.7	18.8	
	20	VFD150ED43S	10.1			BR1K5W039	4	2 in series 2 parallel	19.5	25.0	30.4	23.1	
	25	VFD185ED43S	12.5			BR1k2W039	6	2 in series 3 parallel	29.2	20.8	36.5	27.7	
460V	30	VFD220ED43S	14.9			BR1K5W039	6	2 in series 3 parallel	29.2	19.0	40.0	30.4	
	40	VFD300ED43S	20.3			BR1K5W039	8	2 in series 4 parallel	39.0	14.1	54.0	41.0	
	50	VFD370ED43S	25.0	4045	1	BR1K5W039	10	2 in series 5 parallel	48.7	13.8	55.0	41.8	
	60	VFD450ED43S	30.4	4030	2	BR1K5W039	12	2 in series 6 parallel	58.5	10.3	74.0	56.2	
	75	VFD550ED43S	37.2	4045	2	BR1k2W039	16	2 in series 8 parallel	77.9	6.9	110.0	83.6	
	100	VFD750ED43S	50.7	4110	1	BR1k2W039	22	2 in series 11 parallel	107.2	6.4	118.0	89.7	

Table 6-3

^{*1} Calculation of 125% braking torque: (kW)*125%*0.8; where 0.8 is the motor efficiency.

Since there is a resistor power consumption limit, the longest operation time for 30% ED is 30 seconds (ON: 30 seconds / OFF: 70 seconds).

^{*2} The calculation of the brake resistor is based on a four-pole motor (1800 rpm).

^{*3} To dissipate heat, mount a resistor of 400 W or lower to a frame to keep the surface temperature below 250°C (482°F). Fix a resistor of 1000 W or higher to a surface to keep the surface temperature below 600°C (1112°F). (If the resistor temperature is higher than 350°C, install extra cooling. If the resistor temperature is higher than the temperature limit, increase the size of the resistor.)

^{*4} The calculation of the braking current is based on Delta's brake resistor and default braking voltage (220V_{AC}: 380V_{DC}; 440V_{AC}: 760V_{DC}).

NOTE:

Select the resistance value, power and brake usage (ED %) according to Delta rules.
 Definition for Brake Usage ED%





Figure 6-1

 $ED\% = T1/T0 \times 100 (\%)$

Explanation:

Brake usage ED (%) is the amount of time needed for the brake unit and brake resistor to dissipate heat generated by braking. When the brake resistor heats up, the resistance increases with temperature, and braking torque decreases accordingly.

For safety, install a thermal overload relay between the brake unit and the brake resistor in conjunction with the magnetic contactor (MC) at the drive mains input for additional protection. The thermal overload relay protects the brake resistor from overheat damage due to frequent or continuous braking. Under such circumstances, turn off the power to prevent damage to the brake resistor and the drive. **NOTE:** Never use it to disconnect the brake resistor.



- When the drive is equipped with a DC reactor, read the user manual for the correct wiring for the brake unit input circuit +(P).
- DO NOT connect the input circuit -(N) to the neutral point of the power system.

Figure 6-2

- 2. Any damage to the drive or other equipment caused by using brake resistors and brake units that are not provided by Delta voids the warranty.
- 3. Consider environmental safety factors when installing the brake resistors. If you use the minimum resistance value, consult your local dealers for the power calculation.
- 4. When using more than two brake units, the equivalent resistor value of parallel brake unit cannot be less than the value in the column "Min. Resistor Value (Ω)". Read the wiring information in the brake unit instruction sheet thoroughly prior to operation. Visit the following links to get the instruction sheets for the wiring in the brake unit:
 - VFDB2015 / 2022 / 4030 / 4045 / 5055 Braking Modules Instruction Sheet
 http://www.deltaww.com/Products/PluginWebUserControl/downloadCenterCounter.aspx?DID=1574&DocPath=1&hl=zh-TW
 - VFDB4110 / 4160 / 4185 Braking Modules Instruction Sheet
 http://www.deltaww.com/Products/PluginWebUserControl/downloadCenterCounter.aspx?DID=1562&DocPath=1&hl=zh-TW
 - VFDB6055 / 6110 / 6160 / 6200 Braking Modules Instruction Sheet
 http://www.deltaww.com/Products/PluginWebUserControl/downloadCenterCounter.aspx?DID=8594&DocPath=1&hl=zh-TW

Chapter 6 Optional Accessories | VFD-ED

- 5. The selection tables are for normal use. If the AC motor drive requires frequent braking, increase the Watts by two to three times.
- 6. Thermal Overload Relay (TOR):

Thermal overload relay selection is based on its overload capacity. A standard braking capacity of the VFD-ED is 10%ED (Tripping time = 10s). As shown in the graph below, a 460V, 11 kw VFD-ED requires the thermal relay to take 260% overload capacity for 10 seconds (hot starting) and the braking current is 17.7 A. In this case, select a thermal overload relay larger than 17.7 / 2.6 = 6.8 (A). The specification of each thermal relay may vary among different manufacturers. Carefully read the specification before using it.



Figure 6-3

6-2 Non-fuse Circuit Breaker

Comply with the UL standard: Per UL 508, paragraph 45.8.4, part a. The rated current of a breaker shall be two to four times the maximum rated input current of the AC motor drive.

Single-phase/Three-phase						
Model	Recommended non-fuse					
Model	breaker (A)					
VFD022ED21S*	50					
VFD037ED21S*	75					
VFD040ED23S	40					
VFD055ED23S	50					
VFD075ED23S	60					
VFD110ED23S	100					
VFD150ED23S	125					
VFD185ED23S	150					
VFD220ED23S	175					
VFD300ED23S	250					
VFD370ED23S	300					
*: Single-phase models						

Three-phase						
Model	Recommended non-fuse					
1,555,4555,455	breaker (A)					
VFD040ED43S	30					
VFD055ED43S	35					
VFD075ED43S	40					
VFD110ED43S	50					
VFD150ED43S	60					
VFD185ED43S	75					
VFD220ED43S	100					
VFD300ED43S	125					
VFD370ED43S	150					
VFD450ED43S	200					
VFD550ED43S	250					
VFD750ED43S	350					

Table 6-4 Table 6-5

6-3 Fuse Specification Chart

Fuse specifications lower than the table below are allowed.

Model	Input Current (A)	Line	Fuse
Model	Input Current (A)	I (A)	Bussmann P/N
VFD022ED21S	26	60	JJN-60
VFD037ED21S	37	90	JJN-90
VFD040ED23S	20	50	JJN-50
VFD055ED23S	23	60	JJN-60
VFD075ED23S	30	80	JJN-80
VFD110ED23S	47	125	JJN-125
VFD150ED23S	56	150	JJN-150
VFD185ED23S	73	175	JJN-175
VFD220ED23S	90	225	JJN-225
VFD300ED23S	132	300	JJN-300
VFD370ED23S	161	400	JJN-400
VFD040ED43S	11.5	35	JJS-35
VFD055ED43S	14	40	JJS-40
VFD075ED43S	17	45	JJS-45
VFD110ED43S	24	60	JJS-60
VFD150ED43S	30	80	JJS-80
VFD185ED43S	37	90	JJS-90
VFD220ED43S	47	110	JJS-110
VFD300ED43S	58	150	JJS-150
VFD370ED43S	80	200	JJS-200
VFD450ED43S	100	250	JJS-250
VFD550ED43S	128	300	JJS-300
VFD750ED43S	165	400	JJS-400

Table 6-6

6-4 AC / DC Reactor

AC Input Reactor

Installing an AC reactor on the input side of an AC motor drive can increase line impedance, improve the power factor, reduce input current, increase system capacity, and reduce interference generated from the motor drive. It also reduces momentary voltage surges or abnormal current spikes. For example, when the main power capacity is higher than 500 kVA, or when using a switching capacitor bank, momentary peak voltage and current spikes may damage the AC motor drive's internal circuit. An AC reactor on the input side of the AC motor drive protects it by suppressing surges.

Installation

Install an AC input reactor in series between the main power and the three input phases R S T, as shown in the figure below:




Figure 6-4 Connecting an AC Input Reactor

DC Reactor

A DC reactor can also increase line impedance, improve the power factor, reduce input current, increase system power, and reduce interference generated from the motor drive. A DC reactor stabilizes the DC bus voltage. Compared with an AC input reactor, a DC reactor is in smaller size, lower price, and lower voltage drop (lower power dissipation).

Installation

Install a DC reactor between terminals +1(DC+) and +2/B1(DC+). Remove the DC reactor jumper, as shown in the figure below, before installing a DC reactor.




Figure 6-5 Installing a DC Reactor

THD (Total Harmonic Distortion)

The table below shows the THDi specification when using Deltas drives (three-phase power models) to work with AC/DC reactors.

Motor Drive Spec.		Models wit	hout Built-in D	Models with	Built-in DC			
Motor Drive Spec.	Models without	Widdels Wit	nout built-in b	C Neactors	Rea	Reactors		
Reactors in	AC/DC Reactors	3% Input AC	5% Input AC	4% DC	3% Input AC	5% Input AC		
Series Spec.		Reactor	Reactor	Reactor	Reactor	Reactor		
5th	73.3%	38.5%	30.8%	25.5%	27.01%	25.5%		
7th	52.74%	15.3%	9.4%	18.6%	9.54%	8.75%		
11th	7.28%	7.1%	6.13%	7.14%	4.5%	4.2%		
13th	0.4%	3.75%	3.15%	0.48%	0.22%	0.17%		
THDi	91%	43.6%	34.33%	38.2%	30.5%	28.4%		

NOTE: Table 6-7

- 1. THDi may vary due to different installation conditions and environment (wires, motors).
- 2. For three-phase power models, Delta provides 4% DC reactors and 3% AC reactors. Refer to the following sections to select your applicable reactors.

AC Output Reactor

When using drives in long wiring output application, ground fault (GFF), over-current (OC) and motor over-voltage (OV) often occur. GFF and OC cause errors due to the drives self-protective mechanism; over-voltage damages motor insulation.

The excessive length of the output wires makes the grounded stray capacitance too large, increase the three-phase output common mode current, and the reflected wave of the long wires makes the motor dv / dt and the motor terminal voltage too high. Thus, installing a reactor on the drive's output side can increases the high-frequency impedance to reduce the dv / dt and terminal voltage to protect the motor.

Installation

Install an AC output reactor in series between the three output phases U V W and the motor, as shown in the figure below:




Figure 6-6 Connecting an AC Output Reactor

Applicable Reactors

200V-230V / 50-60 Hz (Single-phase power)

Model	Rated Current (Arms)	Saturation Current (Arms)	AC Input Reactors (mH)	AC Input Reactors (Delta Part#)	AC Output Reactors (mH)	AC Output Reactors (Delta Part #)
VFD022ED21S	12	24	1.172	DR025D0117	2.02	DR012L0202
VFD037ED21S	17	34	0.574	DR049DP574	1.17	DR018L0117

Table 6-8

200V-230V / 50-60 Hz (Three-phase power)

Model	Rated Current (Arms)	Saturation Current (Arms)	3% AC Input / Output Reactors (mH)	3% AC Input / Output Reactors (Delta Part #)	4% DC Reactors (mH)	4% DC Reactors (Delta Part #)
VFD040ED23	20	40	0.507	DR025AP507 DR025LP507	NA*	NA*
VFD055ED23	24	48	0.507	DR025AP507 DR025LP507	1.17	DR025D0117
VFD075ED23	30	60	0.32	DR033AP320 DR033LP320	0.851	DR033DP851
VFD110ED23	45	90	0.215	DR049AP215 DR049LP215	0.574	DR049DP574

Model	Rated Current (Arms)	Saturation Current (Arms)	3% AC Input / Output Reactors (mH)	3% AC Input / Output Reactors (Delta Part #)	4% DC Reactors (mH)	4% DC Reactors (Delta Part #)
VFD150ED23	58	116	0.162	DR065AP162 DR065LP162	0.432	DR065DP432
VFD185ED23	77	154	0.141	DR090AP141 DR090LP141	0.325	DR090DP325
VFD220ED23	87	174	0.141	DR090AP141 DR090LP141	0.325	DR090DP325
VFD300ED23	132	264	0.087	DR146AP087 DR146LP087	NA**	NA**
VFD370ED23	161	322	0.07	DR180AP070 DR180LP070	NA**	NA**

NOTE: NA* stands for not being able to install this accessory; NA** stands for built-in accessory.

Table 6-9

380V-460V / 50-60 Hz (Three-phase power)

Model	Rated Current (Arms)	Saturation Current (Arms)	3% AC Input / Output Reactors (mH)	3% AC Input / Output Reactors (Delta Part #)	4% DC Reactors (mH)	4% DC Reactors (Delta Part #)
VFD040ED43S	11.5	23	2.31	DR010A0231 DR010L0231	NA*	NA*
VFD055ED43S	13	26	2.02	DR012A0202 DR012L0202	4.67	DR012D0467
VFD075ED43S	17	34	1.17	DR018A0117 DR018L0117	3.11	DR018D0311
VFD110ED43S	23	46	0.881	DR024AP881 DR024LP881	2.33	DR024D0233
VFD150ED43S	30	60	0.66	DR032AP660 DR032LP660	1.75	DR032D0175
VFD185ED43S	38	76	0.639	DR038AP639 DR038LP639	1.47	DR038D0147
VFD220ED43S	45	90	0.541	DR045AP541 DR045LP541	1.24	DR045D0124
VFD300ED43S	58	116	0.405	DR060AP405 DR060LP405	0.935	DR060DP935
VFD370ED43S	80	160	0.267	DR091AP267 DR091LP267	NA**	NA**
VFD450ED43S	100	200	0.221	DR110AP221 DR110LP221	NA**	NA**
VFD550ED43S	128	256	0.162	DR150AP162 DR150LP162	NA**	NA**
VFD750ED43S	165	330	0.135	DR180AP135 DR180LP135	NA**	NA**

NOTE: NA* stands for not being able to install this accessory; NA** stands for built-in accessory.

Table 6-10

NOTE: Because Delta's three-phase power drive models fulfill the requirement for EN12015:2014 Section 6.6.3 condition a), and in accordance with EN12015:2014 Section 6.7.2 Table 4, use THD <48% to comply with EN12015:2014.

Reactor Dimension

AC input reactor dimension and specifications:




Figure 6-7

Unit: mm

								OTHE HINT
Input Reactors Delta Part #	А	В	С	D1*D2	E	G1	G2	PE D
DR005A0254	100	115	65	6*9	45	60	40	M4
DR008A0159	100	115	65	6*9	45	60	40	M4
DR011A0115	130	135	95	6*12	60	80.5	60	M4
DR017AP746	130	135	100	6*12	65	80.5	60	M4

Table 6-11






Figure 6-8

Unit: mm

Input Reactors Delta Part #	А	В	С	D1*D2	Н	G1	G2	PE D
DR025AP215	130	195	100	6*12	65	80.5	60	M4
DR033AP163	130	195	100	6*12	65	80.5	60	M4
DR049AP163	160	200	125	6*12	90	107	75	M4

Table 6-12








Figure 6-9

	Unit: mm
Input Reactors Delta Part #	
DR065AP162	See above.

Table 6-13




Figure 6-10

	Unit: mm
Input Reactors Delta Part #	
DR075AP170	See above.

Table 6-14




Figure 6-11

	Unit: mm
Input Reactors Delta Part #	
DR090AP141	See above.

Table 6-15




Figure 6-12

	Unit: mm
Input Reactors Delta Part #	
DR105AP106	See above.

Table 6-16

Chapter 6 Optional Accessories | VFD-ED




Figure 6-13

	Unit: mm
Input Reactors Delta Part #	
DR146AP087	See above.

Table 6-17




Figure 6-14

	Unit: mm
Input Reactors Delta Part #	
DR180AP070	See above.

Table 6-18

Chapter 6 Optional Accessories | VFD-ED




Figure 6-15

Unit: mm

Input Reactors Delta Part #	А	В	С	D1*D2	Н	G1	G2	PE D
DR003A0810	100	125	65	6*9	43	60	40	M4
DR004A0607	100	125	65	6*9	43	60	40	M4
DR006A0405	130	15	95	6*12	60	80.5	60	M4
DR009A0270	160	160	105	6*12	75	107	75	M4
DR010A0231	160	160	115	6*12	90	107	75	M4
DR012A0202	160	160	115	6*12	90	107	75	M4
DR018A0117	160	160	115	6*12	90	107	75	M4

Table 6-19





Figure 6-16


Unit: mm

Input Reactors Delta Part #	А	В	С	D1*D2	Н	G1	G2	PE D
DR024AP881	160	175	115	6*12	90	107	75	M4
DR032AP660	195	200	145	6*12	115	122	85	M6
DR038AP639	190	200	145	6*12	115	122	85	M6
DR045AP541	190	200	145	6*12	115	122	85	M6

Table 6-20



Tightening torque: 3±1.5 Nm






Figure 6-17

	Unit: mm
Input Reactors Delta Part #	
DR060AP405	See above.

Table 6-21




Figure 6-18

												Ur	it: mm
Input Reactors Delta Part#	А	A1	В	B1	B2	С	D	D1*D2	Ш	C1	G1	G2	Н
DR073AP334	228	240	215	40	170	133	8.5	7*13	152	75	176	200	97
DR091AP267	228	240	245	40	195	133	8.8	7*13	152	90	176	200	97
DR110AP221	228	240	245	40	195	138	8.5	7*13	152	75	176	200	102

Table 6-22




Figure 6-19

Unit: mm Input Reactors В1 B2 С C1 D1*D2 F G2 M*T Α Α1 В D G1 Н Delta Part # DR150AP162 11*18 20*3 DR180AP135 11*18 20*3 DR220AP110 30*3 10*18 DR260AP098 10*18 30*3 DR310AP078 10*18 30*3 DR370AP066 50*4 10*18

Table 6-23

DC reactor dimension and specifications:





Figure 6-20


						Unit: mm
DC Reactors	А	В	С	D	Е	R
Delta Part #	7.				_	
DR005D0585	79	78	112	64±2	56±2	9.5*5.5
DR008D0366	79	78	112	64±2	56±2	9.5*5.5
DR011D0266	79	92	112	64±2	69.5±2	9.5*5.5
DR017D0172	79	112	112	64±2	89.5±2	9.5*5.5
DR025D0117	99	105	128	79±2	82.5±2	9.5*5.5
DR033DP851	117	110	156	95±2	87±2	10*6.5
DR049DP574	117	120	157	95±2	97±2	10*6.5
DR065DP432	117	140	157	95±2	116.5±2	10*6.5
DR075DP391	136	135	178	111±2	112±2	10*6.5
DR090DP325	136	135	179	111±2	112±2	10*6.5
DR003D1870	79	78	112	64±2	56±2	9.5*5.5
DR004D1403	79	92	112	64±2	69.5±2	9.5*5.5
DR006D0935	79	92	112	64±2	69.5±2	9.5*5.5
DR009D0623	79	112	112	64±2	89.5±2	9.5*5.5
DR010D0534	99	93	128	79±2	70±2	9.5*5.5
DR012D0467	99	105	128	79±2	82.5±2	9.5*5.5
DR018D0311	117	110	144	95±2	87±2	10*6.5
DR024D0233	117	120	144	95±2	97±2	10*6.5
DR032D0175	117	140	157	95±2	116.5±2	10*6.5
DR038D0147	136	135	172	111±2	112±2	10*6.5
DR045D0124	136	135	173	111±2	112±2	10*6.5
DR060DP935	136	150	173	111±2	127±2	10*6.5

Table 6-24

AC output reactor dimension and specifications:



Tightening torque: 0.6-0.8 Nm



Tightening torque: 1.0-1.2 Nm




Figure 6-21

Unit: mm

Output Reactors	Α	В	С	D1*D2	Е	G1	G2	PE D
Delta Part#	A	Б	C	0102	Ц	Gi	G2	PED
DR005L0254	96	110	70	6*9	42	60	40	M4
DR008L0159	120	135	96	6*12	60	80.5	60	M4
DR011L0115	120	135	96	6*12	60	80.5	60	M4
DR017LP746	120	135	105	6*12	65	80.5	60	M4
DR025LP507	150	160	120	6*12	88	107	75	M4
DR033LP320	150	160	120	6*12	88	107	75	M4

Table 6-25




Figure 6-22

									ι	Jnit: mm
Output Reactors	۸	В	С	D1*D2	Н	C	G1	0	N.4	חב ח
Delta Part #	Α	Б	C	טוטב	П	G	GI	Q	M	PE D
DR049LP215	180	205	175	6*12	115	85	122	16	1.2-1.4	M4
DR065LP162	180	215	185	6*12	115	85	122	35	2.5-3.0	M4

Table 6-26






Figure 6-23

Unit: mm **Output Reactors** D1*D2 M*T Α Α1 В В1 B2 С C1 Ε G1 Н Delta Part # DR075LP170 170 7*13 240 228 215 44 151 100 152 176 85 20*3 DR090LP141 240 228 44 170 100 7*13 152 176 20*3 215 151 85 DR105LP106 240 228 215 44 170 165 110 7*13 152 176 97 20*3 DR146LP087 240 228 240 202 165 7*13 152 176 97 30*3 45 110 DR180LP070 250 240 250 46 205 175 110 11*18 160 190 30*5 124

Table 6-27



Tightening torque: 0.6-0.8 Nm






Figure 6-24

Unit: mm

Output Reactors Delta Part #	А	В	С	D1*D2	Н	G1	G2	PE D
DR003L0810	96	115	65	6*9	42	60	40	M4
DR004L0607	120	135	95	6*12	60	80.5	60	M4
DR006L0405	120	135	95	6*12	60	80.5	60	M4
DR009L0270	150	160	100	6*12	74	107	75	M4
DR010L0231	150	160	115	6*12	88	107	75	M4
DR012L0202	150	160	115	6*12	88	107	75	M4
DR018L0117	150	160	115	6*12	88	107	75	M4
DR024LP881	150	160	115	6*12	88	107	75	M4
DR032LP660	180	190	145	6*12	114	122	85	M6

Table 6-28




Figure 6-25

								Unit: mm
Output Reactors	^	В	C	D1*D2	Н	G1	G2	PE D
Delta Part #	А	В	O	0102	17	91	G2	FED
DR038LP639	180	205	170	6*12	115	85	122	M4
DR045LP541	235	245	155	7*13	85	/	176	M6

Table 6-29





Figure 6-26

Unit: mm **Output Reactors** Α1 В С C1 D1*D2 G1 M*T Α В1 B2 Ε Н Delta Part # 7*13 DR060LP405 240 228 215 44 170 163 110 152 176 97 20*3 174 DR073LP334 250 235 235 44 186 115 11*18 160 190 124 20*3 DR091LP267 240 190 20*3 250 235 44 186 174 115 11*18 160 124 DR110LP221 175 115 10*18 200 106 20*3 270 260 245 50 192 176

Table 6-30



Φ

Φ

E±5

 $M \pm 0.5$




Figure 6-27

Unit: mm Output Reactors Α1 В В1 B2 С C1 D1*D2 Ε G2 Н M*T Α G1 Delta Part # 51 10*18 DR150LP162 270 264 265 208 192 125 176 200 / 118 30*3 DR180LP135 300 295 310 55 246 195 125 11*22 200 230 190 142 30*3


Table 6-31

6-5 Zero Phase Reactor

You can also suppress interference by installing a zero phase reactor at the main input or the motor output of the drive, depending on the location of the interference. Due to the large current passed through the main input/motor output side, pay attention to core saturation issue. Delta provides two types of zero phase reactors to solve interference problems.

A. Casing with mechanical fixed part

The ideal material for withstanding large current loaded for the zero phase reactor at the main input/motor output is composite core. Core has strong saturation, and its strong resistance are many times of simple metal magnetic materials. Thus, it can be used for high frequencies and you can get higher impedance by increasing the number of turns.










Figure 6-28

Unit: mm (inch)

Model	Α	В	С	D	E	F	G(Ø)	Torque
RF008X00A	98 [3.858)	73 (2.874)	36.5 (1.437)	29 (1.142)	56.5 (2.224)	86 (3.386)	5.5 (0.217)	8–10 kgf/cm
RF004X00A	110 (4.331)	87.5 (3.445)	43.5 (1.713)	36 (1.417)	53 (2.087)	96 (3.780)	5.5 (0.217)	8–10 kgf/cm

Table 6-32








Figure 6-29

Unit: mm (inch)

Model	Α	В	С	D	Е	F	G(Ø)	Н	Torque
RF002X00A	200 (7.874)	172.5 (6.791)	90 (3.543)	78 (3.071)	55.5 (2.185)	184 (7.244)	5.5 (0.217)	22 (0.866)	40–45 kgf/cm

Table 6-33




Figure 6-30

Unit: mm (inch)

Model	А	В	С	D	E	F	G(Ø)	Н	I
RF300X00A	241	217	114	155	42	220	6.5	7.0	20
	(9.488)	(8.543)	(4.488)	(6.102)	(1.654)	(8.661)	(0.256)	(0.276)	(0.787)

Torque:40-45 kgf/cm

Table 6-34

B. Casing without mechanical fixed part

Adopts nanocrystalline core developed by VAC®, and has high initial magnetic permeability, high saturation induction density, low iron loss and perfect temperature characteristic. If the zero phase reactor does not need to be fixed mechanically, use this solution.




Figure 6-31

Unit: mm

Model	Α	В	С	Function
T60006L2040W453	22.5	43.1	18.5	Motor wire
T60006L2050W565	36.3	53.5	23.4	Motor wire
T60006L2160V066	123.9	166.9	30.5	Motor wire
T60004L2016W620	10.7	17.8	8.0	Signal line
T60004L2025W622	17.5	27.3	12.3	Signal line

Table 6-35

Reactor Model *1	Recommend	led Wire Size	Wiring Method	Qty	Applicable Motor Drives
RF008X00A T60006L2040W453	≤ 8 AWG	≤ 8.37 mm ²	Fig. 6-32 Fig. 6-33	1	VFD022ED21S VFD037ED21S VFD040ED23S VFD040ED43S
RF004X00A T60006L2050W565	≤4 AWG	≤ 21.15 mm²	Fig. 6-32 Fig. 6-33	1	VFD055ED23S VFD075ED23S VFD110ED23S VFD055ED43S VFD075ED43S VFD110ED43S VFD150ED43S VFD185ED43S
RF002X00A T60006L2160V066	≤ 2 AWG	≤ 33.62 mm ²	Fig. 6-32 Fig. 6-33	1	VFD150ED23S VFD185ED23S VFD220ED23S VFD220ED43S VFD300ED43S
RF300X00A T60006L2160V066	≤ 300 MCM	≤ 152 mm ²	Fig. 6-32 Fig. 6-33	1	VFD300ED23S VFD370ED23S VFD370ED43S VFD450ED43S VFD750ED43S

^{*1: 600}V insulated cable wire

Table 6-36

Installation

During installation, pass the cable through at least one zero phase reactor. Use a suitable cable type (insulation class and wire section) so that the cable passes easily through the zero phase reactor. Do not pass the grounding cable through the zero phase reactor; only pass the motor wire through the zero phase reactor. With longer motor cables the zero-phase reactor can effectively reduce interference at the motor output. Install the zero-phase reactor as close to the output of the drive as possible. Diagram A shows the installation diagram for a single turn zero phase reactor. If the wire diameter allows several turns, Diagram B shows the installation of a multi-turn zero phase reactor. The more turns, the better the noise suppression effect.




Figure 6-32 Single turn wiring diagram for shielding wire with a zero phase reactor




Figure 6-33 Multi-turn zero phase reactor

Installation Precaution

Install the zero phase reactor at the drive's output terminal (U/T1, V/T2, W/T3). After the zero phase reactor is installed, it reduces the electromagnetic radiation and load stress emitted by the wiring of the frequency converter. The number of zero phase reactors required for the drive depends on the wiring length and the drive voltage.

The normal operating temperature of the zero phase reactor should be lower than 85°C (176°F). However, when the zero phase reactor is saturated, its temperature may exceed 85°C (176°F). In this case, increase the number of zero phase reactors to avoid saturation. The following are reasons that might cause saturation of the zero phase reactors: the drive wiring is too long; the drive has several sets of loads; the wiring is in parallel; or the drive uses high capacitance wiring. If the temperature of the zero phase reactor exceeds 85°C (176°F) during the operation of the drive, increase the number of zero phase reactors.

Recommended maximum wiring gauge when installing zero phase reactor:

Zero Phase Reactor	Max. Wire Gauge or	Max. Wire Gauge AWG (1 C*3)		Max. Wire Gau	ge AWG (4 C*1)
Model No.	LUG width	75°C	90°C	75°C	90°C
RF008X00A	13 MM	3 AWG	1 AWG	3 AWG	1 AWG
RF004X00A	16 MM	1 AWG	2/0 AWG	1 AWG	1/0 AWG
RF002X00A	36 MM	600 MCM	600 MCM	1 AWG	1/0 AWG
RF300X00A	73 MM	650 MCM	650 MCM	300 MCM	300 MCM
T60006L2040W453	11 MM	9 AWG	4 AWG	6 AWG	6 AWG
T60006L2050W565	16 MM	1 AWG	2/0 AWG	1 AWG	1/0 AWG
T60006L2160V066	57 MM	600 MCM	600 MCM	300 MCM	300 MCM

Table 6-37

6-6 EMC Filter

The table below shows external EMC filter models for each ED-S series motor drive. Choose corresponding zero phase reactors and applicable shielding cables according to the required noise emission and electromagnetic interference rating for the best configuration and anti-interference performance. If radiation emission (RE) is not a concern on site and you only need conducted emission (CE) to reach EN55011 Class A, you do not need to install a zero phase reactor on the input side to reach the EMC standard.

220V Models

	VFD-ED Zero Phase Rea		Zero Phase Reactor		EN12015		
ō	M . D .	D	EMC Filter		Carrier	Conducted Emission	D 1: 1:
Frame	Motor Drive Model #	Rated Input Current (A)	Model #	Input Side (R/S/T)	Frequency	Length of Output Shielded Cable 50 m	Radiation Emission
	VFD022ED21S	24	B84142A0042R122	RF008X00A or T60006L2040W453		CLASS A	CLASS A
В	VFD037ED21S	34	B84142A0042R122	RF008X00A or T60006L2040W453		CLASSA	CLASSA
	VFD040ED23S	20	EMF035A23A	RF008X00A or T60006L2040W453		CLASS A	CLASS A
	VFD055ED23S	23	EMF056A23A	RF004X00A or T60006L2050W565		CLASS A	CLASS A
С	VFD075ED23S	30	EMF056A23A	RF004X00A or T60006L2050W565	Carrier	CLASS A	CLASS A
	VFD110ED23S	47	EMF056A23A	RF004X00A or T60006L2050W565	frequency by	CLASS A	CLASS A
	VFD150ED23S	56	B84143D0150R127	RF002X00A or T60006L2160V066	deladit	CLASS A	CLASS A
D	VFD185ED23S	73	B84143D0150R127	RF002X00A or T60006L2160V066		CLASS A	CLASS A
	VFD220ED23S	90	B84143D0150R127	RF002X00A or T60006L2160V066		CLASS A	CLASS A
E	VFD300ED23S	132	B84143D0150R127	RF002X00A or T60006L2160V066		CLASS A	CLASS A
	VFD370ED23S	161	B84143D0200R127	RF300X00A or T60006L2160V066		CLASS A	CLASS A

Table 6-38


460V Models

	VFD-ED			Zero Phase Reactor		EN12015	
пе	Motor Drive	Rated Input	EMC Filter		Carrier	Conducted Emission	Radiation
Frame	Model #	Current (A)	Model #	Input Side (R/S/T)	Frequency	Length of Output Shielded Cable 50 m	Emission
В	VFD040ED43S	11.5	EMF018A43A	RF008X00A or T60006L2040W453		CLASS A	CLASS A
	VFD055ED43S	14	EMF018A43A	RF004X00A or T60006L2050W565		CLASSA	CLASS A
	VFD075ED43S	17	EMF018A43A	RF004X00A or T60006L2050W565		CLASS A	CLASS A
С	VFD110ED43S	24	EMF033A43A	RF004X00A or T60006L2050W565		CLASS A	CLASS A
	VFD150ED43S	30	EMF033A43A	RF004X00A or T60006L2050W565		CLASS A	CLASS A
	VFD185ED43S	37	B84143D0075R127	RF004X00A or T60006L2050W565	Carrier frequency by	CLASS A	CLASS A
D	VFD220ED43S	47	B84143D0090R127	RF002X00A or T60006L2160V066	default	CLASS A	CLASS A
	VFD300ED43S	58	B84143D0090R127	RF002X00A or T60006L2160V066		CLASS A	CLASS A
	VFD370ED43S	80	B84143D0200R127	RF300X00A or T60006L2160V066		CLASS A	CLASS A
E	VFD450ED43S	100	B84143D0200R127	RF300X00A or T60006L2160V066		CLASS A	CLASS A
-	VFD550ED43S	128	B84143D0200R127	RF300X00A or T60006L2160V066		CLASS A	CLASS A
	VFD750ED43S	165	B84143D0200R127	RF300X00A or T60006L2160V066		CLASS A	CLASS A

Table 6-39

EMC Filter Dimension

EMC Filter Model #: EMF018A43A



Unit: mm [inch]

Figure 6-34

Unit: mm [inch]





Figure 6-35






Figure 6-36

Unit: mm [inch]




Figure 6-37




Figure 6-38




Figure 6-39




Figure 6-40

EMC Filter Installation

All electrical equipment in operation, including AC motor drives, generates high-frequency and low-frequency noise that interfere with peripheral equipment by radiation or conduction. By correctly installing an EMC filter, you can eliminate much of the interference. Use DELTA EMC filters for the best interference elimination.

The following standards are met when the AC motor drive and EMC filter are installed and wired according to the user manual:

- EN61000-6-4
- EN61800-3: 1996
- EN55011: (1991) Class A Group 1 (1st Environment, restricted distribution)
- European Standards: EN12015 & EN12016

General precaution

To ensure the best anti-interference performance for EMC filter, observe the following precautions in addition to the installation and wiring in the user manual:

- ☑ Install the EMC filter and AC motor drive on the same metal plate. Install the AC motor drive on the EMC filter footprint or install the EMC filter as close as possible to the AC motor drive.
- ☑ Use the shortest wire possible. Ground the metal plate. Fix the EMC filter cover and AC motor drive or grounding to the metal plate and make the contact area as large as possible.

Choose suitable motor cable and precautions

Improper installation and choice of motor cable affect the performance of EMC filters. Be sure to observe the following precautions when selecting motor cable.

- ☑ Use shielded cable (double shielding is best). Ground the shielding on both ends of the motor cable with the minimum length and maximum contact area.
- ☑ Remove any paint on the metal saddle for good ground contact with the plate and shielding (see Figure 6-41).
- ☐ The connections between the motor's shielded cable and metal plate must be correct. Use a U-shape metal saddle to fix both ends of the motor cable. See Figure 6-42 for correct connections.

Remove any paint on metal saddle for good ground contact with the plate and shielding.




Figure 6-41




Figure 6-42

The motor cable length

- Required cable length when the motor drive is at full load.
 - 1. Non-shielded cable: For 5.5 kW (7.5 HP) and below models, the maximum cable length is 100 m (328 ft). For 7.5 kW (10 HP) and above models, the maximum cable length is 200 m (656 ft)
 - 2. Shielded cable: For 5.5 kW (7.5 HP) and below models, the maximum cable length is 50 m (165 ft). For 7.5 kW (10 HP) models, the maximum cable length is 100 m (328 ft).
 - 3. To be compatible with the European Standards EN12015 & EN12016, follow one of the following in addition to the precautions on page 6-45:
 - (1) Use shielded cables
 - (2) The motor cable must be shorter than 2 m (6 ft).

If the cable length is longer than the recommended lengths above, install an output reactor.

NOTE:

- 1. If the cable length is too long, the stray capacitance between cables increases and may cause leakage current. In this case, It activates the over-current protection, increases leakage current, or may affect the current display. The worst case is that it may damage the AC motor drive.
- 2. If more than one motor is connected to the AC motor drive, the total wiring length is the sum of the wiring length from AC motor drive to each motor.
- 3. For the 460V series AC motor drive, when you install an overload thermal relay between the drive and the motor to protect the motor from overheating, the connecting cable must be shorter than 50 m; however, an overload thermal relay malfunction may still occur. To prevent the malfunction, install an output reactor (optional) to the drive or lower the carrier frequency setting (Pr.00-12).
- Consequence of the surge voltages on the motor

When a motor is driven by a PWM-type AC motor drive, the motor terminals experience surge voltages due to component conversion of AC motor drive and cable capacitance. When the motor cable is very long (especially for the 460V series), surge voltages may damage the insulation. To prevent this, follow these rules:

- 1. Use a motor with enhanced insulation (refer to the tables below).
- 2. Reduce the cable length between the AC motor drive and motor to suggested values.
- 3. Connect an output reactor (optional) to the output terminals of the AC motor drive.

For 7.5 kW (10 HP) and higher models:

Insulation level of motor	1000V	1300V	1600V
460 V _{AC} input voltage	20 m (66 ft)	100 m (328 ft)	400 m (1312 ft)
230 V _{AC} input voltage	400 m (1312 ft)	400 m (1312 ft)	400 m (1312 ft)

Table 6-40

For 5.5 kW (7.5 HP) and lower models:

Insulation level of motor	1000V	1300V	1600V
460 V _{AC} input voltage	20 m (66 ft)	50 m (165 ft)	50 m (165 ft)
230 V _{AC} input voltage	100 m (328 ft)	100 m (328 ft)	100 m (328 ft)

Table 6-41

6-7 Digital Keypad

KPC-CC01



Communication Interface RJ45 (socket), RS-485 interface

Communication protocol: RTU19200, 8, N, 2

Installation Method

- 1. Embedded type and can be put flat on the surface of the control box. The front cover is water proof.
- 2. Buy a MKC-KPPK model to do wall mounting or embedded mounting. Its protection level is IP66.
- 3. The maximum RJ45 extension lead is 5 m (16ft)
- 4. This keypad can only be used on Delta's motor drive C2000, CH2000, CP2000, and ED series.

Descriptions of Keypad Functions


Key	Descriptions
RUN	Start Operation Key 1. Only valid when the source of operation command is the keypad. 2. Operates the AC motor drive by the function setting. The RUN LED will be ON. 3. Can be pressed repeatedly at the stop process.
STOP	 Stop Command Key. This key has the highest priority when the command is from the keypad. When it receives the STOP command, regardless of whether the AC motor drive is in operation or stop status, the AC motor drive needs to execute the "STOP" command. Use the RESET key to reset the drive after a fault occurs. If you cannot reset after the fault: The condition which triggers the fault is not cleared. After you clear the condition, you can then reset the fault. The drive is in the fault status when powered on. After you clear the condition, restart and then you can reset the fault.
FWD REV	Operation Direction Key 1. Only controls the operation direction, NOT the drive activation. FWD: forward, REV: reverse. 2. Refer to the Descriptions of LED Functions on p.9-6 for more details.
ENTER	ENTER Key Goes to the next menu level. If at the last level, press ENTER to execute the command.
ESC	ESC Key Leaves the current menu and returns to the previous menu; also functions as a return key or cancel key in a sub-menu.

Key	Descriptions		
MENU	MENU key. Returns to the main menu. Menu items: 1. Parameter Setup 8. Time Setup 14. Main Page 5. Copy Parameter 9. Keypad Locked 15. PC Link 6. Fault Record 12. Display Setup 7. Language Setup 13. Start-up NOTE: Menu items that are not listed above are not supported in VFD-ED.		
< > ^ V	Direction: Left / Right / Up / Down 1. In the numeric value setting mode, moves the cursor and changes the numeric value. 2. In the menu / text selection mode, selects an item.		
F1 F4	Function Key The functions keys have defaults and can also be user-defined. The defaults for F1 and F4 work with the function list below. For example, F1 is the JOG function, and F4 is a quick setting key for adding / deleting user-defined parameters.		

Descriptions of LED Functions

LED		Descriptions		
STOP RESET	•	Steady ON: STOP indicator for the AC motor drive. Blinking: the drive is in standby.		
RESET	Steady OFF: the drive does not execute the "STOP" command.			
FWD REV	Operation Direction LED 1. Green light: the drive is running forward. 2. Red light: the drive is running backward. 3. Flashing light: the drive is changing direction.			
CANopen– "RUN"	RUN LED status OFF Blinking Single flash ON	CANopen at initial No LED CANopen at pre-operation ON OFF CANopen at stop ON OFF ON OFF CANopen at operation status CANopen at operation status		

Chapter 6 Optional Accessories | VFD-ED



Dimension Unit: mm [inch]




Figure 6-43

RJ45 Extension Cables for the Digital Keypad

Part #	Description
CBC-K3FT	3 feet RJ45 extension lead (approximately 0.9 m)
CBC-K5FT	5 feet RJ45 extension lead (approximately 1.5 m)
CBC-K7FT	7 feet RJ45 extension lead (approximately 2.1 m)
CBC-K10FT	10 feet RJ45 extension lead (approximately 3 m)
CBC-K16FT	16 feet RJ45 extension lead (approximately 4.9 m)

NOTE: If communication cables are required, buy non-shielded, 24 AWG, four-wire Table 6-42 twisted pair, 100 ohms communication cables.

6-8 USB/RS-485 Communication Interface IFD6530

Warning

- ✓ Thoroughly read this instruction sheet before installation and putting it into use.
- ✓ The content of this instruction sheet and the driver file may be revised without prior notice. Consult our distributors or <u>download</u> the most updated instruction/driver version.

Introduction

IFD6530 is a convenient RS-485-to-USB converter that does not require an external power supply and a complex setting process. It supports baud rates from 75 to 115.2 kbps and auto-switching of the data transmission direction. In addition, it adopts the RJ45 in RS-485 connector for convenient wiring. Its small size, use of plug-and-play and hot-swappable provide more conveniences for connecting all DELTA IABG products to your PC.

Applicable Models: All DELTA IABG products.

■ Application & Dimension:





Figure 6-45

Specifications

Power supply	No external power is required.	
Power consumption	1.5 W	
Isolated voltage	2,500 V _{DC}	
Baud rate	75, 150, 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 bps	
RS-485 connector	RJ45	
USB connector	A type (plug)	
Compatibility	Full compliance with USB V2.0 specification	
Maximum cable length RS-485 communication port: 100 m		
Supports RS-485 half-duplex transmission		

Table 6-43

RJ45



PIN	Description
1	Reserved
2	Reserved
3	GND
4	SG-

PIN	Description
5	SG+
6	GND
7	Reserved
8	+9V

Preparation before Installing Driver

Extract the driver file (IFD6530_Drivers.exe) by following steps. <u>Download</u> the driver file (IFD6530_Drivers.exe) at Delta's website.

NOTE: DO NOT connect the IFD6530 to PC before extracting the driver file.

STEP 1 STEP 2





STEP 3



STEP 4



STEP 5

At the end of this process, you should have a folder named SiLabs under drive c:\ SiLabs.


Installing the Driver


After connecting the IFD6530 to your PC, install the driver using the following steps.


STEP 1











STEP 5
Repeat Step 1 to Step 4 to complete
COM PORT setting.

LED Display

- 1. Steady green LED ON: power is ON.
- 2. Blinking orange LED: data is transmitting.

[This page intentionally left blank]

Chapter 7 Option Cards

- 7-1 Option Card Installation
- 7-2 EMED-PGABD-2
- 7-3 EMED-PGHSD-3
- 7-4 EMED-PGHSD-4


Chapter 7 Option Cards | VFD-ED

- Select the applicable option cards for your drive or contact your local distributor for suggestions.
- To prevent damage to the motor drive during installation, remove the digital keypad and the cover before wiring. Refer to the following instructions.
- Note that the option cards do not support hot swapping. Turn off the drive power before installing or removing the option cards.


7-1 Option Card Installation

7-1-1 Detach and Attach the Top Cover


Frame B, C and D



Frame E




7-1-2 Vertical View of the Motor Drive & Screw Specifications



7-2 EMED-PGABD-2

7-2-1 Product Profile



NOTE:

- 1. Applicable encoder: A/B/Z and U/V/W Absolute Encoders
- 2. Screw specification

Wire Gauge	0.2–1.5 mm ² (30–16 AWG)	
Torque	1.6 kg-cm (1.4 lb-in.)	

7-2-2 Terminal Function

	Terminals	Descriptions
		Voltage input, to adjust the amplitude of output voltage at terminal A/O and
	Vin	terminal B/O. It also provides a 5 V voltage to support line driver's signal.
		Vin voltage range: 8–24 V, Max: 24 V.
		Output signal for the push-pull voltage frequency division.
		Default: Output amplitude is about +24 V. Use SW3 to disable the internal
		default power. Required input power through Vin-GND port (i.e. output
	A/O D/O	voltage's amplitude)
TB2	A/O, B/O	Vin voltage range: 8–24 V, Max: 24 V.
		Push-Pull Voltage Output
		Max. output frequency: 100 kHz
		Supports frequency division output, the frequency division range: 1–31.
	GND	Common ground terminal connecting to the host controller and the motor drive.
		Output signal for the line driver frequency division.
	AO, AO,	Line Driver RS422
	во, во	Max. output frequency: 150 kHz
		Supports frequency division output, the frequency division range: 1–31. Power output for encoder
		·
	VP	NOTE: Use SW1 to set output voltage amplitude
		Voltage: +5 ± 0.5 V or +12 ± 1 V Current: 200 mA max.
•	0 V	Common power terminal for encoder
		Incremental-type encoder signal input terminal
	A, \overline{A} ,	Types of input signal: line driver, voltage, push-pull, open collector
TB1	B, \overline{B} ,	NOTE: Different input signals need different wiring methods. See the user
	Z, Z	manual for wiring diagrams.
		Max. input frequency: 150 kHz
		Absolute-type encoder signal input terminal
	U, U,	Types of input signal: line driver, voltage, push-pull, open collector
	V, \(\overline{V} \),	NOTE: Different input signals need different wiring methods. See the user
	W, W	manual for wiring diagrams.
		Max. input frequency: 150 kHz
JP1		Ground Terminal
JF I		Connect the motor drive power supply to ground. Supports PG shielding.
SW1		Switch between power for the encoder (5V / 12V).
		Offline Detection Switch. Switch to the Line-D side to enable offline detection
	SW2	for the Line-D input signal. Switch to OPEN-C side to disable offline detection
		function for the OPEN-C input signal.
		Power supply switch for frequency division. Switch to INP side to provide 24 V
	SW3	power for internal use. Switch to EXP side to provide 24 V power for external
		use (client).

7-2-3 Applicable encoders:

 Open collector output encoder application: Use one pull-up resistor for each set of input current 5–15 mA. If open collector input voltage uses 5V or 12V external power, connect the encoder power externally. See the PG wiring Figure 7-8 below.

5V	Suggested pull-up resistor: above 150–520ohm, 1/2 W
12V	Suggested pull-up resistor: above 600–2Kohm, 1/2 W




Figure 7-7




Figure 7-8




Figure 7-9

Chapter 7 Option Cards | VFD-ED

2. Voltage output encoder application: Each set of input current is 5–15 mA. If input voltage uses 5V or 12V external power, connect the encoder power externally. See the PG wiring Figure 7-11 below.




Figure 7-10




Figure 7-11




Figure 7-12

3. Push-pull output encoder application: Each set of input current is 5–15 mA. If input If input voltage uses 5V or 12V external power, connect the encoder power externally. See the PG wiring Figure 7-14 below.




Figure 7-13




Figure 7-14




Figure 7-15

Chapter 7 Option Cards | VFD-ED

4. Line driver output encoder application: Each set of input current is 5–15 mA. If input voltage uses 5V or 12V external power, connect the encoder power externally. See the PG wiring Figure 7-17 below.




Figure 7-16




Figure 7-17

NOTE:

- Verify that the SW1 is set to the correct output voltage before powering ON.
- Keep the motor drive wiring away from any high voltage lines to avoid interference.
- When using push-pull output and voltage output, short-circuit \overline{A} , \overline{B} , \overline{Z} to 0V.
- When using open collector output, short-circuit A, B, Z to VP.

7-2-4 Wiring Diagram




Figure 7-18

7-2-5 Frequency Division Signal Setting

- 1. After the encoder inputs a PULSE signal, there is an output signal by the division factor "n" Set the value in Pr.10-29 (PG card's frequency division output).
- 2. Set Pr.10-29 (PG card's frequency division output): The decimal frequency division output setting; range of the division factor "n": 1–31.
- 3. Pr.10-30 (PG card's frequency division output mode)

Bit3	Bit2	Bit1	Bit0
Χ	Х	OUT/M	IN/M

OUT/M: Pulse output mode for frequency division;

IN/M: Pulse input mode for frequency division;

"X" is for backup while "0" is a value to write.

The following table lists the Input Mode (IN/M) & Output Mode (OUT/M) setting and description:




Table 7-1

NOTE:

- In the waveform, A-/A, B-/B are the PG card input signals; AO-AO, BO-BO are the differential output frequency division signals. Use a differential probe to measure.
- In the waveform, A-/A, B-/B are the PG card input signals; AO- AO, BO- BO are the differential output frequency division signals. Use a differential probe to measure.
- Division factor "n": Set 15 to divide the input signal by 15.

- When OUT/M, IN/M set to 0 and 0, the PG card input signal A-/A, B-/B are square waves while AO-AO, BO-BO are frequency division output.
- When **OUT/M**, **IN/M** are set to 1 and 0, the PG card input signal A-/A, B-/B are square waves while the BO- \overline{BO} is the A and B phase indicator (for example, when \overline{BO} - \overline{BO} is LOW, it means A is ahead of B: when \overline{BO} - \overline{BO} is HIGH, it means B is ahead of A). \overline{AO} - \overline{AO} is frequency division output.
- When OUT/M, IN/M are set to X and 1, B-/B phase has to be the direction indication input signal (for example, when B-/B is LOW, it means A is ahead of B; when B-/B is HIGH, it means B is ahead of A). A-/A is a square wave input, BO-BO and B-/B phase are input into synchronous action; AO-AO is frequency division output.
- Take Pr.10-29 and Pr.10-30 as examples: When the frequency division value is 15, OUT/M =1,
 IN/M = 0. Set Pr.10-29 = 15 and Pr.10-30 = 0002h.

Set Pr.10-29 =15

Set Pr.10-30 =0002h

Bit3	Bit2	Bit1	Bit0
Х	Χ	1	0

7-2-6 Wiring of Frequency Division Output

Push-pull Frequency Division (internal power supply)




Figure 7-19

Push-pull Frequency Division (external power supply)




Figure 7-20

Line Driver Frequency Division (internal power supply)




Figure 7-21

Line Driver Frequency Division (external power supply)





Figure 7-22

7-3 EMED-PGHSD-3

7-3-1 Product Profile



NOTE:

1. Applicable encoder:

SIN/COS; Heidenhain ERN1387

EnDat2.1/01: Heidenhain ECN413 \ ECN1313

SICK HIPERFACE: SRS50/60

2. Screw specification:

Wire	0.2–1.5 mm ² (30–16 AWG)	
Gauge	0.2-1.5 mm² (30-16 AVVG)	
Torque	1.6 kg-cm (1.4 lb-in.)	

3. Supports Heidenhain ERN1387, EnDat2.1, HIPERFACE

7-3-2 Terminal Function

Terminals		Descriptions	
		Voltage input: (to adjust the output voltage amplitude of the push-	
	Vin	pull pulse)	
	VIII	Max. input voltage: 24 V _{DC}	
		Max. input current: 30 mA	
TB1	A/O, B/O	Push-pull pulse output signal	
	A(O, b(O	Max. output frequency: 50 kHz	
	GND	Common power input/signal output terminal	
		Output signal for the line driver frequency division.	
	AO, /AO, BO, /BO	Line driver RS422	
		Max. input frequency: 100 kHz	
J3	(D-SUB female connector)	Encoder signal input terminal	
		Frequency division output power terminal selection	
	SW1 INP: Power supplied by PG card		
		EXP: Power from an external source	
SW2		Encoder's voltage output terminal (Up)	
		NOTE: Modify the terminal output voltage by switching the	
		direction of the SW2 DIP switch on the PG card.	
		5V: 5 V _{DC}	
		8V: 8 V _{DC}	

EMED-PGHSD-3 (Terminal J3) pin definitions depend on the encoder type

= MED-PGHSD-3 (Terminal 33) pin definitions depend on the encoder type				
Terminal		Applicable Encoder		
J3	No.	Heidenhain ERN1387	Heidenhain ECN1313	HIPERFACE®
	1	B-	B-	REFSIN
	2	-	-	-
	3	R+	DATA	DATA+
	4	R-	/DATA	DATA-
	5	A+	A+	+COS
(5 4 3 2 1) (0 9 8 7 6) (5 14 13 12 11)	6	A-	A-	REFCOS
	7	0V	0V	GND
	8	B+	B+	+SIN
(15 (14 (13 (12 (11))))	9	Up	Up	Up
	10	C-	-	-
	11	C+	-	-
	12	D+	-	-
	(13)	D-	-	-
	14	-	/CLOCK	-
	(15)	-	CLOCK	-

Terminal Function

	Terminals	Descriptions	Specifications
	Up (VP)	The output voltage for the encoder. Use the SW2 DIP switch to change the output voltage to +5 V or +8 V.	Voltage: +5.1 V _{DC} ± 0.3 V; +8.4 V _{DC} ± 1.5 V Current: 200 mA max.
	0 V	Encoder common power terminal	Reference level for the encoder's power.
J3	A+, A-, B+, B-, R+, R-	Encoder sine wave differential signal input (incremental signal)	Input frequency: 40 kHz max. 360°el. 4 0.81.2Vss (≈1Vss; Z₀=120 α) B 0.2V0.85V (≈0.5V; Z₀=120 α)
	+SIN, +COS, REFSIN, REFCOS	Encoder sine wave differential signal input (incremental signal)	Input frequency: 20 kHz max. SIN 0.91.1V COS REFSIN/REFCOS
	C+, C-, D+, D-	Encoder sine wave differential signal input (absolute signal)	0 360°mech. 0 0.81.2Vss (≈1Vss; Z=1kΩ)
	DATA+(DATA), DATA-(/DATA)	RS-485 communication interface	Terminal resistance is about 130 Ω
	CLOCK+, CLOCK-	CLOCK differential output for ENDAT.	Line Driver RS422 level output

NOTE:

- Verify that the SW2 switch is set to the correct output voltage before powering on.
- Keep the motor drive wiring away from any high voltage lines to avoid interference.

7-3-3 Wiring Diagram




Figure 7-23

7-3-4 Frequency Division Signal Setting

- 1. After the encoder inputs a PULSE signal, there is an output signal by the division factor "n." Set the value in Pr.10-29 (PG card's frequency division output).
- 2. Set Pr.10-29 (PG card's frequency division output): The decimal frequency division output setting; range of the division factor "n": 1–31.
- 3. Pr.10-30 (PG card's frequency division output mode)

Bit3	Bit2	Bit1	Bit0
Х	Χ	OUT/M	IN/M

OUT/M: Pulse output mode for frequency division;

IN/M: Pulse input mode for frequency division;

"X" is for backup while "0" is a value to write.

The following table lists the Input Mode (IN/M) & Output Mode (OUT/M) setting and description:




Table 7-2

NOTE:

- In the waveform, A-/A, B-/B are the PG card input signals; AO- $\overline{\mathrm{AO}}$, BO- $\overline{\mathrm{BO}}$ are the differential output frequency division signals. Use a differential probe to measure.
- Division factor "n": Set 15 to divide the input signal by 15.

- When OUT/M, IN/M set to 0 and 0, the PG card input signal A-/A, B-/B are square waves while AO-AO, BO-BO are frequency division output.
- When **OUT/M**, **IN/M** are set to 1 and 0, the PG card input signal A-/A, B-/B are square waves while the BO- \overline{BO} is the A and B phase indicator (for example, when \overline{BO} - \overline{BO} is LOW, it means A is ahead of B: when \overline{BO} - \overline{BO} is HIGH, it means B is ahead of A). \overline{AO} - \overline{AO} is frequency division output.
- When OUT/M, IN/M are set to X and 1, B-/B phase has to be the direction indication input signal (for example, when B-/B is LOW, it means A is ahead of B; when B-/B is HIGH, it means B is ahead of A). A-/A is a square wave input, BO-BO and B-/B phase are input into synchronous action; AO-AO is frequency division output.
- Take Pr.10-29 and Pr.10-30 as examples: When the frequency division value is 15, OUT/M
 =1, IN/M = 0. Set Pr.10-29 = 15 and Pr.10-30 = 0002h.

Set Pr.10-29 =15

Set Pr.10-30 =0002h

Bit3	Bit2	Bit1	Bit0
Χ	Χ	1	0

7-3-5 Wiring of Frequency Division Output

Push-pull Frequency Division (internal power supply)




Figure 7-24

Push-pull Frequency Division (external power supply)




Figure 7-25

Line Driver Frequency Division (internal power supply)




Figure 7-26

Line Driver Frequency Division (external power supply)





Figure 7-27

7-4 EMED-PGHSD-4

7-4-1 Product Profile



NOTE:

1. Applicable encoder:

SIN/COS: Heidenhain ERN1387

EnDat2.1/01: Heidenhain ECN413 \ ECN1313

SICK HIPERFACE: SRS50/60

2. Screw specification:


Wire Gauge	0.2–1.5 mm ² (30–16 AWG)
Torque	1.6 kg-cm (1.4 lb-in.)

3. Supports Heidenhain ERN1387, EnDat2.1, HIPERFACE

7-4-2 Terminal Function

	Terminals	Descriptions					
		Voltage input: (to adjust the output voltage amplitude of the push-pull pulse)					
	Vin	Max. input voltage: 24 V _{DC}					
		Max. input current: 30 mA					
	A/O, B/O	Push-pull pulse output signal					
TB1	A/O, B/O	Max. output frequency: 50 kHz					
	GND	Common power input/signal output terminal					
	AO /AO	Output signal for the line driver frequency division.					
	AO, /AO, BO, /BO	Line driver RS422					
		Max. input frequency: 100 kHz					
	TB2	Encoder signal input terminal					
JP3		Ground Terminal					
JFJ		Connect the motor drive power supply to ground. Supports PG shielding.					
		Frequency division output power terminal selection					
	SW1	INP: Power supplied by PG card					
		EXP: Power from an external source					
		Encoder's voltage output terminal (Up)					
		NOTE: Modify the terminal output voltage by switching the direction of the					
	SW2	SW2 DIP switch on the PG card.					
		5V: 5 V _{DC}					
		8V: 8 V _{DC}					

EMED-PGHSD-4 (Terminal TB2) pin definitions depend on the encoder type



Terminals	Heidenhaiı	n ERN1387	Heidenhain ECN1313	HIPERFACE®		
A+	Д	\ +	A+	+COS		
A-	F	\ -	A-	REFCOS		
C+	C+	Must set	-	1		
C-	C-	Pr.10-31=1	-	1		
R+/DATA+	F	{ +	DATA	DATA+		
R-/DATA-	R-		R- /DATA		DATA-	
VP	Up		Up	Up		
B+	Е	}+	B+	+SIN		
B-	Е	3-	B-	REFSIN		
D+)+	-	1		
D-	D-		D-		-	1
CLK+	K+ -		CLOCK	-		
CLK-		-	/CLOCK	-		
0V	0	V	0V	GND		

Terminal Function

	Terminals	Descriptions	Specifications			
	Up (VP)	The output voltage for the encoder. Use the SW2 DIP switch to change the output voltage to +5 V or +8 V.	Voltage: +5.1 V _{DC} ± 0.3 V; +8.4 V _{DC} ± 1.5 V Current: 200 mA max.			
	0 V	Encoder common power terminal	Reference level for the encoder's power.			
TB2	A+, A-, B+, B-, R+, R-	Encoder sine wave differential signal input (incremental signal)	Input frequency: 40 kHz max. $ \begin{array}{cccccccccccccccccccccccccccccccccc$			
	+SIN, +COS, REFSIN, REFCOS	Encoder sine wave differential signal input (incremental signal)	Input frequency: 20 kHz max. SIN 0.91.1V COS REFSIN/REFCOS			
	C+, C-, D+, D-	Encoder sine wave differential signal input (absolute signal)	$0 \longrightarrow C 0.81.2Vss \\ (\approx 1Vss; Z=1k\Omega)$			
	DATA+(DATA), DATA-(/DATA)	RS-485 communication interface	Terminal resistance is about 130 Ω.			
	CLOCK+, CLOCK-	CLOCK differential output for ENDAT	Line driver RS422 level output			

NOTE:

- Verify that the SW2 switch is set to the correct output voltage before powering on.
- Keep the motor drive wiring away from any high voltage lines to avoid interference.

7-4-3 Wiring Diagram




Figure 7-28

7-4-4 Frequency Division Signal Setting

- 1. After the encoder inputs a PULSE signal, there is an output signal by the division factor "n." Set the value in Pr.10-29 (PG card's frequency division output).
- 2. Set Pr.10-29 (PG card's frequency division output): The decimal frequency division output setting; range of the division factor "n": 1–31.
- 3. Pr.10-30 (PG card's frequency division output mode)

X	Χ	OUT/M	IN/M
Bit3	Bit2	Bit1	Bit0

OUT/M: Pulse output mode for frequency division;

IN/M: Pulse input mode for frequency division;

"X" is for backup while "0" is a value to write.

The following table lists the Input Mode (IN/M) & Output Mode (OUT/M) setting and description:

OLIT/NA	181/84	Division Factor							
OUT/M	IN/M	A is ahead of B	B is ahead of A						
0	0	A-/A B-/B AO-AO BO-BO	A-/A B-/B AO-ĀŌ BO-BŌ						
1	0	A-/A B-/B AO-AO BO-BO	A-/A B-/B AO-AO BO-BO						
х	1	A-/A	A-/A B-/B AO-ĀŌ BO-BŌ						

Table 7-3

NOTE:

- In the waveform, A-/A, B-/B are the PG card input signals; AO- $\overline{\rm AO}$, BO- $\overline{\rm BO}$ are the differential output frequency division signals. Use a differential probe to measure.
- Division factor "n": Set 15 to divide the input signal by 15.

- When OUT/M, IN/M set to 0 and 0, the PG card input signal A-/A, B-/B are square waves while AO AO, BO-BO are frequency division output.
- When **OUT/M, IN/M** are set to 1 and 0, the PG card input signal A-/A, B-/B are square waves while the $\overline{BO-\overline{BO}}$ is the A and B phase indicator (for example, when $\overline{BO-\overline{BO}}$ is LOW, it means A is ahead of B: when $\overline{BO-\overline{BO}}$ is HIGH, it means B is ahead of A). $\overline{AO-\overline{AO}}$ is frequency division output.
- When OUT/M, IN/M are set to X and 1, B-/B phase has to be the direction indication input signal (for example, when B-/B is LOW, it means A is ahead of B; when B-/B is HIGH, it means B is ahead of A).
 A-/A is a square wave input, BO- BO and B-/B phase are input into synchronous action; AO- AO is frequency division output.
- Take Pr.10-29 and Pr.10-30 as examples: When the frequency division value is 15, OUT/M =1, IN/M =
 0. Set Pr.10-29 = 15 and Pr.10-30 = 0002h.

Set Pr.10-29 =15

Set Pr.10-30 =0002h

Bit3	Bit2	Bit1	Bit0
Х	Χ	1	0

7-4-5 Wiring of Frequency Division Output

Push-pull Frequency Division (internal power supply)




Figure 7-29

Push-pull Frequency Division (external power supply)




Figure 7-30

Line Driver Frequency Division (internal power supply)




Figure 7-31

Line Driver Frequency Division (external power supply)




Figure 7-32

[This page intentionally left blank]

Chapter 8 Specifications

- 8-1 230V Models
- 8-2 460V Models
- 8-3 General Specifications
- 8-4 Operation, Storage and Transportation Environments
- 8-5 Derating Curve

8-1 230V Models

Frame Size		В			С			D			Е	
Model VFDED23/21S		022*	037*	040	055	075	110	150	185	220	300	370
Арр	licable Motor Output (kW)	2.2	3.7	4	5.5	7.5	11	15	18.5	22	30	37
Арр	licable Motor Output (HP)	3	5	5	7.5	10	15	20	25	30	40	50
	Rated Output Capacity (kVA)	4.8	6.8	7.9	9.5	12.5	19	25	29	34	46	55
D	Rated Output Current (A)	12	17	20	24	30	45	58	77	87	132	161
Rating	Maximum Output Voltage (V)				l	Proport	ional to	input vo	oltage			
Į.	Output Frequency Range (Hz)						0.00-	-299				
Output F	Carrier Frequency Range (kHz)	2–15									2–9	
	Rated Output Maximum Carrier	8 kHz			10 kHz		8 kHz			6 kHz		
	Frequency											
	Input Current (A)	24	34	20	23	30	47	56	73	90	132	161
ng	Rated Voltage (V)	Single-phase Three-phase										
Rati	rated voltage (v)	200–240										
Input Rating	Rated Frequency (Hz)						50/	60				
드	Voltage Tolerance (V)						180–	264				
	Frequency Tolerance (Hz)	47–63										
Coo	Cooling Method		Fan cooling									
Wei	ght (kg)	6	6	6	8	10	10	13	13	13	36	36

NOTE: *VFD022ED21S & VFD037ED21S are single-phase input models.

Table 8-1

8-2 460V Models

Frame Size		В			С			С	D E				
Model VFDED43S			055	075	110	150	185	220	300	370	450	550	750
Арр	licable Motor Output (kW)	4	5.5	7.5	11	15	18.5	22	30	37	45	55	75
Арр	licable Motor Output (HP)	5	7.5	10	15	20	25	30	40	50	60	75	100
	Rated Output Capacity (kVA)	9.2	10.4	13.5	18.3	24	30.3	36	46.2	63.7	80	96.4	116.3
	Rated Output Current (A)	11.5	13	17	23	30	38	45	58	80	100	128	165
ating	Maximum Output Voltage (V)				F	Proport	ional to	input	voltag	е			
ıt R	Output Frequency Range (Hz)	0.00–299											
Output Rating	Carrier Frequency Range (kHz)		2–15						2–9			2-	-6
	Rated Output Maximum Carrier	8 kHz	kHz 10 kHz			8 kHz			6 kHz			7	
	Frequency	O KI IZ										_	•
	Input Current (A)	11.5	14	17	24	30	37	47	58	80	100	128	165
ating	Rated Voltage (V)	Three-phase 380–480											
nput Rating	Rated Frequency (Hz)						50/	60					
Inpu	Voltage Tolerance (V)						342-	-528					
	Frequency Tolerance (Hz)	47–63											
Coo	Cooling Method		Fan cooling							_			
Wei	ght (kg)	6	8	10	10	10	10	13	14.5	36	36	50	50

NOTE: *Assumes operation at the rated output current. Input current rating varies depending on the input reactor, transformer, wiring connections and power supply impedance.

Table 8-2

8-3 General Specifications

	Item	Spe	cifications					
	Control Method	V/F, VF+PG, SVC, FOC+PG, FOC+PM	И					
	Ctarting Targue	In V/F mode: 150% at 0.5 Hz.						
	Starting Torque	In FOC+PG or FOC+PM mode: 150% at 0 Hz.						
	Speed Control Range	1:50 (up to 1:1000 when using PG card)						
	Speed Control Accuracy	$\pm 0.5\%$ (up to $\pm 0.02\%$ when using PG card)						
	Speed Response Ability	5 Hz (Up to 30 Hz for vector control)						
tics	Max. Output Frequency	0.00–299.00 Hz						
Control Characteristics	Output Frequency Accuracy	Digital command 0.005%; analog com	Digital command 0.005%; analog command 0.5%.					
Cha	Frequency Setting	Digital command: 0.01 Hz; analog com	nmand: 1/4096 (12 bit) of the maximum					
ntrol	Resolution	output frequency.						
ပိ	Torque Limit	Max. is 200% of the torque current						
	Torque Accuracy	±5%						
	Accel. / Decel. Time	0.00-600.00 seconds						
	V/F Curve	Adjustable V/F curve using four independent points.						
	Frequency Setting Signal	±10 V						
	Brake Torque	About 125% while ED is 30% (use optional brake resistor)						
	blake lolque	Note: ED is "Executive Duty"						
	Motor Protection	Electronic thermal relay protection						
	Over-current Protection	The current is limited by 190% of the c	drive's rated current and the limit for over-					
(0	Over-current i rotection	current protection is 250% of the drive's rated current.						
cteristics	Ground Leakage Current Protection	More than 50% of the drive's rated cur	rent					
hara	Overload Ability	Constant torque: 150% for 60 seconds	s; variable torque: 180% for 10 seconds.					
Protection Chara		Over-voltage level:	Low-voltage level:					
ectic	Voltage Protection	[230V models] $V_{DC} > 400 \text{ V}$	[230V models] V _{DC} < 200 V					
Prot		[460V models] V _{DC} > 800 V	[460V models] V _{DC} < 400 V					
	Over-voltage Protection for the Input Power	Varistor (MOV)						
	Overheating Protection	Built-in temperature sensor						
S	EMC Directive	EN IEC 61800-3:2018						
Certifications	Production Compliance	EN 61800-5-1:2007 + A1:2017 + A11:2	2021					
	Production Certifications *1	CE, UL, EAC, RCM, KC, RoHS						
Ŏ	Safety Certification *1	TUV (STO SIL2)						

NOTE: Table 8-3

^{*1:} For information on Certifications and Declaration of Conformity (Doc), visit <u>Delta | Download Center (deltaww.com)</u>

8-4 Operation, Storage and Transportation Environments

DO NOT expose the AC motor drive to a poor environment, such as one with dust, direct sunlight, corrosive or inflammable gases, humidity, liquids or excessive vibration. The salt in the air must be less than 0.01 mg/cm² every year.

every year.								
	Installation Location	IEC60364-1/IEC60664-1 pollution degree 2. Indoor use only.						
		Between -10–40°C, up to 50°C with derating for the operation						
			temperature					
				2.2–4 kW: for every 1°C increase in temperature,				
		Operation	Between	decrease the drive's rated current by 2.2%				
	Surrounding	Operation	40–50°C	5.5–30 kW: for every 1°C increase in temperature,				
	Temperature		with	decrease the drive's rated current by 2.5%				
	Temperature		Derating	37–75 kW: for every 1°C increase in temperature,				
				decrease the drive's rated current by 2.0%				
		Storage/	-20–60°C					
		· ·	Transportation					
Environment		Non-condensing	g, non-freezin	g.				
		Operation	Max. 90%					
	Rated Humidity	Storage/	Max. 90%					
		Transportation						
		No water condensation						
			If the AC motor drive is installed at an altitude of 0–1000 m, follow					
			normal operation restrictions. For altitudes of 1000–3000 m,					
	Altitude	Operation	decrease the drive's rated current by 1% or lower the temperature					
			by 0.5°C for every 100 m increase in altitude. The maximum					
			altitude for corner grounding is 3000 m. If installing at an altitude					
	D		nigner than .	3000 m is required, contact Delta for more information.				
	Power	TN system*1*2						
	System							
Package	Storage	ISTA procedure	1A (accordin	g to weight) IEC60068-2-31				
Drop	Transportation							
		ak to peak value	Ū	2–13.2 Hz;				
Vibration		range from 13.2-						
	· ·	e from 55–512 H						
	•	with IEC 60068-						
Impact	Compliance w	ith IEC/EN 6006	8-2-27					
Protection Level	NEMA 1/IP20							
EMC Level	IEC 61800-3 a	and IEC 61000-4						

NOTE: Table 8-4

^{*1:} TN system: The neutral point of the power system connects directly to the ground. The exposed metal components connect to the ground through the protective grounding conductor.

^{*2:} Single-phase models use a single-phase three-wire power system.

8-5 Derating Curve

• To choose the right model for your applications, consider derating factors such as ambient temperature, altitude, carrier frequency, and so on.

Ambient Temperature Derating Curve




Figure 8-1

The rated output current derating (%) for different ambient temperature:

Ambient Temp.(°C) Model	30	35	40	45	50
2.2~4 kW	100	100	100	89	78
5.5~30 kW	100	100	100	87	75
37~75 kW	100	100	100	90	80

Table 8-5

Altitude Derating Curve

Condition	Operating Environment
	If the AC motor drive is installed at an altitude of 0–1000 m, follow normal
	operation restrictions. For altitudes of 1000–3000 m, decrease the drive's rated
High Altitude	current by 1% or lower the temperature by 0.5°C for every 100 m increase in
	altitude. The maximum altitude for corner grounding is 3000 m. If installing at an
	altitude higher than 3000 m is required, contact Delta for more information.

Table 8-6




Figure 8-2

The rated output current derating (%) for different altitudes above sea level:

Altitude above Sea Level (Meter)	0	1000	1500	2000	2500	3000
Output Current / Rated Current (%)	100	100	95	90	85	80

Table 8-7

Carrier Frequency Derating Curve




Figure 8-3

The rated output current derating (%) for different carrier frequencies:

Fra	Fc (kHz)	2	4	6	7	8	9	10	11	12	13	14	15
В	2.2~4 kW	100	100	100	100	100	94.24	88.92	82.54	78.08	73.95	70.14	66.61
С	5.5~11 kW	100	100	100	100	100	100	100	95.35	91.02	86.98	84.14	80.67
D	15~22 kW	100	100	100	100	100	92.32	85.21	78.63	72.53	66.87	61.62	56.74
Е	30~45 kW	100	100	100	90.73	82.20	74.31	-	-	-	-	-	-
Е	55~75 kW	100	100	100	-	-	-	-	-	-	-	-	-

Table 8-8

[This page intentionally left blank]

Chapter 9 Digital Keypad

- 9-1 Description of Keyboard Panel
- 9-2 Keypad Operation Process
- 9-3 Description of the Digital Keypad KPC-CC01
- 9-4 Digital Keypad KPC-CC01 Functions
- 9-5 Digital Keypad KPC-CC01 Fault Codes and Descriptions
- 9-6 TPEditor Installation

9-1 Description of Keyboard Panel

Keyboard Panel KPED-LE01



Keypad Functions

Keys	Description
•	Shift key Moves the cursor so you can adjust the selected value.
RESET	RESET key Resets the motor drive after a fault.
MODE	MODE key Changes among the different display modes.
ENTER	ENTER key Allows you to read or modify the current parameter settings.
A	Up and Down keys These buttons have two functions: 1. Press the Up or Down button to increase or decrease the selected value. 2. Press the Up or Down button to select items in a menu and languages.


LED Function Description

LED	Description
	Status Display
	UP: Moving up.
100 mm	DN: Moving down
UP DN D1 D2	D1: MI1 status
D3 D4	D2: MI2 status
	D3: MI3 status
	D4: MI4 status
	Main Display Area
8.8.8.8	Displays frequency, current, voltage, rotation direction, user-defined units, errors and
	warnings.

Description of Displayed Functions

Displayed Function	Description
UP F 5 0.0 DN D2 D2 D4	Displays the VFD-ED frequency setting.
UP H 5 0.0 DN D2 D4	Displays the actual frequency output from the VFD-ED to the motor.
UP	Displays the user-defined value in Pr.00-04.
UP	Displays the current (amperes).
UP D1 DN D2 D4	Displays the selected parameter.
UP D1 D3 DN D2 D4	Displays the value in a parameter.
UP D1 D2 D4	Displays the external fault.
UP	Displays "End" for approximately one second (as shown in the left figure) if the data has been accepted and automatically stored in the register.
UP D1 DN D2 D4	Displays if the setting data is not accepted or data value exceeds the allowed range.

9-2 Keypad Operation Process



9-3 Description of Digital Keypad KPC-CC01

KPC-CC01



Communication Interface RJ45 (socket), RS-485 interface

Communication protocol: RTU19200, 8, N, 2

Installation Method

- 1. Embedded type and can be put flat on the surface of the control box. The front cover is water proof.
- 2. Buy a MKC-KPPK model to do wall mounting or embedded mounting. Its protection level is IP66.
- 3. The maximum RJ45 extension lead is 5 m (16ft)
- 4. This keypad can only be used on Delta's motor drive C2000, CH2000, CP2000, and ED series.

Descriptions of Keypad Functions


Key	Descriptions
RUN	Start Operation Key 1. Only valid when the source of operation command is the keypad. 2. Operates the AC motor drive by the function setting. The RUN LED will be ON. 3. Can be pressed repeatedly at the stop process.
STOP	 Stop Command Key. This key has the highest priority when the command is from the keypad. When it receives the STOP command, regardless of whether the AC motor drive is in operation or stop status, the AC motor drive needs to execute the "STOP" command. Use the RESET key to reset the drive after a fault occurs. If you cannot reset after the fault: The condition which triggers the fault is not cleared. After you clear the condition, you can then reset the fault. The drive is in the fault status when powered on. After you clear the condition, restart and then you can reset the fault.
FWD REV	Operation Direction Key 1. Only controls the operation direction, NOT the drive activation. FWD: forward, REV: reverse. 2. Refer to the Descriptions of LED Functions on p.9-6 for more details.
ENTER	ENTER Key Goes to the next menu level. If at the last level, press ENTER to execute the command.
ESC	ESC Key Leaves the current menu and returns to the previous menu; also functions as a return key or cancel key in a sub-menu.

Chapter 9 Digital Keypad | VFD-ED


Key	Descriptions					
MENU	MENU key. Returns to the main menu. Menu items: 1. Parameter Setup 8. Time Setup 14. Main Page 5. Copy Parameter 9. Keypad Locked 15. PC Link 6. Fault Record 12. Display Setup 7. Language Setup 13. Start-up NOTE: Menu items that are not listed above are not supported in VFD-ED.					
< > ^ v	Direction: Left / Right / Up / Down 1. In the numeric value setting mode, moves the cursor and changes the numeric value. 2. In the menu / text selection mode, selects an item.					
F1 F4	Function Key The functions keys have defaults and can also be user-defined. The defaults for F1 and F4 work with the function list below. For example, F1 is the JOG function, and F4 is a quick setting key for adding / deleting user-defined parameters.					

Descriptions of LED Functions

Descriptions of LED Functions						
LED		Descriptions				
CTOP.	Steady ON: STOP indicator for the AC motor drive.					
STOP RESET	Blinking:	Blinking: the drive is in standby.				
	Steady OFF: the drive does not execute the "STOP" command.					
	Operation	n Direction LED				
FWD	1. Green	light: the drive is running forward.				
REV	2. Red lig	ght: the drive is running backward.				
	3. Flashii	ng light: the drive is changing direction.				
	5					
	RUN LED);				
	LED status	Condition / State				
		CANopen at initial				
	OFF	No LED				
		CANopen at pre-operation				
	Blinking	ON-200 200				
CANopen-	Dilliking	OFF ms ms				
"RUN"		CANopen at stop				
	Single	ON				
	flash	200 200 ms ms				
		OFF OFF				
		CANopen at operation status				
	ON	err <u>Can</u> run				



9-4 Digital Keypad KPC-CC01 Functions





NOTE:

- 1. Start-up screen can only display pictures, not animation.
- 2. When powered ON, it displays the start-up screen then the main screen. The main screen displays Delta's default setting F/H/A/U. You can set the display order with Pr.00-03 (Start-up Display). When you selected the U screen, use the left / right keys to switch between the items, and set the display order for the U screen with Pr.00-04 (Content of Multi-function Display).
- 3. VFD-ED only supports the following menu items:
 - 1. Parameter Setup
- 6. Fault Record
- 8. Time Setup
- 12. Display Setup
- 14. Main Page

- 5. Copy Parameter
- 7. Language Setup
- 9. Keypad Locked
- 13. Start-up
- 15. PC Link

Display Icon





- : present setting
- ▼ : Scroll down the page for more options

Press for more options

➤ : show complete sentence Press (<) > for complete information


Display item




MENU


6: Fault Record 11: Copy PLC 1: Parameter Setup 7: Language Setup 12: Display Setup 2: Quick Start 3: Application Selection List 8: Time Setup 13: Start-up Menu 9: Keypad Locked 14: Main Page 4: Changed List 5: Copy Parameter 10: PLC Function 15: PC Link 16: Start Wizard

1. Parameter Setup




5. Copy Parameter





Fault Record



drive, the previous fault records are not deleted. The new fault records of the new AC motor drive continue to be added to the KPC-CC01.

7. Language Setup



Use Up / Down keys to select the language, and then press ENTER.

The language setting option is displayed in the language of your choice. Language setting options:


- 1. English
- 3. Türkçe
- 2. 繁體中文
- 4. Русский

NOTE: VFD-ED only supports these four languages currently.

8. Time Setup




Use Left / Right keys to select Year, Month, Day, Hour, Minute or Second to change.




NOTE:


Limitation: The charging process for the keypad super capacitor finishes in about 6 minutes. When the digital keypad is removed, the time setting is saved for 7 days. After 7 days, you must reset the time.

9. Keypad Locked




12. Display Setup






13. Start-up



USB/RS-485 Communication Interface-IFD6530
Refer to Chapter 6 Optional Accessories for more details.


TPEditor
Download
TPEditor software at Delta website. Select TPEditor version 1.60 or above. Refer to the instructions for TPEditor in <15. PC Link> in this


14. Main Page



section.

15. PC Link







ОК Connecting KPC-CCO1 to a computer

Cancel

Run this program as an administrator


Change settings for all users






Other displays

When a fault occurs, the screen shows a fault or warning:






- 1. Press RESET key to reset the fault code. If there is no response, contact your local distributor or return the unit to the factory. To view the fault DC bus voltage, output current and output voltage, press MENU and then choose 6: Fault Record.
- 2. After resetting, if the screen returns to the main screen and shows no fault after you press ESC, the fault is cleared.
- 3. When the fault or warning message appears, the LED backlight blinks until the fault or warning is cleared.

Optional accessory: RJ45 Extension Lead for Digital Keypad

Part No.	Description
CBC-K3FT	RJ45 extension lead, 3 feet (approximately 0.9 m)
CBC-K5FT	RJ45 extension lead, 5 feet (approximately 1.5 m)
CBC-K7FT	RJ45 extension lead, 7 feet (approximately 2.1 m)
CBC-K10FT	RJ45 extension lead, 10 feet (approximately 3 m)
CBC-K16FT	RJ45 extension lead, 16 feet (approximately 4.9 m)

NOTE: If communication cables are required, buy non-shielded, 24 AWG, four-wire twisted pair, 100 ohms communication cables.

9-5 Digital Keypad KPC-CC01 Fault Codes and Descriptions



Fault Codes

Fault Codes			
LCD Display	Fault Name	Description	Corrective Actions
Fault FrEr kpd Flash Read Er	Flash memory read error (FrEr)	Keypad flash memory read error	Error in the keypad's flash memory. 1. Press RESET to clear the errors. 2. Check for any problem on Flash IC. 3. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your authorized local dealer for assistance.
Fault FsEr kpd Flash Save Er	Flash memory save error (FsEr)	Keypad flash memory save error	Error in the keypad's flash memory. 1. Press RESET to clear the errors. 2. Check for any problem on Flash IC. 3. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your authorized local dealer for assistance.
Fault FPEr kpd Flash Pr Er	Flash memory parameter error (FPEr)	Keypad flash memory parameter error	Error in the default parameters. It might be caused by a firmware update. 1. Press RESET to clear the errors. 2. Check for any problem on Flash IC. 3. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your authorized local dealer for assistance.
Fault VFDr Read VFD Info Er	Reading AC motor drive data error (VFDr)	Keypad error when reading AC motor drive data	 Keypad cannot read any data sent from the VFD. 1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45. 2. Press RESET to clear the errors. 3. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your authorized local dealer for assistance.
Fault CPUEr CPU Error	CPU error (CPUEr)	Keypad CPU error	A serious error in the keypad's CPU. 1. Check for any problem on CPU clock. 2. Check for any problem on Flash IC. 3. Check for any problem on RTC IC. 4. Verify that the communication quality of the RS-485 cable is good. 5. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your authorized local dealer for assistance.

Warning Codes

LCD Display	Warning Name	Description	Corrective Actions
Warning CE1 Comm. Error 1	Communication error 1 (CE1)	RS-485 Modbus illegal function code	Motor drive does not accept the communication command sent from the keypad. 1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45. 2. Press RESET on the keypad to clear errors. If none of the above solutions works, contact your local authorized dealer for assistance.
Warning CK1 Comm Command Er	Communication command error 1 (CK1)	Keypad communication data, illegal function code (Keypad auto- detect this error and display it)	Keypad does not accept the motor drive's communication command. 1. Remove the keypad and reconnect it. 2. Verify if the Baud rate = 19200 bps, and the Format = RTU8, N, 2 3. Verify if the keypad is properly connected to the motor drive on the communication contact by a communication cable such as RJ45. If none of the above solutions works, contact your local authorized dealer.
Warning CE2 Comm. Error 2	Communication error 2 (CE2)	RS-485 Modbus illegal data address	Motor drive does not accept the keypad's communication address. 1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45. 2. Press RESET to clear the errors. If none of the above solutions works, contact your local authorized dealer for assistance.
Warning CK2 Comm Address Er	Communication address error (CK2)	data, illegal data	Keypad does not accept the motor drive's communication command. 1. Remove the keypad and reconnect it. 2. Verify if the Baud rate = 19200 bps, and the Format = RTU8, N, 2 3. Verify if the keypad is properly connected to the motor drive on the communication contact by a communication cable such as RJ45. If none of the above solutions works, contact your local authorized dealer.
Warning CE3 Comm. Error 3	Communication error 3 (CE3)		Motor drive does not accept the communication data sent from the keypad. 1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45. 2. Press RESET to clear the errors. If none of the above solutions works, contact your local authorized dealer for assistance.

LCD Display	Warning Name	Description	Corrective Actions
АИТО Warning CK3 Comm Data Error	Communication data error (CK3)	Keypad communication data, illegal data value (Keypad auto-detect this error and display it)	Keypad does not accept the motor drive's communication command. 1. Remove the keypad and reconnect it. 2. Verify if the Baud rate = 19200 bps, and the Format = RTU8, N, 2 3. Verify if the keypad is properly connected to the motor drive on the communication contact by a communication cable such as RJ45. If none of the above solutions works, contact your local authorized dealer.
Warning CE4 Comm. Error 4	Communication error 4 (CE4)	RS-485 Modbus data is written to read-only address	Motor drive cannot process the communication command sent from the keypad. 1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45. 2. Press RESET to clear the errors. 3. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your local authorized dealer for assistance.
Аито Warning CK4 Comm Slave Error	Communication slave error (CK4)	Keypad communication data is written to read- only address (Keypad auto-detect this error and display it)	Keypad does not accept the motor drive's communication command. 1. Remove the keypad and reconnect it. 2. Verify if the Baud rate = 19200 bps, and the Format = RTU8, N, 2 3. Verify if the keypad is properly connected to the motor drive on the communication contact by a communication cable such as RJ45. If none of the above solutions works, contact your local authorized dealer.
Warning CE10 Comm. Error 10	Communication error 10 (CE10)	Modbus transmission time-Out	Motor drive does not respond to the communication command sent from the keypad. 1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45. 2. Press RESET to clear the errors. 3. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your local authorized dealer for assistance.
АИТО Warning CK10 KpdComm Time Out	Keypad communication time out (CK10)	Digital keypad transmission time-out (The keypad automatically detects and shown this warning)	Keypad does not accept the motor drive's communication command. 1. Remove the keypad and reconnect it. 2. Verify if the Baud rate = 19200 bps, and the Format = RTU8, N, 2 3. Verify if the keypad is properly connected to the motor drive on the communication contact by a communication cable such as RJ45. If none of the above solutions works, contact your local authorized dealer.


Chapter 9 Digital Keypad | VFD-ED

LCD Display	Warning Name	Description	Corrective Actions
Warning TPNO TP No Object	TP object is not defined (TPNO)	Object not supported by TPEditor	Keypad's TPEditor uses an unsupported object. 1. Verify that the TPEditor is not using an unsupported object or setting. Delete unsupported objects and unsupported settings. 2. Re-edit the object in the TPEditor, and then download it to the keypad. 3. Verify that the motor drive supports the TP functions. If the drive does not support TP function, the main page displays Default. If none of the above solutions works, contact your local authorized dealer for assistance.

NOTE: The warning code CExx only occurs when the communication problem is between the drive and the keypad. It has nothing to do with the drive and other devices. Note the warning code description to find the cause of the error if CExx appears.

File Copy Setting Fault Description

These faults occur when KPC-CC01 cannot perform the command after pressing the ENTER key in the copy function.



LCD Display	Fault Name	Description	Corrective Actions
001> P00-00 ERR1 Read Only	Read only (ERR1)	Parameter and file are read-only	The parameter / file is read-only and cannot be written to. 1. Verify the specification in the user manual. If this solution does not work, contact your local authorized dealer for assistance.
001> P00-00 ERR2 Write Fail	Write in error (ERR2)	Fail to write parameter and file	 An error occurred while writing to a parameter / file. 1. Check for any problem on the Flash IC. 2. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your local authorized dealer for assistance.
P00-00 ERR3 VFD Running	Drive operating (ERR3)	AC motor drive is in operating status	A setting cannot be changed while the motor drive is in operation. 1. Verify that the drive is not in operation. If this solution does not work, contact your local authorized dealer for assistance.
001> P00-00 ERR4 Pr Lock	Parameter locked (ERR4)	AC motor drive parameter is locked	A setting cannot be changed because a parameter is locked. 1. Check if the parameter is locked. If it is locked, unlock it and try to set the parameter again. If this solution does not work, contact your local authorized dealer for assistance.
P00-00 ERR5 Pr Changing	Parameter changing (ERR5)	AC motor drive parameter is changing	A setting cannot be changed because a parameter is being modified. 1. Check if the parameter is being modified. If it is not being modified, try to change that parameter again. If this solution does not work, contact your local authorized dealer for assistance.
P00-00 ERR6 Fault Code	Fault code (ERR6)	Fault code is not cleared	A setting cannot be changed because an error has occurred in the motor drive. 1. Check if any error occurred in the motor drive. If there is no error, try to change the setting again. If this solution does not work, contact your local authorized dealer for assistance.
P00-00 ERR7 Warning Code	Warning code (ERR7)	Warning code is not cleared	A setting cannot be changed because of a warning message given to the motor drive. 1. Check if there is a warning message given to the motor drive. If this solution does not work, contact your local authorized dealer for assistance.

Chapter 9 Digital Keypad | VFD-ED

LCD Display	Fault Name	Description	Corrective Actions
P00-00 ERR8 Type Mismatch	File type mismatch (ERR8)	File type mismatch	Data to be copied are not the correct type, so the setting cannot be changed. 1. Check if the products' serial numbers to be copied are in the same category. If they are in the same category, try to copy the setting again. If this solution does not work, contact your local authorized dealer for assistance.
P00-00 ERR9 Password Lock	Password locked (ERR9)	File is locked with password	A setting cannot be changed because some data are locked. 1. Check if the data are unlocked or able to be unlocked. If the data are unlocked, try to change the setting again. 2. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your local authorized dealer for assistance.
P00-00 ERR10 Password Fail	Password fail (ERR10)	File password mismatch	A setting cannot be changed because the password is incorrect. 1. Check if the password is correct. If the password is correct, try to change the setting again. 2. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your local authorized dealer for assistance.
P00-00 ERR11 Version Fail	Version fail (ERR11)	File version mismatch	A setting cannot be changed because the version of the data is incorrect. 1. Check if the version of the data matches the motor drive. If it matches, try to change the setting again. If none of the above solutions works, contact your local authorized dealer for assistance.
P00-00 ERR12 VFD Time Out	VFD Time out (ERR12)	AC motor drive copy function time-out	 A setting cannot be changed because the data copying time-out expired. 1. Try copying the data again. 2. Check if copying data is authorized. If it is authorized, try to copy the data again. 3. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your local authorized dealer for assistance.

NOTE: The content in this section only applies to KPC-CC01 keypad V1.01 and later versions.


9-6 TPEditor Installation

TPEditor can edit up to 256 HMI (Human-Machine Interface) pages with a total storage capacity of 256 KB. Each page can include 50 normal objects and 10 communication objects.


- 1. TPEditor: Setup & Basic Functions
 - (1) Run TPEditor version 1.60 or later by double-clicking the program icon.



(2) On the **File** menu, click **New**. In the New project dialog box, for **Set Device Type**, select **DELTA VFD-C Inverter**. For **TP Type**, select **VFD-C KeyPad**. For **File Name**, enter TPE0 and then click **OK**.




(3) The editor displays the Design window. On the **Edit** menu, click **Add** a **New Page**. You can also right-click on the TP page in the upper right corner of the Design window and click **Add** to add one more page(s) to edit.




(4) Edit the start-up screen.

(5) Add static text. Open a blank page (step 3), then on the toolbar click . Double-click the blank page to display the **Static Text Setting** dialog box, and then enter the static text.



(6) Add a static bitmap. Open a blank page (step 3), then on the toolbar, click page to display the **Static Bitmap Setting** dialog box where you can choose the bitmap.




You can only use images in the BMP format. Click the image and then click Open to show the image in the page.

(7) Add a geometric bitmap. There are 11 kinds of geometric bitmaps to choose. Open a new blank page (step 3), then on the toolbar click the geometric bitmap icon that you need.

In the page, drag the geometric bitmap and enlarge it to the size that you need.


(8) When you finish editing the start-up screen, on the **Communication** menu, click **Input User Defined Keypad Starting Screen**.




- (9) Download the new setting: On the **Tool** menu, click **Communication**. Set up the communication port and speed for the IFD6530. There are three speeds available: 9600 bps, 19200 bps, and 38400 bps.
- (10) On the Communication menu, click Input User Defined Keypad Starting Screen.



(11) The Editor displays a message asking you to confirm the new setting. Before you click **OK**, on the keypad, go to MENU, select PC LINK, press ENTER and then wait for few seconds. Then click **YES** in the confirmation dialog box to start downloading.



- 2. Edit the Main Page and Download to the Keypad
 - (1) In the Editor, add a page to edit. On the Edit menu, click Add a New Page. You can also right-click on the TP page in the upper right corner of the Design window and click Add to add one more page to edit. This keypad currently supports up to 256 pages.




(2) In the bottom right-hand corner of the Editor, click the page number to edit, or on the **View** menu, click **HMI Page** to start editing the main page. As shown in the picture above, the following objects are available.


From left to right they are: Static Text, ASCII Display, Static Bitmap, Scale, Bar Graph, Button, Clock Display, Multi-state bit map, Units, Numeric Input, the 11 geometric bitmaps, and lines of different widths. Use the same steps to add Static Text, Static Bitmap, and geometric bitmaps as for the start-up page.




(3) Add a numeric/ASCII display. On the toolbar, click the **Numeric/ASCII** button. In the page, double-click the object to specify the **Refer Device**, **Frame Setting**, **Font Setting** and **Alignment**.



Click [...]. In the **Refer Device** dialog box, choose the VFD communication port that you need. If you want to read the output frequency (H), set the **Absolute Addr.** to 2202. For other values, refer to Appendix B-4 ACMD Modbus Comm Address List in this user manual.




(4) Scale Setting. On the toolbar, click to add a scale. You can also edit the Scale Setting in the Property Window on the right-hand side of your computer screen.




- A. Scale Position: specifies where to place the scale.
- B. **Scale Side**: specifies whether the scale is numbered from smaller numbers to larger numbers or from larger to smaller.
- C. Font Setting: specifies the font.
- D. Value Length: specifies 16 bits or 32 bits.
- E. **Main Scale &** Sub-**Scale**: divides the whole scale into equal parts; enter the numbers for the main scale and sub-scale.
- F. **Max Value &** Min **Value**: specifies the numbers on the two ends of the scale. They can be negative numbers, but the maximum and minimum values are limited by the **Value Length** setting. For example, when **Value Length** is **hexadecimal** (**16 bits**), the maximum and the minimum value cannot be entered as -40000.


Clicking **OK** creates a scale as in the picture below.



(5) Bar Graph setting. On the toolbar, click to add a bar graph.



- A. Refer Device: specifies the VFD communication port.
- B. Direction Setting: specifies the direction: From Bottom to Top, From Top to Bottom, From Left to Right or From Right to Left.
- C. Value Length: determines the range of the maximum value and minimum value.
- D. **Max Value** and **Min Value**: specifies the maximum value and minimum value. A value smaller than or equal to the minimum value causes the bar graph to be blank (0). A value is bigger or equal to the maximum value causes the bar graph is full (100%). A value between the minimum and maximum values causes the bar graph to be filled proportionally.
- (6) Button : on the toolbar, click . Currently this function only allows the keypad to switch pages; other functions are not yet available (including text input and insert image). In the blank page, double-click to open the Button Setting dialog box.



Button Type: specifies the button's functions.

Page Jump and Constant Setting are the only functions currently supported.

A. Page Jump Setting

- Page Jump Setting: in the Button Type list, choose Page Jump to show the Page Jump
 Setting.
- b. Function Key: specifies the functions for the following keys on the KPC-CC01 keypad: F1, F2, F3, F4, Up, Down, Left and Right. Note that the Up and Down keys are locked by TPEditor. You cannot program these two keys. If you want to program Up and Down keys, on the Tool menu, click Function Key Setting, and then click Re-Define Up/Down Key.




c. **Button Text**: specifies the text that appears on a button. For example, when you enter Next Page for the button text, that text appears on the button.


B. Constant Setting

This function specifies the memory address' values for the VFD or PLC. When you press the **Function Key**, it writes a value to the memory address specified by the value for **Constant Setting**. You can use this function to initialize a variable.





(8) Multi-state bitmap: on the toolbar, click Open a new page and click once in that window to add a Multi-state bitmap. This object reads a bit's property value from the PLC. It defines the image or text that appears when this bit is 0 or 1. Set the initial status (**Current State**) to be 0 or 1 to define the displayed image or text.




(9) Unit Measurement: on the toolbar, click




Open a new blank page, and double-click on that window to display the **Units Setting** dialog box. Choose the Metrology Type and the Unit Name. For Metrology, the choices are Length, Square Measure, Volume/Solid Measure, Weight, Speed, Time, and Temperature. The unit name changes automatically when you change metrology type.



(10) Numeric Input Setting: on the toolbar, click



₹



- A. **Refer Device**: **specifies** the **Write** and the **Read** values. Enter the numbers to display and the **corresponding** parameter and communication port numbers. For example, enter 012C to Read and Write Parameter Pr.01-44.
- B. OutLine Setting: specifies the Frame Setting, Font Setting, Hori. Alignment, and Vert.


 Alignment for the outline.
- C. **Function Key**: **specifies** the function key to program on the keypad in the **Function Key** box. The corresponding key on the keypad starts to blink. Press ENTER to confirm the setting.
- D. Value Type and Value Length: specify the range of the Min Value and Max Value for the Limit Setting. Note that the corresponding supporting values for VFD-ED must be 16 bits. 32-bit values are not supported.
- E. Value Setting: automatically set by the keypad itself.
- F. Limit Setting: specifies the range for the numeric input here.


For example, if you set **Function Key** to **F1**, **Min Value** to 0 and **Max Value** to 4, when you press F1 on the keypad, then you can press Up/Down on the keypad to increase or decrease the value. Press


ENTER on the keypad to confirm your setting. You can also view the parameter table 01-44 to verify if you correctly entered the value.


(11) Download TP Page: Press Up / Down on the keypad to select PC Link menu item.

Then press ENTER on the keypad. The screen displays "Waiting". In TPEditor, choose a page that you have created, and then on the **Communication** menu click **Write to TP** to start downloading the page to the keypad. Then, the keypad displays "Receiving". When you see "Completed" on the keypad screen, the download is finished. You can then press ESC on the keypad to go back to the menu screen.









[This page intentionally left blank]

Chapter 10 Auto-tuning Process

- 10-1 Tuning in Easy Steps for IM
- 10-2 Tuning in Easy Steps for PM
- 10-3 Descriptions of Tuning Steps
- 10-4 Elevator Performance Fine-tuning

10-1 Tuning in Easy Steps for IM

1. Basic Parameter Settings

Pr.00-02 Parameter Reset

Pr.00-14 Master Frequency Command Source

Pr.00-15 Operation Command Source

Pr.02-01-Pr.02-08 Multi-function Input Settings

Pr.02-11-Pr.02-16 Multi-function Output Settings

2. Encoder Settings

Pr.10-00 Selection of Encoder

Pr.10-01 Encoder PPR

Pr.10-02 Encoder Input Type Setting

3. Motor Auto-tuning

(1) Motor Settings

Pr.00-09 Control Mode

Pr.01-00 Maximum Output Frequency

Pr.01-01 Motor's Rated Frequency

Pr.01-02 Motor's Rated Voltage

(2) Settings for Induction Motor (IM)

Pr.05-01 Motor Rated Current

Pr.05-02 Motor Rated Power

Pr.05-03 Motor Rated Speed

Pr.05-04 Number of Motor Poles

Pr.05-00 Motor Auto-tuning

4. Multi-step Speed Settings

Pr.04-00-Pr.04-15 Multi-step Speed Setting

Pr.01-12-Pr.01-19 Acceleration / Deceleration Time Setting

Pr.01-24-Pr.01-27. Pr.01-29, Pr.01-30 S-curve for Acceleration and Deceleration Time Settings

5. Elevator Related Parameters

Pr.11-01 Elevator Speed

Pr.11-02 Traction Sheave Diameter

Pr.11-03 Gear Ratio

Pr.11-04 Suspension Ratio

Pr.11-14 Motor Current at Acceleration

Pr.11-05 Mechanical Inertial Ratio

6. Trial Run

7. Elevator Performance Fine-tuning

10-2 Tuning in Easy Steps for PM

1. Basic Parameter Settings

Pr.00-02 Parameter Reset

Pr.00-14 Master Frequency Command Source

Pr.00-15 Operation Command Source

Pr.02-01-Pr.02-08 Multi-function Input Settings

Pr.02-11-Pr.02-16 Multi-function Output Settings

2. Encoder Settings

Pr.10-00 Selection of Encoder

Pr.10-01 Encoder PPR

Pr.10-02 Encoder Input Type Setting

3. Motor Auto-tuning

(1) Motor Settings

Pr.00-09 Control Mode

Pr.01-00 Maximum Output Frequency

Pr.01-01 Motor's Rated Frequency

Pr.01-02 Motor's Rated Voltage

(2) Settings for Permanent Magnet Synchronous Motor (PM)

Pr.08-01 Motor Rated Current

Pr.08-02 Motor Rated Power

Pr.08-03 Motor Rated Speed

Pr.08-04 Number of Motor Poles

Pr.11-00 System Control

Pr.08-00 Motor Auto-tuning

4. Multi-step Speed Settings

Pr.04-00-Pr.04-15 Multi-step Speed Setting

Pr.01-12-Pr.01-19 Acceleration / Deceleration Time Setting

Pr.01-24-Pr.01-27. Pr.01-29, Pr.01-30 S-curve for Acceleration and Deceleration Time Settings

5. Elevator Related Parameters

Pr.11-01 Elevator Speed

Pr.11-02 Traction Sheave Diameter

Pr.11-03 Gear Ratio

Pr.11-04 Suspension Ratio

Pr.11-14 Motor Current at Acceleration

Pr.11-05 Mechanical Inertial Ratio


6. Trial Run

7. Elevator Performance Fine-tuning

10-3 Descriptions of Tuning Steps

10-3-1 Basic Parameter Settings

Pr.00-02 Parameter Reset



password, enter the password to reset to the default. The password is also erased.

Pr.00-14 Master Frequency Command Source



- Setting values:
 - 1: RS-485 serial communication or digital keypad (KPC-CC01)
 - 2: External analog input (See Pr.03-00)
 - 3: Digital terminal inputs
 - 4: Direct docking mode only, contact Delta for more information.
- Determines the drive's master frequency source.

Pr.00-15 Operation Command Source





- Setting values:
 - 1: External terminals (work with controller)
 - 2: RS-485 serial communication or digital keypad (KPC-CC01) (does not work with controller)

Pr.02-01-Pr.02-08 Multi-function Input Settings




- The default value of Pr.02-08 is 40 (Enable Drive). If you do not need this function (does not work with controller), set the setting value to 0.
- Setting value:
 - 0: No function
 - 1: Multi-step speed command 1
 - 2: Multi-step speed command 2
 - 3: Multi-step speed command 3
 - 4: Multi-step speed command 4
 - 5: Reset
 - 6: JOG command
 - 7: Acceleration/deceleration speed inhibit
 - 8: First, second acceleration/deceleration time
 - 9: Third, fourth acceleration/deceleration time
 - 10: EF input (Pr.07-28)
 - 11: Reserved
 - 12: Stop output
 - 13-14: Reserved
 - 15: AUI1 operation speed command
 - 16: Reserved
 - 17: AUI2 operation speed command
 - 18: Emergency Stop (Pr.07-28)
 - 19-23: Reserved
 - 24: FWD JOG Command
 - 25: REV JOG Command

Chapter 10 Auto-tuning Process | VFD-ED

- 26: Reserved
- 27: ASR1/ASR2 selection
- 28: Emergency stop (EF1) (motor coasts to stop)
- 29-30: Reserved
- 31: High torque bias (according to Pr.07-21)
- 32: Middle torque bias (according to Pr.07-22)
- 33: Low torque bias (according to Pr.07-23)
- 34-37: Reserved
- 38: Disable writing to EEPROM
- 39: Torque command direction (0 is positive direction)
- 40: Enable drive function
- 41: Magnetic contactor detection
- 42: Mechanical brake 1
- 43: EPS function (Emergency Power System)
- 44: Mechanical brake 2
- 45-51: Direct docking mode only
- 53: Terminal leveling signal for direct docking
- 54: Power failure signal
- 55: Manual emergency deceleration
- 56: Automatic emergency deceleration
- 57: Brake torque test action signal
- 59: AFE fault

Pr.02-11-Pr.02-16 Multi-function Output Settings




- Setting value:
 - 0: No function
 - 1: Indication during operation
 - 2: Operation speed reached
 - 3: Desired frequency 1 reached (Pr.02-25, Pr.02-26)
 - 4: Desired frequency 2 reached (Pr.02-27, Pr.02-28)
 - 5: Zero Speed (Frequency command)
 - 6: Zero speed with stop (Frequency command)
 - 7: Over-torque (OT1) (Pr.06-05–Pr.06-07)
 - 8: Over-torque (OT2) (Pr.06-08-Pr.06-10)
 - 9: Drive is ready

- 10: User-defined low-voltage detection (LV)
- 11: Malfunction indication
- 12: Mechanical brake release (Pr.02-29, Pr.02-30, Pr.02-37)
- 13: Overheat (Pr.06-14)
- 14: Brake transistor signal
- 15: Motor-controlled magnetic contactor output
- 16: Slip error (oSL)
- 17: Malfunction indication 1
- 18: Reserved
- 19: Brake transistor output error
- 20: Warning output
- 21: Over-voltage warning
- 22: Over-current stall prevention warning
- 23: Over-voltage stall prevention warning
- 24: Operation mode indication (Pr.00-15=1)
- 25: Forward command
- 26: Reverse command
- 27: Output when current ≥ Pr.02-33
- 28: Output when current < Pr.02-33
- 29: Output when frequency ≥ Pr.02-34
- 30: Output when frequency < Pr.02-34
- 31: Power generation direction and status verification
- 32: Power generation direction
- 33: Zero speed (actual output frequency)
- 34: Zero speed with Stop (actual output frequency)
- 35: Fault output option 1 (Pr.06-22)
- 36: Fault output option 2 (Pr.06-23)
- 37: Fault output option 3 (Pr.06-24)
- 38: Fault output option 4 (Pr.06-25)
- 39: Reserved
- 40: Speed reached (including zero speed)
- 41: Reserved
- 42: STO Output Error
- 43-44: Direct Docking Mode only
- 45: Reserved
- 46: Retrying after a fault has occurred indication
- 47: Direct Docking Mode only
- 48: Control output of MPSCC (Motor Phase Short Circuit Contactor)
- 49: Emergency power mode action
- 50: Speed reached Pr.02-34
- 51: Brake torque test finished
- 52: AFE reset

10-3-2 Encoder Settings

Speed feedback card selections: See Chapter 7 Speed Feedback Card Selection. Delta provides three types of PG cards, including EMED-PGABD-2, EMED-PGHSD-3, and EMED-PGHSD-4.

Pr.10-00 Selection of Encoder




- When you set Pr.10-02 to 3, 4 or 5, you can set Pr.10-00 only to 0, 1 or 2, and you cannot use 3, 4, 5 and 6.
- When you set Pr.10-00 to 3, the encoder has one sine and one cosine signal for each revolution. The signal must be: 0.75–1.2 Vpp for the amplitude with phase angle 90°±5 elec. (E.g. ERN 1185 ERN 1387)
- When you set Pr.10-00 to 4 or 6, wait for two seconds after applying the power before executing the RUN command.
- When you set Pr.10-00 to 5, you must set Pr.08-09 to 360.
- Detection of the magnetic pole:
 - (1) 1 or 5: The AC motor drive outputs a short circuit to detect the position of the magnetic pole. At this moment, the motor generates a little noise.
 - (2) 2: The AC motor drive detects the position of the magnetic pole with the UVW encoder signal.
 - (3) 3: The AC motor drive detects the position of the magnetic pole with the sine encoder signal.
 - (4) 4 or 6: The AC motor drive detects the position of the magnetic pole with the communication encoder signal.
- The table below shows the correspondence among encoder, PG card and auto-tuning


PG Signal Type Setting	PG Signal Type	Applicable PG Card x=2, 3,	Pr.08-00=1	Pr.08-00=3
Pr.10-00=1	A, B, Z	EMED-PGAB/ABD-x	N/A	N/A
Pr.10-00=2	A, B, Z+U, V, W	EMED-PGABD- x	Rolling test*1	Rolling test*1
Pr.10-00=3	SIN/COS + Sinusoidal (e.g. ERN1185, ERN1387)	EMED-PGHSD-x	Rolling test* ¹	Pr.11-00 Bit9=0: Rolling test*1 Pr.11-00 Bit9=1: Static test*1
Pr.10-00=4	SIN/COS + Endat 2.1 (e.g. ECN1313, ECN413)	EMED-PGSD-x	Dynamic test* ¹	Static test*1
Pr.10-00=5	SIN/COS	EMED-PGHSD-x	N/A	N/A
Pr.10-00=6	SIN/COS + Hiperface (e.g. SRS50/60)	EMED-PGHSD-x	Dynamic test* ¹	Static test*1

^{*1} Static: Brake engaged, no motor running. Dynamic: Brake released, motor rotates less than one revolution. Rolling: Brake released, motor rotates more than one revolution.

Pr.10-01 Encoder PPR




Pr.10-02 Encoder Input Type Setting



- When you set Pr.10-00 to 3, 4, 5 or 6, you can set Pr.10-02 only to 0, 1 or 2, and you cannot use 3, 4 and 5.
- 2 You must enter the correct pulse type for stable control.
- It is suggested that you set Pr.10-02 to 1 first. When fault code PGF1 occurs or the motor does not run, set it to 2.

10-3-3 Motor Auto-tuning 10-3-3-1 Motor Settings

Pr.00-09 Control Mode




Mode selection:


Settings	Control Mode	Applicable Motor Type	Speed Feedback	Energy- savings	Tuning Difficulty	Ride Comfort	Speed Control Range	Motor Parameter Tuning	Basic Control	Speed Control
0	V/F	IM		Low	Low	Normal	1:50		V/F control	Voltage control
1	VFPG	IM	✓	Medium	Medium	Normal	1:50	✓	Frequency control	Frequency control
2	SVC	IM		Medium	Medium	Normal	1:50	✓	Voltage control	Voltage control
3	FOCPG	IM	✓	High	High	Good	1:1000	✓	Vector control	Frequency control
8	FOCPM	PM	✓	High	High	Good	1:1000	✓	Vector control	Frequency control

- Determines the AC motor drive control method.
 - 0: You can set the V/F ratio as required and control multiple motors simultaneously.
 - 1: You can use a PG card with an Encoder for close-loop speed control.
 - 2: Use auto-tuning for optimal settings of the control parameters.
 - 3: To increase torque and the accuracy of the speed control (1:1000).
 - 8: To increase torque and the accuracy of the speed control (1:1000). This setting is for use only with permanent magnet motors. The other settings are for use with induction motors.

Pr.01-00 Maximum Output Frequency




Pr.01-01 Motor's Rated Frequency



Set this parameter according to the rated frequency on the motor nameplate. If the motor is 60 Hz, set this parameter to 60. If the motor is 50 Hz, set it to 50.


Pr.01-02 Motor's Rated Voltage




Set this parameter according to the rated voltage on the motor nameplate. If the motor is 220 V, set this parameter to 220.0. If the motor is 200 V, set this parameter to 200.0.

10-3-3-2 Settings for Induction Motor (IM)


Pr.05-01 Motor Rated Current




Pr.05-02 Motor Rated Power



Pr.05-03 Motor Rated Speed



Pr.05-04 Number of Motor Poles




Pr.05-00 Motor Auto-tuning



- Position the elevator near the middle floors before auto-tuning.
- Motor auto-tuning:

Set Pr.05-00 to 1 or 2, and then press the RUN key on the digital keypad KPC-CC01 (Pr.00-15=2) to start auto-tuning. Or when the drive is in manual mode (inspection), run the upward operation or downward operation (Pr.00-15=1) to start auto-tuning immediately. In the process of auto-tuning, an "Auto tuning" warning continuously displays on the digital keypad until it is finished.

- Pay attention to the following notes when Pr.05-00=1 (dynamic test):
 - 1. Make sure that all the drive parameters are set to defaults and the motor wiring is correct.
 - 2. Make sure the motor is not loaded before auto-tuning, and that the shaft is not connected to any belt or gear motor. Set this parameter to 2 if you cannot separate the motor from the load.
 - 3. Enter the correct values for Pr.01-01, Pr.01-02, Pr.05-01, Pr.05-02, Pr.05-03 and Pr.05-04. Refer to motor capacity to set the acceleration/deceleration time.
 - 4. After auto-tuning is finished, check if Pr.05-05–Pr.05-09 all have values.
 - 5. Equivalent circuit diagram:




NOTE:


- In torque/vector control mode, do not run motors in parallel.
- Do not use torque/vector control mode if the motor rated power exceeds the rated power for the AC motor drive.
- The no-load current is usually 20–50% of the rated current.
- The rated speed cannot be larger or equal to 120 f/p (f: output frequency Pr.01-01, p: Number of Motor Poles Pr.05-04).
- After auto-tuning is finished, activate the drive again to make it operate when the auto-tuning command source is the external terminal.

10-3-3-3 Settings for Permanent Magnet Synchronous Motor (PM)


Pr.08-01 Motor Rated Current



Pr.08-02 Motor Rated Power




Pr.08-03 Motor Rated Speed




Chapter 10 Auto-tuning Process | VFD-ED

Pr.08-04 Number of Motor Poles




Pr.11-00 System Control




function is valid only when the mechanical brake is in engaged status.

Motor auto-tuning:



Set Pr.08-00 to 1 to 3, and then press the RUN key on the digital keypad KPC-CC01 (Pr.00-15=2) to start auto-tuning. Or when the drive is in manual mode (inspection), run the upward operation or downward operation (Pr.00-15=1) to start auto-tuning immediately. In the




- Pr.08-00=2: Motor auto-tuning is static test:
 - 1. Make sure that all the drive parameters are set to defaults and the motor wiring is correct.
 - 2. Enter the correct values for Pr.01-01, Pr.01-02, Pr.08-01, Pr.08-02, Pr.08-03 and Pr.08-04. Refer to motor capacity to set the acceleration/deceleration time.
 - 3. Note that the motor will run! The shaft needs to be locked by an external force.
 - 4. After auto-tuning is finished, check if Pr.08-05, Pr.08-07, and Pr.08-08 all have values.
- Pr.08-00=1: Auto-measures the angle between the magnetic pole and the PG origin. Pay attention to the following notes when measuring: (dynamic test)
 - 1. Unload before auto-tuning.
 - 2. If the drive controls the brake, the drive can auto-tune according to the normal sequence after you complete the wiring and set the brake control parameters.
 - 3. If the host controller controls the brake, make sure that the brake is in release status before auto-tuning.
- Pr.08-00=3: Auto-measures the angle between the magnetic pole and the PG origin. Pay attention to the following notes when measuring: (static test)
 - 1. The motor can be loaded or unloaded before auto-tuning.
 - 2. See the reference table for auto-tuning for Pr.10-00 (PG Signal Type).
 - 3. If the drive controls the brake, the drive can auto-tune according to the normal sequence after you complete the wiring and set the brake control parameters.
 - 4. If the host controller controls the brake, make sure that the brake is in release status before auto-tuning.
 - 5. Make sure the setting for Pr.10-02 is correct. Incorrectly setting Pr.10-02 causes incorrect positioning of the magnetic pole and results in the wrong angle between the magnetic pole and PG origin.

NOTE:


- The entered rated speed cannot be larger than or equal to 120 f/p.
- Note that if the contactor and brake are not controlled by the AC motor drive, release it manually.
- Set Pr.08-00 to 1 (unloaded motor) for accurate calculation. If you need to execute this function with a loaded motor, balance the carriage before execution.
- If you do not balance the carriage in a measured environment, you can execute this function with a loaded motor by setting Pr.08-00= 3. It will have a difference of 15–300 for different encoder types.
- "Auto Tuning Err" displays on the digital keypad when stopping due to an AC motor drive fault or human error, which means the detection fails. Check the wiring connections of the AC motor drive If "PG Fbk Error" displays on the digital keypad, change the setting of Pr.10-02 (if set to 1, change it to 2). If "PG Fbk Loss" displays on the digital keypad, check the feedback of Z-phase pulse.

10-3-4 Multi-step Speed Settings

Pr.04-00-Pr.04-15 Multi-step Speed Setting




 \square When Pr.00-14 = 3, the master frequency is Pr.04-00.




Multi-speed via External Terminals

Pr.01-12-Pr.01-19 Acceleration / Deceleration Time Setting





- The Acceleration Time determines the time required for the AC motor drive to ramp from 0.00 Hz to the Maximum Output Frequency (Pr.01-00). The Deceleration Time determines the time required for the AC motor drive to decelerate from the Maximum Output Frequency (Pr.01-00) down to 0.00 Hz.
- Select the Acceleration/Deceleration Time 1, 2, 3, 4 with the multi-function input terminal settings. The defaults are Acceleration Time 1 and Deceleration Time 1.
- When there is a large opposing torque and inertial torque for the load, and the acceleration and deceleration time settings are less than the necessary value, then they enable the torque limit and stall prevention functions. When this happens, the actual acceleration and deceleration time are longer than the settings.



Acceleration & Decelertion Time Setting


Pr.01-24-Pr.01-27. Pr.01-29, Pr.01-30 S-curve for Acceleration and Deceleration Time Settings






10-3-5 Elevator Related Parameters


Pr.11-01 Elevator Speed



Pr.11-02 Traction Sheave Diameter




Pr.11-03 Gear Ratio




Chapter 10 Auto-tuning Process | VFD-ED


Pr.11-04 Suspension Ratio



Pr.11-14 Motor Current at Acceleration



Pr.11-05 Mechanical Inertial Ratio



You can calculate the load inertia according to the settings of motor parameters, Pr.11-01 to Pr.11-04 and Pr.11-14 Motor Current at Acceleration and Pr.11-15 Carriage Acceleration. You can use this parameter to adjust the mechanical inertia ratio.

Mechanical inertia reference value (%):


Load / Motor	IM	PM
Without load	40	10
With load	80–120	40

10-3-6 Trial Run

Test method:

- 1. Position the elevator near the middle floors.
- 2. Enter the correct values for Pr.00-14 and Pr.00-15.
- 3. Use the upward / downward operation of the inspection mode to execute the trial run.

10-4 Elevator Performance Fine-tuning



Stage	Function	Pr.	Control Mode	Description	Settings	Default
		05-13	svc	Slip Compensation Gain	0.00–10.00	1.00
	Slip Compen- sation	05-23	VF, SVC	Slip Compensation Gain % (Power Generation Mode)	0.0–100.0%	0.0
		05-24	VF, SVC	Slip Compensation Gain % (Electricity Mode)	0.0–100.0%	0.0
IIA	System Control	11-00	FOCPG, FOCPM	System Control	Bit 0=1: ASR auto-tuning; PDFF enabled (Pr.11-06–11-08, Pr.11-19) Bit 7=1: Zero speed position control is enabled (Pr.10-19, Pr.10-22–10-24)	0000h
	Comfort	11-05	FOCPG, FOCPM	Mechanical Inertial Ratio	1–300%	40
50	Delay Time	02-31	VF, VFPG, SVC, FOCPG, FOCPM	Magnetic Contactor Contracting Delay Time between Drive and Motor	0.010–65.000 sec.	0.200
Starting		02-29	VF, VFPG, SVC, FOCPG, FOCPM	Brake Release Delay Time when Elevator Starts	0.000–65.000 sec.	0.250
	Start-up Adjustment	01-08	VF, VFPG, SVC	Fourth Output Voltage Setting	230V models: 0.1–255.0 V 460V models: 0.1–510.0 V	5.0 10.0

Stage	Function	Pr.	Control Mode	Description	Settings	Default
	Comfort	11-06	FOCPG, FOCPM	Zero Speed Bandwidth	1–40 Hz	10
	Torque Check	02-33	VF, VFPG, SVC, FOCPG, FOCPM	External Terminal Output Current Level	0–100% (motor drive rated current)	0
	Crieck	02-37	VF, VFPG, SVC, FOCPG, FOCPM	Torque Check	0: Disable 1: Enable	0
		07-02	VF, VFPG, SVC	DC Brake Current Level at Start-up	0–100% (motor drive rated current)	0
		07-03	VF, VFPG, SVC, FOCPG, FOCPM	DC Brake Activation Time	0.0-60.0 sec.	0.7
		10-19	FOCPM	Zero Speed Position Control Gain (P)	0.00–655.00%	80.00
	Rollback	10-22	FOCPM	Zero Speed Position Control Holding Time	0.001–65.535 sec.	0.250
		10-24	FOCPM	Zero Speed Position Control Activation Mode Selection	0: After the brake release set in Pr.02-29 1: After the brake signal input (Pr.02-01–Pr.02-08 is set to 42)	0
		01-12	VF, VFPG, SVC, FOCPG, FOCPM	Accel. Time 1	0.00-600.00 sec.	3.00
	Multi-step Speed	01-24	VF, VFPG, SVC, FOCPG, FOCPM	S-curve for Acceleration Begin Time S1	0.00–25.00 sec.	1.00
rating		01-25	VF, VFPG, SVC, FOCPG, FOCPM	S-curve for Acceleration Arrival Time S2	0.00–25.00 sec.	1.00
Accelerating		01-04	VF, VFPG	Second Output Voltage Setting	230V models: 0.1–255.0 V 460V models: 0.1–510.0 V	5.0 10.0
		01-06	VF, VFPG	Third Output Voltage Setting	230V models: 0.1–255.0 V 460V models: 0.1–510.0 V	5.0 10.0
	Comfort	11-07	FOCPG, FOCPM	Low Speed Bandwidth	1–40 Hz	10
		11-08	FOCPG, FOCPM	High Speed Bandwidth	1–40 Hz	10
peed		11-08	FOCPG, FOCPM	High Speed Bandwidth	1–40 Hz	10
High Speed	Comfort	11-09	FOCPG, FOCPM	PDFF Gain Value	0–200%	30

Stage	Function	Pr.	Control Mode	Description	Settings	Default	
		01-13	VF, VFPG, SVC, FOCPG, FOCPM	Decel. Time 1	0.00-600.00 sec.	2.00	
	Multi-step Speed	01-26	VF, VFPG, SVC, FOCPG, FOCPM	S-curve for Deceleration Begin Time S3	0.00-25.00 sec.	1.00	
Decelerating		01-27	VF, VFPG, SVC, FOCPG, FOCPM	S-curve for Deceleration Arrival Time S4	0.00-25.00 sec.	1.00	
Decele		01-04	VF, VFPG	Second Output Voltage Setting	230V models: 0.1–255.0 V 460V models: 0.1–510.0 V	5.0 10.0	
		01-06	VF, VFPG	Third Output Voltage Setting	230V models: 0.1–255.0 V 460V models: 0.1–510.0 V	5.0 10.0	
	Comfort	Comfort	11-07	FOCPG, FOCPM	Low Speed Bandwidth	1–40 Hz	10
		11-08	FOCPG, FOCPM	High Speed Bandwidth	1–40 Hz	10	
Leveling	Comfort	11-07	FOCPG, FOCPM	Low Speed Bandwidth	1–40 Hz	10	
	Delay Time	02-30	VF, VFPG, SVC, FOCPG, FOCPM	Brake Engage Delay Time when Elevator Stops	0.000–65.000 sec.	0.250	
		Delay Time	02-32	VF, VFPG, SVC, FOCPG, FOCPM	Magnetic Contactor Release Delay Time between Drive and Motor	0.010–65.000 sec.	0.200
		01-29	VF, VFPG, SVC, FOCPG, FOCPM	Switch Frequency for S3/S4 Changes to S5	0.00–299.00Hz	0.00	
Stopping	Elevator Parking	01-30	VF, VFPG, SVC, FOCPG, FOCPM	S-curve for Deceleration Arrival Time S5	0.00-25.00 sec.	1.00	
St		01-31	VF, VFPG, SVC, FOCPG, FOCPM	Deceleration Time when Operating without RUN Command	0.00-600.00 sec.	2.00	
	Comfort	07-29	FOCPG, FOCPM	Time for Decreasing Torque at Stop	0.000-5.000 sec.	0.000	
	Somore	11-19	FOCPG, FOCPM	Zero Speed Parking Bandwidth	1–40 Hz	10	
	Torque Check	02-33	VF, VFPG, SVC, FOCPG, FOCPM	External Terminal Output Current Level	0–100% (motor drive rated current)	0	

Chapter 10 Auto-tuning Process | VFD-ED

Stage	Function	Pr.	Control Mode	Description	Settings	Default
		02-37	VF, VFPG, SVC, FOCPG, FOCPM	Torque Check	0: Disable 1: Enable	0
		07-30	VF, VFPG, SVC	DC Brake Current Level at Stop	0–100% (motor drive rated current)	0
	DC Brake		VF, VFPG, SVC, FOCPG, FOCPM	DC Brake Stopping Time	0.0-60.0 sec.	0.7

[This page intentionally left blank]

Chapter 11 Summary of Parameter Settings

- 00 Drive Parameters
- 01 Basic Parameters
- 02 Digital Input / Output Parameters
- 03 Analog Input / Output Parameters
- 04 Multi-step Speed Parameters
- 05 IM Parameters
- 06 Protection Parameters
- 07 Special Parameters
- 08 PM Parameters
- 09 Communication Parameters
- 10 Feedback Control Parameters
- 11 Advanced Parameters
- 12 User-defined Parameters
- 13 View User-defined Parameters

Chapter 11 Summary of Parameter Settings | VFD-ED

This chapter provides a summary of parameter settings including the ranges and defaults that help you set the parameters. You can set, change, and reset the parameters using the digital keypad.

NOTE:

- 1. **★**: Indicates a parameter that you can set during operation.
- 2. For details on parameters, refer to Chapter 12 Descriptions of Parameter Settings.
- 3. indicates that the parameters or the setting values only apply on the Direct Docking Mode. The actual functions of each elevator controller vary from one to another. For more information, please contact Delta.
- 4. The parameters described in this user manual are designed for multi-step speed mode. The defaults for direct docking mode are different from the defaults described in this user manual. If you need to use the direct docking mode, contact Delta for more information.
- 5. The following are abbreviations of different types of motors:
 - IM: Induction motor
 - PM: Permanent magnet synchronous AC motor

00 Drive Parameters

Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
00-00	AC Motor Drive Identity Code	108: 220 V, 2.2 kW, 3 HP (single-phase) 110: 220 V, 3.7 kW, 5 HP (single-phase) 10: 230V, 4.0 kW, 5 HP 11: 460V, 4.0 kW, 5 HP 12: 230V, 5.5 kW, 7.5 HP 13: 460V, 5.5 kW, 7.5 HP 14: 230V, 7.5 kW, 10 HP 15: 460V, 7.5 kW, 10 HP 16: 230V, 11 kW, 15 HP 17: 460V, 11 kW, 15 HP 18: 230V, 15 kW, 20 HP 19: 460V, 15 kW, 20 HP 20: 230V, 18.5 kW, 25 HP 21: 460V, 18.5 kW, 25 HP 22: 230V, 22 kW, 30 HP 23: 460V, 22 kW, 30 HP 24: 230V, 30 kW, 40 HP 25: 460V, 37 kW, 50 HP 26: 230V, 37 kW, 50 HP 29: 460V, 45 kW, 60 HP 31: 460V, 55 kW, 75 HP 33: 460V, 75 kW, 100 HP	Read Only	0	0	0	0	0
00-01	AC Motor Drive Rated Current Display	Display by model	Read only	0	0	0	0	0
00-02	Parameter Reset	0: No function	0	0	0	0	0	0

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
			 Read only Direct docking mode only ◆ Keypad locked Reset all parameters to defaults (base frequency is 50 Hz) Reset all parameters to defaults (base frequency is 60 Hz) 						
*	00-03	Start-up Display	0: Frequency command value 1: The actual output frequency 2: DC bus voltage 3: Output current 4: Output voltage 5: User-defined (Pr.00-04)	0	0	0	0	0	0
	00-04	Content of Multi- function Display	 Display the output current supplied to the motor from the drive (A) (Unit: Amp) Reserved Display the drive's actual output frequency (H) (Unit: Hz) Display the drive's DC bus voltage (v) (Unit: V_{DC}) Display the terminals U, V, and W output voltage of the drive (E) (Unit: V_{AC}) Display the terminals U, V, and W output power factor angle to the motor (n) (Unit: deg) Display the terminals U, V, and W output power to the motor (P) (Unit: kW) Display the actual motor speed in rpm (r) (Unit: rpm) Display the drive's estimated output torque in %; the motor's rated torque is 100% (t) (Unit: %) Display the PG feedback (G) (See Pr.10-00 and Pr.10-01) Display the AUI1 analog input terminal signal (1.) (Unit: %) Reserved Display the AUI2 analog input terminal signal (Unit: %) Display the drive's heat sink temperature (t) (Unit: °C) Display digital input status ON/OFF (i) Display digital output status ON/OFF (o) 	0	0		0	0	0

Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
		 18: Display the step speed of multi-step speed that is executing (S) 19: The corresponding CPU digital input pin status (i.) 20: The corresponding CPU digital output pin status (o.) 21–23: Reserved 24: Output AC voltage when malfunction occurred (E) (Unit: V_{AC}) 25: Output DC voltage when malfunction occurred (v) (Unit: V_{DC}) 26: Motor frequency when malfunction occurred (H) (Unit: Hz) 27: Output current when malfunction occurred (A) (Unit: Amp) 28: Output frequency when malfunction occurred (F) (Unit: Hz) 29: Frequency command when malfunction occurred (P) (Unit: kW) 31: Output power when malfunction occurred (t) (Unit: %) 32: Input terminal status when malfunction occurred (o) 34: Drive status when malfunction occurred (s) 35: Display MI and MO status on digital keypad 36: CAN communication interference index (c) (Unit: %) 						
		37: Multi-function display selection (q) (Unit: %) 40: Elevator actual speed (Unit: m/s)						
00-05	User-Defined Coefficient K	Digit 4: number of decimal points (0–3) Digit 3–0: 40–9999	0	0	0	0	0	0
00-06	Software Version	READ ONLY	##.##	0	0	0	0	0
00-07	Password Input	1–9998, 10000–65535 0–2: number of wrong password attempts	0	0	0	0	0	0
00-08	Password Set	1–9998, 10000–65535 0: No password set or successful input in Pr.00-07 1: Password has been set	0	0	0	0	0	0
00-09	Control Method	0: V/F control (V/F) 1: V/F control + Encoder (VFPG) 2: Sensorless Vector Control (SVC) 3: FOC vector control + Encoder (FOCPG)	0	0	0	0	0	0

Chapter 11 Summary of Parameter Settings | VFD-ED

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
			8: FOC Permanent Motor control (FOCPM)						
×	00-10	0: Hz 1: m/s 2: ft/s 3: Direct docking mode only ◆		0	0	0	0	0	0
	00-11	Output Direction Selection	0: FWD: counterclockwise, REV: clockwise 1: FWD: clockwise, REV: counterclockwise	0	0	0	0	0	0
N	00-12	Carrier Frequency	2–15 kHz	12	0	0	0	0	0
×		Automatic Voltage Regulation (AVR) Function	0: Enable AVR 1: Disable AVR 2: Disable AVR when deceleration stop	0	0	0	0	0	0
×	00-14	Master Frequency Command Source	1: RS-485 serial communication or digital keypad (KPC-CC01) 2: External analog input (Pr.03-00) 3: Digital terminal inputs (Pr.04-00–Pr.04-15) 4: Direct docking mode only ◆	1	0	0	0	0	0
×	00-15	Operation Command Source	External terminals RS-485 serial communication or digital keypad (KPC-CC01)	1	0	0	0	0	0

01 Basic Parameters

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
	()1-()()	Maximum Output Frequency	5.00–299.00 Hz	60.00/ 50.00	0	0	0	0	0
	01-01	motor's rated frequency)	0.00–299.00 Hz	60.00/ 50.00	0	0	0	0	0
	0.02	First Output Voltage Setting (base voltage/ motor's rated voltage)	230V models: 0.1–255.0 V 460V models: 0.1–510.0 V	220.0 440.0	0	0	0	0	0
	01-03	Second Output Frequency Setting	0.00–299.00 Hz	0.50	0	0			
×	01-04	Second Output Voltage Setting	230V models: 0.1–255.0 V 460V models: 0.1–510.0 V	5.0 10.0	0	0			
	01-05	Third Output Frequency Setting	0.00–299.00 Hz	0.50	0	0			
×	01-06	Third Output Voltage Setting	230V models: 0.1–255.0 V 460V models: 0.1–510.0 V	5.0 10.0	0	0			
	01-07	Fourth Output Frequency Setting	0.00–299.00 Hz	0.00	0	0	0	0	
×	1111111	Fourth Output Voltage Setting	230V models: 0.1–255.0 V 460V models: 0.1–510.0 V	5.0 10.0	0	0	0		
	01-09	Starting Frequency	0.00–299.00 Hz	0.50	0	0	0	0	
×	()1-1()	Output Frequency Upper Limit	0.00–299.00 Hz	299.00	0	0	0	0	0
×	01-11	Output Frequency Lower Limit	0.00–299.00 Hz	0.00	0	0	0	0	0
×			0.00–600.00 sec.	3.00	0	0	0	0	0
N			0.00-600.00 sec.	2.00	0	0	0	0	0
×		Accel. Time 2	0.00–600.00 sec.	3.00	0	0	0	0	0
N		Decel. Time 2 Accel. Time 3	0.00-600.00 sec. 0.00-600.00 sec.	3.00	0	0	0 0	0	0
<i>~</i>		Decel. Time 3	0.00-600.00 sec.	2.00	0	0	0	0	0
~		Accel. Time 4	0.00–600.00 sec.	3.00	0	0	0	0	0
N		Decel. Time 4	0.00-600.00 sec.	2.00	0	0	0	0	0
N	01-20	JOG Acceleration Time	0.00-600.00 sec.	1.00	0	0	0	0	0
N	01-21	JOG Deceleration Time	0.00-600.00 sec.	1.00	0	0	0	0	0
×	01-22	JOG Frequency	0.00–299.00 Hz	6.00	0	0	0	0	0
×	01-23	Switch Frequency between First and Fourth Accel./ Decel.	0.00–299.00 Hz	0.00	0	0	0	0	0
×	01-24	S-curve for Acceleration Begin Time S1	0.00–25.00 sec.	1.00	0	0	0	0	0
×	101_25	S-curve for Acceleration Arrival Time S2	0.00-25.00 sec.	1.00	0	0	0	0	0
×	01-26	S-curve for Deceleration	0.00–25.00 sec.	1.00	0	0	0	0	0

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
		Begin Time S3							
×	01-27	S-curve for Deceleration Arrival Time S4	0.00-25.00 sec.	1.00	0	0	0	0	0
	01-28	Mode Selection when Frequency < Fmin	Output waiting Zero-speed operation Fmin (fourth output frequency setting)	1	0	0	0		
×	01-29	Switch Frequency for S3/S4 Changes to S5	0.00–299.00 Hz	0.00	0	0	0	0	0
×	01-30	S-curve for Deceleration Arrival Time S5	0.00-25.00 sec.	1.00	0	0	0	0	0
×	01-31	Deceleration Time when Operating without RUN Command	0.00–600.00 sec.	2.00	0	0	0	0	0
	01-32	Direct docki							
	01-33	High Speed Time for Short Floor	0.00-60.00 sec.	3.00	0	0	0	0	0
	01-34	Leveling Time for Short Floor	0.00-60.00 sec.	3.00	0	0	0	0	0
	01-35	Limit for Direct Docking Terminal	0.00-10.00	2.00	0	0	0	0	0
	01-36	Deceleration Distance for Direct Docking Terminal	0.00–100.00 cm	30.00	0	0	0	0	0
	01-37	Deceleration Distance Reference for Short Floor	0.00–655.35 m	Read only	0	0	0	0	0
	01-38	Short Floor/Direct Docking Terminal Enabled	0000h: Disabled 0001h: Short floor enabled 0002h: Direct docking terminal enabled 0003h: Short floor + direct docking terminal enabled	0000h	0	0	0	0	0
	01-39	Automatic Emergency Deceleration Level	5.00–299.00 Hz	60.00		0		0	0
×	01-40	Deceleration Time for Emergency Deceleration	0.00-600.00 sec.	2.00		0		0	0

02 Digital Input / Output Parameters

Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
02-00	Two-wire/three-wire Operation Control	0: FWD/STOP, REV/STOP 1: FWD/STOP, REV/STOP (Line Start Lockout) 2: RUN/STOP, REV/FWD 3: RUN/STOP, REV/FWD (Line Start Lockout) 4: Three-wire 5: Three-wire (Line Start Lockout)	0	0	0	0	0	0
02-01	Multi-Function Input Command 1 (MI1)	0: no function	1	0	0	0	0	0
	(The Stop terminal for three-wire operation)	1: multi-step speed command 1	1	0	0	0	0	0
02-02	Multi-Function Input Command 2 (MI2)	2: multi-step speed command 2	2	0	0	0	0	0
02-03	Multi-Function Input Command 3 (MI3)	3: multi-step speed command 3	3	0	0	0	0	0
02-04	Multi-Function Input Command 4 (MI4)	4: multi-step speed command 4	4	0	0	0	0	0
02-05	Multi-Function Input Command 5 (MI5)	5: Reset	0	0	0	0	0	0
02-06	Multi-Function Input Command 6 (MI6)	6: JOG command	0	0	0	0	0	0
02-07	Multi-Function Input Command 7 (MI7)	7: Acceleration/ deceleration speed inhibit	0	0	0	0	0	0
		8: First, second acceleration/deceleration time		0	0	0	0	0
		9: Third, fourth acceleration/deceleration time		0	0	0	0	0
		10: EF input (Pr.07-28) 11: Reserved		0	0	0	0	0
		12: Stop output 13–14: Reserved		0	0	0	0	0
	Multi-Function Input	15: AUI1 operation speed command		0	0	0	0	0
02-08	Command 8 (MI8)	16: Reserved 17: AUI2 operation speed command	40	0	0	0	0	0
	(Enable Drive terminal)	18: Emergency Stop (Pr.07-28)		0	0	0	0	0
		19–23: Reserved						
		24: FWD JOG command		0	0	0	0	0
		25: REV JOG command		0	0	0	0	0
		26: Reserved						
		27: ASR1/ASR2 selection		0	0	0	0	0
		28: Emergency stop (EF1) (Motor coasts to stop)		0	0	0	0	0
		29–30: Reserved						

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
			31: High torque bias (according to Pr.07-21)		0	0	0	0	0
			32: Middle torque bias (according to Pr.07-22)		0	0	0	0	0
			33: Low torque bias (according to Pr.07- 23)		0	0	0	0	0
			34–37: Reserved 38: Disable writing to EEPROM function		0	0	0	0	0
			39: Torque command direction (0 is positive direction)		0))	0	
			40: Enable drive function		0	0	0	0	0
			41: Magnetic contactor detection		0	0	0	0	0
			42: Mechanical brake 1		0	0	0	0	0
			43: EPS function (Emergency Power System)		0	0	0	0	0
			44: Mechanical brake 2						
			45–51: Direct docking mode only ◆						
			53: Terminal leveling signal for direct docking			0		0	0
			54: Power failure signal		0	0	О	0	0
			55: Manual emergency deceleration			0		0	0
			56: Automatic emergency deceleration			0		0	0
			57: Brake torque test action signal		0	0	0	0	0
			59: AFE fault		0	0	0	0	0
/	02-09	Digital Input Response Time	0.001–30.000 sec.	0.005	0	0	0	0	0
/	02-10	Digital Input Operation Direction	0–65535	0	0	0	0	0	0
/	02-11	Multi-function Output 1:	0: No function	0	0	0	0	0	0
	02-11	RA, RB, RC (Relay1)	1: Operation indication		0	0	0	0	0
		•	2: Operation speed reached	0	0	0	0	0	0
/	02-12	MRA, MRB, MRC (Relay2)	3: Desired frequency reached 1 (Pr.02- 25, Pr.02-26)		0	0	0	0	0
/	02-13	R1A, R12C (Relay3)	4: Desired frequency reached 2 (Pr.02-27, Pr.02-28)	0	0	0	0	0	0
/	02-14	Multi-function Output 4: R2A, R12C (Relay4)	5: Zero speed (Frequency command)	0	0	0	0	0	0
/	02-15	(MO1)	6: Zero speed with stop (Frequency command)	0	0	0	0	0	0
/	02-16	Multi-function Output 6: (MO2)	7: Over-torque (OT1) (Pr.06-05–06-07)	0	0	0	0	0	0
/	02-17	Multi-function Output 7: (MO3)	8: Over-torque (OT2) (Pr.06-08-06-10)	0	0	0	0	0	0
/	02-18	Multi-function Output 8: (MO4)	9: Drive ready	0	0	0	0	0	0

Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
02-19	Multi-function Output 9: (MO5)	10: User-defined low-voltage detection (LV)	0	0	0	0	0	0
02-20	Multi-function Output 10: (MO6)	11: Malfunction indication	0	0	0	0	0	0
		12: Mechanical brake release (Pr.02-29, Pr.02-30, Pr.02-37)	0	0	0	0	0	0
		13: Overheat (Pr.06-14)		0	0	0	0	0
		14: Brake transistor signal		0	0	0	0	0
		15: Motor-controlled magnetic contactor output		0	0	0	0	0
		16: Slip error (oSL)		0	0	0	0	0
		17: Malfunction indication 1		0	0	0	0	0
		18: Reserved						
		19: Brake transistor output error		0	0	0	0	0
		20: Warning output		0	0	0	0	0
		21: Over-voltage warning		0	0	0	0	0
		22: Over-current stall prevention		0	0	0		
		warning				0		
		23: Over-voltage stall prevention warning		0	0	0	0	0
		24: Operation mode indication (Pr.00-15=1)		0	0	0	0	0
		25: Forward command		0	0	0	0	0
		26: Reverse command		0	0	0	0	0
		27: Output when current ≥ Pr.02-33		0	0	0	0	0
		28: Output when current < Pr.02-33	0	0	0	0	0	0
		29: Output when frequency ≥ Pr.02-34		0	0	0	0	0
		30: Output when frequency < Pr.02-34		0	0	0	0	0
		31: Power generation direction and))		
		status verification		0	0	0	0	0
		32: Power generation direction		0	0	0	0	0
		33: Zero speed (actual output frequency)		0	0	0	0	0
		34: Zero speed with Stop (actual output frequency)		0	0	0	0	0
		35: Fault output option 1 (Pr.06-22)		0	0	0	0	0
		36: Fault output option 2 (Pr.06-23)		0	0	0	0	0
		37: Fault output option 3 (Pr.06-24)		0	0	0	0	0
		38: Fault output option 4 (Pr.06-25)		0	0	0	0	0
		39: Reserved						
		40: Speed reached (including zero						$\overline{}$
		speed)		0	0	0	0	0
		41: Reserved						
		42: STO output error		0	0	0	0	0
		43–44: Direct docking mode only ◆						

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
			45: Reserved						
			46: Retrying after a fault has occurred indication		0	0	0	0	0
			47: Direct docking mode only ◆						
			48: Control output of MPSCC (Motor		0	0	0	0	0
			Phase Short Circuit Contactor)						
			49: Emergency power mode action		0	0	0	0	0
			50: Speed reached Pr.02-34		0	0	00	0	0
			51: Brake torque test finished 52: AFE reset		0	0	0	0	0
	02-21-	<u> </u> 02 22	Reserved			0	0	U	
~		T.	0–65535	0	0	0	0	0	0
,	02 20		0: According to FWD/REV signal))))	
	02-24	Serial Start Signal Selection	According to Enable drive function signal	0	0	0	0	0	0
×	02-25	Desired Frequency Reached 1	0.00–299.00 Hz	60.00/ 50.00	0	0	0	0	0
×	02-26	Desired Frequency Reached Width 1	0.00–299.00 Hz	2.00	0	0	0	0	0
×	02-27	Desired Frequency Reached 2	0.00–299.00 Hz	60.00/ 50.00	0	0	0	0	0
×	02-28	Desired Frequency Reached Width 2	0.00–299.00 Hz	2.00	0	0	0	0	0
	02-29	Brake Release Delay Time when Elevator Starts	0.000–65.000 sec.	0.250	0	0	0	0	0
	02-30	Brake Engage Delay Time when Elevator Stops	0.000–65.000 sec.	0.250	0	0	0	0	0
*	02-31	Magnetic Contactor Contracting Delay Time between Drive and Motor	0.010–65.000 sec.	0.200	0	0	0	0	0
*	02-32	Magnetic Contactor Release Delay Time between Drive and Motor	0.010–65.000 sec.	0.200	0	0	0	0	0
×	02-33	External Terminal Output Current Level	0–100% (motor drive rated current)	0	0	0	0	0	0
*	02-34	External Terminal	0.00–299.00 Hz (this is motor speed when using with PG) NOTE: The setting range and unit of Pr.02-34 varies with Pr.00-10 settings. See Chapter 12 for details.	0.00	0	0	0	0	0
×	02-35	Mechanical Brake Detection Time	0.00-10.00 sec.	0.00	0	0	0	0	0

Chapter 11 Summary of Parameter Settings | VFD-ED

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
×	02-36	Magnetic Contactor Detection Time	0.00-10.00 sec.	0.00	0	0	0	0	0
	02-37	Torque Check	0: Disable 1: Enable	0	0	0	0	0	0
*	02-38	MPSCC (Motor Phase Short Circuit Contactor) Release Delay Time between Drive and Motor	0.010~65.000 sec.	0.200	0	0	0	0	0
*	02-39	MPSCC (Motor Phase Short Circuit Contactor) Contracting Delay Time between Drive and Motor	0.010~65.000 sec.	0.200	0	0	0	0	0
	02-40 - 02-42	Direct	docking mode only ◆	-		0		0	0
*	02-43	Speed Reached Bandwidth	0.00–299.00 Hz	2.00	0	0	0	0	0

03 Analog Input / Output Parameters

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
×	03-00	Analog Input 1 (AUI1)	0: No function	1	0	0	0	0	0
	03-01	Reserved	1: Frequency command (speed limit under torque control mode)						
			2: Torque command (torque limit under speed mode) 3: Load compensation 4–5: Reserved		0	0	0	0	0
×	03-02		6: P.T.C. thermistor input value 7: Positive torque limit	0	0	0	0	0	0
			8: Negative torque limit 9: Regenerative torque limit 10: Positive/negative torque limit					000	0
*	03-03	Analog Input Bias 1 (AUI1)	-100.0–100.0%	0.0	0	0	0	0	0
	03-04	Reserved			I				
×	03-05	Analog Input Bias 1 (AUI2)	-100.0–100.0%	0.0	0	0	0	0	0
*	03-06	AUI1 Positive/negative Bias Mode	0: Zero bias 1: Lower than or equal to bias	0	0	0	0	0	0
	03-07	Reserved	2: Higher than or equal to bias 3: Using bias as the base to get the						
×	03-08	AUI2 Positive/negative Bias Mode	absolute value of bias voltage (unipolar) 4: Using bias as the base (unipolar)	0	0	0	0	0	0
×	03-09	Analog Input Gain 1 (AUI1)	0.0–500.0%	100.0	0	0	0	0	0
	03-10	Reserved			1				
×	03-11	(AUI2)	0.0–500.0%	100.0	0	0	0	0	0
×	03-12	Analog Input Filter Time (AUI1)	0.00–2.00 sec.	0.01	0	0	0	0	0
	03-13	Reserved			I				
×	03-14	Time (AUI2)	0.00–2.00 sec.	0.01	0	0	0	0	0
	03-15	Load Compensation Auto-tuning	0: No function1: Auto-tunes with running without load2: Auto-tunes with running with load	0	0	0	0	0	0
		Reserved							
	03-16	Reserved							
*	03-17	Analog Output Selection 1	0: Output frequency (Hz) 1: Frequency command (Hz) 2: Motor speed (RPM) 3: Output current (rms)	0	0 0 0	0000	0000	0000	0 0
			4: Output voltage		0	0	0	0	0

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
			5: DC bus voltage		0	0	0	0	0
			6: Power factor angle		0	0	0	0	0
			7: Power factor		0	0	0	0	0
			8: Output torque		0	0	0	0	0
			9: AUI1		0	0	0	0	0
			10: Reserved						
			11: AUI2		0	0	0	0	0
			12: q-axis current		0	0	0	0	0
			13: q-axis feedback value		0	0	0	0	0
			14: d-axis current		0	0	0	0	0
			15: d-axis feedback value		0	0	0	0	0
			16: q-axis voltage		0	0	0	0	0
			17: d-axis voltage		0	0	0	0	0
			18: Torque command		0	0	0	0	0
			19–20: Reserved						
			21: Power Output		0	0	0	0	0
×	03-18	Analog Output Gain 1	0–200.0%	100.0	0	0	0	0	0
		Analog Output Value	0: Absolute value in output voltage			_			
×	03-19	in REV Direction 1	1: Output 0 V in REV direction	0	0	0	0	0	0
			2: Enable output voltage in REV direction		_				
			0: Output frequency (Hz)		0	0	0	0	0
			1: Frequency command (Hz)		0	0	0	0	0
			2: Motor speed (RPM)		0	0	0	0	0
			3: Output current (rms)		0	0	0	0	0
			4: Output voltage		0	0	0	0	0
			5: DC bus voltage		0	0	0	0	0
			6: Power factor angle		0	0	0	0	0
			7: Power factor		0	0	0	0	0
			8: Output torque		0	0	0	0	0
		Analog Output	9: AUI1		0	0	0	0	0
×	03-20	Selection 2	10: Reserved	0					
			11: AUI2		0	0	0	0	0
			12: q-axis current		0	0	0	0	0
			13: q-axis feedback value		0	0	0	0	0
			14: d-axis current		0	0	0	0	0
			15: d-axis feedback value		0	0	0	0	0
			16: q-axis voltage		0	0	0	0	0
			17: d-axis voltage		0	0	0	0	0
			18: Torque command 19–20: Reserved		0	0	0	0	0
					0	0	0	0	
	N2 24	Analog Output Cain C	21: Power Output	100.0	0	0	0	0	0
~	U3-Z1	Analog Output Gain 2		100.0			\cup		
. ✓	03-22	Analog Output Value	O: Absolute value in output voltage Output 0 V in REV direction	0	0	0	0	0	0
7	03-22	in REV Direction 2	2: Enable output voltage in REV direction	U					
			2. Litable output voltage in REV direction		<u> </u>				<u> </u>

Chapter 11 Summary of Parameter Settings | VFD-ED

Pr.	Parameter Name	Setting Range	Default	٧F	VFPG	SVC	FOCPG	FOCPM
03-23	Analog Input Type (AUI1)	0: Bipolar (±10 V) 1: Unipolar (0–10 V)	0	0	0	0	0	0
03-24	Analog Input Type (AUI2)	0: Bipolar (±10 V) 1: Unipolar (0–10 V)	0	0	0	0	0	0

04 Multi-step Speed Parameters

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
N	04-00	Zero Step Speed Frequency	0.00–299.00 Hz	0.00	0	0	0	0	0
×	04-01	1st Step Speed Frequency	0.00–299.00 Hz	0.00	0	0	0	0	0
×	04-02	2nd Step Speed Frequency	0.00–299.00 Hz	0.00	0	0	0	0	0
×	04-03	3rd Step Speed Frequency	0.00–299.00 Hz	0.00	0	0	0	0	0
×	04-04	4th Step Speed Frequency	0.00–299.00 Hz	0.00	0	0	0	0	0
×	04-05	5th Step Speed Frequency	0.00–299.00 Hz	0.00	0	0	0	0	0
×	04-06	6th Step Speed Frequency	0.00–299.00 Hz	0.00	0	0	0	0	0
×	04-07	7th Step Speed Frequency	0.00–299.00 Hz	0.00	0	0	0	0	0
×	04-08	8th Step Speed Frequency	0.00–299.00 Hz	0.00	0	0	0	0	0
×	04-09	9th Step Speed Frequency	0.00–299.00 Hz	0.00	0	0	0	0	0
×	04-10	10th Step Speed Frequency	0.00–299.00 Hz	0.00	0	0	0	0	0
×	04-11	11th Step Speed Frequency	0.00–299.00 Hz	0.00	0	0	0	0	0
×	04-12	12th Step Speed Frequency	0.00–299.00 Hz	0.00	0	0	0	0	0
×	04-13	13th Step Speed Frequency	0.00–299.00 Hz	0.00	0	0	0	0	0
N	04-14	14th Step Speed Frequency	0.00–299.00 Hz	0.00	0	0	\circ	\circ	0
×	04-15	15th Step Speed Frequency	0.00–299.00 Hz	0.00	0	0	0	0	0
	04-16 - 04-99	Direct dockin	g mode only ◆						

05 IM Parameters

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
	05-00	Motor Auto-tuning	0: No function 1: Dynamic test (Rs, Rr, Lm, Lx, no-load current) (Motor runs) 2: Static test (Motor does not run)	0	0				
	05-01	Motor Rated Current	(40-120%) * Pr.00-01 Amps	#.##	0	0	0	0	
	05-02	Motor Rated Power	0.00–655.35 kW	#.##			0	0	
	05-03	Motor Rated Speed (rpm)	0–65535	1710		0	0	0	
	05-04	Number of Motor Poles	2–48	4	0	0	0	0	
	05-05	Motor No-load Current	0-Pr.05-01 <default></default>	#.##		0	0	0	
	05-06	Motor Rs	0.000–65.535 Ω	0.000			0	0	
	05-07	Motor Rr	0.000–65.535 Ω	0.000			0	0	
	05-08	Motor Lm	0.0–6553.5 mH	0.0			0	0	
	05-09	Motor Lx	0.0–6553.5 mH	0.0			0	0	
×	05-10	Torque Compensation Low Pass Filter Time	0.001–10.000 sec.	0.020			0		
×	05-11	Slip Compensation Low Pass Filter Time	0.001–10.000 sec.	0.100			0		
×	05-12	Torque Compensation Gain	0–10	0	0	0			
×	05-13	Slip Compensation Gain	0.00–10.00	1.00			0		
×		Slip Deviation Level	0–1000% (0: disable)	0		0	0	0	
×	05-15	Slip Deviation Detection Time	0.0-10.0 sec.	1.0		0	0	0	
*	05-16	Over-slip Action	0: Warn and keep operation 1: Fault and ramp to stop 2: Fault and coast to stop	0		0	0	0	
×		Hunting Gain	0–10000 (0: disable)	2000	0	0	0		
	05-18	Operation Time (Min.)	0–1439	0	0	0	0	0	0
	05-19	Accumulated Motor Operation Time (day)	0–65535	0	0	0	0	0	0
×		Core Loss Compensation	0–250%	10			0		
	05-21	Accumulated Motor Power-on Time (Min.)	0–1439	0	0	0	0	0	0
	05-22	Accumulated Motor Power-on Time (day)	0–65535	0	0	0	0	0	0
×	05-23	Slip Compensation Gain % (Power Generation Mode)	0.0–100.0%	0.0	0		0		
×	05-24	Slip Compensation Gain % (Electricity Mode)	0.0–100.0%	0.0	0		0		

06 Protection Parameters

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
×	06-00	Low Voltage Level	230V models: 160.0–220.0 V 460V models: 320.0–440.0 V	180.0 360.0	0	0	0	0	0
×		Protection during	0: Warn and keep operation 1: Fault and ramp to stop 2: Fault and coast to stop	2	0	0	0	0	0
×		Prevention during	0: Disable 0–250% (rated current of the motor drive)	0	0	0	0		
×	06-03	Over-current Stall	0: Disable 0–250% (rated current of the motor drive)	0	0	0	0		
*		Acceleration/Deceleration Time for Stall Prevention at Constant Speed	0: Use the current acceleration/deceleration time 1: Use the first acceleration/deceleration time 2: Use the second acceleration/deceleration time 3: Use the third acceleration/deceleration time 4: Use the fourth acceleration/deceleration time 5: Use the auto-acceleration/ auto-deceleration time	0	0	0	0		
N	06-05	Over-torque Detection (OT1)	 Disable Over-torque detection during constant speed operation, continue to operate after detection Over-torque detection during constant speed operation, stop operating after detection Over-torque detection during operation, continue to operate after detection Over-torque detection during operation, stop operating after detection 	0	0	0	0	0	0
×	06-06	Over-torque Detection Level (OT1)	10–250% (rated current of the motor drive)	150	0	0	0	0	0
×	06-07	Over-torque Detection Time (OT1)	0.1–60.0 sec.	0.1	0	0	0	0	0
×	06-08	Over-torque Detection (OT2)	0: Disable1: Over-torque detection during constant speed operation, continue to operate after detection	0	0	0	0	0	0

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
			 2: Over-torque detection during constant speed operation, stop operating after detection 3: Over-torque detection during operation, continue to operate after detection 4: Over-torque detection during operation, stop operating after 						
×	06-09	Over-torque Detection Level (OT2)	detection 10–250% (rated current of the motor drive)	150	0	0	0	0	0
×	06-10	Over-torque Detection Time (OT2)	0.1–60.0 sec.	0.1	0	0	0	0	0
×	06-11	Current Limit	0–250% (rated current of the motor drive)	200				0	0
	06-12	Electronic Thermal Relay	0: Standard motor1: Inverter motor2: Disabled	2	0	0	0	0	0
×	06-13	Electronic Thermal Characteristic	30.0–600.0 sec.	60.0	0	0	0	0	0
×	06-14	IGBT Overheat Warning (oH1)	0.0-110.0°C	90.0	0	0	0	0	0
×	06-15	Stall Prevention Limit Level	0–100% (refer to Pr.06-02, Pr.06-03)	50	0	0	0		
	06-16	Present Fault Record	0: No fault	0	0	0	0	0	0
	06-17	Second Most Recent Fault Record	1: Over-current during acceleration (ocA)	0	0	0	0	0	0
	06-18	Third Most Recent Fault Record	2: Over-current during deceleration (ocd)	0	0	0	0	0	0
	06-19	Fourth Most Recent Fault Record	3: Over-current during constant speed (ocn)	0	0	0	0	0	0
	06-20	Fifth Most Recent Fault Record	4: Ground fault (GFF)	0	0	0	0	0	0
	06-21	Sixth Most Recent Fault Record	5: IGBT short-circuit (occ) 6: Over-current at stop (ocS) 7: Over-voltage during acceleration (ovA) 8: Over-voltage during deceleration (ovd) 9: Over-voltage during constant speed (ovn) 10: Over-voltage at stop (ovS) 11: Low voltage during acceleration (LvA) 12: Low voltage during deceleration (Lvd) 13: Low voltage during constant speed (Lvn)		0	0	0	0	0

Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
		14: Low voltage at stop (LvS) 15: Input phase loss (PHL) 16: IGBT overheat (oH1) 17: Bulk capacitors overheat (oH2) 18: Abnormal IGBT temperature detected (tH1o) 19: Abnormal bulk capacitor temperature detected (tH2o) 20: Unusual cooling fan operation (FAn) 21: Overload (oL) (150%; 1 minute, motor drive overloaded) 22: Motor overloaded (EoL1) 23: Reserved 24: Motor PTC overheat (oH3) 25: Reserved 26: Over-torque 1 (ot1) 27: Over-torque 2 (ot2) 28: Reserved 29: Reserved 30: Memory writing error (cF1) 31: Memory reading error (cF2) 32: Isum current detection error (cd1) 34: V-phase current detection error (cd2) 35: W-phase current detection error (cd3) 36: CC current clamp hardware error (Hd0) 37: OC (over-current) hardware error (Hd1) 38: ov (over-voltage hardware error (Hd2) 39: GFF (ground fault) hardware error (Hd3) 40: Auto-tuning error on motor's parameter (AUE) 41: Reserved 42: PG feedback error (PGF1) 43: PG feedback loss (PGF2) 44: PG feedback stall (PGF3) 45: PG slip error (PGF4) 46: Reserved 47: Reserved 48: Reserved 49: External fault input (EF)						
		50: Emergency stop from external						

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
			terminals (EF1) 51: Reserved 52: Password error after three attempts (Pcod) 53: Reserved 54: Illegal communication command (cE01) 55: Illegal communication address (cE02) 56: Communication data length error (cE03) 57: Communication attempts to write to a read-only address (cE04) 58: Modbus transmission time-out (cE10) 59: Keypad transmission time-out (cP10) 60: Brake transistor error (BF) 61–63: Reserved 64: Mechanical brake feedback error (MBF) 65: PG hardware error (PG5) 66: Magnetic contactor error (MCF) 67: Output phase loss (MPHL) 68: CAN BUS disconnected (CANF) 69–71: Reserved 72: Safe torque loss (STL1) 73: PG cd hardware error (PGcd) 74: PG absolute signal error (PGHL) 75: PG Z phase signal loss (PGAF) 76: Safe torque output stops (STO) 77: Safe torque loss 2 (STL2) 78: Safe torque loss 3 (STL3) 82: U-phase output phase loss (OPHL) 83: V-phase output phase loss (OPHL) 84: W-phase output phase loss (OPHL) 85: BTTx Fail (btt) 95: BTTx Error (bttE)						
′ (06-22	Fault Output Option 1	0–65535 (refer to bit table for fault code in Chapter 12)	0	0	0	0	0	0
′ ()6-23	Fault Output Option 2	0–65535 (refer to bit table for fault code in Chapter 12)	0	0	0	0	0	0
′ ()6-24	Fault Output Option 3	0–65535 (refer to bit table for fault code in Chapter 12)	0	0	0	0	0	0
′ [06-25	Fault Output Option 4	0–65535 (refer to bit table for fault code in Chapter 12)	0	0	0	0	0	0

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
×	06-26	PTC (Positive Temperature Coefficient) Detection Action	O: Warn and keep operation 1: Fault and ramp to stop	0	0	0	0	0	0
×	06-27	PTC Level	0.0–100.0%	50.0	0	0	0	\circ	0
×	06-28	PTC Detection Filter Time	0.00-10.00 sec.	0.20	0	0	0	0	0
	06-29	Voltage of Emergency Power	24.0–375.0 V _{DC} 48.0–750.0 V _{DC}	24.0 48.0	0	0	0	0	0
×	1116-311	Fault Output Setting Method	0: According to Pr.06-22–Pr.06-25 (four sets) 1: According to the binary setting (fifteen sets)	0	0	0	0	0	0
		Phase Loss Detection of Drive Output at Start-up (MPHL)	0: Disable 1: Enable	1	0	0	0	0	0
	06-32	Accumulated Drive Power-on Time at the First Fault (min.)	0–65535	Read only	0	0	0	0	
		Accumulated Drive Power-on Time at the First Fault (day)	0–65535	Read only	0	0	0	0	
	06-34	Accumulated Drive Power-on Time at the Second Fault (min.)	0–65535	Read only	0	0	0	0	
	06-35	Accumulated Drive Power-on Time at the Second Fault (day)	0–65535	Read only	0	0	0	0	
		Accumulated Drive Power-on Time at the Third Fault (min.)	0–65535	Read only	0	0	0	0	
		Accumulated Drive Power-on Time at the Third Fault (day)	0–65535	Read only	0	0	0	0	
		Accumulated Drive Power-on Time at the Fourth Fault (min.)	0–65535	Read only	0	0	0	0	
		Accumulated Drive Power-on Time at the Fourth Fault (day)	0–65535	Read only	0	0	0	0	
	06-40	Accumulated Drive Power-on Time at the Fifth Fault (min.)	0–65535	Read only	0	0	0	0	
	06-41	Accumulated Drive Power-on Time at the Fifth Fault (day)	0–65535	Read only	0	0	0	0	
	_	Accumulated Drive	0–65535	Read	0	0	0	0	

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
		Power-on Time at the Sixth Fault (min.)		only					
	06-43	Accumulated Drive Power-on Time at the Sixth Fault (day)	0–65535	Read only	0	0	0	0	
	06-44	(EPS) Emergency Power Mode Operation Speed	0.00–299.00 Hz	Read only	0	0	0	0	0
W	06-45	Fault and Warning Actions	Bit0 = 0: Display Lv fault and coast to stop Bit0 = 1: Display Lv warn and coast to stop Bit1 = 0: Fan lock, fault and coast to stop Bit1 = 1: Fan lock, warn and continue operation Bit2 = 0: software GFF protection enabled Bit2 = 1: software GFF protection disabled	0	0	0	0	0	0
\varkappa	06-46	(EPS) Emergency Power ON Operation Direction	 Run according to the current command Run according to the operation direction of power generation mode, and execute the power generation direction detection when in power generation mode. After determining the power generation direction, the host controller sends a running direction command. (When at STOP, the direction of power generation mode (MO = 32) confirms and the direction of power generation mode does not remain.) Execute the power generation direction detection every time. After determining the power generation direction direction, the host controller sends a running direction command. (When at STOP, the direction of power generation mode (MO =32) confirms and the direction of power generation mode remains.) Execute the power generation direction detection one time. Run according to the operation mode, and execute the power generation mode, 	0	0	0	0	0	0

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
			direction detection when in normal mode.						
×	06-47	Power Generation Direction Search Time	0.0–5.0 sec.	1.0	0	0	0	0	0
	1116-7181	Power Capacity of Emergency Power (EPS)	0.0–100.0 kVA	0.0	0	0	0	0	0
*	06-49	STO Latch Selection	0000h: STO fault latched, resending RUN command is required 0001h: STO warning latched, resending RUN command is required 0002h: STO fault latched 0003h: STO warning unlatched	0000h	0	0	0	0	0
×	106-501		0: Output	0	0	0	0	0	0
×	06-51	Retrying after Fault Number of Times to Retry after Fault	1: No output 0–10	0	0	0	0	0	0
×	06-52	Time Interval between Retries	0.5–600.0 sec.	10.0	0	0	0	0	0
	06-53	Frequency Command when the Most Recent Fault Occurred	0.00–655.35 Hz	Read only	0	0	0	0	0
	06-54	Output Frequency when the Most Recent Fault Occurred	0.00–655.35 Hz	Read only	0	0	0	0	0
	06-55	Output Current when the Most Recent Fault Occurred	0.00–655.35 Amps	Read only	0	0	0	0	0
	06-56	Motor Frequency when the Most Recent Fault Occurred	0.00–655.35 Hz	Read only	0	0	0	0	0
	06-57	Output Voltage when the Most Recent Fault Occurred	0.0–6553.5 V	Read only	0	0	0	0	0
	06-58	DC Bus Voltage when the Most Recent Fault Occurred	0.0–6553.5 V	Read only	0	0	0	0	0
	06-59	Output Power when the Most Recent Fault Occurred	0.0–6553.5 kW	Read only	0	0	0	0	0
	06-60	Output Torque when the Most Recent Fault Occurred	0.00–655.35%	Read only	0	0	0	0	0
	06-61	IGBT Temperature when the Most Recent Fault Occurred	-3276.8–3276.7°C	Read only	0	0	0	0	0
	06-62	Multi-input Terminals	0000h-FFFFh	Read	0	0	0	0	0

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
		Status when the Most		only					
		Recent Fault Occurred							
		Multi-output Terminals status when the Most Recent Fault Occurred	0000h-FFFFh	Read only	0	0	0	0	0
		Motor Drive Status when							
			0000h-FFFFh	Read	0	0	0	0	0
		Occurred		only					
		Power Factor Angle Level							
N	06-68	for Power Generation	0.0–150.0°	70.0	0	0	0	0	0
		Direction							
		Reference Level for		David					
	06-69	Power Factor Angle	-200.0–200.0°	Read	0	0	0	0	0
		during Operation		only					
	06-70	Power Generation	0: FWD	Read	0	0	0	0	0
	06-70	Direction	1: REV	only	O)	0	O	
N	06-71	UPS Output Delay Time	0.0-10.0 sec.	1.0	0	0	0	0	0
	06-72	UPS Stops Output Delay Time	0.0-60.0 sec.	3.0	0	0	0	0	0
	06-73	Permanent Operation	0–60000	Read	0	0	0	0	0
	00-73	Direction Count (H)	0-80000	only	O))	O	
	06-74	Permanent Operation Direction Count (L)	0–9999	Read only	0	0	0	0	0
	06-75	Single Operation Direction Count (H)	0–20	Read only	0	0	0	0	0
	06-76	Single Operation Direction Count (L)	0–9999	Read only	0	0	0	0	0
	06-77	Number of Times for Single Operation Reset	0–100	Read only	0	0	0	0	0
	06-78	Number of Times for Operation Direction	0.00–200.00 k	2.00	0	0	0	0	0
	06-79	Function Selection for Operation Times	0–2	0	0	0	0	0	0
	06-80	Output Frequency when Fault 2 Occurred	0.00–655.35 Hz	Read only	0	0	0	0	0
	06-X1	DC Bus Voltage when Fault 2 Occurred	0.0–6553.5 V	Read only	0	0	0	0	0
	06-82	Output Current when Fault 2 Occurred	0.00–655.35 Amps	Read only	0	0	0	0	0
	06-83	IGBT Temperature when Fault 2 Occurred	-3276.8–3276.7°C	Read only	0	0	0	0	0
	06-84	Output Frequency when Fault 3 Occurred	0.00–655.35 Hz	Read only	0	0	0	0	0
	06-85	DC Bus Voltage when Fault 3 Occurred	0.0–6553.5 V	Read only	0	0	0	0	0
	06-86	Output Current when	0.00–655.35 Amps	Read	0	0	0	0	0

Chapter 11 Summary of Parameter Settings | VFD-ED

Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
	Fault 3 Occurred		only					
06-87	IGBT Temperature when Fault 3 Occurred	-3276.8–3276.7°C	Read only	0	0	0	0	0
06-88	Output Frequency when Fault 4 Occurred	0.00–655.35 Hz	Read only	0	0	0	0	0
06-89	DC Bus Voltage when Fault 4 Occurred	0.0–6553.5 V	Read only	0	0	0	0	0
06-90	Output Current when Fault 4 Occurred	0.00–655.35 Amps	Read only	0	0	0	0	0
06-91	IGBT Temperature when Fault 4 Occurred	-3276.8–3276.7°C	Read only	0	0	0	0	0
06-92	Output Frequency when Fault 5 Occurred	0.00–655.35 Hz	Read only	0	0	0	0	0
06-93	DC Bus Voltage when Fault 5 Occurred	0.0–6553.5 V	Read only	0	0	0	0	0
06-94	Output Current when Fault 5 Occurred	0.00–655.35 Amps	Read only	0	0	0	0	0
06-95	IGBT Temperature when Fault 5 Occurred	-3276.8–3276.7°C	Read only	0	0	0	0	0
06-96	Output Frequency when Fault 6 Occurred	0.00–655.35 Hz	Read only	0	0	0	0	0
06-97	DC Bus Voltage when Fault 6 Occurred	0.0–6553.5 V	Read only	0	0	0	0	0
06-98	Output Current when Fault 6 Occurred	0.00–655.35 Amps	Read only	0	0	0	0	0
06-99	IGBT Temperature when Fault 6 Occurred	-3276.8–3276.7°C	Read only	0	0	0	0	0

07 Special Parameters

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
×	07-00	Brake Transistor Level	230V models: 350.0–450.0 V _{DC} 460V models: 700.0–900.0 V _{DC}	380.0 760.0	0	0	0	0	0
	07-01	Brake Transistor Hysteresis Voltage	0.0–100.0 V	0.0	0	0	0	0	0
×	07-02	DC Brake Current Level at Start-up	0-100% (motor drive rated current)	0	0	0	0		
N	07-03	DC Brake Activation Time	0.0-60.0 sec.	0.7	0	0	0	0	0
N	07-04	DC Brake Stopping Time	0.0-60.0 sec.	0.7	0	0	0	0	0
N		Start-point for DC Brake	0.00–299.00 Hz	0.00	0	0	0	0	
N		DC Brake Proportional Gain	1–500	50	0	0	0		
N		Dwell Time at Acceleration	0.00-600.00 sec.	0.00	0	0	0	0	0
<i>M</i>	07-08	Dwell Frequency at Acceleration.	0.00–299.00 Hz	0.00	0	0	0	0	0
N	07-09	Dwell Time at Deceleration.	0.00-600.00 sec.	0.00	0	0	0	0	0
×	07-10	Dwell Frequency at Deceleration.	0.00–299.00 Hz	0.00	0	0	0	0	0
*	07-11	Cooling Fan Control	0: Cooling fan always ON. 1: One minute after AC motor drive stops, cooling fan is OFF. 2: AC motor drive runs and cooling fan is ON; AC motor drive stops and cooling fan is OFF. 3: Cooling fan is ON to run when preliminary IGBT temperature (°C) reached. 4: Cooling fan is always OFF.	2	0	0	0	0	0
×	07-12	Torque command	-150.0–150.0% (Pr.07-14 setting = 100%)	0.0					
×	07-13	Torque Command Source	0: Digital keypad (KPC-CC01) 1: RS-485 serial communication 2: Analog signal (Pr.03-00)	2					
×	07-14	Maximum Torque Command	0–300% (motor drive rated torque)	100	0	0	0	0	0
×	07-15	Torque Command Filter Time	0.000-1.000 sec.	0.000					
	07-16	Speed Limit	0: Settings in Pr.07-17 and Pr.07-18 1: Frequency command source (Pr.00-14)	0					
×	07-17	Torque Mode + Speed Limit	0–120%	10					
N	07-18	Torque Mode - Speed Limit	0–120%	10					
×	07-19	Torque Offset Source	0: Disable 1: Analog input (Pr.03-00) 2: Torque offset setting (Pr.07-20) 3: Control through external terminals (by Pr.07-21–Pr.07-23)	0			0	0	0

Chapter 11 Summary of Parameter Settings | VFD-ED


	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
×	07-20	Torque Offset Setting	0.0–100.0% (motor drive rated torque)	0.0			0	0	0
×	07-21	High Torque Offset	0.0–100.0% (motor drive rated torque)	30.0			0	0	0
×	07-22	Middle Torque Offset	0.0–100.0% (motor drive rated torque)	20.0			0	0	0
×	07-23	Low Torque Offset	0.0–100.0% (motor drive rated torque)	10.0			0	0	0
×	07-24	Forward Motor Torque Limit	0–300% (motor drive rated torque)	200				0	0
×	07-25	Forward Regenerative Torque Limit	0-300% (motor drive rated torque)	200				0	0
N	07-26	Reverse Motor Torque Limit	0-300% (motor drive rated torque)	200				0	0
×	07-27	Reverse Regenerative Torque Limit	0-300% (motor drive rated torque)	200				0	0
×	07-28	Emergency Stop (EF) & Forced Stop	0: Coast to stop 1: According to deceleration time 1 2: According to deceleration time 2 3: According to deceleration time 3 4: According to deceleration time 4 5: According to Pr.01-31	0	0	0	0	0	0
×	07-29	Time for Decreasing Torque at Stop	0.000-5.000 sec.	0.000				0	0
×	07-30	DC Brake Current Level at Stop	0-100% (motor drive rated current)	0	0	0	0		
×	07-31	Drive Output Torque	0.0–300.0%	0.0	0	0	0	0	0
	07-32	Brake Torque Test Function	0: No function 1: Brake torque test	0	0	0	0	0	0
	07-33	Brake Torque Test Distance	0–65535 ppr	0	0	0	0	0	0
	07-34	Brake Torque Test Time	0.0-5.0 sec.	5.0	0	0	0	0	0
	07-35	Most Recent Output Torque Ratio before Brake Torque Test Failure	0.00–3.00	Read only	0	0	0	0	0
×	07-36	Minimum Output Torque Ratio Allowed during Brake Torque Test	0.00–2.00	0.00	0	0	0	0	0
×	07-37	Maximum Output Torque Ratio Allowed during Brake Torque Test	0.00–2.00	0.00	0	0	0	0	0

08 PM Parameters

Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
08-00	Motor Auto-tuning	O: No function 1: Only for an unloaded motor, auto-measures the angle between magnetic pole and PG origin (Pr.08-09) 2: For PM parameters (suggested to lock the brake) 3: Auto-measures the angle between magnetic pole and PG origin (Pr.08-09)	0					0
08-01	Motor Rated Current	(40-120%) * Pr.00-01 Amps	#.##					0
08-02	Motor Rated Power	0.00–655.35 kW	#.##					0
08-03	Motor Rated Speed (rpm)	0–65535 rpm	1710					0
08-04	Number of Motor Poles	2–96	4					0
08-05	Motor Rs	$0.000-65.535~\Omega$	0.000					0
08-06	Motor Ld	0.0–6553.5 mH	0.0					0
08-07	Motor Lq	0.0–6553.5 mH	0.0					0
08-08	Back Electromotive Force	0.0-6553.5 V rms	0.0					0
08-09	Angle between Magnetic Pole and PG Origin	0.0–360.0°	360.0					0
08-10	Magnetic Pole Reorientation	0: Disable 1: Enable	0					0

09 Communication Parameters

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
×	09-00	Communication Address	1–254	1					
×	09-01	Transmission Speed	4.8-115.2 kbps	19.2	0	0	0	0	0
×	09-02	Transmission Fault Treatment	0: Warn and keep operation 1: Fault and ramp to stop 2: Reserved 3: No action and no display	3	0	0	0	0	0
×	09-03	Time-out Detection	0.0–100.0 sec. 0.0: Disable	0.0	0	0	0	0	0
N	09-04	Communication Protocol	0: 7N1 (ASCII) 1: 7N2 (ASCII) 2: 7E1 (ASCII) 3: 7O1 (ASCII) 4: 7E2 (ASCII) 5: 7O2 (ASCII) 6: 8N1 (ASCII) 7: 8N2 (ASCII) 8: 8E1 (ASCII) 9: 8O1 (ASCII) 10: 8E2 (ASCII) 11: 8O2 (ASCII) 12: 8N1 (RTU) 13: 8N2 (RTU) 14: 8E1 (RTU) 15: 8O1 (RTU) 16: 8E2 (RTU) 17: 8O2 (RTU)	13	0	0	0	0	0
×		Response Delay Time	0.0–200.0 ms	2.0	0	0	0	0	0
	09-06 - 09-13	Direct docki	ng mode only ◆	-		0		0	0
	09-14	PDO Transmission Interval	0–65535 ms	0	0	0	0	0	0



10 Feedback Control Parameters

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
	10-00	Selection of Encoder	0: Disable 1: ABZ 2: ABZ+Hall 3: SIN/COS+Sinusoidal 4: SIN/COS+Endat 5: SIN/COS 6: SIN/COS+Hiperface	0		0		0	0
	10-01	Encoder PPR	1–25000	2048		0		0	0
		Encoder Input Type Setting	 0: Disable 1: Phase A leads in a forward run command and phase B leads in a reverse run command 2: Phase B leads in a forward run command and phase A leads in a reverse run command 3: Phase A is a pulse input and phase B is a direction input (low input = reverse direction, high input = forward direction) 4: Phase A is a pulse input and phase B is a direction input (low input = forward direction, high input = forward direction, high input = reverse direction) 5: Single-phase input 	0		0		0	0
N	10-03	Encoder Feedback Signal Fault Action (PGF1, PGF2)	Warn and keep operation Fault and ramp to stop Fault and stop operation	2		0		0	0
×	10-04	Encoder Feedback Signal Fault Detection Time	0.0-10.0 sec.	1.0		0		0	0
N	10-05	Encoder Stall Level (PGF3)	0–120% (0: Disable)	115		0	0	0	0
×	10-06	Encoder Stall Detection Time	0.0–2.0 sec.	0.1		0	0	0	0
N	10-07	Encoder Slip Range (PGF4)	0–50% (0: Disable)	50		0	0	0	0
N	10-08	Encoder Slip Detection Time	0.0-10.0 sec.	0.5		0	0	0	0
N	10-09	Encoder Stall and Slip Error Action	0: Warn and keep operation 1: Fault and ramp to stop 2: Fault and stop operation	2		0	0	0	0
	10-10	Mode Selection for UVW Input	0: Z signal is at the falling edge of U-phase1: Z signal is at the rising edge of U-phase	0		0		0	0

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
*	10-11	Zero Speed	0.0–1000.0%	100.0	0	0	0	0	0
*	10-12	ASR (Auto Speed Regulation) Control (I) of Zero Speed	0.000-10.000 sec.	0.100	0	0	0	0	0
×	10-13	ASR (Auto Speed Regulation) Control (P) 1	0.0–1000.0%	100.0	0	0	0	0	0
*	10-14	ASR (Auto Speed Regulation) Control (I) 1	0.000-10.000 sec.	0.100	0	0	0	0	0
×	10-15	ASR (Auto Speed Regulation) Control (P) 2	0.0–1000.0%	100.0	0	0	0	0	0
×	10-16	ASR (Auto Speed Regulation) Control (I) 2	0.000-10.000 sec.	0.100	0	0	0	0	0
×	10-17	ASR 1/ ASR2 Switch Frequency	0.00–299.00 Hz (0: Disable)	7.00	0	0	0	0	0
×	10-18	ASR Primary Low Pass Filter Gain	0.001–0.350 sec.	0.008	0	0	0	0	0
×	10-19	Zero Speed Position Control Gain (P)	0.00–655.00%	80.00					0
×	10-20	Low Speed ASR Width Adjustment	0.00–299.00 Hz	5.00		0		0	0
×	10-21	High Speed ASR Width Adjustment	0.00–299.00 Hz	5.00		0		0	0
×	10-22	Zero Speed Position Control Holding Time	0.001–65.535 sec.	0.250					0
*	10-23	Zero Speed Position Control Low Pass Filter Time	0.001–65.535 sec.	0.004					0
*	10-24	Zero Speed Position Control Activation Mode Selection	0: After the brake release set in Pr.02-29 1: After the brake signal input (Pr.02-01–Pr.02-08 is set to 42)	0					0
×	10-25	Elevator Leveling (Zero Speed Gain P)	0.0–1000.0%	100.0	0	0	0	0	0
×	10-26	Elevator Leveling (Zero Speed Integral I)	0.000-10.000 sec.	0.100	0	0	0	0	0
*	10-27	Elevator Starting (Zero Speed Gain P)	0.0–1000.0%	100.0	0	0	0	0	0
×	10-28	Elevator Starting (Zero Speed Integral I)	0.000-10.000 sec.	0.100	0	0	0	0	0
×	10-29	PG Card Frequency Division Output	0–31	0		0		0	0
×	10-30	PG Card Frequency Division Output Type	0000h–0008h	0000h		0		0	0
	10-31	PG Card C+/C-	0000h–0001h	0000h					

Chapter 11 Summary of Parameter Settings | VFD-ED

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
N	10-32	Over-acceleration Level	0.0–20.0 m/s ²	0.0	0	0	0	0	0
	10-33	Over-acceleration Detection Time	0.01-5.00 sec.	0.05	0	0	0	0	0
	110_37	Over-acceleration Detection Selection	Always detect Detect during operation	0	0	0	0	0	0

11 Advanced Parameters

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
	11-00	System Control	Bit 0 = 0: No function Bit 0 = 1: ASR auto-tuning; PDFF enabled Bit 7 = 0: No function Bit 7 = 1: Zero speed position control is enabled Bit 9 = 0: Dynamic PG origin auto- tuning with load (support by PGHSD-1) Bit 9 = 1: Static PG origin auto- tuning with load by enabling PGHSD-1 Bit 15 = 0: Detect the position of magnetic pole again when power is applied Bit 15 = 1: Start from the magnetic pole position of the previous power failure when power is applied	0				0	0
×	11-01	Elevator Speed	0.10–4.00 m/s	1.00				0	0
×	11-02	Traction Sheave Diameter	100–2000 mm	400				0	0
×	11-03	Gear Ratio	1.00-100.00	1.00				0	0
*	11-04	Suspension Ratio	0 = 1:1 1 = 2:1 2 = 4:1 3 = 8:1	1				0	0
N	11-05	Mechanical Inertial Ratio	1–300%	40				0	0
N	11-06	Zero speed Bandwidth	1–40 Hz	10				0	0
~		Low speed Bandwidth	1–40 Hz	10				0	0
~		High speed Bandwidth	1–40 Hz	10				0	0
~		PDFF Gain Value	0–200%	30				0	0
~	11-10	Speed Feed Forward Gain	0–500	0				0	0
×	11-11	Notch Filter Depth	0–20 db	0				0	0
×	11-12	Notch Filter Frequency	0.00–200.00 Hz	0.00				0	0
×	11_13	Keypad Display for Low Pass Filter Time	0.001–65.535 sec.	0.500	0	0	0	0	0
×	11-14	Motor Current at Acceleration	50–200%	150					0
×	11-15	Carriage Acceleration	0.20–2.00 m/s ²	0.75					0
	11-16	Reserved							
	11-17	Reserved							
	11-18	Reserved							
×	11-19	Zero Speed Parking Bandwidth	1–40 Hz	10				0	0

Chapter 11 Summary of Parameter Settings | VFD-ED

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
×	11-20	PWM Mode	0: DPWM mode (Digital Pulse- Width Modulation Mode) 1: SVPWM mode (Space-Vector Pulse Width Modulation Mode)	0					
×	11-21	Filter Time Display on KPED-LE01	0.001–65.535 sec.	0.500	0	0	0	0	0

12 User-defined Parameters

User-defined Parameters include parameters from Group 00–11.

	Pr.	Parameter Name	Setting Range	Default	VF	VFPG	SVC	FOCPG	FOCPM
×	12-00	User-defined Parameter 1	0–9999	0616	0	0	0	0	0
N	12-01	User-defined Parameter 2	0-9999	0632	0	0	0	0	0
N	12-02	User-defined Parameter 3	0–9999	0633	0	0	0	0	0
N	12-03	User-defined Parameter 4	0–9999	0653	0	0	0	0	0
×	12-04	User-defined Parameter 5	0-9999	0654	0	0	0	0	0
×	12-05	User-defined Parameter 6	0–9999	0655	0	0	0	0	0
×	12-06	User-defined Parameter 7	0-9999	0656	0	\circ	0	0	0
×	12-07	User-defined Parameter 8	0–9999	0657	0	0	0	0	0
×	12-08	User-defined Parameter 9	0–9999	0658	0	0	0	0	0
N	12-09	User-defined Parameter 10	0–9999	0659	0	0	0	0	0
×	12-10	User-defined Parameter 11	0–9999	0660	0	0	0	0	0
N	12-11	User-defined Parameter 12	0–9999	0661	0	0	0	0	0
N	12-12	User-defined Parameter 13	0–9999	0662	0	0	0	0	0
×	12-13	User-defined Parameter 14	0–9999	0663	0	0	0	0	0
N	12-14	User-defined Parameter 15	0–9999	0664	0	0	0	0	0
×	12-15	User-defined Parameter 16	0–9999	0617	0	0	0	0	0
N	12-16	User-defined Parameter 17	0–9999	0634	0	0	0	0	0
×	12-17	User-defined Parameter 18	0–9999	0635	0	0	0	0	0
×	12-18	User-defined Parameter 19	0–9999	0618	0	0	0	0	0
×	12-19	User-defined Parameter 20	0–9999	0636	0	0	0	0	0
×	12-20	User-defined Parameter 21	0–9999	0637	0	0	0	0	0
×	12-21	User-defined Parameter 22	0–9999	0619	0	0	0	0	0
×	12-22	User-defined Parameter 23	0–9999	0638	0	0	0	0	0
×	12-23	User-defined Parameter 24	0–9999	0639	0	0	0	0	0
×	12-24	User-defined Parameter 25	0–9999	0620	0	0	0	0	0
×	12-25	User-defined Parameter 26	0–9999	0640	0	0	0	0	0
×	12-26	User-defined Parameter 27	0–9999	0641	0	0	0	0	0
×	12-27	User-defined Parameter 28	0–9999	0621	0	0	0	0	0
×	12-28	User-defined Parameter 29	0–9999	0642	0	0	0	0	0
×	12-29	User-defined Parameter 30	0–9999	0643	0	0	0	0	0
×	12-30	User-defined Parameter 31	0–9999	0	0	0	0	0	0
×	12-31	User-defined Parameter 32	0–9999	1561	0	0	0	0	0

13 View User-defined Parameters

Pr.	Parameter Name Parameter Group 12 Setting Values	Display Address Pr.00-00–Pr.11-20	Default	VF	VFPG	SVC	FOCPG	FOCPM
13-00	Present Fault Record	0616	-	0	0	0	0	0
13-01	Motor Operation at Present Fault Time (min.)	0632	-	0	0	0	0	0
13-02	Motor Operation at Present Fault Time (day)	0633	-	0	0	0	0	0
13-03	Frequency Command at Present Fault	0653	-	0	0	0	0	0
13-04	Output Frequency at Preset Fault	0654	-	0	0	0	0	0
13-05	Output Current at Present Fault	0655	-	0	0	0	0	0
13-06	Motor Frequency at Present Fault	0656	-	0	0	0	0	0
13-07	Output Voltage at Present Fault	0657	-	0	0	0	0	0
13-08	DC Bus Voltage at Present Fault	0658	-	0	0	0	0	0
13-09	Output Power at Present Fault	0659	-	0	0	0	0	0
	Output Torque at Present Fault	0660	-	0	0	0	0	0
13-11	Power Module IGBT Temperature at Present Fault	0661	-	0	0	0	0	0
13-12	Multi-function Terminal Input Status at Present Fault	0662	-	0	0	0	0	0
13-13	Multi-function Terminal Output Status at Present Fault	0663	-	0	0	0	0	0
13-14	Drive Status at Present Fault	0664	-	0	0	0	0	0
13-15	Second Most Recent Fault Record	0617	-	0	0	0	0	0
13-16	Motor Operation at Second Most Recent Fault Time (min.)	0634	-	0	0	0	0	0
13-17	Motor Operation at Second Most Recent Fault Time (day)	0635	-	0	0	0	0	0
	Third Most Recent Fault Record	0618	-	0	0	0	0	0
13-19	Motor Operation at Third Most Recent Fault Time (min.)	0636	-	0	0	0	0	0
13-20	Motor Operation at Third Most Recent Fault Time (day)	0637	-	0	0	0	0	0
13-21	Fourth Most Recent Fault Record	0619	-	0	0	0	0	0
13-22	Motor Operation at Fourth Most Recent Fault Time (min.)	0638	-	0	0	0	0	0
13-23	Motor Operation at Fourth Most Recent Fault Time (day)	0639	-	0	0	0	0	0
13-24	Fifth Most Recent Fault Record	0620	-	0	0	0	0	0
13-25	Motor Operation at Fifth Most Recent Fault Time (min.)	0640	-	0	0	0	0	0
13-26	Motor Operation at Fifth Most Recent Fault Time (day)	0641	-	0	0	0	0	0
13-27	Sixth Most Recent Fault Record	0621	-	0	0	0	0	0
13-28	Motor Operation at Sixth Most Recent Fault Time (min.)	0642	-	0	0	0	0	0

Chapter 11 Summary of Parameter Settings | VFD-ED

Pr.	Parameter Name Parameter Group 12 Setting Values	Display Address Pr.00-00–Pr.11-20	Default	VF	VFPG	SVC	FOCPG	FOCPM
13-29	Motor Operation at Sixth Most Recent Fault Time (day)	0643	-	0	0	0	0	0
13-30	AC Motor Drive Identity Code	0	-	0	0	0	0	0
13-31	Date Code Y.WKD	1561	Read only	0	0	0	0	0

Chapter 12 Descriptions of Parameter Settings

- 00 Drive Parameters
- 01 Basic Parameters
- 02 Digital Input / Output Parameters
- 03 Analog Input / Output Parameters
- 04 Multi-step Speed Parameters
- 05 IM Parameters
- 06 Protection Parameters
- 07 Special Parameters
- 08 PM Parameters
- 09 Communication Parameters
- 10 Speed Feedback Parameters
- 11 Advanced Parameters
- 12 User-defined Parameters
- 13 View User-defined Parameters

00 Drive Parameters

★: You can set this parameter during operation

					/· . 104 0411 00t t	ine parameter daring operation						
AC Motor Drive Identity Code												
Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: ##						
	Settings	Read Or	ıly									
88-81	AC Mot	or Drive F	Rated (Current Dis	play							
Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: ##						
	Settings	Read Or	ıly (Disp	lay by model))							

- Pr.00-00 displays the AC motor drive identity code. The capacity, rated current, rated voltage and the maximum carrier frequency relate to the identity code. Use the following table to check how the AC motor drive rated current, rated voltage, and maximum carrier frequency correspond to the identity code.
- Pr.00-01 displays the AC motor drive rated current. By reading this parameter, you can check if the AC motor drive is correct.

				230V m	nodels						
Power (kW)	2.2*	3.7*	4.0	5.5	7.5	11	15	18.5	22	30	37
Horsepower (HP)	3	5	5	7.5	10	15	20	25	30	40	50
Motor Drive ID Code (Pr.00-00)	108	110	10	12	14	16	18	20	22	24	26
Rated Output Current for General Purposes (A)	12.0	17.0	20	24	30	45	58	77	87	132	161
Range of the Carrier Frequency				2–	15 kHz					2–9	kHz
Rated Max. Output Carrier Frequency		8 kHz		10 kHz				8 kHz		6 k	κHz

^{*}VFD022ED21S and VFD037ED21S are single-phase models.

	460V models												
Power (kW)	4.0	5.5	7.5	11	15	18.5	22	30	37	45	55	75	
Horsepower (HP)	5	7.5	10	15	20	25	30	40	50	60	75	100	
Motor Drive ID Code (Pr.00-00)	11	13	15	17	19	21	23	25	27	29	31	33	
Rated Output Current for General Purposes (A)	11.5	13	17	23	30	38	45	58	80	100	128	165	
Range of the Carrier Frequency			2-	–15 kH	Z			2–9 kHz 2–6 k					
Rated Max. Output Carrier Frequency	8 kHz	3 kHz 10 kHz				8 kHz				6 kHz			

Parameter Reset **VFPG** Control Mode **SVC FOCPG FOCPM** Default: 0 0: No Function Settings 1: Read Only 5: Direct docking mode only, contact Delta for more information. 8: Keypad Locked 9: Reset all parameters to defaults (50 Hz) 10: Reset all parameters to defaults (60 Hz) 1: Set all parameters to read-only except Pr.00-00–Pr.00-07, and you can use this setting with the password setting for password protection. 9 or 10: Reset all parameters to the default. If the keypad is locked by a password, enter the password to reset to the default. The password is also erased. 8: Lock the keypad and only Pr.00-02 and Pr.00-07 can be changed. Control Mode **VFPG** SVC **FOCPG FOCPM** Default: 0 0: Display the Frequency command value (LED F) Settings 1: Display the actual output frequency (LED H) 2: DC bus voltage (V) 3: Display the output current (A) 4: Output voltage (E) 5: User-defined (see Pr.00-04)

Determines the start-up display page after power is applied to the drive.

Content of Multi-function Display

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Cottings 0: Display the output current supplied to the motor from the drive (A

Settings

- 0: Display the output current supplied to the motor from the drive (A) (Unit: Amp)
- 1: Reserved
- 2: Display the drive's actual output frequency (H) (Unit: Hz)
- 3: Display the drive's DC bus voltage (v) (Unit: VDC)
- 4: Display the terminals U, V, and W output voltage of the drive (E) (Unit: V_{AC})
- 5: Display the terminals U, V, and W output power factor angle to the motor (n) (Unit: deg)
- 6: Display the terminals U, V, and W output power to the motor (P) (Unit: kW)
- 7: Display the actual motor speed in rpm (r) (Unit: rpm)
- 8: Display the drive's estimated output torque in %; the motor's rated torque is 100% (t) (Unit: %)
- 9: Display the PG feedback (G) (See Pr.10-00 and Pr.10-01)
- 10: Display the electrical angle of drive output (d) (Unit: deg)
- 11: Display the AUI1 analog input terminal signal (1.) (Unit: %)
- 12: Reserved

- 13: Display the AUI2 analog input terminal signal (Unit: %)
- 14: Display the drive's heat sink temperature (t) (Unit: °C)
- 15: Display the IGBT temperature (T) (Unit: °C)
- 16: Display digital input status ON/OFF (i)
- 17: Display digital output status ON/OFF (o)
- 18: Display the step speed of multi-step speed that is executing (S)
- 19: The corresponding CPU digital input pin status (i.)
- 20: The corresponding CPU digital output pin status (o.)
- 21-23: Reserved
- 24: Output AC voltage when malfunction occurred (E) (Unit: VAC)
- 25: Output DC voltage when malfunction occurred (v) (Unit: V_{DC})
- 26: Motor frequency when malfunction occurred (H) (Unit: Hz)
- 27: Output current when malfunction occurred (A) (Unit: Amp)
- 28: Output frequency when malfunction occurred (F) (Unit: Hz)
- 29: Frequency command when malfunction occurred (F) (Unit: Hz)
- 30: Output power when malfunction occurred (P) (Unit: kW)
- 31: Output torque when malfunction occurred (t) (Unit: %)
- 32: Input terminal status when malfunction occurred (i)
- 33: Output terminal status when malfunction occurred (o)
- 34: Drive status when malfunction occurred (s)
- 35: Display MI and MO status on digital keypad
- 36: CAN communication interference index (c) (Unit: %)
- 37: Multi-function display selection (q) (Unit: %)
- 40: Elevator actual speed (Unit: m/s)

This parameter displays the content on the digital keypad KPC-CC01 on page U. Use this parameter to get the AC motor drive's status.

Example 01

Termir	al MI8	MI7	MI6	MI5	MI4	MI3	MI2	MI1	REV	FWD
Statu	s 0	0	1	0	0	0	0	1	1	0

0: OFF, 1: ON

MI1: Set Pr.02-01 to 1 (multi-step speed command 1).

MI8: Set Pr.02-08 to 8 (the 1st, 2nd acceleration/deceleration time selection).

If REV, MI1 and MI8 are ON, the value is 0000 0000 1000 01102 in binary and 0086H in HEX. Meanwhile, if you set Pr.00-04 to 16 or 19, the keypad KPC-CC01 displays "0086" and LED U is ON. Pr.00-04=16 is the status of the digital input and Pr.00-04=19 is the corresponding CPU digital input pin status. Set the parameter to 16 to monitor the digital input status and then set to 19 to check if the wire is normal.


Example 02

Terminal	MO8	MO7	MO6	MO5	MO4	МОЗ	MO2	MO1	R2A	R1A	MRA	RA
Status	0	0	0	0	1	0	0	0	0	1	1	0

RA: Set Pr.02-11 to 9 (Drive ready)

After applying the power to the AC motor drive, if there is no other error, the contact is ON. If you set Pr.00-04 to 17 or 20, the keypad displays 0001 and LED U is ON. Pr.00-04=17 is the status of digital output and Pr.00-04=20 is the corresponding CPU digital output pin status. Set the parameter to 17 to monitor the digital output status and then set to 20 to check if the wire is normal.

Setting value 40 (elevator actual speed) displays as below on keyboard panel KPED-LE01:



Elevator runs downward:



✓ ☐☐ - ☐ 5 User-defined Coefficient K

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings Digit 4: number of decimal points (0-3)

Digit 0-3: 40-9999

Digital setting method

Digital 4: number of decimal points (0: no decimal points, 1: one decimal point and so on.)

Digit 0–3: 40–9999 (the corresponding value for the maximum frequency).

Meaning of numerical order

For example, if you use rpm to display the motor speed, and the corresponding value for the four-pole motor, 60 Hz is 1800. You can set this parameter to 1800 to indicate that the corresponding value for 60 Hz is 1800 rpm. If the unit is rps, set to 10300 to indicate that the corresponding value for 60 Hz is 30.0 (one decimal point).

Decimal Point Number

- The frequency setting only displays as the rpm value. For example, 60 Hz is displayed as 1800 rpm.
- After you set Pr.00-05, the keypad does not display the frequency unit "Hz" after returning to the Main menu.

Software Version

Control Mode VF VFPG SVC FOCPG FOCPM Default: ##.##

Settings Read Only

Password Input

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings 1–9998, 10000–65535

Display 0–2 (number of wrong password attempts)

Chapter 12 Descriptions of Parameter Settings | VFD-ED

- Inputs the password that is set in Pr.00-08. Enter the correct password here to enable changing parameters. You are limited to a maximum of three attempts. After three consecutive failed attempts, "Password Error" is displayed, and you must restart the AC motor drive before you can try again to enter the correct password.
- If you forget the password, you can decode by setting this parameter to 9999 and press the PROG/DATA button () twice. Note that this resets the settings to the default.

✓ ☐☐ - ☐☐ Password Set

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0


Settings 1–9998, 10000–65535

Display 0: No password set or successful input in Pr. 00-07

1: Password has been set

- This parameter is for setting the password protection. Password can be set directly the first time. After you set the password, the value of Pr.00-08 is 01, which means password protection is activated. However, if the value of Pr.00-08 is 00, the password protection is deactivated, which means you can change any of the parameter settings (including resetting the parameter protection password for Pr.00-08). When Pr.00-08 is 01 and if you want to change any of the parameter settings, you must enter the correct password in Pr.00-07 to deactivate the password, and this would make Pr.00-08 become 00. Note that if you set this parameter to 00 again, the password protection function is permanently deactivated. Otherwise, password protection is always reactivated after you reboot the motor drive. If you want to change any of the parameter settings after rebooting the motor drive, enter the correct password in Pr.00-07 to deactivate the password.
- How to make the password valid again after decoding by Pr.00-07:
 - Method 1: Re-enter the original password into Pr.00-08 (or you can enter a new password if you want to use a changed or new one).
 - Method 2: After rebooting, the password function is restored.
 - Method 3: Entering a non-password value into Pr.00-07.

Password Decode Flow Chart



Control Mode

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings 0: V/F control (V/F)

1: V/F control + Encoder (VFPG)

2: Sensorless Vector Control (SVC)

3: FOC vector control + Encoder (FOCPG)


8: FOC Permanent Motor control (FOCPM)

Mode selection:


Settings	Control Mode	Applicable Motor Type	Speed Feedback	Energy- savings	Tuning Difficulty	Ride Comfort	Speed Control Range	Motor Parameter Tuning	Basic Control	Speed Control
0	V/F	IM		Low	Low	Normal	1:50		V/F control	Voltage control
1	VFPG	IM	✓	Medium	Medium	Normal	1:50	✓	Frequency control	Frequency control
2	SVC	IM		Medium	Medium	Normal	1:50	✓	Voltage control	Voltage control
3	FOCPG	IM	✓	High	High	Good	1:1000	✓	Vector control	Frequency control
8	FOCPM	PM	✓	High	High	Good	1:1000	✓	Vector control	Frequency control

- Determines the AC motor drive control method.
 - 0: You can set the V/F ratio as required and control multiple motors simultaneously.
 - 1: You can use a PG card with an encoder for closed-loop speed control.
 - 2: Use auto-tuning for optimal settings of the control parameters.
 - 3: To increase torque and the accuracy of the speed control (1:1000).
 - 8: To increase torque and the accuracy of the speed control (1:1000). This setting is for use only with permanent magnet motors. The other settings are for use with induction motors.


When Pr.00-09=0, V/F control (V/F) control diagram is as follows:




When Pr.00-09=1, V/F control + Encoder (VFPG) control diagram is as follows:




When Pr.00-09=2, Sensorless Vector Control (SVC) control diagram is as follows:



When Pr.00-09=3, FOC vector control + Encoder (FOCPG) control diagram is as follows:



When Pr.00-09=8, FOC Permanent Motor control (FOCPM) control diagram is as follows:



✓

Speed Unit

Speed Uni

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings 0: Hz

1: m/s

2: ft/s

3: Direct docking mode only, contact Delta for more information.

Output Direction Selection

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings 0: FWD: counterclockwise, REV: clockwise

1: FWD: clockwise, REV: counterclockwise

✓ ☐☐ - ☐☐ Carrier Frequency

Control Mode VF VFPG SVC FOCPG FOCPM Default:12

Settings 2-15 kHz

Determines the PWM carrier frequency for the AC motor drive.

Models	3–5 HP	7.5–15 HP	20-30 HP	40–60 HP	75–100 HP
Settings	2–15 kHz	2–15 kHz	2–15 kHz	2–9 kHz	2–6 kHz
Default	8 kHz	10 kHz	8 kHz	6 kHz	6 kHz

Carrier Frequency	Acoustic Noise	Electromagnetic Noise or Leakage Current	Heat Dissipation	Current Wave
2 kHz	Significant 	Minimal 	Minimal 🛕	-
8 kHz				
15 kHz	Minimal 🔻	Significant 🔻	Significant 🔻	-√√//

- From the table, you see that the PWM carrier frequency has significant influences on the motor's electromagnetic noise, the AC motor drive heat dissipation, and the motor acoustic noise. Therefore, if the surrounding noise is greater than the motor noise, lower the carrier frequency to reduce the temperature rise. Although the motor has quiet operation in the higher carrier frequency, consider the entire wiring and interference.
- If you set the carrier frequency higher than the defaults in the table above, the motor drive derates the capacity. See Carrier Frequency Derating Capacity (Fc) in Chapter 08.

Automatic Voltage Regulation (AVR) Function

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings 0: Enable AVR

1: Disable AVR

2: Disable AVR when decelerating to stop

The AVR function automatically regulates the AC motor drive output voltage to the motor's rated voltage when the input power is larger than the motor's rated voltages. For instance, if you set V/F curve to 200 V_{AC}/50 Hz and the input voltage is between 200–264 V_{AC}, then the output voltage to the motor is

Chapter 12 Descriptions of Parameter Settings | VFD-ED

automatically regulated to 200 $V_{AC}/50$ Hz. If the input voltage is from 180 to 200 V_{AC} , the output voltage to the motor and the input voltage is in direct proportion to the input voltage.

When the motor stops with deceleration, it shortens the deceleration time with AVR disabled. Setting this parameter to 1 with auto-acceleration/auto-deceleration results in quicker deceleration.

★ III - II Master Frequency Command Source

Control Mode VF VFPG SVC FOCPG FOCPM Default:1

Settings 1: RS-485 serial communication or digital keypad (KPC-CC01)

2: External analog input (Pr.03-00)

3: Digital terminal inputs

4: Direct docking mode only, contact Delta for more information.

Determines the drive's master frequency source.

✓ ☐☐ - 15 Operation Command Source

Control Mode VF VFPG SVC FOCPG FOCPM Default:1

Settings 1: External terminals

2: RS-485 serial communication or digital keypad (KPC-CC01)

- The ED series motor drives are shipped without a digital keypad, but you can use the external terminals or RS-485 to control the operation command.
- When the LED PU is ON, you can control the operation command with the optional digital keypad. (Refer to Chapter 09 for more information about the digital keypad KPC-CC01).


01 Basic Parameters

					∦ : You	ı can se	et this parameter during operation
8 :-88 N	/laximui	m Outpu	ıt Frequ	iency			, 3,
Control Mode	VF	VFPG	svc	FOCPG	FO	СРМ	Default: 60.00/50.00
S	Settings	5.00–29	9.00 Hz				
Determines	the AC i	motor driv	e's Maxi	mum Outpu	ıt Frequency	. All the	AC motor drive frequency command
sources (ar	nalog inpi	uts -10–10	V) are	scaled to co	orrespond to	the outp	out frequency range.
0 1-0 1	st Outp	ut Frequ	iency S	Setting (ba	ase frequer	ncy/ m	otor's rated frequency)
Control Mode	VF	VFPG	SVC	FOCPG	FO	CPM	Default: 60.00/50.00
<u>_</u>	Settings	0.00–29	9.00 Hz				
Set this par	ameter a	ccording	to the ra	ted frequen	cy on the mo	tor nam	neplate. If the motor is 60 Hz, set this
parameter t	to 60. If tl	he motor i	s 50 Hz,	set it to 50.			
8 1-82 1	st Outp	out Volta	ae Sett	ing (base	voltage/ m	notor's	rated voltage)
Control Mode	VF	VFPG	SVC	FOCPG	FOC		Default: 220.0/440.0
S	Settings	230V m	odels 0.	1–255.0 V			
		460V m	odels 0.	1–510.0 V			
☐ Set this par	ameter a	ccording	to the ra	ted voltage	on the motor	namep	late. If the motor is 220 V, set this
parameter t	to 220.0.	If the mot	or is 200	V, set this	parameter to	200.0.	
There are n	nany mot	tor types i	n the ma	rket and the	e power syste	em for e	each country is also different. The
economical	l and con	venient so	olution is	to install ar	n AC motor d	lrive. Th	en there is no problem using the
motor with	different	voltage ar	nd freque	ency inputs,	and the mot	or drive	can improve the original motor
characteris	tics and ι	useful life.					
0:-03 s	Second	Output F	- regue	ncv Settin	α		
Control Mode	VF	VFPG	. oquo.	,	9		Default: 0.50
S	Settings	0.00–29	9.00 Hz				
		Output \	/oltage	Setting			
Control Mode	VF	VFPG	5	J			Default: 5.0/10.0
S	Settings	230V m	odels 0.	1–255.0 V			
		460V m	odels 0.	1–510.0 V			
01-05 T	hird Ou	ıtput Fre	quency	y Setting			
Control Mode	VF	VFPG					Default: 0.50
S	Settings	0.00-29	9.00 Hz				
0:-08 T	hird Ou	ıtput Vol	tage S	etting			
Control Mode	VF	VFPG					Default: 5.0/10.0
S	Settings	230V m	odels 0.	1–255.0 V			
		460V m	odels 0.	1–510.0 V			
8 1-87 F	ourth C	output Fi	requen	cy Setting			
Control Mode	VF	VFPG	svc	FOCPG			Default: 0.00
S	Settings	0.00-29	9.00 Hz				

Control Mode VF VFPG SVC Default: 5.0/10.0

Settings 230V models 0.1–255.0 V 460V models 0.1–510.0 V

- You usually set the V/F curve according to the motor's allowable loading characteristics. Pay special attention to the motor's heat dissipation, dynamic balance, and bearing lubrication when the loading characteristics exceed the loading limit of the motor.
- The frequency setting of V/F curve must be set according to this rule: Pr.01-01 ≥ Pr.01-03 ≥ Pr.01-05 ≥ Pr.01-07. There is no limit for the voltage setting, but a high voltage at low frequency may cause motor burnout, overheating, and trigger stall prevention or over-current protection. Use I
- w voltages at low frequencies to prevent motor damage or drive malfunction.



G!-09 Starting Frequency


Control Mode VF VFPG SVC FOCPG Default: 0.50

Settings 0.00–299.00 Hz

Determines the starting frequency. When the starting frequency (Pr.01-09) is larger than the output frequency (Pr.01-11), the frequency output starts when the starting frequency (Pr.01-09) reaches the F command.

When min. output frequency > start frequency

When start frequency > min. output frequency




					12 200011ptil	ons of i arameter oethings Vi b-
8 1- 18	Output I	Frequen	су Upp	er Limit		
Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 299.00
	Settings	0.00-29	99.00 Hz	:		
!!-!!	Output I	Frequen	cy Low	er Limit		
Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 0.00
	Settings	0.00–29	99.00 Hz			
Use the u	pper/lowe	r output fr	equency	settings to li	mit the actual output fr	equency. If the frequency settir
is lower th	nan the sta	art-up freq	uency, it	runs with ze	ro speed. If the freque	ncy setting is higher than the
upper lim	it, it runs v	vith the up	per limit	frequency. If	the output frequency	ower limit is larger than output
frequency	upper lim	nit, this fun	iction is i	nvalid.		
v 0 1- 12	Accel T	īme 1				
Control Mode		VFPG	SVC	FOCPG	FOCPM	Default: 3.00
	Settings	0.00–60	00.00 se	C.		
w <u>[] - 3</u>	Decel. 7					
Control Mode		VFPG	SVC	FOCPG	FOCPM	Default: 2.00
	Settings	0.00–60	00.00 se	C.		
W [] - Y	Accel. T	īme 2				
Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 3.00
	Settings	0.00–60	00.00 se	c.		
W 0 1- 15	Decel. 7	Time 2				
Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 2.00
	Settings	0.00–60	00.00 se	c.		
W 0 1- 18	Accel. T	īme 3				
Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 3.00
	Settings	0.00–60	00.00 se	С.		
W [] -]	Decel. 7	Time 3				
Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 2.00
	Settings	0.00–60	00.00 se	C.		
v <u>8 :- :8</u>						
Control Mode		VFPG	SVC	FOCPG	FOCPM	Default: 3.00
	Settings		00.00 se	C.		
	Decel. 7					
Control Mode		VFPG	SVC	FOCPG	FOCPM	Default: 2.00
	Settings		00.00 se			
The Acce	leration Ti	me detern	nines the	e time require	ed for the AC motor dri	ve to ramp from 0.00 Hz to the

Maximum Output Frequency (Pr.01-00). The Deceleration Time determines the time required for the AC

motor drive to decelerate from the Maximum Output Frequency (Pr.01-00) down to 0.00 Hz.


- Select the Acceleration/Deceleration Time 1, 2, 3, 4 with the multi-function input terminal settings. The defaults are Acceleration Time 1 and Deceleration Time 1.
- When there is a large opposing torque and inertial torque for the load, and the acceleration and deceleration time settings are less than the necessary value, then they enable the torque limit and stall prevention functions. When this happens, the actual acceleration and deceleration time are longer than the settings.



Acceleration & Decelertion Time Setting



- You can use both the external terminal JOG and the JOG key on the keypad. When the JOG command is ON, the AC motor drive accelerates from the fourth output voltage setting (Pr.01-07) to the JOG frequency (Pr.01-22). When the JOG command is OFF, the AC motor drive decelerates from the JOG frequency to zero. The Acceleration and Deceleration time are set by these parameters (Pr.01-20, Pr.01-21).
- You cannot execute the JOG command when the AC motor drive is running. When the JOG command is running, other operation commands are invalid except the Forward and Reverse commands.



JOG accel./decel.time

Control Mode VF VFPG SVC FOCPG FOCPM Default: 6.00


Settings 0.00–299.00 Hz

You can use both the external terminal JOG and the JOG key on PU. When the JOG terminal is disabled, the AC motor drive accelerates from 0 Hz to the JOG frequency (Pr.01-22). When the JOG terminal is enabled, the AC motor drive decelerates from the JOG frequency to zero. The Acceleration and Deceleration time are set by these parameters (Pr.01-20, Pr.01-21). You cannot execute the JOG command when the AC motor drive is running. When the JOG command is running, other operation commands are invalid except the Forward and Reverse commands and the STOP key on the digital keypad.

★ 3 1 - 2 3 Switch Frequency between First and Fourth Accel./Decel.

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.00 Settings 0.00–299.00 Hz

Determines the frequency for the transition from acceleration and deceleration time 1 to acceleration and deceleration time 4. You can also enable the transition from acceleration or deceleration time 1 to acceleration and deceleration time 4 with the external terminals (Pr.02-01–Pr.02-08). The external terminal has priority over Pr.01-23.



1st/4th Acceleration/Deceleration Switching

- ✓ ☐ : 2 Y S-curve for Acceleration Begin Time S1
- ★ ☐ 1 2 5 S-curve for Acceleration Arrival Time S2
- ★ 3 1 25 S-curve for Deceleration Begin Time S3
- S-curve for Deceleration Arrival Time S4
- ★ ① ! ③ ② S-curve for Deceleration Arrival Time S5

Control Mode VF VFPG SVC FOCPG FOCPM Default: 1.00 Settings 0.00–25.00 sec.

Switch Frequency for S3/S4 Changes to S5


Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.00

Settings 0.00–299.00 Hz

Using an S-curve gives the smoothest transition between speed changes. The acceleration and deceleration curve adjusts the acceleration and deceleration S-curve. When enabled, the motor drive produces a different acceleration and deceleration curve according to the acceleration and deceleration time.

- The Actual Acceleration Time = selected acceleration Time + (Pr.01-24 + Pr.01-25) ÷ 2.

 The Actual Deceleration Time = selected deceleration Time + (Pr.01-26 + Pr.01-27 + Pr.01-30 x 2) ÷ 2.
- Use Pr.01-29 to set the switch frequency between S4 and S5 for smooth stopping.
- ☐ Set Pr.01-29 to the leveling speed of the elevator.



☐ ! - ☐ ☐ Mode Selection when Frequency < Fmin </p>

Control Mode VF VFPG SVC Default: 1

Settings 0: Output Waiting

1: Zero-speed operation

2: Fmin (Fourth output frequency setting)

- The AC motor drive uses this parameter when it is at 0 Hz.
- 1 or 2: The voltage outputs according to the output voltage command corresponding to Fmin (Pr.01-08).

Market Run Command

Control Mode VF VFPG SVC FOCPG FOCPM Default: 2.00

Settings 0.00–600.00 sec.

The AC motor drive stops according to this parameter when cancelling the RUN command. Refer to the figure in the description for Pr.01-29 for details.

★ ☐ ! - 3 ② Direct docking mode only

Control Mode Default: -

Settings Contact Delta for more information

1 - 3 3 High Speed Time for Short Floor

Control Mode VF VFPG SVC FOCPG FOCPM Default: 3.00

Settings 0.00-60.00 sec.

Sets the high speed duration during short floor operation.

☐ I - 3 Y Leveling Speed Time for Short Floor

Control Mode VF VFPG SVC FOCPG FOCPM Default: 3.00

Settings 0.00-60.00 sec.

Sets the leveling speed duration during short floor operation.

12 Descriptions of Parameter Settings | VFD-ED **Limit for Direct Docking Terminal** Control Mode **VFPG** SVC **FOCPG FOCPM** Default: 2.00 0.00 - 10.00Settings Sets the limit for changing from leveling speed to acceleration when using terminals for direct docking. British Deceleration Distance for Direct Docking Terminal Control Mode **VF VFPG** SVC **FOCPG FOCPM** Default: 30.00 Settings 0.00-10.00 cm Sets the distance between deceleration points. Deceleration Distance Reference for Short Floor **VF VFPG** SVC **FOCPG** Control Mode **FOCPM** Default: Read only Settings 0.00-655.35 m Sets the distance between deceleration points according to short floors (write inhibit). Short Floor/Direct Docking Terminal Enabled **VFPG** SVC **FOCPG** Default: 0000h Control Mode **FOCPM** Settings 0000h: Disabled 0001h: Short floor enabled 0002h: Direct docking terminal enabled 0003h: Short floor + direct docking terminal enabled Related parameters: Pr.02-01–02-08 multi-function input terminal (53: terminal leveling signal for direct docking).


Direct docking terminal function:

When the elevator runs to the leveling area, controller sends a leveling signal to the drive to make the drive stop within effective distance (Pr.01-36). If deceleration distance is too short, the drive adjusts the speed according to the limit for acceleration change (Pr.01-35). Deceleration of direct docking terminal function is calculated through Pr.11-01.

There are two methods for sending leveling signals:

- 1. Using multi-function input terminals (MI=53)
- 2. Deactivate MI1 and MI2 (Multi-step speed command 1 and 2)

Method 1: Direct docking terminal function (using MI terminal to input leveling signals)




The steps to execute direct docking terminal function using multi-function input terminal (MI=53) are as follows:

- 1. The control mode should be in closed-loop. Set Pr.00-01 = 2 (FOCPG) or 3 (FOCPM).
- 2. Set Pr.00-14 = 3 (External digital input).
- 3. Set Pr.00-15 = 1 (External terminals).
- 4. Set Pr.04-00 = 0 (Zero-step speed frequency must be set to 0 Hz).
- 5. Increase Pr.01-13 appropriately in case the elevator stops while having not reached the leveling plate.
- Set Pr.01-35 (Limit for Direct Docking Terminal Function). In normal condition, there is no need to adjust this parameter.
- 7. Set Pr.01-36 (Deceleration Distance for Direct Docking Terminal Function). Enter the length of leveling plate.
- 8. Set Pr.01-38 = 2 (Direct docking terminal function enabled).
- 9. Set multi-function input (MI) terminal to 53.
- 10. Set Pr.11-01 (Elevator speed). Deceleration speed for terminal function direct docking is calculated according to this parameter

NOTE: Before the terminal function direct docking is activated, all speed commands must be disabled (zero-step speed = 0 Hz).

Method 2: Direct docking terminal function (using multi-step speed change)



The steps to execute direct docking terminal function using deactivating multi-step speed command 1 and 2 (MI1 and MI2) are as follows:

- 1. The control mode should be in closed-loop. Set Pr.00-09 = 3 (FOCPG) or 8 (FOCPM).
- 2. Set Pr.00-14 = 3 (External digital input).
- 3. Set Pr.00-15 = 1 (External terminals).
- 4. Set Pr.04-00 = 0 (Zero-step speed frequency must be set to 0 Hz).
- 5. Set Pr.04-01 (First-step Speed Frequency).
- 6. Set Pr.04-03 (Third-step Speed Frequency).
- 7. Increase Pr.01-13 appropriately in case the elevator stops while having not reached the leveling plate.
- 8. Set Pr.01-35 (Limit for Direct Docking Terminal Function). In normal condition, there is no need to adjust this parameter.
- 9. Set Pr.01-36 (Deceleration Distance for Direct Docking Terminal Function). Enter the length of leveling plate.
- 10. Set Pr.01-38 = 2 (Direct docking terminal function enabled).
- 11. Set Pr.11-01 (Elevator speed). Deceleration speed for terminal function direct docking is calculated according to this parameter.

NOTE: Do NOT set multi-function (MI) terminal to 53.

1 - 3 9 Automatic Emergency Deceleration Level

Control Mode VFPG FOCPG FOCPM Default: 60.00

Settings 5.00-299.00 Hz


When MI is set to 56, the system monitors the current speed. If the speed is higher than Pr.01-39, the drive decelerates to Pr.01-29 speed according to Pr.01-40 deceleration time.

✓ ☐ ! - Ч☐ Deceleration Time for Emergency Deceleration

Control Mode VFPG FOCPG FOCPM Default: 2.00

Settings 0.00-600.00 sec.

When MI=55 function is triggered, the drive decelerates to Pr.01-29 speed according to Pr.01-40 deceleration time, as shown in the figure below.



02 Digital Input / Output Parameters

★: You can set this parameter during operation

Two-wire//three-wire Operation Control

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings 0: FWD/STOP, REV/STOP

1: FWD/STOP, REV/STOP (Line Start Lockout)

2: RUN/STOP, REV/FWD


3: RUN/STOP, REV/FWD (Line Start Lockout)

4: Three-wire

5: Three-wire (Line Start Lockout)

Three of the six modes include a "Line Start Lockout" feature. When line start lockout is enabled, the motor drive does not run when you apply power. The Line Start Lockout feature does not guarantee that the motor never starts under this condition. It is possible the motor may be set in motion by a mechanical vibration or malfunctioning switch.

This parameter controls operation from external terminals. There are three different control modes.



Multi-function Input Command 1 (MI1) (It is the Stop terminal for three-wire operation)

Default: 1

G = G ≥ Multi-function Input Command 2 (MI2)

Default: 2

Default: 3

Multi-function Input Command 4 (MI4)

Default: 4

Multi-function Input Command 5 (MI5)

Default: 0

Default: 0

Default: 0

Default: 0

Multi-function Input Command 7 (MI7)

Default: 0

Multi-function Input Command 8 (MI8) (Enable Drive terminal)

			D	efault:4	0	
Settings C	ontrol Mode	VF	VFPG	SVC	FOCPG	FOCPM
0: No function		Ο	0	0	0	0
1: Multi-step speed command 1		0	0	0	0	0
2: Multi-step speed command 2		0	0	0	0	0
3: Multi-step speed command 3		0	0	0	0	0
4: Multi-step speed command 4		0	0	0	0	0
5: Reset		0	0	0	0	0
6: JOG command		0	0	0	0	0
7: Acceleration/deceleration speed inhi	bit	0	0	0	0	0
8: First, second acceleration/deceleration	on time	0	0	0	0	0
9: Third, fourth acceleration/deceleration	on time	0	0	0	0	0
10: EF input (Pr.07-28)		0	0	0	0	0
11: Reserved						
12: Stop output		0	0	0	0	0
13-14: Reserved						
15: AUI1 operation speed command		0	0	0	0	0
16: Reserved		0	0	0	0	0
17: AUI2 operation speed command		0	0	0	0	0
18: Emergency Stop (Pr.07-28)		0	0	0	0	0
19–23: Reserved						
24: FWD JOG Command		0	0	0	0	0
25: REV JOG Command		0	0	0	0	0
26: Reserved						
27: ASR1/ASR2 selection		Ο	0	Ο	0	Ο
28: Emergency stop (EF1) (motor coas	sts to stop)	Ο	0	Ο	0	Ο
29-30: Reserved						
31: High torque bias (according to Pr.0	7-21)	0	0	0	0	0
32: Middle torque bias (according to Pr	.07-22)	0	0	0	0	0
33: Low torque bias (according to Pr.07	7-23)	0	0	0	0	0
34–37: Reserved						
38: Disable writing to EEPROM		0	0	0	0	0
39: Torque command direction (0 is pos	sitive					
direction)						
40: Enable drive function		0	0	0	0	0

41: Magnetic contactor detection		0	0	0	0	
42: Mechanical brake 1	0	0	0	0	0	
43: EPS function (Emergency Power System)	0	0	0	0	0	
44: Mechanical brake 2	0	0	0	0	0	
45–51: Direct docking mode only						
53: Terminal leveling signal for direct docking		0		0	0	
54: Power failure signal	0	0	0	0	0	
55: Manual emergency deceleration		0		0	0	
56: Automatic emergency deceleration		0		0	0	
57: Brake torque test action signal	0	0	0	0	0	
59: AFE fault	0	0	0	0	0	

 $[\]hfill \square$ Selects the functions for each multi-function input terminal.


☐ If you set Pr.02-00 to three-wire operation control, terminal MI1 is for STOP terminal, and MI1 is not available for any other operation.

Settings	Functions			Descriptions		
0	No Function					
1	Multi-step speed command 1	15-step speeds controlled through the four terminals, and 17 in				
2	Multi-step speed command 2	total includi	ng the ma	aster speed and JOG (refer to Pr. 04-00–		
3	Multi-step speed command 3	Pr.04-14).				
4	Multi-step speed command 4		=	nication to control the multi-step speed,		
4	Multi-step speed command 4	settings 1-4	4 are inva	ilia.		
5	Reset	After you el	iminate th	ne drive error, use this terminal to reset the		
	110001	drive.				
6	JOG Command	JOG operat	tion			
	Acceleration/deceleration	When enab	led, acce	leration and deceleration are stopped and		
7	Speed Inhibit	the AC motor drive starts to accelerate and decelerate from				
		the inhibit point.				
		You can select the motor drive's acceleration and deceleration				
		time through the terminals; there are four acceleration and				
	The first, second acceleration	deceleration speeds in total.				
8	or deceleration time	Bit 0	Bit 1	Descriptions		
		0	0	First accel./decel. time		
				When output frequency is less than		
				Pr.01-23 (Switch Frequency between First/Fourth Accel./Decel.), it outputs		
				the fourth accel./decel. time.		
		0	1	Second accel./decel. time		
	The third, fourth acceleration or	1	0	Third accel./decel. time		
9	deceleration time	1	1	Fourth accel./decel. time		
	· -	If the drive	receives	STOP command, it decelerates to stop with		
		Pr.01-31.				
10	EE lanut	External fau	ult input te	erminal, and decelerates according to		
10	EF Input	Pr.07-28 (records EF fault).				
11: Rese	rved					

	Functions		L	Descriptions				
		When enabled	I, the motor o	rive output	stops immediately and			
12 Stop out	tput	the motor coas	sts. When dis	sabled, the n	notor drive accelerates			
		to the frequency setting.						
13–14: Reserved								
		When the operation speed command source is AUI1 and AUI2,						
15	eration speed	and two or more terminals are ON, the priority is AUI1 > AUI2.						
commar	nd	When enabled, the frequency source is AUI1.						
16: Reserved		1		-				
17 AUI2 op	eration speed	When enabled	I, it forces the	e frequency	source to AUI2.			
		When enabled	I, the motor o	Irive ramps t	to stop according to			
18 Emerge	ncy Stop	Pr.07-28.						
19–23: Reserved		•						
24 FWD JC	OG command	When enabled	I, the motor o	Irive execute	es the forward Jog			
2		command.						
25 REV JO	G command	When enabled	I, the motor o	Irive execute	es the reverse Jog			
		command.						
26: Reserved								
27 ASR1/A	SR2 selection	ON: Speed is	-	_				
		OFF: Speed is adjusted according to ASR 1.						
	ncy stop (EF1) (Motor		r drive execu	ıtes emergei	ncy stop and records the			
coasts to	ο stop)	fault code.						
29–30: Reserved		1						
		When Pr.07-1						
31 High tor	que bias	Set the high to	·					
		Set the middle torque bias in Pr.07-22.						
		Set the low torque bias in Pr.07-23.						
32 Middle t	orque bias	31	32	33	Torque Bias			
		OFF	OFF	OFF	N/A			
		OFF OFF	OFF ON	ON OFF	Pr.07-23 Pr.07-22			
		OFF	ON	ON	Pr.07-23+ Pr.07-22			
		ON	OFF	OFF	Pr.07-21			
33 Low tord	que bias	ON	OFF	ON	Pr.07-21+ Pr.07-23			
		ON	ON	OFF	Pr.07-21+ Pr.07-22 Pr.07-21+ Pr.07-22+			
		ON	ON	ON	Pr.07-23			
34–37: Reserved		1						
38 Disable	writing to EEPROM	When enabled	l, you cannot	write to EEI	PROM.			
		When the torq	ue command	l is AUI, set	this function to change			
39 Torque	command direction	the torque con	nmand direct	ion. To work	with Pr.07-13 = 2, set			
		Pr.03-00 to 2.						

Settings	Functions	Descriptions
40	Enable drive function	When enabled, it executes the motor drive function. This function can be used with multi-function output (setting Pr.02-11–Pr.02-14 to 15) and (Pr.02-31 and Pr.02-32).
41	Magnetic contactor detection	This terminal is for the magnetic contactor feedback signal ON/OFF. When the motor drive receives a RUN command, it enables the corresponding output terminal (setting 15) after Pr.02-31 time. It checks if this function is enabled in the detection time (Pr.02-36). If NOT, the magnetic contactor error occurs and error code "MCF" displays.
42	Mechanical brake 1	When the motor drive receives a RUN command, it enables the corresponding output terminal (setting 12) after Pr.02-29 time. It checks if this function is enabled in the detection time (Pr.02-35). If NOT, the mechanical brake error occurs and error code "MBF" displays.
43	EPS function (Emergency Power System)	If power is cut during running, the drive stops when the DC bus voltage is less than the low voltage level. After power is cut, the drive runs according to the EPS frequency when EPS is applied and this function is ON.
44	Mechanical brake 2	When the motor drive receives a RUN command, it enables the corresponding output terminal (setting 12) after Pr.02-29 time. It checks if this function is enabled in the detection time (Pr.02-35). If NOT, the mechanical brake error occurs and error code "MBF" displays.
45–51	Direct docking mode only	Contact Delta for more information.
53	Terminal leveling signal for direct docking	When the elevator runs to the leveling area, controller sends a signal to the drive to make the drive stop within effective distance (Pr.01-36).
54	Power failure signal	When power failure occurs, the host controller inputs this signal to inform the drive. When the motor drive receives this signal, MO = 49 is disabled after Pr.06-71 time
55	Manual emergency deceleration	When the motor drive receives this signal, it decelerates to Pr.01-29 speed according to Pr.01-40 deceleration time.
56	Automatic emergency deceleration	After setting this MI function, the system monitors the current speed. If the speed is higher than Pr.01-39, the drive decelerates to Pr.01-29 speed according to Pr.01-40 deceleration time.

Settings	Functions	Descriptions
57	Brake torque test action signal	Executes brake torque test when receiving signals.
59	AFE fault	Use with AFE series product



Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.005

Settings 0.001–30.000 sec.

Defines the digital input terminal signal delay and confirmation. The delay time prevents interference that can cause errors (except for the counter input) in the digital terminal input (FWD, REV and MI1–8). Increasing the setting for this parameter can reduce the errors, but it delays the response time.

✓ ☐ 2 - ☐ Digital Input Operation Direction

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0
Settings 0–65535

- ☐ Sets the input signal level and it is not affected by the SINK/SOURCE status.
- Bit 0 is for FWD terminal, bit 1 is for REV terminal and bits 2–9 are for MI1 to MI8.

You can change the terminal status between ON and OFF through communications.

For example, set MI1=1 (multi-step speed command 1) and MI2=2 (multi-step speed command 2). Then the reverse + second step speed command = 1010 (binary) = A (hexadecimal). You only need to set Pr.02-10=A through communications and it can move reverse at the second step speed. In this case, you

do not need to wire any multi-function terminals.

bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
MI8	MI7	MI6	MI5	MI4	MI3	MI2	MI1	REV	FWD

Default: 0

Multi-function Output 2: MRA, MRB, MRC (Relay 2)

Default: 0

Multi-function Output 3: R1A, R12C (Relay 3)

Multi-function Output 4: R2A, R12C (Relay 4)

★ ## Multi-function Output 5: MO1

✓ B2 - 15 Multi-function Output 6: MO2

★ ## Multi-function Output 7: MO3

★ B 2 - 18 Multi-function Output 8: MO4

★ B 2 - 13 Multi-function Output 9: MO5

✓ B2 - 2B Multi-function Output 10: MO6

Reserved
Reserved

		Default: 0				
Settings	Control Mode	VF	VFPG	SVC	FOCPG	FOCPM
0: No function		0	0	0	0	0
1: Indication during operation		0	0	0	0	0
2: Operation speed reached		0	0	0	0	0
3: Desired frequency 1 reached (Pr 26)	.02-25, Pr.02-	0	Ο	0	0	0
4: Desired frequency 2 reached (Pr 28)	.02-27, Pr.02-	0	Ο	0	0	0
5: Zero Speed (Frequency commar	nd)	0	0	0	0	0
6: Zero speed with stop (Frequency	/ command)	0	0	0	0	0
7: Over-torque (OT1) (Pr.06-05-06-	-07)	0	0	0	0	0
8: Over-torque (OT2) (Pr.06-08-06-	-10)	0	0	0	0	0
9: Drive is ready		0	0	0	0	0
10: User-defined low-voltage detec	tion (LV)	0	0	0	0	0
11: Malfunction indication		0	0	0	0	0
12: Mechanical brake release (Pr.0 Pr.02-37)	2-29, Pr.02-30,	0	Ο	0	0	0
13: Overheat (Pr.06-14)		0	0	Ο	0	0

14: Brake transistor signal	0	0	0	0	0
15: Motor-controlled magnetic contactor output	0	0	0	0	0
16: Slip error (oSL)	0	0	0	0	0
17: Malfunction indication 1	0	0	0	0	0
18: Reserved					
19: Brake transistor output error	0	0	0	0	0
20: Warning output	0	0	0	0	0
21: Over-voltage warning	0	0	0	0	0
22: Over-current stall prevention warning	0	0	0		
23: Over-voltage stall prevention warning	0	0	0	0	0
24: Operation mode indication (Pr.00-15=1)	0	0	0	0	0
25: Forward command	0	0	0	0	0
26: Reverse command	0	0	0	0	0
27: Output when current ≥ Pr.02-33	0	0	0	0	0
28: Output when current < Pr.02-33	0	0	0	0	0
29: Output when frequency ≥ Pr.02-34	0	0	0	0	0
30: Output when frequency < Pr.02-34	0	0	0	0	0
31: Power generation direction and status					
verification	0	0	0	0	0
32: Power generation direction	0	0	0	0	0
33: Zero speed (actual output frequency)	0	0	0	0	0
34: Zero speed with Stop (actual output	_				_
frequency)	0	0	0	0	0
35: Fault output option 1 (Pr.06-22)	0	0	0	0	0
36: Fault output option 2 (Pr.06-23)	0	0	0	0	0
37: Fault output option 3 (Pr.06-24)	0	0	0	0	0
38: Fault output option 4 (Pr.06-25)	0	0	0	0	0
39: Reserved					
40: Speed reached (including zero speed)	0	0	0	0	0
41: Reserved					
42: STO Output Error	0	0	0	0	0
43–44: Direct Docking Mode only					
45: Reserved					
46: Retrying after a fault has occurred indication	0	0	0	0	0
47: Direct Docking Mode only					
48: Control output of MPSCC (Motor Phase Short					
Circuit Contactor)	0	0	0	0	0
49: Emergency power mode action	0	0	0	0	0
50: Speed reached Pr.02-34	0	0	0	0	0
51: Brake torque test finished	0	0	0	0	0
52: AFE reset	0	0	0	0	0

Settings	Functions	Descriptions			
0	No function	MO has no function			
1	Indication during operation	Active when there is an output from the drive or RUN command is ON.			
2	Operation speed reached	Active when the AC motor drive reaches the output frequency setting.			
3	Desired frequency 1 reached (Pr.02-25, 02-26)	Active when the desired frequency (Pr.02-25, 02-26) reached.			
4	Desired frequency 2 reached (Pr.02-27, 02-28)	Active when the desired frequency (Pr.02-27, 02-28) reached.			
5	Zero Speed (Frequency command)	Active when the Frequency command = 0. (the drive should be at RUN mode)			
6	Zero Speed with stop (Frequency command)	Active when Frequency command = 0 or Stop.			
7	Over-torque (OT1) (Pr.06-05-06-07)	Active when detecting over-torque. Refer to Pr.06-05 (over-torque detection-OT1), Pr.06-06 (over-torque detection level-OT1) and Pr.06-07 (over-torque detection time-OT1).			
8	Over-torque (OT2) (Pr.06-08-06-10)	Active when detecting over-torque. Refer to Pr.06-08 (over-torque detection-OT2), Pr.06-09 (over-torque detection level-OT2) and Pr.0 10 (over-torque detection time-OT2).			
9	Drive is ready	Active when the drive is ON and no error detected.			
10	User-defined low-voltage detection	Active when the DC bus voltage is too low (see Pr.06-00 Low voltage level).			
11	Malfunction indication	Active when a fault occurs (except Lv stop).			
12	Mechanical brake release (Pr.02-29, Pr.02-30, Pr.02-37)	When the drive runs according to Pr.02-29, it is ON. Use this function with the DC brake. It is recommended to use contact "b" (N.C). phase loss detection 06-31 of drive output is normal operation command enable drive function (MI setting #40) drive is ready magnetic contactor contracting delay time between drive and motor no-load current>70%*05-05 output current > 02-33			
13	Overheat (Pr.06-14)	Active when IGBT or heat sink overheats. To prevent OH, turn off the drive (refer to Pr.06-14).			
14	Brake transistor signal	Activated when the drive needs help braking the load. This function helps achieve a smooth deceleration (refer to Pr.07-00).			
15	Motor-controlled magnetic contactor output	Active when you set MI function to #40 (Enable drive function).			
16	Slip error (oSL)	Active when the slip error is detected (according to Pr.05-14).			
17	Malfunction indication 1	Activate after 10 ms when a fault occurs (except Lv stop).			

	<u></u>	
18	Reserved	
19	Brake transistor output error	Active when a brake transistor error is detected
20	Warning output	Active when a warning is detected.
21	Over-voltage warning	Active when an over-voltage is detected.
22	Over-current stall prevention warning	Active when an over-current stall prevention is detected.
23	Over-voltage stall prevention warning	Active when an over-voltage stall prevention is detected.
24	Operation mode indication	Active when the operation command is controlled by an external terminal (Pr.00-15=1).
25	Forward command	Active when the operation direction is forward.
26	Reverse command	Active when the operation direction is reverse.
27	Output when current ≥ Pr.02- 33	Active when current is ≥ Pr.02-33.
28	Output when current < Pr.02-33	Active when current is < Pr.02-33.
29	Output when frequency ≥ Pr.02-34	Active when frequency is ≥ Pr.02-34.
30	Output when frequency < Pr.02-34	Active when frequency is < Pr.02-34.
31	Power generation direction and status verification	Activate when the power generation direction is verified.
32	Power generation direction	Activate when the power generation direction runs forward.
33	Zero speed (actual output frequency)	Active when the actual output frequency is 0. The drive should be in RUN mode.
34	Zero speed with stop (actual output frequency)	Active when the actual output frequency is 0 or Stop. The drive should be in RUN mode.
35	Fault output option 1 (Pr.06-22)	Active when Pr.06-22 is ON.
36	Fault output option 2 (Pr.06-23)	Active when Pr.06-23 is ON.
37	Fault output option 3 (Pr.06-24)	Active when Pr.06-24 is ON.
38	Fault output option 4 (Pr.06- 25)	Active when Pr.06-25 is ON.
39	Reserved	
40	Speed reached (including zero speed)	Active when the output frequency reaches the frequency setting. Can be used to work with Pr.02-43.
41	Reserved	
	<u>L</u>	1

		Status of drive	Status of safety output					
		Status of drive	Status A (MO=42)					
42	STO Output Error	Normal	Broken circuit (open)	*See Table 16-3 for				
		STO	Short circuit (closed)	settings of logic				
		STL1-STL3	Short circuit (closed)	output B				
43–44	Direct Docking Mode only	Contact Delta for I	more information					
45	Reserved							
46	Retrying after a fault has	Retry multiple outputs after an error has occurred. When the retry						
46	occurred indication	period has finished, MO stops.						
47	Direct Docking Mode only	Contact Delta for more information						
	Control output of MPSCC							
48	(Motor Phase Short Circuit	Active when the d	rive receives a STOP con	nmand.				
	Contactor)							
49	Emergency power mode	Active when the d	rive receives a signal fron	n the host controller (Pr.02-				
49	action	01-02-08=54) afte	er Pr.06-71 time.					
50	Speed reached Pr.02-34	Active when drive's output frequency is > Pr.02-34, and PGF3 error						
50	Speed readiled F1.02-34	will be triggered.						
51	Brake torque test finished	Active when brake torque test is finished.						
52	AFE reset	Use with AFE series product						

N	U5-53	Multi-function Output Terminal Direction
---	-------	--

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0
Settings 0–65535

This parameter uses bit setting. If the bit is 1, the multi-function output terminal acts in the opposite direction. For example, if you set Pr.02-11 to 1 and the forward bit is 0, Relay 1 is ON when the drive is running and OFF when the drive is stopped.

Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
-	-	MO6	MO5	MO4	МОЗ	MO2	MO1	R2A	R1A	MRA	RA


\$2 - 24 Serial Start Signal Selection

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings 0: According to FWD/REV signal


1: According to Enable drive function signal

- Selects the contactor serial start method.
- 0: According to FWD/REV signal, the motor starts to run after the Enable signal MI = 40 is ON.
- 1: According to Enable signal, the contactor, mechanical brake and DC brake all follow parameters' setting to run after FWD/REV and Enable are ON.



No matter if the Enable Drive function signal outputs or not,

the drive starts to count Pr.02-31 after MO15 outputs.



After both Enable Drive function signal and MO15 output, the drive starts to count Pr.02-31.

×	02-25	Desired	Frequen	cy Rea	ched 1		
	Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 60.00/50.00
		Settings	0.00–299	9.00 Hz			
N	85-58	Desired	Frequen	cy Rea	ched Width 1		
	Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 2.00
		Settings	0.00–299	9.00 Hz			
N	02-27	Desired	Frequen	cy Rea	ched 2		
	Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 60.00/50.00
		Settings	0.00–299	9.00 Hz			
N	85-58	Desired	Frequen	cy Rea	ched Width 2		
	Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 2.00
		Settings	0.00–299	9.00 Hz			

Once the output frequency reaches the desired frequency and the corresponding multi-function output terminal is set to 3 or 4 (Pr.02-11–Pr.02-22), this multi-function output terminal is ON.


Brake Release Delay Time when Elevator Starts

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.250

Settings 0.000–65.000 sec.

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.250
Settings 0.000–65.000 sec.

- When the AC motor drive runs and after the delay time in Pr.02-29, the corresponding multi-function output terminal (12: mechanical brake release) is ON.
- When the AC motor drive stops and after the delay time in Pr.02-30, the corresponding multi-function output terminal (12: mechanical brake release) is OFF.
- Use this function with the DC brake function.



Magnetic Contactor Contracting Delay Time between Drive and Motor

Magnetic Contactor Release Delay Time between Drive and Motor

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.200

Settings 0.010–65.000 sec.


After running, use these parameters with multifunction input terminal setting 40 (Enable drive function), and multifunction output terminal setting 15 (motor-controlled magnetic contactor output). When the multifunction output terminals are ON, the drive starts outputting after the delay time in Pr.02-31. When the drive stops outputting, multifunction output terminals release after the delay time in Pr.02-32.

MPSCC (Motor Phase Short Circuit Contactor) Release Delay Time between Drive and Motor

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.200 Settings 0.010~65.000 sec.


MPSCC (Motor Phase Short Circuit Contactor) Contracting Delay Time between Drive and Motor

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.200 Settings 0.010~65.000 sec.



Elevator Timing Diagram

	2-33	Externa	l Termina	l Outpu	ut Current L	_evel	
Со	ntrol Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 0
		Settings	0–100%				
	When out	tput curren	t is ≥ Pr.02	2-33, it a	ctivates the n	nulti-function output ter	minal (Pr.02-11–Pr.02-22 are
	set to 27)						
	When out	tput curren	t is < Pr.02	2-33, it a	ctivates the n	nulti-function output ter	minal (Pr.02-11-Pr.02-22 are
	set to 28)	-					
ı B	2-34	Externa	l Termina	l Outpu	ut Speed Li	mit	
	ntrol Mode		VFPG	SVC	FOCPG	FOCPM	Default: 0.00
		Settings	0.00–299	9.00 Hz	(this is motor	speed when using with	n PG)
	When driv	ve's output	frequency	is ≥ Pr.0)2-34, multi-fu	unction terminal 29 (Pr.0	02-11–Pr.02-22) will be activate
	When driv	ve's output	frequency	is < Pr.0)2-34, multi-fu	unction terminal 30 (Pr.0	02-11–Pr.02-22) will be activate
	When driv	ve's output	frequency	is > Pr.0)2-34, multi-fu	unction terminal 50 (Pr.0	02-11–Pr.02-22) will be activate
	and PGF	3 error will	be triggere	ed.			
	The settir	ng range a	nd unit of F	Pr.02-34	varies with P	r.00-10 settings:	
	When Pr.	00-10=0, t	he setting ı	range ar	nd unit of Pr.0	02-34 is 0.00–299.0 Hz	
	When Pr.	00-10=1, t	he setting ı	range ar	nd unit of Pr.0	02-34 is 0.00–93.93 m/s	S.
	When Pr.	00-10=2, t	he setting ı	range ar	nd unit of Pr.0	02-34 is 0.00-308.09 ft/	's.
/ F	2-35	Mechan	ical Brak	e Dete	ction Time		
	ntrol Mode		VFPG	SVC	FOCPG	FOCPM	Default: 0.00
		Settings	0.00–10.				
	When the				Pr.02-01–Pr.0)2-08 are set to 42) is r	not enabled within this setting
				•		nical brake error.	Ŭ
. 🙃		·	•	·	,		
	C-30				tection Time		
Co	ntrol Mode		VFPG	SVC	FOCPG	FOCPM	Default:0.00
		Settings	0.00–10.				
		•			•	•	t enabled within this setting
	time, the	drive displ	ays error c	ode 66 (MCF) magne	etic contactor error.	
B	2-37	Torque (Check				
Со	ntrol Mode	•	VFPG	svc	FOCPG	FOCPM	Default: 0
		Settings	0: Disabl	le			
			1: Enable	е			
	When the	drive rece	eives the op	peration	signal, the dr	rive checks if there is a	torque output. When enabled,
	the drive	releases th	ne mechan	ical brak	e after confir	ming that there is a tor	que output.



02-40 - 02-42	Direct Do	ocking Mode (Only			
Control Mode		VFPG	FOCPG	FOCPM	Default: -	
	Settings	Contact Delta f	or more information			

×	02-43 Speed Reached Bandwidth										
	Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 2.00				
		Settings	0.00-299.00	Hz							

When drive's output frequency and target frequency is smaller than or equal to this bandwidth, multi-function output terminal MO=2 and MO=40 will be activated (ON). When drive's output frequency and target frequency is larger than this bandwidth, MO=2 and MO=40 will be deactivated (OFF).

[This page intentionally left blank]

03 Analog Input / Output Parameters

★ B 3 - B B Analog Input 1 (AUI1)


Default:1

Reserved

✓ B3-B2 Analog Input 2 (AUI2)

			D	efault: ()	
Settings	Control Mode	VF	VFPG	SVC	FOCPG	FOCPM
0: No function		0	0	0	0	0
1: Frequency command (speed limi control mode)	t under torque	0	0	0	0	0
2: Torque command (torque limit un mode)	der speed					
3: Load compensation		0	0	0	0	0
4–5: Reserved						
6: P.T.C. thermistor input value		0	0	0	0	0
7: Positive torque limit					0	0
8: Negative torque limit					0	0
9: Regenerative torque limit					0	0
10: Positive/negative torque limit					0	0

- When using the Frequency command or speed limit under torque control mode, the corresponding value for 0 to ±10 V or 4–20 mA is 0–maximum output frequency (Pr.01-00).
- When using the Torque command or torque limit, the corresponding value for 0 to ±10 V or 4–20 mA is 0–maximum output torque (Pr.07-14).
- When using torque compensation, the corresponding value for 0 to ±10 V or 4–20 mA is 0–moto's rated torque.




07-19: Source of torque offset

03-00~02: Analog input selections (AUI1/ACI/AUI2)

03-03~05: Analog input bias (AUI1/ACI/AUI2)

03-06~08: AUI1/ACI/AUI2 bias mode



Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.0

Settings -100.0-100.0%

Sets the corresponding AUI1 voltage for the external analog input 0.

Reserved

✓ ☐ 3 - ☐ 5 Analog Input Bias 1 (AUI2)

Control Mode VF VFPG SVC FOCPG FOCPM Default:0.0

Settings -100.0-100.0%

- Sets the corresponding AUI2 voltage for the external analog input 0.
- The relation between external input voltage/current and setting frequency is equal to -10–10 V (4–20 mA) corresponding to 0–60 Hz.

Reserved

✓ ## AUI1 Positive/negative Bias Mode


Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

AUI2 Positive/negative Bias Mode

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings 0: Zero bias

- 1: Lower than or equal to bias
- 2: Higher than or equal to bias
- 3: Use bias as the base to get the absolute value of bias voltage (unipolar)
- 4: Using bias as the base (unipolar)
- In a noisy environment, you can use a negative bias to provide a noise margin. It is recommended that you NOT use less than 1 V to set the operating frequency.



03-09~03-11 gain is positive

- 0 Zero bias
- 1 Serve bias as the center, lower than bias = bias
- 2 Serve bias as the center, greater than bias=bias
- The absolute value of the bias voltage while serving as the center (unipolar)
- 4 Serve bias as the center (unipolar)

✓ ₩ 3 - ₩ 3 Analog Input Gain 1 (AUI1)

Control Mode VF VFPG SVC FOCPG FOCPM Default: 100.0

Settings 0.0–500.0%

Reserved

Analog Input Gain 1 (AUI2)

Control Mode VF VFPG SVC FOCPG FOCPM Default: 100.0

Settings 0.0-500.0%

Pr.03-03-Pr.03-11 are used when the Frequency command source is the analog voltage/current signal.

★ 3 - 12 Analog Input Filter Time (AUI1)

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.01 Settings 0.00–2.00 sec.

Reserved

★ ☐ 3 - 14 Analog Input Filter Time (AUI2)

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.01 Settings 0.00–2.00 sec.

- Analog signals, such as those entering AUI1 and AUI2, are commonly affected by interference that affects the stability of the analog control. Use the Input Noise Filter to create a more stable system.
- If Pr.03-14 is large, the control is more stable, but the response to the input is slower. If Pr.03-14 is small, the control may be unstable, but the response to the input is faster.

3-15 Load Compensation Auto-tuning

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0


Settings 0: No function

1: Auto-tunes with running without load

2: Auto-tunes with running with load

Use torque compensation function to avoid the roll-back generated by using IM to work with spiral gear.

- This function is only valid for AUI1.
- Auto-tuning process:



Reserved

- ★ 3 17 Analog Output Selection 1
- ✓ ☐ 3 2 ☐ Analog Output Selection 2

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings 0: Output frequency (Hz)

1: Frequency command (Hz)

2: Motor speed (RPM)

3: Output current (rms)

4: Output voltage

5: DC bus voltage

6: Power factor angle

7: Power factor

8: Output torque

9: AUI1

10: Reserved

11: AUI2

12: q-axis current

13: q-axis feedback value

- 14: d-axis current
- 15: d-axis feedback value
- 16: q-axis voltage
- 17: d-axis voltage
- 18: Torque command
- 19-20: Reserved
- 21: Power output
- When setting to 0, it is output frequency, not ASR output frequency.
- ★ 3 2 | Analog Output Gain 2

Control Mode VF VFPG SVC FOCPG FOCPM Default: 100.0

Settings 0-200.0%


- Sets the corresponding voltage for the analog output 0.
- ★ # 3 # Analog Output Value in REV Direction 1
- ★ 3 2 2 Analog Output Value in REV Direction 2

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0


Settings 0: Absolute value in output voltage

1: Output 0 V in REV direction

2: Enable output voltage in REV direction



Selection for the analog output direction



Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings 0: Bipolar (±10 V)

1: Unipolar (0-10 V)


- When this parameter is set to 0 (bipolar), the input function direction is determined by the input signal.
- ①: And Pr.03-00=1 or 2, AUI decides the operation direction.
- 1: And Pr.03-00=1, the FWD/REV terminal decides the operation direction.
- 1: And Pr.03-00=2, setting Pr.02-01–Pr.02-08 to 39 decides the operation direction.


[This page intentionally left blank]

04 Multi-step Speed Parameters

							set this pa	arameter during op	eration			
×	84-88	Zero Ste	p Speed	l Frequ	ency							
×	04-01	1st Step	Speed I	reque	ncy							
N	04-02	2nd Step	Speed	Freque	ency							
N	04-03	3rd Step	rd Step Speed Frequency									
×	84-84	4th Step	Speed I	Freque	ncy							
×	84-85	5th Step	h Step Speed Frequency									
×	89-88	6th Step	Speed I	Freque	ncy							
×	04-07	7th Step	Speed I	Freque	ncy							
×	89-88	8th Step	th Step Speed Frequency									
×	84-89	9th Step	Speed I	Freque	ncy							
×	04-10	10th Ste	p Speed	Frequ	ency							
×	34- ;;	11th Ste	p Speed	Frequ	ency							
×	84 - 15	12th Ste	p Speed	Frequ	ency							
×	84-13	13th Ste	p Speed	Frequ	ency							
N	84-14	14th Ste	p Speed	Frequ	ency							
N	84-15	15th Ste	p Speed	Frequ	ency							
	Control Mode	VF	VFPG	SVC	FOCPG	FOCPM		Default: 0.00				
		Settings	0.00–29	9.00 Hz								

- The multi-function input terminals (refer to Pr.02-01–Pr.02-08) select one of the AC motor drive multi-step speeds (including the master frequency, in total 16 speeds). Pr.04-00–Pr.04-15 determine the speeds (frequencies) as shown above.
- \square When Pr.00-14 = 1, the master frequency is Pr.01-00.
- \square When Pr.00-14 = 3, the master frequency is Pr.04-00.





05 IM Parameters

★: You can set this parameter during operation

Motor Auto-tuning

Control Mode VF Default: 0

Settings 0: No function

1: Dynamic test (Rs, Rr, Lm, Lx, no-load current) [motor runs]


2: Static Test [motor does not run]

Position the elevator near the middle floors before auto-tuning.

Motor auto-tuning:

Set Pr.05-00 to 1 or 2, and then press the RUN key on the digital keypad KPC-CC01 (Pr.00-15=2) to start auto-tuning. Or when the drive is in manual mode (inspection), run the upward operation or downward operation (Pr.00-15=1) to start auto-tuning immediately. In the process of auto-tuning, an "Auto tuning" warning continuously displays on the digital keypad until it is finished.

- Pay attention to the following notes when Pr.05-00=1 (dynamic test):
 - 1. Make sure that all the drive parameters are set to defaults and the motor wiring is correct.
 - 2. Make sure the motor is not loaded before auto-tuning, and that the shaft is not connected to any belt or gear motor. Set this parameter to 2 if you cannot separate the motor from the load.
 - 3. Enter the correct values for Pr.01-01, Pr.01-02, Pr.05-01, Pr.05-02, Pr.05-03 and Pr.05-04. Refer to motor capacity to set the acceleration/deceleration time.
 - 4. After auto-tuning is finished, check if Pr.05-05-Pr.05-09 all have values.
 - 5. Equivalent circuit diagram:



NOTE:

- In torque/vector control mode, do not run motors in parallel.
- Do not use torque/vector control mode if the motor rated power exceeds the rated power for the AC motor drive.
- The no-load current is usually 20-50% of the rated current.
- The rated speed cannot be larger or equal to 120 f/p (f: output frequency Pr.01-01, p: Number of Motor Poles Pr.05-04).
- After auto-tuning is finished, activate the drive again to make it operate when the auto-tuning command source is the external terminal.

G 5 - G ∤
Motor Rated Current

Control Mode VF VFPG SVC FOCPG Unit: Amp

Default: #.##

Settings (40-120%) * Pr.00-01 Amps

Set this value according to the rated motor frequency from the motor nameplate.

Example: Suppose the rated current for 7.5 HP (5.5 kW) models is 25 A and the default is 22.5 A. In this way, the current range is from 10 A (25 * 40%) to 30 A (25 * 120%).

As the table below shows, the defaults vary according to the different motor drive outputs in HP and in kW.

	Motor Drive's Output (HP)	3*	5*	5	7.5	10	15	20	25	30	40	50	60	75	100
	Motor Drive's Output (kW)	2.2	3.7	4	5.5	7.5	11	15	18.5	22	30	37	45	55	75
230V	Motor Rated Current (A) Default	9.82	13.91	16.36	19.64	24.54	36.82	47.46	63	71.18	108	131.72			
460V	Motor Rated Current (A) Default			9.41	10.64	13.91	18.82	24.54	31.1	36.82	47.46	65.46	81.82	104.72	135

^{*:} single-phase models.

₩5-₩2 Motor Rated Power

Control Mode SVC FOCPG Default: #.##

Settings 0.00-655.35 kW

Sets the rated power of the motor. The default is the power of the drive.

Control Mode VFPG SVC FOCPG Default: 1710

Settings 0-65535

Sets the motor rated speed from the value on the motor nameplate.

Number of Motor Poles

Control Mode VF VFPG SVC FOCPG Default: 4

Settings 2-48

Sets the number of motor poles (must be an even number).

#5 - #5 Motor No-load Current

Control Mode VFPG SVC FOCPG Unit: Amp

Default: #.##

Settings 0-Pr.05-01 default

As the table below shows, the defaults vary according to the different motor drive output in HP and in kW.

	Motor Drive's	3*	5*	5	7.5	10	15	20	25	30	40	50	60	75	100
	Output (HP)	Ŭ	Ŭ	Ů		. •	. •				. •			. •	
	Motor Drive's	2.2	3.7	4	5.5	7.5	11	15	18.5	22	30	37	45	55	75
	Output (kW)	2.2	3.7		0.0	7.5	' '	10	10.5		30	01	75	55	13
	Motor Current														
230V	w/o Load (A)	3.44	4.87	5.73	6.85	8.5	12.56	15.97	20.78	23.22	33.51	39.52			
	Default														
	Motor Current														
460V	w/o Load (A)			3.29	3.71	4.81	6.43	8.26	10.28	11.99	15	19.64	24.55	31.42	40.5
	Default														

^{*:} single-phase models.

					12 Descriptions of Farameter Settings VFD-ED
	05-08	Rs of Mo	otor		
	85-87	Rr of Mo	otor		
	Control Mode		svc	FOCPG	Default: 0.000
		Settings	0.000–65.535 Ω	!	
	05-08	Lm of M	otor		
	85-89	Lx of Mo	otor		
	Control Mode	:	svc	FOCPG	Default: 0.0
		Settings	0.0–6553.5 mH		
N	85-18	Torque (Compensation	Low Pass Filter T	ime
	Control Mode	•	svc		Default: 0.020
		Settings	0.001–10.000 se	ec.	
N	85-11	Slip Con	npensation I ov	v Pass Filter Time	
,	Control Mode	-	SVC	r acc i mer inne	Default: 0.100
	Ooma or mode	Settings	0.001–10.000 se	- C	Boladik 0.100
	Setting P				for the compensation.
	_		_	•	kimizes the response time for the compensation.
	-				·
	ii tile seti	ings are to	o low, the system	may become unstab	ie.
N	85 - 12	Torque (Compensation	Gain	
	Control Mode	· VF	VFPG		Default: 0
		Settings	0–10		
	☐ You can	set this par	ameter so that the	AC motor drive incr	eases its voltage output for a higher torque.
/	06 17	Clin Com	eneneation Coi	_	
*		-	npensation Gai	rı	Default 4 00
	Control Mode		SVC		Default: 1.00
		Settings	0.00–10.00		
			_		e load and slip increase. Use this parameter to run near the synchronous speed under the
		-	-	•	otor no-load current, the drive compensates the
		-		etting. If the actual s	peed is slower than the expected speed,
		•	and vice versa.		
	H This is or	nly valid in	SVC mode.		
N	85-14	Slip Dev	riation Level		
	Control Mode	•	VFPG SVC	FOCPG	Default: 0
		Settings	0–1000%		
		J	0: Disable		
N	05-15	Slip Dev	riation Detection	n Time	
,	Control Mode	•	VFPG SVC	FOCPG	Default:1.0
	o. mode	Settings	0.0–10.0 sec.		23.33.1.10
	85 - 18	Over-slip			
~		~ v ~ i ~ 3			

	Control Mode		VFPG	svc	FOCPG		Default: 0	
		Settings	0: Warn	and kee	p operation			
			1: Fault a	and ram	p to stop			
			2: Fault a	and coas	st to stop			
	Pr.05-14-	-Pr.05-16 s	et the allov	wable sli	p level and ov	er-slip action when t	he drive is running.	
	When Pr.	05-16 is se	et to 1 (Fau	It and ra	amp to stop), if	brake or operation	contactor is OFF under the	
	circumsta	nce that S	TO or MI40) (Enabl	e drive functio	n) is not deactivated	during deceleration, elevate	or still
	runs ever	n brake has	s engaged	(brake v	vear), and elec	ctric arc occurs wher	n operation contactor is OFF	
×	85-17	Hunting	Gain					
	Control Mode	VF	VFPG	svc			Default: 2000	
		Settings	0–10000)				
			0: Disabl	е				
	The moto	r has curre	ent wave m	otion un	der some spe	cific conditions. You	can improve this situation b	у
	setting thi	is paramet	er. You caı	n set it to	0 for current	wave motion in the I	nigh frequency range or whe	en
	running w	ith PG. Wi	nen the cui	rent wa	ve motion hap	pens in the low frequ	uency range, increase Pr.05	-17.
	85 - 18	Accumu	lated Mo	tor Ope	eration Time	(Min.)		
	Control Mode		VFPG	SVC	FOCPG	FOCPM	Default: 0	
		Settings	0–1439 r	minutes				
				•	eration Time	,		
	Control Mode		VFPG	SVC	FOCPG	FOCPM	Default: 0	
		Settings	0–65535					
					•		e records by setting the valu	es to
	0. Operat	ing time th	at is less th	nan 60 s	econds is not	recorded.		
×	05-20	Core Lo	ss Comp	ensatio	on			
	Control Mode			SVC			Default: 10	
		Settings	0–250%					
	06.3.4	Λοοι 1:22:	loted Mar	tor Da	vor on Time	(Min)		
	Control Mode		VFPG	SVC	ver-on Time FOCPG	FOCPM	Default: 0	
	Control Mode	Settings	0–1439 r	_	FUCPG	FOCFIVI	Delault. 0	
		Settings	0-14391	IIIIules				
	05-22	Accumu	lated Mo	tor Pov	ver-on Time	(day)		
	Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 0	
		Settings	0-65535	days				
	00 00	0.11			0/ /			
×		•	npensatio		n % (power	generation mode	,	
	Control Mode			SVC			Default: 0.0	
		Settings	0.0–100.	<u>0%</u>				

V	85-24	Slip Con	npensation Gain % (e	electricity mode)
	Control Mode	VF	SVC	Default: 0.0
	_	Settings	0.0-100.0%	
	When in V	/F mode, y	ou do NOT have to set P	r.05-13. To satisfy the demand for different compensation
	gains in po	ower gene	ration mode and electricit	y mode, set Pr.05-23 and Pr.05-24.
	When in S	SVC mode,	set Pr.05-13 first. To sat	isfy the demand for different compensation gains in power
	generation	n mode an	d electricity mode, set Pr.	05-23 and Pr.05-24.

[This page intentionally left blank]


06 Protection Parameters

★: You can set this parameter during operation

Control Mode VF VFPG SVC FOCPG FOCPM Default: 180.0/360.0

Settings 230V models: 160.0–220.0 V 460V models: 320.0–440.0 V

Sets the Lv level.



✓ ₩ ☐ F - ☐ I Input Phase-loss Protection during Operation

Control Mode VF VFPG SVC FOCPG FOCPM Default: 2

Settings 0: Warn and keep operation

1: Fault and ramp to stop

2: Fault and coast to stop

- Sets the phase-loss protection action for power at input side. The phase-loss affects the drive's control characteristics and life.
- When Pr.06-01 is set to 1 (Fault and ramp to stop), if brake or operation contactor is OFF under the circumstance that STO or MI40 (Enable drive function) is not deactivated during deceleration, elevator still runs even brake has engaged (brake wear), and electric arc occurs when operation contactor is OFF.


✓ ☐ 6 - ☐ 2 Over-current Stall Prevention during Acceleration

Control Mode VF VFPG SVC Default: 0

Settings 0: Disable

0-250% (rated current of the motor drive)

During acceleration, the AC motor drive output current may increase abruptly and exceed the value specified in Pr.06-02 due to rapid acceleration or excessive load on the motor. When you enable this function, the AC motor drive stops accelerating and keeps the output frequency constant until the current drops below the maximum value.



actual acceleration time when over-current stall prevention is enabled


✓ # # Over-current Stall Prevention during Operation

Control Mode VF VFPG SVC Default: 0

Settings 0: Disable

0-250% (rated current of the motor drive)

If the output current exceeds the setting specified in Pr.06-03 when the drive is operating, the drive decreases its output frequency according to the Pr.06-04 setting to prevent motor stall. If the output current is lower than the setting in Pr.06-03, the drive accelerates (according to Pr.06-04) again to catch up with the Frequency command value.



over-current stall prevention during operation

Acceleration/Deceleration Time for Stall Prevention at Constant Speed

Control Mode VF VFPG SVC Default: 0

Settings 0: Use the current acceleration/deceleration time

1: Use the 1st acceleration/deceleration time

2: Use the 2nd acceleration/deceleration time

3: Use the 3rd acceleration/deceleration time

4: Use the 4th acceleration/deceleration time

5: Use the auto-acceleration/auto-deceleration time

Sets the acceleration/deceleration time when stall prevention occurs at constant speed.

✓ SS - SS Over-torque Detection (OT1)

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings 0: Over-torque detection disabled

1: Over-torque detection during constant speed operation, continue to operate after detection

2: Over-torque detection during constant speed operation, stop operating after detection

3: Over-torque detection during operation, continue to operate after detection

4: Over-torque detection during operation, stop operating after detection

Control Mode VF VFPG SVC FOCPG FOCPM Default: 150

Settings 10-250% (rated current of the motor drive)

✓ ☐ 6 - ☐ 7 Over-torque Detection Time (OT1)

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.1

Settings 0.1–60.0 sec.

✓ ☐ 6 - ☐ 8 Over-torque Detection (OT2)

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings 0: Over-torque detection disabled

1: Over-torque detection during constant speed operation, continue to operate after

2: Over-torque detection during constant speed operation, stop operating after detection

3: Over-torque detection during operation, continue to operate after detection

4: Over-torque detection during operation, stop operating after detection

✓ ☐ ☐ ☐ ☐ ☐ ☐ Over-torque Detection Level (OT2)

Control Mode VF VFPG SVC FOCPG FOCPM Default: 150

Settings 10–250% (rated current of the motor drive)


✓ ☐ ☐ - ☐ Over-torque Detection Time (OT2)

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.1

Settings 0.1–60.0 sec.

Pr.06-05 and Pr.06-08 determine the drive's operating mode after over-torque is detected.

Over-torque is detected according to the following method: if the output current exceeds the over-torque detection level (Pr.06-06, default is 150%) and also exceeds the over-torque detection time (Pr.06-07, default is 0.1 second), the keypad displays the fault code "OT1/OT2". If using a multi-function output terminal for over-torque detection, the output is ON. Refer to Pr.02-11–02-22 for details.



Current Limit

Control Mode FOCPG FOCPM Default: 200

Settings 0–250% (rated current of the motor drive)

Sets the drive's maximum output current.

Electronic Thermal Relay

Control Mode VF VFPG SVC FOCPG FOCPM Default: 2

Settings 0: Standard motor

1: Inverter motor


2: Disabled

Prevents self-cooled motor from overheating at low speeds. You can use an electrical thermal relay to limit the drive's output power.

Control Mode VF VFPG SVC FOCPG FOCPM Default: 60.0

Settings 30.0-600.0 sec.

The parameter is set by the drive's output frequency, current and operation time for activating the I²t electronic thermal protection function. The function is activated for 150% of the setting current in Pr.06-13.



✓ 『 S - ドド IGBT Overheat Warning (oH1)

Control Mode VF VFPG SVC FOCPG FOCPM Default: 90.0

Settings 0.0-110.0°C


Control Mode VF VFPG SVC Default: 50

Settings 0-100% (Refer to Pr.06-02, Pr.06-03)

When the operating frequency is larger than Pr.01-01, Pr.06-02 = 150%, Pr.06-03 = 100% and Pr.06-15 = 80%:

Stall Prevention Level during acceleration = Pr.06-02 x Pr.06-15 = 150% x 80% = 120%.

Stall Prevention Level at constant speed = Pr.06-03 x Pr.06-15 = 100% x 80% = 80%.



88 - 18	Present Fault Record
88-17	Second Most Recent Fault Record
81 - 38	Third Most Recent Fault Record
88 - 19	Fourth Recent Fault Record
88-28	Fifth Most Recent Fault Record
88-24	Sixth Most Recent Fault Record

Control mode	VF	V	FPG	SVC	FOCPG	FOCPM	Default: 0
	Settings	0:	No faul	t			
		1:	Over-cı	urrent durino	g acceleration (d	ocA)	
		2:	Over-cı	urrent durino	g deceleration (d	ocd)	
		3:	Over-cı	urrent durinç	g constant spee	d (ocn)	
		4:	Ground	l fault (GFF)	1		
		5:	IGBT sl	hort-circuit (occ)		
		6:	Over-cı	urrent at sto	p (ocS)		
		7:	Over-vo	oltage durin	g acceleration (d	ovA)	
		8:	Over-vo	oltage durin	g deceleration ((bvd)	
		9:	Over-vo	oltage durin	g constant spee	d (ovn)	
		10:	Over-vo	oltage at sto	p (ovS)		
		11:	Low vo	ltage during	acceleration (L	vA)	
		12:	Low vo	ltage during	deceleration (L	vd)	
		13:	Low vo	ltage during	constant speed	l (Lvn)	
		14:	Low vo	ltage at stop	(LvS)		
		15:	Input pl	hase loss (F	PHL)		
		16:	IGBT o	verheat (oH	1)		
		17:	Bulk ca	pacitor over	heat (oH2)		
		18:	Abnorm	nal IGBT ter	nperature detec	ted (tH1o)	
		19:	Abnorm	nal bulk cap	acitor temperatu	ure detected (tH2o)	
		20:	Unusua	al cooling fa	n operation (FAı	า)	
		21:	Overloa	ad (oL) (150	%; 1 minute, mo	otor drive overloaded)	
		22:	Motor o	verload (Ed	L1)		
		23:	Reserve	ed			
		24:	Motor F	PTC overhea	at (oH3)		
		25:	Reserve	ed			
		26:	Over-to	rque 1 (ot1))		
		27:	Over-to	rque 2 (ot2))		
		28:	Reserv	ed			
		29:	Reserv	ed			
		30:	Memor	y writing err	or (cF1)		
		31:	Memor	y reading er	ror (cF2)		
		32:	Isum cı	urrent detec	tion error (cd0)		
		33:	U-phas	e current de	etection error (co	d1)	
		34:	V-phase	e current de	tection error (co	12)	
		35:	W-phas	se current de	etection error (c	d3)	
		36:	cc curre	ent clamp ha	ardware error (H	ld0)	
		37:	oc (ove	r-current) h	ardware error (F	ld1)	

38: ov (over-voltage) hardware error (Hd2) 39: GFF (ground fault) hardware error (Hd3) 40: Auto-tuning error on motor's parameter (AuE) 41: Reserved 42: PG feedback error (PGF1) 43: PG feedback loss (PGF2) 44: PG feedback stall (PGF3) 45: PG slip error (PGF4) 46: Reserved 47: Reserved 48: Reserved 49: External fault input (EF) 50: Emergency stop from external terminals (EF1) 51: Reserved 52: Password error after three attempts (Pcod) 53: Reserved 54: Illegal communication command (cE01) 55: Illegal communication address (cE02) 56: Communication data length error (cE03) 57: Communication attempts to write to a read-only address (cE04) 58: Modbus transmission time-out (cE10) 59: Keypad transmission time-out (cP10) 60: Brake transistor error (BF) 61-63: Reserved Mechanical brake feedback error (MBF) 64: 65: PG hardware error (PGF5) 66: Magnetic contactor error (MCF) 67: Motor output phase loss (MPHL) CAN BUS disconnected (CANF) 68: 69-71: Reserved 72: Safe torque loss (STL1) 73: PG cd hardware error (PGcd) 74: PG absolute signal error (PGHL) 75: PG Z phase signal loss (PGAF) 76: Safe torque output stops (STO) 77: Safe torque loss 2 (STL2) 78: Safe torque loss 3 (STL3) 82: U-phase output phase loss (OPHL) 83: V-phase output phase loss (OPHL) W-phase output phase loss (OPHL) 84: Leveling switch short-circuited (LSS) 86: 87: Leveling switch open-circuited (LSo) 94: BTTx Fail (btt) 95: BTTx Error (bttE)

The parameters record when the fault occurs and forces a stop. For the Lv, it records when it is operating, or it warns without recording.

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings 0: According to settings in Pr.06-22–Pr.06-25 (four sets)

1: According to the binary setting (fifteen sets)

- This parameter is used with the settings 35–38 in Pr.02-11–Pr.02-22 (multi-function output). The fault output selections 1–4 correspond to Bit 0–3.
- This parameter provides two setting methods for the fault output.
 - 0: Set according to the settings in Pr.06-22-Pr.06-25.
 - 1: Set according to the binary setting. Refer to the following example for details.

Example:

Assume that:

- Pr.02-13 (Multi-function output 3 R1A (Relay 3)) is set to 35 Bit0 (Pr.06-22).
- Pr.02-14 (Multi-function output 4 R2A (Realy4)) is set to 36 Bit1 (Pr.06-23).
- Pr.02-15 (Multi-function output 5 (MO1)) is set to 37 Bit2 (Pr.06-24).
- Pr.02-16 (Multi-function output 6 (MO2)) is set to 38 Bit3 (Pr.06-25).

Also assume that external fault (EF) outputs with the following signal: R1A = 1, R2A = 1, MO1 = 0 and MO2 = 1. The corresponding Bit 3–0 is 1011.

Bit 3	Bit 2	Bit 1	Bit 0	Fault Code
-	-	-	-	0: No fault
				1: Over-current during acceleration (ocA)
				2: Over-current during deceleration (ocd)
0	0	0	4	3: Over-current during constant speed (ocn)
0	0	0	1	4: Ground fault (GFF)
				5: IGBT short-circuit (occ)
				6: Over-current at stop (ocS)
				7: Over-voltage during acceleration (ovA)
0	0	1	0	8: Over-voltage during deceleration (ovd)
U	U	1	0	9: Over-voltage during constant speed (ovn)
				10: Over-voltage at stop (ovS)
				11: Low voltage during acceleration (LvA)
				12: Low voltage during deceleration (Lvd)
0	0	1	1	13: Low voltage during constant speed (Lvn)
				14: Low voltage at stop (LvS)
				15: Input phase loss (PHL)
				16: IGBT overheat (oH1)
0	1	0	0	17: Bulk capacitor overheat (oH2)
U	ı	U		18: Abnormal IGBT temperature detected (tH1o)
				19: Abnormal bulk capacitor temperature detected (tH2o)
1	0	0	0	20: Unusual cooling fan operation (FAn)
0	1	0	1	21: Overload (oL) (150%; 1 minute, motor drive overloaded)
0	1	1	0	22: Motor overload (EoL1)
	ı		1 O F	24: Motor PTC overheat (oH3)
0	1	4		26: Over-torque 1 (ot1)
U	I	1	1	27: Over-torque 2 (ot2)

Bit 3	Bit 2	Bit 1	Bit 0	Fault Code
				30: Memory writing error (cF1)
				31: Memory reading error (cF2)
				32: Isum current detection error (cd0)
				33: U-phase current detection error (cd1)
				34: V-phase current detection error (cd2)
1	0	0	0	35: W-phase current detection error (cd3)
				36: cc (current clamp) hardware error (Hd0)
				37: oc (over-current) hardware error (Hd1)
				38: ov (over-voltage) hardware error (Hd2)
				39: GFF (ground fault) hardware error (Hd3)
1	0	0	1	40: Auto-tuning error on motor's parameter (AUE)
				41: Reserved
1	0	1	0	42: PG feedback error (PGF1)
				43: PG feedback loss (PGF2)
0	1	1	1	44: PG feedback stall (PGF3)
				45: PG slip error (PGF4)
				46: Reserved
1	0	1	0	47: Reserved
				48: Reserved
				49: External fault input (EF)
1	0	1	1	50: Emergency stop from external terminals (EF1)
1	0	0	1	52: Password error after three attempts (Pcod)
				54: Illegal communication command (cE01)
				55: Illegal communication address (cE02)
				56: Communication data length error (cE03)
1	1	0	0	57: Communication attempts to write to a read-only address
				(cE04)
				58: Modbus transmission time-out (cE10)
				59: Keypad transmission time-out (cP10)
1	0	0	0	60: Brake transistor error (BF)
	_	4	4	61–63: Reserved
1	0	1	1	64: Mechanical brake feedback error (MBF)
1	0	0	0	65: PG hardware error (PGF5)
1	0	1	1	66: Magnetic contactor error (MCF)
1	0	1	1	67: Output phase loss (MPHL)
1	1	0	1	68: CAN BUS disconnected (CANF)
1	1	1	0	72: Safe torque loss (STL1)
1	0	0	0	73: PG cd hardware error (PGcd)
1	0	0	0	74: PG absolute signal error (PGHL)
1	0	0	0	75: PG Z phase signal loss (PGAF)
1	1	1	0	76: Safe torque output stops (STO)
1	1	1	0	77: Safe torque loss 2 (STL2)
1	1	1	0	78: Safe torque loss 3 (STL3)
1	0	1	1	82: U-phase output phase loss (OPHL)
1	0	1	1	83: V-phase output phase loss (OPHL)
1	0	1	1	84: W-phase output phase loss (OPHL)
	I	<u> </u>	I	

Bit 3	Bit 2	Bit 1	Bit 0	Fault Code
-	-	-	-	86: Leveling switch short-circuited (LSS)
-	-	-	-	87: Leveling switch open-circuited (LSo)
1	0	0	0	94: BTTx Fail (btt)
1	0	0	0	95: BTTx Error (bttE)

×	88-88	Fault Output Option 1
×	88-23	Fault Output Option 2
×	88-24	Fault Output Option 3
×	88-25	Fault Output Option 4

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings 0–65535 sec. (refer to bit table for fault code)

You can use these parameters with multi-function output (set Pr.02-11–Pr.02-22 to 35–38) for the specific requirement. When a fault occurs, the corresponding terminals are activated. You must convert binary value to decimal value when setting Pr.06-22–Pr.06-25.

Foult Code	Bit0	Bit1	Bit2	Bit3	Bit4	Bit5	Bit6
Fault Code	current	Volt.	OL	SYS	FBK	EXI	CE
0: No fault							
1: Over-current during acceleration (ocA)	•						
2: Over-current during deceleration (ocd)	•						
3: Over-current during constant speed (ocn)	•						
4: Ground fault (GFF)						•	
5: IGBT short-circuit (occ)	•						
6: Over-current at stop (ocS)	•						
7: Over-voltage during acceleration (ovA)		•					
8: Over-voltage during deceleration (ovd)		•					
9: Over-voltage during constant speed (ovn)		•					
10: Over-voltage at stop (ovS)		•					
11: Low voltage during acceleration (LvA)		•					
12: Low voltage during deceleration (Lvd)		•					
13: Low voltage during constant speed (Lvn)		•					
14: Low voltage at stop (LvS)		•					
15: Input phase loss (PHL)						•	
16: IGBT overheat (oH1)			•				
17: Bulk capacitor overheat (oH2)			•				
18: Abnormal IGBT temperature detected (tH1o)			•				
19: Abnormal bulk capacitor temperature detected (tH2o)			•				
20: Unusual cooling fan operation (FAn)						•	
21: Overload (oL) (150%; 1 minute, motor drive overloaded)			•				
22: Motor overload (EoL1)			•				
23: Reserved							
24: Motor PTC overheat (oH3)			•				

	Bit0	Bit1	Bit2	Bit3	Bit4	Bit5	Bit6
Fault Code	current	Volt.	OL	SYS	FBK	EXI	CE
25: Reserved							
26: Over-torque 1 (ot1)			•				
27: Over-torque 2 (ot2)			•				
28: Reserved							
29: Reserved							
30: Memory writing error (cF1)				•			
31: Memory reading error (cF2)				•			
32: Isum current detection error (cd0)				•			
33: U-phase current detection error (cd1)				•			
34: V-phase current detection error (cd2)				•			
35: W-phase current detection error (cd3)				•			
36: cc (current clamp) hardware error (Hd0)				•			
37: oc (over-current) hardware error (Hd1)				•			
38: ov (over-voltage) hardware error (Hd2)				•			
39: GFF (ground fault) hardware error (Hd3)				•			
40: Auto-tuning error on motor's parameter (AUE)				•			
41: Reserved					•		
42: PG feedback error (PGF1)					•		
43: PG feedback loss (PGF2)					•		
44: PG feedback stall (PGF3)					•		
45: PG slip error (PGF4)					•		
46: Reserved					•		
47: Reserved						•	
48: Reserved						•	
49: External fault input (EF)						•	
50: Emergency stop from external terminals (EF1)						•	
51: Reserved							
52: Password error after three attempts (Pcod)				•			
53: Reserved							
54: Illegal communication command (cE01)							•
55: Illegal communication address (cE02)							•
56: Communication data length error (cE03)							•
57: Communication attempts to write to a read-only address (cE04)							•
58: Modbus transmission time-out (cE10)							•
59: Keypad transmission time-out (cP10)							•
60: Brake transistor error (BF)						•	
61–62: Reserved							
63: Reserved				•			
64: Mechanical brake feedback error (MBF)						•	
65: PG hardware error (PGF5)				•			
66: Magnetic contactor error (MCF)						•	
67: Output phase loss (MPHL)						•	

Foult Code	Bit0	Bit1	Bit2	Bit3	Bit4	Bit5	Bit6
Fault Code	current	Volt.	OL	SYS	FBK	EXI	CE
68: CAN BUS disconnected (CANF)							•
72: Safe torque loss (STL1)				•			
73: PG cd hardware error (PGcd)				•			
74: PG absolute signal error (PGHL)				•			
75: PG Z phase signal loss (PGAF)				•			
76: Safe torque output stops (STO)				•			
77: Safe torque loss 2 (STL2)				•			
78: Safe torque loss 3 (STL3)				•			
82: U-phase output phase loss (OPHL)						•	
83: V-phase output phase loss (OPHL)						•	
84: W-phase output phase loss (OPHL)						•	
86: Leveling switch short-circuited (LSS)							
87: Leveling switch open-circuited (LSo)						_	
94: BTTx Fail (btt)				•		-	
95: BTTx Error (bttE)				•			

): I	BIIX FLLOL (DI	(LE)						•			
,	06 26										
N	88-28	PTC (Po	ositive Te	empera	ture Coe	efficient)	Detec	tion Actic	n		
	Control Mode	· VF	VFPG	SVC	FOCPG		FOCP	М	Default: ()	
		Settings	0: Warn	and ke	ep operatio	on					
			1: Fault	and ran	np to stop						
	Sets the	action after	detecting	PTC.							
	When Pr.	.06-26 is se	et to 1 (Fa	ult and ı	ramp to sto	p), if bra	ke or op	eration cor	ntactor is C	FF under t	he
	circumsta	ance that S	TO or MI	10 (Enal	ole drive fu	nction) is	not dea	ctivated du	uring decel	eration, ele	vator sti
	runs ever	n brake has	s engaged	l (brake	wear), and	l electric	arc occu	ırs when o	peration co	ontactor is 0	OFF.
	00 00	-		·	·						
M	08-27	PTC Lev	vel								
	Control Mode	· VF	VFPG	SVC	FOCPG		FOCP	М	Default:	50.0	
		Settings	0.0–100	0.0%							
	Sets the I	PTC level.	100% PT	C level o	correspond	s to the r	maximur	n analog ir	iput value.		
N	85-88	PTC De	tection F	ilter Ti	me						
	Control Mode		VFPG	SVC	FOCPG		FOCPI	М	Default: (20	
	• • • • • • • • • • • • • • • • • • • •	Settings	0.00–10	_					20.0.0		
	See Para					Paramete	ers for de	taile			
	E OCC I dia	inclei Gio	up 00 And	nog mpc	at Output i	aramoto	,13 101 GC	italis.			
	88-31	Phase L	oss Det	ection	of Drive (Output a	at Start	-up (MPI	HL)		
	Control Mode	· VF	VFPG	SVC	FOCPG		FOCP	М	Default:	1	
		Settings	0: Disab	ole							
			1: Enab	le							
	1: Auto-de	etect wheth	ner the co	nnectior	n between	the drive	and mot	tor is norm	al wheneve	er the drive	runs. If
	an error o	occurs to th	ne connec	tion betv	ween the d	rive and t	the moto	or (broken o	or loose wi	ring) or the	re is no
	a o o.			~ 511	u	o aa		. ,~. ~			

output phase loss.

output for the drive's any or all of the three phases, the drive displays fault code "67" to indicate motor


- 3.2 Accumulated Drive Power-on Time at the First Fault (min.) **III.** - **III** Accumulated Drive Power-on Time at the Second Fault (min.) ## Accumulated Drive Power-on Time at the Third Fault (min.) ## Accumulated Drive Power-on Time at the Fourth Fault (min.) A - Ч


Accumulated Drive Power-on Time at the Fifth Fault (min.) Accumulated Drive Power-on Time at the Sixth Fault (min.) Control Mode **VFPG** SVC **FOCPG VF** Default: Read only Settings 0-65535 min. **Accumulated Drive Power-on Time at the First Fault (day)** ## Accumulated Drive Power-on Time at the Second Fault (day) Accumulated Drive Power-on Time at the Third Fault (day) 유유 - 극후 Accumulated Drive Power-on Time at the Fourth Fault (day) ## Accumulated Drive Power-on Time at the Fifth Fault (day) Accumulated Drive Power-on Time at the Sixth Fault (day) Control Mode VF **VFPG** SVC **FOCPG** Default: Read only Settings 0-65535 day Fault and Warning Action Control Mode VF **VFPG** SVC **FOCPG FOCPM** Default: 0 Settings Bit 0 = 0: Display Lv fault and coast to stop Bit 0 = 1: Display Lv warn and coast to stop Bit 1= 0: Fan lock, fault and coast to stop Bit 1 = 1: Fan lock, warn and continue operation Bit 2 = 0: Software GFF protection enabled Bit 2 = 1: Software GFF protection disabled Voltage of Emergency Power **VF VFPG** SVC **FOCPG** Default: 24.0/48.0 Control Mode **FOCPM** Settings 24.0-375.0 VDC 48.0-750.0 V_{DC} This parameter works with setting 43 (EPS function) for Pr.02-01-Pr.02-08 (multi-function input commands). Emergency Power (EPS) Mode Operation Speed Control Mode VF **VFPG SVC FOCPG FOCPM** Default: Read only 0.00-299.00 Hz Settings Emergency Power (EPS) ON Operation Direction Control Mode **VF VFPG SVC FOCPG FOCPM** Default: 0

12-06-12

Settings

- 0: Run according to current command
- 1: Run according to the operation direction of power generation mode, and execute the power generation direction detection when in power generation mode.
- 2: After determining the power generation direction, the host controller sends a running direction command. (When at STOP, the direction of power generation mode (MO = 32) confirms and the direction of power generation mode does not remain.) Execute the power generation direction detection every time.
- 3: After determining the power generation direction, the host controller sends a running direction command. (When at STOP, the direction of power generation mode (MO =32) confirms and the direction of power generation mode remains.) Execute the power generation direction detection one time.
- 4: Run according to the operation direction of power generation mode, and execute the power generation direction detection when in normal mode.
- Pr.06-46 is enabled when the external terminal detects the emergency power signal EPS (MI=43).
- When you set Pr.06-46 to 1 and a forward/reverse run command is given, the drive checks for the elevator loading and operates in the power regeneration direction (the motor is in power generating status). The drive uses and operates in the direction that was detected as its power regeneration direction. For safety, the drive does not operate in user command direction to prevent emergency power voltage drop (EPS).
- When you set Pr.06-46 to 4 (motor with gear box, for IM):
 - 1. When the normal mode runs to the largest power factor angel, the results are saved in Pr.06-69.
 - 2. Compare the power factor angle detected by the power generation direction with Pr.06-68 setting value, if the value is larger than Pr.06-68, the current direction is saved in Pr.06-70.
 - 3. When in emergency power mode, the drive runs according to the Pr.06-70 operation direction.
- VF and SVC control modes: In the time setting in Pr.06-47, the drive detects the elevator loading status by performing forward/reverse run. Then the elevator operates in the power regeneration direction (the motor is in power generating status). Refer to the diagram below for the Auto-Detection Timing Graph.





A Pr.02-31: Magnetic Contactor Contracting Delay Time between Drive and Motor

E Pr.02-30: Brake Engage Delay Time when **Elevator Stops**

B Pr.02-29: Brake Release Delay Time when Elevator F Pr.07-04: DC Brake Stopping Time Starts

C Pr.07-03: DC Brake Activation Time

G Pr.02-32: Magnetic Contactor Release


Delay Time between Drive and

D Pr.06-47: Power Generation Direction Search Time

Motor

Auto-detection Timing Diagram

FOCPG/PM Control Mode: In the time setting in Pr.06-47, the drive remains at zero-speed and it is able to determine the elevator loading without performing forward/reverse run. Then the elevator operates in the power regeneration direction (the motor is in power generating status). Refer to the diagram below for the Auto-Detection Timing Graph.



Power Generation Direction Search Time

Control Mode VF VFPG SVC FOCPG FOCPM Default: 1.0

Settings 0.0-5.0 sec.

Power Capacity of Emergency Power (EPS)

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.0

Settings 0.0–100.0 kVA

- When using emergency power (EPS), you must set the parameter to the required power capacity for the emergency power, and then the AC motor drive calculates the acceptable elevator speed (Pr.06-44) with the following equation.
- $I_{motor_rated} = 05 01 \text{ (Induction Motor)} / 08 01 \text{ (PM Motor)}$

$$V_{eps_max} = \frac{06 - 48 \times 0.5}{\sqrt{3} \times I_{motor\ rated}}$$

$$f_{eps_lim\,it} = \frac{V_{eps_max}}{01-02} \times 01-01$$

When the Frequency command > f_{EPS}, the operation speed of emergency power (EPS) is f_{EPS}.

When the Frequency command \leq f_{EPS}, the operation speed of emergency power (EPS) is set according to the current Frequency command.

Power Factor Angle Level for Power Generation Direction

Control Mode VF VFPG SVC FOCPG FOCPM Default: 70.0

Settings 0.0-150.0°

During operation, if the largest power factor angle is larger than Pr.06-68 setting value, the power generation direction is the current operation direction.

Reference Level for Power Factor Angle during Operation

Control Mode VF VFPG SVC FOCPG FOCPM Default: Read only

Settings -200.0-200.0°

The largest power factor angle during operation.

Power Generation Direction

Control Mode VF VFPG SVC FOCPG FOCPM Default: Read only

Settings 0: FWD

1: REV

✓ ☐ ☐ - ☐ ; UPS Output Delay Time

Control Mode VF VFPG SVC FOCPG FOCPM Default: 1.0


Settings 0.0–10.0 sec.

UPS Stops Output Delay Time


Control Mode VF VFPG SVC FOCPG FOCPM Default: 3.0

Settings 0.0-60.0 sec.

- Pr.06-71: At power failure, the contactor sends a MI signal to inform the drive to activate UPS. Then, the drive sends a MO signal to activate the UPS contactor after Pr.06-71 delay time.
- Pr.06-72: After the controller deactivates the emergency power mode, it stops sending a MO signal to deactivate the UPS power after Pr.06-72 delay time.
- Related parameters: multi-function input commands Pr.02-01—Pr.02-08 function setting 54 (Power failure signal) and multi-function output terminals Pr.02-11—Pr.02-16 function setting 49 (Emergency power mode action).



EPS Flow Chart




EPS Flow Chart (ARD or UPS)

The steps to set ARD/UPS as EPS are as follows:

- 1. Set MI = 43 (EPS function)
- 2. Set Pr.06-46 = EPS mode selection
- 3. Set Pr.06-29 = Emergency power voltage running
- 4. Set Pr.06-48 = Emergency power capacity running
- 5. Set Pr.06-47 = Power generation direction search time
- 6. Set Pr.06-68 = Detecting level of power factor at the direction of power generation

NOTE: ARD or UPS can automatically judge whether to cut off the power or not.



The steps to set battery as EPS are as follows:

- 1. Set MI = 54 (Power failure signal)
- 2. Set MI = 43 (EPS function)
- 3. Set MO = 49 (Emergency power mode action)
- 4. Set Pr.06-46 = EPS mode selection
- 5. Set Pr.06-29 = Emergency power voltage running
- 6. Set Pr.06-48 = Emergency power capacity running
- 7. Set Pr.06-47 = Power generation direction search time
- 8. Set Pr.06-68 = Detecting level of power factor at the direction of power generation
- 9. Set Pr.06-71 = MO enables UPS delay time
- 10. Set Pr.06-72 = MO disables UPS delay time

NOTE: When using battery as EPS in an elevator system, auxiliary contact of the contactor should be used to judge whether to cut off the power and notify the drive.

B	<u>8-49</u>	STO La	tch Sele	ction							
Co	ntrol Mode	vF	VFPG	svc	FOCPG	FOCPM	Default:	0000h			
Settings 0000h: STO fault latched, resending RUN command is required											
	0001h: STO warning latched, resending RUN command is required										
	0002h: STO fault latched										
			0003h	: STO w	arning unlat	ched					
	0000h: S	TO fault la	itched, res	ending I	RUN comma	and is required					
	If STO is ON in any condition and a fault occurs, it does not reset until STO is back to normal and use a										
	RESET command or power-on again after resending the RUN command.										
	0001h: S	TO warnin	ıg latched,	resendi	ng RUN cor	mmand is required					
	If STO is	ON in any	condition	and a w	arning occu	ırs, it does not rese	et until STO is bac	k to normal and			
	resend th	ne RUN co	mmand.								
	0002h: S	TO fault la	itched								
	If STO is	ON in any	condition	and a fa	ault occurs,	it does not reset u	ntil STO is back to	normal and use a			
	RESET o	command o	or power-o	n again.							
	0003h: S	TO warnin	ig unlatche	ed							
	If STO is	ON in any	condition	and a w	arning occu	ırs, it automatically	resets when STC) is back to normal.			
				_	•	Section 16-5.					
				nich is a	ssessed by	the elevator contro	oller, before using	the STO warning			
		d function.									
Ш	Fault coc	les STL1 to	o STL3 are	e regard	ed as fault l	atched (you canno	ot set Pr.06-49).				
B	6-50	MO's Ad	ction whe	en Retr	ying after	Fault					
Cor	ntrol Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default:	0			
		Settings	0: Outpu	ut							
			1: No ou	utput							
	Determin	es whethe	r to displa	y the fau	ult indication	when the followin	g faults occur:				
	1: Over-c	current dur	ing accele	ration (d	ocA)						
	2: Over-c	current dur	ing decele	ration (c	ocd)						
	3: Over-current during constant speed (ocn)										
	4: Ground fault (GFF)										
	6: Over-current at stop (ocS)										
	7: Over-voltage during acceleration (ovA)										
	8: Over-voltage during deceleration (ovd)										
	9: Over-voltage during constant speed (ovn)										
	10: Over-voltage at stop (ovS)										
11: Low voltage during acceleration (LvA)											
12: Low voltage during deceleration (Lvd)											
	13: Low v	voltage du	ring consta	ant spee	ed (Lvn)						
	14: Low v	voltage at	stop (LvS)								

15: Input Phase loss (PHL)


Two MO terminals are affected by this parameter and should be set up as: MO = 10: Low voltage waning (LV) MO = 11: Fault Indication ## - 5 | Number of Times to Retry after Fault Control Mode **VF VFPG** SVC **FOCPG FOCPM** Default: 0 Settings 0-10 times To determine the number of times to retry when the following faults occur: 1: Over-current during acceleration (ocA) 2: Over-current during deceleration (ocd) 3: Over-current during constant speed (ocn) 4: Ground fault (GFF) 6: Over-current at stop (ocS) 7: Over-voltage during acceleration (ovA) 8: Over-voltage during deceleration (ovd) 9: Over-voltage during constant speed (ovn) 10: Over-voltage at stop (ovS) 11: Low voltage during acceleration (LvA) 12: Low voltage during deceleration (Lvd) 13: Low voltage during constant speed (Lvn) 14: Low voltage at stop (LvS) 15: Input Phase loss (PHL) After every retry attempt, the number of times to retry is automatically reduced by one as displayed on the keypad. The principles for the number of times to reset: 1. Reset the fault manually. 2. After running normally for 10 minutes, the motor drive returns to the prior setting. 3. The motor drive is powered on and powered off again. Time Interval between Retries Control Mode **VF VFPG** SVC **FOCPG FOCPM** Default: 10.0 Settings 0.5-600.0 sec. Determines the time interval between retries when the following faults occur: 1: Over-current during acceleration (ocA) 2: Over-current during deceleration (ocd) 3: Over-current during constant speed (ocn) 4: Ground fault (GFF) 6: Over-current at stop (ocS) 7: Over-voltage during acceleration (ovA)

8: Over-voltage during deceleration (ovd) 9: Over-voltage during constant speed (ovn)

11: Low voltage during acceleration (LvA)

10: Over-voltage at stop (ovS)

- 12: Low voltage during deceleration (Lvd)
- 13: Low voltage during constant speed (Lvn)
- 14: Low voltage at stop (LvS)
- 15: Input Phase loss (PHL)
- A minimum time interval between retries is 5.5 seconds when OCx/GFF faults are triggered.



Frequency Command when the Most Recent Fault Occurred

Control Mode VF VFPG SVC FOCPG FOCPM Default: Read only

Settings 0.00-655.35 Hz

Output Frequency when the Most Recent Fault Occurred

Control Mode VF VFPG SVC FOCPG FOCPM Default: Read only

Settings 0.00-655.35 Hz

35 - 55 Output Current when the Most Recent Fault Occurred

Control Mode VF VFPG SVC FOCPG FOCPM Default: Read only

Settings 0.00–655.35 Amps

Motor Frequency when the Most Recent Fault Occurred

Control Mode VF VFPG SVC FOCPG FOCPM Default: Read only

Settings 0.00–655.35 Hz

35 - 5 7 Output Voltage when the Most Recent Fault Occurred

Control Mode VF VFPG SVC FOCPG FOCPM Default: Read only

Settings 0.0–6553.5 V

DC Bus Voltage when the Most Recent Fault Occurred

Control Mode VF VFPG SVC FOCPG FOCPM Default: Read only

Settings 0.0-6553.5 V

36 - 53 Output Power when the Most Recent Fault Occurred

Control Mode VF VFPG SVC FOCPG FOCPM Default: Read only

Settings 0.0-6553.5 kW

Output Torque when the Most Recent Fault Occurred

Control Mode VF VFPG SVC FOCPG FOCPM Default: Read only

Settings 0.00-655.35% IGBT Temperature when the Most Recent Fault Occurred **VFPG FOCPG FOCPM** Control Mode **VF SVC** Default: Read only Settings -3276.8-3276.7°C Multi-input Terminals Status when the Most Recent Fault Occurred Control Mode **VFPG SVC FOCPG FOCPM** Default: Read only Settings 0000h-FFFFh Multi-output Terminals Status when the Most Recent Fault Occurred **VFPG SVC** Control Mode **VF FOCPG FOCPM** Default: Read only Settings 0000h-FFFFh Motor Drive Status when the Most Recent Fault Occurred Control Mode **VFPG** SVC **FOCPG FOCPM** Default: Read only Settings 0000h-FFFFh Permanent Operation Direction Count (H) Control Mode **VFPG** SVC **FOCPG FOCPM** Default: Read only 0-60000 Settings Permanent Operation Direction Count (L) Control Mode **VFPG SVC FOCPG FOCPM** Default: Read only Settings 0-9999 Single Operation Direction Count (H) **VFPG** Control Mode **VF SVC FOCPG FOCPM** Default: Read only Settings 0 - 20186 - 76 Single Operation Direction Count (L) **VFPG** Control Mode **VF SVC FOCPG FOCPM** Default: Read only Settings 0 - 9999Number of Times for Single Operation Reset **VF VFPG SVC FOCPG** Control Mode **FOCPM** Default: Read only Settings 0 - 100**RE-18** Number of Times for Operation Direction **VF VFPG SVC FOCPG FOCPM** Control Mode Default: 2.00 Settings 0.00-200.00 k ## - | Function Selection for Operation Times Control Mode **VF VFPG SVC FOCPG FOCPM** Default: 0

0-2

Settings

	When you set Pr.06-79 to 0: Disable the operation direction count function and clear parameters (Pr.06-75, 06-76, and 06-78), and ad one time to the number of times for single operation reset (pr.06-77).									
	When you set Pr.06-79 to 1: Enable the operation direction count function and add one time to the permanent operation direction count and single operation direction count whenever the operation direction changes. If the single operation direction count is larger than Pr.06-78, SERV warning code will be triggered and continues operation.									
	When you set Pr.06-79 to 2: Enable the operation direction count function and add one time to the permanent operation direction count and single operation direction count whenever the operation direction changes. If the single operation direction count is larger than Pr.06-78, SERV fault code will be triggered before operation.									
88	5 - 80	Output F	requency	when	Fault 2 Occu	ırred				
Con	trol Mode	VF Settings	VFPG 0.00–655.	SVC 35 Hz	FOCPG	FOCPM	Default: Read only			
\cap (.01	DC Rue	DC Bus Voltage when Fault 2 Occurred							
Con	trol Mode		VFPG	SVC	FOCPG	FOCPM	Default: Read only			
0011	iti Oi Wode	Settings	0.0–6553.				Boldani. Noda omy			
88	5-82	Output (Current w	hen Faı	ult 2 Occurre	ed				
Con	trol Mode	•	VFPG	SVC	FOCPG	FOCPM	Default: Read only			
		Settings	0.00–655.	35 Amps	3					
88	5 - 8 3	IGBT Te	mperatur	e when	Fault 2 Occi	urred				
Con	trol Mode		, VFPG	SVC	FOCPG	FOCPM	Default: Read only			
		Settings	-3276.8–3	276.7°C						
$\Omega \theta$	5-84	Output F	requency	, when	Fault 3 Occu	ırred				
	trol Mode	•	VFPG	SVC	FOCPG	FOCPM	Default: Read only			
•		Settings	0.00–655.							
Ω	5-85	DC Rue	Voltage v	vhen Fa	ault 3 Occurr	ad				
	trol Mode		VFPG	SVC	FOCPG	FOCPM	Default: Read only			
•		Settings	0.0–6553.							
0.0	. nr	Output (Disease to the	han Fai	ult 2 Occurre					
		•			ult 3 Occurre		Default: Dead only			
Control Mod		VF Settings	VFPG 0.00–655.	SVC 35 Amps	FOCPG	FOCPM	Default: Read only			
_		Journey	0.00 000	.oo Ampa	•					
08	5-87	IGBT Te	mperatur	e when	Fault 3 Occi	urred				
Con	trol Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: Read only			
		Settings	-3276.8–3	3276.7°C						

Descriptions of	raiailietei t	Settings Vi	D-LD			
88-88	Output F	requency	when	Fault 4 Occurre	d	
Control Mode	· VF	VFPG	SVC	FOCPG	FOCPM	Default: Read only
	Settings	0.00–655.	35 Hz			
00.00	DC Pue	Voltago v	hon E	ault 4 Occurred		
		_	SVC	ault 4 Occurred	FOODM	Defends Dead and
Control Mode	vF Settings	VFPG	_	FOCPG	FOCPM	Default: Read only
	Settings	0.0–6553.	5 V			
88-98	Output 0	Current wh	nen Fa	ult 4 Occurred		
Control Mode	· VF	VFPG	SVC	FOCPG	FOCPM	Default: Read only
	Settings	0.00–655.	35 Amp	S		
88-9:	IGBT Te	mperature	e when	Fault 4 Occurre	d	
Control Mode		' VFPG	SVC	FOCPG	FOCPM	Default: Read only
	Settings	-3276.8–3	276.7°C			,
88-88	•			Fault 5 Occurre		
Control Mode		VFPG	SVC	FOCPG	FOCPM	Default: Read only
	Settings	0.00–655.	35 Hz			
88-93	DC Bus	Voltage w	/hen Fa	ault 5 Occurred		
Control Mode		VFPG	SVC	FOCPG	FOCPM	Default: Read only
	Settings	0.0–6553.	5 V			·
05 0	_	_				
86-84	•			ult 5 Occurred		
Control Mode		VFPG	SVC	FOCPG	FOCPM	Default: Read only
	Settings	0.00–655.	.35 Amp	S		
88-95	IGBT Te	mperature	e when	Fault 5 Occurre	d	
Control Mode	VF	VFPG	svc	FOCPG	FOCPM	Default: Read only
	Settings	-3276.8–3	276.7°C	;		
nc ac	0 1 1	_		F 11.2.0		
06-95	•			Fault 6 Occurre		D. C. III D
Control Mode		VFPG	SVC	FOCPG	FOCPM	Default: Read only
	Settings	0.00–655.	35 HZ			
88-97	DC Bus	Voltage w	hen Fa	ault 6 Occurred		
Control Mode	· VF	VFPG	svc	FOCPG	FOCPM	Default: Read only
	Settings	0.0–6553.	5 V			
oc oo	Out			ult 6 Ossums d		
06 - 98 Control Made	•			ult 6 Occurred	EOCD4	Default: Dead!
Control Mode		VFPG	SVC	FOCPG	FOCPM	Default: Read only
	Settings	0.00–655.	So Amp	5		

IGBT Temperature when Fault 6 Occurred

Control Mode VF VFPG SVC FOCPG FOCPM Default: Read only

Settings -3276.8-3276.7°C

[This page intentionally left blank]

07 Special Parameters

★: You can set this parameter during operation

Control Mode VF VFPG SVC FOCPG FOCPM Default: 380.0/760.0

Settings 230V models: 350.0–450.0 V_{DC} 460V models: 700.0–900.0 V_{DC}


Sets the DC bus voltage at which the brake transistor is activated.

Brake Transistor Hysteresis Voltage

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.0

Settings 0.0-100.0 V

Used with Pr.07-00 to make the activated voltage level within range in order to prevent the brake resistor from overheating due to frequent ON/OFF of the brake transistor caused by fluctuated DC bus voltage.



✓ ☐ 7 - ☐ ☐ DC Brake Current Level at Start-up

Control Mode VF VFPG SVC Default: 0

Settings 0–100% of the rated current of the motor drive

- Sets the level of the DC brake current output to the motor at start-up. When setting the DC brake current, the rated current (Pr.00-01) is 100%. It is recommended that you start with a low DC brake current level and then increase until you reach the proper holding torque. However, the DC brake current cannot exceed the motor's rated current to prevent the motor from burnout. Therefore, DO NOT use the DC brake for mechanical retention, otherwise injury or accident may occur.
- When in FOCPG/FOCPM mode, you can enable the DC brake function without setting up this parameter.

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.7

Settings 0.0-60.0 sec.

Sets the length of time that the DC brake current is supplied to motor when activating the drive.

✓ ☐ ? - ☐ Y DC Brake Stopping Time

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.7


Settings 0.0-60.0 sec.

Sets the length of time that the DC brake current is supplied to motor when stopping the drive.

Control Mode VF VFPG SVC FOCPG Default: 0.00

Settings 0.00-299.00 Hz

Determines the frequency at which the DC brake begins during deceleration. When the setting is less than the start frequency (Pr.01-09), the start-point for the DC brake begins at the minimum frequency.



DC Brake Time

✓ ☐ 7 - ☐ DC Brake Proportional Gain

Control Mode VF VFPG SVC Default: 50

Settings 1-500

Sets the output voltage gain when DC braking.

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.00

Settings 0.00-600.00 sec.

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.00

Settings 0.00-600.00 sec.

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.00


Settings 0.00-299.00 Hz

Dwell Frequency at Deceleration

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.00

Settings 0.00-299.00 Hz

- In a heavy load situation, dwelling can temporarily stabilize the output frequency.
- ☐ Use Pr.07-07—Pr.07-10 with heavy load to prevent over-voltage or over-current.



Cooling Fan Control

Control Mode VF VFPG SVC FOCPG FOCPM Default: 2

Settings 0: Cooling fan is always ON.

- 1: One minute after AC motor drive stops, cooling fan is OFF.
- 2: AC motor drive runs and cooling fan is ON; AC motor drive stops and cooling fan is OFF.
- 3: Cooling fan is ON to run when preliminary IGBT temperature (°C) reached.
- 4: Cooling fan is always OFF.
- Use this parameter for the fan control.
- When set to 3, the fan starts to run until the heat sink temperature is less than 40°C if temperature exceeds 40°C.

★ ☐ 7 - 12 Torque Command

Control Mode Default: 0.0

Settings -150.0–150.0% (Pr.07-14 setting = 100%)

This parameter sets the Torque command. When Pr.07-14 is 250% and Pr.07-12 is 100%, the actual Torque command = 250 x 100% = 250% of the motor rated torque.

Control Mode Default: 2

Settings 0: Use the KPC-CC01 digital keypad

1: Use the RS-485 serial communication

2: Use the analog signal (Pr.03-00)

☐ Specifies the Torque command source (Torque command is in Pr.07-12).

Maximum Torque Command

Control Mode VF VFPG SVC FOCPG FOCPM Default: 100

Settings 0–300% of the rated motor drive torque

Sets the maximum Torque command value (the motor rated torque is 100%).

√ ☐ 7 - 15 Torque Command Filter Time

Control Mode Default: 0.000

Settings 0.000-1.000 sec.


When the setting is too long, the control is stable but the control response is delayed. When the setting is too short, the response is quick but the control may be unstable. Adjust the setting according to your control and response situation.

3 - 15 Speed Limit

Control Mode Default: 0

Settings 0: Use the settings in Pr.07-17 and Pr.07-18

1: Use the Frequency command source (Pr.00-14)



✓ ☐ ? - / ? Torque Mode + Speed Limit

Control Mode Default: 10

Settings 0–120%

✓ ☐ 7 - 18 Torque Mode - Speed Limit

Control Mode Default: 10

Settings 0-120%

Limits the speed for forward and reverse running in torque mode (Pr.01-00 Maximum Output Frequency = 100%).

Control Mode SVC FOCPG FOCPM Default: 0

Settings 0: Disable

1: Use the analog input (Pr.03-00)

2: Use the torque offset setting (Pr.07-20)


3: Use the external terminals (by Pr.07-21-Pr.07-23)

- Specifies the torque offset source.
- When set to 3, the torque offset sources are Pr.07-21, Pr.07-22 and Pr.07-23 according to the multifunction input terminal settings (31, 32 or 33).

Pr.02-01-Pr.02-08	Pr.02-01-Pr.02-08	Pr.02-01-Pr.02-08	Torque offset	
is set to 31	is set to 32	is set to 33	•	
OFF	OFF	OFF	N/A	
OFF	OFF	ON	07-23	
OFF	ON	OFF	07-22	
OFF	ON	ON	07-23+07-22	
ON	OFF	OFF	07-21	
ON	OFF	ON	07-21+07-23	
ON	ON	OFF	07-21+07-22	
ON	ON	ON	07-21+07-22+07-23	

				12 B0001 par	mo or r aramotor cominge	, , v. b <u>-</u> .
× 87-28	Torque (Offset Setting				
Control Mode	Э	svc	FOCPG	FOCPM	Default: 0.0	
	Settings	0.0-100.0% (mot	tor drive rated	torque)		
Sets the	torque offs	et. The motor rate	ed torque is 10	00%.		
× 87-21	High Tor	que Offset				
Control Mode	e	svc	FOCPG	FOCPM	Default: 30.0	
	Settings	0.0–100.0% (m	otor drive rate	d torque)		
~ Ωη ₋ ορ	Middle T	Forgue Officet				
•		Torque Offset				
Control Mode	9	SVC	FOCPG	FOCPM	Default: 20.0	
	Settings	0.0–100.0% (m	otor drive rate	d torque)		
	1					
× 83-23	Low Tor	que Offset				
Control Mode	e	SVC	FOCPG	FOCPM	Default: 10.0	
	Settings	0.0–100.0% (m	otor drive rate	d torque)		
When se	t to 3, the to	orque offset sourc	ces are Pr.07-	21, Pr.07-22 and Pr.0	7-23 according to the mu	ulti-
function	input termir	nal settings (31, 3	2 or 33). The i	motor rated torque is 1	100%.	
× 87-24	Forward	Motor Torque	Limit			
× 87-25	Forward	I Regenerative	Torque Lim	it		
× 87-28		Motor Torque	•			
× 87-27		Regenerative		it		
Control Mode			FOCPG	FOCPM	Default: 200	
	Settings	0-300% (rated	torque of the i	motor drive)		
The motor	or rated tor	que is 100%. The	settings for P	r.07-24-Pr.07-27 com	pare with Pr.03-00=7, 8,	, 9, 10.
		•	9		'	

The minimum of the comparison result is torque limit. The diagram below illustrates the torque limit.



★ R 7 - 28 Emergency Stop (EF) & Forced Stop

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings 0: Coast to stop

1: According to deceleration Time 1

2: According to deceleration Time 2

3: According to deceleration Time 3

4: According to deceleration Time 4

5: According to Pr.01-31


When the multi-function input terminal is set to 10 or 18 and is ON, the drive operates according to this parameter setting.

Fig. 7 - 23 Time for Decreasing Torque at Stop

Control Mode FOCPG FOCPM Default: 0.000

Settings 0.000-5.000 sec.


- When the elevator is stopped and the mechanical brake is engaged, the drive stops output. At the same time, it produces noise from the reacting force between the motor and the mechanical brake. Use this parameter to decrease this reacting force and lower the noise.
- Sets the time when torque decreases from 300% to 0%.



							12 Descri	otions of Paramet	ter Settings VFD-ED
N		1 - 30	DC Bral	ke Currer	nt Level at	Stop			
	Cont	rol Mode	VF	VFPG	svc			Default: 0	
			Settings	0–100%	of the rated	current of the	motor drive		
		Sets the	level of the	DC brake	current outp	ut to the moto	or at stop. Whe	en setting the DC	brake current, the
	r	ated cur	rent (Pr.00	-01) is 100	%. It is recor	nmended tha	t you start with	n a low DC brake	current level and
	t	hen incre	ease until y	you reach t	he proper ho	lding torque.	However, the	DC brake currer	it cannot exceed the
	r	notor's r	ated currer	nt to prever	nt the motor f	rom burnout.	Therefore, DO	O NOT use the D	C brake for
	r	mechanio	cal retentio	n, otherwis	se injury or a	ccident may c	occur.		
	<u> </u>	When in	FOCPG/F	OCPM con	trol mode, yo	u can enable	the DC brake	without setting u	up Pr.07-30.
/	0	7-31	Drive O	utput Tord	gue				
		rol Mode	VF	VFPG	svc	FOCPG	FOCPM	Default: 0.0	
			Settings	0.0–300	.0%				
		Measure	ment: Mak	e mechani	cal brake eng	gage, and en	able drive run	3 to 5 seconds.	At this time, output
	t	orque va	alue will be	displayed	on built-in ke	yboard pane	(set Pr.00-04	=8). Then, enter	the value into
	F	Pr.07-31							
	Q I	f the valu	ue displays	too fast to	view, increa	se Pr.11-21 (Filter Time Di	splay on KPED-L	E01).
	0.	7-32	Brake To	orque Tes	st Function				
	Cont	rol Mode	VF	VFPG	svc	FOCPG	FOCPM	Default: 0	
				0: No fur	nction				
			Settings	1: Brake	torque test				
		Brake tor	que test a	ction:					
	,	1. Make	sure the	drive's outp	out torque va	lue has been	entered (as de	escribed in Pr.07	-31).
	2	2. Ente	r Pr.07-36	and Pr.07-3	37 according	to actual con	ditions		
	3	3. Set F	Pr.07-32=1	. Press RU	N key on dig	ital keypad K	PC-CC01 or e	xecute inspectio	n upward operation
		or do	wnward op	peration in	manual mod	e (inspection)	(set Pr.00-15	=1) so that brake	e torque test can be
		run ir	mmediately	/.					
	2	4. In the	e process o	of brake tor	que test, wa	rning code bt	tA (BTTx Testi	ng) will be trigge	red. Increase 10%

- of Pr.07-31 setting value for each time, and a maximum test is 10 times (BTT1 to BTT10). Once the test succeeds, warning code bttS (BTTx Success) will be displayed.
- Multi-function input terminal MI=57 can also be used to enable the brake torque test.

07-33	Brake To	orque Test [Distance			
Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 0
	Settings	0–65535 pp	r			
07-34	Brake To	orque Test 7	īme			
Control Mode	VF	VFPG	svc	FOCPG	FOCPM	Default: 5.0
	Settings	0.0–5.0 sec				



Maximum Output Torque Ratio Allowed during Brake Torque Test

Control Mode

VF VFPG SVC FOCPG FOCPM Default: 0.00

Settings 0.00–2.00

failed in the fourth times Pr.07-35 is smaller than Pr.07-36, it means the brake torque test fails, and fault

For example: When brake torque test fails in the fifth time,

code btt (BTTx Fail) will be triggered on display.

- 1. If the output torque ratio of brake torque test in the fifth time Pr.07-35 ≥ Pr.07-36, then brake torque test succeeds, warning code bttS (BTTx Success) will be displayed on keypad.
- 2. If the output torque ratio of brake torque test in the fifth time Pr.07-35 < Pr.07-36, then brake torque test is valid, warning code bttn (BTTx Success) will be displayed on keypad. In this case, check if it is necessary to adjust Pr.07-37 and execute the brake torque test again.

08 PM Parameters

★: You can set this parameter during operation ## Motor Auto-tuning Control Mode **FOCPM** Default: 0 Settings 0: No function 1: Only for an unloaded motor; auto-measures the angle between magnetic pole and PG origin (Pr.08-09) 2: Auto-tuning PM parameters (suggested to lock the brake) 3: Auto-measures the angle between magnetic pole and PG origin (Pr.08-09) Position the elevator near the middle floors before auto-tuning. Auto-tuning process: 2, and then 1 or 3. Motor auto-tuning: Set Pr.08-00 to 1 to 3, and then press the RUN key on the digital keypad KPC-CC01 (Pr.00-15=2) to start auto-tuning. Or when the drive is in manual mode (inspection), run the upward operation or downward operation (Pr.00-15=1) to start auto-tuning immediately. In the process of auto-tuning, an "Auto tuning" warning continuously displays on the digital keypad until it is finished. Pr.08-00=2: Motor auto-tuning is static test: 1. Make sure that all the drive parameters are set to defaults and the motor wiring is correct. 2. Enter the correct values for Pr.01-01, Pr.01-02, Pr.08-01, Pr.08-02, Pr.08-03 and Pr.08-04. Refer to motor capacity to set the acceleration/deceleration time. 3. Note that the motor will run! The shaft needs to be locked by an external force. 4. After auto-tuning is finished, check if Pr.08-05, Pr.08-07, and Pr.08-08 all have values. Pr.08-00=1: Auto-measures the angle between the magnetic pole and the PG origin. Pay attention to the following notes when measuring: (dynamic test) 1. Unload before auto-tuning. 2. If the drive controls the brake, the drive can auto-tune according to the normal sequence after you complete the wiring and set the brake control parameters.

- 3. If the host controller controls the brake, make sure that the brake is in release status before autotuning.
- Pr.08-00=3: Auto-measures the angle between the magnetic pole and the PG origin. Pay attention to the following notes when measuring: (static test)
 - 1. The motor can be loaded or unloaded before auto-tuning.
 - 2. See the reference table for auto-tuning for Pr.10-00 (PG Signal Type).
 - 3. If the drive controls the brake, the drive can auto-tune according to the normal sequence after you complete the wiring and set the brake control parameters.
 - 4. If the host controller controls the brake, make sure that the brake is in release status before autotuning.
 - 5. Make sure the setting for Pr.10-02 is correct. Incorrectly setting Pr.10-02 causes incorrect positioning of the magnetic pole and results in the wrong angle between the magnetic pole and PG origin.

NOTE:

- The entered rated speed cannot be larger than or equal to 120 f/p.
- Note that if the contactor and brake are not controlled by the AC motor drive, release it manually.

Chapter 12 Descriptions of Parameter Settings | VFD-ED

- Set Pr.08-00 to 1 (unloaded motor) for accurate calculation. If you need to execute this function with a loaded motor, balance the carriage before execution.
- If you do not balance the carriage in a measured environment, you can execute this function with a loaded motor by setting Pr.08-00 = 3. It will have a difference of 15–30° for different encoder types.
- "Auto Tuning Err" displays on the digital keypad when stopping due to an AC motor drive fault or human error, which means the detection fails. Check the wiring connections of the AC motor drive If "PG Fbk Error" displays on the digital keypad, change the setting of Pr.10-02 (if set to 1, change it to 2). If "PG Fbk Loss" displays on the digital keypad, check the feedback of Z-phase pulse.

	88-81	Motor Ra	ated Current		
	Control Mode	:		FOCPM	Unit: Amp
					Default: #.##
		Settings	(40-120%) * Pr.00-01 Amps		
	☐ Sets acco	ording to the	e motor rated current as indicated on	the motor namepla	te. The default is 90% of the
	rated curr	rent.			
	Example:	Suppose t	he rated current for 7.5 HP (5.5 kW) r	models is 25 A and	the default is 22.5 A. In this
	case, the	current ran	ge is from 10 A (25 * 40%) to 30 A (2	25 * 120%).	
N	08-02	Motor Ra	ated Power		
	Control Mode			FOCPM	Default: #.##
		Settings	0.00–655.35 kW		
	Sets the i	motor rated	power. The default is the power of the	e drive.	
	00 00				
×			ated Speed (rpm)		
	Control Mode			FOCPM	Default: 1710
		Settings	0–65535 rpm		
	Sets the i	motor rated	speed according to the motor namer	olate.	
	88-84	Number	of Motor Poles		
	Control Mode	•		FOCPM	Default: 4
		Settings	2–96		
	Sets the i	number of r	motor poles (must be an even numbe	r).	
	08-05	Motor Rs	3		
	Control Mode			FOCPM	Default: 0.000
		Settings	0.000–65.535 Ω		
	<u> </u>				
	08-07	Motor Lq			
	Control Mode	•		FOCPM	Default: 0.0
		Settings	0.0-6553.5 mH		

	8-08	Back Ele	ectromotive Force					
Cor	ntrol Mode	•		FOCPM	Default: 0.0			
		Settings	0.0-6553.5 Vrms					
	Sets the back electromotive force (phase-phase RMS value) when the motor is operated at the rated							
	speed.							
	You can	get the RM	S value by setting Pr.08-00 = 2 (Motor Auto-tuning).				
8	8 - 8 9	Offset Ar	ngle between Magnetic Pole	and PG Origin				
Cor	ntrol Mode	9		FOCPM	Default: 360.0			
		Settings	0.0–360.0°					
	The offse	et angle bet	ween the magnetic pole and PG	origin (measured by	auto-tuning).			
8	8- :0	Magnetic	c Pole Re-orientation					
Cor	ntrol Mode	•		FOCPM	Default: 0			
		Settings	0: Disable					
			1: Enable					
	Use with	Pr.11-00 b	it15 = 1.					
	Use this function to search for the magnetic pole position only for permanent magnet motors.							
	When there is no origin-adjustment for the encoder (Pr.08-09 is 360.0), it only ensures that the motor							
	operatio	n efficiency	can be up to 86% of the best effi	ciency. In this situati	on, if you need to improve the			
	operatio	n efficiency,	cycle the power or set Pr.08-10	to 1 to measure the	magnetic pole orientation again.			

[This page intentionally left blank]

09 Communication Parameters

Control Mode

VF

Settings

VFPG

0: 7, N, 1 for ASCII 1: 7, N, 2 for ASCII

SVC

When using the communication interface, the diagram on the right shows the communication port pin definitions. It is recommended that you connect the AC motor drive to your PC by using Delta IFD6530 or IFD6500 as a communication converter. For details on Modbus communication protocol, see Appendix B. Modbus Protocol.



					N	: You can se	et this parameter du	uring operation
N	09-00	Commu	nication A	ddress			•	
							Default: 1	
		Settings	1–254					
	Sets the	communi	cation addre	ess for th	e drive if the	AC motor dr	ive is controlled thr	ough RS-485
	serial co	mmunicat	ion. The cor	mmunica	tion address	for each AC	motor drive must b	e unique.
×	09-01	Transm	ission Spe	ed				
	Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 19.2	
		Settings	4.8–115.2	dps				
	Sets the	transmiss	sion speed b	etween t	he RS-485 m	naster (PLC,	PC, etc.) and the A	C motor drive.
×	09-02	Transm	ission Fau	It Treati	ment			
	Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 3	
		Settings	0: Warn ar	nd keep o	peration			
			1: Fault an	id ramp t	o stop			
			2: Reserve	ed				
			3: No action	n and no	display			
	Determine commun		eatment if a	transmiss	sion time-out	error (such	as disconnection) o	occurs during
		r.09-02 is	set to 1 (Fa	ult and ra	amp to stop),	if brake or	operation contactor	is OFF under
	the circu	ımstance t	hat STO or	MI40 (En	able drive fu	nction) is no	t deactivated during	g deceleration,
	elevator	still runs	even brake	has enga	iged (brake v	vear), and e	lectric arc occurs w	hen operation
	contacto	or is OFF.						
×	09-03	Time-ou	ıt Detectio	n				
	Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 0.0	
		Settings	0.0–100.0	sec.				
			0.0: Disab	le				
	☐ Sets the	communi	cation time-	out value	·.			
×	09-04	Commu	nication P	rotocol				

FOCPG

FOCPM

Default: 13

Chapter 12 Descriptions of Parameter Settings | VFD-ED

2: 7, E, 1 for ASCII

3: 7, O, 1 for ASCII

4: 7, E, 2 for ASCII

5: 7, O, 2 for ASCII

6: 8, N, 1 for ASCII

7: 8, N, 2 for ASCII

8: 8, E, 1 for ASCII

9: 8, O, 1 for ASCII

10: 8, E, 2 for ASCII

11: 8, O, 2 for ASCII

12: 8, N, 1 for RTU

13: 8, N, 2 for RTU

14: 8, E, 1 for RTU

15: 8, O, 1 for RTU

16: 8, E, 2 for RTU

17: 8, O, 2 for RTU

Control by PC (Computer Link)


When using the RS-485 serial communication interface, you must specify each drives communication address in Pr.09-00. The computer then implements control using the drive's individual addresses.

Modbus ASCII (American Standard Code for Information Interchange): Each byte of data is the combination of two ASCII characters. For example, one byte of data: 64 Hex, shown as '64' in ASCII, consists of 6 (36Hex) and 4 (34Hex).

Control Mode VF VFPG SVC FOCPG FOCPM Default: 2.0

Settings 0.0-200.0 ms

If the host computer does not finish the transmitting/receiving process, you can use this parameter to set the response delay time after the AC motor drive receives communication command as shown in the following picture.



09-06Direct Docking Mode Only09-13

Control Mode VFPG FOCPG FOCPM Default: -

Settings Contact Delta for more information

09-14 PDO Transmission Interval

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings 0-65535 ms

10 Feedback Control Parameters

In this parameter group, ASR is the abbreviation for Adjust Speed Regulator and PG is the abbreviation for Pulse Generator.

★: You can set this parameter during operation

;;; - ;; Selectio	n of Encoder				
Control Mode	VFPG	FOCPG	FOCPM	Default: 0	
Settings 0: No function					
	1: ABZ				
2: ABZ+Hall					
	3: SIN/COS + S	inusoidal			
	4: SIN/COS + E	ndat			
	5: SIN/COS				
	6: SIN/COS + H	iperface			
When you set Pr 10	-02 to 3 4 or 5 vo	u can set Pr 1∩₋	00 only to 0 1 or 2	and you cannot use 3 4 5 and	

- When you set Pr.10-02 to 3, 4 or 5, you can set Pr.10-00 only to 0, 1 or 2, and you cannot use 3, 4, 5 and 6.
- When you set Pr.10-00 to 3, the encoder has one sine and one cosine signal for each revolution. The signal must be: 0.75–1.2 Vpp for the amplitude with phase angle 90°±5 elec. (E.g. ERN 1185 ERN 1387)
- When you set Pr.10-00 to 4 or 6, wait for two seconds after applying the power before executing the RUN command.
- When you set Pr.10-00 to 5, you must set Pr.08-09 to 360.
- Detection of the magnetic pole:
 - (1) 1 or 5: The AC motor drive outputs a short circuit to detect the position of the magnetic pole. At this moment, the motor generates a little noise.
 - (2) 2: The AC motor drive detects the position of the magnetic pole with the UVW encoder signal.
 - (3) 3: The AC motor drive detects the position of the magnetic pole with the sine encoder signal.
 - (4) 4 or 6: The AC motor drive detects the position of the magnetic pole with the communication encoder signal.
- The table below shows the correspondence among encoder, PG card and auto-tuning

PG Signal Type Setting	PG Signal Type	Applicable PG Card x=2, 3,	Pr.08-00=1	Pr.08-00=3
Pr.10-00=1	A, B, Z	EMED-PGAB/ABD-x	N/A	N/A
Pr.10-00=2	A, B, Z+U, V, W	EMED-PGABD- x	Rolling test*1	Rolling test*1
Pr.10-00=3	SIN/COS + Sinusoidal (e.g. ERN1185, ERN1387)	EMED-PGHSD-x	Rolling test*1	Pr.11-00 Bit9=0: Rolling test*1 Pr.11-00 Bit9=1: Static test*1
Pr.10-00=4	SIN/COS + Endat 2.1 (e.g. ECN1313, ECN413)	EMED-PGSD-x	Dynamic test*1	Static test*1
Pr.10-00=5	SIN/COS	EMED-PGHSD-x	N/A	N/A
Pr.10-00=6	SIN/COS + Hiperface (e.g. SRS50/60)	EMED-PGHSD-x	Dynamic test*1	Static test*1

^{*1} Static: Brake engaged, no motor running. Dynamic: Brake released, motor rotates less than one revolution.

Rolling: Brake released, motor rotates more than one revolution.

- # Encoder PPR

Control Mode VFPG FOCPG FOCPM Default: 2048

Settings 1-25000

Sets the encoder pulses per revolution (PPR).


- ## Encoder Input Type Setting

Control Mode VFPG FOCPG FOCPM Default: 0


Settings

0: Disable


1: Phase A leads in a forward run command and phase B leads in a reverse run command




2: Phase B leads in a forward run command and phase A leads in a reverse run command




3: Phase A is a pulse input and phase B is a direction input. (low input=reverse direction, high input=forward direction)



4: Phase A is a pulse input and phase B is a direction input. (low input=forward direction, high input=reverse direction)



5: Single-phase input



- When Pr.10-00 is set to 3, 4, 5 or 6, Pr.10-02 can be only set to 0, 1 or 2, and you cannot use 3, 4 and 5.
- You must enter the correct pulse type for stable control.

Control Mode VFPG FOCPG FOCPM Default: 2

Settings 0: Warn and keep operation


1: Fault and ramp to stop

2: Fault and stop operation

When Pr.10-03 is set to 1 (Fault and ramp to stop), if brake or operation contactor is OFF under the circumstance that STO or MI40 (Enable drive function) is not deactivated during deceleration, elevator still runs even brake has engaged (brake wear), and electric arc occurs when operation contactor is OFF.

				•	0 1
~ 18-84	Encoder	Feedback	Signal Fault De	tection Time	
Control Mode		VFPG	FOCPG	FOCPM	Default: 1.0
	Settings	0.0–10.0 se	ec.		
When the	re is a PG	loss, encode	er signal error, pulse	signal setting error o	or signal error, if time exceeds the
setting fo	r this paran	neter (Pr.10-	04), the PG signal e	rror occurs. Refer to	Pr.10-03 for the encoder
feedback	signal faul	t action.			
w <u>10-05</u>	Encoder	Stall Leve	l (PGF3)		
Control Mode			SVC FOCPG	FOCPM	Default: 115
	Settings	0–120%			
		0: Disable			
Determine	es the max	imum encod	er feedback signal a	illowed before a fault	occurs. (The maximum output
frequency	/ Pr.01-00	= 100%.)			
× 10-08	Encoder	Stall Dete	ction Time (maxi	mum output freat	uency Pr.01-00 = 100%)
Control Mode			SVC FOCPG	FOCPM	Default: 0.1
	Settings	0.0–2.0 sed	C.		
			, , ,		ency Pr.01-00 = 100%)
Control Mode			SVC FOCPG	FOCPM	Default: 50
	Settings	0–50%			
		0: Disable			
~ 18-88	Encoder	Slip Detec	ction Time (maxir	num output frequ	ency Pr.01-00=100%)
Control Mode		VFPG S	SVC FOCPG	FOCPM	Default: 0.5
	Settings	0.0–10.0 se	ec.		
v 10 00		· Ctall and (Clin Frank Astion	/	t francisco Dr. 01.00 -
" "" "" "" "" "" "" "" "" "" "" "" "" "	100%)	Stall and s	Slip Elloi Action	(maximum outpu	t frequency Pr.01-00 =
Control Mode	,	VFPG S	SVC FOCPG	FOCPM	Default: 2
Control Wood	Settings		d keep operation	1 001 111	Doladit. 2
	90		d ramp to stop		
			d stop operation		
	difference			ency) exceeds the P	r.10-07 setting, and the detection
time exce	eds Pr.10-	08 or the mo	tor frequency excee	ds Pr.10-05 setting,	the drive starts to count time. If
the detec	tion time ex	xceeds Pr.10	-06, the encoder fee	edback signal error o	ccurs. Refer to Pr.10-09 encoder
stall and	slip error a	ction.			
When Pr.	10-09 is se	et to 1 (Fault a	and ramp to stop), if	brake or operation o	contactor is OFF under the
circumsta	ince that S	TO or MI40 (Enable drive functio	n) is not deactivated	during deceleration, elevator stil
runs ever	n brake has	s engaged (b	rake wear), and elec	ctric arc occurs when	operation contactor is OFF.
10-10	Mode Se	election for	UVW Input		
Control Mode		VFPG	FOCPG	FOCPM	Default: 0
	Settings	0: Z signal	is at the falling edge	e of U-phase	
		1: Z signal	is at the rising edge	of U-phase	

- 0: The operation is U->V->W, Z signal is at the falling edge of U-phase.
- 1: The operation is U->V->W, Z signal is at the rising edge of U-phase.



ASR (Auto Speed Regulation) Control (P) of Zero Speed

Control Mode VF VFPG SVC FOCPG FOCPM Default: 100.0 Settings 0.0–1000.0%

ASR (Auto Speed Regulation) Control (I) of Zero Speed

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.100 Settings 0.000–10.000 sec.

ASR (Auto Speed Regulation) Control (P) 1

Control Mode VF VFPG SVC FOCPG FOCPM Default: 100.0 Settings 0.0–1000.0%

ASR (Auto Speed Regulation) Control (I) 1

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.100 Settings 0.000–10.000 sec.

ASR (Auto Speed Regulation) Control (P) 2

Control Mode VF VFPG SVC FOCPG FOCPM Default: 100.0

Settings 0.0–1000.0%

ASR (Auto Speed Regulation) Control (I) 2

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.100

Settings 0.000–10.000 sec.


ASR 1/ASR2 Switch Frequency

Control Mode VF VFPG SVC FOCPG FOCPM Default: 7.00 Settings 0.00–299.00 Hz


ettings 0.00–299.00 m

0: Disable

- ASR P determines the proportional control and associated gain (P). ASR I determines the integral control and associated gain (I).
- When you set the integral time to 0, it is disabled. Pr.10-17 defines the switch frequency for the ASR1 (Pr.10-13, Pr.10-14) and ASR2 (Pr.10-15, Pr.10-16).



When using multi-function input terminals to switch ASR1/ASR2, the following diagram shows the operation.



ASR Primary Low Pass Filter Gain Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.008 Settings 0.001–0.350 sec.

- Defines the ASR command filter time.
- When Pr.11-00 is set to 1 ASR auto-tuning, Pr.10-18 is invalid.

Zero Speed Position Control Gain (P)

Control Mode FOCPM Default: 80.00

Settings 0.00-655.00%

☐ When Pr.11-00 is set to bit 7=1, Pr.10-19 is valid

★ III - 2 II Low Speed ASR Width Adjustment

Control Mode VFPG FOCPG FOCPM Default: 5.00


Settings 0.00-299.00 Hz

★ ## High Speed ASR Width Adjustment

Control Mode VFPG FOCPM Default: 5.00

Settings 0.00-299.00 Hz

These two parameters set the width of the slope of the ASR command during zero speed to low speed or Pr.10-17 to high speed.



Zero Speed Position Control Holding Time

Control Mode FOCPM Default: 0.250

Settings 0.001-65.535 sec.

- Sets this parameter when elevator jerk at start-up or carriage inversion occurs. In principle, the holding time cannot exceed the time when frequency starts output.

Zero Speed Position Control Low Pass Filter Time

Control Mode FOCPM Default: 0.004

Settings 0.001-65.535 sec.

Zero Speed Position Control Activation Mode Selection

Control Mode FOCPM Default: 0

Settings 0: After the brake release set in Pr.02-29

1: After the brake signal input (Pr.02-01-02-08 is set to 42)

When Pr.10-24 = 0, use the zero speed control with Pr.02-29 (refer to the explanations in Pr.02-32).

Elevator Leveling (Zero Speed Gain P)

Control Mode VF VFPG SVC FOCPG FOCPM Default: 100.0

Settings 0.0-1000.0%

Elevator Leveling (Zero Speed Integral I)

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.100

Settings 0.000-10.000 sec.

Fig. - 2 ? Elevator Starting (Zero Speed Gain P)


Control Mode VF VFPG SVC FOCPG FOCPM Default: 100.0

Settings 0.0–1000.0%

Elevator Starting (Zero Speed Integral I)

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0.100

Settings 0.000-10.000 sec.



Control Mode VFPG FOCPG FOCPM Default: 0

Settings 0-31

- Setting to 0 is the same as setting to 1:
 - 0: No frequency division
 - 1: Frequency division by 1 (remains the same as the original frequency)

✓ ☐ → ☐ PG Card Frequency Division Output Type

Control Mode VFPG FOCPG FOCPM Default: 0000h

Settings 0000h–0008h

See Chapter 7 for more information about PG cards.

✓ ☐ → ☐ → ☐ PG Card C+/C-

Control Mode VFPG FOCPG FOCPM Default: 0000h

Settings 0000h-0001h

- When using a Heidenhain ERN1387 encoder, use Pr.10-31 to adjust the definition of the Delta PG card EMED-PGHSD-3's terminal 10 and terminal 11 (see the table below). Refer to p.7-17 for detailed terminal descriptions.
- Delta PG card: EMED-PGHSD-3 (D-sub Terminal #)



	Heidenhain ERN1387							
Terminal #	Pr.10-31=0000h	Pr.10-31=0001h						
10	C-	C+						
11	C+	C-						

After connecting Delta PG card EMED-PGHSD-4 according to the descriptions in Section 7-4, **you must** set Pr.10-31=0001h.

w 10-32	Over-acceleration Level											
Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 0.0						
	Settings	0.0-20.0	m/s²									
10-33	Over-acc	celeration	Detec	tion Time								
Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 0.05						
	Settings	0.01-5.00 sec.										
18-34	₩ - 3 ¥ Over-acceleration Detection											
Control Mode	VF	VFPG	SVC	FOCPG	FOCPM	Default: 0						
	Settings	0: Alway	s detect	t		Settings 0: Always detect						
	1: Detect during operation											

11 Advanced Parameters

★: You can set this parameter during operation


System Control


Control Mode

FOCPG
FOCPM
Default: 0000h

Settings
Bit 0 = 0: No function
Bit 0 = 1: ASR auto-tuning; PDFF enabled
Bit 7 = 0: No function
Bit 7 = 1: Zero speed position control is enabled
Bit 9 = 0: Dynamic PG origin auto-tuning with load (support by PGHSD-x)
Bit 9 = 1: Static PG origin auto-tuning with load by enabling PGHSD-x
Bit 15 = 0: When power is applied, detect the position of the magnetic pole again
Bit 15 = 1: When power failure

Bit 0 = 1: Enable the PDFF function and the system generates an ASR setting. At this time, Pr.10-11–Pr.10-16 are invalid and Pr.11-09–Pr.11-10 are valid.





- When Bit 7 = 1, zero speed position control is enabled (refer to Chapter 12 Parameter Group 02 Elevator Timing Diagram). Pr.10-22 is valid only when bit 7 is set to 1, and this function only supports PM motors.
- When Bit 9 = 1, valid only when Pr.10-00 is set to 3, and the mechanical brake must be in engaged status.

Control Mode FOCPG FOCPM Default: 1.00

Settings 0.10-4.00 m/s

Control Mode FOCPG FOCPM Default: 400

Settings 100-2000 mm

Control Mode FOCPG FOCPM Default: 1.00

Settings 1.00-100.00

I - II Y Suspension Ratio


Control Mode FOCPG FOCPM Default: 1

Settings 0 = 1: 11 = 2: 1

2 = 4:1

3 = 8:1

Suspension Ratio 1:1 Suspension Ratio 2:1



Mechanical Inertial Ratio

Control Mode FOCPG FOCPM Default: 40

Settings 1-300%

- You can calculate the load inertia according to the settings of motor parameters, Pr.11-02 Traction Sheave Diameter, Pr.11-14 Motor Current at Acceleration and Pr.11-15 Carriage Acceleration. You can use this parameter to adjust the mechanical inertia ratio.
- Mechanical inertia reference value (%):

Load / Motor	IM	PM
Without load	40	10
With load	80–120	40

✓ ; ; - ; ; Zero speed Bandwidth

Control Mode FOCPG FOCPM Default: 10

Settings 1–40 Hz

★ ! ! - [] T Low speed Bandwidth

Control Mode FOCPG FOCPM Default: 10

Settings 1–40 Hz

★ ! - # # High speed Bandwidth

Control Mode FOCPG FOCPM Default: 10

Settings 1-40 Hz


After estimating the inertia and setting Pr.11-00 =1 (auto-tuning), you can adjust parameters Pr.11-06, Pr.11-07 and Pr.11-08 separately by speed response. The larger the value, the faster the response. Pr.10-17 is the switch frequency between the low speed and high speed bandwidth.

PDFF Gain Value

Control Mode FOCPG FOCPM Default: 30

Settings 0–200%

- After you estimate and set Pr.11-00=1 (auto-tuning), use Pr.11-09/11-10 to reduce overshoot. Adjust the PDFF gain value according to the actual situation.
- In addition to traditional PI control, it also provides the PDFF function to reduce overshoot for speed control.
 - 1. Get system inertia
 - 2. Set Pr.11-00 to 1
 - 3. Adjust Pr.11-09 and Pr.11-10 (a larger value suppresses overshoot better). Adjust according to the actual condition.



★ ! ! - ! Speed Feed Forward Gain

Control Mode FOCPG FOCPM Default: 0

Settings 0-500

Pr.11-09 and Pr.11-10 are enabled when Pr.11-00 is set to Bit 0 = 1.

	diameter C	octings VI D-			
11-11	Notch Fil	Iter Depth			
Control Mode			FOCPG	FOCPM	Default: 0
	Settings	0–20 db			
11-12	Notch Fil	lter Frequer	псу		
Control Mode	!		FOCPG	FOCPM	Default: 0.00
	Settings	0.00-200.00	Hz		
Sets the r	esonance f	frequency of th	ne mechanical sys	tem. Adjust it to a s	maller value to suppress the
mechanic	al system r	esonance.			
A larger v	alue impro	ves resonance	e suppression fund	tion.	
☐ The notch	า filter frequ	ency is the m	echanical frequenc	cy resonance.	
_	• •	Display for I	_ow Pass Filter	Time	
Control Mode		VFPG SV	C FOCPG	FOCPM	Default: 0.500
	Settings	0.001–65.53	5 sec.		
Lowers th	ie blinking f	requency of th	ne LCD display.		
11_14	Motor Cu	urrent at Acc	celeration		
Control Mode			Seleration	FOCPM	Default: 150
Control Mode	Settings	50–200%		I OOF W	Delault. 130
	- Settings				
11-15	Carriage	Acceleratio	n		
Control Mode	!			FOCPM	Default: 0.75
	Settings	0.20–2.00 m	/s²		
	_				
11-16	Reserve				
11-18	Reserve	d			
_		eed Parking			D. f lt. 40
Control Mode			FOCPG	FOCPM	Default: 10
	Settings	1–40 Hz			
11.30	$D\backslash \Lambda/\Lambda \Lambda$ $\Lambda \Lambda_c$	nde (Dulse)	Nidth Modulatio	n Mode)	
	I A A IAI IAIC	Jue (Fuise-1	vidin ModulaliC	ni wode)	Default: 0
Control Mode		O- DD\\/\\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	odo (Digital Dulca	Midth Madulation	
	Settings			Width Modulation N	Mode)
				Width Modulation Nor Pulse Width Mod	Mode)
Control Mode	Settings	1: SVPWM r	mode (Space-Vecto		Mode)
Control Mode	Settings Filter Tim	1: SVPWM r	node (Space-Vector	or Pulse Width Mod	Mode) dulation Mode)
Control Mode 11-21 Control Mode	Settings	1: SVPWM r	node (Space-Vectors) n KPED-LE01 SVC FOCPO	or Pulse Width Mod	Mode)

12 User-defined Parameters

						arameter during operation
× 12-00	User-de	efined Para	ameter	1		
Control Mod	e VF	VFPG	SVC	FOCPG	FOCPM	Default: 0616
	Settings	0–9999				
				_		
× 12-01		fined Para				
Control Mod		VFPG	SVC	FOCPG	FOCPM	Default: 0632
	Settings	0–9999				
× 12-02	User-de	fined Para	meter	3		
Control Mode		VFPG	svc	FOCPG	FOCPM	Default: 0633
	Settings	0–9999				
× 12-03		fined Para		4		
Control Mode	e VF	VFPG	SVC	FOCPG	FOCPM	Default: 0653
	Settings	0–9999				
w 10_0u	l leer-de	fined Para	meter	5		
Control Mod		VFPG	SVC	FOCPG	FOCPM	Default: 0654
Control Mod	Settings	0-9999	010	10010	1 001 111	Delault. 0004
	Octungo	0 0000				
× 12-05	User-de	fined Para	ameter	6		
Control Mod	e VF	VFPG	SVC	FOCPG	FOCPM	Default: 0655
	Settings	0-9999				
/ 13 OC	11 1-	£ J D		7		
<i>"</i> 16-08		fined Para			F00014	D (11 0050
Control Mod		VFPG	SVC	FOCPG	FOCPM	Default: 0656
	Settings	0–9999				
/ 12-03	User-de	fined Para	ameter	8		
Control Mod		VFPG	SVC	FOCPG	FOCPM	Default: 0657
	Settings	0-9999				
		fined Para	ameter	9		
Control Mod	e VF	VFPG	SVC	FOCPG	FOCPM	Default: 0658
	Settings	0–9999				
w 13.00	l Isar₋da	fined Para	meter	10		
Control Mode		VFPG	SVC	FOCPG	FOCPM	Default: 0659
Control Mode	Settings	0-9999	340	FOCFG	FOCFIVI	Delault. 0039
	Jettings	0-3333				
× 12 - 18	User-de	fined Para	ameter	11		
Control Mode	e VF	VFPG	svc	FOCPG	FOCPM	Default: 0660
	Settings	0–9999				

✓ ; User-defined Parameter 12							
Control Mode V		SVC	FOCPG	FOCPM	Default: 0661		
Setti	ngs 0–9999						
Control Mode V	_	SVC	FOCPG	FOCPM	Default: 0662		
Setti	ngs 0–9999						
	r-defined Par	ameter	14				
Control Mode V	F VFPG	svc	FOCPG	FOCPM	Default: 0663		
Setti	ngs 0–9999						
/ 17 111			45				
Control Mode V	r-defined Par F VFPG	svc	FOCPG	FOCPM	Default: 0664		
Setti		SVC	FUCPG	FOCPINI	Delault. 0004		
Settil	igs 0–9999						
/ 12 - 15 Use	r-defined Par	ameter	16				
Control Mode V	F VFPG	SVC	FOCPG	FOCPM	Default: 0617		
Setti	ngs 0–9999						
<i>×</i> 12-15 Use	r defined Da	ramotor	17				
Control Mode V		SVC	FOCPG	FOCPM	Default: 0634		
Setti			10010	1 001 III	Boladit. 0004		
	.gc						
	r-defined Par	ameter	18				
Control Mode V	F VFPG	SVC	FOCPG	FOCPM	Default: 0635		
Setti	ngs 0–9999						
<i>×</i> 12 - 18 Use	r-defined Par	ameter	19				
Control Mode V		SVC	FOCPG	FOCPM	Default: 0618		
Setti					20.00.00		
Control Mode V	_	SVC	FOCPG	FOCPM	Default: 0636		
Setti	ngs 0–9999						
<i>×</i> 12-28 Use	r-defined Par	ameter :	21				
Control Mode V		SVC	FOCPG	FOCPM	Default: 0637		
Setti	ngs 0–9999						
	r-defined Par				D (11 22/2		
Control Mode V		SVC	FOCPG	FOCPM	Default: 0619		
Setti	ngs 0–9999						

w !2-22	User-de	fined Para	meter	23					
Control Mod		VFPG	SVC	FOCPG	FOCPM	Default: 0638			
CONTROL MOG	Settings	0–9999	010	10010	1 001 111	Delault. 0000			
	- Cettings	0-9999							
× 12-23	✓ 12 - 2 3 User-defined Parameter 24								
Control Mod	e VF	VFPG	SVC	FOCPG	FOCPM	Default: 0639			
	Settings	0-9999							
× 15-54	User-de	fined Para	ameter	25					
Control Mod	e VF	VFPG	SVC	FOCPG	FOCPM	Default: 0620			
	Settings	0–9999							
(13 36		.		00					
<i>№</i> 12-25									
Control Mod		VFPG	SVC	FOCPG	FOCPM	Default: 0640			
	Settings	0–9999							
w !2-25	User-de	fined Para	meter	27					
Control Mod		VFPG	SVC	FOCPG	FOCPM	Default: 0641			
Control Mod	Settings	0-9999	340	10010	1 001 111	Delault. 0041			
	Settings	0-9999							
× 12-23	User-de	fined Para	ameter	28					
Control Mod		VFPG	svc	FOCPG	FOCPM	Default: 0621			
	Settings	0-9999							
× 15-58	User-de	fined Para	ameter	29					
Control Mod	e VF	VFPG	SVC	FOCPG	FOCPM	Default: 0642			
	Settings	0–9999							
2 13 30		.		00					
	User-de								
Control Mod		VFPG	SVC	FOCPG	FOCPM	Default: 0643			
	Settings	0–9999							
√ 12-38		fined Para							
Control Mod	e VF	VFPG	SVC	FOCPG	FOCPM	Default: 0			
	Settings	0–9999							
w 13_3_1	✓ ; 2 - 3 ; User-defined Parameter 32								
Control Mad					F0001:	D-f 4504			
Control Mod		VFPG	SVC	FOCPG	FOCPM	Default: 1561			
CC -	Settings	0–9999							
				fined in parame					
	·	•	•	• ,	roup 12 (it saves up to	•			
The sav	ed values c	an also be t	he parar	meter addresse	s (but the hexadecimal	value must be converted to a			
decimal	decimal value).								
Example	es of user-d	efined para	meters						

Example 1:

If you need to enter Pr.08-03 into Pr.12-00, enter 0803 into Pr.12-00. Then, the keypad displays the setting for Pr.08-03 in Pr.13-00.

Example 2:

If you need to enter parameter addresses 2102H and 211BH with the digital keypad, convert 211BH to a decimal value before entering (see below for details).

The setting method for 211BH:

Convert 211BH (hexadecimal) to a decimal value:

$$211B$$

 $1x16^{1}+11x16^{0}=16+11=27$ input 2127

13 View User-defined Parameters

★: You can set this parameter during operation

View User-defined Parameters

Control Mode

VF **VFPG** **SVC FOCPG** **FOCPM**

Default: -

Settings Pr.00-00-Pr.11-20

Present Fault Record

Control Mode

۷F **VFPG** **SVC FOCPG** **FOCPM**

Default: -

Display

0616 (Same as Pr.06-16)

Address

Motor Operation at Present Fault Time (min.)

Control Mode

VF **VFPG** **SVC FOCPG** **FOCPM**

Default: -

Display

0632 (Same as Pr.06-32)

Address

Control Mode

VF

VFPG

SVC **FOCPG** **FOCPM**

Default: -

Display

0633 (Same as Pr.06-33)

Address

Frequency Command at Present Fault

Control Mode

VF

VFPG

SVC

FOCPG

FOCPM

Default: -

Display

0653 (Same as Pr.06-53)

Address

Output Frequency at Preset Fault

Control Mode

VF

VFPG

SVC

FOCPG

FOCPM

Default: -

Display

0654 (Same as Pr.06-54) Address

Output Current at Present Fault

Control Mode

۷F **VFPG**

SVC

FOCPG

FOCPM

Default: -

Display

Address

0655 (Same as Pr.06-55)

Motor Frequency at Present Fault

Control Mode

VF **VFPG** SVC **FOCPG** **FOCPM**

Default: -

Display

Address

0656 (Same as Pr.06-56)

13-11 Output Voltage at Present Fault **VFPG** SVC **FOCPG FOCPM** Control Mode ۷F Default: -Display 0657 (Same as Pr.06-57) Address Control Mode VF **VFPG SVC FOCPG FOCPM** Default: -Display 0658 (Same as Pr.06-58) Address Output Power at Present Fault Control Mode ۷F **VFPG** SVC **FOCPG FOCPM** Default: -Display 0659 (Same as Pr.06-59) Address **Output Torque at Present Fault** Control Mode **VF VFPG** SVC **FOCPG FOCPM** Default: -Display 0660 (Same as Pr.06-60) Address Power Module IGBT Temperature at Present Fault VF **VFPG SVC FOCPG FOCPM** Control Mode Default: -Display 0661 (Same as Pr.06-61) Address 🚼 - 🔛 Multi-function Terminal Input Status at Present Fault Control Mode **VFPG** ۷F SVC **FOCPG FOCPM** Default: -Display 0662 (Same as Pr.06-62) Address Harait Multi-function Terminal Output Status at Present Fault **VFPG** Control Mode ۷F SVC **FOCPG FOCPM** Default: -Display 0663 (Same as Pr.06-63) Address The Italian Drive Status at Present Fault Control Mode **VF VFPG** SVC **FOCPG FOCPM** Default: -Display 0664 (Same as Pr.06-64) Address Second Most Recent Fault Record Control Mode ۷F **VFPG SVC FOCPG FOCPM** Default: -Display 0617 (Same as Pr.06-17) Address

12 Descriptions of Parameter Settings | VFD-ED **13 - 15** Motor Operation at Second Most Recent Fault Time (min.) VF **VFPG** SVC **FOCPG** Control Mode **FOCPM** Default: -Display 0634 (Same as Pr.06-34) Address Motor Operation at Second Most Recent Fault Time (day) Control Mode **VF VFPG** SVC **FOCPG FOCPM** Default: -Display 0635 (Same as Pr.06-35) Address - Third Most Recent Fault Record **VFPG VF SVC** Control Mode **FOCPG FOCPM** Default: -Display 0618 (Same as Pr.06-18) Address **VFPG SVC FOCPG FOCPM** Control Mode **VF** Default: -Display 0636 (Same as Pr.06-36) Address Motor Operation at Third Most Recent Fault Time (day) Control Mode **VF VFPG SVC FOCPG FOCPM** Default: -Display

0637 (Same as Pr.06-37) Address

Fourth Most Recent Fault Record VF **VFPG SVC FOCPG** Control Mode **FOCPM** Default: -Display 0619 (Same as Pr.06-19) Address

VF **VFPG** SVC **FOCPG** Control Mode **FOCPM** Default: -

> Display 0638 (Same as Pr.06-38) Address

Motor Operation at Fourth Most Recent Fault Time (day)

Control Mode VF **VFPG SVC FOCPG FOCPM** Default: -Display

0639 (Same as Pr.06-39) Address

Fifth Most Recent Fault Record **VF** Control Mode **VFPG** SVC **FOCPG FOCPM** Default: -

Display 0620 (Same as Pr.06-20) Address

12 Descriptions of Parameter Settings | VFD-ED

∤ २ - २ ९ Motor Operation at Fifth Most Recent Fault Time (min.)

Control Mode VF VFPG SVC FOCPG FOCPM Default: -

Display

0640 (Same as Pr.06-40) Address

Control Mode VF VFPG SVC FOCPG FOCPM Default: -

Display

0641 (Same as Pr.06-41) Address

- 13 - 2 → Sixth Most Recent Fault Record

Control Mode VF VFPG SVC FOCPG FOCPM Default: -

Display

0621 (Same as Pr.06-21) Address

🚼 - 🛂 Motor Operation at Sixth Most Recent Fault Time (min.)

Control Mode VF VFPG SVC FOCPG FOCPM Default: -

Display

0642 (Same as Pr.06-42) Address

[구구구역] Motor Operation at Sixth Most Recent Fault Time (day)

Control Mode VF VFPG SVC FOCPG FOCPM Default: -

Display

0643 (Same as Pr.06-43)

Address

Control Mode VF VFPG SVC FOCPG FOCPM Default: -

Display

0 (Same as Pr.00-00)

Address

13-31 Date Code Y.WKD

Control Mode VF VFPG SVC FOCPG FOCPM Default: Read only

Display


1561 (Same as Pr.15-61) Address

Displays the year / week / day that the program of this firmware version is completed. For example, 20.321 indicates that the program is completed on the first day of the 32th week in year 2020.


Chapter 13 Warning Codes

Warning code displays differently on digital keypad KPC-CC01 and built-in keyboard panel KPED-LE01. Examples of their different displays show as below.

Example of warning code shows on digital keypad KPC-CC01:



Example of warning code shows on built-in keyboard panel KPED-LE01:



Chapter 13 Warning Codes | VFD-ED

ID No.	Display on KPED-LE01	Display on KPC-CC01	Descriptions
1	£ 8 0 1	CE01 Warning CE01 Comm. Cmd. Err	Illegal communication command Cause Communication command error
2	6605	CE02 Warning CE02 Data Adrr. Err	Illegal data address Cause Data address error
3	C E O 3	CE03 Warning CE03 Data Length Err	Communication data length error Cause Communication data length exceeds 1–20 characters
4	C E O 4	CE04 Warning CE04 Wrong Writing	Attempt to write to a read-only address. Cause Communication error occurred when attempting to write values into 0x21xx, 0x22xx read-only address.
5	C 8 10	CE10 Warning CE10 Comm. Time Out	Modbus transmission time-out Cause Communication cable error
6	CP 18	CP10 Warning CP10 Keypad time out	Digital keypad KPC-CC01 transmission time-out Cause Communication cable or digital keypad error
7	58 /	SE1 Warning SE1 Keypad Copy Err	Keypad copy parameter error Cause Keypad copy errors, including communication delays, communication error (keypad received error FF86) and parameter value error.
8	582	SE2 Warning SE2 Keypad Copy Fail	Keypad copy parameter failure Cause Keypad copy done but parameter writing error
9	o# !	oH1 Warning oH1 IGBT Over Heat	IGBT overheat warning Cause IGBT temperature is over the default 90°C (Pr.06-14).

ID No.	Display on KPED-LE01	Display on KPC-CC01	Descriptions
10	o#2	oH2 Warning oH2 Capacitance oH	Capacitor overheat warning Cause The temperature of the capacitor is over 65°C.
15	P9F 1	PGF1 Warning PGF1 PGFBK warn	PG feedback error Cause When Pr.10-03 = 0 (default = 2), a warning message displays instead of a fault message when an error occurs.
16	P9F2	PGF2 Warning PGF2 PGFBK Loss	PG feedback loss warning Cause Pr.10-03 = 0 (default = 2), a warning message displays instead of a fault message when an error occurs.
17	P9F3	PGF3 Warning PGF3 PGFBK Stall	PG feedback stall warning Cause Pr.10-09 = 0 (default = 2), a warning message displays instead of a fault message when an error occurs.
18	P9F4	PGF4 Warning PGF4 PG Slip Err	PG slip error warning Cause Pr.10-09 = 0 (default = 2), a warning message displays instead of a fault message when an error occurs.
19	PXL	PHL Warning PHL Phase Loss	Phase loss Cause When Pr.06-01 =0 (default = 2), a warning message displays instead of a fault message when a phase loss occurs.
20	ot !	ot1 Warning ot1 Over Torque 1	Over-torque 1 Cause When Pr.06-05 =1 or 3 (default = 0), a warning message displays instead of a fault message when there is an over-torque detection.
21	o t 2	ot2 Warning ot2 Over Torque 2	Over-torque 2 Cause When Pr.06-05 =1 or 3 (default = 0), a warning message displays instead of a fault message when there is an over-torque detection.
22	o#3	oH3 Warning oH3 Motor Over Heat (PTC)	Motor overheat (PTC) Cause When Pr.06-26 = 0 (default = 0), a warning message displays when there is a PTC detection.

Chapter 13 Warning Codes | VFD-ED

ID No.	Display on KPED-LE01	Display on KPC-CC01	Descriptions
24	oSL	oSL Warning oSL Over Slip Warn	Over-slip error Cause When Pr.05-16 = 0 (default = 0), a warning message displays when the slip deviation level is over the setting in Pr.05-14 and the slip deviation detection time is longer than the setting in Pr.05-15.
25	ხში	tUn Warning tUn Auto tuning	Auto-tuning is in process
26	FAn	FAn Warning Fan Fan Off	Fan error warning Cause When Pr.06-45 bit 1 = 1, a warning message displays when the cooling fan is locked (when bit1 = 1, there is an output error).
27	dEAn	dCAn HAND Warning CAN OFF CAN bus Off	CAN Bus off Cause CAN Bus disconnection or PDO communication time- out
28	5EOA	STOA Warning STOA STO Warning	Safe Torque Off alarm Cause Safe torque output function is off and Pr.06-49 = 0001h or 0003h.
43	L5	LS Warning LS Lv Sensor Warn	Leveling switch signal error When elevator runs downward, LU signal is still active. When elevator runs upward, LD signal is still active. Cause Leveling switch (LU/LD) action error Corrective Action Check if the action of leveling switch (LU/LD) is normal.
48	ььья	bttA Warning bttA BTTx Testing	BTTx Testing Brake torque test is running Cause When brake torque test is running, this warning code will be triggered. Corrective Action When brake torque test is finished, this warning will be automatically cleared.

Chapter 13 Warning Codes | VFD-ED


ID No.	Display on KPED-LE01	Display on KPC-CC01	Descriptions
49	bttn	bttn BTTx Normal	BTTx Normal Brake torque test is valid Cause Maximum output torque ratio allowed during brake torque test (Pr.07-37) is too large Corrective Action Adjust Pr.07-37 Maximum Output Torque Ratio Allowed during Brake Torque Test
50	bEE5	bttS Warning bttS BTTx Success	BTTx Success Brake torque test is finished.

[This page intentionally left blank]


Chapter 14 Fault Codes

Fault code displays differently on digital keypad KPC-CC01 and built-in keyboard panel KPED-LE01. Examples of their different displays show as below.

Example of fault code shows on digital keypad KPC-CC01:



• Example of fault code shows on built-in keyboard panel KPED-LE01:



NOTE: Check Pr.06-16 to Pr.06-21 for the most recent fault records.

*: ID No. are in accordance with the settings of Pr.06-16 to Pr.06-21.

ID	Display on	nce with the settings of	1.00 10 10 1.00 21.
No.*	KPED-LE01	Display on KPC-CC01	Descriptions
1	осЯ	Fault ocA oc at Accel	Over-current during acceleration (output current exceeds three times the drive's rated current during acceleration). corrective action 1. Short-circuit at motor output: Check for possible poor insulation at the output. 2. Acceleration Time is too short: Increase the Acceleration Time. 3. AC motor drive output power is too small: Replace with a drive with larger capacity.
2	ocd	Fault ocd oc at Decel	Over-current during deceleration (output current exceeds three times the drive's rated current during deceleration). corrective action 1. Short-circuit at motor output: Check for possible poor insulation at the output. 2. Deceleration Time is too short: Increase the Deceleration Time. 3. AC motor drive output power is too small: Replace with a drive with larger capacity.
3	ocn	Fault ocn oc at Normal SPD	Over-current during steady operation (output current exceeds three times the drive's rated current during constant speed). corrective action 1. Short-circuit at motor output: Check for possible poor insulation at the output. 2. Sudden increase in motor load: Check for possible motor stall. 3. AC motor drive output power is too small: Replace with a drive with larger capacity.
4	9FF	Fault GFF Ground Fault	Ground fault When one or more of the output terminals is (are) grounded, and the short circuit current is more than 60% of the AC motor drive rated current, the AC motor drive power module may be damaged. NOTE: The short circuit protection is to protect the AC motor drive, not to protect you. corrective action 1. Check the wiring connections between the AC motor drive and motor for possible short circuits, also check connection to ground. 2. Check whether the IGBT power module is damaged. 3. Check for possible poor insulation at the output.
5	occ	Fault occ Short Circuit	Short circuit is detected between the IGBT module upper bridge and lower bridge. corrective action Contact the dealer or manufacturer to return the motor drive to the factory for repair.
6	oc5	Fault ocS oc at Stop	Over-current at stop Hardware failure in over-current detection corrective action Contact the dealer or manufacturer to return the motor drive to the factory for repair.

ID No.*	Display on KPED-LE01	Display on KPC-CC01	Descriptions
7	ouA	Fault ovA ov at Accel	DC bus over-voltage during acceleration 230V: 405 V _{DC} ; 460V: 810 V _{DC} corrective action 1. Check if the input voltage falls in the rated AC motor drive input voltage range. 2. Check for possible voltage transients. 3. If DC bus over-voltage is due to regenerative voltage, increase the Acceleration Time or add an optional brake resistor.
8	oud	Fault ovd ov at Decel	DC bus over-voltage during deceleration 230V: 405 V _{DC} ; 460V: 810 V _{DC} corrective action 1. Check if the input voltage falls in the rated AC motor drive input voltage range. 2. Check for possible voltage transients. 3. If DC bus over-voltage due to regenerative voltage, increase the Deceleration Time or add an optional brake resistor.
9	חחם	Fault ovn ov at Normal SPD	DC bus over-voltage at constant speed 230V: 405 V _{DC} ; 460V: 810 V _{DC} corrective action 1. Check if the input voltage falls in the rated AC motor drive input voltage range. 2. Check for possible voltage transients. 3. If DC bus over-voltage due to regenerative voltage, increase the Deceleration Time or add an optional brake resistor.
10	ou5	Fault ovS ov at Stop	Over-voltage at stop Hardware failure in voltage detection. corrective action 1. Check if the input voltage falls in the rated AC motor drive input voltage range. 2. Check for possible voltage transients.
11	LuA	Fault LvA Lv at Accel	DC bus voltage during acceleration is less than the setting in Pr.06-00. corrective action 1. Check if the input voltage is normal. 2. Check for possible sudden load change.
12	Lud	Fault Lvd Lv at Decel	DC bus voltage during deceleration is less than the setting in Pr.06-00. corrective action 1. Check if the input voltage is normal. 2. Check for possible sudden load change.

ID No.*	Display on KPED-LE01	Display on KPC-CC01	Descriptions
13	Lun	Fault Lvn Lv at Normal SPD	DC bus voltage at constant speed is less than the setting in Pr.06-00 corrective action 1. Check if the input voltage is normal. 2. Check for possible sudden load change.
14	Lu5	Fault LvS Lv at Stop	Low voltage at stop corrective action 1. Check if the input voltage is normal. 2. Check for possible sudden load change.
15	PHL	Fault PHL Phase Loss	Phase Loss corrective action Check power source input to make sure all three input phases are connected correctly.
16	oH I	Fault oH1	IGBT overheating IGBT temperature exceeds protection level 3–5 HP, 50–60 HP: 105°C 7.5–30 HP: 95°C 40–100 HP: 110°C corrective action 1. Ensure that the ambient temperature falls in the specified temperature range. 2. Make sure heat sink is not obstructed. Check if the fan is operating 3. Check if there is enough ventilation clearance for the AC motor drive.
17	oH2	Fault OH2 Capacitance oH	Capacitor overheating Capacitor's temperature exceeds the protection level. 3–100 HP: 65°C corrective action 1. Ensure that the ambient temperature falls in the specified temperature range. 2. Make sure heat sink is not obstructed. Check if the fan is operating 3. Check if there is enough ventilation clearance for the AC motor drive.
18	EH lo	Fault tH1o Thermo 1 Open	IGBT overheating protection fault corrective action Contact the dealer or manufacturer to return the motor drive to the factory for repair.

ID No.*	Display on KPED-LE01	Display on KPC-CC01	Descriptions
19	ŁH2o	Fault tH2o Thermo 2 Open	Capacitor module overheating fault corrective action Contact the dealer or manufacturer to return the motor drive to the factory for repair.
20	FAn	Fault FAn Fan Locked	Cooling fan does not run properly. corrective action Check if the cooling fan is covered by dust and needs to be cleaned. Contact the dealer or manufacturer to return the motor drive to the factory for repair if necessary.
21	oL	Fault oL Over Load	The output current causes the motor drive to be overload. If the output current is 150% higher than the drive's rated current, the motor drive can sustain the output for a maximum of 60 seconds. corrective action 1. Check if the motor is overloaded. 2. Increase the output capacity of the motor drive.
22	EoL I	Fault EoL1 Thermal Relay 1	The output current causes the motor to be overload. If the output current is 150% higher than the drive's rated current, the motor can sustain the output for a maximum of 60 seconds. corrective action 1. Check the setting for motor full-load current (Pr.05-01). 2. Check if motor is overloaded and change to a higher power motor.
24	οΗЭ	Fault oH3 Motor Over Heat	Motor overheating The AC motor drive internal temperature exceeds the setting in Pr.06-27 (PTC level). corrective action 1. Make sure that the motor is not obstructed. 2. Ensure that the ambient temperature falls in the specified temperature range. 3. Change to a higher power motor.
26	ot I	Fault ot1 Over Torque 1	The ot1 and ot2 fault codes appear when the following conditions occur: - The output current exceeds the setting in Pr.06-06 (Over-torque Detection Level (OT1)> and Pr.06-09 (Over-torque Protection Level (OT2).

ID	Display on	Display on KPC-CC01	Descriptions
No.*	KPED-LE01		
			- The output current lasts longer than the time setting in Pr.06-07
			and Pr.06-10.
		HAND	- You set Pr.06-05 or Pr.06-08 to 2 or 4.
	. =	Fault	
27	otZ	ot2	corrective action
		Over Torque 2	Check if the motor is overloaded.
			2. Check if the setting in Pr.05-01 IM (Motor Full-load Current)
			and Pr.08-01 PM (Motor Full-load Current) are appropriate.
			If necessary, increase the motor output capacity.
			Cannot program internal EEPROM.
	_	Fault	corrective action
30	cF I	cF1	Press RESET key to reset to the default.
		EEPROM Write Err	Contact the dealer or manufacturer to return the motor drive
			to the factory for repair.
			Cannot read internal EEPROM.
		HAND	
	- -	Fault	corrective action
31	cF2	cF2	Press RESET key to reset to the default.
		EEPROM Read Err	2. Contact the dealer or manufacturer to return the motor drive
			to the factory for repair.
			Hardware failure in current detection
		HAND	4:
32	cd0	Fault cd0	corrective action
		Isum Sensor Err	Reboot the motor drive. If fault code continues to display on the
			keypad, contact the dealer or manufacturer to return the motor drive
			to the factory for repair.
			U-phase current detection error
		Fault	corrective action
33	cd l	cd1	Reboot the motor drive. If fault code continues to display on the
		las Sensor Err	keypad, contact the dealer or manufacturer to return the motor drive
			to the factory for repair.
			V-phase current detection error
		HAND	
34	c d Z	Fault	corrective action
		cd2 Ibs Sensor Err	Reboot the motor drive. If fault code continues to display on the
		IDO CONSOI EN	keypad, contact the dealer or manufacturer to return the motor drive
			to the factory for repair.

ID	Display on	Display on KPC-CC01	Descriptions
No.*	KPED-LE01		
35	cd3	Fault cd3	W-phase current detection error corrective action Reboot the motor drive. If fault code continues to display on the keypad, contact the dealer or manufacturer to return the motor drive to the factory for repair.
36	HdO	Fault Hd0 cc HW Error	CC (current clamp) hardware error corrective action Reboot the motor drive. If fault code continues to display on the keypad, contact the dealer or manufacturer to return the motor drive to the factory for repair.
37	Hd I	Fault Hd1 oc HW Error	OC hardware error corrective action Reboot the motor drive. If fault code continues to display on the keypad, contact the dealer or manufacturer to return the motor drive to the factory for repair.
38	HdZ	Fault Hd2 ov HW Error	OV hardware error corrective action Reboot the motor drive. If fault code continues to display on the keypad, contact the dealer or manufacturer to return the motor drive to the factory for repair.
39	НаЭ	Fault Hd3 GFF HW Error	GFF hardware error corrective action Reboot the motor drive. If fault code continues to display on the keypad, contact the dealer or manufacturer to return the motor drive to the factory for repair.
40	AUE	Fault AUE Auto Tuning Err	Auto-tuning error corrective action 1. Check the cabling between drive and motor. 2. Check if the motor capacity and the parameter settings are appropriate and try again.
42	P9F I	Fault PGF1 PG Fbk Error	PG feedback error (command direction is different from the feedback direction) corrective action When PG feedback control is enabled, check if Pr.10-01 (Encoder PPR) is set to 0.

ID No.*	Display on KPED-LE01	Display on KPC-CC01	Descriptions
43	P9F2	Fault PGF2 PG Fbk Loss	PG feedback loss corrective action Check the PG feedback wiring.
44	P9F3	Fault PGF3 PG Fbk Over SPD	PG feedback stall corrective action 1. Check the PG feedback wiring. 2. Check if the settings for PI gain and acceleration/deceleration are appropriate (Pr.10-05, Pr.10-06). 3. Contact the dealer or manufacturer to return the motor drive to the factory for repair.
45	P9F4	Fault PGF4 PG Fbk Deviate	 PG slip error corrective action 1. Check the PG feedback wiring. 2. Check if the settings for PI gain and acceleration/deceleration are appropriate (Pr.10-07, Pr.10-08). 3. Contact the dealer or manufacturer to return the motor drive to the factory for repair.
49	EF	Fault EF External Fault	External Fault When you set the Multi-Function Input command (MI1–MI8) to #10 EF input (Pr.07-28) and when multi-function input terminals are triggered to close, the motor drive stops running. corrective action Press RESET after you clear the fault.
50	EF I	Fault EF1 Emergency Stop	Emergency Stop When you set the Multi-Function Input command (MI1–MI8) to #28 Emergency stop (EF1) (Motor coasts to stop), the motor drive stops running. corrective action Press RESET after you clear the fault.
52	Pcod	Fault Pcod Password Error	Password error After entering the wrong password three consecutive times, the keypad is locked. corrective action Refer to Pr.00-07 and Pr.00-08 settings for more information. Cycle the power for the motor drive to clear the lock and enter the correct password.

ID No.*	Display on KPED-LE01	Display on KPC-CC01	Descriptions
54	cE0 I	Fault cE01	Illegal function code corrective action Check if the function code is correct (function code must be 03, 06, 10, 63).
55	cE02	Fault cE02 Data Addr Err	Illegal data address (00H to 254H) The data address for 0X2XX is between 0X2000–0X2005. Any address out of this range is a fault. corrective action Check if the communication data address is correct.
56	cE03	Fault cE03 Data length Err	Illegal data length The data length must be between 1 to 20 digits. Any length out of this range is a fault. corrective action Check if the data length is smaller than the minimum value or larger than the maximum value.
57	cE04	Fault cE04 Wrong Writing	Attempt to write value to read-only communication address Communication addresses such as 0X21XX, 0X22XX are read-only. Any command sent to these addresses causes a fault. corrective action Check if the communication address is correct.
58	cE 10	Fault cE10 Comm Time Out	Modbus communication time-out (Pr.09-02–Pr.09-03) corrective action Check if the communication wiring is correct.
59	cP 10	Fault cP10 Keypad Time Out	Keypad KPC-CC01 transmission time-out corrective action 1. Check if the communication wiring is correct 2. Check if there is anything wrong with the keypad
60	ЬF	Fault BF Braking Fault	Brake transistor fault corrective action If the fault code continues to display on the keypad after you press RESET key, contact the dealer or manufacturer to return the motor drive to the factory for repair.

ID No.*	Display on KPED-LE01	Display on KPC-CC01	Descriptions
110.	TH ED LEGT		Mechanical brake failure
			The feedback signal and the release signal are not consistent.
		Fault	
64	лЬF	MBF	corrective action
		Mech. Brake Fail	Check if the mechanical brake signal is correct.
			2. Check if the mechanical brake detection time setting (Pr.02-35)
			is correct.
			PG card hardware error
		HAND	corrective action
65	P9F5	Fault PGF5	Check if the PG feedback wiring is correct.
	' _'' _'	PG HW Error	2. If fault code continues to display on the keypad, contact the
			dealer or manufacturer to return the motor drive to the factory
			for repair.
			Magnetic contactor error
		HAND	The feedback signal and the release signal are not consistent.
66	ПЕF	Fault	corrective action
	1111	MCF Contactor Fail	Check if the magnetic contactor signal is correct.
		Dontactor Fair	2. Check if the magnetic contactor detection time setting (Pr.02-
			36) is correct.
			Motor output phase loss.
			corrective action
			Unbalanced three-phase impedance of the motor. Replace the
			motor.
		Fault	Check if the motor wiring is incorrect.
67	TPHL	MPHL	Check if a single-phase motor is used.
		Motor Phase Loss	4. Check if the current sensor is broken.
			5. Check if temporary power supply is used or any grounding fault.
			6. Make sure the capacity of the drive matches the motor.
			7. Any abnormal motor current spikes or drops may trigger
			MPHL.
		HAND	CAN Bus off
68	[AnF	Fault	corrective action
	בחחר	CANF CAN Bus Off	Check that the CAN Bus is wired correctly.
		O/M Bus Off	Verify that there is no PDO communication time-out.
69			Reserved
70			Reserved
71			Reserved

ID	Display on	Display on KPC-CC01	Descriptions
No.*	KPED-LE01		
72	SEL I	Fault STL1 STO Loss 1	 STO1–SCM1 internal hardware error. corrective action Check the STO1/SCM1 wiring. Reset the emergency switch (ON) and reboot the motor drive. Check the voltage at least > 11 V. Check the wiring between STO1 and E24V, and the wiring between SCM1 and DCM. After checking all the wiring, reboot the motor drive. If STL1 still appears, contact the local dealer or manufacturer.
73	P9cd	Fault PGcd PG cd Wrong Wire	PG card wiring error corrective action Incorrect wiring for pin C+, C-, D+, D Verify if the wiring matches the descriptions in Section 7-3 (EMED-PGHSD-3) and Section 7-4 (EMED-PGHSD-4).
74	P9HL	Fault PGHL PG Hall loss Err	PG absolute signal error corrective action 1. Check if the encoder absolute positions (C+/C- and D+/D-) and PG card are properly wired. 2. If the cables are properly wired but the fault code still displays on the keypad, contact the dealer or manufacturer to return the motor drive to the factory for repair.
75	P9AF	Fault PGAF Z Sig. loss Err	PG Z-phase signal loss corrective action 1. Check if the encoder's Z-phase signal and PG card are properly wired. 2. If the cables are properly wired but the fault code still displays on the keypad, contact the dealer or manufacturer to return the motor drive to the factory for repair.
76	5E0	Fault STO Safe Torque Off	 Safe Torque Off function is enabled. corrective action Check the wiring for STO1/SCM1 and STO2/SCM2. Reset the emergency switch (ON) and reboot the motor drive. Check the voltage at least > 11 V. Check the wiring between STO1/STO2 and E24V, and the wiring between SCM1/SCM2 and DCM. After checking all the wiring, reboot the motor drive. If STO still appears, contact the local dealer or manufacturer.

ID No.*	Display on KPED-LE01	Display on KPC-CC01	Descriptions
77	5EL2	Fault STL2 STO Loss 2	 STO2–SCM2 internal hardware error. corrective action Check the STO2/SCM2 wiring. Reset the emergency switch (ON) and reboot the motor drive. Check the voltage at least > 11 V. Check the wiring between STO2 and E24V, and the wiring between SCM2 and DCM. After checking all the wiring, reboot the motor drive. If STL2 still appears, contact the local dealer or manufacturer.
78	5EL3	Fault STL3 STO Loss 3	Internal hardware error. corrective action After checking all the wiring, reboot the motor drive. If STL3 still appears, contact the local dealer or manufacturer.
82	OPHL	Fault OPHL U Phase Loss	 U-phase output phase loss corrective action Unbalanced three-phase impedance of the motor. Replace the motor. Check if the motor wiring is incorrect. Check if a single-phase motor is used. Check if the current sensor is broken. Check if temporary power supply is used or any grounding fault. Make sure the capacity of the drive matches the motor.
83	0PHL	Fault OPHL V Phase Loss	 V-phase output phase loss corrective action 1. Unbalanced three-phase impedance of the motor. Replace the motor. 2. Check if the motor wiring is incorrect. 3. Check if a single-phase motor is used. 4. Check if the current sensor is broken. 5. Check if temporary power supply is used or any grounding fault. 6. Make sure the capacity of the drive matches the motor.

ID No.*	Display on KPED-LE01	Display on KPC-CC01	Descriptions
INO.	KPED-LEUT		W-phase output phase loss
84	Fault OPHL W Phase Loss		 Corrective action Unbalanced three-phase impedance of the motor. Replace the motor. Check if the motor wiring is incorrect. Check if a single-phase motor is used. Check if the current sensor is broken. Check if temporary power supply is used or any grounding fault. Make sure the capacity of the drive matches the motor.
86	L55	Fault LSS Lv Sensor Short	Leveling switch short-circuited When elevator runs downward, LD signal will be inactive. When elevator runs upward, LU signal will be inactive. When elevator is running, there will be signal active for LU and LD whenever passing through each floor. If not so, this fault code will be triggered.
			corrective action Check if the action of leveling switch (LU/LD) is normal.
87	Fault LSo Lv Sensor Open		Leveling switch open-circuited When elevator executes leveling, either LU or LD is open-circuited or both are open-circuited, this fault code will be triggered. corrective action Check if the action of leveling switch (LU/LD) is normal.
94	ЬЕЕ	Fault btt BTTx Fail	BTTx Fail Brake torque test failed corrective action 1. Minimum output torque ratio allowed during brake torque test (Pr.07-36) is too large. Adjust Pr.07-36 Minimum Output Torque Ratio Allowed during Brake Torque Test 2. Mechanical brake clamping force is insufficient. Adjust or replace the mechanical brake.
95	ььье	Fault bttE BTTx Error	BTTx Error Brake torque test action error corrective action Poor wiring connection. Check MI terminal wiring (FWD, REV, and MI=57).

[This page intentionally left blank]

Chapter 15 Maintenance and Troubleshooting

- 15-1 Maintenance and Inspections
- 15-2 Greasy Dirt Problems
- 15-3 Fiber Dust Problems
- 15-4 Corrosion Problems
- 15-5 Industrial Dust Problems
- 15-6 Installation and Wiring Problems
- 15-7 Multi-function Input / Output Terminal Application Problems

Chapter 15 Maintenance and Troubleshooting | VFD-ED

The AC motor drive has various warnings and protections against errors such as over-voltage, low voltage, or over-current. Once an error occurs, the protections activate, the AC motor drive stops output, activates the error contacts, and the motor coasts to stop. Please refer to the warning/fault display from the AC motor drive and look up the corresponding causes / corrective actions in Chapter 13 Warning Codes and Chapter 14 Fault Codes. The fault record is stored in the AC motor drive internal memory and can store the six most recent error messages. You can read it from the digital keypad or through the communications by accessing the parameters.

The AC motor drive includes a large number of electronic components, including ICs, resistors, capacitors, transistors, cooling fans and relays. These components do not last forever. Even under normal circumstances, they will eventually become error-prone if used past their lifespans. Therefore, you must perform periodic preventive maintenance to identify defective and worn out parts, and eliminate the causes of malfunctions in the AC motor drive at an early stage. At the same time, parts that have exceeded their product life should be replaced whenever possible to ensure safe operation.

Visual checks should be done regularly to monitor the AC motor drives operation, and to make sure nothing unusual happens. Check the situations listed in the following table.



- ☑ Wait five seconds after a fault has been cleared before pressing RESET with the input terminal keypad.
- ☑ The drive must first be switched off for at least five minutes for ≤ 22 kW models, and 10 minutes for ≥ 30kW models until the charging indicator turns off, and the voltage between terminals \oplus \odot must be lower than 25 V_{DC} before it is safe to open the cover to begin maintenance operations.
- ☑ Only qualified personnel can work on maintenance or replace parts. (Remove metal items such as watch, rings, and other metal items before operation, and use only insulated tools.)
- ☑ Never modify internal components or wiring.
- ☑ The performance and the surrounding environment should meet the standard specifications. There should be no abnormal noise, vibration, or odor.

15-1 Maintenance and Inspections

For regular maintenance, first stop operation, then turn off the power, and then take off the outer cover. Even after turning off the power supply, charging voltages remaining in the filter capacitor require some time to discharge. To avoid danger, operation must not start until the charging indicator goes off, and you confirm the voltage with a voltmeter to be below the safety value ($\leq 25 \text{ V}_{DC}$).

Ambient environment					
Itama ta Chaele	Mathada and Critarian	M	Maintenance Period		
Items to Check	Methods and Criterion	Daily	Half Year	One Year	
Check the ambient temperature, humidity,	Visual inspection and				
and vibration and check for any dust, gas,	measurement with equipment	0			
oil or water drops.	with standard specification				
Check for any dangerous objects	Visual inspection	0			

Voltage				
Items to Check	Methods and Criterion	Maintenance Period		
items to check		Daily	Half Year	One Year
Check that the voltage of main circuit and	Measure with multimeter with	0		
control circuit are correct.	standard specifications.			

Digital keypad display					
ltama ta Chaali	Methods and Criterion	Maintenance Period			
Items to Check		Daily	Half Year	One Year	
Check that the display is clear for reading	Visual inspection	0			
Check for any missing characters	Visual inspection	0			

Mechanical parts				
Items to Check	Methods and Criterion	М	aintenance F	Period
items to Check		Daily	Half Year	One Year
Check for any abnormal sound or vibration	Visual and audible inspection		0	
Check for any loose bolts	Securely tighten		0	
Check for any deformed or damaged parts	Visual inspection		0	
Check for any color change caused by	Vigual inapaction		0	
overheating	Visual inspection)	
Check for any dust or dirt	Visual inspection		0	

Chapter 15 Maintenance and Troubleshooting | VFD-ED

Main circuit					
Items to Check	Mathada and Critarian	M	Maintenance Period		
items to Check	Methods and Criterion	Daily	Half Year	One Year	
Check for any loose or missing bolts	Securely tighten	0			
Check for machine or insulator deformation,					
crack, damage or color change due to	Visual inspection		0		
overheating or ageing					
Check for any dust or dirt	Visual inspection		0		

Main circuit terminals and wiring					
Items to Check	Methods and Criterion	Maintenance Period			
items to Check		Daily	Half Year	One Year	
Check the terminal and copper plate for					
color change or deformation due to	Visual inspection		0		
overheating					
Check for damage to the wiring insulation	Vigual inapaction		0		
or color change	Visual inspection)		

Main circuit terminal block						
ltama ta Chaela	Methods and Criterion	Maintenance Period				
Items to Check		Daily	Half Year	One Year		
Check for any damage	Visual inspection	0				

Main circuit filter capacitor					
Items to Check	Methods and Criterion	M	Maintenance Period		
		Daily	Half Year	One Year	
Check for any liquid leaks, color change,	Visual inspection	0			
crack or buckling of the exterior cover					
Check if the safety valve is not removed or	Visual inspection	0			
if the valve is obviously expanded	Visual inspection				
Measure static capacity when required	-	0			

Main circuit resistor				
Items to Check	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
Check for any odors or insulation cracks	Visual and audible inspection	0		
due to overheating				
Check for any disconnections	Visual inspection	0		
Check for damaged connections	Measure with multimeter with	0		
	standard specifications			

Main circuit transformer and reactor					
Items to Check	Methods and Criterion	Maintenance Period			
		Daily	Half Year	One Year	
Check for any abnormal vibration or odors	Visual and audible inspection	0			

Main circuit magnetic contactor and relay				
Items to Check	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
Check for any sound of vibration while running	Audible inspection	0		
Check that the contact works correctly	Visual inspection	0		

Main circuit PCB and connector				
Items to Check	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
Chack for any loose scrows and connectors	Tighten the screws and press		0	
Check for any loose screws and connectors	the connectors firmly in place.			
Check for any odors and color change	Visual and smell inspection		0	
Check for any crack, damage, deformation	Visual inspection		0	
or corrosion				
Check for any liquid leaks or deformation in	Visual inspection		0	
capacity				

Cooling system cooling fan				
Items to Check	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
Check for any abnormal sound or vibration	Visual, audible inspection, and			
	turn the fan by hand (turn off the		0	
	power before operation) to see if			
	it rotates smoothly.			
Check for any loose bolts	Securely tighten		0	
Check for any color change due to	Visual inspection		0	
overheating			0	

Cooling system ventilation channel				
Items to Check	Methods and Criterion	Maintenance Period		
		Daily	Half Year	One Year
Check for any obstruction in the heat sink,	Visual inspection		0	
air intake or air outlet				

NOTE: Use a chemically neutral cloth to clean and use a dust cleaner to remove dust when necessary.

15-2 Greasy Dirt Problems

Serious greasy dirt problems generally occur in processing industries such as machine tools, punching machines and so on. Please be aware of the possible damages that greasy oil may cause to your drive.

- 1. Electronic components that silt up with greasy oil may cause the drive to burn out or even explode.
- 2. Most greasy dirt contains corrosive substances that may damage the drive.

Solution:

Install the AC motor drive in a standard cabinet to keep it away from greasy dirt. Clean and remove greasy dirt regularly to prevent damage to the drive.





15-3 Fiber Dust Problems

Serious fiber dust problems generally occur in the textile industry. Please be aware of the possible damages that fiber may cause to your drives.

- 1. Fiber that accumulates or adheres to the fans leads to poor ventilation and causes overheating problems.
- 2. Plant environments in the textile industry have higher degrees of humidity that may cause the drive to burn out, become damaged or explode due to wet fiber dust adhering to the devices.

Solution:

Install the AC motor drive in a standard cabinet to keep it away from fiber dust. Clean and remove fiber dust regularly to prevent damage to the drive.








15-4 Corrosion Problems


Corrosion problems may occur if any fluids flow into the drives. Please be aware of the possible damages that corrosion may cause to your drive.


1. Corrosion of internal components may cause the drive to malfunction and possibility to explode.

Solution:

Install the AC motor drive in a standard cabinet to keep it away from fluids. Clean the drive regularly to prevent corrosion.







15-5 Industrial Dust Problems


Serious industrial dust pollution frequently occurs in environments such as stone processing plants, flour mills, cement plants, and so on. Please be aware of the possible damages that industrial dust may cause to your drives.

- 1. Dust accumulating on electronic components may cause overheating problem and shorten the service life of the drive.
- 2. Conductive dust may damage the circuit board and may even cause the drive to explode.

Solution:

Install the AC motor drive in a standard cabinet and cover the drive with a dust cover. Clean the cabinet and ventilation holes regularly for good ventilation.






15-6 Installation and Wiring Problems

When wiring the drive, the most common problem is incorrect wire installation or poor wiring. Please be aware of the possible damages that poor wiring may cause to your drives.

- 1. If screws are not fully tightened, then sparking may occur as impedance increases.
- 2. If you have opened the drive and modified the internal circuit board, the internal components may have been damaged.

Solution:

Ensure that all screws are tightened when installing the AC motor drive. If the AC motor drive functions abnormally, send it back to Delta for repair. DO NOT try to modify or repair the internal components or wiring.








15-7 Multi-function Input / Output Terminal Application Problems


Multi-function input / output terminal errors are generally caused by over-usage of the terminals and not following the specifications. Please be aware of the possible damages that multi-function input / output terminal errors may cause to your drives.


1. Input / output circuit may burn out when the terminal usage exceeds the specified limit.

Solution:

Refer to the user manual for multi-function input / output terminals usage and follow the specified voltage and current. DO NOT exceed the specification limits.







[This page intentionally left blank]

Chapter 16 Safe Torque Off Function

- 16-1 Failure Rate of the Drive's Safety Function
- 16-2 Description of STO's Functions
- 16-3 Wiring Diagram
- 16-4 Related Parameters
- 16-5 Timing Diagram Description
- 16-6 Fault Codes Related to STO

16-1 Failure Rate of the Drive's Safety Function

Item	Definition	Standard	Performance
SFF	Safe Failure Fraction	IEC61508	Channel 1: 80.08%
SFF	Sale Fallule Flaction		Channel 2: 68.91%
HFT (Type A	Hardware Fault Tolerance	IEC61508	1
subsystem)	Hardware Fault Tolerance	15001300	
CII	Sofaty Integrity Level	IEC61508	SIL 2
SIL	Safety Integrity Level	IEC62061	SILCL 2
PFH	Average frequency of dangerous failure [h-1]	IEC61508	9.56×10 ⁻¹⁰
PFDav	Probability of Dangerous Failure on Demand	IEC61508	4.18×10 ⁻⁶
Category	Category	ISO13849-1	Category 3
PL	Performance level	ISO13849-1	d
MTTFd	Mean time to dangerous failure		High
DC	Diagnostic coverage		Low

Table 16-1

16-2 Description of STO's Functions

The STO (Safe Torque Off) function is to cut off the motor's power supply to prevent the motor from producing torque force. The STO function is run by two independent hardware circuits to control the drive signals emitted by the motor's current, and then to cut off motor drive's power module output in order to safely stop the motor drive.

The following table describes the terminal functions.

Signal	Channel	Status of Photo Coupler				
STO	STO1-SCM1	ON (High)	ON (High)	OFF (Low)	OFF (Low)	
Signal	STO2-SCM2	ON (High)	OFF (Low)	ON (High)	OFF (Low)	
Drive Output Status		Ready	STL2 mode (Torque output off)	STL1 mode (Torque output off)	STO mode (Torque output Off)	

Table 16-2

- STO is Safe Torque Off
 STL1−STL3 means an STO internal hardware error.
 STL3 means STO1−SCM1 and STO2−SCM2 has an internal circuit error.
 STO1−SCM1 ON (High): means STO1−SCM1 has connection to a +24 V_{DC} power supply.
 STO2−SCM2 ON (High): means STO2−SCM2 has connection to a +24 V_{DC} power supply.
 STO1−SCM1 OFF (Low): means STO1−SCM1 has no connection to a +24 V_{DC} power supply.
- STO2–SCM2 OFF (Low): means STO2–SCM2 has no connection to a +24 V_{DC} power supply.

16-3 Wiring Diagram

16-3-1 Internal Safety Circuit

Drive's internal safety circuit shows as Figure 16-1 below.




Figure 16-1

16-3-2 Internal Safety Circuit Terminals

The part D in Figure 16-2 below shows the default for terminals +24V-STO1-STO2 and terminals SCM1-SCM2-DCM in the drive's internal safety circuit, which are short-circuited when they are delivered from the factory.




Figure 16-3

16-3-3 Drive's Control Circuit Wiring Diagram

- 1. Remove the E24V-STO1-STO2 short circuit.
- 2. Figure 16-4 below shows the wiring. The contract for safety interlock circuit must be closed during the normal situation so that the motor drive can run.
- 3. In STO mode, if you switch on the safety interlock circuit, the motor drive stops outputting and the keypad displays STO.
- 4. If the restart permission signal is OFF before the elevator controller issues the command to start the elevator, it means that the STO function is currently malfunctioned or M1 magnetic contactor error has occurred, and then the elevator is unable to start (R1 cannot be ON).




Figure 16-4

NOTE: R" in R1/R2 stands for Relay; "M" in M1 stands for MC (Magnetic Contactor)

16-4 Related Parameters

M 06-49 STO Latch Selection

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0000h

Settings 0000h: STO fault latched, resending RUN command is required

0001h: STO warning latched, resending RUN command is required

0002h: STO fault latched

0003h: STO warning unlatched

Multi-function Output 1: RA, RB, RC (Relay 1)

Default: 0

✓ 02-12 Multi-function Output 2: MRA, MRB, MRC (Relay 2)

Default: 0

Multi-function Output 3: R1A, R12C (Relay 3)

Multi-function Output 4: R2A, R12C (Relay 4)

✓ 02-15 Multi-function Output 5: MO

✓ 02-16 Multi-function Output 6: MO2

Multi-function Output 7: MO3

✓ 02-18 Multi-function Output 8: MO4

Multi-function Output 9: MO5

Multi-function Output 10: MO6

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings 0: No function

1: Operation indication

11: Malfunction indication

42: STO Output Error

Multi-function Output Terminal Direction

Default: 0

This parameter uses bit setting. If the bit is 1, the multi-function output terminal acts in the opposite direction.

Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
-	-	MO6	MO5	MO4	МО3	MO2	MO1	R2A	R1A	MRA	RA

STO output default: Pr.02-15 (MO1 = 42 Logic Output A). You can also set Pr.02-23 (Multi-output direction) to choose Logic Output B.

	Output Safety Status				
Drive Status	Logic Output A (Pr.02-15=42)	Logic Output B (Pr.02-15=42) (Pr.02-23=16)			
Normal	Broken circuit (Open)	Short circuit (Closed)			
STO	Short circuit (Closed)	Broken circuit (Open)			
STL1-STL3	Short circuit (Closed)	Broken circuit (Open)			

Table 16-3

16-5 Timing Diagram Description

16-5-1 Normal Operation Status

As shown in Figure 16-5, when the STO1–SCM1 and STO2–SCM2 are ON (safety function is not required), the motor drive executes "Operating" or "Output Stop" according to the RUN/STOP command.




Figure 16-5

16-5-2 Pr.06-49 = 0000h, STO fault latched, resending RUN command is required If STO is ON in any condition and a fault occurs, it does not reset until STO is back to normal and use a RESET command or power-on again after resending the RUN command.




Figure 16-6

16-5-3 Pr.06-49 = 0001h, STO warning latched, resending RUN command is required If STO is ON in any condition and a warning occurs, it does not reset until STO is back to normal and resend the RUN command.




Figure 16-7

16-5-4 Pr.06-49 = 0002h, STO fault latched

If STO is ON in any condition and a fault occurs, it does not reset until STO is back to normal and use a RESET command or power-on again.





Figure 16-8

16-5-5 Pr.06-49 = 0003h, STO warning unlatched

If STO is ON in any condition and a warning occurs, it automatically resets when STO is back to normal.



16-5-6 STL1




Figure 16-10

16-5-7 STL2




Figure 16-11

16-6 Fault Codes Related to STO

06-16	Present Fault Record
06-17	Second Most Recent Fault Record
06-18	Third Most Recent Fault Record
06-19	Fourth Recent Fault Record
06-20	Fifth Most Recent Fault Record
06-21	Sixth Most Recent Fault Record

Control Mode VF VFPG SVC FOCPG FOCPM Default: 0

Settings 72: Safe torque loss (STL1)

76: Safe torque output stops (STO)

77: Safe torque loss 2 (STL2)

78: Safe torque loss 3 (STL3)

Fault Code	Reading	Description
72 (STL1)	Safe torque loss (STL1)	STO1–SCM1 internal circuit error.
76 (STO)	Safa tarreus autaut atara (STO)	Safe Torque Off function is enabled while Pr.06-
76 (STO)	Safe torque output stops (STO)	49 is set to 0000h or 0002h.
77 (STL2)	Safe torque loss 2 (STL2)	STO2–SCM2 internal circuit error.
78 (STL3)	Safe torque loss 3 (STL3)	STO1–SCM1 and STO2–SCM2 internal circuit
		error.

[This page intentionally left blank]

Appendix A. AC Motor Drives EMC Standard Installation Guide

EMC Compliance Practice

- A-1 Introduction
- A-2 How to Prevent EMC
- A-3 Solution to EMC: Grounding
- A-4 Solution to EMC: Shielding
- A-5 Solution to EMC: Filter

Preface

When an AC motor drive is installed in a noisy environment, radiated and/or conducted noise via signal and power cables can interfere with the correct functioning, cause errors or even damage to the drive. To prevent this, some AC motor drives have an enhanced noise resistance but the results are limited and it is not economical. Therefore, an effective method would be finding the cause of the noise and use the right solution to achieve "no emission, no transmission and no reception of noise". All three solutions should be applied.

Finding the Noise

- Ensure whether the error is caused by noise.
- Find the source of the noise and its transmission path.
- Confirm the signal and the source of noise

Solutions

- Ensure whether the error is caused by noise.
- Find the source of the noise and its transmission path.
- Confirm the signal and the source of noise

A-1 Introduction

A-1-1 What is EMC

Electromagnetic Compatibility (EMC) is the ability of an electrical device to function properly in electromagnetic environments. It does not emit electromagnetic noise to surrounding equipment and is immune to interference from surrounding equipment. The goal is to achieve high immunity and low emission; these two properties define the quality of EMC. In general, electrical devices react to high and low frequency phenomena. High frequency phenomena are electrostatic discharge (ESD); pulse interference; radiated electromagnetic field; and conducted high frequency electrical surge. Low frequency phenomena refer to mains power harmonics and imbalance.

The standard emission and immunity levels for compliance depend on the installation location of the drive. A Power Drive System (PDS) is installed in an industrial or domestic environment. A PDS in a domestic environment must have lower emission levels and is allowed to have lower immunity levels. A PDS in an industrial environment is allowed to have higher emission levels but must have more severe immunity levels.

A-1-2 EMC for AC Motor Drive

When an AC motor drive is put into operation, harmonic signal will occur at the AC drive's power input and output side. It creates a certain level of electromagnetic interference to the surrounding electrical devices and the mains power network. An AC motor dive is usually applied in industrial environments with a strong electromagnetic interference. Under such conditions, an AC drive could disturb or be disturbed.

Installing the AC motor drive accurately will decrease EMC influences and ensure long-term stability of the electricity system. It is strongly suggested to follow Delta's user manual for wiring and grounding. If any difficulties or problems arise, follow the instructions and measures as indicated in this EMC Standard Installation Guide.

A-2 How to Prevent EMC

A-2-1 Types of EMC: Common-mode and Differential Mode Noise

The electromagnetic noise of an AC motor drive can be distinguished into common-mode and differential-mode noise. Differential-mode noise is caused by the stray capacitance between the conducting wires and common-mode noise is caused by the common-mode coupling current path created by the stray capacitance between the conducting wires and ground.

Basically, differential-mode noise has a greater impact to the AC motor drive and common-mode noise has a greater impact to high-sensitivity electronic devices. An excessive amount of differential-mode noise may trigger the circuit protection system of the AC motor drive. Common-mode noise affects peripheral electronic devices via the common ground connection.

EMC problems can be more serious when the following conditions apply:

- When a large horsepower AC motor drive is connected to a large horsepower motor.
- The AC motor drive's operation voltage increases.
- Fast switching of the IGBTs.
- When a long cable is used to connect the motor to the AC motor drive.

A-2-2 How does EMC Transmit (Noise Transmission)

Noise disturbs peripheral high-sensitivity electrical devices/systems via conduction and radiation, their transmission paths are shown hereafter:

 Noise current in the unshielded power cable is conducted to ground via stray capacitances into a common-mode voltage. Whether or not other modules are capable to resist this common-mode noise depends on their Common-Mode Rejection Ratio (CMRR), as shown in Figure A-1.




Figure A-1

2. Common-mode noise in the power cable is transmitted through the stray capacitance and coupled into the adjacent signal cable, as shown in Figure A-2. Several methods can be applied to reduce the effect of this common-mode noise; for example, shield the power cable and/or the signal cables, separate the power and signal cables, take the input and output side of the signal cable and twist them together to balance out the stray capacitance, let power cables and signal cables cross at 90°, etc.




Figure A-2

3. Common-mode noise is coupled via the power cable to other power systems then the cable of such a power system is coupled to the transmission system, as shown in Figure A-3.




Figure A-3

4. The common-mode noise of an unshielded power cable is transmitted to the ground via the stray capacitance. Since both shielded wire and unshielded wire are connected to a common ground, other systems can be interfered with by the common-mode noise that is transmitted from the ground back to the system via the shield. See Figure A-4.




Figure A-4

5. When excessive pulse modulated currents pass through an un-grounded AC drive cable, it acts as an antenna and creates radiated interference.

A-3 Solution to EMC: Grounding

The leakage current of an electronic equipment is conducted to ground via the grounding wire and the ground electrode. According to Ohm's law, potential differences may arise when the electrode's ground and the ground's ground resistance are different.

According to Ohm's law, the earth resistance for electrode and the ground are different; in this case, potential differences may arise.

A-3-1 Protective Grounding & Functional Grounding

Please carefully read the following instructions if two types of grounding are applied at the same time.

Protective grounding is applied outside buildings and must have low resistance. On the other hand, functional grounding can be applied inside buildings and must have low impedance.

The goal of EMC is to avoid any interference effects. Grounding for EMC can be distinguished by frequency. For frequencies lower than 10 kHz, a **single point ground** *system* should be used and for frequencies higher than 10 kHz, a **multiple point ground** *system* should be used.

- **Single Point Grounding**: all signal grounds of all IT equipment are connected in series to form a single reference point. This point can be grounded directly to earth; to the designated grounding point or to the safety point that is already grounded.
- Multiple Point Grounding: all signals of all IT equipment are grounded independently.
- **Hybrid Grounding**: this type of grounding behaves differently for low and high frequencies. When two pieces of IT equipment (A and B) are connected via a shielded cable, one end is connected directly to ground while the other end is connected to ground via a capacitor. This type of grounding system fulfils the criteria for high and low frequency grounding.
- **Floating grounding**: the signals of all IT equipment are isolated from each other and are not grounded.

DC current flows evenly throughout the conductor section. But AC current flows towards the conductor's surface as frequency increases; this is called the "skin effect". It causes the effective cross-section area to be reduced with increasing frequency. Therefore, it is suggested to increase the effective ground cross-section area for high frequencies by replacing pigtail grounding by braided conductors or strip conductors. Refer to the Figure A-5 below.




Figure A-5

This is why a thick short ground wire must be implemented for connecting to the common grounding path or the ground busbar. Especially when a controller (e.g. PLC) is connected to an AC motor drive, it must be grounded by a short and thick conducting wire. It is suggested to use a flat braided conductor (ex: metal mesh) with a lower impedance at high frequencies.

If the grounding wire is too long, its inductance may interfere structure of the building or the control cabinet and form mutual inductance and stray capacitance. As shown in the Figure A-6, a long grounding wire could become a vertical antenna and turn into a source of noise.




Figure A-6

A-3-2 Ground Loops

A **ground loop** occurs when the pieces of equipment are connected to more than one grounding path. In this case, the ground current may return to the grounding electrode via more than one path. There are three methods to prevent ground loops:

- 1. Use a common power circuit
- 2. Single point grounding
- 3. Isolate signals, e.g. by photocouplers




Figure A-7




Figure A-8

In order to avoid "Common Mode Noise", use parallel wires or twisted pair wiring. Follow this rule and also avoid long wires, it is suggested to place the two wires as close to each other as possible.

Appendix A. EMC Standard Installation Guide | VFD-ED

A-3-3 Earthing Systems

The international standard IEC60364 distinguishes three different earthing system categories, using the two-letter codes **TN**, **TT**, **IT**.

- The first letter indicates the type of earthing for the power supply equipment (generator or transformer).
 - **T**: One or more points of the power supply equipment are connected directly to the same earthing point.
 - I: Either no point is connected to earth (isolated) or it is connected to earth via high impedance.
- The **second letter** indicates the connection between earth and the power supply equipment.
 - **T**: Connected directly to earth (This earthing point is separate from other earthing points in the power supply system.)
- N: Connected to earth via the conductor that is provided by the power supply system
- The **third and fourth letter** indicate the location of the earth conductor.
 - S: Neutral and earth conductors are separate
 - C: Neutral and earth are combined into a single conductor

TN system

TN: The neutral point of the low voltage transformer or generator is earthed, usually the star point in a three-phase system. The body of the electrical device is connected to earth via this earth connection at the transformer.

Protective earth (PE): The conductor that connects the exposed metallic parts of the consumer. **Neutral (N)**: The conductor that connects to the start point in a three-phase system or that carries the return current in a single-phase system.




Figure A-9

TN-S system

TN-S: PE and N are two separate conductors that are combined together only near the power source (transformer or generator). It is the same as a three-phase five-wire system.




Figure A-10

TN-C system

TN-C: PE and N are two separate conductors in an electrical installation similar to a three-phase five-wire system, but near the power side, PE and N are combined into a PEN conductor similar to a three-phase four-wire system.





Figure A-11

TN-C-S system

TN-C-S: A combined earth and neutral system (PEN conductor) is used in certain systems but eventually split up into two separate conductors PE and N. A typical application of combined PEN conductor is from the substation to the building but within the building PEN is separated into the PE and N conductors. Direct connection of PE and N conductors to many earthing points at different locations in the field will reduce the risk of broken neutrals. Therefore, this application is also known as **protective multiple earthing (PME)** in the UK or as **multiple earthed neutral (MEN)** in Australia



TT system

TT: The neutral point (N) of the low voltage transformer and the equipment frames (PE) are connected to a separate earthing point. The Neutral (N) of the transformer and electrical equipment are connected.




Figure A-13

IT system

IT: The neutral point of the transformer and electrical equipment are not earthed, only the equipment frames PE are earthed.

In the IT network, the power distribution system Neutral is either not connected to earth or is earthed via high impedance. In such a system, an insulated monitoring device is used for impedance monitoring.

A built-in filter should be disconnected by the RFI-jumper and an external filter should not be installed when the AC motor drive or the AC servo motor drive is connected to an IT system.




Figure A-14

Criteria for Earthing System and EMC

	TN-S	TN-C	TT	IT
	Good	Good	Good	Good
Safety of	Continuity of the PE conductor	Continuity of the PE conductor	RCD is mandatory	Continuity of the PE conductor
Personnel	must be ensured throughout the installation	must be ensured throughout the installation		must be ensured throughout the installation
	Poor	Poor	Good	Good
Safety of Property	High fault current (around 1kA)	High fault current (around 1kA)	Medium fault current (< a few dozen amperes)	Low current at the first fault (< a few dozen mA) but high current at the second fault
Availability of Energy	Good	Good	Good	Excellent
	Excellent	Poor (prohibited)	Good	Poor (should be avoided)
EMC Behavior	 Almost equipotential Problems: Need to handle the high leaking currents problem of the device High fault current (transient disturbances) 	 Neutral and PE are the same Circulation of disturbance currents in exposed conductive parts (high magnetic-field radiation) High fault currents (transient disturbances) 	 Over-voltage risk Equipotential Problems: Need to handle the high leaking currents problem of the device RCD (Residual-current device) 	 Over-voltage risk Common— mode filters and surge arrestors must handle the phase-to-phase voltage. RCDs subject to nuisance tripping when common-mode capacitors are present Equivalent to TN system for second fault

A-4 Solution to EMC: Shielding

A-4-1 What is Shielding


Electrostatic shielding is used to isolate equipment so that it will not create electromagnetic field interference or be influenced by an external electromagnetic field. A conductive material is used for electrostatic shielding to achieve this isolation. A Faraday cage can be made from a mesh of metal or a conductive material.

One characteristic of metal is that it is highly conductive and not electrostatic, which offers shielding and prevents interference by external electrical fields. Metal with its high conductivity protects the internal devices from high voltages—no voltage will enter the cage even when the cage is experiencing a high current. In addition, electromagnetic fields can also pass through the Faraday cage without causing any disturbance.

Electromagnetic shielding is applied to some electrical devices and measurement equipment for the purpose of blocking interference. Examples of shielding include:

- Earth high-voltage indoor equipment using a metal frame or a high-density metal mesh
- Shielding a power transformer is achieved by wrapping a metal sheet between the primary and secondary windings or by adding an enamel wire to the winding wire which is then earthed.
- A shielding coating, which is made of metal mesh or conductive fibers to provide effective protection for the workers who work in a high-voltage environment.

In the picture below, the radio appears to be not fully covered by metal but if the conductivity of the metal is high, radio waves are completely blocked and the radio will not receive any signal.



Mobile phone connections are also established through the transmission of radio waves. This is why the mobile phone reception is often cut off when we walk into an elevator. The metal walls of the elevator create the same shielding effect just as if we had entered a metal cage. Another example is a microwave oven. The microwave door may seem transparent in visible light, but the density of the metal mesh in the microwave door blocks the electromagnetic waves. A higher density of the metal mesh offers better shielding.




Figure A-17

A-4-2 How to Reduce EMC by Shielding

Iron and other metals are high conductivity materials that provide effective shielding at extremely low frequencies. But conductivity will decrease as:

- 1. High frequency signals are applied to the conductor
- 2. Equipment is located in a strong magnetic field
- 3. The shielding frame is forced into a specific form by machines

It is difficult to select a suitable high-conductivity material for shielding without the help from a shielding material supplier or a related EMC institution.

Metallic Shielding Effectiveness

Shielding Effectiveness (SE) is used to assess the applicability of the shielding shell. The formula is:

SEdB=A+R+B (Measures where A= Absorption loss (dB) in dB)

R= Reflection loss (dB)

B= Correction factor (dB) (for multiple reflections in thin shields)

The absorption loss refers to the amount of energy loss as the electromagnetic wave travels through the shield. The formula is:

AdB=1.314($f\sigma\mu$) 1/2t where f= frequency (MHz)

μ= permeability relative to copper

 σ = conductivity relative to copper

t= thickness of the shield in centimeters

The reflection loss depends on the source of the electromagnetic wave and the distance from that source. For a rod or straight wire antenna, the wave impedance increases as it moves closer to the source and decreases as it moves away from the source until it reaches the plane wave impedance (377) and shows no change. If the wave source is a small wire loop, the magnetic field is dominant and the wave impedance decreases as it moves closer to the source and increases as it moves away from the source; but it levels out at 377 when the distance exceeds one-sixth of the wavelength.

Electrical Cabinet Design

In a high frequency electric field, shielding can be achieved by painting a thin layer of conductive metal on the enclosure or on the internal lining material. However, the coating must be thorough and all parts should be properly covered without any seams or gaps (just like a Faraday cage). That is only the ideal. Making a seamless shielding shell is practically impossible since the cage is composed of metal parts. In some conditions, it is necessary to drill holes in the shielding enclosure for installation of accessories (like optional cards and other devices).

- 1. If the metallic components are properly welded using sophisticated welding technology to form an electrical cabinet, deformation during usage is unlikely to occur. But if the electrical cabinet is assembled with screws, the protective insulating layer under the screw must be properly removed before assembly to achieve the greatest conductivity and best shielding.
- 2. Drilling holes for the installation of wires in the electrical cabinet lowers the shielding effectiveness and increases the chance of electric waves leaking through the openings and emitting interference. We recommend that the drilled holes are as narrow as possible. When the wiring holes are not used, properly cover the holes with metal plates or metal covers. The paint or the coating of the metal plate and metal cover should be thoroughly removed to ensure a metal-to-metal contact or a conductive gasket should be installed.
- Install industrial conductive gaskets to completely seal the electrical cabinet and the cabinet door
 without gaps. If conductive gaskets are too costly, please screw the cabinet door to the electrical
 cabinet with a short distance between the screws.
- 4. Reserve a grounding terminal on the electrical cabinet door. This grounding terminal shall not be painted. If the paint already exists, please remove the paint before grounding.


Electrical Wires and Cables

Shielded Twisted Pair (STP) is a type of cable where two insulated copper wires are twisted together with a metal mesh surrounding the twisted pair that forms the electromagnetic shielding and can also be used for grounding.

The individual electrical wires and complete cable are surrounded by (synthetic) rubber that provides insulation and also protects against damage.

There are two types of electrical cables: high voltage and low voltage. The high voltage cable differs from the low voltage cable in that it has an additional insulation layer called the dielectric insulator within the plastic sleeve. The dielectric insulator is the most important component in insulation. The low voltage cable is usually only filled with a soft polymer material for keeping the internal copper wire in place. The shield has two functions:

- 1. To shield the electrical wire and cable.
 - (1) Electric currents increase as power flows through the power cable and generate an electrical field. Such interference can be suppressed inside the cable by shielding the power cables or the electrical wires.
 - (2) To form a protective earthing. When the cable core is damaged, the leakage current will flow via the shield to ground.
- 2. To protect the cable. A power cable used for the computer control purpose generates only relatively low amount of current inside the cable. Such power cable will not become the source of interferences but has great possibility to be interfered by the surrounding electrical devices.



A-5 Solution to EMC: Filter

A-5-1 Filter

Electromagnetic interference is transmitted in two ways, by radiation and by conduction. The most effective and economical method of reducing radiated interference is to use shielding and of reducing conducted interference is to use an electromagnetic filter.

Noise interference can be divided into two categories: high frequency (150 kHz–300 MHz) and low frequency (100–3000 Hz). High-frequency noise fades more over distance and has a shorter wavelength, while low-frequency noise fades less over distance and has a longer wave-length. Both types of interference are transmitted through power cables and power leads, affecting the power supply side.

High-frequency interference at the power side can be eliminated or attenuated by mounting a filter. The filter consists of coils and capacitors. Some drives do not have a built-in filter, in which case the installation of an external option filter is required. Figure A-20 below shows a standard filter diagram.




Figure A-20

A filter is composed of a Differential Mode section (to eliminate noise below 150 kHz) and a Common Mode section (to eliminate noise above 150 kHz). For high-frequency noise, the inductor acts as a high impedance to form an open circuit and the capacitor acts as a low impedance to form a short circuit. Proper design and dimensioning of inductors and capacitors give a resonant circuit to absorb harmonic currents. Capacitor Cy is earthed to lead the harmonic currents to the ground.

External Filter

The filter and the AC drive should be installed in the control cabinet or on the mounting plate that is earthed to ground. The motor cable must be shielded and as short as possible. Use the filters recommended by Delta to ensure compliance with EMC standards.





Figure A-21

AC Motor Drives with Built-in Filter

- 1. Since interferences are suppressed by installing an earthed capacitor in the filter, the amount of current to ground (leakage current) could result in electric shocks to personnel or the power system. Please be aware of this problem.
- 2. Since the leakage current to ground can be high, it is crucial to implement protective earthing to prevent electrical shocks.

Filter Installation (With and Without)



Zero Phase Reactor (Choke)

Interferences can also be suppressed by installing a zero phase reactor at the power supply side and/or the AC Motor Drive's output, depending on where the interference is. Since currents are large at the power input and the AC Motor Drive's output, please carefully select the magnetic core with

suitable current handling capability. An ideal magnetic material for large currents is compound magnetic powder. It has a higher current handling capability and higher impedance compared to pure metallic magnetic cores. It is therefore suitable to implement in a high frequency environment. The impedance can also be enhanced by increasing the turn ratio.

Zero Phase Reactor Installation

There are two installation methods, depending on the size of the zero phase reactor and the motor cable length.

1. Wind the motor cable through the middle of a zero-phase reactor four times. Place the reactor and the AC Motor Drive as close to each other as possible.




Figure A-24

2. Place all wires through the middle of four zero-phase reactors without winding.




Figure A-25

Analog Input Signals

If the analog input signals are affected by noise from the AC motor drive, connect a capacitor and a ferrite core as indicated in Figure A-26 below. Wind the wires around the core in same direction for 3 times or more.




Figure A-26

A-5-2 Harmonic Interference

The AC motor drive's input current is non-linear, the input rectifier generates harmonics. Harmonics must be limited to within a certain range to avoid impact the mains power and to avoid current distortion to ensure surrounding devices are not influenced. An AC Motor Drive with built-in DC reactor suppresses harmonic currents (Total Harmonic Current Distortion THID) effectively and therefore reduces the harmonic voltage peaks (Total Harmonic Voltage Distortion).

Harmonic Current at the Power Supply Side




Figure A-27

Suppression of Harmonic Currents

Reactor

When a large portion of lower order harmonic currents (5th, 7th, 11th etc.) occur at the power input, surrounding devices will be disturbed and the power factor will be low as a result of reactive power. Installing a reactor at the AC Motor Drive's input effectively suppresses lower order harmonic currents.




Figure A-28

AC Reactor

Installed in series with the power supply and is effective in reducing low order current harmonics. Features of an AC reactor include:

- 1. Reduces the harmonic currents to the AC Motor Drive and increases the impedance of the power supply.
- 2. Absorbs interferences generated by surrounding devices (such as surge voltages, currents, and mains surge voltages) and reduce their effect on the AC Motor Drive.
- 3. Increases the power factor.

DC Reactor

A DC-Reactor is installed between the rectifier and the DC-bus capacitor to suppress harmonic currents and to achieve a higher power factor.

Current Wave Diagrams

Without Reactor




Figure A-29

With Reactor




Figure A-30

[This page intentionally left blank]

Appendix B. Modbus Protocol

- B-1 Code Description
- B-2 Data Format
- **B-3** Communication Protocol
- B-4 Address List
- B-5 Exception Response

Appendix B. Modbus Protocol | VFD-ED

- This appendix helps users to control by computers and monitor drive parameters and status through Modbus by using RS-485 serial communication interface
- When using the communication interface, the diagram on the right shows the communication port pin definitions. It is recommended that you connect the AC motor drive to your PC by using Delta IFD6530 or IFD6500 as a communication converter. For details on communication port as the right diagram shows, see the lower right corner in Figure 3-5 in Chapter 3 Wiring.



- The default communication formats for communication port:
 - 1. Modbus ASCII mode
 - 2. 9600 bps serial communication baud rates
 - 3. 7-bit data character
 - 4. No parity bit
 - 5. 2 stop bit
- Modbus ASCII (American Standard Code for Information Interchange): Each byte of data is the combination of two ASCII characters. For example, one byte of data: 64 Hex, shown as '64' in ASCII, consists of '6' (36Hex) and '4' (34Hex)


B-1 Code Description


The communication protocol is in hexadecimal, ASCII: "0"..."9", "A"..."F", every hexadecimal value represents an ASCII code. The following table shows some examples.

		U			•			
Character	'0'	'1'	'2'	'3'	'4'	' 5'	'6'	'7'
ASCII code	30H	31H	32H	33H	34H	35H	36H	37H
Character	'8'	'9'	'A'	'B'	'C'	'D'	'E'	'F'
ASCII code	38H	39H	41H	42H	43H	44H	45H	46H


B-2 Data Format

1. 10-bit character frame (For ASCII)





2. 11-bit character frame (For RTU)



B-3 Communication Protocol

1. Communication data frame

ASCII mode:

STX	Start character = ':' (3AH)
Address High	Communication address:
Address Low	one 8-bit address consists of 2 ASCII codes
Function High	Command code:
Function Low	one 8-bit command consists of 2 ASCII codes
DATA (n-1)	Contents of data:
	n x 8-bit data consists of 2n ASCII codes
DATA 0	n ≤ 16, maximum of 32 ASCII codes (20 sets of data)
LRC Check High	LRC checksum:
LRC Check Low	one 8-bit checksum consists of 2 ASCII codes
END High	End characters:
END Low	END1= CR (0DH), END0= LF(0AH)

RTU mode:

START	Defined by a silent interval of larger than / equal to 10 ms	
Address	Communication address: 8-bit binary address	
Function	Command code: 8-bit binary command	
DATA (n-1)	Contents of data:	
	N × 8-bit data, n ≤ 16	
DATA 0		
CRC Check Low	CRC checksum:	
CRC Check High	one 16-bit CRC checksum consists of 2 8-bit binary	
CINO CHECK HIGH	characters	
END	Defined by a silent interval of larger than / equal to 10 ms	

2. Communication address (Address)

00H: broadcast to all AC motor drives

01H: AC motor drive of address 01 0FH: AC motor drive of address 15 10H: AC motor drive of address 16

:

FEH: AC motor drive of address 254

Function (function code) and data (data characters)

03H: read data from a register

Example: Reading two continuous data from register address 2102H, AMD address is 01H.

ASCII mode:

Command Message

8			
STX	4.3		
Address	'0'		
Address	'1'		
Function	'0'		
Function	'3'		
	'2'		
Starting register	'1'		
Starting register	'0'		
	'2'		
Number of register	'0'		
	'0'		
(count by word)	'0'		
	'2'		
L DC Charle	'D'		
LRC Check	'7'		
END	CR		
END	LF		
	•		

Response Message

STX	· ·
Address	'0'
Address	'1'
Function	'0'
Fullction	'3'
Number of register	'0'
(count by byte)	'4'
	'1'
Content of starting	'7'
register 2102H	'7'
	'0'
	'0'
Content of register 2103H	'0'
Content of register 2 10311	'0'
	'0'
LRC Check	'7'
LING OTIECK	'1'
END	CR
LIND	LF

RTU mode:

Command Message

Response Message

Address	01H
Function	03H
Starting data register	21H
Starting data register	02H
Number of register	00H
(count by word)	02H
CRC Check Low	6FH
CRC Check High	F7H

Address	01H
Function	03H
Number of register (count by byte)	04H
Content of register	17H
address 2102H	70H
Content of register	00H
address 2103H	00H
CRC Check Low	FEH
CRC Check High	5CH

3. 06H: single write, write single data to a register.

Example: Writing data 6000 (1770H) to register 0100H. AMD address is 01H.

ASCII mode:

Command Message

Response Message

Command Message		response message	
STX		STX	· · ·
Address	'0' '1'	Address	'0' '1'
Function	'0'	Function	'0'
	,0,		'6' '0'
Target register	'1' '0'	Target register	'1' '0'
	'0'		'0' '1'
Register content	'7'	Register content	'7'
	'7' '0'		'7' '0'
LRC Check	'7'	LRC Check	'7' '1'
END	CR	END	CR
END	LF	EIND	LF

RTU mode:

Command Message

Response Message

	_		_
Address	01H	Address	01H
Function	06H	Function	06H
Torget register	01H	Torget register	01H
Target register	00H	Target register	H00
Degister centent	17H	Degister content	17H
Register content	70H	Register content	70H
CRC Check Low	86H	CRC Check Low	86H
CRC Check High	22H	CRC Check High	22H

Appendix B. Modbus Protocol | VFD-ED

4. 10H: write multiple registers (can write at most 20 sets of data simultaneously).

Example: Set the multi-step speed of an AC motor drive (address is 01H),

Pr.04-00 = 50.00 (1388H), Pr.04-01 = 40.00 (0FA0H.)

ASCII mode:

Command Message

STX	<i>i.</i> ;
ADR 1	' 0'
ADR 0	'1'
CMD 1	'1'
CMD 0	' 0'
	' 0'
T	'4'
Target register	'0'
	' 0'
	' 0'
Number of register	' 0'
(count by word)	'0'
, ,	'2'
Number of register	' 0'
(count by byte)	'4'
	'1'
The first data content	'3'
The first data content	'8'
	'8'
	' 0'
The second data content	'F'
The second data content	'A'
	' 0'
LRC Check	' 9'
LRC Check	'A'
END	CR
EIND	LF

Response Message

STX	í.;
ADR 1	'0'
ADR 0	'1'
CMD 1	'1'
CMD 0	'0'
	'0'
Torget register	'4'
Target register	'0'
	'0'
	'0'
Number of register	'0'
(count by word)	'0'
	'2'
LRC Check	'E'
LRC Check	'8'
END	CR
EIND	LF

RTU mode:

Command Message

01H
10H
04H
00H
00H
02H
04
13H
88H
0FH
A0H
' 9'
'A'

Response Message

ADR	01H
CMD	10H
Torget register	04H
Target register	00H
Number of register	00H
(Count by word)	02H
CRC Check Low	41H
CRC Check High	04H

5. Checksum

(1) ASCII mode (LRC Check):

LRC (Longitudinal Redundancy Check) is calculated by summing up the values of the bytes from ADR1 to last data character then calculating the hexadecimal representation of the 2's-complement negation of the sum.

Example:

}

01H + 03H + 21H + 02H + 00H + 02H = 29H, the 2's-complement negation of 29H is D7H.

(2) RTU mode (CRC Check):

CRC (Cyclical Redundancy Check) is calculated by the following steps:

Step 1: Load a 16-bit register (called CRC register) with FFFh.

- Step 2: Exclusive OR the first 8-bit byte of the command message with the low order byte of the 16-bit CRC register, putting the result in the CRC register.
- Step 3: Examine the LSB of CRC register.
- Step 4: If the LSB of CRC register is 0, shift the CRC register one bit to the right, fill MSB with zero, then repeat step 3. If the LSB of CRC register is 1, shift the CRC register one bit to the right, fill MSB with zero, Exclusive OR the CRC register with the polynomial value A001H, then repeat step 3.
- Step 5: Repeat step 3 and 4 until you perform eight shifts. This processes a complete 8-bit byte.
- Step 6: Repeat step 2 through 5 for the next 8-bit byte of the command message. Continue doing this until all bytes are processed. The final contents of the CRC register are the CRC value. When transmitting the CRC value in the message, the upper and lower bytes of the CRC value must be swapped, that is, the lower order byte is transmitted first.
- 6. The following is an example of CRC generation using C language.

Unsigned char* data ← a pointer to the message buffer

```
Unsigned char length ← the quantity of bytes in the message buffer
unsigned int crc chk(unsigned char* data, unsigned char length)
{
      int j;
      unsigned int reg crc=0xffff;
      while(length--){
           reg crc ^= *data++;
           for(j=0;j<8;j++)
                if(reg_crc & 0x01){ /* LSB(b0)=1 */
                     reg_crc=(reg_crc>>1) ^ 0xa001;
                }else{
                     reg crc=reg crc >>1;
               }
          }
      }
                                         // return register CRC
      return reg_crc;
```

B-4 Address List

1. ASCII

- Reads one or more parameter values: 3Ah (start bit': ') + 30h 31h (station address 01) + 30h
 33h (function code 03h) + 30h 30h xxh xxh-32h 36h xxh xxh (Modbus address 00xxh-26xxh)
 + xxh xxh xxh xxh (reading length 1) + LRC (checksum) + CR/LF
- Writes one parameter value: 3Ah (start bit': ') + 30h 31h (station address 01) + 30h 36h (function code 06h) + 30h 30h xxh xxh–32h 36h xxh xxh (Modbus address 00xxh–26xxh) + xxh xxh xxh xxh (writing value) + LRC (checksum) + CR/LF
- Writes 20 parameter values: 3Ah (start bit': ') + 30h 31h (station address 01) + 31h 30h (function code 10h) + 30h 30h xxh xxh-32h 36h xxh xxh (Modbus address 00xxh-26xxh) + 30h 30h 31h 34h (word data length) + 32h 38h (byte data length) + xxh xxh xxh xxh (the first writing value) + ... + xxh xxh xxh xxh xxh (the 20th writing value) + LRC (checksum) + CR/LF

2. RTU

- Reads one or more parameter values: 01h (station address 01) + 03h (function code 03h) + 00xxh-26xxh (Modbus address) + xxxxh (reading length) + CRC (checksum)
- Writes one parameter value: 01h (station address 01) + 06h (function code 06h) + 00xxh–
 26xxh (Modbus address) + xxxxh (writing value) + CRC (checksum)
- Writes 20 parameter values: 01h (station address 01) + 10h (function code 10h) + 00xxh–
 26xxh (Modbus address) + 0014h (data length, count by word) + 28h (data length, count by byte) + xxxxh (the first writing value) + ... + xxxxh (the 20th writing value) + CRC (checksum)

3. AC motor drive parameters (GGnnH): communication station address is Pr.09-00 setting value

Modbus Address	Attribute (Function Code)	Description
		GG means parameter group, nn means parameter number. For
GGnnH	R(03H) / W(06H, 10H)	example, the Modbus address of Pr.04-10 is 040AH when
		reading by Delta VFDsoft.

4. Control command (20xx): communication station address is Pr.09-00 setting value

Function Name	Modbus Address	Attribute (Function Code)	Size	Description			
			U16	bit1–0	00B: No function 01B: Stop 10B: Run	1.	Remains the status specified by a first command until a
					11B: JOG + Run		second command is
				bit3-2	Reserved		received.
		R (03H)/			00B: No function	2.	Valid only when
Operation	2000H	W (06H,		bit5–4	01B: FWD		operation command
command	200011	10H)			10B: REV		source is set to
	, , , , , , , , , , , , , , , , , , ,		U16		11P: Change direction		communication
			016		11B: Change direction		(Pr.00-15=2).
					00B: 1st accel. / decel.	1.	Valid only when 2000h
				bit7–6	01B: 2nd accel. / decel.		bit12 is set to 1.
				טונז–6	10B: 3rd accel. / decel.	2.	Obtain the current
					11B: 4th accel. / decel.		running speed by

Function Name	Modbus Address	Attribute (Function Code)	Size		Descriptio	n
					0000B: zero step speed	reading 2107h.
					0001B: 1st step speed	
					0010B: 2nd step speed	
					0011B: 3rd step speed	
					0100B: 4th step speed	
					0101B: 5th step speed	
					0110B: 6th step speed	
				bit11–8	0111B: 7th step speed	
				DICTI-0	1000B: 8th step speed	
					1001B: 9th step speed	
					1010B: 10th step speed	
				1011B: 11th step speed		
					1100B: 12th step speed	
					1101B: 13th step speed	
					1110B: 14th step speed	
					1111B: 15th step speed	
				bit12	1: Enable bit06–11 function	on
				bit15	Reserved	
Frequency command	2001H	R (03H) / W (06H, 10H)			command (XXX.XX Hz). general-purpose drives.	There are two decimal
Fault / control command	2002H	R (03H) / W (06H,		bit0	1: External Fault (E.F.) ON	To trigger an external fault to the drive to make it stop running. Drive's stop method can be set through drive parameters.
source		10H)		bit1	1: Reset	To clear the fault status
				bit15–2	Reserved	

5. Status monitor read only (21xx): communication station address is Pr.09-00 setting value

Otatus monitor read only (217x). Communication station address is 11.05-00 setting value						
Function Name	Modbus Address	Attribute (Function	Size	Description		
		Code)				
Fault status	2100H	R(03H)	U16	bit7–0: Fault code		
Fault Status	bit15–8: Warning code		/arning code			
					Status of RUN / STOP	
		İ				00B: Drive fully stops
Drive					(RUN indicator is OFF / STOP indicator is ON)	
Drive	2440	D(03H)	1116	bit1 0	01B: Drive is stopping	
operation	2119H	R(03H)	U16	bit1–0	(RUN indicator flashes / STOP indicator is ON)	
status					10B: Drive is in standby status	
					(RUN indicator is ON / STOP indicator flashes)	
					11B: Drive is running	

Function Name	Modbus Address	Attribute (Function Code)	Size		Description
					(RUN indicator is ON / STOP indicator is OFF)
				bit2	1: JOG command
					Operation direction
					00B: FWD
					(REV indicator is OFF / FWD indicator is ON)
					01B: from REV to FWD
				bit4-3	(REV indicator flashes / FWD indicator is ON)
					10B: from FWD to REV
					(REV indicator is ON / FWD indicator flashes)
					11B: REV
					(REV indicator is ON / FWD indicator is OFF)
				bit7–5	Reserved
				bit8	1: Master frequency controlled by communication
				Dito	interface
				bit9	Master frequency controlled by analog / external terminal signal
				h::40	1: Operation command controlled by
				bit10	communication interface
				bit11	1: Parameter locked
				bit12	1: Enable copy parameter from keypad
				bit15-13	Reserved
Frequency command	2102H	R(03H)		Drive's fre	quency command (XXX.XX Hz)
Output frequency	2103H	R(03H)		Drive's ou	tput frequency (XXX.XX Hz)
Output				Drive's ou	utput current (XX.XX A). Decimal places can be
current	2104H	R(03H)		referred by	y the high byte of 211F
DC bus	2105H	R(03H)		Drive's DC	bus voltage (XXX.X V)
Output voltage	2106H	R(03H)		Drive's out	tput voltage (XXX.X V)
Multi-step speed status	2107H	R(03H)	U16		rrent running speed step given by multi-step speed (0 is main speed)
Multi- function display	2116H	R(03H)			e low word value (Pr.00-04) of user-defined items, the w 16 bits data.

6. Status monitor read only (22xx): communication station address is Pr.09-00 setting value

Function Name	Modbus Address	Attribute (Function Code)	Size	Description
Maximum user- defined value	2201H	R(03H)		Maximum Operation Frequency (Pr.01-00)
AUI1 analog input	2203H	R(03H)		Display signal of AUI analog input terminal, -10–10 V corresponds to -100.00–100.00%
AUI2 analog input	2204H	R(03H)		Display signal of AUI analog input terminal, -10–10 V corresponds to -100.00–100.00%
IGBT temperature	2206H	R(03H)	U16	IGBT temperature of drive power module (XXX.X°C)
Heat sink temperature	2207H	R(03H)		Display temperature of heat sink (°C) (only for model 40 HP and above)
Digital input status	2208H	R(03H)		The status of digital input (ON/OFF), refer to Pr.02-10 (see Example 01 in Pr.00-04)
Digital output status	2209H	R(03H)		The status of digital output (ON/OFF), refer to Pr.02-23 (see Example 02 in Pr.00-04)

B-5 Exception Response

When the drive is using the communication connection, if an error occurs, the drive responds to the error code and sets the highest bit (bit 7) of the command code to 1 (function code AND 80H) then responds to the control system to signal that an error occurred.

If the keypad displays "CE-XX" as a warning message, "XX" is the error code at that time. Refer to the table of error codes for communication error for reference.

ASCII r	no	d	е
---------	----	---	---

STX	·.,
Address	'0'
Address	'1'
Function	'8'
Function	'6'
Execution code	'0'
Exception code	'2'
LRC Check	'7'
LING CHECK	'7'
END	CR
END	LF

RTU mode

Address	01H
Function	86H
Exception code	02H
CRC Check Low	C3H
CRC Check High	A1H

The explanation of exception codes:

Error code	Explanation
1	Function code is not supported or unrecognized.
2	Address is not supported or unrecognized.
3	Data is not correct or unrecognized.
4	Failure to execute this function code
10	Transmission time-out

Appendix C. Revision History

Firmware Version: V1.11

Issued Edition: 00

Issued Date: June, 2023

Added	
Descriptions	Chapters
Added notes for airflow and heat dissipation for single and multiple drive installation	Section 2-2
 Added maximum and minimum wire gauge, screw size and tightening torque for ground terminal. Added recommended wires when installing at an ambient 50°C or above environment 	Section 4-2
Added wiring diagram for frequency division output	Section 7-2-6 Section 7-3-5 Section 7-4-5
Added links for Certifications and Declaration of Conformity (Doc)	Section 8-3
Added data value in tables for derating curves	Section 8-5
 Added rollback function parameters in Starting stage. Added Pr.07-29 for comfort function in Stopping stage. 	Section 10-4
 Pr.00-04: Added setting value 40 (elevator actual speed m/s) and display illustration Pr.00-09: Added block diagrams for each control mode 	Pr. Group 00
Pr.01-08: Added SVC control mode	Pr. Group 01
 MO40: Added descriptions regarding use with Pr.02-43 Added multi-function input #MI57, MI59, and multi-function output #MO50, MO51, MO52 Pr.02-34: Added related descriptions when actual output H > Pr.02-34, and descriptions regarding setting range and unit varying with Pr.00-10. Added Pr.02-40 to Pr.02-42 (direct docking mode only), and Pr.02-43 (Speed Reached Bandwidth) 	Pr. Group 02
 Pr.05-16, Pr.06-01, Pr.06-26, Pr.09-02, Pr.10-03, Pr.10-09: Added notes regarding setting value "fault and ramp to stop" 	Pr. Group 05, 06, 09, 10
 Pr.06-50, Pr.06-51, Pr.06-52: Added cross-reference fault codes ocA, ocd, ocn, ocS, GFF Pr.06-52: Added notes regarding minimum time interval Pr.06-72: Added two methods 1. <u>ARD or UPS</u> 2. <u>Battery</u> used as EPS 	Pr. Group 06
Added Pr.07-31 to Pr.07-37 brake torque test functions	Pr. Group 07
Added Pr.11-21 (filter time display settings on built-in keyboard panel)	Pr. Group 11
Added warning codes: LS, bttA, bttn, bttS	Chapter 13
Added fault codes: OPHL (U/V/W phase output phase loss), LSS, LSo, btt, bttE	Pr. Group 06 Chapter 14

Updated	
Descriptions	Chapters
Updated Personal Repair Request service link	Section 1-4
Updated data value for MI1 to MI8 Default (NPN Mode)	Section 5-3
Updated recommended filter selections for the following models: • VFD055ED43S: from EMF033A43A to EMF018A43A • VFD075ED43S: from EMF033A43A to EMF018A43A • VFD150ED43S: from B84143D0075R127 to EMF033A43A	Section 6-6
Updated information on digital keypad from KPC-CE01 to KPC-CC01	Section 6-7 Section 9-4
Updated IFD6530 driver download link	Section 6-8
Deleted discontinued option cards: EMED-PGABD-1, EMED-PGHSD-1, EMED-PGHSD-2	Section 7-1-2 Section 7-2 to 7-4 Section 10-3 Pr. Group 10, 11 Section 14
Updated terminal DGND to GND in wiring diagrams	Section 7-2 to 7-4
 Maximum external power is 12V, deleted 24V related information Updated wiring diagrams in external power Updated note item 3: from A, B, Z to /A, /B, /Z 	Section 7-2-3
Maximum output voltage: deleted "three-phase"	Section 8-1
 Output frequency range: updated output frequency upper limit to 299 Hz Updated speed control range: 1: 100 (up to 1:1000 when using PG card) to 1:50 (up to 1:1000 when using PG card) Maximum output frequency: updated output frequency upper limit to 299.00 Hz Categorized Certifications into EMC Directive, Production Compliance, Production Certifications, and Safety Certification. 	Section 8-2 Section 8-3
 Updated digital keypad KPC-CC01 to latest Simplified Chinese language is not supported in this version. 	Chapter 09
 Updated function parameters in All stage. Updated parameters for comfort function in Starting stage. 	Section 10-4
 Pr.01-38: Updated the process and steps for two methods of sending leveling signals Updated drive's output frequency upper limit: Pr.01-00, Pr.01-01, Pr.01-03, Pr.01-05, Pr.01-07, Pr.01-09, Pr.01-10, Pr.01-11, Pr.01-22, Pr.01-23, Pr.01-29, Pr.01-39 	Chapter 10 Pr. Group 01
 Multi-function input Ml#39: Updated cross-reference from Pr.03-01 to Pr.03-00 Pr.02-34: Updated drive's output frequency upper limit to 299.00 Hz, and deleted tolerance range plus—minus sign Pr.02-38, Pr.02-39: Updated elevator timing diagram Pr.02-25, Pr.02-26, Pr.02-27, Pr.02-28, Pr.02-34: Updated drive's output frequency upper limit 	Pr. Group 02
Pr.03-15: Updated load compensation auto-tuning process	Pr. Group 03
Pr.04-00 to Pr.04-15: Updated drive's output frequency upper limit	Chapter 10 Pr. Group 04

Updated	
Descriptions	Chapters
 Pr.06-01: Updated parameter name Pr.06-14: Updated parameter name Pr.06-30: Updated parameter setting range and descriptions Pr.06-44: Updated drive's output frequency upper limit Pr.06-45: Updated setting value Bit1=1 to "Fan lock, warn and continue operation" Pr.06-46: Updated descriptions Pr.06-79: Updated cross-reference ERV/SERV warning/fault code descriptions 	Pr. Group 06
 Pr.7-24 to Pr.07-27: Updated cross-reference from Pr.03-00=5, 6, 7, 8 to Pr.03-00=7, 8, 9, 10 Pr.07-05, Pr.07-08, Pr.07-10: Updated drive's output frequency upper limit 	Pr. Group 07
 Pr.09-02: Updated setting value 1 to "Fault and ramp to stop" Pr.09-04: Moved partial contents in Parameter Group 09 to Appendix B. Modbus Protocol 	Pr. Group 09 Appendix B
Pr.10-17, Pr.10-20, Pr.10-21: Updated drive's output frequency upper limit	Pr. Group 10
Pr.11-00: Delated "speed bandwidth control enabled" for setting value Bit 0=1, and updated text descriptions of "PI adjustment-auto gain" diagram	Pr. Group 11
Fault code MPHL: Updated fault name and corrective actions	Pr. Group 06 Chapter 14

[This page intentionally left blank]