

Industrial Automation Headquarters

Taiwan: Delta Electronics, Inc. Taoyuan Technology Center No.18, Xinglong Rd., Taoyuan District, Taoyuan City 33068, Taiwan TEL: +886-3-362-6301 / FAX: +886-3-371-6301

Asia

China: Delta Electronics (Shanghai) Co., Ltd. No.182 Minyu Rd., Pudong Shanghai, P.R.C. Post code : 201209 TEL: +86-21-6872-3988 / FAX: +86-21-6872-3996 Customer Service: 400-820-9595

Japan: Delta Electronics (Japan), Inc. Industrial Automation Sales Department 2-1-14 Shibadaimon, Minato-ku Tokyo, Japan 105-0012 TEL: +81-3-5733-1155 / FAX: +81-3-5733-1255

Korea: Delta Electronics (Korea), Inc. 1511, 219, Gasan Digital 1-Ro., Geumcheon-gu, Seoul, 08501 South Korea TEL: +82-2-515-5305 / FAX: +82-2-515-5302

Singapore: Delta Energy Systems (Singapore) Pte Ltd. 4 Kaki Bukit Avenue 1, #05-04, Singapore 417939 TEL: +65-6747-5155 / FAX: +65-6744-9228

India: Delta Electronics (India) Pvt. Ltd. Plot No.43, Sector 35, HSIIDC Gurgaon, PIN 122001, Haryana, India TEL: +91-124-4874900 / FAX: +91-124-4874945

Thailand: Delta Electronics (Thailand) PCL.

909 Soi 9, Moo 4, Bangpoo Industrial Estate (E.P.Z), Pattana 1 Rd., T.Phraksa, A.Muang, Samutprakarn 10280, Thailand TEL: +66-2709-2800 / FAX: +66-2709-2827

Australia: Delta Electronics (Australia) Pty Ltd. Unit 2, Building A, 18-24 Ricketts Road, Mount Waverley, Victoria 3149 Australia Mail: IA.au@deltaww.com TEL: +61-1300-335-823 / +61-3-9543-3720

Americas

USA: Delta Electronics (Americas) Ltd. 5101 Davis Drive, Research Triangle Park, NC 27709, U.S.A. TEL: +1-919-767-3813 / FAX: +1-919-767-3969

Brazil: Delta Electronics Brazil Ltd. Estrada Velha Rio-São Paulo, 5300 Eugênio de Melo - São José dos Campos CEP: 12247-004 - SP - Brazil TEL: +55-12-3932-2300 / FAX: +55-12-3932-237

Mexico: Delta Electronics International Mexico S.A. de C.V.

Gustavo Baz No. 309 Edificio E PB 103 Colonia La Loma, CP 54060 Tlalnepantla, Estado de México TEL: +52-55-3603-9200

EMEA

EMEA Headquarters: Delta Electronics (Netherlands) B.V. Sales: Sales.IA.EMEA@deltaww.com Marketing: Marketing.IA.EMEA@deltaww.com Technical Support: iatechnicalsupport@deltaww.com Customer Support: Customer-Support@deltaww.com Service: Service.IA.emea@deltaww.com TEL: +31(0)40 800 3900

BENELUX: Delta Electronics (Netherlands) B.V. Automotive Campus 260, 5708 JZ Helmond, The Netherlands Mail: Sales.IA.Benelux@deltaww.com TEL: +31(0)40 800 3900

DACH: Delta Electronics (Netherlands) B.V. Coesterweg 45, D-59494 Soest, Germany

Mail: Sales.IA.DACH@deltaww.com TEL: +49(0)2921 987 0

France: Delta Electronics (France) S.A. ZI du bois Challand 2,15 rue des Pyrénées,

Lisses, 91090 Evry Cedex, France Mail: Sales.IA.FR@deltaww.com TEL: +33(0)1 69 77 82 60

Iberia: Delta Electronics Solutions (Spain) S.L.U

Ctra. De Villaverde a Vallecas, 265 1º Dcha Ed. Hormigueras – P.I. de Vallecas 28031 Madrid TEL: +34(0)91 223 74 20 Carrer Llacuna 166, 08018 Barcelona, Spain Mail: Sales.IA.Iberia@deltaww.com

Italy: Delta Electronics (Italy) S.r.l.

Via Meda 2–22060 Novedrate(CO) Piazza Grazioli 18 00186 Roma Italy Mail: Sales.IA.Italy@deltaww.com TEL: +39 039 8900365

Russia: Delta Energy System LLC

Vereyskaya Plaza II, office 112 Vereyskaya str. 17 121357 Moscow Russia Mail: Sales.IA.RU@deltaww.com TEL: +7 495 644 3240

Turkey: Delta Greentech Elektronik San. Ltd. Sti. (Turkey)

Şerifali Mah. Hendem Cad. Kule Sok. No:16-A 34775 Ümraniye – İstanbul Mail: Sales.IA.Turkey@deltaww.com TEL: + 90 216 499 9910

MEA: Eltek Dubai (Eltek MEA DMCC)

OFFICE 2504, 25th Floor, Saba Tower 1, Jumeirah Lakes Towers, Dubai, UAE Mail: Sales.IA.MEA@deltaww.com TEL: +971(0)4 2690148

VFD-Delta Π 0 ANopen I. C Serie C S ommunic User Manual ation C ompact Drive



Digitized Automation for a Changing World

Delta CANopen Communication Compact Drive VFD-EL-C Series User Manual



*We reserve the right to change the information in this manual without prior notice.

www.deltaww.com



Copyright notice

©Delta Electronics, Inc. All rights reserved.

All information contained in this user manual is the exclusive property of Delta Electronics Inc. (hereinafter referred to as "Delta ") and is protected by copyright law and all other laws. Delta retains the exclusive rights of this user manual in accordance with the copyright law and all other laws. No parts in this manual may be reproduced, transmitted, transcribed, translated or used in any other ways without the prior consent of Delta.

Limitation of Liability

The contents of this user manual are only for the use of the product manufactured by Delta. Except as defined in special mandatory laws, Delta provides this user manual "as is" and does not offer any kind of warranty through this user manual for using the product, either express or implied, including but not limited to the following: (i) this product will meet your needs or expectations; (ii) the information contained in the product is current and correct; (iii) the product does not infringe any rights of any other person. You shall bear your own risk to use this product.

In no event shall Delta, its subsidiaries, affiliates, managers, employees, agents, partners and licensors be liable for any direct, indirect, incidental, special, derivative or consequential damages (including but not limited to the damages for loss of profits, goodwill, use or other intangible losses) unless the laws contains special mandatory provisions to the contrary.

Delta reserves the right to make changes to the user manual and the products described in the user manual without prior notice and afterwards.

Thank you for using Delta's compact built-in CAN communication drive VFD-EL-C series.

The VFD-EL-C series is manufactured using high-quality components, materials and incorporating the latest embedded control technology.

This product description provides users with precautions related to installation, parameter setting, abnormal diagnosis, troubleshooting and daily maintenance of the drive. In order to ensure correct installation and operation, please read this product manual carefully before installing the drive, and please keep it properly and hand it over to the user of the machine.

For the safety of the operator and mechanical equipment, it must be installed, tested and adjusted by professional electrical engineering personnel. There are symbols such as [Danger] and [Caution] in this product description. Please be sure to read it carefully. If you have any doubts, please contact our agents.

PLEASE READ PRIOR TO INSTALLATION FOR SAFETY.



- Disconnect AC input power before connecting any wiring to the AC motor drive.
- ☑ Even if the power has been turned off, a charge may still remain in the DC-link capacitors with hazardous voltages before the POWER LED is OFF. Do not touch the internal circuits and components.
- There are highly sensitive MOS components on the printed circuit boards.
 These components are especially sensitive to static electricity. Take anti-static measures before touching these components or the circuit boards.
- ☑ Never modify the internal components or wiring.
- Ground the AC motor drive by using the ground terminal. The grounding method must comply with the laws of the country where the AC motor drive is to be installed.
- ☑ This series is used to control the variable speed operation of three-phase induction motors, and cannot be used for single-phase motors or for other purposes.
- \square This series cannot be used in situations that endanger personal safety.
- ☑ Please prevent children or general irrelevant persons from approaching the drive.
- ☑ Never connect the AC motor drive output terminals U/T1, V/T2 and W/T3 directly to the AC mains circuit power supply.



- ☑ Do not perform withstand voltage test on the components inside the drive, the semiconductor used in the drive is easily damaged by high voltage breakdown.
- ☑ Even if the three-phase AC motor is stopped, a charge with hazardous voltages may still remain in the main circuit terminals of the AC motor drive.
- ☑ Only qualified persons are allowed to install, wire and maintain the AC motor drives.

☑ When using an external terminal as the source of the running command, the motor may start to run immediately after the power is input. It may cause danger if there are people near the drive.

- ☑ Install the drive in a safe area to prevent high temperature and direct sunlight, and avoid splashing of moisture and water droplets.
- Please comply with the installation precautions when installing the drive.
 Unapproved use environment may cause fire, gas explosion, electric shock and other incidents.

V	When the wiring between the drive and the motor is too long, the interlayer
	insulation of the motor may be damaged. Please use an AC motor dedicated to
	the drive, or install a reactor between the drive and the AC motor (refer to
	Appendix A) to avoid damage to the AC motor due to insulation damage.
\checkmark	The rated voltage of power system to install motor drives is listed below. Ensure
	that the installation voltage is in the correct range when installing a motor drive.
	For 230V models, the range is between 180–264 V.
	For 460V models, the range is between 342–528 V.
\checkmark	If the motor drive produces a leakage current of over AC 3.5mA or over DC 10mA,
	the minimum specifications required of the Protective Earthing conductor have to
	be a copper wire with a cross-sectional area of at least 10 mm ² , an aluminum wire
	with a cross-sectional area of 16 mm ² , or install an earth leakage circuit breaker.

NOTE:

- In the pictures in this manual, the cover or safety shield is disassembled only when explaining the details of the product. During operation, install the top cover and wiring correctly according to the provisions. Refer to the operation descriptions in the manual to ensure safety.
- The figures in this instruction are only for reference and may be slightly different depending on your model, but it will not affect your customer rights.
- The content of this manual may be revised without prior notice. Consult our distributors or download the latest version at http://www.deltaww.com/iadownload_acmotordrive.

Table of Contents

CHAPTER 1 USE AND INSTALLAT	ON1-1
1-1 Product Profile	
1-2 Product Installation	
1-3 Product Dimensions	
CHAPTER 2 WIRING	
2-1 Wiring Instructions	
2-2 System Wiring Diagram	
2-3 Main circuit terminal descri	ption2-8
2-4 Control circuit terminal dese	cription2-11
2-5 NPN and PNP modes	
CHAPTER 3 OPERATION PANEL D	ESCRIPTION AND TEST RUN
3-1 Panel Description	
3-2 Operation mode	
3-3 Test run	
CHAPTER 4 SPECIFICATION	
4-1 230V 1φ Models	4-2
4-2 460V 3φ Models	4-3
4-3 General Specifications	
4-4 Environmental Specificatio	ns4-5
4-5 Operating ambient tempera	ature and Carrier Derating4-6
CHAPTER 5 CANopen OVERVIEW	
5-1 CANopen Ovreview	
5-2 Wiring for CANopen	
5-3 CANopen Communication	Interface Descriptions5-8
5-4 CANopen Supporting Index	۲5-16
5-5 CANopen Fault Codes	5-21
5-6 CANopen LED Function	
CHAPTER 6 DESCRIPTIONS OF PA	ARAMETER SETTINGS 6-1-1
6-1 Summary of Parameter Sett	ings6-1-2
6-2 Descriptions of Parameter S	Settings6-2-001
00 Drive Parameters	
01 Basic Parameters	
02 Digital Input / Output	Parameters6-2-021
04 Multi-Stage Speed Pa	arameters6-2-041

	05 Motor Parameters	6-2-051
	06 Protection Parameters (1)	6-2-061
	07 Special Parameters	6-2-071
	09 Communication Parameters	6-2-091
	10 Speed Feedback Control Parameters	6-2-101
	12 System control and CANopen function Parameters	6-2-121
	13 Control Mode Parameter Macro Function	6-2-131
СНАРТІ	ER 7 WARNING CODES	7-1
	ER 8 FAULT CODES	
CHAPTI		8-1
CHAPTI APPEN	ER 8 FAULT CODES	8-1 A-1
CHAPTI APPEN A-1	ER 8 FAULT CODES DIX A. MODBUS PROTOCOL	8-1 A-1 A-2
CHAPTI APPEN A-1 A-2	ER 8 FAULT CODES DIX A. MODBUS PROTOCOL Circuit Breaker	8-1 A-1 A-2 A-2
CHAPTI APPEN A-1 A-2 A-3	ER 8 FAULT CODES DIX A. MODBUS PROTOCOL Circuit Breaker Reactors	8-1 A-1 A-2 A-2 A-2 A-4

Issued Edition: 02

Firmware Version: V1.04 (Refer to Parameter 00-06 on the product to get the firmware version.) Issued Date: 2023/3

[This page intentionally left blank]

Chapter 1 Use and Installation

- 1-1 Product Profile
- 1-2 Product Installation
- **1-3 Product Dimensions**

Chapter 1 Use and Installation | EL-C

The product should be in the box when customers received. If the machine is not used temporarily, for the safety of the maintenance during the warranty period of our company, be sure to pay attention to the following points when storing the machine:



- ☑ The machine must be placed in a ventilated, dust-free and dry location.
- ☑ The ambient temperature of the storage location must be in the range of -20°C to +60°C.
- CAUTION
- ☑ The relative humidity of the storage location must be in the range of 0% to 90% with no condensation.
- Avoid storing the machine in environments containing corrosive gases or liquids.
- Avoid placing the machine on the ground, but should place it on a suitable stand. And place a desiccant in the packaging bag if the surrounding environment is harsh.
- Avoid installing the machine in places exposed to direct sunlight or vibrations.
- Even if the humidity meets the specification requirements, condensation and freezing may occur when the temperature changes sharply which location should be avoided.
- ☑ If the machine has been opened and used for more than 3 months, the ambient temperature of the storage environment should not be higher than 30°C. It is considered that when the electrolytic capacitor is stored without electricity, its characteristics are easily deteriorated when the ambient temperature is too high. Do not leave the machine unpowered for more than a year.
- ☑ When the motor drive is installed in a device or control panel and is not in use (especially in a construction site or in a humid and dusty place), the drive should be removed and placed in a suitable environment meets the above-mentioned storage conditions.

1-1 Product Profile


Each VFD-EL-C is subject to strict quality control and enhanced anti-collision packaging before shipment. After the customer unpacks the drive, please carry out the following inspection steps immediately.

- ☑ Check whether the drive has been damaged during transportation.
- After unpacking, check the model of the drive is consistent with the data in the outer box.

If there is any inconsistency with your ordering information or any questions about the product, please contact the agent or distributor.

Nameplate Information

Take 1 HP/0.4 kW 230V 1-Phase as an example



Appearance

Frame A1



Frame A2



Input terminals (R/L1, S/L2, T/L3)

Digital keypad

Control board cover

Output terminals (U/T1, V/T2, W/T3) Ground terminals



MODE

NTER

В

128


A: Digital keypad B: Control terminals C: CAN Connect 1 (RJ45) D: CAN Connect 2 (RJ45)

A: Digital keypad B: Control terminals C: CAN Connect 1

D: CAN Connect 2 (RJ45)

(RJ45)


Frame B



Frame	Capacity	Model
A1 Keypad	0.25–1 HP	VFD002EL21C, VFD004EL21C / 43C, VFD007EL21C / 43C
Panel Mounting:	(0.2–0.75 kW)	VFD002EL21C, VFD004EL21C / 43C, VFD007EL21C / 43C
A2	2 HP (1.5 kW)	VFD015EL43C
в	2–5.5 HP	VFD015EL21C, VFD022EL21C / 43C,
В	(1.5–5.5 kW)	VFD040EL43C, VFD055EL43C

Table 1-1

RFI Jumper switch



NOTE:

If the grounding system is required or the leakage current is too large to cause the leakage protection device to trip, loosen the screws next to the input side of (R/L1, S/L2, T/L3) and remove the grounding short-circuit metal sheet.

Note: To re-tighten the loosened screws to keep the grounding well to prevent electric shock after removing the grounding shorting piece.

RFI Jumper

RFI Jumper:

- (1) The drive contains Varistors / MOVs that are connected from phase to phase and from phase to ground to prevent the drive from unexpected stop or damage caused by mains surges or voltage spikes. Because the Varistors / MOVs from phase to ground are connected to ground with the RFI jumper, removing the RFI jumper disables the protection.
- (2) The RFI jumper connects the filer capacitors to ground to form a return path for high frequency noise in order to isolate the noise from contaminating the mains power. Removing the RFI jumper strongly reduces the effect of the built-in EMC filter. Although a single drive complies with the international standards for leakage current, an installation with several drives with built-in EMC filters can trigger the RCD. Removing the RFI jumper helps, but the EMC performance of each drive is no longer guaranteed.

Isolating main power from ground:

When the power distribution system for the drive is a floating ground system (IT Systems) or an asymmetric ground system (Corner Grounded TN Systems), you must remove the RFI jumper. Removing the RFI jumper disconnects the internal capacitors from ground to avoid damaging the internal circuits and to reduce the ground leakage current.

Pay particular attention to the following points:

- ☑ Do not remove the RFI jumper while the power is on.
- ☑ Make sure the main power is OFF before removing the RFI jumper.
- ☑ Removing the RFI jumper also cuts the capacitor conductivity of the surge absorber to ground and the capacitors. Compliance with the EMC specifications is no longer guaranteed.

Reliable electrical isolation cannot be maintained if the ground shorts are removed. In other words, all control inputs and outputs can only be regarded as low-voltage terminals with basic electrical isolation. In addition, the electromagnetic compatibility of the frequency converter will be reduced by removing the grounding shorts.

- ☑ Do not remove the RFI jumper if the mains power is a symmetrical grounded power system in order to maintain the efficiency for EMC filter.
- ☑ The short-circuit piece must be removed during the high voltage test, and be sure to tighten the screws securing the shorting strip after removing the shorting strip. When conducting a high voltage test to the entire facility, disconnect the mains power and the drive if the leakage current is too high.
- ☑ If the drive is installed in a non-grounded power system or a high-impedance grounded power system (over 30Ω) or a corner-grounded TN system, the grounding short must be removed to avoid the machine damage. After removing the jumper, the screws fix the jumper must be tightened.

Remove step

Remove the control terminal slide

Press the control board terminal slide cover lightly as shown in Figure A first, and then slide it down as shown in Figure B to remove it easily.



Figure A



Remove the fan

Frame B

Press the buckles on the left and right sides of the fan lightly and pull up to remove the fan.



Chapter 1 Use and Installation | EL-C

1-2 Product Installation


Please install the drive in the following environmental conditions to ensure the safety of the product:

	Ambient	-10°C-+50°C NOTE 1
	temperature Rated Humidity	< 90%, no frosting
Operating Environmental	Air Pressure	86–106 kPa
Conditions	Altitude	< 1000 m
	Vibration	1.0 mm, peak to peak value range from 2–13.2 Hz; 0.7–1.0 G range from 13.2–55 Hz; 1.0 G range from 55–512 Hz. Compliance with IEC 6006826
	Ambient temperature	-20°C–+60°C (-4°F–140°F)
Storage / Transportation	Rated Humidity	< 90%, no frosting
	Air Pressure	86–106 kPa
	Vibration	1.0 mm, peak to peak value range from 2–13.2 Hz; 0.7–1.0 G range from 13.2–55 Hz; 1.0 G range from 55–512 Hz. Compliance with IEC 6006826 Table 1-2
Pollution Degree	Level 2: Suital	ble for low-to-medium pollution factory environments


NOTE:

1. The VFD007EL21C needs to install the fan accessory MKEL-AFKM1, and the upper limit of the ambient temperature operation can reach 50°C.

Mounting Clearance Inflow Single drive installation



Distance Zero stack installation



	Installation	Minimu	ım distanc	e (mm)	Ambient temperature (°C)		
Model	Method	А	В	C NOTE 1	Max. (Without derating)	Max. (derating)	
	Single drive installation	120	50	-	50	60	
VFD002EL21C VFD004EL21C VFD004EL43C	Side-by-side horizontal installation	120	50	30	50	60	
VI DOOHEEHOO	Zero stack installation	-	-	-	-	-	
	Single drive installation	120	50	-	50 ^{NOTE 4}	60	
VFD007EL21C	Side-by-side horizontal installation	120	50	30	50 NOTE 4	60	
	Zero stack installation	-	-	-	-	-	
	Single drive installation	120	50	-	50	60	
VFD007EL43C VFD015EL43C	Side-by-side horizontal installation	120	50	30	50	60	
	Zero stack installation	-	-	-	-	-	
VFD015EL21C	Single drive installation	150	50	-	50	60	
VFD022EL21C VFD022EL43C VFD040EL43C	Side-by-side horizontal installation	150	50	30	50	60	
VFD040EL43C VFD055EL43C	Zero stack installation	150	50	0	40	50	


NOTE:

Table 1-3

- 1. The shape of the heat sink of frame A1 / A2 protrudes from the left and right plastic shell bodies, therefore, the horizontal side-by-side installation distance C is calculated based on the position of the plastic shell of the drive.
- 2. Frame A1 / A2 does not support zero stack installation. Frame B supports zero stack installation.
- 3. When the ambient temperature exceeds the column of "Max. (without derating)", full load operation will shorten the service life of the drive.

Chapter 1 Use and Installation | EL-C

- 4. When the model VFD007EL21C is equipped with a fan accessory, the upper limit of the ambient operating temperature is as shown in the table above; when there is no fan accessory, the upper limit of the corresponding ambient operating temperature is 10°C lower than the temperature value in the table (refer to Appendix B-3-3 for the installation of fan accessories).
 - ☑ The drive should be installed vertically on a solid structure with screws. Do not install it upside down, obliquely or horizontally.
 - ☑ Heat is generated when the drive is running. To ensure the passage of cooling air should be as shown. The design leaves a certain space that the heat generated can be dissipated upwards. Do not install it under the equipment which is not heat-resistant. It is necessary to consider ventilation and heat dissipation in the control panel to ensure the ambient temperature of the drive does not exceed the specified value. Do not install the drive in an airtight box with poor ventilation and heat dissipation, which may easily cause machine failure due to overheating
 - ☑ When the drive is running, the temperature of the heatsink plate can rise up to nearly 90°C. Therefore, the mounting surface on the back of the drive must be made of a metal material which can withstand higher temperatures and have good heat dissipation.
 - ☑ To installing multiple drives in the same control panel, it is recommended to install them horizontally side by side in order to reduce mutual thermal influence. If upper and lower installations are required, a partition plate must be installed to reduce the effect of the heat generated in the lower part on the upper part.



NOTE:


Prevent fiber particles, scraps of paper, shredded wood, sawdust, metal particles, etc. from adhering to the heat sink.

Install the AC motor drive in a metal cabinet. When installing one drive below another one, use a metal separator between the AC motor drives to prevent mutual heating and to prevent the risk of fire accident.

1-3 Product Dimensions

Frame A1


VFD002EL21C, VFD004EL21C, VFD004EL43C, VFD007EL21C, VFD007EL43C



						U	nit: mm [inch]
Frame	W	W1	Н	H1	D	D1	S1
A 4	92.0	82.0	162.0	152.0	128.7	2.0	5.4
A 1	[3.62]	[3.23]	[6.38]	[5.98]	[5.07]	[0.08]	[0.21]
							Table 1-4

Frame A2

VFD015EL43C




Unit: mm [inch]

Frame	W	W1	Н	H1	H2	D	D1	S1
4.2	92.0	82.0	180.5	162.0	152.0	128.7	2.0	5.4
A2	[3.62]	[3.23]	[7.11]	[6.38]	[5.98]	[5.07]	[0.08]	[0.21]
								Table 1-5

Frame B

VFD015EL21C, VFD022EL21C, VFD022EL43C, VFD040EL43C, VFD055EL43C



Unit: mm [inch]

Frame	W	W1	Н	H1	D	D1	S1	S2
D	100.0	89.0	174.0	162.9	136.0	4.0	5.9	5.4
В	[3.94]	[3.50]	[6.85]	[6.42]	[5.35]	[0.16]	[0.23]	[0.21]
								Tabla

Table 1-6

[This page intentionally left blank]

Chapter 2 Wiring

- 2-1 Wiring Instructions
- 2-2 System Wiring Diagram
- 2-3 Main circuit terminal description
- 2-4 Control circuit terminal description
- 2-5 NPN and PNP modes

Chapter 2 Wiring | EL-C

After removing the Input/output side terminal slide cover and control board terminal slide cover, verify that the power and control terminals are clearly noted. Read the following precautions before wiring.

Δ	V	Turn off the AC motor drive power before doing any wiring. A charge with hazardous
14		voltages may remain in the DC bus capacitors even after the power has been turned
		off for a short time. In order to avoid danger, customers can wait at least 5 minutes
DANGER		before starting wiring after the digital panel display light goes out. If the AC motor drive
		does not fully discharge, and assemble the wiring with a residual voltage may cause
		personal injury, sparks and a short circuit. Ensure your safety to use AC motor drive with no voltage.
	Ø	Only qualified personnel familiar with AC motor drives are allowed to perform
		installation, wiring and commissioning. Make sure the power is turned off before wiring to prevent electric shock.
	V	Make sure that power is only applied to the R/L1, S/L2, and T/L3 terminals. Failure to
		comply may result in damage to the equipment. The voltage and current must be in
		the range indicated on the nameplate (refer to Section 1-1 Nameplate Information for
		details).
	Ø	All units must be grounded directly to a common ground terminal to prevent damage
		from a electric shock or fire accident and reduce noise interference.
	\square	Tighten the screws of the main circuit terminals to prevent sparks caused by screws
		loosened due to vibration.
Δ	V	For your safety, choose wires that comply with local regulations when wiring.
	Ø	Check the following items after finishing the wiring:
\sim		1. Are all connections correct?
CAUTION		2. Are there any loose wires?
		3. Are there any short circuits between the terminals or to ground?


2-1 Wiring Instructions

The wiring is divided into the main circuit and the control circuit, the user must connect according to the following wiring circuits.

Recommended Wiring Diagram for VFD-EL-C

230V 1-PHASE

VFD002EL21C, VFD004EL21C, VFD007EL21C, VFD015EL21C, VFD022EL21C






- *1. The MI digital input terminal is switch with NPN/PNP mode. In addition to the correct wiring, it needs to be switched with Pr.02-55. The default setting Pr.02-55 is 0: NPN mode.
- *2. The MI digital input terminal and the MO digital output terminal share the same ground, the terminal is DCM.
- *3. CAN1/CAN2 terminals (two-way RJ45) internal lines are connected in parallel, logically they are the same way.
- *4. RJ45 terminal metal shield shell internal connect with the PE terminal.
- *5. RJ45 terminal PIN4 to 8 is reserved for on-site adjustment, please do not connect any cable to prevent abnormal function.

460V 3-PHASE:

VFD004EL43C, VFD007EL43C, VFD015EL43C, VFD022EL43C, VFD040EL43C, VFD055EL43C






- *1. The MI digital input terminal is switch with NPN/PNP mode. In addition to the correct wiring, it needs to be switched with Pr.02-55. The default setting Pr.02-55 is 0: NPN mode.
- *2. The MI digital input terminal and the MO digital output terminal share the same ground, the terminal is DCM.
- *3. CAN1/CAN2 terminals (two-way RJ45) internal lines are connected in parallel, logically they are the same way.
- *4. RJ45 terminal metal shield shell internal connect with the PE terminal.
- *5. RJ45 terminal PIN4 to 8 is reserved for on-site adjustment, please do not connect any cable to prevent abnormal function.



- Separate the main circuit and control circuit wiring to prevent erroneous actions.
- ☑ Use shielded wire for the control wiring and do not expose the peeled-off shield in front of the terminal.
- ☑ Use shielded wire or conduit for the power wiring and ground the two ends of the shielded wire or conduit.
- ☑ Usually control wires are not well insulated. Damaged insulation of wiring may cause personal injury or damage to circuits and equipment if it comes in contact with high voltage.
- The AC motor drive, motor and wiring may cause interference. To prevent equipment damage, take care of interference between the surrounding sensors and the equipment.
- Connect the AC drive output terminals U/T1, V/T2, and W/T3 to the motor terminals U/T1, V/T2, and W/T3, respectively. To permanently reverse the direction of motor rotation, switch over any of the two motor leads.
- ☑ With long motor cables, high capacitive switching current peaks can cause overcurrent, high leakage current or lower current readout accuracy. To prevent this, the motor cable should be less than 20 m for 4.0 kW models and below. The cable should be less than 50 m for 5.5 kW models and above. For longer motor cables, use an AC output reactor.
- ☑ The AC motor drives, electric welding machines and the larger horsepower motors should be grounded separately.
- ☑ The VFD-EL-W series does not have a built-in brake unit, and no support for external brake unit and brake resistor.
- ☑ When grounding, choose wires that comply with local regulations for your safety.
- ☑ To prevent lightning strike and electric shock, the metal grounding wire of electrical equipment should be thick and short, and connected to the dedicated grounding terminal of the motor drive system.
- You can install multiple VFD-EL-W units in one location. All the units should be grounded directly to a common ground terminal, as shown in the figure below.
 Ensure that there are no ground loops.






2-2 System Wiring Diagram

Power Input Terminal

	Power input terminal	Please follow the specific power supply requirements in Chapter 4.
k∕ k∕ k∕ Breaker		There may be an inrush current during
by by Contactor	Fuse	power-up. Please check the chart in Appendix A-1 and select the correct
		fuse for the rated current. Switching the power ON/OFF on the
AC reactor (input terminal)	Magnetic	primary side of the electromagnetic contactor can turn the drive ON/OFF, but frequent switching can cause machine failure. Do not switch
Zero-Phase Reactor	contactor	ON/OFF more than once an hour. Do not use the electromagnetic contactor as the power switch for the
EMC Filter		drive; doing so shortens the life of the drive.
U/T1 V/T2 W/T3	AC reactor (input terminal)	Use to improve the input power factor, reduce harmonics and provide protection from AC line disturbances (such as surges, switching spikes, short interruptions). Install an AC line reactor when the power supply capacity is 500 kVA or more, or advanced capacity is activated. The wiring distance should be within 10 m. Refer to Appendix A-2-1 for details.
Reactor Reactor Input AC line reactor	Zero phase reactor	Used to reduce radiated interference, especially in environments with audio devices, and reduce input and output side interference. The effective range is AM band to 10 MHz. Refer to Appendix A-2-2 for details.
Motor	EMC Filter	Use to reduce electromagnetic interference.
Figue 2-6	AC reactor (output terminal)	Motor surge voltage amplitude depends on motor cable length. For applications with long motor cable (>20 m), install a reactor at the drive output side. Refer to Appendix A-2-1 for details.


2-3 Main circuit terminal description

Main Circuit Diagram 230V 1-PHASE





460V 3-PHASE



Figue 2-8

Terminals	Descriptions	
R/L1, S/L2, T/L3	Mains input terminals (one / three-phase)	
U/T1, V/T2, W/T3	Motor drive output terminals for connecting three-phase induction motor	
Ground connection. Please comply with local regulations.		





Main input power terminals:


☑ DO NOT connect a three-phase model to one-phase power. R/L1, S/L2 and T/L3 have no phase-sequence requirement; they can be connected in any sequence.

- ☑ You must install a breaker between the three-phase power input terminals and the main circuit terminals (R/L1, S/L2, T/L3). Add a magnetic contactor (MC) to the power input wiring to cut off power quickly and reduce malfunctions when the AC motor drive protection function activates. Both ends of the MC should have an R-C surge absorber.
- ☑ Tighten the screws in the main circuit terminal to prevent sparks caused by screws loosened due to vibration.
- Use voltage and current within the specifications in Chapter 09. Refer to Appendix A for Standard Specifications.
- ☑ When using a leak breaker for leakage fault protection, use a current sensor with sensitivity of 200 mA or above and not less than 0.1 second operation time to prevent the residual current circuit breaker from malfunctioning. When using a leak breaker, use a current sensor with sensitivity of 30 mA.

Output terminals of the main circuit:

- The default for the operation direction is running forward. Since the standard accessory of VFD-EL-C is a simple panel operation interface which cannot judge the direction directly. The method to control the running direction is to set by the communication parameters. Refer to the Parameter Group 09 for details.
- If necessary, use an inductive filter only at the motor output terminals U/T1, V/T2, W/T3 of the AC motor drive. DO NOT use phase-compensation capacitors or L-C (Inductance-Capacitance) or R-C (Resistance-Capacitance), unless approved by Delta.
- DO NOT connect phase-compensation capacitors or surge absorbers at the output terminals of AC motor drives.
- ☑ Use a well-insulated motor to avoid the leakage.

Main Circuit Terminal Specifications






Note:

- If you install at Ta 50°C environment, use copper wires that are temperature resistant to 75°C or 90°C. If you install at Ta 50°C above environment, use copper wires that are temperature resistant to 90°C or above.
- 2. For VFD007EL21C:

If you install at Ta 40°C environment, use copper wires that are temperature resistant to 75°C or 90°C. If you install at Ta 40°C above environment, use copper wires that are temperature resistant to 90°C or above.

3. For VFDxxxEL21C: use copper wires that have a voltage rating of $300V_{AC}$ or above. For VFDxxxEL43C: use copper wires that have a voltage rating of $600V_{AC}$ or above.

2-4 Control circuit terminal description



Figue 2-12 Control Terminal Location Diagram

Terminal	Function Description	Default (NPN mode, Pr.02-55=0)	
MI1		External terminal control: MI1–MI3 supports the two / three-	
MI2		wire start function.	
MI3	Multi-function Output	Communication control: MI1–MI6 can be used as multi-	
MI4	(Default: no function)	function input options.	
MI5		ON: activation current is 6.0 mA (with 24V power) \square	
MI6		OFF: cut-off voltage is 10 μA	
PE	Ground connection;	PE terminal is for shielded cable to grounding to decrease	
	comply with local	the interference when you use RS485 communication CAN1	
	regulations.	and CAN2.	
+24V	Digital control signal	The total output capacity of the 24V power supply is 60 mA,	
	common (Source)	1) When using the MI terminal, the current capacity required	
DCM	Digital control signal	for the terminal action should be deducted accordingly.	
	common (Sink)	2) Do not overload to avoid damage to the internal circuit of	
		the drive.	
MO1	Multifunctional digital	The drive outputs various monitoring signals by MOSFET	
	output terminal	(Open Drain method). Such as running, frequency arrival,	
MO2	Multifunctional digital	overload indication and other signals.	
	output terminal	Load capacity: 500 mA	
MO3	Multifunctional digital	Maximum voltage: 30 V _{DC}	
	output terminal	Note: When the DO output drives the relay, the inverting	
MO4	Multifunctional digital	diode freewheeling must be connected in parallel to avoid	
	output terminal the MOSFET damage.		


Table 2-3

Main Circuit Terminal Specifications

Frame	Model	Wire Gauge	Double row terminal torque (±10%)
A1	VFD002EL21C	24–18 AWG	I–18 AWG 2–0.8 mm²] 2 kg-cm [1.7 lb-in] [0.2 Nm]
	VFD004EL21C		
	VFD004EL43C		
	VFD007EL21C		
	VFD007EL43C		
A2	VFD015EL43C		
В	VFD015EL21C	[0.2–0.6 mm]	
	VFD022EL21C		
	VFD022EL43C		
	VFD040EL43C		
	VFD055EL43C		

Table 2-4

2-5 NPN and PNP mode



Note:

- 1. In NPN/PNP mode, in addition to the correct wiring according to the above figure, it is also necessary to match the Pr.02-55 setting for internal circuit switching (defaultis 0: NPN mode).
- 2. +24V-DCM internal 24V total power load capacity is 60 mA. For the output capability of other external loads, deduct the corresponding number of MI terminals current consumption (6 mA per MI terminal).
- If the VFD007EL21C needs to install fan accessories which is powered from +24V-DCM. At this time, except for the normal use of the MI terminal, other external loads are not allowed to avoid overloading the +24V terminal and damage the motor drive.

[This page is intentionally left blank]

Chapter 3 Operation panel description and test run

- 3-1 Panel Description
- 3-2 Operation mode
- 3-3 Test run

Chapter 3 Operation panel description and test run | EL-C

$\mathbf{\Lambda}$	$\mathbf{\nabla}$	Please check the wiring again before running. Especially the output terminals U/T1,
		V/T2 and W/T3 cannot be connected to the input power supply, and the grounding
		terminal E is well grounded.
CAUTION	\checkmark	Check the motor is not connected to the load mechanism.
	$\mathbf{\nabla}$	Do not operate the switch with wet hands.
	\checkmark	Check the digital panel displays F60.0 or F50.0 when the power is turned on.
$\mathbf{\Lambda}$	V	If the operation of the drive and the motor is abnormal, stop the operation immediately
14		and refer to "Troubleshooting" to check the cause of the abnormal. After the drive stops
		output, touching the output terminals U, V, W of the drive before disconnecting the
DANGER		main circuit power terminals L1/R, L2/S, L3/T may result in electric shock.

3-1 Panel Description

VFD-EL-C series operate and display functions through a digital operation panel.



• Status Display

Display the drive's current status: RUN, STOP, FWD, REV, CAN RUN, CAN ERROR



LED Display Indicates frequency, current, voltage, running direction, user-defined units, faults, etc.


UP/DOWN Key

Select parameters and sets/changes parameter settings

There are four kinds of indicator lights on the panel.

- STOP STOP indicator light: shows the operation is stopped.
- RUN RUN indicator light: indicator will light up when the motor is set to RUN.
- FWD Forward rotation indicator light: indicator will light up when the motor is running in forward direction.
- REV Reverse rotation indicator light: indicator will light up when the motor is running in reverse direction.
- CRUN CAN communication running indicator light: refer to Section 6, CANopen LED Indicator Display in Chapter 5.
- CERR CAN communication error indicator light: refer to Section 6, CANopen LED Indicator Display in Chapter 5.

Displayed items	Descriptions
RUN FWD REV. STOP	Displays the present frequency setting for the drive.
RUN FWD REV. STOP	Displays the actual output frequency to the drive.
RUNC FWD REV.	Displays the user-defined output of a physical quantity $(U = F \times Pr.00-05)$.
RUNA FWD REV.	Displays the load current.
RUNO FWDO REVO	Forward command
RUN FWD REV.	Reverse command
RUN FWD REV.	Displays the count value.
RUN FWD REV: U U U U STOP	Displays a parameter item.
RUN• FWD• REV• • • • • • • • • • • • • • • • • • • •	Displays a parameter value.
RUN• FWD• REV• • • • • • • • • • • • • • • • • • •	Displays an external fault.
RUN•	Displays "End" for approximately one second if the data has been accepted
rev. COO.	and automatically stored in the register.
RUN • • STOP	Displays if the setting data is not accepted or data value exceeds the
	allowed range.



Chapter 3 Operation panel description and test run | EL-C

3-2 Operation mode

To select digital operator, external control terminal, RS-485 communication or CANopen communication by Pr.00-20 and 00-21.




- A: Digital keypad
- **B:** Control terminals
- C: CAN Connect 1 (RJ45)
- D: CAN Connect 2 (RJ45)

Operation mode	Operation Command							
Digital Keypad Pr.00-20 = 0	Figure 3-1 RUN, STOP / RESET as shown in the figure							
External control terminal Pr.00-20 = 1	FWD/STOP MI1 ON: STOP, OFF: RUN (Forward) REV/STOP MI2 ON: STOP, OFF: RUN (Reverse) MI3 Multi-function terminal DCM Figure 3-2							
	The default is NPN mode, MI1-DCM short-circuit is forward / stop, and MI2-							
	DCM short-circuit is reverse / stop (default). Refer to Pr.02-00 in Chapter 6 Parameter Description for forward / reverse running direction.							
RS-485 communication Pr.00-20 = 2	Refer to Group 09 RS-485 Communication Related Parameters in Chapter 6.							
CANopen communication Pr.00-20 = 3 (default)	Refer to Chapter 5 CANopen communication applications for details.							

3-3 Test run

The default of this product is to perform test run on the digital operation panel, as follows:

- ☑ After turning on the power, confirm the digital keypad LED displays the frequency F 60.0 Hz.
- ☑ To modify the frequency command source (Pr.00-20) and the running command source (Pr.00-21) to 0 first, which means digital keypad operation.
- Press key to set the low frequency around 5 Hz.(Refer to Figure 3-3)
- ☑ To switch from forward to reverse: keep pressing MODE key to select FWD, then press the up or down key to select REV, the switch is completed.



☑ Check whether the motor rotation direction is correct and meets the user's needs; whether the motor rotates smoothly (no abnormal noise and vibration); whether the acceleration / deceleration is smooth.

If there is no abnormal situation, increase the operating frequency and continue the test run. After the above test run with no abnormal condition, the motor can be officially put into operation.

Then modify the settings of Pr.00-20 and 00-21 according to the required frequency and operation command source.

Schematic diagram of the running direction of the motor

When the AC drive output terminals U/T1, V/T2, and W/T3 are connected to the motor terminals U/T1, V/T2, and W/T3 respectively, the FWD LED indicator on the digital keypad is ON. This means the AC motor drive executes running forward, and the motor rotation direction (viewed from the shaft end of the motor) as shown in the figure below. On the contrary, when the REV LED indicator lights, the AC motor drive executes running in reverse, and the motor rotates in an opposite direction to the figure below. If the AC motor drive executes running forward but the motor rotates in a reverse direction, exchange any two of the U/T1, V/T2 and W/T3 motor leads.




Figure 3-4

Chapter 4 Specification

- 4-1 230V 1φ Models
- 4-2 460V 3φ Models
- 4-3 General Specifications
- 4-4 Environmental Specifications
- 4-5 Operating ambient temperature and Carrier Derating

Chapter 4 Specification | EL-C

VFD-EL-C series includes 230V and 460V models. The 230V model is single-phase model, and the 460V model is three-phase model. Please refer to the following specification table.

4-1 230V 1φ Models

ľ		002	004	007	015	022				
Applical	ble Motor Output (kW)	0.2	0.4	0.75	1.5	2.2				
Applicable Motor Output (HP)		0.25	0.5	1.0	2.0	3.0				
	Rated Output Capacity (kVA)	0.6	1.0	1.6	2.9	4.2				
	Rated Output Current (A)	1.6	2.5	4.2	7.5	11.0				
Output	Max. Output Voltage (V)	Three-phase corresponding input voltage								
	Output Frequency (Hz)	0.1–400 Hz								
	Carrier Frequency (kHz)	2–9 kHz (Default: 2 kHz)								
	Input Current (A)	4.9	6.5	9.3	15.7	24.0				
المعادية	Rated Voltage, Frequency	One-phase 200–240 V, 50 / 60 Hz								
Input	Voltage Range	±10% (180–264 V)								
	Frequency Range (Hz)	±5% (47–63 Hz)								
Cooling Method		C	onvective cooli	ng	Fan c	ooling				
	Weight (kg)	1.0	1.0	1.0	1.4	1.4				

Table 4-1

4-2 460V 3φ Models

ſ		004	007	015	022	040	055			
Applicable Motor Output (kW)		0.4	0.75	1.5	2.2	4.0	5.5			
Applical	ble Motor Output (HP)	0.5	1.0	2.0	3.0	5.5	7.5			
	Rated Output Capacity (kVA)	1.2	2.0	3.3	4.4	7.4	10.4			
	Rated Output Current (A)	1.5	2.5	4.2	5.5	9.0	13			
Output	Max. Output Voltage (V)	Three-phase corresponding input voltage								
	Output Frequency (Hz)	0.1–400 Hz								
	Carrier Frequency (kHz)	2–9 kHz (Default: 2 kHz)								
	Input Current (A)	1.8	3.2	4.3	7.1	10.0	17.0			
last	Rated Voltage, Frequency	Three-phase 380–480 V, 50 / 60 Hz								
Input	Voltage Range	±10% (342–528 V)								
	Frequency Range (Hz)	±5% (47–63 Hz)								
	Cooling Method		/e cooling		Fan c	ooling				
	Weight (kg)	1.0	1.0	1.0	1.4	1.4	1.5			

Table 4-2

4-3 General Specifications

	Performance	Descriptions
	Control Method	Sine wave PWM method / (V/F control)
	Frequency Setting Resolution	0.01Hz
	Output Frequency Resolution	0.01Hz
C	Torque	Torque compensation and slip compensation, reach 150% of the rated torque at 5.0 Hz
ontro	Overload Capability	150% of rated output current for 60 seconds
S Ch	Skip Frequency	3 points can be set from 0.1–400.0 Hz
Control Characteristics	Acceleration and Deceleration Time	0.1–600 seconds (2-stage acceleration / deceleration time can be set independently)
istics	Stall Prevention	The motor load characteristics can be set at 0–200% of the drive's rated current
	DC Brake	When stopped, it can operate from 0.1–400.0 Hz, the braking current is 0–100% of the rated current, the starting time is 0–60 seconds, and the stopping time is 0–60 seconds
	V/F Curve	Arbitrary V/F curve setting
	Protection	Overvoltage, overcurrent, low voltage, external abnormal interruption, motor overload, drive overload, drive overheating
	Built-in function	Built-in automatic voltage regulator output regulation Acceleration / deceleration S-curve setting Overvoltage and overcurrent stall prevention Fault record Disable reverse Restart after momentary power loss DC brake Torque offset Slip compensation Carrier frequency adjust Output frequency upper and lower limit settings Parameter reset External count Fault reset Restart after fault Energy-saving operation NPN / PNP mode selection
	Digital Keypad	Contains 6 function keys, 4-digit 7-segment LED display, 4 LED status indicators, settable frequency, display actual output frequency, output current, user-defined position, parameter browsing and modification settings and parameter locking, abnormal fault display, execute run, stop, reset, forward / reverse.

4-4 Environment

Perf	ormance	Descriptions					
	Protection Rating	IP20					
	Degree of						
	environmental	2					
	pollution						
	Location	Altitude below 1000 m, indoors (no corrosive gas, liquid, no dust)					
	Operation	No condensation and no icing					
Environment	Temperature	-10°C-+50°C NOTE 1					
	Storage	-20°C–+60°C					
	Temperature						
	Humidity	Below 90% RH (no condensation)					
		1.0 mm, peak to peak value range from 2–13.2 Hz; 0.7–1.0 G range					
	Vibration	from 13.2–55 Hz; 1.0 G range from 55–512 Hz. Compliance with IEC					
		6006826					
Cert	ifications	CE, RoHS, GB 12668.3					

Table 4-4

NOTE:

VFD007EL21C must be installed with fan accessories to reach 50°C the upper limit of the operating temperature. All EL-C series are installed closely side by side, and the upper limit of the operating temperature is +40°C.

4-5 Operating ambient temperature and Carrier Derating

Operating Environment Temperature Derating Curve




Table 4-5

Derating Curve for Carrier Frequency






Table 4-6

Model	Carrier frequency limit
VFD007EL21C	When the ambient temperature is 40°C, the carrier frequency needs to be set within 8 kHz when operating at rated current. When the carrier frequency needs to be higher than 8 kHz, the rated current needs to be reduced 5% for every 1 kHz increase, and the maximum carrier frequency can be up to 9 kHz.
Other models of EL-C series ^{NOTE 1}	When the ambient temperature is 50°C, the carrier frequency needs to be set within 8 kHz when operating at rated current. When the carrier frequency needs to be higher than 8 kHz, the rated current needs to be reduced 5% for every 1 kHz increase, and the maximum carrier frequency can be up to 9 kHz.

NOTE:

When the VFD007EL21C is installed with the fan assembly MKEL-AFKM1, the specifications are the same as other models.

Chapter 5 CANopen Overview

- 5-1 CANopen Overview
- 5-2 Wiring for CANopen
- 5-3 CANopen Communication Interface Descriptions
- 5-4 CANopen Supported Index
- 5-5 CANopen Fault Codes
- 5-6 CANopen LED Function

Chapter 5 CANopen Overview | EL-C

The built-in CANopen function is a kind of remote control. You can control the AC motor drive using the CANopen protocol. CANopen is a CAN-based higher layer protocol that provides standardized communication objects, including real-time data (Process Data Objects, PDO), configuration data (Service Data Objects, SDO), and special functions (Time Stamp, Sync message, and Emergency message). It also has network management data, including Boot-up message, NMT message, and Error Control message. Refer to the CiA website http://www.can-cia.org.

Delta CANopen supported functions:

- Supports CAN2.0A Protocol
- Supports CANopen DS301 V4.02
- Supports DSP-402 V2.0

Delta CANopen supported services:

- PDO (Process Data Objects): PDO1–PDO4
- SDO (Service Data Objects): Initiate SDO Download; Initiate SDO Upload; Abort SDO;

You can use the SDO message to configure the slave node and access the Object Dictionary in every node.

- SOP (Special Object Protocol): Supports default COB-ID in Predefined Master/Slave Connection Set in DS301 V4.02; Supports SYNC service; Supports Emergency service.
- NMT (Network Management): Supports NMT module control; Supports NMT Error control; Supports Boot-up.


Delta CANopen does not support this service:

Time Stamp service

5-1 CANopen Overview

CANopen Protocol

CANopen is a CAN-based higher layer protocol, and was designed for motion-oriented machine control networks such as handling systems. CANopen 301 (Version 4.02) is standardized as EN50325-4. The CANopen specifications cover the application layer and communication profile (CiA DS301), as well as a framework for programmable devices (CiA DS302), recommendations for cables and connectors (CiA DS303-1) and SI units and prefix representations (CiA DS303-2).




PIN	Signal	Fault Descriptions
1	CAN_H	CAN_H bus line (dominant high)
2	CAN_L	CAN_L bus line (dominant low)
3	CAN_GND	Ground / 0 V / V-

CANopen Communication Protocol contains the following services:

- NMT (Network Management Object)
- SDO (Service Data Objects)
- PDO (Process Data Objects)
- EMCY (Emergency Object)

NMT (Network Management Object)

The Network Management (NMT) follows a Master/Slave structure for executing NMT service. A network has only one NMT master, and the other nodes are slaves. All CANopen nodes have a present NMT state, and the NMT master can control the state of the slave nodes. The following shows the state diagram of a node:



(1) After power is applied, start in the auto-initialization state

- (2) Automatically enter the pre-operational state
- (3) (6) Start remote node
- (4) (7) Enter the pre-operational state
- (5) (8) Stop remote node
- (9) (10) (11) Reset node
- (12) (13) (14) Reset communication
- (15) Automatically enter the reset application state
- (16) Automatically enter the reset communication state

	Initializing	Pre-Operational	Operational	Stopped
PDO			0	
SDO		0	0	
SYNC		0	0	
Time Stamp		0	0	
EMCY		0	0	
Boot-up	0			
NMT		0	0	0

- A: NMT B: Node Guard C: SDO
- D: Emergency
- E: PDO
- F: Boot-up

SDO (Service Data Objects)

Use SDO to access the Object Dictionary in every CANopen node using the Client/Server model. One SDO has two COB-IDs (request SDO and response SDO) to upload or download data between two nodes. There is no data limit for SDOs to transfer data, but it must transfer data by segment when the data exceeds four bytes with an end signal in the last segment. However, EL-C series does not support transferring data by segment.

The Object Dictionary (OD) is a group of objects in a CANopen node, and every node has an OD in the system. An OD contains all parameters describing the device and its network behavior. The access path in the SOD is the index and sub-index. Each object has a unique index in the OD, and has a subindex if necessary.

					Dat	a 0				Data 1	Data 2	Data 3	Data 4	Data 5	Data 6	Data 7
Туре		7	6	5	4	3	2	1	0	Index	Index	Index	Data	Data	Data	Data
		со	mma	ind						L	Н	Sub	LL	LH	HL	HH
Domain	Client	0	0	1	1	Z		Е	s							
Download	Server	0	1	1	1	I	I	-	-							
Demoin Unload	Client	0	1	0	1	I	I	-	-							
Domain Upload	Server	0	1	0	1	Ζ		Е	S							
Abort Domain	Client	1	0	0	-	-	-	-	-							
Transfer	Server	1	0	0	-	-	-	-	-							

N: Bytes not used; E: normal (0) / transferred (1); S: data size

PDO (Process Data Objects)

PDO communication can be described by the producer/consumer model. Each node of the network listens to the messages of the transmission node and distinguishes whether the message has to be processed or not after receiving the message. A PDO can be transmitted from one device to one another device or to many other devices. Every PDO has two PDO services: a TxPDO (transmitting) and an RxPDO (receiving). All transmission types are listed in the following table

			PDO		
Type Number	Cyclic	Acyclic	Synchronous	Asynchronous	RTR only
0		0	0		
1–240	0		0		
241–251			Reserved		
252			0		0
253				0	0
254				0	
255				0	

• Type number 0 indicates acyclic SYNC message between two PDO transmissions.

- Type number 1–240 indicates the number of SYNC message between two PDO transmissions.
- Type number 252 indicates the data is updated (but not sent) immediately after receiving SYNC.
- Type number 253 indicates the data is updated immediately after receiving RTR.
- Type number 254: Delta CANopen does not support this transmission format.
- Type number 255 indicates the data is an asynchronous transmission.


All PDO transmission data must be mapped to the index with Object Dictionary.

EMCY (Emergency Object)

When errors occur inside the hardware, an emergency object is triggered. An emergency object is only sent when an error occurs. As long as there is nothing wrong with the hardware, there is no emergency object warning of an error message.

5-2 Wiring for CANopen

CANopen wiring of the EL-C drive does not require a Hub. The connector from the drive adopts the two-way RJ45 with one-in and one-out. You must wire the two farthest ends with 120 Ω terminating resistors as shown in the picture below.



NOTE:

According to the EL-C EMS test results, it is recommended to insert the terminal resistor into the left RJ45 and the CAN cable into the right RJ45 for better communication immunity performance.

5-3 CANopen Communication Interface Descriptions

5-3-1 Control Method

There are two control modes for CANopen: the DS402 standard (Pr.09-40=1) is the default, and the Delta's standard setting (Pr.09-40=0). There are two control modes according to Delta's standard. One is the old control mode (Pr.09-30=0); this control mode can only control the motor drive under the frequency control. The other mode is a new standard (Pr.09-30=1); this new control mode allows the motor drive to be controlled under all kinds of modes. The EL-C currently supports the speed mode. For torque, position and home mode, refer to MH300 series.

CANlenen	Contro	I Mode			
CANopen Control Mode Selection	Speed				
	Index	Descriptions			
DS402 Standard	6042-00	Target rotating speed (rpm)			
Pr.09-40=1					
Delta Standard (Old definition) Pr.09-40=0, Pr.09-30=0	2020-02	Target rotating speed (Hz)			
Delta Standard (New definition)	2060-03	Target rotating speed (Hz)			
Pr.09-40=0, Pr.09-30=0	2060-04	Torque limit (%)			

CANopen	Operation Control					
Control Mode Selection	Index	Descriptions				
DS402 Standard	6040-00	Operation Command				
Pr.09-40=1						
Delta Standard (Old definition) Pr.09-40=0, Pr.09-30=0	2020-01	Operation Command				
Delta Standard	2060-01	Operation Command				
(New definition EL-C series) Pr.09-40=0, Pr.09-30=0						

CANopen	Oth	ners
Control Mode Selection	Index	Descriptions
DS402 Standard	605A-00	Quick stop processing mode
Pr.09-40=1	605C-00	Disable operation processing mode
Delta Standard (Old definition) Pr.09-40=0, Pr.09-30=0		
Delta Standard		
(New definition EL-C series) Pr.09-40=0, Pr.09-30=0		

You can use some indexes in either DS402 or Delta's standard when:

- 1. 1. Indexes that are defined as RO attributes.
- 2. Parameters Mapping Index (2000-00~200B-XX)
- 3. Acceleration/Deceleration Index: 604F 6050

5-3-2 DS402 Standard Control Mode

5-3-2-1 Related settings for an AC motor drive (following the DS402 standard)

If you want to use the DS402 standard to control the motor drive, follow these steps:

1. Wire the hardware (refer to Section 5-2 Wiring for CANopen).

you finish the station setting, set Pr.00-02 = 7 to reset.

- Set the operation source: set Pr.00-21 to 3 for CANopen communication card control. Set the operation command source to CANopen settings (Run/stop, forward/reverse running, etc.).
- 3. Set the frequency source: set Pr.00-20 to 6. Choose the source for the Frequency command from the CANopen setting.
- 4. Set DS402 as the control mode: Pr.09-40=0
- Set the CANopen station: set Pr.09-36; the range is between 1–127. When Pr.09-36 = 0, the CANopen slave function is disabled.
 Note: If an error appears (station address error CAdE or CANopen memory error CFrE) when
- 6. Set the CANopen baud rate: set Pr.09-37 (CANBUS baud rate: 1 M (0), 500 K (1), 250 K (2), 125 K (3), 100 K (4) and 50 K (5))
- Set the multiple input functions to Quick Stop. You can also choose to enable or disable; the default setting is disabled. If it is necessary to enable the function, set MI terminal to 53 in one of the following parameters: 02-01–02-08 or Pr.02-26–02-31. Note that this function is available in DS402 only.

5-3-2-2 The status of the motor drive (following the DS402 standard)

According to the DS402 definition, the motor drive is divided into 3 blocks and 9 statuses as described below.

3 blocks

Power Disable: without PWM output

Power Enable: with PWM output

Fault: one or more errors have occurred.

9 statuses

Start: power on

Not Ready to Switch On: the motor drive is initiating.

Switch On Disable: occurs when the motor drive finishes initiating.

Ready to Switch On: warning up before running.

Switch On: the motor drive has the PWM output, but the reference command is not effective. Operation Enable: able to control normally.

Quick Stop Active: when there is a Quick Stop request, stop running the motor drive.

Fault Reaction Active: the motor drive detects conditions which might trigger error(s).

Fault: one or more errors have occurred in the motor drive.

When the motor drive turns on and finishes the initiation, it remains in Ready to Switch On status. To control the operation of the motor drive, change to Operation Enable status. To do this, set the control word's bit0–bit3 and bit7 of the Index 6040H and pair with Index Status Word (Status Word 0X6041). The control steps and index definition are described below.

Index 6040:

IIIUEX U															
15–9)		8		7	6–4			3		2		1		0
Reserv	red		Halt	Faul	t Reset	Operat	tion	Ena oper	able atior			pp Enable Voltage		Switch On	
Index 6			-	-	-		-								
15–14	13–	12	11	10	9	8	7	6	5	5	4	3	2	1	0
Reserved	Opera	ition	Internal limit active	Target reached	Remote	Reserved	Warning	Swite disa		Quick stop	Voltage enabled	Fault	Operation enable	Switch on	Ready to switch on
		D	ower								•				
			isable	•	St	tart				Fau	lt React	ion Ac	tive		
											X0XX	(1111			
				Not	Ready	• to Switcl	h On								
						X0000					Fa	ult			
				L]				X0XX	1000			
					, witch C	↓)n Disab						≜ XXX	XXXX		
			xxxxx	▶		X0000	le ∢								
						•									
				0XX>	(X110	0XXX or	XX0X								
			Die	able QS	and top=1	0XXXX or	X01X								
			013				le QSto	p=0							
				Re	eady to	Switch (Dn		0XX	XXXO	X				
					X01>	K0001			or	(XX01			Fault		
				0XXX	(X111	oxxx>	<110		or						
					▼ Swit	L ch On			Disa	able Q	Stop=0		ower		
						K0011]					nable		
					(1111	1 0xxxx		0.V.V.V	VOA				XX0X or		
			0XXX					0XXX o	r			Fou			
				C	-	on Enabl	e Dis	sable (1210	→ (Quick St		tive		
					X01>	K0111		0XXX aı	X01) nd	x	X00>	<0111			
							Di	sable		p=1					

Set command 6040 = 0xE, and then set another command 6040 = 0xF. Then you can switch the motor drive to Operation Enable. The Index 605A determines the direction of the lines from Operation Enable when the control mode changes from Quick Stop Active. When the setting value is 1–3, both direction lines are active, but when the setting value of 605A is not 1–3, once the motor drive is switched to Quick Stop Active, it is not able to switch back to Operation Enable.

Chapter 5 CANopen Overview | EL-C

Index	Sub	Definition	Default	R/W	Size	Unit	PDO Map	Mode	Note
605Ah	0	Quick stop option code	2	RW	S16	6	No		0: Disable drive function 1: Slow down on slow down ramp 2: Slow down on quick stop ramp 5: Slow down on slow down ramp and stay in QUICK STOP
									6: Slow down on quick stop ramp and stay in QUICK STOP
									7: Slow down on the current limit and stay in Quick stop

When the control block switches from Power Enable to Power Disable, use 605C to define the stop method.

Index	Sub	Definition	Default	R/W	Size	Unit	PDO Map	Mode	Note
605Ch	0	Disable operation option code	1	RW	S16		No		0: Disable drive function 1: Slow down with slow down ramp; disable the drive function

5-3-2-3 Various mode control method (following the DS402 standard)

EL-C supports the speed control mode. The speed control mode is described below.

- 1. Set EL-C to the speed control mode: set Index6060 to 2.
- 2. Switch the mode to Operation Enable: Index 6040 can run at 0Hz by first assigning 0x7E and then 0x7F.
- 3. Set the target frequency: set target frequency for 6042. Since the operation unit of 6042 is rpm, a conversion is required.

$$n = f \times \frac{120}{p}$$

n: rotation speed (rpm) (revolutions/minute)


P: number of poles of the motor (Pole)

f: rotation frequency (Hz)

For example: Set 6042H = 1500 (rpm), if the number of poles for the drive is 4 (Pr.05-04, Pr.05-16, Pr.05-67 or Pr.05-73), then the motor drive's operation frequency is 1500 (120/4) = 50 Hz. The 6042 is defined as a signed operation. The plus or minus sign means to rotate clockwise or counter-clockwise.

- 4. To stop running: Index 6040 assign 0x7E.
- 5. To set acceleration and deceleration: use 604F (Acceleration) and 6050 (Deceleration).
- 6. Fault alarm and reset: It can be judged by whether Index 6041 bit 3 is 1, and the fault type can be judged by the specific value of Index 603F (for details, please refer to DS302 / 402 CANopen Error Code Definition). The panel alarm can be reset by assigning H0 first and then H80 through Index 6040.
- Trigger an ACK signal: in the speed control mode, control the bit 6–4 of Index 6040.
 It is defined below.

		Index 6040		SUM		
Chood Mode	bit 6	bit 5	bit 4	30M		
Speed Mode	1	0	1	Locked at the current frequency.		
(Index 6060 = 2)	1	1	1	Run to reach the target frequency.		
		Others		Decelerating to 0 Hz.		



NOTE:

- 1. Read 6043 to get the current rotation speed (unit: rpm)
- Read bit 10 of 6041 to check if the rotation speed has reached the targeting value (0: Not reached; 1: Reached).

5-3-3 Using the Delta Standard (Old definition, only supports speed mode)

5-3-3-1 Related settings for an AC motor drive (following the Delta old standard)

If you want to use the Delta old standard to control the motor drive, follow these steps:


- 1. Wire the hardware (refer to Section 5-2 Wiring for CANopen).
- 2. Set the operation source: set Pr.00-21 to 3 for CANopen communication card control. Set the operation command source to CANopen settings (Run/stop, forward/reverse running, etc.).
- 3. Set the frequency source: set Pr.00-20 to 6. Choose the source for the Frequency command from the CANopen setting.
- 4. Set Delta Standard (Old definition, only supports speed mode) as the control mode: Pr.09-40
 = 0 and Pr.09-30 = 0.
- 5. Set the CANopen station: set Pr.09-36; the range is between 1–127. When Pr.09-36=0, the CANopen slave function is disabled.

Note that if an error appears (station address error CAdE, CANopen memory error CFrE, or index value error CIdE) when you finish the station setting, set Pr.00-02 = 7 to reset.

Set the CANopen baud rate: set Pr.09-37 (CANBUS baud rate: 1 M (0), 500 K (1), 250 K (2), 125 K (3), 100 K (4) and 50 K (5))

5-3-3-2 The control method under speed mode

- 1. Set the target frequency: set 2020-02, the unit is Hz, with 2 decimal places. For example, 1000 is 10.00 Hz.
- 2. Operation control: set 2020-01 = 0002H for running, and set 2020-01 = 0001H for stopping.



5-3-4 Using Delta Standard (New Definition)

5-3-4-1 Related settings for an AC motor drive (following the Delta new standard)

If you want to use the Delta old standard to control the motor drive, follow these steps:

- 1. Wire the hardware (refer to Section 5-2 Wiring for CANopen).
- 2. Set the operation source: set Pr.00-21 to 3 for CANopen communication card control. Set the operation command source to CANopen settings (Run/stop, forward/reverse running, etc.).
- 3. Set the frequency source: set Pr.00-20 to 6. Choose the source for the Frequency command from the CANopen setting.
- 4. Set Delta Standard (New definition) as the control mode: Pr.09-40 = 0 and 09-30 = 1.
- 5. Set the CANopen station: set Pr.09-36; the range is between 1–127. When Pr.09-36=0, the CANopen slave function is disabled.


Note: If an error appears (station address error CAdE or CANopen memory error) when you finish the station setting, set Pr.00-02 = 7 to reset.

Set the CANopen baud rate: set Pr.09-37 (CANBUS baud rate: 1 M (0), 500 K (1), 250 K (2), 125 K (3), 100 K (4) or 50 K (5)).

5-3-4-2 Various mode control method (Delta New Standard)

Speed Mode

- 1. Set EL-C to speed control mode: set index 6060 = 2.
- 2. Set the target frequency: set 2060-03, unit is Hz, with 2 decimal places. For example, 1000 is 10.00 Hz.
- 3. Operation control: set 2060-01 = 008H for server on, and set 2060-01 = 0081H for running.



5-3-5 Control DI/DO by CANopen

To control the DO of the motor drive through CANopen, follow these steps:

- Define the DO to be controlled by CANopen.
 For example, set Pr.02-13-02-16 = 50 to control MO1-MO4.
- 2. Control the Index mapped by CANopen.

To control DO by setting Index 2026-41 = 1, to control MO1 into ON by setting bit 0 of Index 2026-41 = 1, then MO1 outputs 1.

The mapping table of the CANopen DI/DO is shown in the following table:

DI:

Terminal	Related Parameters	Attribute	Mapping Index	
MI1	==	RO	2026-01 bit 0	
MI2	==	RO	2026-01 bit 1	
MI3	==	RO	2026-01 bit 2	
MI4	==	RO	2026-01 bit 3	
MI5	==	RO	2026-01 bit 4	
MI6	==	RO	2026-01 bit 5	

DO:

Terminal	Related Parameters	Attribute	Mapping Index
MO1	Pr.02-13 = 50	RW	bit 0 of 2026-41 initial value 0x01
MO2	Pr.02-14 = 50	RW	bit 1 of 2026-41 initial value 0x01
MO3	Pr.02-15 = 50	RW	bit 2 of 2026-41 initial value 0x01
MO4	Pr.02-16 = 50	RW	bit 3 of 2026-41 initial value 0x01

5-4 CANopen Supported Index

EL-C Supported Parameter Index:

The parameter index corresponds as shown in this example:

Index	sub-Index	
2000H + Grou	member+1	
For example: I	.10-15 (Encoder Stall and Slip Error Actior	ר)
Group	member	
10(0AH)	- 15(0FH)	

10(0AH) - 15(0FH) Index = 2000H + 0AH = 200A Sub-Index = 0FH + 1H = 10H

EL-C Supported Control Index:

Delta Standard Mode (Old Definition)

Index	Sub	Definition	Defa ult	R/W	Size		Note
	0	Number	3	R	U8		
						bit 1–0	00B: No function
							01B: Stop
							10B: Run
							11B: JOG + RUN
						bit 3–2	Reserved
						bit 5–4	00B: No function
							01B: FWD direction
							10B: REV direction
							11B: Change direction
						bit 7–6	00B: 1st step accel./decel.
							01B: 2nd step accel./decel.
							10B: 3rd step accel./decel.
							11B: 4th step accel./decel.
						bit 11–8	0000B: Master speed
							0001B: 1st step speed
							0010B: 2nd step speed
							0011B: 3rd step speed
							0100B: 4th step speed
2020H							0101B: 5th step speed
20201	1	Control word	0	RW	U16		0110B: 6th step speed
							0111B: 7th step speed
							1000B: 8th step speed
							1001B: 9th step speed
							1010B: 10th step speed
							1011B: 11th step speed
							1100B: 12th step speed
							1101B: 13th step speed
							1110B: 14th step speed
							1111B: 15th step speed
						bit12	1: Enable the function of bit 06-
						DILTZ	11
							00B: No function
							01B: Operation command by th
						bit 14–13	digital keypad
							10B: Operation command by
							Pr.00-21 setting
							11B: Switch the operation
							command source
						bit15	Reserve

Index	Sub	Definition	Defa ult	R/W	Size		Note
-	2	Frequency command (XXX.XX Hz)	0	RW	U16		
						bit 0	1: E.F. (External Fault) ON
			~		140	bit 1	1: Reset command
	3	Other trigger	0	RW	U16	bit 2	1: Base Block (B.B) ON
						bit153	Reserve
2021H	0	Number	10	R	U8		
	1	Error code	0	R	U16		Warning Code
							Error Code
	2	AC motor drive status	0	R	U16	bit 1–0	00B: The drive stops
							01B: The drive is decelerating
							10B: The drive is in standby
							status
						1.11.0	11B: The drive is operating
						bit 2	1: JOG command
						bit 4–3	00B: FWD running
							01B: From REV running to FWD running
							10B: From FWD running to REV
							running
							11B: REV running
						bit 7–5	Reserved
						bit 8	1: Master frequency controlled
						Dit 0	by the communication interface
						bit9	1: Master Frequency command
							controlled by analog signal input
						bit10	1: Operation command
							controlled by the communication
							interface
						bit11	1: Parameter lock
						bit12	1: Enable the digital keypad
							copy parameter function
			•	-	1140	bit 15–13	Reserved
	3	Frequency command (XXX.XX Hz)	0	R	U16		
	4	Output frequency (XXX.XX Hz)	0	R	U16		
	5 6	Output current (XX.X A)	0	R R	U16 U16		
	7	DC bus voltage (XXX.X V) Output voltage (XXX.X V)	0	R	U16		
		The current step run by the multi-	0				
	8	step speed command	0	R	U16		
	9	Reserved	0	R	U16		
	A	Display counter value (c)	0	R	U16		
	B	Output power factor angle (XX.X°)	0	R	U16		
	C	Output torque (XX.X%)	0	R	U16		
	D	Motor speed (rpm)	0	R	U16		
	Е	Reserve					
	F	Reserve					
	10	Output power (X.XXX kW)	0	R	U16		
	17	Multi-function display (Pr.00-04)	0	R	U16		
2022H	0	Reserved	0	R	U16		
	1	Display the drive's output current	0	R	U16		
	2	Counter value	0	R	U16		
	3	Actual output frequency	0	R	U16		
		(XXX.XX Hz)					
	4	DC bus voltage	0	R	U16		
	5	Output voltage (XXX.X V)	0	R	U16		
	6	Power factor angle (XX.X°)	0	R	U16		
	7	Display the output power of U, V, W in kW	0	R	U16		

Chapter 5 CANopen Overview | EL-C

Index	Sub	Definition	Defa ult	R/W	Size	Note
	8	Display the motor speed estimated by the drive or encoder feedback in rpm	0	R	U16	
	9	Display the positive / negative output torque estimated by the drive (+0.0: positive torque; -0.0: negative torque)	0	R	U16	
	A	Reserve				
	В	Display the PID feedback value after enabling the PID function in %	0	R	U16	
	С	Display the AVI analog input terminal signal, 0–10 V corresponds to 0.00–100.00% (see Explanation 1 in Pr.00-04)	0	R	U16	
	D	Display the ACI analog input terminal signal, 4–20 mA / 0–10 V corresponds to 0.00–100.00% (2.) (see Explanation 2 in Pr.00-04)	0	R	U16	
	F	IGBT temperature of the power module in oC	0	R	U16	
	11	The digital input status (ON / OFF), refer to Pr.02-12 (see Explanation 2 in Pr.00-04)	0	R	U16	
	12	The digital output status (ON / OFF), refer to Pr.02-18 (see Explanation 3 in Pr.00-04)	0	R	U16	
	13	Current step for the multi-step speed operation	0	R	U16	
	14	The corresponding CPU digital input pin status (d.) (see Explanation 3 in Pr.00-04)	0	R	U16	
	15	The corresponding CPU digital output pin status (O.) (see Explanation 4 in Pr.00-04)	0	R	U16	
	16	Reserved				
	18	Reserved				
	1A	Counter value of overload (0.00–100.00%)	0	R	U16	
	1C	DC bus voltage ripples (Unit: V _{DC}) (r.)	0	R	U16	
	1D	PLC register D1043 data	0	R	U16	
	1E	Magnetic field area of the synchronous motor	0	R	U16	
	1F	User page displays the value in physical measure	0	R	U16	
	20	Output value of Pr.00-05	0	R	U16	
	21	Reserved				
	22	Reserved				
	23	Reserved Control mode of the drive 0:				
	24	speed mode	0	R	U16	
	25	Carrier frequency of the drive	0	R	U16	
	26	Reserved				
	27	AC motor drive status				
	28	Output positive/negative torque of motor drive calculation				
	29	Reserved				
	2A	kWh display				

CANopen Remote IO Mapping

Index	Sub	R/W	Descriptions
	01h	R	Each bit corresponds to different input terminals.
	02h	R	Reserve
	03h–40h	R	Reserve
	41h	RW	Each bit corresponds to different output terminals
2026h	42h-60h	R	Reserve
202011	61h	R	Reserve
	62h	R	Reserve
	63h	R	Reserve
	64h–A0h	R	Reserve
	A1h	RW	Reserved

Index 2026-01	bit 0	bit 1	bit 2	bit 3	bit 4	bit 5	bit 6	bit 7	bit 8	bit 9	bit 10	bit 11	bit 12	bit 13	bit 14	bit 15
DI	MI1	MI2	MI3	MI4	MI5	MI6	-	-	-	-	-	-	-	-	-	-
Index 2026-41	bit 0	bit 1	bit 2	bit 3	bit 4	bit 5	bit 6	bit 7	bit 8	bit 9	bit 10	bit 11	bit 12	bit 13	bit 14	bit 15
DO	MO1	MO2	MO3	MO4	-	-	-	-	-	-	-	-	-	-	-	-

Delta Standard Mode (New Definition)

Index	sub	R/W	Size		Descriptions		Speed Mode
IIIUEX		17/00		bit	Definition	Priority	Speed Mode
	00h	R	U8				
				0	Ack	4	0: fcmd = 0 1: fcmd = Fset (Fpid)
				1	Dir	4	0: FWD command 1: REV command
				2			
				3	Halt	3	0: Drive runs until target speed is reached 1: Drive stops by deceleration setting
	01h	RW	/ U16	4	Hold	4	0: Drive runs until target speed is reached 1: Frequency stops at current frequency
2060h				5	JOG	4	0: JOG OFF Pulse 1: JOG RUN
				6	QStop	2	Quick Stop
				7	Power	1	0: Power OFF 1: Power ON
				8	Ext_md2	4	$0 \rightarrow 1$: Absolute position cleared
				14–9			
				15	RST	4	Pulse 1: Fault code cleared
	02h	RW	U16		Mode Cmd		0: Speed mode
	03h	RW	U16				Speed command (unsigned decimal)
	04h	RW	U16				
	05h	RW	S32				
	06h	RW					
	07h	RW	S16				
	08h	RW	U16				
				0	Arrive		Frequency command reached
00041	041			1	Dir		0: Motor FWD run 1: Motor REV run
2061h	01h	R	U16	2	Warn		Warning occurs
				3	Error		Error detected
				4			

Chapter 5 CANopen Overview | EL-C

Index	sub	R/W	Size		Descriptions		Speed Mode
muex	Sub	Γ./ ٧ V	SIZE	bit	Definition	Priority	Speed Mode
				5	JOG		JOG
				6	QStop		Quick stop
				7	Power On		Switch ON
				15–8			
	02h	R					
	03h	R	U16				Actual output frequency (XXX.XX Hz)
	04h	R					
	05h	R	S32				Actual position (absolute)
	06h	R					
	07h	R	S16				Actual torque

DS402 Standard

Index	Sub	Definition	Default	R/W	Size	Unit	PDO Map	Mode	Note
6007h	0	Abort connection option code	2	RW	S16		Yes		0: No action 2: Disable voltage 3: Quick Stop
603Fh	0	Error code	0	RO	U16		Yes		· · · · ·
6040h	0	Control word	0	RW	U16		Yes		
6041h	0	Status word	0	RO	U16		Yes		
6042h	0	velocity mode target velocity	0	RW	S16	rpm	Yes	vl	
6043h	0	velocity mode velocity demand	0	RO	S16	rpm	Yes	vl	
6044h	0	velocity mode control effort	0	RO	S16	rpm	Yes	vl	
604Fh	0	velocity mode ramp function time	10000	RW	U32	1ms	Yes	vl	The minimum unit is 100 ms. For example, when it is set to 290 ms, it
6050h	0	velocity mode slow down time	10000	RW	U32	1ms	Yes	vl	is regarded as 200 ms. When it is set to 10301 ms, it is regarded as 10300
6051h	0	velocity mode quick stop time	1000	RW	U32	1ms	Yes	vl	ms. In addition, it cannot be set to zero.
605Ah	0	Quick stop option code	2	RW	S16		No		0: Disable drive function 1: Slow down on slow down ramp 2: Slow down on quick stop ramp 5: Slow down on slow down ramp and stay in QUICK STOP 6: Slow down on quick stop ramp and stay in QUICK STOP
605Ch	0	Disable operation option code	1	RW	S16		No		0: Disable drive function 1: Slow down with slow down ramp; disable the drive function
6060h		Mode of operation	2	RW	S8		Yes		2: Velocity mode
6061h	0	Mode of operation display	2	RO	S8		Yes		Same as above

5-5 CANopen fault code

- ☑ Refer to settings for Pr.06-17–Pr.06–22 and Pr.12-70–Pr.12-73
- ☑ Refer to Chapter 08 Fault Codes for detailed descriptions.

ID*	Display	Fault code	Fault Descriptions	CANopen fault register (bit 0–7)	DS302 / 402 CANopen Fault Codes
1	oc R	0001H	Over-current during acceleration (ocA)	1	2213H
2	ocd	0002H	Over-current during deceleration (ocd)	1	2213H
3	ocn	0003H	Over-current during steady operation (ocn)	1	2314H
6	oc S	0006H	Over-current at stop (ocS)	1	2314H
7	oūR	0007H	Over-voltage during acceleration (ovA)	2	3210H
8	متم	0008H	Over-voltage during deceleration (ovd)	2	3210H
9	oun	009H	Over-voltage during constant speed (ovn)	2	3210H
10	oūS	000AH	Over-voltage at stop (ovS)	2	3210H
11	108	000BH	Low-voltage during acceleration (LvA)	2	3220H
12	Lūd	000CH	Low-voltage during deceleration (Lvd)	2	3220H
13	Lūn	000DH	Low-voltage at constant speed (Lvn)	2	3220H
14	LŪS	000EH	Low-voltage at stop (LvS)	2	3220H
15	orP	000FH	Phase loss protection (orP)	2	3130H
16	oX¦	0010H	IGBT overheating (oH1)	3	4310H
18	2X 10	0012H	IGBT temperature detection failure (tH1o)	3	FF00H
21	οL	0015H	Over load (oL)	1	2310H
22	Eot /	0016H	Electronic thermal relay protection 1 (EoL1)	1	2310H
26	οt /	001AH	Over torque 1 (ot1)	3	8311H
28	υί	001CH	Under current (uC)	1	8321H
31	623 م	001FH	EEPROM read error (cF2)	5	5530H
33	cd i	0021H	U-phase error (cd1)	1	FF04H
34	c d 2	0022H	V-phase error (cd2)	1	FF05H
35	cd3	0023H	W-phase error (cd3)	1	FF06H
36	890 89	0024H	cc hardware error (Hd0)	5	FF07H
37	Xd	0025H	oc hardware error (Hd1)	5	FF08H
49	۶۶	0031H	External fault (EF)	5	9000H
50	881	0032H	Emergency stop (EF1)	5	9000H

Chapter 5 CANopen Overview | EL-C

ID*	Display	Fault code	Fault Descriptions	CANopen fault register (bit 0–7)	DS302 / 402 CANopen Fault Codes
51	66	0033H	External base block (bb)	5	9000H
52	Pcod	0034H	Password is locked (Pcod)	5	FF26H
54	133	0036H	Illegal command (CE1)	4	7500H
55	533	0037H	Illegal data address (CE2)	4	7500H
56	683	0038H	Illegal data value (CE3)	4	7500H
57	[2 4	0039H	Data is written to read-only address (CE4)	4	7500H
58	0:33	003AH	Modbus transmission time-out (CE10)	4	7500H
62	959	003EH	Deceleration energy backup error (dEb)	2	FF27H
79	Roc	0050H	U-phase over-current before run (Aoc)	1	FF2BH
80	boc	0051H	V-phase over-current before run (boc)	1	FF2CH
81	coc	0050H	W-phase over-current before run (coc)	1	FF2DH
82	oPL 1	0052H	Output phase loss U phase (OPHL)	2	2331H
83	0962	0053H	Output phase loss V phase (OPH2)	2	2332H
84	oPt3	0054H	Output phase loss W phase (OPH3)	2	2333H
87	ol 3	0057H	87: Low frequency overload protection (oL3)	0	8A00H
101	3633	0065H	CANopen guarding error (CGdE)	4	8130H
102	588S	0066H	CANopen heartbeat error (CHbE)	4	8130H
104	5965	0068H	CANopen bus off error (CbFE)	4	8140H
105	3633	0069H	CANopen index error (CidE)	4	8100H
106	3683	006AH	CANopen station address error (CAdE)	4	8100H
107	[FrE	006BH	CANopen index setting exceed limit (CFrE)	4	8100H
111	ict8	006FH	InrCOM time-out error (ictE)	4	7500H
121	6650	007AH	Internal communication error (CP20)	7	FF36H
123	5543	007CH	Internal communication error (CP22)	7	FF38H
124	5643	007DH	Internal communication error (CP30)	7	FF39H
126	6635	0080H	Internal communication error (CP32)	7	FF3BH
127	[P33	0081H	Internal communication error (CP33)	7	FF3CH

5-6 CANopen LED Function

There are two CANopen flash signs: CRUN and CERR.



• Status Display

Display the drive's current status: RUN, STOP, FWD, REV, CAN RUN, CAN ERROR

2 LED Display

Indicates frequency, current, voltage, running direction, user-defined units, faults, etc.

O UP/DOWN Key

Select parameters and sets/changes parameter settings

CRUN:

LED status	Condition/ State	CANopen Status
OFF	Keep lighting off	Initial
Blinking	ON-200 200 ms ms ms	Pre-operation
Single flash	ON- 200 200 1000 ms ms ms	Stopped
ON	Keep lighting on	Operation

CERR

LED status	Condition / State
OFF	No Error
Single flash	One message fail ON OFF OFF
Double flash	Guarding failure or heartbeat failure
Triple flash	SYNC fail ON 200 200 200 200 1000 MS MS MS MS MS MS MS MS
ON	Bus off

[This page intentionally left blank]

- 6-1 Summary of Parameter Settings
- 6-2 Descriptions of Parameter Settings

6-1 Summary of Parameter Settings

This chapter provides a summary of parameters (Pr.) setting ranges and defaults You can set, change, and reset parameters through the digital keypad.

NOTE:

×

N

- 1. *: You can set this parameter during operation. Refer to chapter 06 for the details of parameters.
- 2. Refer to Section 6-2 for the details of parameters.

00 Drive Parameters

Pr.	Parameter Name	Settings	Default
		302: 230 V, 1 Phase, 0.25 HP	
		303: 230 V, 1 Phase, 0.5 HP	
		304: 230 V, 1 Phase, 1 HP	
		305: 230 V, 1 Phase, 2 HP	
		306: 230 V, 1 Phase, 3 HP	
00-00	Ac Motor Drive Identity Code	403: 460 V, 3 Phase, 0.5 HP	Read only
		404: 460 V, 3 Phase, 1 HP	
l		405: 460 V, 3 Phase, 2 HP	
		406: 460 V, 3 Phase, 3 HP	
		407: 460 V, 3 Phase, 5.5 HP	
		408: 460V, 3Phase, 7.5HP	
00.01	Ac Motor Drive Rated Current	Dianlay by models	Deederby
00-01	Display	Display by models	Read only
		0: No Function	
		1: Write protection for parameters	
		5: Return kWh displays to 0	
		7: Reset CANopen Slave index	
00-02	Parameter Reset	8: Keypad does not respond	0
		9: Reset all parameters to defaults	
		(base frequency is 50 Hz)	
		10: Reset all parameters to defaults	
		(base frequency is 60 Hz)	
		0: F (frequency command)	
		1: H (output frequency)	
00-03	Start-Up Display	2: U (user-defined) see Pr.00-04	0
		3: A (output current)	
		4: DI / DO status	
		0: Display output current from the drive to the motor	
	Operatorial of Multi Free stine	(A) (Unit: Amp)	
00-04	Content of Multi-Function	1: Display counter value (c) (Unit: CNT)	3
l	Display (User-Defined)	2: Display the drive's actual output frequency (H.)	
		(unit: Hz)	

	Pr.	Parameter Name	Settings	Default
			3: Display the drive's DC bus voltage (v) (Unit: V _{DC})	
			4: Display the drive's U, V, W output voltage (E)	
			(Unit: V _{AC})	
			5: Display the drive's output power angle (n)	
			(Unit: deg)	
			6: Display the drive's output power (P) (Unit: kW)	
			7: Display the motor speed (r) (Unit: rpm)	
			14: Display the drive's IGBT temperature (i.)	
			(Unit: °C)	
			16: the digital input status (ON / OFF) (i)	
			17: the digital output status (ON / OFF) (o)	
			18: Display multi-step speed (S)	
			19: the corresponding CPU digital input pin status	
			(d)	
			20: the corresponding CPU digital output pin	
			status (0.)	
			25: Overload count (0.00–100.00%) (o.) (Unit: %)	
			27: DC bus voltage ripple (r.) (Unit: V _{DC})	
			30: Display the output of User-defined (U)	
			31: Display Pr.00-05 user gain (K)	
			36: Present operating carrier frequency of the drive	
			(J.) (Unit: Hz)	
			38: Display the drive status (6.)	
			41: kWh display (J) (Unit: kWh)	
	00.05	Coefficient Gain in Actual	0.00.400.00	4.00
	00-05	Output Frequency	0.00–160.00	1.00
	00-06	Firmware Version	Read only	#.#
	00.07	Parameter Protection	0–9998	0
	00-07	Password input	0–4 (the number of password attempts)	0
			0–9998	
	00.00	Parameter Protection	0: No password protection or password is entered	0
	00-08	Password Setting	correctly (Pr.00-07)	0
			1: Password has been set	
Γ	00-10	Control Mode	0: Speed mode	0
	00-11	Speed Control Mode	0: VF (IM V/F control)	0
Γ	00-16	Load Selection	1: Heavy load	1
ľ	00-17	Carrier Frequency	Heavy load: 2–9 kHz	2
ľ			0: Digital keypad	
	00-20	Master Frequency Command	1: RS-485 communication input	6
	00 <u>2</u> 0	Source (AUTO, REMOTE)	3: External UP / DOWN terminal	Ū
			6: CANopen communication	

	Pr.	Parameter Name	Settings	Default
ĺ			0 (Digital keypad)	
,		Operation Command Source	1: External terminals	
~	00-21	(AUTO, REMOTE)	2: RS-485 communication input	3
			3: CANopen communication	
,			0: Ramp to stop	
~	00-22	Stop Method	1: Coast to stop	0
·			0: Enable forward / reverse	
×	00-23	Motor Direction Control	1: Disable reverse	0
			2: Disable forward	
·		Digital Operator (Keypad)		
	00-24	Frequency Command	Read only	Read only
		Memory		
·			0: Standard HOA function	
			1: When switching between local and remote, the	
			drive stops.	
			2: When switching between local and remote, the	
			drive runs with REMOTE settings for frequency	
			and operating status.	
			3: When switching between local and remote, the	
	00-29	29 Local / Remote Selection	drive runs with LOCAL settings for frequency and	0
			operating status.	
			4: When switching between local and remote, the	
			drive runs with LOCAL settings when switched	
			to Local and runs with REMOTE settings when	
			switched to Remote for frequency and operating	
			status.	
İ			0: Digital keypad	
			1: RS-485 communication input	
N	00-30	Master Frequency Command	2: External analog input (refer to Pr.03-00)	6
		Source (HAND, LOCAL)	3: External UP / DOWN terminal	
			6: CANopen communication	
ĺ			0 (Digital keypad)	
	00.04	Operation Command Source	1: External terminals	0
	00-31	(HAND, LOCAL)	2: RS-485 communication input	3
			3: CANopen communication	
	00.00		0: STOP key disabled	0
*	00-32	Digital Keypad Stop Function	1: STOP key enabled	0
-	00.47		0: Standard	
	00-47	Output Phase Order Selection	1: Reverse the operation direction	0
×	00-48	Display Filter Time (Current)	0.001–65.535 sec.	0.100

	Pr.	Parameter Name	Settings	Default
×	00-49	Display Filter Time (Keypad)	0.001–65.535 sec.	0.100
	00-50	Software Version (Date)	Read only	Read only

01 Basic Parameters

	Pr.	Parameter Name	Settings	Default
	01-00	Motor 1 Maximum Operation	0.00–400.00 Hz	60.00 /
	01-00	Frequency	0.00-400.00 Hz	50.00
	01-01	Minimum Output Frequency	0.00–400.00 Hz	60.00 /
	01-01	of Motor 1	0.00-400.00 Hz	50.00
	01-02	Minimum Output Voltage of	230V models: 0.0–255.0 V	220.0
	01-02	Motor 1	460V models: 0.0–510.0 V	440.0
	01-03	Mid-Point Frequency 1 of Motor 1	0.00–400.00 Hz	3.00
	04.04	Mid-Point Voltage 1 of Motor	230V models: 0.0–240.0 V	11.0
~	01-04	1	460V models: 0.0–480.0 V	22.0
	01-05	Mid-Point Frequency 2 of Motor 1	0.00–400.00 Hz	1.5
	04.00	Mid-Point Voltage 2 of Motor	230V models: 0.0–240.0 V	5.0
*	01-06	1	460V models: 0.0–480.0 V	10.0
	01-07	Minimum Output Frequency of Motor 1	0.00–400.00 Hz	0.50
	04.00	Minimum Output Voltage of	230V models: 0.0–240.0 V	1.0
~	01-08	Motor 1	460V models: 0.0–480.0 V	2.0
	01-09	Start-Up Frequency	0.00–400.00 Hz	0.50
*	01-10	Output Frequency Upper Limit	0.00–400.00 Hz	400.00
*	01-11	Output Frequency Lower Limit	0.00–400.00 Hz	0.00
	04.40		Pr.01-45 = 0: 0.00–600.00 sec.	10.00
*	01-12	Acceleration Time 1	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
	04.40		Pr.01-45 = 0: 0.00–600.00 sec.	10.00
*	01-13	Deceleration Time 1	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
	04 44	Appaleration Times 0	Pr.01-45 = 0: 0.00–600.00 sec.	10.00
~	01-14	Acceleration Time 2	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
	04 45	Deceleration Time 2	Pr.01-45 = 0: 0.00–600.00 sec.	10.00
*	01-15	Deceleration Time 2	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
<u>,</u>	01 16	Acceleration Time 2	Pr.01-45 = 0: 0.00–600.00 sec.	10.00
~	01-16	Acceleration Time 3	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
<i></i>	01 17	Deceleration Time 3	Pr.01-45 = 0: 0.00–600.00 sec.	10.00
~	01-17		Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
~	01 10	Appeloration Time 4	Pr.01-45 = 0: 0.00–600.00 sec.	10.00
*	01-18	Acceleration Time 4	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
<u>,</u>	01-19	Deceleration Time 4	Pr.01-45 = 0: 0.00–600.00 sec.	10.00
~	01-19		Pr.01-45 = 1: 0.0–6000.0 sec.	10.0

	Pr.	Parameter Name	Settings	Default
	01.00		Pr.01-45 = 0: 0.00–600.00 sec.	10.00
~	01-20	Jog Acceleration Time	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
	01-21	lag Deceleration Time	Pr.01-45 = 0: 0.00–600.00 sec.	10.00
~	01-21	Jog Deceleration Time	Pr.01-45 = 1: 0.0–6000.0 sec.	10.0
*	01-22	Jog Frequency	0.00–400.00 Hz	6.00
~	01-23	Switch Frequency Between First and Fourth Accel./Decel.	0.00–400.00 Hz	0.00
	04.04	S-Curve Acceleration Begin	Pr.01-45 = 0: 0.00–25.00 sec.	0.20
×	01-24	Time 1	Pr.01-45 = 1: 0.0–250.0 sec.	0.2
	04.05	S-Curve Acceleration Arrival	Pr.01-45 = 0: 0.00–25.00 sec.	0.20
×	01-25	Time 2	Pr.01-45 = 1: 0.0–250.0 sec.	0.2
	04.00	S-Curve Deceleration Begin	Pr.01-45 = 0: 0.00–25.00 sec.	0.20
×	01-26	Time 1	Pr.01-45 = 1: 0.0–250.0 sec.	0.2
	04.07	S-Curve Deceleration Arrival	Pr.01-45 = 0: 0.00–25.00 sec.	0.20
~	01-27	Time 2	Pr.01-45 = 1: 0.0–250.0 sec.	0.2
	01-28	Skip Frequency 1 (Upper Limit)	0.00–400.00 Hz	0.00
_	01-29	Skip Frequency 1 (Lower Limit)	0.00–400.00 Hz	0.00
	01-30	Skip Frequency 2 (Upper Limit)	0.00–400.00 Hz	0.00
	01-31	Skip Frequency 2 (Lower Limit)	0.00–400.00 Hz	0.00
-	01-32	Skip Frequency 3 (Upper Limit)	0.00–400.00 Hz	0.00
	01-33	Skip Frequency 3 (Lower Limit)	0.00–400.00 Hz	0.00
ļ			0: Output waiting	
	01-34	Zero-Speed Mode	1: Zero-speed operation	0
			2: Fmin (refer to Pr.01-07 and Pr.01-41)	
Ē			0: V/F curve determined by Pr.01-00–01-08	
	01-43	V/F Curve Selection	1: V/F curve to the power of 1.5	0
			2: V/F curve to the power of 2	
Ī			0: Linear acceleration and deceleration	
			1: Auto-acceleration and linear deceleration	
	04.44	Auto-Acceleration and Auto-	2: Linear acceleration and auto-deceleration	2
	01-44	Deceleration Setting	3: Auto-acceleration and auto-deceleration	0
			4: Stall prevention by auto-acceleration and	
			auto-deceleration (limited by Pr.01-12–Pr.01-21)	

Pr.	Parameter Name	Settings	Default
01-45	Time Unit for Acceleration	0: Unit 0.01 sec.	0
01-45	and Deceleration and S-Curve	1: Unit 0.1 sec.	U
01.46	Oananan Ouisk Otan Tina	Pr.01-45 = 0: 0.00–6000.0 sec.	1.00
01-46	Canopen Quick Stop Time	Pr.01-45 = 1: 0.0–6000.0 sec.	

02 Digital input / Output Parameters

Pr.	Parameter Name	Settings	Default
		0: No Function	
	Two-Wire / Three-Wire Operation Control	1: Two-wire mode 1, power on for operation control	
		(M1: FWD / STOP, M2: REV / STOP)	
02-00		2: Two-wire mode 2, power on for operation control	1
		(M1: RUN / STOP, M2: REV / FWD)	
		3: Three-wire, power on for operation control	
		(M1: RUN, M2: REV / FWD, M3: STOP)	
02-01	Multi-Function input	0: No Function	0
02-01	Command 1 (MI1)	1: Multi-step speed command 1	0
02-02	Multi-Function input	2: Multi-step speed command 2	0
02-02	Command 2 (MI2)	3: Multi-step speed command 3	0
00.00	Multi-Function input	4: Multi-step speed command 4	0
02-03	Command 3 (MI3)	5: Reset	0
00.04	Multi-Function input	6: JOG command	0
02-04	Command 4 (MI4)	7: Acceleration / deceleration speed inhibit	0
00.05	Multi-Function input	8: 1 st and 2 nd acceleration / deceleration time	<u>^</u>
02-05	Command 5 (MI5)	selection	0
	Multi-Function input	9: 3 rd and 4 th acceleration / deceleration time	<u>^</u>
02-06	Command 6 (MI6)	selection	0
		10: External Fault (EF) input	
		11: Base Block (B.B.) input from external	
		12: Output stop	
		13: Cancel the setting of auto-acceleration / auto-	
		deceleration time	
		18: force to stop (Pr.07-20)	
		19: Frequency up command	
		20: Frequency down command	
		22: Clear the counter	
		23: input the counter value (MI6)	
		24: FWD JOG command	
		25: REV JOG command	
		28: Emergency stop (EF1)	
		38: Disable writing EEPROM function	
		40: force coasting to stop	
		41: HAND switch	
		42: AUTO switch	
		49: Enable drive	
		56: Local / Remote selection	

	Pr.	Parameter Name	Settings	Default
			0: UP / DOWN by the accel. / decel. time	
	02-09	Lin / Down Koy Mode	1: UP / DOWN constant speed (Pr.02-10)	0
~		Up / Down Key Mode	2: Pulse signal (Pr.02-10)	0
			3: External terminals UP / DOWN key mode	
		Acceleration / Deceleration		
*	02-10	Speed of External Terminal	0.001–1.000 Hz / ms	0.001
		UP / DOWN Key		
~	02-11	Multi-Function input	0.000–30.000 sec.	0.005
~	02-11	Response Time	0.000-30.000 sec.	0.005
~	02-12	Multi-Function input Mode	0000h–FFFFh (0: N.O.; 1: N.C.)	0000
~	02-12	Selection	00001-FFFF1 (0. N.O., 1. N.C.)	0000
~	02-13	Multi-Function Output 1	0: No Function	50
~	02-13	(MO1)	1: indication during RUN	50
~	02-14	Multi-Function Output 2	2: Operation speed reached	50
<i>,</i> .	02-14	(MO2)	3: Desired frequency reached 1 (Pr.02-22)	
~	02-15	Multi-Function Output 3	4: Desired frequency reached 2 (Pr.02-24)	50
~	02-13	(MO3)	5: Zero speed (Frequency command)	50
~	02-16	Multi-Function Output 4	6: Zero speed including STOP	50
<i>,</i> .	02-10	(MO4)	(Frequency command)	
			7: Over-torque 1 (Pr.06-06-08)	
			9: Drive is ready	
			10: Low voltage warning (Lv) (Pr.06-00)	
			11: Malfunction indication	
			13: Overheat warning (Pr.06-15)	
			16: Slip error (oSL)	
			17: Count value reached, does not return to 0	
			(Pr.02-20)	
			18: Count value reached, return to 0 (Pr.02-19)	
			19: External interrupt B.B. input (Base Block)	
			20: Warning output	
			21: Over-voltage	
			22: Over-current stall prevention	
			23: Over-voltage stall prevention	
			24: Operation source	
			25: forward command	
			26: Reverse command	
			29: Output when frequency \geq Pr.02-34	
			30: Output when frequency < Pr.02-34	
			33: Zero speed (actual output frequency)34: Zero speed including STOP	
			(actual output frequency)	
l				

	Pr.	Parameter Name	Settings	Default
			35: Error output selection 1 (Pr.06-23)	
			36: Error output selection 2 (Pr.06-24)	
			37: Error output selection 3 (Pr.06-25)	
			38: Error output selection 4 (Pr.06-26)	
			40: Speed reached (including STOP)	
			43: Actual motor speed detection	
			44: Low current output	
			(use with Pr.06-71–Pr.06-73)	
			46: Master dEb output	
			50: Output control for CANopen	
			51: Analog output control for RS-485 interface	
			75: forward RUN status	
			76: Reverse RUN status	
1	02-18	Multi-Function Output Direction	0000h–FFFFh (0: N.O.; 1: N.C.)	0000
	00.40	Terminal Counting Value	0.05500	
	02-19	Reached (Returns To 0)	0–65500	0
		Preliminary Counting Value		
1	02-20	Reached	0–65500	0
		(Does Not Return To 0)		
,		Desired Frequency Reached		60.00 /
^	02-22	1	0.00–400.00 Hz	50.00
_		the Width of the Desired		
	02-23	Frequency Reached 1	0.00–400.00 Hz	2.00
_		Desired Frequency Reached		60.00 /
^	02-24	2	0.00–400.00 Hz	50.00
,		the Width of the Desired		
	02-25	Frequency Reached 2	0.00–400.00 Hz	2.00
		Output Frequency Setting for		
^	02-34	Multi-Function Output Terminal	0.00–400.00 Hz	0.00
		External Operation Control	0: Disabled	
/	02-35	Selection after Reset and	1: Drive runs if the RUN command remains after	0
		Reboot	reset or reboot.	
/	02-47	Motor Zero-Speed Level	0–65535 rpm	0
		Display the Status of Multi-	Monitor the status of the Multi-function input	
	02-50	Function input Terminal	Terminal	Read only
		Display the Status of Multi-	Monitor the status of the Multi-function Output	
	02-51	Function Output Terminal	Terminal	Read only
		Display the Frequency		
	02-54	Command Executed by	Read only	Read only
1		External Terminal		

	Pr.	Parameter Name	Settings	Default
	02-55	MI Terminal NPN / PNP Mode	0: NPN (SINK) mode	0
	02-55	Selection	1: PNP (SOURCE) Mode	U
		EF Activates When the	0: Terminal count value reached, no EF displays	
*	02-81	-81	(continues to operate)	0
	Terminal Count Value Reached	1: Terminal count value reached, EF activates		
		initial Frequency Command	0: Use current Frequency command	
*	02-82	02-82 (F) Mode after Stop	1: Use zero Frequency command	0
	(F) Mode alter Stop		2: Refer to Pr.02-83 to set up	
N	✓ 02-83	initial Frequency Command	0.00–400.0 Hz	60.00
~	02-03	(F) Setting after Stop	0.00-400.0112	00.00

03 Reserved

	Pr.	Parameter Name	Settings	Default
~	04-00	1 st Step Speed Frequency	0.00–400.00 Hz	0.00
~	04-01	2 nd Step Speed Frequency	0.00–400.00 Hz	0.00
*	04-02	3 rd Step Speed Frequency	0.00–400.00 Hz	0.00
*	04-03	4th Step Speed Frequency	0.00–400.00 Hz	0.00
*	04-04	5 th Step Speed Frequency	0.00–400.00 Hz	0.00
~	04-05	6 th Step Speed Frequency	0.00–400.00 Hz	0.00
×	04-06	7 th Step Speed Frequency	0.00–400.00 Hz	0.00
×	04-07	8th Step Speed Frequency	0.00–400.00 Hz	0.00
*	04-08	9th Step Speed Frequency	0.00–400.00 Hz	0.00
×	04-09	10 th Step Speed Frequency	0.00–400.00 Hz	0.00
*	04-10	11 th Step Speed Frequency	0.00–400.00 Hz	0.00
×	04-11	12 th Step Speed Frequency	0.00–400.00 Hz	0.00
×	04-12	13th Step Speed Frequency	0.00–400.00 Hz	0.00
~	04-13	14th Step Speed Frequency	0.00–400.00 Hz	0.00
×	04-14	15th Step Speed Frequency	0.00–400.00 Hz	0.00

04 Multi-Step Speed Parameters

05 Motor Parameters

	Pr.	Parameter Name	Settings	Default
	05-01	Full-Load Current for induction Motor 1 (A)	10–120% of the drive's rated current	Depending on the model power
*	05-02	Rated Power for induction Motor 1 (Kw)	0.00–655.35 kW	Depending on the model power
*	05-03	Rated Speed for induction Motor 1 (Rpm)	0–65535 1710 (60 Hz 4 poles); 1410 (50 Hz 4 poles)	Depending on the motor's number of poles
	05-04	Number of Poles for induction Motor 1	2–20	4
	05-05	No-Load Current for induction Motor 1 (A)	0–Pr.05-01 default	Depending on the model power
	05-26	Motor Accumulated Watt in Every Second (W-Sec.)	Read only	Read only
	05-27	Motor Accumulated Watt in Every Second (W-Sec.)	Read only	Read only
	05-28	Motor Accumulated Watt in Every Hour (W-Hour)	Read only	Read only
	05-29	Accumulated Watt-Hour for A Motor in Low Word (Kw-Hour)	Read only	Read only
	05-30	Accumulated Watt-Hour for A Motor in High Word (MW-Hour)	Read only	Read only
	05-31	Accumulated Motor Operation Time (Minutes)	0–1439	0
	05-32	Accumulated Motor Operation Time (Days)	0–65535	0

06 Protection Parameters (1)

	Pr.	Parameter Name	Settings	Default
~	06.00		115V / 230V models: 150.0–220.0 V _{DC}	180.0
~	06-00	Low Voltage Level	460V models: 300.0–440.0 V_{DC}	360.0
			0: No Function	
×	06-01	Over-Voltage Stall Prevention	230V models: 0.0–450.0 V _{DC}	380.0
			460V models: 0.0–900.0 V _{DC}	760.0
	06.02	Selection for Over-Voltage Stall	0: Traditional over-voltage stall prevention	0
~	06-02	Prevention	1: Smart over-voltage stall prevention	0
	00.00	Over-Current Stall Prevention	0–250%	400
~	06-03	During Acceleration	(100% corresponds to the rated current of the drive)	180
	00.04	Over-Current Stall Prevention	0–250%	400
*	06-04	During Operation	(100% corresponds to the rated current of the drive)	180
			0: by current acceleration / deceleration time	
			1: by the first acceleration / deceleration time	
		Acceleration / Deceleration	2: by the second acceleration / deceleration time	
*	06-05	Time Selection for Stall	3: by the third acceleration / deceleration time	0
		Prevention at Constant Speed	4: by the fourth acceleration / deceleration time	
			5: by auto-acceleration / auto-deceleration	
			0: No function	
			1: Continue operation after over-torque detection	
			during constant speed operation	
,		06-06 Over-Torque Detection Selection (Motor 1)	2: Stop after over-torque detection during constant	0
*	06-06		speed operation	
			3: Continue operation after over-torque detection	
			during RUN	
			4: Stop after over-torque detection during RUN	
,		Over-Torque Detection Level	10–250%	
*	06-07	(Motor 1)	(100% corresponds to the rated current of the drive)	120
		Over-Torque Detection Time		
*	06-08	(Motor 1)	0.1–60.0 sec.	0.1
			0: inverter motor (with external forced cooling)	
~	06-13	Electronic thermal Relay	1: Standard motor (motor with fan on the shaft)	2
		Selection 1 (Motor 1)	2: Disabled	
		Electronic thermal Relay Action		
*	06-14	Time 1 (Motor 1)	30.0–600.0 sec.	60.0
		Temperature Level Overheat		
*	06-15	(Oh) Warning	0.0–110.0°C	95.0
×	06-16	Stall Prevention Limit Level	0–100% (Refer to Pr.06-03–Pr.06-04)	100
	06-17	Fault Record 1	0: No fault record	0
	06-18	Fault Record 2	1: Over-current during acceleration (ocA)	0

Pr.	Parameter Name	Settings	Default
06-19	Fault Record 3	2: Over-current during deceleration (ocd)	0
06-20	Fault Record 4	3: Over-current during steady operation (ocn)	0
06-21	Fault Record 5	6: Over-current at stop (ocS)	0
06-22	Fault Record 6	7: Over-voltage during acceleration (ovA)	0
	Fault Record 7 (Pr.14-70)	8: Over-voltage during deceleration (ovd)	
	Fault Record 8 (Pr.14-71)	9: Over-voltage during constant speed (ovn)	
	Fault Record 9 (Pr.14-72)	10: Over-voltage at stop (ovS)	
	Fault Record 10 (Pr.14-73)	11: Low-voltage during acceleration (LvA)	
		12: Low-voltage during deceleration (Lvd)	
		13: Low-voltage at constant speed (Lvn)	
		14: Low-voltage at stop (LvS)	
		15: Phase loss protection (orP)	
		16: IGBT overheating (oH1)	
		18: IGBT temperature detection failure (tH1o)	
		21: Over load (oL)	
		22: Electronic thermal relay 1 protection (EoL1)	
		26: Over torque 1 (ot1)	
		28: Under current (uC)	
		31: EEPROM read error (cF2)	
		33: U-phase error (cd1)	
		34: V-phase error (cd2)	
		35: W-phase error (cd3)	
		36: cc hardware error (Hd0)	
		37: oc hardware error (Hd1)	
		49: External fault (EF)	
		50: Emergency stop (EF1)	
		51: External base block (bb)	
		52: Password is locked (Pcod)	
		54: Illegal command (CE1)	
		55: Illegal data address (CE2)	
		56: Illegal data value (CE3)	
		57: Data is written to read-only address (CE4)	
		58: Modbus transmission time-out (CE10)	
		62: Deceleration energy backup error (dEb)	
		79: U-phase over-current before run (Aoc)	
		80: V-phase over-current before run (boc)	
		81: W-phase over-current before run (coc)	
		82: Output phase loss U phase (OPL1)	
		83: Output phase loss V phase (OPL2)	
		84: Output phase loss W phase (OPL3)	

	Pr.	Parameter Name	Settings	Default
			87: Low frequency overload protection (oL3)	
			101: CANopen guarding error (CGdE)	
			102: CANopen heartbeat error (CHbE)	
			104: CANopen bus off error (CbFE)	
			105: CANopen index error (CidE)	
			106: CANopen station address error (CAdE)	
			107: CANopen index setting exceed limit (CFrE)	
			111: inrCOM time-out error (ictE)	
			121: internal communication error (CP20)	
			123: internal communication error (CP22)	
			124: internal communication error (CP30)	
			126: internal communication error (CP32)	
			127: internal communication error (CP33)	
~	06-23	Fault Output Option 1	0–65535 (refer to bit table for fault code)	0
~	06-24	Fault Output Option 2	0–65535 (refer to bit table for fault code)	0
~	06-25	Fault Output Option 3	0–65535 (refer to bit table for fault code)	0
~	06-26	Fault Output Option 4	0–65535 (refer to bit table for fault code)	0
	06-31	Frequency Command at Malfunction	0.00–400.00 Hz	Read only
	06-32	Output Frequency at Malfunction	0.00–400.00 Hz	Read only
	06-33	Output Voltage at Malfunction	0.0–6553.5 V	Read only
	06-34	DC Bus Voltage at Malfunction	0.0–6553.5 V	Read only
	06-35	Output Current at Malfunction	0.00–655.35 Amps	Read only
	06-36	IGBT Temperature at Malfunction	-3276.7–3276.7 °C	Read only
	06-38	Motor Speed at Malfunction	-32767–32767 rpm	Read only
	06-39	Torque Command at Malfunction	-32767–32767	Read only
	06-40	Status of the Multi-Function input Terminal at Malfunction	0000h-FFFFh	Read only
	06-41	Status of the Multi-Function Output Terminal at Malfunction	0000h-FFFFh	Read only
	06-42	Drive Status at Malfunction	0000h-FFFFh	Read only
			0: Warn and continue operation	
,	ac (-	Output Phase Loss Detection 1: Warn and ramp to stop	1: Warn and ramp to stop	
~	06-45	Action (Ophl)	2: Warn and coast to stop	3
			3: No warning	
		Detection Time for Output	-	
*	06-46	Phase Loss	0.000–65.535 sec.	0.500

	Pr.	Parameter Name	Settings	Default
~	06-47	Current Detection Level for Output Phase Loss	0.00–100.00 %	1.00
~	06-48	DC Brake Time for Output Phase Loss	0.000–65.535 sec.	0.000
~	06-49	Lvx Auto-Reset	0: Disabled 1: Enabled	0
~	06-53	input Phase Loss Detection Action (Orp)	0: Warn and ramp to stop 1: Warn and coast to stop	0
	06-63	Operation Time of Fault Record 1 (Day)	0–65535 days	Read only
	06-64	Operation Time of Fault Record 1 (Min.)	0–1439 min.	Read only
	06-65	Operation Time of Fault Record 2 (Day)	0–65535 days	Read only
	06-66	Operation Time of Fault Record 2 (Min.)	0–1439 min.	Read only
	06-67	Operation Time of Fault Record 3 (Day)	0–65535 days	Read only
	06-68	Operation Time of Fault Record 3 (Min.)	0–1439 min.	Read only
	06-69	Operation Time of Fault Record 4 (Day)	0–65535 days	Read only
	06-70	Operation Time of Fault Record 4 (Min.)	0–1439 min.	Read only
×	06-71	Low Current Setting Level	0.0–100.0%	0.0
~	06-72	Low Current Detection Time	0.00–360.00 sec.	0.00
			0: No Function 1: Fault and coast to stop	
×	06-73	Low Current Action	2: Fault and ramp to stop by the 2nd deceleration time	0
	06-90	Operation Time of Fault Record 5 (Day)	3: Warn and continue operation 0–65535 days	Read only
	06-91	Operation Time of Fault Record 5 (Min.)	0–1439 min.	Read only
	06-92	Operation Time of Fault Record 6 (Day)	0–65535 days	Read only
	06-93	Operation Time of Fault Record 6 (Min.)	0–1439 min.	Read only

07 Special Parameters

	Pr.	Parameter Name	Settings	Default
×	07-01	Dc Brake Current Level	0–100	0
~	07-02	DC Brake Time at Start-Up	0.0–60.0 sec.	0.0
~	07-03	DC Brake Time at STOP	0.0–60.0 sec.	0.0
×	07-04	DC Brake Frequency at STOP	0.00–400.00 Hz	0.00
~	07-05	Voltage increasing Gain	1–200 %	100
*	07-06	Restart after Momentary Power Loss	0: Stop operation1: Speed tracking by the speed before the power loss2: Speed tracking by the minimum output frequency	0
×	07-07	Allowed Power Loss Duration	0.0–20.0 sec.	2.0
×	07-08	Base Block Time	0.0–5.0 sec.	0.5
~	07-09	Current Limit of Speed Tracking	20–200 %	100
×	07-10	Restart after Fault Action	0: Stop operation1: Speed tracking by current speed2: Speed tracking by the minimum output frequency	0
*	07-11	Number of Times of Restart after Fault	0–10	0
×	07-12	Speed Tracking During Start- Up	 0: No function 1: Speed tracking by the maximum output frequency 2: Speed tracking by the motor frequency at start-up 3: Speed tracking by the minimum output frequency 	0
×	07-13	Deb Function Selection	 0: Disabled 1: dEb with auto-acceleration / auto-deceleration, the drive does not output the frequency after the power is restored. 2: dEb with auto-acceleration / auto-deceleration, the drive outputs the frequency after the power is restored. 	0
×	07-15	Dwell Time at Acceleration	0.00–600.00 sec.	0.00
~	07-16	Dwell Frequency at Acceleration	0.00–400.00 Hz	0.00
~	07-17	Dwell Time at Deceleration	0.00–600.00 sec.	0.00
×	07-18	Dwell Frequency at Deceleration	0.00–400.00 Hz	0.00

	Pr.	Parameter Name	Settings	Default
*	07-19	Fan Cooling Control (Only Valid for Models With Fans)	 6: Fan is always ON 1: Fan is OFF after the AC motor drive stops for one minute. 2: Fan is ON when the AC motor drive runs; fan is OFF when the AC motor drive stops 3: Fan turns ON when the temperature (IGBT) reaches around 60oC. 5: Fan is ON when the AC motor drive runs; fan is OFF when the AC motor drive stops. Fan is in stand-by mode at zero speed. 	3
*	07-20	Emergency Stop (Ef) & force To Stop Selection	 0: Coast to stop 1: by the first deceleration time 2: by the second deceleration time 3: by the third deceleration time 4: by the fourth deceleration time 5: System deceleration 6: Automatic deceleration 	0
*	07-21	Automatic Energy-Saving Setting	0: Disabled 1: Enabled	0
~	07-22	Energy-Saving Gain	10–1000	100
*	07-23	Automatic Voltage Regulation (Avr) Function	0: Enable AVR 1: Disable AVR 2: Disable AVR during deceleration	0
~	07-24	Torque Command Filter Time	0.001–10.000 sec.	0.050
~	07-25	Torque Command Filter Time	0.001–10.000 sec.	0.100
~	07-26	Torque Compensation Gain	0–10	1
~	07-27	Slip Compensation Gain	0.00–10.00	0.00
~	07-29	Slip Deviation Level	0.0–100.0 0: No detection	0
*	07-30	Over-Slip Deviation Detection Time	0.0–10.0 sec.	1.0
*	07-31	Over-Slip Deviation Treatment	0: Warn and continue operation1: Warn and ramp to stop2: Warn and coast to stop3: No warning	0
*	07-32	Motor Oscillation Compensation Factor	0–10000	1000
~	07-33	Auto-Restart interval of Fault	0.0–6000.0 sec.	60.0
~	07-62	Deb Gain (Kp)	0–65535	8000
*	07-63	Deb Gain (Ki)	0–65535	150

08 Reserved

[Pr.	Parameter Name	Settings	Default
~	09-00	Communication Address	1–254	1
~	09-01	Com1 Transmission Speed	4.8–19.2 Kbps	9.6
×	09-02	COM1 Transmission Fault Treatment	0: Warn and continue operation1: Warn and ramp to stop2: Warn and coast to stop3: No Warn and continue operation	3
~	09-03	COM1 Time-Out Detection	0.0–100.0 sec.	0.0
~	09-04	Com1 Communication Protocol	1: 7, N, 2 (ASCII) 2: 7, E, 1 (ASCII) 3: 7, O, 1 (ASCII) 4: 7, E, 2 (ASCII) 5: 7, O, 2 (ASCII) 6: 8, N, 1 (ASCII) 7: 8, N, 2 (ASCII) 8: 8, E, 1 (ASCII) 9: 8, O, 1 (ASCII) 10: 8, E, 2 (ASCII) 11: 8, O, 2 (ASCII) 12: 8, N, 1 (RTU) 13: 8, N, 2 (RTU) 14: 8, E, 1 (RTU) 15: 8, O, 1 (RTU) 16: 8, E, 2 (RTU) 17: 8, O, 2 (RTU)	1
*	09-09	Communication Response Delay Time	0.0–200.0 ms	2.0
	09-10	Communication Main Frequency	0.00–400.00 Hz	60.00
~	09-11	Block Transfer 1	0–65535	0
~	09-12	Block Transfer 2	0–65535	0
~	09-13	Block Transfer 3	0–65535	0
~	09-14	Block Transfer 4	0–65535	0
~	09-15	Block Transfer 5	0–65535	0
~	09-16	Block Transfer 6	0–65535	0
~	09-17	Block Transfer 7	0–65535	0
~	09-18	Block Transfer 8	0–65535	0
~	09-19	Block Transfer 9	0–65535	0
~	09-20	Block Transfer 10	0–65535	0
*	09-21	Block Transfer 11	0–65535	0

09 Communication Parameters

	Pr.	Parameter Name	Settings	Default
✓	09-22	Block Transfer 12	0–65535	0
✓	09-23	Block Transfer 13	0–65535	0
✓ [09-24	Block Transfer 14	0–65535	0
✓ [09-25	Block Transfer 15	0–65535	0
✓ [09-26	Block Transfer 16	0–65535	0
ſ	00.00	Communication Decoding	0: Decoding method 1	1
	09-30	Method	1: Decoding method 2	1
Ī	00.00	Osman an Olava Address	0: Disable	0
	09-36	Canopen Slave Address	1–127	0
Ī			0: 1 Mbps	
			1: 500 Kbps	
		Canopen Speed	2: 250 Kbps	
	09-37		3: 125 Kbps	0
			4: 100 Mbps (Delta Only)	
			5: 50 Kbps	
Ī			bit 0: CANopen software disconnection 1	
			(CANopen Guarding Time-out)	
			bit 1: CANopen software disconnection 2	
			(CANopen Heartbeat Time-out)	
	09-39	Cananan Warning Depart	bit 3: CANopen SDO time-out	0
	09-39	Canopen Warning Record	bit 4: CANopen SDO buffer overflow	0
			bit 5: CANopen hardware disconnection warning	
			(CANopen Bus OFF)	
			bit 6: CANopen format error warning (Error	
			protocol for CANopen)	
ſ	00.40	Cananan Deceding Method	0: Use Delta-defined decoding method	1
	09-40	Canopen Decoding Method	1: Use CANopen Standard DS402 protocol	1
Γ			0: Node Reset State	
			1: Com Reset State	
	00.44	Canopen Communication	2: Boot up State	Deederb
	09-41	Status	3: Pre-operation State	Read only
			4: Operation State	
			5: Stop State	

10 Speed Feedback Control Parameters

	Pr.	Parameter Name	Settings	Default
	10-29	Upper Limit of Frequency		20.00
~	10-29	Deviation	0.00–200.00 Hz	20.00

11 Reserved

12 System control and CANopen function parameters

Pr.	Parameter Name	Settings	Default
40.00	Questa en Ocentral	bit 3: Dead time compensation closed	0
12-00	System Control	bit 7: Save or do not save the frequency	0
40.04		0: Two-phase modulation mode	
12-01	Pwm Mode Selection	2: Space vector modulation mode	2
12-02	System Control Flag	0000–FFFFh	0000
12-03	Canopen Cycle Time Setting	1–400 ms	50
12-04	Canopen Online Response Time	1–30000 ms	1000
12-05	Canopen Detects Master Time	1–30000 ms	1000
12-06	Canopen Detects Master Number	1–127	127
12-07	Canonon Protocol Solaction	0: Standard CiA402 Protocol	0
12-07	Canopen Protocol Selection	1: Customization	0
	Canopen MO1 Disconnection	0: MO1 output disconnected	
12-08		1: MO1 output closed	2
	Disposal	2: MO1 output maintains the previous state	
	Canopen MO2 Disconnection	0: MO2 output disconnected	
12-09	Disposal	1: MO2 output closed	2
	Disposal	2: MO2 output maintains the previous state	
	Canopen MO3 Disconnection	0: MO3 output disconnected	
12-10		1: MO3 output closed	2
	Disposal	2: MO3 output maintains the previous state	
	Canopen MO4 Disconnection	0: MO4 output disconnected	
12-11	Disposal	1: MO4 output closed	2
	Бізрозаі	2: MO4 output maintains the previous state	
12-12	Canopen TPDO Delay Time	0.0–100.0 %	20.0
12-50	Output Frequency at Fault 2	0.00–400.00 Hz	Read only
12-51	DC Bus Voltage at Malfunction 2	0.0–6553.5 V	Read only
12-52	Output Current at Malfunction 2	0.00–655.35 Amps	Read only
	IGBT Temperature at		
12-53	Malfunction 2	-3276.7–3276.7 °C	Read only
12-54	Output Frequency at Malfunction 3	0.00–400.00 Hz	Read only
12-55	DC Bus Voltage at Malfunction 3	0.0–6553.5 V	Read only

Pr.	Parameter Name	Settings	Default
12-56	Output Current at Malfunction 3	0.00–655.35 Amps	Read only
12-57	IGBT Temperature at Malfunction 3	-3276.7–3276.7 °C	Read only
12-58	Output Frequency at Malfunction 4	0.00–400.00 Hz	Read only
12-59	DC Bus Voltage at Malfunction 4	0.0–6553.5 V	Read only
12-60	Output Current at Malfunction 4	0.00–655.35 Amps	Read only
12-61	IGBT Temperature at Malfunction 4	-3276.7–3276.7 °C	Read only
12-62	Output Frequency at Malfunction 5	0.00–400.00 Hz	Read only
12-63	DC Bus Voltage at Malfunction 5	0.0–6553.5 V	Read only
12-64	Output Current at Malfunction 5	0.00–655.35 Amps	Read only
12-65	IGBT Temperature at Malfunction 5	-3276.7–3276.7 °C	Read only
12-66	Output Frequency at Malfunction 6	0.00–400.00 Hz	Read only
12-67	DC Bus Voltage at Malfunction 6	0.0–6553.5 V	Read only
12-68	Output Current at Malfunction 6	0.00–655.35 Amps	Read only
12-69	IGBT Temperature at Malfunction 6	-3276.7–3276.7 °C	Read only
12-70	Fault Record 7	Refer to fault record Pr.06-17–06-22	0
12-71	Fault Record 8	Refer to fault record Pr.06-17–06-22	0
12-72	Fault Record 9	Refer to fault record Pr.06-17–06-22	0
12-73	Fault Record 10	Refer to fault record Pr.06-17–06-22	0

13 Control Mode Parameter Macro Function

Pr.	Parameter Name	Settings	Default
		0: No Function	
		1: by user	
13-00	Macro Selection	2: I/O mode control	0
		3: CANopen remote control and monitoring mode	
		4: I/O control and CANopen remote monitoring mode	

[This page is intentionally left blank]

6-2 Descriptions of Parameter Settings

00 Drive Parameters

00-00

✓ You can set this parameter during operation.

		Default: Read only
	Settings Read only	
00-01	AC Motor Drive Rated Current Display	
		Default: Read only

Settings Read only

AC Motor Drive Identity Code

Pr.00-00 displays the AC motor drive identity code. Use the following specification table to check if Pr.00-01 setting is the rated current of the AC motor drive. Pr.00-01 corresponds to the identity code of Pr.00-00.

230V Models - Single-phase							
Frame		А	В				
Power (kW)	0.2	0.4	0.75	1.5	2.2		
Power (HP)	0.25	0.5	1	2	3		
Identity Code	302	303	304	305	306		
Rated Current	1.6	2.5	4.2	7.5	11.0		

460V Models - Three-phase							
Frame	A			В			
Power (kW)	0.4	0.75	1.5	2.2	4.0	5.5	
Power (HP)	0.5	1	2	3	5.5	7.5	
Identity Code	403	404	405	406	407	408	
Rated Current	1.5	2.5	4.2	5.5	9.0	13	

00-02 Parameter Reset

Default: 0

Settings 0: No function

- 1: Write protection for parameters
- 5: Return kWh displays to 0
- 7: Reset CANopen Slave index
- 8: Keypad does not respond
- 9: Reset all parameters to defaults (base frequency is 50 Hz)
- 10: Reset all parameters to defaults (base frequency is 60 Hz)
- 1: All parameters are read only except Pr.00-02, Pr.00-07, and Pr.00-08. Set Pr.00-02 to 0 before changing other parameter settings.
- 5: You can return the kWh displayed value to 0 even during drive operation.For example, you can set Pr.05-26–Pr.05-30 to 0.

- 7: Reset the related settings of CANopen slave. Generally, it needs to be reset after setting Pr.12-07, 09-40, 09-30, etc., otherwise the CANopen network cannot be connected normally.
- 8: RUN key on the keypad is invalid; the rest of the keys work normally. Set Pr.00-02 to 0 to unlock the setting.
- 9 or 10: Reset all parameters to defaults. If you have set a password (Pr.00-08), unlock the password (Pr.00-07) to clear the password you have set before you reset all parameters.
- Definition For the setting of 9 and 10, you must reboot the motor drive after you finish the setting.

00-03	Start-up	Display
-------	----------	---------

Default: 0

- Settings 0: F (frequency command) 1: H (output frequency) 2: U (user-defined) see Pr.00-04 3: A (output current)
 - 4: DI / DO status

Determines the start-up display page after power is applied to the drive. The user-defined contents display according to the Pr.00-04 settings.

✓ 00-04 Conte	nt of Multi-function Display (User-Defined)
	Default: 3
Setting	s 0: Display output current (A) (Unit: Amp)
	1: Display counter value (c) (Unit: CNT)
	2: Display the drive's actual output frequency (H.) (unit: Hz)
	3: Display the drive's DC bus voltage (v) (Unit: V_{DC})
	4: Display the drive's output voltage (E) (Unit: V _{AC})
	5: Display the drive's output power angle (n) (Unit: deg)
	6: Display the drive's output power (P) (Unit: kW)
	7: Display the motor speed (r) (Unit: rpm)
	14: Display the drive's IGBT temperature (i.) (Unit: °C)
	16: The digital input status (ON / OFF) (i)
	17: The digital output status (ON / OFF) (o)
	18: Display multi-step speed (S)
	19: The corresponding CPU digital input pin status (d)
	20: The corresponding CPU digital output pin status (0.)
	25: Overload count (0.00–100.00%) (o.) (Unit: %)
	27: DC bus voltage ripple (r.) (Unit: V _{DC})
	30: Display the output of User-defined (U)
	31: Display Pr.00-05 user gain (K)
	36: Present operating carrier frequency of the drive (J.) (Unit: Hz)
	38: AC motor drive status (6.)
	41: kWh display (J) (Unit: kWh)

Explanation 1

If MI1 and MI4 are ON, the following table shows the status of the terminals.

Normally opened contact (N.O.): (0: OFF, 1: ON)

Terminal	MI6	MI5	MI4	MI3	MI 2	MI 1
Status	0	1	0	0	0	1

- The value is 0000 0000 0000 0001 in binary. and 0011H in HEX. When Pr.00-04 is set to 16 or 9, the u page on the keypad displays 0011h.
- The setting 16 is the ON / OFF status of digital input according to Pr.02-12 setting. And the setting 19 is the corresponding CPU pin ON / OFF status of the digital input.
- When MI1 / MI2 default setting is two-wire / three-wire operation control (Pr.02-00 ≠ 0), and MI3 is set to three-wire, it is not affected by Pr.02-12.
- You can set 16 to monitor the digital input ON / OFF status, and then set 19 to check if the circuit is normal.

Explanation 2

Example: Assume that MO: Pr.02-13 is set to 9 (Drive is ready). After powering the drive on, if there is no other abnormal status, the contact is close. The display status is shown below.

Normally opened contact (N.O.):

Terminal	MO1	MO2	MO3	MO4
Status	1	0	0	0

- If Pr.00-04 is set to 17 or 20, it displays in hexadecimal "0001h" with LED u page is ON in the keypad.
- The setting 17 is the ON / OFF status of digital output according to Pr.02-18 setting and the setting 20 is the corresponding CPU pin ON / OFF status of the digital output.
- You can set 17 to monitor the digital output ON / OFF status, and then set 20 to check if the circuit is normal.

Explanation 3

• Setting value 25: when displayed value reaches 100.00%, the drive shows "oL" as an overload warning.

Explanation 4

- Setting value 38:
 - bit 0: The drive is running forward.
 - bit 1: The drive is running backward.
 - bit 2: The drive is ready.
 - bit 3: Errors occurred on the drive.
 - bit 4: The drive is running.
 - bit 5: Warnings occurred on the drive.

00-05 Coefficient Gain in Actual Output Frequency

Default:1.00

Settings 0.00-160.00

Sets the user-defined unit coefficient gain. Set Pr.00-04 = 31 to display the calculation result on the screen (calculation = output frequency * Pr.00-05).

00-06 Firmware Version

Settings Read only

00-07 Parameter Protection Password Input

Settings 0–9998

Display 0–4 (the number of password attempts)

- This parameter allows you to enter your password (which is set in Pr.00-08) to unlock the parameter protection and to make changes to the parameter.
- I To avoid problems in the future, be sure to write down the password after you set this parameter.
- Pr.00-07 and Pr.00-08 are used to prevent personnel from setting other parameters by accident.
- If you forget the password, clear the password setting by entering 9999 and pressing the ENTER key, then enter 9999 again and press ENTER within 10 seconds. After decoding, all the settings return to default.
- When setting is under password protection, all the parameters read 0, except Pr.00-08.

00-08 Parameter Protection Password Setting


Default: 0

Settings 0-9998

- 0: No password protection or password is entered correctly (Pr.00-07)
- 1: Password has been set
- This parameter is for setting the password protection. Password can be set directly the first time. After you set the password, the value of Pr.00-08 is 1, which means password protection is activated. At this time, if you want to change any of the parameter settings, you must enter the correct password in Pr.00-07 to deactivate the password temporarily, and this would make Pr.00-08 become 0. After you finish setting the parameters, reboot the motor drive and the password is activated again.
- Entering the correct password in Pr.00-07 only temporarily deactivates the password. To permanently deactivate password protection, set Pr.00-08 to 0 manually. Otherwise, password protection is always reactivated after you reboot the motor drive.
- The keypad copy function works only when the password protection is deactivated (temporarily or permanently). And the password set in Pr.00-08 cannot be copied to the keypad. So when copying parameters from the keypad to the motor drive, set the password manually again in the motor drive to activate password protection.

Default: #.#

Default: 0




Compensation

Pr.07-27

I PF

Pr.07-25



00-17 Carrier frequency

Settings Heavy load: 2–9 kHz

Determines the PWM carrier frequency for the AC motor drive.

Models	230V	460V		
Model	0.25–3 HP	0.5–5 HP		
	[0.2–2.2 kW]	[0.4–4.0 kW]		
Settings	2–9 kHz			
Default:	2 kHz			

Carrier Frequency	Acoustic Noise	Electromagnetic Noise or Leakage Current	Heat Dissipation	Current Wave
2 kHz	Significant	Minimal	Minimal	
8 kHz		Ī	Ī	
15 kHz	Minimal	Significant	Significant	

- From the table, you see that the PWM carrier frequency has significant influences on the electromagnetic noise, the AC motor drive heat dissipation, and the motor acoustic noise. Therefore, if the surrounding noise is greater than the motor noise, lower the carrier frequency to reduce the temperature rise. Although the motor has quiet operation in the higher carrier frequency, consider the entire wiring and interference.
- When the carrier frequency is higher than the default, decrease the carrier frequency to protect the drive. Refer to chapter 4-5 for the related setting and details.
 - **00-20** Master frequency command source (AUTO, REMOTE)

Default: 6

Default:2

- Settings 0: Digital keypad
 - 1: RS-485 communication input
 - 3: External UP / DOWN terminal
 - 6: CANopen communication
- You can switch the HAND, LOCAL mode with the multi-function input terminal (MI) to set the master frequency source.
- Pr.00-20, 00-21 and 00-30, 00-31 are the frequency and operation source setting of AUTO and HAND respectively.

The default for the frequency source or operation source is for AUTO mode. It returns to AUTO or REMOTE mode whenever you cycle the power. If you use a multi-function input terminal to switch between HAND (LOCAL) and AUTO (REMOTE) mode, the highest priority is the multi-function input terminal.

00-21 Operation command source (AUTO, REMOTE)

Default: 3

Settings 0: Digital keypad

- 1: External terminals
- 2: RS-485 communication input
- 3: CANopen communication
- Determines the operation frequency source in the "AUTO, REMOTE" mode.
- In the HOA mode, if the multi-function input terminal (MI) function setting 41 and 42 are OFF, the drive does not receive any operation command and JOG is invalid.
- When the operation command is controlled by CANopen, the CRUN function on the panel is valid.




Default: 0

Settings 0: Ramp to stop

1: Coast to stop

Determines how the motor is stopped when the drive receives the Stop command.



Ramp to Stop and Coast to Stop

- 1. Ramp to stop: the AC motor drive decelerates to 0 or the minimum output frequency (Pr.01-09) according to the set deceleration time, and then to stop (according to Pr.01-07).
- 2. Coast to stop: the AC motor drive stops output immediately, and the motor coasts to stop according to the load inertia.
 - ☑ Use "ramp to stop" for the safety of personnel or to prevent material from being wasted in applications where the motor must stop immediately after the drive stops. You must set the deceleration time accordingly.
 - ☑ If idling is allowed or the load inertia is large, use "coast to stop".
 For example, blowers, punching machines and pumps.

00-23

Motor direction control

Default: 0

Settings 0: Enable forward / reverse 1: Disable reverse 2: Disable forward

Enables the motor to run in the forward and reverse direction. You can use it to prevent a motor from running in a direction that would cause injury or damage to the equipment, especially when only one running direction is allowed for the motor load.

00-24 Digital operator (keypad) frequency command memory

Default: Read only

Settings Read only

If the keypad is the frequency command source, when Lv or fault occurs, this parameter stores the current frequency command.

00-29 LOCAL / REMOTE Selection

Default: 0

- Settings 0: Standard HOA function
 - 1: When switching between local and remote, the drive stops.
 - 2: When switching between local and remote, the drive runs with REMOTE settings for frequency and operating status.
 - 3: When switching between local and remote, the drive runs with LOCAL settings for frequency and operating status.
 - 4: When switching between local and remote, the drive runs with LOCAL settings when switched to Local and runs with REMOTE settings when switched to Remote for frequency and operating status.
- The default for Pr.00-29 is 0, that is, the standard HOA (Hand-Off-Auto) function. Set the AUTO and HAND frequency and operation source with Pr.00-20, 00-21 and Pr.00-30, 00-31. The external terminal function (MI) = 56 for LOC / REM mode selection is disabled when Pr.00-29=0.
- If Pr.00-29 is not set to 0,that is, the Local / Remote function. LOC or REM. Set the REMOTE and LOCAL frequency and operation source with Pr.00-20, 00-21, 00-30, and 00-31. Set the multi-function input terminal (MI) = 56 to set the LOC / REM selection.

00-30 Master frequency command source (HAND, LOCAL)

Default: 6

- Settings 0: Digital keypad
 - 1: RS-485 communication input
 - 3: External UP / DOWN terminal
 - 6: CANopen communication
- Determines the master frequency source in the "HAND, LOCAL" mode.
- You can switch the HAND, LOCAL mode with the multi-function input terminal (MI) to set the master frequency source.

6-2-009

Default: 3

It returns to AUTO or REMOTE mode whenever you cycle the power. If you use a multi-function input terminal to switch between HAND (LOCAL) and AUTO (REMOTE) mode, the highest priority is the multi-function input terminal.

00-31 Operation command source (HAND, LOCAL)

Settings 0: Digital keypad

- 1: External terminals
- 2: RS-485 communication input
- 3: CANopen communication
- Determines the operation frequency source in the "HAND, LOCAL" mode.
- In the HOA mode, if the multi-function input terminal (MI) function setting 41 and 42 are OFF, the drive does not receive any operation command and JOG is invalid.
- IP When the operation command is controlled by CANopen, the CRUN function on the panel is valid.

00-32 Digital Keypad STOP Function

Default: 0

Settings 0: STOP key disabled

1: STOP key enabled

□ Valid when the operation command source is not the digital keypad (Pr.00-21 \neq 0).

When Pr.00-21=0, the STOP key on the digital keypad is not affected by this parameter.

00-47 Output Phase Order Selection

Default: 0

Settings 0: Standard

1: Reverse the operation direction

- Without changing the output wiring of the motor drive, the actual running direction of the motor can be changed from forward to reverse and reverse to forward through this parameter, and the indicator signals (FWD, REV) on the keypad remain unchanged.
- When using this parameter with Pr.00-23 (Motor Direction Control), the output logic is to first judge whether there is a prohibited direction, and then whether to output the reverse direction. If a certain direction is prohibited, no action will be taken.

00-48 Display Filter Time (Current)

Settings 0.001-65.535 sec.

Settings 0.001-65.535 sec.

 \square Minimizes the current fluctuation displayed by the digital keypad.

Minimizes the value fluctuation displayed by the digital keypad.

00-49 Display Filter Time (Keypad)

Default: 0.100

-

Default: 0.100

00-50 Software Version (Date)

Default: Read only

Settings Read only

 $\hfill\square$ Displays the current drive software version by date.

01 Basic Parameters

✓ You can set this parameter during operation.

01-00 Motor 1 Maximum Operation Frequency

Default: 60.00 / 50.00

Settings 0.00-400.00 Hz

$\hfill\square$ Determines the AC motor drive's maximum operation frequency.

01-01 Minimum output frequency of motor 1

Default: 60.00 / 50.00

Default: 220.0 / 440.0

Settings 0.00–400.00 Hz

Set this parameter according to the motor's rated frequency on the motor nameplate. If the motor's rated frequency is 60 Hz, set this parameter to 60. If the motor's rated frequency is 50 Hz, set this parameter to 50.

01-02 Minimum output voltage of motor 1


Settings 230V models: 0.0–255.0 V 460V models: 0.0–510.0 V

Set this parameter according to the motor's rated frequency on the motor nameplate. If the motor's rated frequency is 60 Hz, set this parameter to 60. If the motor's rated frequency is 50 Hz, set this parameter to 50.

	01-03	Mid-poir	nt Frequency 1 of Motor 1	
				Default: 3.00
		Settings	0.00–400.00 Hz	
×	01-04	Mid-poir	nt Voltage 1 of Motor 1	
				Default: 11.0 / 22.0
		Settings	230V models: 0.0–240.0 V	
			460V models: 0.0–480.0 V	
	01-05	Mid-poir	nt frequency 2 of motor 1	
				Default: 1.5
		Settings	0.00–400.00 Hz	
×	01-06	Mid-poir	nt voltage 2 of motor 1	
				Default: 5.0 /10.0
		Settings	230V models: 0.0–240.0 V	
			460V models: 0.0–480.0 V	
	01-07	Minimur	n output frequency of motor 1	
				Default: 0.50
		Settings	0.00–400.00 Hz	
×	01-08	Minimur	n output voltage of motor 1	
				Default: 1.0 / 2.0
		Settings	230V models: 0.0–240.0 V	
			460V models: 0.0–480.0 V	


You usually set the V/F curve according to the motor's allowable loading characteristics. Pay special attention to the motor's heat dissipation, dynamic balance, and bearing lubrication when the loading characteristics exceed the loading limit of the motor.


There is no limit for the voltage setting, but a high voltage at a low frequency may cause motor damage, overheating, and trigger the stall prevention or the over-current protection. Therefore, use low voltage at low frequency to prevent motor damage or drive error.



V/F Curve and The Related Parameters

Gommon settings for the V/F curve:





01-09 Start-up Frequency

Default: 0.50

Settings 0.00-400.00 Hz

When the starting frequency (Pr.01-09) is larger than the Minimum Output Frequency of Motor 1 (Pr.01-07), the drive's frequency output starts from the starting frequency (Pr.01-09) until reaching the F command.

Refer to the figure shown below:


Fcmd = Frequency command;

Fstart = Start-up frequency (Pr.01-09);

fstart = actual start-up frequency of the drive;

Fmin = 4th output frequency setting (Pr.01-07 / Pr.01-41);

Flow = output frequency lower limit (Pr.01-11)




When Fcmd > Fmin and Fcmd < Fstart:

If Flow < Fcmd, the drive runs directly with Fcmd.

- If Flow ≥ Fcmd, the drive runs with Fcmd, and then rises to Flow according to acceleration time.
- Description: The drive's output frequency goes directly to 0 when decelerating to Fmin.

×	01-10	Output Frequency Upper Limit	
			Default: 400.00
		Settings 0.00–400.00 Hz	
×	01-11	Output Frequency Lower Limit	
_			Default: 0.00
		Settings 0.00–400.00 Hz	

- If the output frequency setting is higher than the upper limit (Pr.01-10), the drive runs with the upper limit frequency. If the output frequency setting is lower than the lower limit (Pr.01-11) but higher than the minimum output frequency (Pr.01-07), the drive runs with the lower limit frequency. Set the upper frequency limit > lower frequency limit (Pr.01-10 setting value must be > Pr.01-11 setting value).
- When the drive starts Pr.07-27 slip compensation, the output frequency may exceed the frequency command.




- When the drive starts, it operates according to the V/F curve and accelerates from the minimum output frequency (Pr.01-07) to the setting frequency. It is not limited by the lower output frequency settings.
- Use the output frequency upper and lower limit settings to prevent operator misuse, overheating caused by the motor's operating at a too low frequency, or mechanical wear due to a too high speed.
- If the output frequency upper limit setting is 50 Hz and the frequency setting is 60 Hz, the maximum output frequency is 50 Hz.

- □ If the output frequency lower limit setting is 10 Hz and the minimum output frequency setting (Pr.01-07) is 1.5 Hz, then the drive operates at 10 Hz when the Frequency command is higher than Pr.01-07 but lower than 10 Hz. If the Frequency command is lower than Pr.01-07, the drive is in ready status without output.
- ✓ 01-12 Acceleration Time 1
- ✓ 01-13 Deceleration Time 1
- 01-14 Acceleration Time 2
- 01-15 Deceleration Time 2
- 01-16 Acceleration Time 3
- 01-17 Deceleration Time 3
- 01-18 Acceleration Time 4
- 01-19 Deceleration Time 4
- ✓ **01-20** JOG Acceleration Time
- **01-21** JOG Deceleration Time

Default: 10.00 /10.0

Settings Pr.01-45 = 0: 0.00–600.00 sec. Pr.01-45 = 1: 0.0–6000.0 sec.

- □ The acceleration time determines the time required for the AC motor drive to ramp from 0.00 Hz to the maximum operation frequency (Pr.01-00). The deceleration time determines the time required for the AC motor drive to decelerate from the maximum operation frequency (Pr.01-00) down to 0.00 Hz.
- The acceleration and deceleration time are invalid when using Pr.01-44 Auto-acceleration and Auto-deceleration Setting.
- Select the Acceleration / Deceleration Time 1, 2, 3, 4 with the multi-function input terminal settings. The defaults are Acceleration Time 1 and Deceleration Time 1.
- With the enabled torque limits and stall prevention functions, the actual acceleration and deceleration time are longer than the above action time.
- Note that set the acceleration and deceleration time too short may trigger the drive's protection function (Pr.06-03 Over-current Stall Prevention during Acceleration or Pr.06-01 Over-voltage Stall Prevention), and the actual acceleration and deceleration time are longer than this setting.
- Note that set the acceleration time too short may cause motor damage or trigger drive protection due to over-current during the drive's acceleration.
- Note that set the deceleration time too short may cause motor damage or trigger drive protection due to over-current during the drive's deceleration or over-voltage.
- When you enable Pr.01-24–Pr.01-27 (S-curve acceleration and deceleration begin and arrival time), the actual acceleration and deceleration time are longer than the setting.



01-22 JOG Frequency

Default: 6.00

Settings 0.00-400.00 Hz


You can use both the external terminal JOG and F1 key on the optional keypad KPC-CC01 (optional) to set the JOG function. When the JOG command is ON, the AC motor drive accelerates from 0 Hz to the JOG frequency (Pr.01-22). When the JOG command is OFF, the AC motor drive decelerates from the JOG frequency to stop. The JOG acceleration and deceleration time (Pr.01-20, Pr.01-21) are the time to accelerate from 0.0 Hz to the JOG frequency (Pr.01-22). You cannot execute the JOG command when the AC motor drive is running. When the JOG command is executing, other operation commands are invalid.

01-23 First / fourth acceleration and deceleration frequency

Default: 0.00

Settings 0.00-400.00 Hz

- This function does not require the external terminal switching function; it switches the acceleration and deceleration time automatically according to the Pr.01-23 setting. If you set the external terminal, the external terminal has priority over Pr.01-23.
- When using this function, set the S-curve acceleration time to 0 if the fourth acceleration time is short.



1st/4th Acceleration/Deceleration Frequency Switching




01-24 S-curve acceleration begin time 1 S-curve acceleration arrival time 2


- 01-25
- 01-26 S-curve deceleration begin time 1
- S-curve deceleration arrival time 2 01-27

Default: 0.20

Settings Pr.01-45 = 0: 0.00–25.00 sec. Pr.01-45 = 1: 0.0–250.0 sec.

- Dusing an S-curve gives the smoothest transition between speed changes. The acceleration and deceleration curve adjusts the acceleration and deceleration S-curve. When enabled, the drive produces a different acceleration and deceleration curve according to the acceleration and deceleration time.
- In the S-curve function is invalid when you set the acceleration and deceleration time to 0.
- \square When Pr.01-12, 01-14, 01-16, 01-18 ≥ Pr.01-24 and Pr.01-25,
- the actual acceleration time = Pr.01-12, 01-14, 01-16, 01-18 + (Pr.01-24 + Pr.01-25) / 2.
- \square When Pr.01-13, 01-15, 01-17, 01-19 ≥ Pr.01-26 and Pr.01-27, the actual deceleration time =
- Pr.01-13, 01-15, 01-17, 01-19 + (Pr.01-26 + Pr.01-27) / 2.






Settings 0.00–400.00 Hz

- Bets the AC motor drive's skip frequency. The drive's frequency setting skips these frequency ranges. However, the frequency output is continuous. There are no limits for these six parameters and you can combine them. Pr.01-28 does not need to be greater than Pr.01-29; Pr.01-30 does not need to be greater than Pr.01-31; Pr.01-32 does not need to be greater than Pr.01-33. You can set Pr.01-28–01-33 as you required. There is no size distinction among these six parameters.
- Description These parameters set the skip frequency ranges for the AC motor drive. You can use this function to avoid frequencies that cause mechanical resonance. The skip frequencies are useful when a motor has resonance vibration at a specific frequency bandwidth. Skipping this frequency avoids the vibration. There are three frequency skip zones available.

- You can set the Frequency command (F) within the range of skip frequencies. Then the output frequency (H) is limited to the lower limit of skip frequency ranges.
- During acceleration and deceleration, the output frequency still passes through the skip frequency ranges.




01-34 Zero-speed Mode

Default: 0

Settings 0: Output waiting


- 1: Zero-speed operation
- 2: Fmin (refer to Pr.01-07 and Pr.01-41)
- When the drive's Frequency command is lower than Fmin (Pr.01-07 and Pr.01-41), the drive operates according to this parameter.
- D: the AC motor drive is in waiting mode without voltage output from terminals U, V, W.
- 1: the drive executes the DC brake by Vmin (Pr.01-08 and Pr.01-42) in V/F mode.
- 2: the AC motor drive runs using Fmin (Pr.01-07, Pr.01-41) and Vmin (Pr.01-08, Pr.01-42) in V/F mode.



Settings 0: V/F curve determined by Pr.01-00–01-08

- 1: V/F curve to the power of 1.5
- 2: V/F curve to the power of 2
- \square When setting to 0, refer to Pr.01-01-01-08 for the motor 1 V/F curve.
- When setting to 1 or 2, the second and third voltage frequency settings are invalid.
- If the load of the motor is a variable torque load (torque is in direct proportion to the rotating speed, such as the load of a fan or a pump), the load torque is low at low rotating speed. You can decrease the input voltage appropriately to make the magnetic field of the input current smaller and reduce flux loss and iron loss for the motor to increase efficiency.


When you set the V/F curve to high power, it has lower torque at low frequency, and the drive is not suitable for rapid acceleration and deceleration. Do NOT use this parameter for rapid acceleration and deceleration.



01-44 Auto-acceleration and Auto-deceleration Setting


Default: 0

- Settings 0: Linear acceleration and deceleration
 - 1: Auto-acceleration and linear deceleration
 - 2: Linear acceleration and auto-deceleration
 - 3: Auto-acceleration and auto-deceleration
 - 4: Stall prevention by auto-acceleration and auto-deceleration
 - (limited by Pr.01-12-01-21)
- 0 (linear acceleration and deceleration): the drive accelerates and decelerates according to the setting for Pr.01-12–01-19.
- 1 or 2 (auto / linear acceleration and auto / linear deceleration): the drive auto-tunes the acceleration and deceleration to effectively reduce the mechanical vibration during the load start-up and stop and make the auto-tuning process easier. It does not stall during acceleration and does not need a brake resistor during deceleration to stop. It can also improve operation efficiency and save energy.
- 3 (auto-acceleration and auto-deceleration-decelerating by the actual load): the drive auto-detects the load torque and automatically accelerates from the fastest acceleration time and smoothest start-up current to the setting frequency. During deceleration, the drive automatically determines the loaded regenerative energy to steadily and smoothly stop the motor in the fastest deceleration time.
- 4 (stall prevention by auto-acceleration and deceleration-reference to the acceleration and deceleration time settings): if the acceleration and deceleration time are within a reasonable range, the actual acceleration and deceleration time refer to the Pr.01-12–01-19 settings. If the acceleration and deceleration time are too short, the actual acceleration and deceleration time are greater than the acceleration and deceleration time settings.



Optimize the acceleration / deceleration time when Pr.01-44 is set to 0.

Optimize the acceleration / deceleration time which load needs actually when Pr.01-44 is set to 3.



Sets the time required to decelerate from the maximum operation frequency (Pr.01-00) to 0.00 Hz through the CANopen control.

02 Digital Input / Output Parameters

✓ You can set this parameter during operation.

02-00 Two-wire / Three-wire Operation Control

Default: 1

Settings 0: No function

1: Two-wire mode 1, power on for operation control (M1: FWD / STOP, M2: REV / STOP)

- 2: Two-wire mode 2, power on for operation control (M1: RUN / STOP, M2: REV / FWD)
- 3: Three-wire, power ON for operation control

(M1: RUN, M2: REV / FWD, M3: STOP)

This parameter sets the configuration of the external drive operation control and the Quick Start function. There are three different control modes listed in the following table.

Pr.02-00	External Terminal Control Circuits	
Setting value: 1 Two-wire FWD / STOP REV / STOP	FWD / STOP REV / STOP GOO MI1 "OPEN": STOP "CLOSE": FWD MI2 "OPEN": STOP "CLOSE": REV DCM VFD-EL-C	
Setting value: 2 Two-wire RUN / STOP REV / FWD	RUN / STOP FWD / REV MI1 GOPEN": STOP "CLOSE": RUN MI2 GOPEN": FWD "CLOSE": RUN MI2 CLOSE": RUN WFD-EL-C	
Setting value: 3 Three-wire	OIO OO STOP RUN MI1 "CLOSE": RUN MI3 "OPEN": STOP MI2 REV/FWD: "OPEN": FWD COO WI2 REV / FWD CLOSE": REV DCM VFD-EL-C	

02-01	Multi-function Input Command 1 (MI1)
02-02	Multi-function Input Command 2 (MI2)
02-03	Multi-function Input Command 3 (MI3)
02-04	Multi-function Input Command 4 (MI4)
02-05	Multi-function Input Command 5 (MI5)
02-06	Multi-function Input Command 6 (MI6)

Default: 0

Settings 0: No function

- 1: Multi-step speed command 1
- 2: Multi-step speed command 2
- 3: Multi-step speed command 3
- 4: Multi-step speed command 4
- 5: Reset
- 6: JOG command
- 7: Acceleration / deceleration speed inhibit
- 8: 1st and 2nd acceleration / deceleration time selection
- 9: 3rd and 4th acceleration / deceleration time selection
- 10: External Fault (EF) input
- 11: Base Block (B.B.) input from external
- 12: Output stop
- 13: Cancel the setting of auto-acceleration / auto-deceleration time
- 18: Force to stop (Pr.07-20)
- 19: Frequency up command
- 20: Frequency down command
- 22: Clear the counter
- 23: Input the counter value (MI6)
- 24: FWD JOG command
- 25: REV JOG command
- 28: Emergency stop (EF1)
- 38: Disable writing EEPROM function
- 40: Force coasting to stop
- 41: HAND switch
- 42: AUTO switch
- 49: Enable drive
- 56: Local / Remote selection
- \square Use this parameter to set the function of multi-function terminals.
- When Pr.02-00 = 0, you can set multi-function options with multi-function input terminals MI1, MI2.
- When Pr.02-00 ≠ 0, the multi-function input terminals MI1, MI2 work in accordance with the setting values for Pr.02-00.

Example:

If Pr.02-00 = 1: multi-function input terminal MI1 = FWD / STOP, MI2 = REV / STOP.

If Pr.02-00 = 2: multi-function input terminal MI1 = RUN / STOP, MI2 = FWD / REV.

If Pr.02-00 is set to three-wire operation control, terminal MI3 is for the STOP contact. The function set previously for this terminal is automatically invalid.

Summary of function settings (Take the normally open contact (N.O.) for example, ON: contact is closed, OFF: contact is open)

Settings	Functions	Descriptions		
0	No function	· · · · · · · · · · · · · · · · · · ·		
1	Multi-step speed command 1	You can set 15 steps of speed or 15 positions with the digital		
2	Multi-step speed command 2	status of these four terminals. You can use 16-steps of speed if		
3	Multi-step speed command 3	you include the master speed when setting as 15 steps of speed.		
4	Multi-step speed command 4	(refer to Parameter Group 04 Multi-step Speed Parameters).		
5	Reset	Use this terminal to reset the drive after clearing a drive fault.		
6	JOG command	This function is valid when the source of the operation command is the external terminal. The JOG operation executes when the drive stops completely. While running, you can still change the operation direction, and the STOP key on the keypad* and the STOP command from communications are valid. Once the external terminal receives the OFF command, the motor stops in the JOG deceleration time. Refer to Pr.01-20–01-22 for details. *: This function is valid when Pr.00-32 is set to 1. Pr.01-22 JOG frequency Pr.01-07 Min. output frequency DOG accel. time DOG decel. time		
		MIx-GND ON OFF MIx : External terminal		
7	Acceleration / deceleration speed inhibit	MIx : External terminal When you enable this function, the drive stops acceleration or deceleration immediately. After you disable this function, the AC motor drive starts to accelerate or decelerate from the inhibit point. Frequency Setting frequency Accel. inhibit area Accel. inhibit area Actual operation frequency Decel. inhibit area Actual operation frequency ON ON ON ON ON ON OFF		

Settings	Functions		Desc	criptions		
		You can select	the accelerat	ion and deceler	ation time	of the
8	1 st and 2 nd acceleration /	drive with this function, or from the digital status of the terminals;				minals;
	deceleration time selection	there are four acceleration and deceleration selections.				
		MIx = 8	MIx = 9	Accel. and d	ecele, spee	ed
		OFF	OFF	1 st accel./ d	ecel. speed	k
	3 rd and 4 th acceleration /	ON	OFF	2 nd accel./ d	lecel. speed	b
9	deceleration time selection	OFF	ON	3 rd accel./ d	ecel. speed	t
		ON	ON	4 th accel./ d	ecel. speed	k
10	External Fault (EF) input (EF: External Fault)	Pr.07-20 setting record when an	, and the keyp external fault	rive decelerates ad shows "EF" (occurs). The driv nal status restore	it shows th ve keeps r	ne fault unning
				ops immediately		
11	B.B. inputs from external	•		lys the B.B. signa		
	(B.B.: Base Block)	08 for details.	Keypad displa			11.07-
			of the drive sto	ps immediately a	and the mo	tor is
		•		in output waiting		
	Output stop			nen the drive res		
		the current setti				
		Frequency				
12		Setting frequency				-
		V				– Time
		MIx-GND	ON	OFF	ON	
		Operation command		ON		
	Cancel the setting of auto-	Set Pr.01-44 to	one of the 01–0	04 setting modes	before usi	ng this
13	acceleration / auto-deceleration	function. When	this function is	s enabled, OFF	is for auto	mode
	time	and ON is for linear acceleration / deceleration.				
18	Force to stop	ON: the drive ramps to a stop according to the Pr.07-20 setting.				
19	Frequency up command (Up Command)	ON: the frequency of the drive increases or decreases by one unit. If this function remains ON continuously, the frequency increases or decreases according to Pr.02-09 / Pr.02-10.				
20	Frequency down command (Down Command)	The Frequency command returns to zero when the drive stops and the displayed frequency is 0.00 Hz. If you select Pr.12-00, bit 7 = 1, the frequency is not saved.				
22	Clear the counter			e is cleared and ction is disabled.	l displays	0. The

Settings	Functions	Descriptions		
23	Input the counter value (MI6)	ON: the counter value increases by one. Use the function with Pr.02-19.		
24	FWD JOG command	This function is valid when the source of the operation command is the external terminal. ON: the drive executes forward JOG. When executing the JOG command in torque mode, the drive automatically switches to speed mode. The drive returns to torque mode after the JOG command is complete.		
25	REV JOG command	This function is valid when the source of the operation command is the external terminal. ON: the drive executes reverse JOG. When executing the JOG command in torque mode, the drive automatically switches to speed mode. The drive returns to torque mode after the JOG command is complete.		
28	Emergency stop (EF1)	ON: the output of the drive stops immediately, displays "EF1" on the keypad, and the motor is in free run status. The drive keeps running until the external fault is cleared after you press RESET on the keypad. (EF: External Fault) Voltage Frequency Setting frequency MIx-GND ON OFF ON Reset ON OFF		
38	Disable writing EEPROM function	ON: writing to EEPROM is disabled. Changed parameters are not saved after powering off.		
40	Force coasting to stop	ON: during operation, the motor coasts to stop.		
41	HAND switch	When the MI terminal switches to OFF, it executes a STOP command. Therefore, if the MI terminal switches to OFF during operation, the drive stops. The optional digital keypad KPC-CC01 displays the current		
42	AUTO switch	Status of the drive (HAND / OFF / AUTO). bit 1 bit 0 OFF 0 0 AUTO 0 1 HAND 1 0 OFF 1 1		

Settings	Functions	Descriptions		
		When the drive is enabled, the RUN command is valid. When		
10	Enable drive	the drive is disabled, the RUN command is invalid. When the		
49		drive is operating, the motor coasts to stop.		
		This function varies with MO = 45.		
		Use Pr.00-29 to select LOCAL / REMOTE mode.		
		(refer to Pr.00-29)		
56		bit 0 REMOTE 0		
		LOCAL 1		

02-09 UP / DOWN Key Mode


Default: 0

- Settings 0: UP / DOWN by the acceleration / deceleration time
 - 1: UP / DOWN constant speed (Pr.02-10)
 - 2: Pulse signal (Pr.02-10)
 - 3: External terminals UP / DOWN key mode


Acceleration / Deceleration Speed of External terminal UP / DOWN Key Default: 0.001

Settings 0.001-1.000 Hz / ms

- Use when the multi-function input terminals are set to 19, 20 (Digital UP / DOWN command). The frequency increases or decreases according to Pr.02-09 and Pr.02-10.
- When Pr.11-00 bit 7 = 1, the frequency is not saved. The Frequency command returns to zero when the drive stops, and the displayed frequency is 0.00 Hz. At this time, increasing or decreasing the Frequency command (F) by using the UP or DOWN key is valid only when the drive is running.
- When Pr.02-09 is set to 0: The increasing or decreasing Frequency command (F) operates according to the setting for acceleration or deceleration time (refer to Pr.01-12–01–19).



When Pr.02-09 is set to 1: The increasing or decreasing Frequency command (F) operates according to the setting of Pr.02-10 (0.01–1.000 Hz/ms).



02-11 Multi-function Input Response Time

Default: 0.005

Settings 0.000-30.000 sec.

- Use this parameter to set the response time of the digital input terminals MI1–MI6.
- This function is to delay and confirm the digital input terminal signal. The time for delay is also the time for confirmation. The confirmation prevents interference that could cause error in the input to the digital terminals. But in the meanwhile, it delays the response time though confirmation improves accuracy.

02-12 Multi-function Input Mode Selection

Default: 0000

Settings 0000h-FFFFh (0: N.O.; 1: N.C.)

- Description: This parameter is in hexadecimal.
- This parameter sets the status of the multi-function input signal (0: normally open; 1: normally

closed) and it is not affected by the status of SINK / SOURCE.

- □ bit 0-bit 5 correspond to MI1-MI6.
- The default for bit 0 (MI1) is FWD terminal, and the default for bit 1 (MI2) is REV terminal. You cannot use this parameter to change the input mode when $Pr.02-00 \neq 0$.
- \square You can change the terminal ON / OFF status through communications.
 - For example: MI3 is set to 1 (multi-step speed command 1) and MI4 is set to 2 (multi-step speed command 2).

Then the forward + second step speed command = $1001_2 = 9_{10}$.

As long as Pr.02-12 = 9 is set through communications, there is no need to wire any multifunction terminal to run forward with the second step speed.

bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
MI6	MI5	MI4	MI3	MI2	MI1

Use Pr.11-42 bit 1 to select whether FWD / REV terminal is controlled by Pr.02-12 bit 0 and bit 1.

- Multi-function Output 1 (MO1)
- **02-14** Multi-function Output 2 (MO2)
- **02-15** Multi-function Output 3 (MO3)
- **02-16** Multi-function Output 4 (MO4)

Default: 50

- Settings 0: No function
 - 1: Indication during RUN
 - 2: Operation speed reached
 - 3: Desired frequency reached 1 (Pr.02-22)
 - 4: Desired frequency reached 2 (Pr.02-24)
 - 5: Zero speed (Frequency command)
 - 6: Zero speed including STOP (Frequency command)
 - 7: Over-torque 1 (Pr.06-06-08)
 - 9: Drive is ready
 - 10: Low voltage warning (Lv) (Pr.06-00)
 - 11: Malfunction indication
 - 13: Overheat warning (Pr.06-15)
 - 16: Slip error (oSL)
 - 17: Count value reached, does not return to 0 (Pr.02-20)
 - 18: Count value reached, return to 0 (Pr.02-19)
 - 19: External interrupt B.B. input (Base Block)
 - 20: Warning output
 - 21: Over-voltage
 - 22: Over-current stall prevention
 - 23: Over-voltage stall prevention
 - 24: Operation source
 - 25: Forward command
 - 26: Reverse command
 - 29: Output when frequency ≥ Pr.02-34
 - 30: Output when frequency < Pr.02-34
 - 33: Zero speed (actual output frequency)
 - 34: Zero speed including STOP (actual output frequency)
 - 35: Error output selection 1 (Pr.06-23)
 - 36: Error output selection 2 (Pr.06-24)
 - 37: Error output selection 3 (Pr.06-25)
 - 38: Error output selection 4 (Pr.06-26)
 - 40: Speed reached (including STOP)
 - 43: Actual motor speed detection
 - 44: Low current output (use with Pr.06-71-Pr.06-73)
 - 46: Master dEb output
 - 50: Output control for CANopen
 - 51: Analog output control for RS-485 interface

75: Forward RUN status

76: Reverse RUN status

Use this parameter to set the function of multi-function terminals.

Summary of Function Settings

(Take the normally open contact (N.O.) for example, closed: contacts are conducted)

Setting	Functions	Descriptions
0	No function	Output terminal with no function
1	Indication during RUN	Activates when the drive is not in STOP.
2	Operation speed reached	Activates when output frequency of drive reaches to the setting frequency.
3	Desired frequency reached 1 (Pr.02-22)	Activates when the desired frequency (Pr.02-22) is reached.
4	Desired frequency reached 2 (Pr.02-24)	Activates when the desired frequency (Pr.02-24) is reached.
5	Zero speed	Activates when Frequency command = 0 or stopped.
5	(Frequency command)	(the drive must be in RUN status)
	Zero speed including	
6	STOP	Activates when Frequency command = 0 or stopped.
	(Frequency command)	
		Activates when the drive detects over-torque.
7	Over torque 1	Pr.06-07 sets the over-torque detection level, and Pr.06-08 sets the
		over-torque detection time. (Refer to Pr.06-06-08)
9	Drive is ready	Activates when the drive is ON with no error detected.
		Activates when an extremely low voltage at DC side is detected.
10	Low voltage warning (Lv)	Activates when the DC bus voltage is too low. (refer to Pr.06-00
		Low Voltage Level)
11	Malfunction indication	Activates when fault occurs (except Lv stop).
13	Overheat warning	Activates when IGBT or heat sink overheats to prevent the drive
10		from shutting down due to overheating. (Refer to Pr.06-15)
16	Slip error (oSL)	Activates when the slip error is detected.
	Count value reached,	When the drive executes external counter, this contact activates if
17	does not return to 0	the count value is equal to the setting value for Pr.02-20. This
	(Pr.02-20)	contact deactivates when the setting value for Pr.02-20 > Pr.02-19.
	Count value reached,	When the drive executes the external counter, this contact
18	returns to 0 (Pr.02-19)	activates if the count value is equal to the setting value for Pr.02- 19.
10	External interrupt B.B.	Activates when external interrupt (B.B.) occurs in the drive and
19	input (Base Block)	stops outputting .
20	Warning output	Activates when a warning is detected.
21	Over-voltage	Activates when over-voltage is detected.

Setting	Functions	Descriptions				
	Over-current stall	Activates when the over-current stall prevention is detected.				
22	prevention					
23	Over-voltage stall	Activates when over-voltage stall prevention is detected.				
	prevention	Activates when over-voltage stall prevention is detected.				
24	Operation source	Activates when the source of operation command is not controlled				
24 Operation source by the c		by the digital keypad (Pr.00-21 ≠ 0).				
25	Forward command	Activates when the operation direction is forward.				
26	Reverse command	Activates when the operation direction is reverse.				
00	Outputs when frequency	Activates when frequency is \geq Pr.02-34				
29	≥ Pr.02-34	(actual output H ≥ Pr.02-34).				
30	Outputs when frequency	Activates when frequency is < Pr.02-34				
30	< Pr.02-34	(actual output H < Pr.02-34).				
22	Zero speed	Activates when the actual output frequency is 0 or stopped.				
33	(actual output frequency)	(the drive must be in RUN status).				
24	Zero speed including stop					
34	(actual output frequency)	Activates when the actual output frequency is 0 or stopped.				
35	Error output selection 1	Activates when Pr.06-23 is ON.				
36	Error output selection 2	Activates when Pr.06-24 is ON.				
37	Error output selection 3	Activates when Pr.06-25 is ON.				
38	Error output selection 4	Activates when Pr.06-26 is ON.				
40	Speed reached	Activates when the drive's output frequency reaches the setting				
40	(including Stop)	frequency or stopped.				
40	The motor speed is less					
43	than Pr.02-47	Activates when the motor actual speed is less than Pr.02-47.				
44	Low current output	Use this function with Pr.06-71–Pr.06-73.				
		When dEb rises at the master, MO sends a dEb signal to the				
		slave. Output the message when the master triggers dEb. This				
46	Master dEb output	ensures that the slave also triggers dEb. Then the slave follows				
		the deceleration time of the master to stop simultaneously with				
		the master.				
		Control the multi-function output terminals through CANopen.				
		Set Pr.02-13 = 50 to control MO1.				
		The mapping table of the CANopen DO is shown in the following				
		table: Refer to subsection 5-3-5 for more information.				
50	Output control for	Terminal Related Parameters Attribute Mapping Index				
	CANopen	MO1 Pr.02-13 = 50 RW bit 0 of 2026-41 initial value 0x01				
		MO2 $Pr 02-14 = 50$ PW bit 1 of 2026-41				
		MO2 Pr.02-15 = 50 RW initial value 0x01 MO3 Pr.02-15 = 50 RW bit 2 of 2026-41				
		Initial value 0x01				
		MO4 Pr.02-16 = 50 RW initial value 0x01				

Setting	Functions	Descriptions			
51	Output control for RS-485	For RS-485 communication control output.			
		Set Pr.02-13 = 51 to control MO1.			
		The following is the RS485 mapping table.			
		Terminal Related Parameters Attribute Mapping Index			
		MO1 Pr.02-13 = 51 RW bit 0 of 2640H			
		MO2 Pr.02-14 = 51 RW bit 1 of 2640H			
		MO3 Pr.02-15 = 51 RW bit 2 of 2640H			
		MO4 Pr.02-16 = 51 RW bit 3 of 2640H			
75	Forward RUN status	When the drive runs FWD, the output terminal for forward running			
		is closed; when the drive stops, the output terminal for forward			
		running is open.			
76	Reverse RUN status	When the drive runs REV, the output terminal for reverse running			
		is closed; when the drive stops, the output terminal for reverse			
		running is open.			

02-18 Multi-function Output Direction

Default: 0000

Settings 0000h-FFFFh (0: N.O.; 1: N.C.)

- Derived Price of the second se
- This parameter is set by a bit. If the bit is 1, the corresponding multi-function output acts in an opposite way. Example: Assume Pr.02-13 = 1 (indication when the drive is operating). If the output is positive, and the bit is set to 0, then Relay is ON when the drive runs and is OFF when the drive stops. On the contrary, if the output is negative, and the bit is set to 1, then the Relay is OFF when the drive runs and is OFF when the drive stops.

bit3	bit2	bit1	bit0
MO4	MO3	MO2	MO1

✓ 02-19 Terminal Counting Value Reached (returns to 0)

Default: 0

Settings 0-65500


02-20 Preliminary Counting Value Reached (does not return to 0)

Default: 0


Settings 0-65500

- The counter can be triggered by multi-function input terminal MI6 ON / OFF state changes as the cumulative value of the counting value (Pr.02-06 is set to 23).
- The current counting value of the counter can be cleared by a multi-function input terminal MI1– MI5 any terminal (Pr.02-01–02-05 corresponding value is set to 22).
- Set the Pr.00-04 to 1: Display the value (C) (unit: CNT). Press the Mode button of the operating panel to switch the display value to the countor to check the current counting value. However, the panel display is limited by 4 digits, it's only for the value less than 999. It is recommended to use a communication method to check the count value when actual use. The mapping site is as follows.
 - 1. Modbus communication check 2109H
 - 2. Canopen (Delta Old Definition) Index 2022H-SUB02


- \square The counting function is enabled when Pr.02-19 \neq 0.
- Description in the setting of Pr.02-19 is greater than Pr.02-20.
- When the counter reaches Pr.02-19 or 02-20, the MO is activates according to the parameter settings.
 - Select the Pr.02-13–02-16 to be set to 18 as needed. When the counting value increase continually and reaches Pr.02-19, the corresponding multi-function output terminal MO1–MO4 contact to drive customer device connection, while the counting value will returns to zero. After the MI6 has a new count signal input, the count will be counted from 0 to enter the next circle.
 - Select the Pr.02-13–02-16 to be set to 17 as needed. When the counting value increase continually and reaches Pr.02-20, the corresponding multi-function output terminal MO1–MO4 contact to drive customer device connection, the counting value will not returns to zero. The value then counted after the MI6 input a new count signal, until the value reaches Pr.02-19 and value returns to zero.
 - 3. The timing digram shows as follows:



multi-function output terminal is set to 3 or 4 (Pr.02-13 and 02-16), this multi-function output terminal is "closed".




shown in the diagram below.



02-50 Display the Status of Multi-function Input Terminal


Default: Read only

Settings Monitor the status of the Multi-function Input Terminal



Example:


When Pr.02-50 displays 0014h (hex) (that is, the value is 20 (decimal) and 10100 (binary)), it means that MI3 and MI5 are ON.



02-51 Display the Status of Multi-function Output Terminal


Default: Read only


Settings Monitor the status of the Multi-function Output Terminal



Example:

When Pr.02-51 displays 0003h (hex) (that is, the value is 3 (decimal) and 0011 (binary)), it means that $2^0 + 2^1$ MO1 and MO2 are ON.





[This page intentionally left blank]

04 Multi-Step Speed Parameters

✓ You can set this parameter during operation.

N	04-00	1st Step Speed
N	04-01	2nd Step Speed
N	04-02	3rd Step Speed
N	04-03	4th Step Speed
N	04-04	5th Step Speed
N	04-05	6th Step Speed
N	04-06	7th Step Speed Frequency
N	04-07	8th Step Speed Frequency
×	04-08	9th Step Speed Frequency
×	04-09	10th Step Speed Frequency
×	04-10	11th Step Speed Frequency
×	04-11	12th Step Speed Frequency
×	04-12	13th Step Speed Frequency
×	04-13	14th Step Speed Frequency
N	04-14	15th Step Speed Frequency


Default: 0.00

Settings 0.00-400.00 Hz


- Use the multi-function input terminals (refer to settings 1–4 of Pr.02-01–02-06 Multi-function Input Command) to select the multi-step speed command (the maximum is 15th step speed). Pr.04-00 to Pr.04-14 sets the multi-step speed (frequency) as shown in the following diagram.
- The external terminal / digital keypad / communication controls the RUN and STOP commands with Pr.00-21.
- I You can set each multi-step speed (frequency) between 0.00–180.00 Hz during operation.
- B Explanation for the timing diagram of the multi-step speed and external terminals:
- Derived parameter settings are:
 - 1. Pr.04-00–Pr.04-14: sets the 1st–15th multi-step speed (to set the frequency of each step speed).
 - 2. Pr.02-01–Pr.02-06: sets the multi-function input terminals (multi-step speed command 1–4).

Related parameters:

- Pr.01-22 JOG frequency setting
- Pr.02-01 multi-function input command 1 (MI1)
- Pr.02-02 multi-function input command 2 (MI2)
- Pr.02-03 multi-function input command 3 (MI3)
- Pr.02-04 multi-function input command 4 (MI4)
- Pr.02-05 multi-function input command 4 (MI5)
- Pr.02-06 multi-function input command 4 (MI6)



Speed selection via External Terminals



Settings Read only

Pr.05-26–05-30 records the amount of power the motors consume. The accumulation begins when

the drive is activated and the record is saved when the drive stops or turns OFF. The amount of consumed watts continues to accumulate when the drive is activated again.

To clear the accumulation, set Pr.00-02 to 5 to return the accumulation record to 0.

- The accumulated total watts of the motor per second = Pr.05-27 x 65536 + Pr.05-26 Example: when Pr.05-26 = 2548.1 and Pr.05-27 = 15.2, the accumulated total watts of the motor per second = 15.2 x 65536 + 2548.1 = 996147.2 + 2548.1 = 998695.3 (W-sec.)
- The accumulated total kilowatts of the motor per hour = Pr.05-30 x 65536 + Pr.05-29 Example: when Pr.05-29 = 3361.4 and Pr.05-30 = 11.2, the accumulated total kilowatts of the motor per hour = 11.2 x 65536 + 3361.4 = 734003.2 + 3361.4 = 737364.6 (kWh)

05-31	Accumulated Motor Operation Time (minutes)		
		Default: 0	
	Settings 0–1439		
05-32	Accumulated Motor Operation Time (days)		
		Default: 0	
	Settings 0–65535		
~~			

Use Pr.05-31 and Pr.05-32 to record the motor operation time. To clear the operation time, set Pr.05-31 and Pr.05-32 to 0. An operation time shorter than 60 seconds is not recorded.

06 Protection Parameters (1)

✓ You can set this parameter during operation.


06-00

Low voltage level

Default: 180.0 / 360.0

Settings 230V models: 150.0–220.0 V_{DC} 460V models: 300.0–440.0 V_{DC}

- Sets the Low Voltage (LV) level. When the DC bus voltage is lower than Pr.06-00, a LV fault is triggered, and the drive stops output then the motor coasts to a stop.
- If the LV fault is triggered during operation, the drive stops output and the motor coasts to a stop. There are three LV faults, LvA (LV during acceleration), Lvd (LV during deceleration), and Lvn (LV in constant speed) that are triggered according to the status of acceleration or deceleration. You must press RESET to clear the LV fault. The drive automatically restarts if set to restart after momentary power loss (refer to Pr.07-06 Restart after Momentary Power Loss and Pr.07-07 Allowed Power Loss Duration for details).
- □ If the LV fault is triggered when the drive is in STOP status, the drive displays LvS (LV during stop), which is not recorded, and the drive restarts automatically when the input voltage is higher than the LV level of 30 V (30V models), 60 V (230V models) or 60V (575 models).



06-01 Over-voltage Stall Prevention

Default: 380.0 / 760.0

- Settings
 0: No function

 230V models: 0.0–450.0 V_{DC}


 460V models: 0.0–900.0 V_{DC}
- Set Pr.06-01 to 0.0 disables the over-voltage stall prevention function (connected with braking unit or brake resistor).
- Setting Pr.06-01 to a value > 0.0 enables the over-voltage stall prevention. This setting refers to the power supply system and loading. If the setting is too low, then over-voltage stall prevention is easily activated, which may increase deceleration time.
- Related parameters: Pr.01-13, Pr.01-15, Pr.01-17, Pr.01-19 Deceleration Time 1–4, Pr.02-13 Multi-function Output (Relay), Pr.02-16 Multi-function Output (MO1), and Pr.06-02 Selection for Over-voltage Stall Prevention.

06-02 Selection for Over-voltage Stall Prevention


Default: 0

Settings0: Traditional over-voltage stall prevention1: Smart over-voltage stall prevention

- Use this function when you are unsure about the load inertia. When stopping under normal load, the over-voltage does not occur during deceleration and meet the deceleration time setting. Sometimes it may not stop due to over-voltage during decelerating to STOP when the load regenerative inertia increases. In this case, the AC motor drive extends the deceleration time automatically until the drive stops.
- When you set Pr.06-02 to 0, during deceleration the motor exceeds the synchronous speed due to load inertia. In this case, the motor becomes an electrical generator. The DC bus voltage may exceed its maximum allowable value due to motor regeneration in some situations, such as motor's loading inertia being too high or drive's deceleration time being set too short. When you enable traditional over-voltage stall prevention and the DC bus voltage detected is too high, the drive stops decelerating (output frequency remains unchanged) until the DC bus voltage drops below the setting value.



When you set Pr.06-02 to 1 to use smart over-voltage stall prevention during deceleration, the drive maintains the DC bus voltage when decelerating and prevents the drive from OV.




- When you enable the over-voltage stall prevention, the drive's deceleration time is longer than the setting.
- If the deceleration time affects your application, it is not recommended to use this function. The solution is to increase the deceleration time appropriately.
- Related parameters: Pr.01-13, Pr.01-15, Pr.01-17, Pr.01-19 Deceleration Time 1–4, Pr.02-13 Multi-function Output (Relay), Pr.02-16 Multi-function Output (MO1), and Pr.06-01 Over-voltage Stall Prevention.

06-03 Over-current Stall Prevention during Acceleration

Default: 180

Settings 0–200% (100% corresponds to the rated current of the drive)

- If the motor load is too large or the drive's acceleration time is too short, the output current of the drive may be too high during acceleration, and it may cause motor damage or trigger the drive's protection functions (oL or oc). Use this parameter to prevent these situations.
- During acceleration, the output current of the drive may increase abruptly and exceed the setting value of Pr.06-03. In this case, the drive stops accelerating and keeps the output frequency constant, and then continues to accelerate until the output current decreases.
- When you enable the over-current stall prevention, the drive's acceleration time is longer than the setting.
- When the over-current stall prevention occurs because the motor capacity is too small or operates in the default, decrease the Pr.06-03 setting value.
- If you encounter any problem with the acceleration time, refer to the following guides for troubleshooting.
 - 1. Increase the deceleration time to a proper value.
 - 2. Set Pr.01-44 Auto-Acceleration and Auto-Deceleration Setting to 1, 3 or 4. (auto-acceleration)
 - 3. Related parameters:
 - Pr.01-12, 01-14, 01-16, 01-18 (Acceleration Time 1–4)
 - Pr.01-44 Auto-Acceleration and Auto-Deceleration Setting
 - Pr.02-13–02-16 Multi-function Output 1 (MO1–MO4)




stall prevention is enabled

06-04 Over-current Stall Prevention during Operation

Default: 180

Settings 0–200% (100% corresponds to the rated current of the drive)

- This is a protection for the drive to decrease output frequency automatically when the motor overloads abruptly during constant motor operation.
- □ If the output current exceeds the setting value for Pr.06-04 when the drive is operating, the drive decelerates according to the Pr.06-05 setting to prevent the motor from stalling. If the output current is lower than the setting value for Pr.06-04, the drive accelerates (according to Pr.06-05) again to the setting frequency.



Over-current stall prevention during operation

06-05 Accel./Decel. Time Selection for Stall Prevention at Constant Speed

Default: 0

Default: 0


- Settings 0: By current acceleration / deceleration time
 - 1: By the first acceleration / deceleration time
 - 2: By the second acceleration / deceleration time
 - 3: By the third acceleration / deceleration time
 - 4: By the fourth acceleration / deceleration time
 - 5: By auto-acceleration / auto-deceleration

Sets the acceleration / deceleration time selection when stall prevention occurs at constant speed.

06-06 Over-torque Detection Selection (Motor 1)

Settings 0: Disabled


- 1: Continue operation after over-torque detection during constant speed operation
- 2: Stop after over-torque detection during constant speed operation
- 3: Continue operation after over-torque detection during RUN
- 4: Stop after over-torque detection during RUN



Default: 120

Settings 10–250% (100% corresponds to the rated current of the drive)

06-0	8 Over-to	rque Detection T	ime (Moto	or 1)				
					Def	ault: 0.1		
	Settings	0.1–60.0 sec.						
06-1	3 Electron	nic Thermal Rela	y Selection	n 1 (Mot	or 1)			
					Def	ault: 2		
	Settings	0: Inverter motor (with externa	al forced c	ooling)			
		1: Standard motor	⁻ (motor with	n fan on th	e shaft)			
		2: Disabled						
🕮 Prev	ents self-cool	ed motor from over	neating unde	er low spe	ed. Use a	n electr	onic the	ermal relay
limit	the drive's out	tput power.						
🛄 Setti	ng the parame	eter to 0 is suitable f	or an inverte	er motor (r	notor fan	using ar	n indepe	endent pow
supp	oly). For this k	kind of motor, there	is no signif	ficant corr	elation be	tween c	cooling	capacity ar
moto	or speed. The	refore, the action o	f electronic	thermal r	elays rem	ains sta	able in	low speed
ensu	ire the load ca	apability of the moto	r in low spe	ed.				
🕮 Setti	ng the parame	eter to 1 is suitable f	or standard	motor (mo	otor fan is	fixed or	the rot	tor shaft). Fo
						a tha ar	tion of	on alastran
this I	kind of motor,	the cooling capacity	/ is lower in	low speed	; therefor	e, me ac		an electron
		the cooling capacity ices the action time		•		e, me ac		an electron
therr	mal relay redu	• • •	to ensure th	ne life of m	otor.			
therr	mal relay redu en the power is	ices the action time is cycled frequently,	to ensure th if the powe	ne life of m er is switcl	otor. ned OFF,	the elec	ctronic	thermal rela
therr Whe prote	mal relay redu on the power is ection is reset;	ices the action time is cycled frequently, ; therefore, even set	to ensure th if the powe tting the par	ne life of m er is switcl ameter to	otor. ned OFF, 0 or 1 ma	the elec y not pr	ctronic otect th	thermal relate the motor we
therr I Whe prote	mal relay redu in the power is ection is reset; ere are several	ices the action time is cycled frequently, ; therefore, even set I motors connected t	to ensure th if the powe tting the par to one drive,	ne life of m er is switcl ameter to , install an	otor. ned OFF, 0 or 1 ma electronic	the elec y not pr	ctronic otect th	thermal rela ne motor we
therr Whe prote	mal relay redu in the power is ection is reset; ere are several	ices the action time is cycled frequently, ; therefore, even set	to ensure th if the powe tting the par to one drive,	ne life of m er is switcl ameter to , install an	otor. ned OFF, 0 or 1 ma electronic otor 1)	the elec y not pr therma	ctronic otect th I relay ir	thermal rela ne motor we
therr Whe prote If the	mal relay redu en the power is ection is reset; ere are several 4 Electron	ices the action time is cycled frequently, ; therefore, even set I motors connected t nic Thermal Rela	to ensure th if the powe tting the par to one drive,	ne life of m er is switcl ameter to , install an	otor. ned OFF, 0 or 1 ma electronic otor 1)	the elec y not pr	ctronic otect th I relay ir	thermal rela ne motor we
therr Whe prote If the	mal relay redu in the power is ection is reset; ere are several	ices the action time is cycled frequently, ; therefore, even set I motors connected t	to ensure th if the powe tting the par to one drive,	ne life of m er is switcl ameter to , install an	otor. ned OFF, 0 or 1 ma electronic otor 1)	the elec y not pr therma	ctronic otect th I relay ir	thermal rela ne motor we
therr Whe prote If the	mal relay redu en the power is ection is reset; ere are several 4 Electron Settings	ices the action time is cycled frequently, ; therefore, even set I motors connected t nic Thermal Rela	to ensure th if the powe tting the par- to one drive, y Action Ti	ne life of m er is switch rameter to , install an ime 1 (M	otor. ned OFF, 0 or 1 ma electronic otor 1) Def	the elec y not pr therma ault: 60.	ctronic otect th I relay in 0	thermal relate ne motor we n each moto
therr Whe prote If the 06-1	mal relay redu en the power is ection is reset; ere are several 4 Electron <u>Settings</u> the parameter	ices the action time is cycled frequently, ; therefore, even set I motors connected t nic Thermal Rela 30.0–600.0 sec.	to ensure th if the powe tting the par- to one drive, y Action Ti ated current	ne life of m er is switch ameter to , install an ime 1 (M	otor. ned OFF, 0 or 1 ma electronic otor 1) Def	the elec y not pr therma ault: 60. etting of	otect th I relay in 0 Pr.06-	thermal relate motor we n each moto
therr Whe prote If the 06-1	mal relay redu en the power is ection is reset; ere are several 4 Electron Settings the parameter o prevent moto	ices the action time is cycled frequently, ; therefore, even set I motors connected t nic Thermal Relat 30.0–600.0 sec.	to ensure th if the powe tting the par- to one drive, y Action Ti ated current overheating.	ne life of m er is switch ameter to , install an ime 1 (M	otor. ned OFF, 0 or 1 ma electronic otor 1) Def	the elec y not pr therma ault: 60. etting of	otect th I relay in 0 Pr.06-	thermal relate motor we n each moto
therr Whe prote If the 06-1 Set t 28 to "EoL	mal relay redu en the power is ection is reset; ere are several 4 Electron <u>Settings</u> the parameter o prevent moto 1 / EoL2", and	ices the action time is cycled frequently, ; therefore, even set I motors connected t nic Thermal Relat 30.0–600.0 sec. to 150% of motor ra or damage due to c	to ensure the if the powe tting the par- to one drive, y Action Ti ated current overheating.	ne life of m er is switch ameter to , install an ime 1 (M t and use When it r	otor. ned OFF, 0 or 1 ma electronic otor 1) Def with the se eaches th	the elec y not pr therma ault: 60. etting of e setting	ctronic otect th I relay in 0 Pr.06- ⁷ g, the c	thermal relate motor we n each moto 14 and Pr.00 drive display
therr Whe prote If the 06-1 Set t 28 to "EoL W Use	mal relay redu en the power is ection is reset; ere are several 4 Electron Settings the parameter o prevent moto 1 / EoL2", and this parameter	ices the action time is cycled frequently, ; therefore, even set I motors connected t nic Thermal Relat 30.0–600.0 sec. to 150% of motor ra or damage due to c d the motor coasts t	to ensure the if the powe tting the para to one drive, y Action Ti ated current overheating. to stop. me of the el	he life of m er is switch rameter to , install an ime 1 (M t and use When it r lectronic th	otor. ned OFF, 0 or 1 ma electronic otor 1) Def with the se eaches th	the elec y not pr thermal ault: 60. etting of e setting	otect th otect th I relay in 0 Pr.06-7 g, the c	thermal relate motor we n each moto 14 and Pr.06 drive display sed on the la
therr Whe prote If the 06-1 Set t 28 to "EoL Wse char	mal relay redu en the power is ection is reset; ere are several 4 Electron Settings the parameter o prevent moto 1 / EoL2", and this parameter acteristic curv	ices the action time is cycled frequently, ; therefore, even set I motors connected to nic Thermal Relation 30.0–600.0 sec. to 150% of motor re or damage due to co d the motor coasts to er to set the action ti	to ensure th if the powe tting the par- to one drive, y Action Ti ated current overheating. to stop. me of the el mal relay, the	he life of m er is switch ameter to , install an ime 1 (M t and use When it r lectronic th e output fr	otor. ned OFF, 0 or 1 ma electronic otor 1) Def with the se eaches th	the elec y not pr thermal ault: 60. etting of e setting	otect th otect th I relay in 0 Pr.06-7 g, the c	thermal relate motor we n each moto 14 and Pr.00 drive display
therr Whe prote If the 06-1 Set to 28 to "EoL Use char	mal relay redu en the power is ection is reset; ere are several 4 Electron <u>Settings</u> the parameter o prevent moto 1 / EoL2", and this paramete racteristic curv operation time	aces the action time is cycled frequently, ; therefore, even set I motors connected to nic Thermal Relation 30.0–600.0 sec. to 150% of motor rates or damage due to co d the motor coasts to er to set the action ti- re of electronic therr	to ensure the if the powe tting the para to one drive, y Action Ti ated current overheating. to stop. me of the el mal relay, the or from over	he life of m er is switch ameter to , install an ime 1 (M t and use When it r lectronic th e output fr	otor. ned OFF, 0 or 1 ma electronic otor 1) Def with the se eaches th	the elec y not pr thermal ault: 60. etting of e setting	otect th otect th I relay in 0 Pr.06-7 g, the c	thermal relate motor we n each moto 14 and Pr.00 drive display sed on the I
therr Whe prote If the 06-1 Set t 28 to "EoL Wise char the c Motor i curren	mal relay redu en the power is ection is reset; ere are several 4 Electron Settings the parameter o prevent moto 1 / EoL2", and this paramete acteristic curv operation time rated t %	aces the action time is cycled frequently, ; therefore, even set I motors connected to nic Thermal Relation 30.0–600.0 sec. to 150% of motor rates or damage due to co d the motor coasts to er to set the action ti- re of electronic therr	to ensure the if the powe tting the para to one drive, y Action Ti ated current overheating. to stop. me of the el mal relay, the or from over	he life of m er is switch ameter to , install an ime 1 (M t and use v When it r lectronic th e output fr heating.	otor. ned OFF, 0 or 1 ma electronic otor 1) Def with the se eaches th	the elec y not pr thermal ault: 60. etting of e setting	otect th otect th I relay in 0 Pr.06-7 g, the c	thermal relate motor we n each moto 14 and Pr.06 drive display sed on the l2
therr Whe prote If the 06-1	mal relay redu en the power is ection is reset; ere are several 4 Electron <u>Settings</u> the parameter o prevent moto 1 / EoL2", and this parameter acteristic curv operation time rated t %	aces the action time is cycled frequently, ; therefore, even set I motors connected to nic Thermal Relation 30.0–600.0 sec. to 150% of motor rates or damage due to co d the motor coasts to er to set the action ti- re of electronic therr	to ensure the if the powe tting the para to one drive, y Action Ti ated current overheating. to stop. me of the el mal relay, the or from over	he life of m er is switch rameter to , install an ime 1 (M t and use v When it r lectronic th e output fr heating.	otor. ned OFF, 0 or 1 ma electronic otor 1) Def with the se eaches th	the elec y not pr thermal ault: 60. etting of e setting	otect th otect th I relay in 0 Pr.06-7 g, the c	thermal relate motor we n each moto 14 and Pr.00 drive display
therr Whe prote If the 06-1 Set t 28 to "EoL Wie char the c Motor 10 8 6 4	mal relay redu en the power is ection is reset; ere are several 4 Electron <u>Settings</u> the parameter o prevent mote at / EoL2", and this paramete racteristic curv operation time rated	aces the action time is cycled frequently, ; therefore, even set I motors connected to nic Thermal Relation 30.0–600.0 sec. to 150% of motor rates or damage due to co d the motor coasts to er to set the action ti- re of electronic therr	to ensure the if the powe tting the para to one drive, y Action Ti ated current overheating. to stop. me of the el mal relay, the or from over	he life of mer is switch rameter to ameter to install an ime 1 (Mer t and use When it mer lectronic the e output fre heating.	otor. ned OFF, 0 or 1 ma electronic otor 1) Def with the se eaches th	the elec y not pr thermal ault: 60. etting of e setting	otect th otect th I relay in 0 Pr.06-7 g, the c	thermal relate motor we n each moto 14 and Pr.06 drive display sed on the la
therr Whe prote If the 06-1 Set t 28 to "EoL Use char the c ⁸ ⁰	mal relay redu en the power is ection is reset; ere are several 4 Electron <u>Settings</u> the parameter o prevent mote at / EoL2", and this paramete racteristic curv operation time rated	aces the action time is cycled frequently, ; therefore, even set I motors connected to nic Thermal Relation 30.0–600.0 sec. to 150% of motor rates or damage due to co d the motor coasts to er to set the action ti- re of electronic therr	to ensure the if the powe tting the para to one drive, y Action Ti ated current overheating. to stop. me of the el mal relay, the or from over	he life of mer is switch rameter to , install an ime 1 (Mer it mer otor. ned OFF, 0 or 1 ma electronic otor 1) Def with the se eaches th nermal rel equency a	the elec y not pr thermal ault: 60. etting of e setting	ctronic for otect the I relay in 0 Pr.06-7 g, the control of the prks base for the control of th	thermal relate motor we n each moto 14 and Pr.00 drive display	




1. Pr.06-13 or Pr.06-27 is set to 0 (using inverter motor):

When the output current of the drive is higher than 150% of the motor rated current (refer to the motor rated current % corresponded to the motor rated frequency in the motor cooling curve with independent fan), the drive starts to count the time. The electronic thermal relay acts when the accumulated time exceeds Pr.06-14 or Pr.06-28.

2. Pr.06-13 or Pr.06-27 is set to 1 (using standard motor):

When the output current of the drive is higher than 150% of the motor rated current (refer to the motor rated current % corresponded to the motor rated frequency in the motor cooling curve with shaft-fixed fan), the drive starts to count the time. The electronic thermal relay acts when the accumulated time exceeds Pr.06-14 or Pr.06-28.

The actual electronic thermal relay action time adjusts according to the drive output current (shown as the motor loading rate %). The action time is short when the current is high, and the action time is long when the current is low. Refer to the following diagram.



06-15 Temperature Level Overheat (OH) Warning

Default: 95.0

Settings 0.0-110.0°C

- The default value of this parameter is 105°C. The drive will not displays an OH overheating warning if the setting is not lowered. When the temperature reaches 100°C, the inverter will directly displays an IGBT overheating error and stop.
- **06-16** Stall prevention limit level

Default: 100

Settings 0–100% (Refer to Pr.06-03–Pr.06-04)

- Description: This parameter only works in VF control mode.
- Sets the over-current stall prevention level when the motor's operation frequency is larger than Pr.01-01 (base frequency).

⇔ Example: When Pr.06-03 = 150%, Pr.06-04 = 100% and Pr.06-16 = 80%.

The over-current stall prevention level during acceleration:

Pr.06-03 * Pr.06-16 = 150 x 80 % = 120%.

The over-current stall prevention level during operation:

Pr.06-04 * Pr.06-16 = 100 x 80 % = 80%.

06-17	Fault Record 1
06-18	Fault Record 2
06-19	Fault Record 3
06-20	Fault Record 4
06-21	Fault Record 5
06-22	Fault Record 6

Default: 0

- Settings 0: No fault record
 - 1: Over-current during acceleration (ocA)
 - 2: Over-current during deceleration (ocd)
 - 3: Over-current during steady operation (ocn)
 - 6: Over-current at stop (ocS)
 - 7: Over-voltage during acceleration (ovA)
 - 8: Over-voltage during deceleration (ovd)
 - 9: Over-voltage during constant speed (ovn)
 - 10: Over-voltage at stop (ovS)
 - 11: Low-voltage during acceleration (LvA)
 - 12: Low-voltage during deceleration (Lvd)
 - 13: Low-voltage at constant speed (Lvn)
 - 14: Low-voltage at stop (LvS)
 - 15: Phase loss protection (orP)
 - 16: IGBT overheating (oH1)
 - 18: IGBT temperature detection failure (tH1o)
 - 21: Over load (oL)
 - 22: Electronics thermal relay 1 protection (EoL1)
 - 26: Over torque 1 (ot1)
 - 28: Under current (uC)
 - 31: EEPROM read error (cF2)
 - 33: U-phase error (od1)
 - 34: V-phase error (od2)
 - 35: W-phase error (od3)
 - 36: cc hardware error (Hd0)
 - 37: oc hardware error (Hd1)
 - 49: External fault (EF)
 - 50: Emergency stop (EF1)
 - 51: External base block (bb)
 - 52: Password is locked (Pcod)
 - 54: Illegal command (CE1)
 - 55: Illegal data address (CE2)
 - 56: Illegal data value (CE3)
 - 57: Data is written to read-only address (CE4)
 - 58: Modbus transmission time-out (CE10)

- 62: Deceleration energy backup error (dEb)
- 79: U-phase over-current before run (Aoc)
- 80: V-phase over-current before run (boc)
- 81: W-phase over-current before run (coc)
- 82: U-phase output phase loss (oPHL)
- 83: V-phase output phase loss (oPHL)
- 84: W-phase output phase loss (oPHL)
- 87: Low frequency overload protection (oL3)
- 101: CANopen guarding error (CGdE)
- 102: CANopen heartbeat error (CHbE)
- 104: CANopen bus off error (CbFE)
- 105: CANopen index error (CidE)
- 106: CANopen station address error (CAdE)
- 107: CANopen index setting exceed limit (CFrE)
- 111: InrCOM time-out error (ictE)
- 121: Internal communication error (CP20)
- 123: Internal communication error (CP22)
- 124: Internal communication error (CP30)
- 126: Internal communication error (CP32)
- 127: Internal communication error (CP33)
- I The parameters record when the fault occurs and forces a stop.
- When low-voltage at stop fault (LvS) occurs, the fault is not recorded. When low-voltage during operation faults (LvA, Lvd, Lvn) occur, the faults are recorded.
- When dEb function is valid and enabled, the drive executes dEb and records fault code 62 to Pr.06-17–Pr.06-22 simultaneously.
- Ø6-23 Fault Output Option 1
- 66-24 Fault Output Option 2
- ✓ 06-25 Fault Output Option 3
- 06-26 Fault Output Option 4

Default: 0

Settings 0–65535 (refer to bit table for fault code)

Use these parameters with multi-function output terminal (set 06-23–Pr.06-26 to 35–38) for the specific requirement. When a fault occurs, the corresponding terminals are activated. Convert the binary value to a decimal value before you enter the value for Pr.06-23–Pr.06-26.

Fault Code	bit0	bit1	bit2	bit3	bit4	bit5	bit6
	current	Volt.	OL	SYS	FBK	EXI	CE
0: No fault record							
1: Over-current during acceleration (ocA)							
2: Over-current during deceleration (ocd)							
3: Over-current during steady operation (ocn)	•						

Fault Code	bit0	bit1	bit2	bit3	bit4	bit5	bit6
	current	Volt.	OL	SYS	FBK	EXI	CE
6: Over-current at stop (ocS)	•						
7: Over-voltage during acceleration (ovA)		•					
8: Over-voltage during deceleration (ovd)		•					
9: Over-voltage during constant speed (ovn)		•					
10: Over-voltage at stop (ovS)		•					
11: Low-voltage during acceleration (LvA)		•					
12: Low-voltage during deceleration (Lvd)		•					
13: Low-voltage at constant speed (Lvn)		•					
14: Low-voltage at stop (LvS)		•					
15: Phase loss protection (orP)		•					
16: IGBT overheating (oH1)			•				
18: IGBT temperature detection failure (tH1o)			•				
21: Over load (oL)			•				
22: Electronics thermal relay 1 protection (EoL1)			•				
26: Over torque 1 (ot1)			•				
28: Under current (uC)	•						
31: EEPROM read error (cF2)				•			
33: U-phase error (od1)				•			
34: V-phase error (od2)				•			
35: W-phase error (od3)				•			
36: cc hardware error (Hd0)				•			
37: oc hardware error (Hd1)				•			
49: External fault (EF)						•	
50: Emergency stop (EF1)						•	
51: External base block (bb)						•	
52: Password is locked (Pcod)				•			
54: Illegal command (CE1)							•
55: Illegal data address (CE2)							•
56: Illegal data value (CE3)							•
57: Data is written to read-only address (CE4)							•
58: Modbus transmission time-out (CE10)							•
62: Deceleration energy backup error (dEb)		•					
79: U-phase over-current before run (Aoc)	•						
80: V-phase over-current before run (boc)	•						
81: W-phase over-current before run (coc)	•						
82: Output phase loss U phase (OPHL)	•						
83: Output phase loss V phase (OPH2)	•						
84: Output phase loss W phase (OPH3)	•						

Fault Code	bit0	bit1	bit2	bit3	bit4	bit5	bit6
Fault Code	current	Volt.	OL	SYS	FBK	EXI	CE
87: Low frequency overload protection (oL3)			•				
101: CANopen guarding error (CGdE)							•
102: CANopen heartbeat error (CHbE)							•
104: CANopen bus off error (CbFE)							•
105: CANopen index error (CidE)							•
106: CANopen station address error (CAdE)							•
107: CANopen index setting exceed limit (CFrE)							•
111: InrCOM time-out error (ictE)							•
121: Internal communication error (CP20)							•
123: Internal communication error (CP22)							•
124: Internal communication error (CP30)							•
126: Internal communication error (CP32)							•
127: Internal communication error (CP33)							•

Frequency Command at Malfunction 06-31

Default: Read only

Settings 0.00–400.00 Hz

When a malfunction occurs, check the current Frequency command. If the error happens again, this parameter overwrites the previous record.

Output Frequency at Malfunction 06-32

Default: Read only

Settings 0.00-400.00 Hz

When a malfunction occurs, check the current output frequency. If the error happens again, this parameter overwrites the previous record.

06-33 Output Voltage at Malfunction

Default: Read only

Default: Read only

Settings 0.0–6553.5 V

When a malfunction occurs, check the current output voltage. If the error happens again, this parameter overwrites the previous record.

06-34 DC bus Voltage at Malfunction

> Settings 0.0–6553.5 V

When an error occurs, you can check the DC bus voltage for the malfunction. If the error happens again, this parameter overwrites the previous record.

06-35 Output Current at Malfunction

Default: Read only

Settings 0.00-655.35 Amps When an error occurs, you can check the output current for the malfunction. If the error happens again, this parameter overwrites the previous record.

06-36 IGBT Temperature at Malfunction

Default: Read only

Settings -3276.7-3276.7 °C

When a malfunction occurs, check the current IGBT temperature. If the error happens again, this parameter overwrites the previous record.

06-38 Motor Speed at Malfunction

Default: Read only

Settings -32767-32767 rpm

When a malfunction occurs, check the current motor speed in rpm. If the error happens again, this parameter overwrites the previous record.

06-39 Torque Command at Malfunction

Default: Read only

Settings -32767-32767 %

- When a malfunction occurs, check the current torque command. If the error happens again, this parameter overwrites the previous record.
 - 06-40 Status of the Multi-function Input Terminal at Malfunction

Default: Read only

Settings 0000h-FFFFh

06-41 Status of the Multi-function Output Terminal at Malfunction

Default: Read only

Settings 0000h-FFFFh

When a malfunction occurs, check the current status of the multi-function input / output terminals. If the error happens again, this parameter overwrites the previous record.

06-42 Drive Status at Malfunction

Default: Read only

Settings 0000h-FFFFh


When a malfunction occurs, check the current drive status (communication address 2101H). If the error happens again, this parameter overwrites the previous record.

✓ 06-45 Output Phase Loss Detection Action (OPHL)


Default: 3

- Settings 0: Warn and continue operation
 - 1: Warn and ramp to stop
 - 2: Warn and coast to stop
 - 3: No warning

The OPHL protection is enabled when Pr.06-45 is not set to 3.




After the drive starts, the DC brake operates according to Pr.07-01 and Pr.07-02. During this period, OPHL detection is not active. After the DC brake action is completed, the drive starts to run, and enables the OPHL protection as mentioned above for status 1.



□ Status 3: The drive is in STOP; Pr.06-48 \neq 0; Pr.07-02 \neq 0


When the drive starts, it executes Pr.06-48 first, and then executes Pr.07-02 (DC brake). The DC brake current level in this state includes two parts: one is 20 times the Pr.06-47 setting value in Pr.06-48 setting time; the other is the Pr.07-01 setting value in Pr.07-02 setting time. The total DC brake time T = Pr.06-48 + Pr.07-02.

Status 3-1: Pr.06-48 \neq 0; Pr.07-02 \neq 0 (No OPHL detected before operation)



Status 3-2: Pr.06-48 \neq 0; Pr.07-02 \neq 0 (OPHL detected before operation)


In this period, if an OPHL occurs within the time for Pr.06-48, the drive executes the Pr.06-45 setting after the drive starts counting for half the time of Pr.06-48.



□ Status 4: The drive is in STOP; Pr.06-48 ≠ 0; Pr.07-02=0


When the drive starts, it executes Pr.06-48 as the DC brake. The DC brake current level is 20 times the Pr.06-47 setting value.

Status 4-1: Pr.06-48 \neq 0; Pr.07-02 = 0 (No OPHL detected before operation)



Status 4-2: Pr.06-48 ≠ 0; Pr.07-02 = 0 (OPHL detected before operation)

In this period, if an OPHL occurs within the time for Pr.06-48, the drive executes the Pr.06-45 setting after the drive starts counting for half the time of Pr.06-48.



06-53 Input Phase Loss Detection Action (OrP) Default: 0 Settings 0: Warn and ramp to stop 1: Warn and coast to stop \square The drive executes the input phase loss protection according to Pr.06-53. 06-63 Operation Time of Fault Record 1 (Day) 06-65 Operation Time of Fault Record 2 (Day) 06-67 Operation Time of Fault Record 3 (Day) 06-69 Operation Time of Fault Record 4 (Day) 06-90 Operation Time of Fault Record 5 (Day) 06-92 Operation Time of Fault Record 6 (Day) Default: Read only Settings 0–65535 days 06-64 Operation Time of Fault Record 1 (Min.) 06-66 Operation Time of Fault Record 2 (Min.) 06-68 Operation Time of Fault Record 3 (Min.) 06-70 Operation Time of Fault Record 4 (Min.) 06-91 Operation Time of Fault Record 5 (Min.) 06-93 Operation Time of Fault Record 6 (Min.) Default: Read only

Settings 0–1439 min.

If there is any malfunction when the drive operates, Pr.06-17–06-22 records the malfunctions, and Pr.06-63–06-70 records the operation time for four sequential malfunctions. Check if there is any problem with the drive according to the interval of the recorded fault.

Example: The first error: ocA occurs after motor drive operates for 1000 minutes. The second error: ocd occurs after another 1000 minutes. The third error: ocn occurs after another 1000 minutes. The fourth error: ocA occurs after another 1000 minutes. The fifth error: ocd occurs after another 1000 minutes. The sixth error: ocn occurs after another 1000 minutes. Then, Pr.06-17–06-22 and Pr.06-63–06-70 are recorded as follows:

	1 st fault	2 nd fault	3 rd fault	4 th fault	5 th fault	6 th fault
Pr.06-17	ocA	ocd	ocn	ocA	ocd	ocn
Pr.06-18	0	ocA	ocd	ocn	ocA	ocd
Pr.06-19	0	0	ocA	ocd	ocn	ocA
Pr.06-20	0	0	0	ocA	ocd	ocn
Pr.06-21	0	0	0	0	ocA	ocd
Pr.06-22	0	0	0	0	0	ocA
Pr.06-63	1000	560	120	1120	680	240
Pr.06-64	0	1	2	2	3	4
Pr.06-65	0	1000	560	120	1120	680

Parameters are recorded as follows:

	1 st fault	2 nd fault	3 rd fault	4 th fault	5 th fault	6 th fault
Pr.06-66	0	0	1	2	2	3
Pr.06-67	0	0	1000	560	120	1120
Pr.06-68	0	0	0	1	2	2
Pr.06-69	0	0	0	1000	560	120
Pr.06-70	0	0	0	0	1	2

※ By examining the time record, you can see that the last fault (Pr.06-17) happened after the drive ran for four days and 240 minutes.

06-71 Low Current Setting Level Default: 0.0 Settings 0.0-100.0% 06-72 Low Current Detection Time Default: 0.00 Settings 0.00-360.00 sec. 06-73 Low Current Action Default: 0 Settings 0: No function 1: Warn and coast to stop 2: Warn and ramp to stop by the 2nd deceleration time 3: Warn and continue operation

The drive operates according to the setting for Pr.06-73 when the output current is lower than the setting for Pr.06-71 and when the time of the low current exceeds the detection time for Pr.06-72. Use this parameter with the external multi-function output terminal setting 44 (low current output).

Deliver the low current detection function does not execute when drive is in sleep or standby status.

07 Special Parameters

07-01 DC Brake Current Level

✓ You can set this parameter during operation.

Default: 0

Settings 0–100%

Sets the level of the DC brake current output to the motor at start-up and stop. When setting the DC brake current, the rated current is 100%. It is recommended that you start with a low DC brake current level and then increase until you reach the proper holding torque. However, the DC brake current cannot exceed the motor's rated current to prevent the motor from burnout. Therefore, DO NOT use the DC brake for mechanical retention, otherwise injury or accident may occur.

07-02 DC Brake Time At Start-up

Default: 0.0

Settings 0.0-60.0 sec.

The motor may continue rotating due to external forces or the inertia of the motor itself. If you use the drive with the motor rotating, it may cause motor damage or trigger drive protection due to over-current. This parameter outputs DC current, generating torque to force the motor stop to get a stable start before motor operation. This parameter determines the duration of the DC brake current output to the motor when the drive starts up. Set this parameter to 0.0 to disable the DC brake at start-up.

07-03 DC brake time at STOP

Default: 0.0

Settings 0.0-60.0 sec.


- The motor may continue rotating after the drive stops output due to external forces or the inertia of the motor itself. This parameter outputs DC current, generating torque to force the motor stop after the drive stops output to make sure that the motor stops.
- This parameter determines the duration of the DC Brake current output to the motor when braking. To enable the DC brake at STOP, you must set Pr.00-22 (Stop Method) to 0 (ramp to stop). Set this parameter to 0.0 to disable the DC brake at stop.
- Related parameters: Pr.00-22 Stop Method, Pr.07-04 DC Brake Frequency at STOP.

07-04 DC Brake Frequency at STOP

Default: 0.00

Settings 0.00-400.00 Hz

Determines the start frequency of the DC brake before the drive ramps to stop. When this setting is less than Pr.01-09 (Start-up Frequency), the start frequency for the DC brake begins at the minimum frequency.



DC Brake Output Timing Diagram

- Use the DC brake before running the motor when the load is movable at stop, such as with fans and pumps. The motor is in free running status and in unknown rotation direction before the drive starts up. Execute the DC brake before you start the motor.
- Use the DC Brake at STOP when you need to brake the motor quickly or to control the positioning. Such as cranes or cutting machines.

Default: 100

Settings 1-200%

When using speed tracking, adjust Pr.07-05 to slow down the increasing voltage gain if there are errors such as oL or oc; however, the speed tracking time will be longer.

07-06 Restart after momentary power loss Default: 0

Settings 0: Stop operation

- 1: Speed tracking by the speed before the power loss
- 2: Speed tracking by the minimum output frequency
- Determines the operation mode when the drive restarts from a momentary power loss.
- The power system connected to the drive may power off momentarily for many reasons. This function allows the drive to keep outputting voltages after the drive is re-powered and does not cause the drive to stop.
- 1: Frequency tracking begins before momentary power loss and accelerates to the master Frequency command after the drive output frequency and motor rotator speed are synchronous. It is recommended to use this setting when there is a lot of inertia with little resistance on the motor load. For example, in equipment with a large inertia flywheel, there is NO need to wait until the flywheel stops completely after a restart to execute the operation command; therefore, it saves time.
- 2: Frequency tracking starts from the minimum output frequency and accelerates to the master Frequency command after the drive output frequency and motor rotator speed are synchronous. It is recommended to use this setting when there is little inertia and large resistance.

× 07-07

Allowed Power Loss Duration

Default: 2.0

Default: 0.5


Settings 0.0–20.0 sec.

- Determines the maximum time of allowable power loss. If the duration of a power loss exceeds this parameter setting, the AC motor drive stops output after the power recovers.
- Pr.07-06 is valid when the AC motor drive displays "Lv" during the maximum allowable power loss time. If the AC motor drive is powered off due to overload, even if the maximum allowable power loss time is ≤ 20 seconds, the drive does not execute the operation mode you set for Pr.07-06. In that case it starts up normally.


✓ 07-08 Base Block Time

Settings 0.0–5.0 sec.

When momentary power loss is detected, the AC motor drive blocks its output and then waits for a specified period of time (determined by Pr.07-08, called Base Block Time) before resuming operation. Set this parameter to the time that allows the residual voltage at the output side to decrease to 0 V before activating the drive again.



B.B. Search with last output frequency downward timing chart



Over-current stall prevention action chart

07-09 Current Limit of Speed Tracking

Default: 100

Settings 20–200%

- The AC motor drive executes speed tracking only when the output current is greater than the value set in Pr.07-09.
- The maximum current for speed tracking affects the synchronous time. The larger the parameter setting, the faster the synchronization occurs. However, if the parameter setting is too large, the overload protection function may be activated.

×

07-10 Restart after Fault Action

Default: 0

Settings 0: Stop operation

1: Speed tracking by current speed

2: Speed tracking by the minimum output frequency

III Faults include: bb, oc, ov, occ. To restart after oc, ov, occ, you can NOT set Pr.07-11 to 0.

07-11 Number of Times of Restart after Fault

Default: 0

Default: 0

Settings 0–10

After fault (allowed fault: oc, ov, occ) occurs, the AC motor drive can reset and restart automatically up to 10 times. If Pr.07-11 is set to 0, the drive does not reset or restart automatically after faults occur. The drive starts according to the Pr.07-10 setting after restarting after fault.

- □ If the number of faults exceeds the Pr.07-11 setting, the drive does not reset and restart until you press "RESET" manually and execute the operation command again.
- **07-12** Speed Tracking During Start-up

Settings 0: Disabled

- 1: Speed tracking by the maximum output frequency
- 2: Speed tracking by the motor frequency at start-up
- 3: Speed tracking by the minimum output frequency

Speed tracking is suitable for punch, fans and other large inertia loads. For example, a mechanical punch usually has a large inertia flywheel, and the general stop method is coast to stop. If it needs to be restarted again, the flywheel may take 2–5 minutes or longer to stop. This parameter setting allows you to start the flywheel operating again without waiting until the flywheel stops completely.

07-13 dEb Function Selection

Default: 0

Settings 0: Disabled

1: dEb with auto-acceleration / auto-deceleration, the drive does not output the frequency after the power is restored.


2: dEb with auto-acceleration / auto-deceleration, the drive outputs the frequency after the power is restored.

- □ dEb (Deceleration Energy Backup) lets the motor decelerate to stop when momentary power loss occurs. When the power loss is instantaneous, use this function to let the motor decelerate to zero speed. If the power recovers at this time, the drive restarts the motor after the dEb return time.
- Lv return level: Pr.06-00 + 60 V / 30 V (460V models: 60V, 230V models: 30V)
- Lv level: Default is Pr.06-00.
- During dEb operation, other protection, such as ryF, ov, oc, occ, and EF may interrupt it, and these error codes are recorded.
- The STOP (RESET) command does not work during the dEb auto-deceleration, and the drive continues decelerating to stop. To make the drive coast to stop immediately, use another function (EF) instead.

- The B.B. function does not work when executing dEb. The B.B. function is enabled after the dEb function finishes.
- Even though the Lv warning does not display during dEb operation, if the DC bus voltage is lower than the Lv level, MO = 10 (Low voltage warning) still operates.
- Description: The following explains the dEb action:
- When the DC bus voltage drops below the dEb setting level, the dEb function starts to work (soft start relay remains closed), and the drive executes auto-deceleration.
 - Situation 1: Momentary power loss, or too low and unstable power voltage, or power supply sliding down because of sudden heavy load.

Pr.07-13=1, "dEb active, DC bus voltage returns, output frequency does not return" and power recovers.


When the power recovers and DC bus voltage exceeds the dEb return level, the drive linearly decelerates to 0 Hz and stops. The keypad displays the "dEb" warning until you manually reset it, so you can see the reason for the stop.



• Situation 2: Momentary power loss, or too low and unstable power voltage, or power supply sliding down because of sudden heavy load.

Pr.07-13=2 "dEb active, DC bus voltage returns, output frequency returns" and power recovers.


During the dEb deceleration (includes 0 Hz run), if the power recovers to a voltage higher than dEb return level, the drive maintains the frequency for three seconds and then accelerates again. The dEb warning on the keypad clears automatically.



• Situation 3: Unexpected power shut down or power loss

Pr.07-13=1 "dEb active, DC bus voltage returns, the output frequency does not return" and the power does not recover.

The keypad displays the "dEb" warning and the drive stops after decelerating to the lowest operating frequency. When the DC bus voltage is lower than the Lv level, the drive disconnects the soft start relay until the power completely runs out.




 Situation 4: Pr.07-13=2 "dEb active, DC bus voltage returns, the output frequency returns" and power does not recover.

Same as Situation 3. The drive decelerates to 0 Hz. The DC bus voltage continues to decrease until the voltage is lower than the Lv level, and then the drive disconnects the soft start relay. The keypad displays "dEb" warning until the drive completely runs out of power.


 Situation 5: Pr.07-13 = 2 and power recovers after the DC bus voltage is lower than the Lv level.

The drive decelerates to 0 Hz. The DC bus voltage continues to decrease until the voltage is lower than the Lv level, and then the drive disconnects the soft start relay. The soft start relay closes again after the power recovers and the DC bus voltage is higher than the Lv return level. When the DC bus voltage is higher than the dEb return level, the drive maintains the frequency for three seconds and starts to accelerate linearly. The "dEb" warning on the keypad is automatically cleared.



In heavy load situations, the Dwell temporarily maintains stable output frequency. Use this parameter for cranes, elevators, and so on.

When the load is heavier, use Pr.07-15–Pr.07-18 to avoid OV or OC protection.



- D: Fan runs immediately when the drive power is turned ON.
- 1: Fan runs when the AC motor drive runs. One minute after the AC motor drive stops, the fan is OFF.
- 2: Fan runs when the AC motor drive runs and stops immediately when the AC motor drive stops.
- 3: When temperature of the IGBT or capacitance is higher than 60°C, the fan runs. When both the temperature of the IGBT and capacitance are lower than 40°C, the fan stops.

07-20 Emergency Stop (EF) & Force To Stop Selection

Default: 0

Settings 0: Coast to stop

- 1: By the first deceleration time
- 2: By the second deceleration time
- 3: By the third deceleration time
- 4: By the fourth deceleration time
- 5: System deceleration
- 6: Automatic deceleration

When the multi-function input terminal setting is set to 10 (EF input) or 18 (force to stop) and the terminal contact is ON, the drive stops according to the setting of this parameter.

07-21

Automatic Energy-saving Setting

Default: 0

Settings 0: Disabled 1: Enable

- When energy-saving is enabled, the motor acceleration/deceleration operates with full voltage. During constant speed operation, it automatically calculates the best voltage value according to the load power. This function is not suitable for fluctuating loads or loads which are nearly full during operation.
- When the output frequency is constant (that is, constant operation), the output voltage decreases automatically as the load decreases. Therefore, the drive operates with minimum multiplication of voltage and current (electric power).

07-22 Energy-saving Gain

Default: 100

Settings 10–1000%

- When Pr.07-21 is set to 1, use this parameter to adjust the energy-saving gain. The default is 100%. If the result is not satisfactory, adjust it by decreasing the setting value. If the motor oscillates, then increase the setting value.
- In certain applications such as high speed spindles, the temperature rise in the motor is a major concern. When the motor is not in working state, reduce the motor current to a lower level. Reduce this parameter setting to meet this requirement.

07-23 Automatic Voltage Regulation (AVR) Function

Default: 0

Settings 0: Enable AVR

- 1: Disable AVR
- 2: Disable AVR during deceleration
- □ The rated voltage of a 220V motor is usually 200 V_{AC}, 60 Hz / 50 Hz, and the input voltage of the AC motor drive may vary from 180–264 V_{AC}, 50 Hz / 60 Hz. Therefore, when the AC motor drive is used without the AVR function, the output voltage is the same as the input voltage. When the motor runs at the voltage exceeding 12–20% of the rated voltage, it causes higher temperatures, damaged insulation, and unstable torque output, which result in losses due to shorter motor lifetime.
- The AVR function automatically regulates the output voltage of the AC motor drive to the motor's rated voltage when the input voltage exceeds the motor's rated voltage. For example, if the V/F curve is set at 200 V_{AC} / 50 Hz and the input voltage is at 200–264 V_{AC} , then the drive automatically reduces the output voltage to the motor to a maximum of 200 V_{AC} / 50 Hz. If the input voltage is at 180–200 V_{AC} , the output voltage to motor is in direct proportion to the input voltage.
- 0: When the AVR function is enabled, the drive calculates the output voltage according to the actual DC bus voltage. The output voltage does NOT change when the DC bus voltage changes.
- 1: When the AVR function is disabled, the drive calculates the output voltage according to the actual DC bus voltage. The output voltage changes with the DC bus voltage, and may cause insufficient current, over-current or oscillation.

- 2: The drive disables the AVR function only during deceleration to stop, and at this time, you can accelerate the braking to achieve the same result.
- When the motor ramps to stop, disable the AVR function to shorten the deceleration time. Then, use with the auto-acceleration and auto-deceleration functions to make the motor's deceleration more stable and quicker.

07-24 Torque Command Filter Time

07-25


Default: 0.050

Default: 0.100

Settings 0.001-10.000 sec.

Torque Command Filter Time

When the time constant setting is too large, the control is stable but the control response is slow. When the time constant setting is too small, the control response is faster but the control may be unstable. For optimal setting, adjust the setting based on the control stability or the control response.



07-32 Motor Oscillation Compensation Factor

Default: 1000

Settings 0–10000

The drift current occurs in a specific zone of the motor and it causes serious motor vibration. Adjust this parameter could greatly improve this situation. (When running with high frequency or PG, set this parameter to 0. When the current wave motion occurs in low frequency and high power, increase the value for Pr.07-32.)

×	07-33	Auto-restart Interval of Fault	
			Default: 60.0

Settings 0.0-6000.0 sec.

When a reset/restart occurs after a fault, the drive uses Pr.07-33 as a timer and starts counting the number of faults within this time period. Within this period, if the number of faults does not exceed the setting for Pr.07-11, the counting clears and starts from 0 when the next fault occurs.



07-63

Default: 8000

Default: 150

Settings 0-65535

Settings 0-65535

dEb Gain (Ki)

Sets the PI gain of DC bus voltage controller when the dEb function activates.

If the DC bus voltage drops too fast, or the speed oscillation occurs during deceleration after the dEb function activates, adjust Pr.07-62 and Pr.07-63. Increase the Kp setting to quicken the control response, but the oscillation may occur if the setting is too large. Use Ki parameter to decrease the steady-state error to zero, and increase the setting to quicken the response speed.

09 Communication Parameters

✓ You can set this parameter during operation.

There are two RJ45 interfaces on the control board of the EL-C series, the definitions are as follows:

Figure	PIN	Left RJ45	Rigjt RJ45
	1	CAN_H	CAN_H
	2	CAN_L	CAN_L
8 ←1	3	GND	GND
	4	NC	SG-
	5	NC	SG+
	6	NC	NC
	7	NC	NC
	8	NC	Vcc

NC stands for Not Connect

Pin3 GND of the right RJ45 interface is the common ground for CAN and RS-485.

The internal lines of the left RJ45 interface and the right RJ45 interface Pin1~3 are connected in parallel, logically they are only the same CAN interface.

09-00 Communication Address

Default: 1

Settings 1–254

Sets the communication address for the drive if the AC motor drive is controlled through RS-485 serial communication. The communication address for each AC motor drive must be unique.


×	09-01 COM1 Transmission Speed	
		Default: 9.6
	Settings 4.8–19.2 Kbps	

□ Sets the transmission speed between the computer and the AC motor drive.

- Options are 4.8 Kbps, 9.6 Kbps, 19.2 Kbps; otherwise, the transmission speed is set to the default 9.6 Kbps.
- **09-02** COM1 transmission fault handling

Default: 3

- Settings 0: Warn and continue operation
 - 1: Warn and ramp to stop
 - 2: Warn and coast to stop
 - 3: No Warn and continue operation
- Determines the treatment when an error is detected that the host controller does not continuously transmit data to the AC motor drive during Modbus communication. The detection time is based on the Pr.09-03 setting.
- When a transmission error occurs (for example, the error code CE10 displays), the error remains even if the transmission status returns to normal, and is not cleared automatically. In this case, set a reset command (Reset) to clear the error.



Control by PC (Computer Link)

When using the RS-485 serial communication interface, you must specify each drive's communication address in Pr.09-00. The computer then implements control using the drives' individual addresses.


Modbus ASCII (American Standard Code for Information Interchange): Each byte of data is the combination of two ASCII characters. For example, one byte of data: 64 Hex, shown as '64' in ASCII, consists of '6' (36Hex) and '4' (34Hex).


1. Code Description

The communication protocol is in hexadecimal, ASCII: "0" ... "9", "A" ... "F", every hexadecimal value represents an ASCII code. Example:

Character	'0'	'1'	'2'	'3'	'4'	ʻ5'	'6'	'7'
ASCII code	30H	31H	32H	33H	34H	35H	36H	37H
Character	'8'	'9'	'A'	'B'	'C'	'D'	'E'	'F'
ASCII code	38H	39H	41H	42H	43H	44H	45H	46H

2. Data Format





3. Communication Protocol

Communication Data Frame

ASCII mode:

STX	Start character = ':'(3AH)
Address High	Communication address:
Address Low	one 8-bit address consists of 2 ASCII codes
Function High	Command code:
Function Low	one 8-bit command consists of 2 ASCII codes
DATA (n-1)	Contents of data:
	n x 8-bit data consists of 2n ASCII codes
DATA 0	n \leq 16, maximum of 32 ASCII codes (20 sets of data)
LRC Check High	LRC checksum:
LRC Check Low	one 8-bit checksum consists of 2 ASCII codes
END High	End characters:
END Low	END High = CR (0DH), END Low = LF (0AH)

RTU mode:

START	A silent interval of more than 10 ms
Address	Communication address: 8-bit binary address
Function	Command code: 8-bit binary command
DATA (n-1)	
	Contents of data: n × 8-bit data, n ≤ 16
DATA 0	11×0 -bit data, $11 \ge 10$
CRC Check Low	CRC checksum:
CRC Check High	one 16-bit CRC checksum consists of 2 8-bit binary characters
END	A silent interval of more than 10 ms

Communication address

00H: Broadcast to all AC motor drives

01H: AC motor drive at address 01

0FH: AC motor drive at address 15

10H: AC motor drive at address 16, and so on up to 254 (FEH).

Function (Function code) and DATA (Data characters)

03H: Read data from register

06H: Write single register

Example: Reading two continuous data from register address 2102H. AMD address is 01H.

ASCII mode:

Command Message		Response Message	
STX ':'		STX	(_) -
Address	ʻ0'	Address	ʻ0'
Address	'1'	Address	'1'
Function	ʻ0'	Function	ʻ0'
Function	'3'	Function	'3'
	'2'	Number of register	ʻ0'
Storting register	'1'	(count by byte)	'4'
Starting register	ʻ0'		'1'
	'2'	Content of starting	'7'
Number of register	ʻ0'	register 2102H	'7'
	ʻ0'		ʻ0'
(count by word)	ʻ0'		ʻ0'
	'2'	Content of register	ʻ0'
LRC Check	'D'	2103H	ʻ0'
LRC Check	'7'		ʻ0'
END	CR	LRC Check	'7'
	LF		'1'
		END	CR
			LF

RTU mode:

Command Message		Response	Message
Address	Address 01H		01H
Function	03H	Function	03H
Starting data register	21H	Number of register	04H
Starting data register	02H	(count by byte)	04⊓
Number of register (count by word)	00H	Content of register	17H
	02H	address 2102H	70H
CRC Check Low	6FH	Content of register	00H
CRC Check High	F7H	address 2103H	00H
		CRC Check Low	FEH
		CRC Check High	5CH

06H: Single write, write single data to a register

Example: Writing data 6000 (1770H) to register 0100H. AMD address is 01H.

ASCII mode:

Command	l Message	Response Message	
STX	STX ⁽		۰.,
Addus s	·0'	A data a s	·0'
Address	'1'	Address —	'1'
Function	·0'	Function	ʻ0'
Function	·6'	Function —	'6'
	·0'		·0'
Townet ve sister	'1'	Target to gister	'1'
Target register	·0'	Target register	·0'
	·0'		·0'
	'1'		'1'
De sister e sutent	'7'		'7'
Register content	'7'	Register content	'7'
	·0'		·0'
L DC Check	'7'		'7'
LRC Check	'1'	LRC Check	'1'
END	CR	END	CR
	LF		LF

RTU mode:

Command Message		Response Message	
Address	Address 01H		01H
Function	06H	Function	06H
Target register	01H	Target register	01H
	00H	Target register	00H
Pogiator content	17H	Pagiatar contant	17H
Register content	70H	Register content	70H
CRC Check Low	86H	CRC Check Low	86H
CRC Check High 22H		CRC Check High	22H

10H: Write multiple registers (can write at most 20 sets of data simultaneously). Example: Set the multi-step speed of an AC motor drive (address is 01H):

Pr.04-00 = 50.00 (1388H), Pr.04-01 = 40.00 (0FA0H)

ASCII mode:

Command Message		Response	Message
STX	(.)	STX	د_ع -
ADR 1	ʻ0'	ADR 1	ʻ0'
ADR 0	'1'	ADR 0	'1'
CMD 1	'1'	CMD 1	'1'

Command	Message	Response Message	
CMD 0	'0'	CMD 0	'0'
Townet versioter	'0'	Torret register	'0'
Target register	'5'	Target register	'5'
Target register	ʻ0'	Target register	ʻ0'
Target register	ʻ0'	Target Tegister	ʻ0'
	ʻ0'		ʻ0'
Number of register	ʻ0'	Number of register	ʻ0'
(count by word)	ʻ0'	(count by word)	ʻ0'
	'2'		'2'
Number of register	ʻ0'	LRC Check	'E'
(count by byte)	'4'		'8'
	'1'	END	CR
The first data content	'3'		LF
	'8'		
	'8'		
The encoded data	ʻ0'		
The second data content	'F'		
content	'A'		
	ʻ0'		
LRC Check	ʻ9'		
	'A'		
END	CR		
END	LF		

RTU mode:

Command Message		
ADR	01H	
CMD	10H	
Torget register	05H	
Target register	00H	
Number of register	00H	Ν
(count by word)	02H	
Quantity of data (byte)	04	(
The first data content	13H	C
The first data content	88H	
The second data	0FH	
content	A0H	
CRC Check Low	·9'	
CRC Check High	'A'	

 Response Message				
ADR	01H			
CMD 1	10H			
Tanadaa sistaa	05H			
Target register	00H			
Number of register	00H			
(count by word)	02H			
CRC Check Low	41H			
CRC Check High	04H			

ASCII mode (LRC Check):

LRC (Longitudinal Redundancy Check) is calculated by summing up the values of the bytes from Address to the end of Data Content Take the above 3.3.1 Command Message for example: 01H + 03H + 21H + 02H + 00H + 02H = 29H, take complementary number of 2 = D7H

RTU mode (CRC Check):

CRC (Cyclical Redundancy Check) starts from Address to the end at Data Content. It is calculated by the following steps:

Step 1: Load a 16-bit register (called CRC register) with FFFFH.

- Step 2: Exclusive OR the first 8-bit byte of the command message with the low order byte of the 16-bit CRC register, and put the result in the CRC register.
- Step 3: Shift one CRC register to the right, and fill the high position with 0.
- Step 4: Check the value shifted right, if it is 0, store the new value in step 3 into the CRC register, otherwise Exclusive OR A001H and the CRC register, and store the result into the CRC register.
- Step 5: Repeat step 3 and 4 until you perform eight shifts. This processes a complete 8-bit byte.
- Step 6: Repeat step 2 through 5 for the next 8-bit byte of the command message. Continue doing this until all bytes are processed. The final contents of the CRC register are the CRC value. Be share to check the code of the CRC must be exchanged and placed in the check code of the message command.

The following is an example of CRC generation using C language. The function takes two arguments:

Unsigned char* data \leftarrow a pointer to the message buffer

Unsigned char length \leftarrow the quantity of bytes in the message buffer

The function returns the CRC value as a type of unsigned integer. Unsigned int crc_chk(unsigned char* data, unsigned char length)

{

```
int j;
unsigned int reg_crc=0xffff;
while(length--){
    reg_crc ^= *data++;
    for(j=0;j<8;j++){
        if(reg_crc & 0x01){ /* LSB(b0)=1 */
            reg_crc=(reg_crc>>1) ^ 0Xa001;
        }else{
            reg_crc=reg_crc >>1;
        }
    }
    return reg_crc; // return register CRC
```

}

4. Address list

AC motor drive parameters

Modbus address	Function
GGnnH	GG is the parameter group, nn is the parameter number. For example, the address
	of Pr.04-10 is 040AH.

Control command (20xx)

Modbus address	Attribute	Function Description	
			00B: No function
			01B: Stop
		bit1–0	10B: Run
			11B: JOG + RUN
		bit3–2	Reserved
			00B: No function
		1.15	01B: FWD direction
		bit5–4	10B: Direction reverse
			11B: Change direction
			00B: 1st accel. / decel.
		bit7–6	01B: 2nd accel. / decel.
		DIL7-0	10B: 3rd accel. / decel.
			11B: 4th accel. / decel.
			0000B: Master speed
			0001B: 1st step speed
2000H	RW	bit11–8	0010B: 2nd step speed
			0011B: 3rd step speed
			0100B: 4th step speed
			0101B: 5th step speed
			0110B: 6th step speed
			0111B: 7th step speed
			1000B: 8th step speed
			1001B: 9th step speed
			1010B: 10th step speed
			1011B: 11th step speed
			1100B: 12th step speed
			1101B: 13th step speed
			1110B: 14th step speed
			1111B: 15th step speed
		bit12	1: Enable bit 06–11 function
		bit14–13	00B: No function

Modbus address	Attribute	Function Description		
		01B: Operation command by the digital keypad		
			10B: Operation command by Pr.00-21 setting	
		11B: Switch the operation command source		
		bit15 Reserved		
2001H	RW	Frequency command (XXX.XX Hz)		
		bit0 1: E.F. (External Fault) ON		
200211	RW	bit1	1: Reset command	
2002H		bit2	1: Base Block (B.B) ON	
			bit15–3 Reserved	

Status monitor read only (21xx)

Modbus	Attribute	Function Description		
address				
2100H	R	High byte: Warn Code		
		Low byte	: Error code	
			AC motor drive operation status	
			00B: The drive stops	
		bit1–0	01B: The drive is decelerating	
			10B: The drive is in standby status	
			11B: The drive is operating	
		bit2	1: JOG command	
			Operation direction	
			00B: FWD running	
	R	bit4–3	01B: From REV running to FWD running	
2101H			10B: From FWD running to REV running	
			11B: REV running	
		bit 8	1: Master frequency controlled by the communication interface	
		bit 9	1: Master frequency controlled by the analog / external terminal signal	
		bit10	1: Operation command controlled by the communication	
			interface	
		bit11	1: Parameter lock	
		bit12	1: Enable the digital keypad copy parameter function	
		bit15–13 Reserved		
2102H	R	Frequency command (XXX.XX Hz)		
2103H	R	Output frequency (XXX.XX Hz)		
210411	R	Output current (XX.XX A). When current is higher than 655.35, it shifts		
2104H		the decimal as (XXX.X A) The decimal can refer to High byte of 211F.		
2105H	R	DC bus voltage (XXX.X V)		

Modbus address	Attribute	Function Description	
2106H	R	Output voltage (XXX.X V)	
2107H	R	Current step for the multi-step speed operation	
2108H	R	Reserved	
2109H	R	Counter value	
210AH	R	Output power factor angle (XXX.X)	
210BH	R	Output torque (XXX.X %)	
210CH	R	Actual motor speed (XXXXX rpm)	
210FH	R	Prompt Power output (X.XXX kW)	
2116H	R	Multi-function display (Pr.00-04)	
211BH	R	Maximum Operation Frequency (Pr.01-00) or Maximum User-defined Value (Pr.00-26) When Pr.00-26 is 0, this value is equal to Pr.01-00 setting. When Pr.00-26 is not 0, and the command source is keypad, this value = Pr.00-24 * Pr.00-26 / Pr.01-00. When Pr.00-26 is not 0, and the command source is 485, this value = Pr.09-10 * Pr.00-26 / Pr.01-00.	
211FH	R	High byte: the decimal place of current value (display)	

Status monitor read only (22xx)

Modbus address	Attribute	Function Description	
2200H	R	Display the drive's output current. When the current is higher than 655.35, it automatically shifts one decimal place as (XXX.X A). The decimal can	
		refer to High byte of 211F.	
2201H	R	Counter value	
2202H	R	Actual output frequency (XXXXX Hz)	
2203H	R	DC bus voltage (XXX.X V)	
2204H	R	Output voltage (XXX.X V)	
2205H	R	Power factor angle (XXX.X)	
2206H	R	Display the output power of U, V, W (XXXX.X kW)	
2207H	R	Display motor speed in rpm estimated by the drive (XXXXX rpm)	
2208H	R	Display positive / negative output torque in %, estimated by the drive	
22000	ĸ	(XXX.X%)	
220DH	R	Reserved	
220EH	R	IGBT temperature of drive power module (XXX.X °C)	
220FH	R	Reserved	
2210H	R	The digital input status (ON / OFF), refer to Pr.02-12	
22100		(see Explanation 3 in Pr.00-04)	

Modbus address	Attribute		Function Description		
2211	Р	The digital output status (ON / OFF), refer to Pr.02-18			
2211H	R	(see Explanation 4 in Pr.00-04)			
2212H	R	Current st	ep for the multi-step speed operation		
00101	Р	The corre	sponding CPU digital input pin status (d.)		
2213H	R	(see Expla	anation 3 in Pr.00-04)		
22141	Р	The corre	sponding CPU digital output pin status (O.)		
2214H	R	(see Expla	anation 4 in Pr.00-04)		
2215H	R	Reserved			
2216H	R	Reserved			
2217H	R	Reserved			
2218H	R	Reserved			
2219H	R	Display tir	nes of counter overload (XXX.XX%)		
221BH	R	DC bus vo	oltage ripples (XXX.X V)		
221CH	R	Reserved			
221DH	R	Magnetic	field area of the synchronous motor		
221EH	R	User page	e displays the value in physical measure		
221FH	R	Output va	lue of Pr.00-05 (XXX.XX Hz)		
000011	P	The number of revolutions of the motor			
2220H	2220H R		(retained when stopped, reset to zero before running)		
2221H	Р	The running position of the motor			
222111	R	(retained	when stopped, reset to zero before running)		
2222H	R	Reserved			
2223H	R	Control mode of the drive 0: speed mode			
2224H	R	Carrier fre	equency of the drive (XX kHZ)		
2225H	R	Reserved			
		Motor drive status			
		(00b: No direction		
		bit1–0	01b: Forward		
			10b: Reverse		
2226H	R	bit3–2	01b: Drive ready		
222011	N	DIL3-2	10b: Error		
		bit4	0b: Motor drive does not output		
		5114	1b: Motor drive outputs		
		bit 5	0b: No warning		
		Sico	1b: Warning		
2227H	R	Drive's estimated output torque (positive or negative direction)			
		(XXXX Nt	-m)		
2228H	R	Reserved			
2229H	R	Accumulate KWH display (XXXX.X)			

Modbus address	Attribute	Function Description	
222AH	R	Reserved	
222BH	R	Reserved	
222CH	R	Motor actual position low character	
222DH	R	Motor actual position high character	
222EH	R	Reserved	
222FH	R	Reserved	
2230H	R	Reserved	
2231H	R	Reserved	

Remote IO (26xx)

Modbus Address	Attribute	Function Description	
		bit0	MI1 is turned on = 1, MI1 is not turned on = 0
		bit1	MI2 is turned on = 1, MI2 is not turned on = 0
2600	R	bit2	MI3 is turned on = 1, MI3 is not turned on = 0
2600H		bit3	MI4 is turned on = 1, MI4 is not turned on = 0
		bit4	MI5 is turned on = 1, MI51 is not turned on = 0
		bit 5	MI6 is turned on = 1, MI6 is not turned on = 0
	RW	bit0	bit0 = 1, MO1 is forced to turn on. MO1 is not turned on when
			bit0 is cleared to 0.
		bit1	bit1 = 1, MO2 is forced to turn on. MO2 is not turned on when
264011			bit1 is cleared to 0.
2640H		bit2	bit2 = 1, MO3 is forced to turn on. MO3 is not turned on when
			bit2 is cleared to 0.
		bit3	bit3 = 1, MO4 is forced to turn on. MO4 is not turned on when
			bit3 is cleared to 0.

5. Exception response:

When the drive is using the communication connection, if an error occurs, the drive responds to the error code and sets the highest bit (bit 7) of the command code to 1 (function code AND 80H) then responds to the control system to signal that an error occurred. If the keypad displays "CEXX" as a warning message, "XX" is the error code at that time. Refer to the table of error codes for communication error for reference.

Example:

RTU mode:

01H

86H

02H

C3H

A1H

7,0011		
STX	4.3	Address
Addroop	·0'	Function
Address	'1'	Exception code
Function	'8'	CRC Check Low
Function	'6'	CRC Check High
Exception code	ʻ0'	
Exception code	'2'	
LRC Check	'7'	
LKC Check	'7'	
END	CR	
LIND	LF	

The explanation of exception codes:


Error code	Fault Descriptions	
1	Function code is not supported or unrecognized.	
2	Address is not supported or unrecognized.	
3	Data is not correct or unrecognized.	
4 Failure to execute this function code		

09-09 Communication Response Delay Time

Default: 2.0

Settings 0.0-200.0 ms

If the host controller does not finish the transmitting / receiving process, you can use this parameter to set the response delay time after the AC motor drive receives communication command.



09-10 Communication Main Frequency

Default: 60.00

Settings 0.00–400.00 Hz

- When Pr.00-20 is set to 1 (RS-485 serial communication input) The AC motor drive saves the last Frequency command into Pr.09-10 when there is abnormal power off or momentary power loss. When power is restored, the AC motor drive operates with the frequency in Pr.09-10 if there is no new Frequency command input. When a Frequency command of 485 changes (the Frequency command source must be set as Modbus), this parameter also changes.
- 09-11 Block Transfer 1 09-12 Block Transfer 2 09-13 **Block Transfer 3** 09-14 Block Transfer 4 09-15 Block Transfer 5 09-16 Block Transfer 6 09-17 Block Transfer 7 Block Transfer 8 09-18 09-19 **Block Transfer 9** 09-20 Block Transfer 10 09-21 Block Transfer 11 09-22 Block Transfer 12 09-23 Block Transfer 13 09-24 Block Transfer 14 09-25 Block Transfer 15 09-26 Block Transfer 16

Default: 0

Settings 0-65535

There is a group of block transfer parameters available in the AC motor drive (Pr.09-11–Pr.09-26). Using communication code 03H, you can store the parameters (Pr.09-11–Pr.09-26) that you want to read.

Default: 1

Settings 0: Decoding method 1

1: Decoding method 2

Communication Decoding Method		Decoding Method 1	Decoding Method 2	
	Digital Keypad	Digital keypad controls the drive action regardless of decoding method 1 or 2.		
Source of Operation	External Terminal	External terminal controls the drive action regardless of decoding method 1 or 2.		
Control	RS-485	Refer to address: 2000h–20FFh	Refer to address: 6000h–60FFh	
	CANopen	Refer to index: 2020-01h–2020-FFh	Refer to index: 2060-01h–2020-FFh	

09-36	CANope	en Slave Address	
			Default: 0
	Settings 0: Disable		
		1–127	
09-37	CANope	en Speed	
			Default: 0
	Settings	0: 1 Mbps	
		1: 500 Kbps	
		2: 250 Kbps	
		3: 125 Kbps	
		4: 100 Mbps (Delta Only)	
		5: 50 Kbps	
09-39	CANope	en Warning Record	
			Default: 0
	Settings	bit 0: CANopen Guarding Time-out	
ł		bit 1: CANopen Heartbeat Time-out	
bit 3: CANopen SDO time-out			
bit 4: CANopen SDO buffer overflow			
bit 5: CANopen Bus OFF		bit 5: CANopen Bus OFF	
bit 6: Error protocol for CAN		bit 6: Error protocol for CANopen	
09-40	CANope	en Decoding Method	
			Default: 1
	Settings	0: Use Delta-defined decoding method	
		1: Use CANopen Standard DS402 protocol	
09-41	CANope	en Communication Status	
			Default: Read only
	Settings	0: Node Reset State	
		1: Com Reset State	
		2: Boot up State	
		3: Pre-operation State	
		4: Operation State	
		5: Stop State	

10 Speed Feedback Control Parameters

✓ You can set this parameter during operation.

10-29 Upper Limit of Frequency Deviation

Default: 20.00

Settings 0.00-200.00 Hz

Limits the maximum frequency deviation.

If you set this parameter too high, an abnormal feedback malfunction occurs.


[This page intentionally left blank]

12 System control and CANopen function parameters

✓ You can set this parameter during operation.

12-00	System control				
			Default: 0		
	Settings	bit 3: Dead time compensation closed			
		bit 7: Save or do not save the frequency			
12-01	PWM mode selection				
			Default: 2		
	Settings	0: Two-phase modulation mode			
		2: Space vector modulation mode			
🛄 Two-ph	ase modula	ation mode: Effectively reduces the drive powe	er component losses and provides		
better p	better performance in long wiring applications.				

Space vector modulation mode: Effectively reduces the power loss and electromagnetic noise of the motor.



Default: 0000

Settings 0000–FFFFh

The bit setting function are as follows, please do not set the function as a reserved bit arbitrarily to avoid abnormal control and device damage.

bit No.	Functions	Descriptions
0	Reserved	
1	FWD / REV action	0: FWD / REV cannot be controlled by Pr.02-12 bit 0 & 1.
I	control	1: FWD / REV can be controlled by Pr.02-12 bit 0 & 1.
2–15	Reserved	

12-03 CANopen Cycle Time Setting

		Default: 50
Settings	1–400 ms	
CANope	n Online Response Time	
		Default: 1000
Settings	1–30000 ms	
CANope	n Detects Master Time	
		Default: 1000
Settings	1–30000 ms	
CANope	n Detects Master Number	
		Default: 127
Settings	1–127	
	CANope Settings CANope Settings CANope	CANopen Online Response Time Settings 1–30000 ms CANopen Detects Master Time Settings 1–30000 ms CANopen Detects Master Number

•		2 .		
12-07 CANopen Protocol Selection				
			Default: 0	
	Settings	0: Standard CiA402 Protocol		
		1: Customization		
🕮 When P	r.12-07 = (), the CANopen decoding method needs to be	e selected with Pr. 09-30 and 09-	
40.				
🛄 When P	r.12-07 = 1	l, the settings of Pr.09-30 and 09-40 are invali	d.	
12-08	CANope	en MO1 Disconnection Disposal		
			Default: 2	
	Settings	0: MO1 output disconnected		
		1: MO1 output closed		
		2: MO1 output maintains the previous state		
12-09	CANope	en MO2 Disconnection Disposal		
			Default: 2	
	Settings	0: MO2 output disconnected		
		1: MO2 output closed		
		2: MO2 output maintains the previous state		
12-10 CANopen MO3 Disconnection Disposal				
			Default: 2	
	Settings	0: MO3 output disconnected		
		1: MO3 output closed		
		2: MO3 output maintains the previous state		
12-11	CANope	en MO4 Disconnection Disposal		
			Default: 2	
	Settings	0: MO4 output disconnected		
		1: MO4 output closed		
		2: MO4 output maintains the previous state		
🚇 Pr.12-08	3–12-11 ar	e valid only when Pr.12-07 = 1.		
12-12	CANope	en TPDO Delay Time		
			Default: 20.0	
	Settings	0.0–100.0%		
🕮 When th	ne slave sta	ation receives the SYNC signal from the mast	er station, after delaying the time	
of Pr.12	-12, it start	s to return the TPDO status to the master stat	tion.	
🛄 The dela	ay time is o	calculated as: Pr.12-12 x Pr.12-03		
Example	e: Pr.12-03	s = 50 ms, Pr.12-12 = 20.0		

The delay time = 50 ms÷100 x 20.0 = 500 us x 20.0 = 10 ms

- **12-50** Output Frequency at Malfunction 2
- **12-54** Output Frequency at Malfunction 3
- **12-58** Output Frequency at Malfunction 4
- **12-62** Output Frequency at Malfunction 5
- **12-66** Output Frequency at Malfunction 6

Default: Read only

Settings 0.00–400.00 Hz

When a fault occurs, user can check the current output frequency. If the fault happens again, this parameter overwrites the previous record.

12-51	DC bus Voltage at Malfunction 2
12-55	DC bus Voltage at Malfunction 3
12-59	DC bus Voltage at Malfunction 4
12-63	DC bus Voltage at Malfunction 5

- 12-63 DC bus Voltage at Malfunction 5
- **12-67** DC bus Voltage at Malfunction 6

Default: Read only

Settings 0.0-6553.5 V

When a fault occurs, user can check the current DC bus voltage. If the fault happens again, this parameter overwrites the previous record.

- **12-52** Output Current at Malfunction 2
- **12-56** Output Current at Malfunction 3
- **12-60** Output Current at Malfunction 4
- **12-64** Output Current at Malfunction 5
- **12-68** Output Current at Malfunction 6

Default: Read only

Settings 0.00-655.35 Amps

When a fault occurs, user can check the current output current value. If the fault happens again, this parameter overwrites the previous record.

12-53	IGBT Temperature at Malfunction 2
12-57	IGBT Temperature at Malfunction 3
12-61	IGBT Temperature at Malfunction 4
12-65	IGBT Temperature at Malfunction 5
12-69	IGBT Temperature at Malfunction 6

Default: Read only

Settings -3276.7-3276.7 °C

When a fault occurs, user can check the current IGBT temperature. If the fault happens again, this parameter overwrites the previous record.

apter 6 Descrip	otions of Para	ameter Settings EL-C
12-70 12-71 12-72 12-73	Fault Re Fault Re Fault Re Fault Re	ecord 8
		Default: 0
	Settings	0: No fault record
		1: Over-current during acceleration (ocA)
		2: Over-current during deceleration (ocd)
		3: Over-current during steady operation (ocn)
		6: Over-current at stop (ocS)
		7: Over-voltage during acceleration (ovA)
		8: Over-voltage during deceleration (ovd)
		9: Over-voltage during constant speed (ovn)
		10: Over-voltage at stop (ovS)
		11: Low-voltage during acceleration (LvA)
		12: Low-voltage during deceleration (Lvd)
13: Low-voltage at constant speed (Lvn)		13: Low-voltage at constant speed (Lvn)
		14: Low-voltage at stop (LvS)
		15: Phase loss protection (orP)
		16: IGBT overheating (oH1)
		18: IGBT temperature detection failure (tH1o)
		21: Over load (oL)
		22: Electronics thermal relay 1 protection (EoL1)
		26: Over torque 1 (ot1)
		28: Under current (uC)
		31: EEPROM read error (cF2)
		33: U-phase error (od1)
		34: V-phase error (od2)
		35: W-phase error (od3)
		36: cc hardware error (Hd0)
		37: oc hardware error (Hd1)
		49: External fault (EF)
		50: Emergency stop (EF1)
		51: External base block (bb)
		52: Password is locked (Pcod)
		54: Illegal command (CE1)
		55: Illegal data address (CE2)
		56: Illegal data value (CE3)
		57: Data is written to read-only address (CE4)
		58: Modbus transmission time-out (CE10)

- 62: Deceleration energy backup error (dEb)
- 79: U-phase over-current before run (Aoc)

- 80: V-phase over-current before run (boc)
- 81: W-phase over-current before run (coc)
- 82: U-phase output phase loss (oPHL)
- 83: V-phase output phase loss (oPHL)
- 84: W-phase output phase loss (oPHL)
- 87: Low frequency overload protection (oL3)
- 101: CANopen guarding error (CGdE)
- 102: CANopen heartbeat error (CHbE)
- 104: CANopen bus off error (CbFE)
- 105: CANopen index error (CidE)
- 106: CANopen station address error (CAdE)
- 107: CANopen index setting exceed limit (CFrE)
- 111: InrCOM time-out error (ictE)
- 121: Internal communication error (CP20)
- 123: Internal communication error (CP22)
- 124: Internal communication error (CP30)
- 126: Internal communication error (CP32)
- 127: Internal communication error (CP33)
- I The parameters record when the fault occurs and forces a stop.
- Low voltage Lv (LvS warning, not record) during stop. Low voltage Lv during operation (LvA, Lvd, Lvn fault will be recorded).
- When dEb function is valid and enabled, the drive executes dEb and records fault code 62 to Pr.06-17–Pr.06-22 and Pr.12-70–Pr.12-73 simultaneously.

[This page intentionally left blank]

13 Control Mode Parameter Macro Function

✓ You can set this parameter during operation.

13-00 Macro Selection

Default: 0

- Settings 0: No function
 - 1: By user
 - 2: I/O mode control
 - 3: CANopen remote control and monitoring mode
 - 4: I/O control and CANopen remote monitoring mode

Setting 2: I/O mode control

Pr.	Parameter Name	ID*	Note
00-11	Speed control selections	Default setting	0 (IM V/F)
00-16	Load selection	Default setting	1 (Heavy load)
00-20	Master frequency command source	0	0 (Digital keypad)
00-21	Operation command source	1	1 (External terminals)
01-12	Acceleration Time 1	Default setting	10s
01-13	Deceleration Time 1	Default setting	10s
02-00	Two-wire / Three-wire Operation Control	Default setting	1 (two-wire mode 1, power on for operation control (M1: FWD / STOP, M2: REV / STOP))
02-01	Multi-function Input Command 1 (MI1)	Default setting	
02-02	Multi-function Input Command 2 (MI2)	Default setting	
02-03	Multi-function Input Command 3 (MI3)	1	1 (Multi-step speed command 1)
02-04	Multi-function Input Command 4 (MI4)	2	2 (Multi-step speed command 2)
02-05	Multi-function Input Command 5 (MI5)	3	3 (Multi-step speed command 3)
02-06	Multi-function Input Command 6 (MI6)	4	4 (Multi-step speed command 4)
02-13	Multi-function Output 1 (MO1)	11	11 (Malfunction indication)
02-14	Multi-function Output 2 (MO2)	1	1 (Indication during RUN)
02-15	Multi-function Output 3 (MO3)	0	No function

Chapter 6 Descriptions of Parameter Settings | EL-C

Pr.	Parameter Name	ID*	Note
02-16	Multi-function Output 4 (MO4)	0	No function

□ Setting 3: CANopen remote control and monitoring mode

Pr.	Parameter Name	ID*	Note
00-11	Selections of control	Default setting	0 (IM V/F)
00-16	Load selection	Default setting	1 (Heavy load)
00-20	Master frequency command source	Default setting	6 (CANopen communication)
00-21	Operation command source	Default setting	3 (CANopen communication)
01-12	Acceleration Time 1	Default setting	10s
01-13	Deceleration Time 1	Default setting	10s
02-00	Two-wire / Three-wire Operation Control	Default setting	1 (two-wire mode 1, power on for operation control (M1: FWD / STOP, M2: REV / STOP))
02-01	Multi-function Input Command 1 (MI1)	Default setting	0 (DI terminal status is mapped to CANopen index 2026-01h)
02-02	Multi-function Input Command 2 (MI2)	Default setting	0 (DI terminal status is mapped to CANopen index 2026-01h)
02-03	Multi-function Input Command 3 (MI3)	Default setting	0 (DI terminal status is mapped to CANopen index 2026-01h)
02-04	Multi-function Input Command 4 (MI4)	Default setting	0 (DI terminal status is mapped to CANopen index 2026-01h)
02-05	Multi-function Input Command 5 (MI5)	Default setting	0 (DI terminal status is mapped to CANopen index 2026-01h)
02-06	Multi-function Input Command 6 (MI6)	Default setting	0 (DI terminal status is mapped to CANopen index 2026-01h)
02-13	Multi-function Output 1 (MO1)	Default setting	5 (DO terminal status is mapped to CANopen index 2026-41h)
02-14	Multi-function Output 2 (MO2)	Default setting	5 (DO terminal status is mapped to CANopen index 2026-41h)
02-15	Multi-function Output 3 (MO3)	Default setting	5 (DO terminal status is mapped to CANopen index 2026-41h)
02-16	Multi-function Output 4 (MO4)	Default setting	5 (DO terminal status is mapped to CANopen index 2026-41h)
09-37	CANopen Speed	2	CiA301 250kbps support line length 250m

Pr.	Parameter Name	ID*	Note
00-11	Selections of control	Default setting	0 (IM V/F)
00-16	Load selection	Default setting	1 (Heavy load)
00-20	Master frequency command source	0	0 (Digital keypad)
00-21	Operation command source	1	1 (External terminals)
01-12	Acceleration Time 1	Default setting	10s
01-13	Deceleration Time 1	Default setting	10s
02-00	Two-wire / Three-wire Operation Control	Default setting	1 (two-wire mode 1, power on for operation control (M1: FWD / STOP, M2: REV / STOP))
02-01	Multi-function Input Command 1 (MI1)	Default setting	0 (DI terminal status is mapped to CANopen index 2026-01h)
02-02	Multi-function Input Command 2 (MI2)	Default setting	0 (DI terminal status is mapped to CANopen index 2026-01h)
02-03	Multi-function Input Command 3 (MI3)	Default setting	0 (DI terminal status is mapped to CANopen index 2026-01h)
02-04	Multi-function Input Command 4 (MI4)	Default setting	0 (DI terminal status is mapped to CANopen index 2026-01h)
02-05	Multi-function Input Command 5 (MI5)	Default setting	0 (DI terminal status is mapped to CANopen index 2026-01h)
02-06	Multi-function Input Command 6 (MI6)	Default setting	0 (DI terminal status is mapped to CANopen index 2026-01h)
02-13	Multi-function Output 1 (MO1)	Default setting	5 (DO terminal status is mapped to CANopen index 2026-41h)
02-14	Multi-function Output 2 (MO2)	Default setting	5 (DO terminal status is mapped to CANopen index 2026-41h)
02-15	Multi-function Output 3 (MO3)	Default setting	5 (DO terminal status is mapped to CANopen index 2026-41h)
02-16	Multi-function Output 4 (MO4)	Default setting	5 (DO terminal status is mapped to CANopen index 2026-41h)
09-37	CANopen Speed	2	CiA301 250kbps support line length 250m

Setting 4: I/O control and CANopen remote monitoring mode

[This page intentionally left blank]

Chapter 7 Warning Codes

Summary of Warning Codes

ID*	Warning Name	ID*	Warning Name
1	Communication error 1 (CE1)	37	CANopen heartbeat error (CHbn)
2	Communication error 2 (CE2)	39	CANopen bus off error (CbFE)
3	Communication error 3 (CE3)	40	CANopen index error (CidE)
4	Communication error 4 (CE4)	41	CANopen station address error (CAdE)
5	Communication error 10 (CE10)	42	CANopen index setting exceed limit (CFrE)
9	IGBT over-heating warning (oH1)	43	CANopen SDO time-out (CSdn)
20	Over terrine 1 (et1)	44	CANopen SDO receives register overflow
20	Over-torque 1 (ot1)	44	(CSbn)
24	Over slip error (oSL)	45	CANopen start-up error warning (Cbtn)
28	Output phase loss (oPHL)	46	CANopen format error (CPtn)
36	CANopen guarding time-out (CGdn)		

Immediately act		
running.		
The drive resets automatically when receiving the correct function code.		
Immediately reset		
No		
Check if the communication command is correct.		
		is recommended
to separate the communication circuit from the main circuit, or wire in 90 degree		
for effective anti-interference performance.		
ha uppar upit		
he upper unit.		
lace it if necessary.		

ID No.	Display on LED Keypad	Warning Name	Fault Descriptions	
2	533	Communication error 2 (CE2)	RS-485 Modbus illegal data address (00–254 H)	
		Action and	Reset	
	Action level	When the data address is	s incorrect.	
	Action time	Immediately act		
War	ning setting parameter	N/A		
	Reset method	-	Pr.09-02=0 and the motor drive keeps running. tically when receiving the correct data address.	
	Reset condition	Immediately reset		
	Record	No		
	Cause	Corrective Actions		
	t communication nd from the upper unit	Check if the communicat	ion command is correct.	
Malfunction caused by interference			unding of the communication circuit. It is recommended cation circuit from the main circuit, or wire in 90 degree ence performance.	
Different communication setting from the upper unit		Check if the setting for P	r.09-02 is the same as the setting for the upper unit.	
Disconnection or bad connection of the cable		Check the cable and rep	lace it if necessary.	

ID No.	Display on LED Keypad	Warning Name	Fault Descriptions	
3	683	Communication error 3 (CE3)	RS-485 Modbus illegal data value	
		Action and	Reset	
	Action level	When the data length is t	oo long	
	Action time	Immediately act		
War	ning setting parameter	N/A		
		"Warning" occurs when P	r.09-02=0 and the motor drive keeps running.	
	Reset method	The drive resets automatically when receiving the correct communication data		
		value.		
	Reset condition	Immediately reset		
	Record	No		
	Cause		Corrective Actions	
Incorrect communication command from the upper unit		Check if the communicati	ion command is correct.	
Verify the wiring and grounding of the communication circuit. It is recommended Malfunction caused by interference to separate the communication circuit from the main circuit, or wire in 90 d for effective anti-interference performance.		cation circuit from the main circuit, or wire in 90 degree		
Different communication setting from the upper unit		Check if the setting for Pr	.09-02 is the same as the setting for the upper unit.	
Disconnection or bad connection of the cable		Check the cable and repl	ace it if necessary.	

ID No.	Display on LED Keypad	Warning Name	Fault Descriptions	
4	684	Communication error 4 (CE4)	RS-485 Modbus data is written to read-only address	
		Action and	Reset	
	Action level	Data is written to read-on	ly address	
	Action time	Immediately act		
War	ning setting parameter	N/A		
Reset method		"Warning" occurs when Pr.09-02=0 and the motor drive keeps running. The drive resets automatically when receiving the correct written address of communication data.		
	Reset condition	Immediately reset		
	Record	Νο		
	Cause		Corrective Actions	
	t communication nd from the upper unit	Check if the communicat	on command is correct.	
Malfunction caused by interference Verify the wiring and grounding of the communication circuit. It is recommunication circuit, or wire in 90 for effective anti-interference performance.		cation circuit from the main circuit, or wire in 90 degree		
Different communication setting from the upper unit		Check if the setting for P	.09-02 is the same as the setting for the upper unit.	
Disconnection or bad connection		Check the cable and repl	ace it if necessary.	

ID No.	Display on LED Keypad	Warning Name	Fault Descriptions
5	0:33	Communication error 10 (CE10)	RS-485 Modbus transmission time-out
		Action and	l Reset
	Action level	When the communication time exceeds the detection time of Pr.09-03 communication time-out	
	Action time	Pr.09-03	·
War	ning setting parameter	N/A	
	Reset method		Pr.09-02=0 and the motor drive keeps running. atically when receiving the next communication packet.
	Reset condition	Immediately reset	
	Record	No	
	Cause		Corrective Actions
The upper unit does not transmit the communication command within Pr.09-03 setting time.		Check if the upper unit t time for Pr.09-03.	ransmits the communication command within the setting
Malfunct interfere	ion caused by nce	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.	
Different communication setting from the upper unit		Pr.09-02 is the same as the setting for the upper unit.	
Disconnection or bad connection of the cable		place it if necessary.	

ID No.	Display on LED Keypad	Warning Name	Fault Descriptions	
9	oX (IGBT over-heating warning (oH1)	The AC motor drive detects over-heating of IGBT, and over the protection level of oH1 warning. (When Pr.06-15 is higher than the IGBT over-heating level, the drive shows oH1 error without displaying oH1 warning.)	
		Action and	d Reset	
	Action level	Pr.06-15		
	Action time	"oH1" warning occurs w value.	hen IGBT temperature is higher than Pr.06-15 setting	
War	rning setting parameter	N/A		
	Reset method	Auto-reset		
	Reset condition	The drive auto-resets w minus (–) 5°C	hen IGBT temperature is lower than oH1 warning level	
	Record	Νο		
	Cause		Corrective Actions	
Check if the ambient temperature or temperature inside the control cabinet is too high, or if there is obstruction in the ventilation hole of the control cabinet.		 Change the installe resistors, in the surr 	he ventilation hole of the control cabinet. d place if there are heating objects, such as brake	
	Check if there is any obstruction on the heat sink or if the fan is Remove the obstruction or replace the c running.		n or replace the cooling fan.	
Insufficie	ent ventilation space Increase ventilation space of the drive.		ice of the drive.	
	Check if the drive matches the porresponding load1. Reduce the load.2. Reduce the carrier wave 3. Replace the drive with a larger capacity model.			
	re has run 100% or more 0% of the rated output for me	Replace the drive with a larger capacity model.		

ID No.	Display on LED	Keypad	Warning Name	Fault Descriptions	
20	_ L	1	Over-torque 1	Over tergue 1 werning	
20	ο Έ	1	(ot1)	Over-torque 1 warning	
			Action and	d Reset	
	Action level		Pr.06-07		
	Action time		Pr.06-08		
			Pr.06-06 Over-torque D	etection Selection (Motor 1) =1 or 3	
			0: No detection		
			1: Continue operation a	fter over-torque detection during constant speed	
War	ning setting para	meter	operation		
			2: Stop after over-torque	e detection during constant speed operation	
			3: Continue operation a	fter over-torque detection during RUN	
			4: Stop after over-torque	e detection during RUN	
	Reset method		The warning is automat	ically cleared when the output current < (Pr.06-07 $-$ 5%)	
	Reset condition		The warning is automat	ically cleared when the output current < (Pr.06-07 $-$ 5%)	
	Record		No		
	Cause			Corrective Actions	
Incorrect	parameter settir	ng	Configure the settings for	or Pr.06-07 and Pr.06-08 again.	
Mechani	cal error				
(e.g. me	chanical lock due	e to over-	Remove the causes of malfunction.		
torque)					
The load	is too large.		Decrease the loading.		
	is too large.		Replace with a motor with larger capacity.		
	ecel. time or the second short	working	Increase the setting val	ue for Pr.01-12–01-19 (accel./decel. time)	
			Adjust the settings for V	//F curve (Motor 1: Pr.01-01-01-08). Especially the	
V/F volta	ge is too high		setting value for the mid-point voltage (if the mid-point voltage is set too low,		
			the load capacity decreases at low speed).		
The mote	or capacity is too	small	Replace the motor with	a larger capacity model.	
Overload	I during low-spee	ed	Reduce the load during	low-speed operation.	
operation. Increase the motor capacity.		acity.			
Torrette	omporceti : 4	oo low-	Readjust the torque cor	npensation value (Pr.07-26 torque compensation gain)	
iorque c	ompensation is t	oo large	till the output current de	creases and the motor does not stall.	
Imprope	r parameter settir	ngs for	Corroct the parameter	attings for anod tracking	
the spee	d tracking functio	on		settings for speed tracking.	
(includin	g restart after mo	omentary	Start the speed tracking function.		
power loss and restart after fault)		Adjust the maximum current for Pr.07-09 speed tracking.			

ID No.	Display on LED Keypad	Warning Name	Fault Descriptions
24	oSL	Over slip error (oSL)	Over slip warning. By using the maximum slip (Pr.10-29) as the base, when the drive outputs at constant speed, and the F>H or F <h and="" exceeds="" level="" pr.07-29="" pr.07-30="" setting<br="">time, 100% Pr.07-29 = Pr.10-29.</h>
		Action and	d Reset
	Action level	When the drive outputs 29 level	at constant speed, and F>H or F <h exceeds="" pr.07-<="" td="" the=""></h>
	Action time	Pr.07-30	
Warning setting parameter		 Pr.07-31 = 0 Warning 0: Warn and continue operation 1: Warn and ramp to stop 2: Warn and coast to stop 3: No warning 	
	Reset method	When Pr.07-31=0 and when the drive outputs at constant speed, and F>H or F <h automatically="" clears.<="" exceeds="" level,="" longer="" no="" osl="" pr.07-29="" td="" the="" warning=""></h>	
	Reset condition	N/A	
	Record	No	
	Cause		Corrective Actions
Any of the motor parameters in parameter group 5 may be incorrect		Check the motor parameter.	
The load is too large.		Decrease the loading.	
Any of the setting value of Pr.07-29, 07-30, and 10-29 is improper		ettings for oSL protection.	

ID No.	Display on LED Keypad	Warning Name	Fault Descriptions	
28	oPX1	Output phase loss (oPHL)	Output phase loss of the drive	
		Action and	d Reset	
	Action level	Pr.06-47		
	Action time	N/A		
		Pr.06-45		
		0: Warn and continue o	peration	
War	ning setting parameter	1: Warn and ramp to sto	pp	
		2: Warn and coast to st	qq	
		3: No warning		
	Reset method	If Pr.06-45 is set to 0, the oPHL warning automatically clears after the drive stops.		
	Reset condition	N/A		
	Record	No		
	Cause		Corrective Actions	
	ced three-phase nce of the motor	Replace the motor.		
The surged		Check the cable condition.		
i ne mot	or is wired incorrectly	Replace the cable.		
Using a	single-phase motor	Choose a three-phase r	notor	
		Check if the control board cable is loose. If yes, reconnect the cable and run the		
Chook if	the current sensor is	drive to test. If the fault still exists, return to the factory for repair.		
broken.		Check if the three-phase current is balanced with a current clamp meter. If the		
DIOKEII.		current is balanced and the oPHL error still shows on the display, return to the		
		factory for repair.		
	e capacity is much larger motor capacity Make sure the capacity of the drive and motor match to each other.			

ID No.	Display on LCD Keypad	Warning Name	Fault Descriptions	
36	[[dn	CANopen guarding time-out (CGdn)	CANopen guarding error	
		Action and	d Reset	
	Action level	When CANopen Node (the CGdE fault occurs.	Guarding detects that one of the slaves does not respond,	
		The upper unit sets the	factor and time during configuration.	
	Action time	The time that upper uni	t sets during configuration	
War	rning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	The upper unit sends a reset package to clear this warning.		
	Record	No		
	Cause		Corrective Actions	
The guarding time is too short, or less detection times		Increase the guarding t	ime (Index 100C) and detection times	
Malfunction caused by interference		recommended to se or wire in 90 degree 2. Make sure the com	g and wiring of the communication circuit. It is eparate the communication circuit from the main circuit, e for effective anti-interference performance. munication circuit is wired in series. e or add terminating resistance.	

ID No.	Display on LCD Keypad	Warning Name	Fault Descriptions	
37	[860	CANopen heartbeat error (CHbn)	CANopen heartbeat error	
		Action and	d Reset	
Action level		When CANopen Heartbeat detects that one of the slaves does not respond, the CHbE fault occurs. The upper unit sets the confirming time of producer and consumer during		
Action time		configuration. The upper unit sets the confirming time of producer and consumer during configuration.		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	The upper unit sends a reset package to clear this warning.		
	Record	When Pr.00-21≠3, CHbn is a "Warning", and the warning is not recorded.		
	Cause		Corrective Actions	
The hea	rtbeat time is too short	Increase heartbeat time	(Index 1016)	
Malfunction caused by interference		recommended to se or wire in 90 degree 2. Make sure the com	g and wiring of the communication circuit. It is eparate the communication circuit from the main circuit, e for effective anti-interference performance. munication circuit is wired in series. e or add terminating resistance.	
Disconnection or bad connection of the cable		place it if necessary.		

ID No.	Display on LCD Keypad	Warn	ing Name	Fault Descriptions	
39	[bfn	-	n bus off error CbFE)	CANopen BUS off error	
	Action and Reset				
Action level		Hardwar e When CANopen card is not installed, the CbFn warning occurs.			
		When the master receives wrong communication package, the CbFn warning occurs. Software Too much interference on BUS The master receives wrong package when the CAN_H and CAN_L			
			communication cables are short, CbFn warning occurs.		
Action time		Immediately act when the fault is detected			
Warning setting parameter		N/A			
Reset method		Manual reset			
Reset condition		Cycle the power			
Record		When Pr.00-21≠3, CbFn is a "Warning", and the warning is not recorded.			
Cause		Corrective Actions			
Check if correct	the CANopen speed is	Reset CANopen speed (Pr.09-37)			
Malfunction caused by interference		 Verify the grounding and wiring of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance. Make sure the communication circuit is wired in series. Use CANopen cable or add terminating resistance. 			
Disconnection or bad connection of the cable Check the cable and replace it if necessary.			place it if necessary.		

ID No.	o. Display on LCD Keypad Warning Name		Fault Descriptions	
40	Eldn	CANopen index error (CidE)	CANopen index error	
	Action and Reset			
Action level		CANopen index error		
Action time		Immediately act when the fault is detected		
Warning setting parameter		N/A		
Reset method		Manual reset		
Reset condition		The upper unit sends a reset package to clear this warning.		
Record		When Pr.00-21≠3, Cidn is a "Warning", and the warning is not recorded.		
Cause		Corrective Actions		
Incorrect setting of CANopen index		Reset CANopen Index (Pr.00-02=7)		

ID No.	Display on LCD Keypad	Warning Name	Fault Descriptions	
41	[Rdn	CANopen station address error (CAdE)	CANopen station address error (only supports 1–127)	
		Action and Reset		
Action level		CANopen station address error		
Action time		Immediately act when the fault is detected		
Warning setting parameter		N/A		
Reset method		Manual reset		
Reset condition		Pr.00-02=7		
Record		When Pr.00-21≠3, CAdn is a "Warning", and the warning is not recorded.		
Cause		Corrective Actions		
Incorrec station a	et setting of CANopen address	 Disable CANopen (Pr.09-36=0) Reset CANopen (Pr.00-02=7) Reset CANopen station address (Pr.09-36) 		

ID No.	Display on LCD Keypad	Warning Name	Fault Descriptions	
42	[Fro	CANopen index setting exceed limit (CFrE)	CANopen memory error	
	Action and Reset			
Action level		When you update the firmware version of the control board, the FRAM internal data does not change, then CFrn warning occurs.		
Action time		Immediately act when the fault is detected		
Warning setting parameter		N/A		
Reset method		Manual reset		
Reset condition		Pr.00-02=7		
Record		When Pr.00-21≠3, CFrn is a "Warning", and the warning is not recorded.		
Cause		Corrective Actions		
CANopen internal memory error		 Disable CANopen (Pr.09-36=0) Reset CANopen (Pr.00-20=7) Reset CANopen station address (Pr.09-36) 		

ID No.	Display on LCD Keypad	Warning Name	Fault Descriptions		
ID NO.		CANopen SDO	SDO transmission time-out		
43	ESdn	·			
		time-out (CSdn)	(only shows on master station)		
	Action and Reset				
Action level		When the CANopen master transmits a SDO command, and the slave			
		response "times-out", CSdn warning occurs.			
Action time		Immediately act when the fault is detected			
Warning setting parameter		N/A			
Reset method		When the master resends a SDO command and receives the response, the			
		warning automatically clears.			
Reset condition		N/A			
Record		No			
Cause		Corrective Actions			
Slave is not connected		Connect the slave and CANopen BUS.			
The synchronous cycle is set too short		Increase the synchronous time (Index 1006)			
	recommended to separate the communication circuit from the main circuit,				
Malfunct interfere	or wire in 90 degree for effective anti-interference performance.				
	2. Make sure the communication circuit is wired in series.				
	3. Use CANopen cable or add terminating resistance.				
Disconnection or bad connection of the cable			<u> </u>		
		Check the cable and replace it if necessary.			

Chapter 7 Warning Codes | EL-C

ID No.	Display on LCD Keypad	Warning Name	Fault Descriptions	
		CANopen SDO		
44	[Sbn	receives register	CANopen SDO receives register overflow	
		overflow (CSbn)		
		Action and	d Reset	
	Action level	The upper unit sends to	o much SDO at one time and causes buffer overflow	
	Action time	Immediately act when the fault is detected		
War	rning setting parameter	N/A		
	Reset method	The upper unit sends a reset package to clear the warning.		
	Reset condition	N/A		
	Record	No		
	Cause	Corrective Actions		
Too much SDO from the upper unit		Check if the master sends too much SDO command. Make sure the master		
at one time		sends the SDO command according to the command format.		

ID No.	Display on LCD Keypad	Warning Name	Fault Descriptions	
45	[btn	CANopen start-up	CANopen start-up error warning	
40		error warning (Cbtn)	CANopen start-up endr warning	
		Action and	l Reset	
	Action level	When the amount of se	nt error messages reach 255	
	Action time	N/A		
War	rning setting parameter	Index 6007		
	Reset method	Disable CANopen, and cycle the power after power-off		
	Reset condition	N/A		
	Record	No		
	Cause	Corrective Actions		
Serious interference on hardware		Verify if the grounding, terminating resistance and bus line are properly installed.		
Incorrect setting for		Verify the setting for communication speed.		
communication speed				

Chapter 7 Warning Codes | EL-C

ID No.	Display on LCD Keypad	Warning Name	Fault Descriptions	
46	[PEn	CANopen format error (CPtn)	CANopen protocol format error	
		Action and	d Reset	
	Action level	The slave detects that c recognized, and then C	communication data from the upper unit cannot be Ptn warning occurs.	
	Action time	Immediately act when the fault is detected		
War	rning setting parameter	N/A		
	Reset method	The upper unit sends a reset package to clear the warning.		
	Reset condition	N/A		
	Record	No		
	Cause	Corrective Actions		
The upper unit sends incorrectMake sure the mastercommunication packetcommand format.			ends the packet based on CANopen DS301 standard	

Chapter 8 Fault Codes

Summary of Fault Codes

ID*	Fault Codes	ID*	Fault Name
1	Over-current during acceleration (ocA)	52	Password is locked (Pcod)
2	Over-current during deceleration (ocd)	54	Illegal command (CE1)
3	Over-current during steady operation (ocn)	55	Illegal data address (CE2)
6	Over-current at stop (ocS)	56	Illegal data value (CE3)
7	Over-voltage during acceleration (ovA)	57	Data is written to read-only address (CE4)
8	Over-voltage during deceleration (ovd)	58	Modbus transmission time-out (CE10)
9	Over-voltage during constant speed (ovn)	62	Deceleration energy backup error (dEb)
10	Over-voltage at stop (ovS)	79	U-phase over-current before run (Aoc)
11	Low-voltage during acceleration (LvA)	80	V-phase over-current before run (boc)
12	Low-voltage during deceleration (Lvd)	81	W-phase over-current before run (coc)
13	Low-voltage at constant speed (Lvn)	82	Output phase loss U phase (oPL1)
14	Low-voltage at stop (LvS)	83	Output phase loss V phase (oPL2)
15	Phase loss protection (orP)	84	Output phase loss W phase (oPL3)
16	IGBT overheating (oH1)	87	Low frequency overload protection (oL3)
18	IGBT temperature detection failure (tH1o)	101	CANopen guarding error (CGdE)
21	Over load (oL)	102	CANopen heartbeat error (CHbE)
22	Electronics thermal relay 1 protection (EoL1)	104	CANopen bus off error (CbFE)
26	Over torque 1 (ot1)	105	CANopen index error (CidE)
28	Under current (uC)	106	CANopen station address error (CAdE)
31	EEPROM read error (cF2)	107	CANopen index setting exceed limit (CFrE)
33	U-phase error (cd1)	111	InrCOM time-out error (ictE)
34	V-phase error (cd2)	121	Internal communication error (CP20)
35	W-phase error (cd3)	123	Internal communication error (CP22)
36	cc hardware error (Hd0)	124	Internal communication error (CP30)
37	<u>oc hardware error (Hd1)</u>	126	Internal communication error (CP32)
49	External fault (EF)	127	Internal communication error (CP33)
50	Emergency stop (EF1)	141	Short circuit before run (b4oc)
51	External base block (bb)		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions		
1	oc R	Over-current during acceleration (ocA)	Output current exceeds three times of the rated current during acceleration. When ocA occurs, the drive closes the gate of the output immediately, the motor runs freely, and the display shows an ocA error.		
		Action and	d Reset		
	Action level	250% of the rated curre	ent		
	Action time	Immediately act			
Fau	lt treatment parameter	N/A			
	Reset method	Manual reset			
	Reset condition	Reset in five seconds a	fter the fault is cleared		
	Record	Yes			
	Cause		Corrective Actions		
Acceleration time is too short		 Increase the acceleration time Increase the acceleration time of S-curve Use auto-acceleration and auto-deceleration setting (Pr.01-44) Set over-current stall prevention function (Pr.06-03) Replace the drive with a larger capacity model. 			
Short-cir	rcuit at motor output due to	Check the motor cable and remove causes of the short circuits, or replace the			
poor ins	ulation wiring	cable before turning on	the power.		
Check for	or possible burnout or	Check the motor insulat	ion value with megger. Replace the motor if the insulation		
aging in	sulation of the motor	is poor.			
The load	d is too large.	Check if the output current during the whole working process exceeds the AC motor drive's rated current. If yes, replace the AC motor drive with a larger capacity model.			
Impulsiv	e change of the load	Reduce the load or increase the capacity of AC motor drive.			
Use spe	cial motor or motor with	Check the motor capac	ity (the rated current on the motor's nameplate should \leq		
larger ca	apacity than the drive	the rated current of the	drive)		
Use ON / OFF controller of an electromagnetic contactor at the output (U/V/W) of the drive when the drive outputs the voltage.					
V/F curve setting error Adjust the V/F curve setting and frequency / voltage. When the fault occ the frequency voltage is too high, reduce the voltage. Adjust the V/F curve setting and frequency / voltage.					
Torque o	compensation is too large	Adjust the torque compensation value (Pr.07-26 torque compensation gain) till the output current decreases and the motor does not stall.			
Malfunct interfere	tion caused by ence	Verify the wiring of the control circuit and the wiring/grounding of the main circuit to prevent interference.			
The mot	tor starts when in free run	Enable the speed track	ing during start-up of Pr.07-12.		
L		1			

Cause	Corrective Actions	
Improper parameter settings for		
the speed tracking function	Correct the parameter settings for speed tracking.	
(including restart after	1. Start the speed tracking function.	
momentary power loss and	2. Adjust the maximum current for Pr.07-09 speed tracking.	
restart after fault)		
The length of motor cable is too	Increase the AC motor drive's capacity.	
long	Install AC reactor(s) on the output side (U/V/W).	
Hardware failure	The ocA occurs due to the short circuit or ground fault at the output side of the drive. Check for possible short circuits between terminals with the electric meter:	
	B1 corresponds to U, V and W; DC- corresponds to U, V and W; $(=)$ corresponds to U, V and W.	
Check if the setting for stall prevention is correct	Set the stall prevention to the proper value.	

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
			Output current exceeds 2.5 times of the rated current	
2		Over-current during	during deceleration. When ocd occurs, the drive closes	
	ocď	deceleration (ocd)	the gate of the output immediately, the motor runs	
			freely, and the display shows an ocd error.	
		Action and		
	Action level	250% of the rated current		
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds a	fter the fault is cleared	
	Record	Yes		
	Cause		Corrective Actions	
-		1. Increase the decele	eration time	
		2. Increase the decele	eration time of S-curve	
Accelera	ation time is too short	3. Use auto-accelerati	on and auto-deceleration setting (Pr.01-44)	
		4. Set over-current sta	all prevention function (Pr.06-03)	
		5. Replace the drive with a larger capacity model.		
Check if	the mechanical brake of	Check the action timing of the mechanical brake		
the moto	or activates too early			
Short-cir	rcuit at motor output due to	Check the motor cable	and remove causes of the short circuits, or replace the	
poor insulation wiring		cable before turning on the power.		
Check for	or possible burnout or	Check the motor insulation value with megger. Replace the motor if the insulation		
aging in	sulation of the motor	is poor.		
		Check if the output current during the whole working process exceeds the AC		
The load	d is too large.	motor drive's rated curr	ent. If yes, replace the AC motor drive with a larger	
		capacity model.		
Impulsiv	e change of the load	Reduce the load or incr	ease the capacity of AC motor drive.	
Use spe	cial motor or motor with	Check the motor capac	ity (the rated current on the motor's nameplate should \leq	
larger ca	apacity than the drive	the rated current of the	drive)	
Use ON	/ OFF controller of an	Check the action timing	of the contactor and make sure it is not turned ON / OFF	
electrom	nagnetic contactor at the	when the drive outputs		
output (U/V/W) of the drive				
V/F curve setting error		Adjust the V/F curve setting and frequency/voltage. When the fault occurs, and		
		the frequency voltage is too high, reduce the voltage.		
Toraue a	compensation is too large	Adjust the torque compensation value (Pr.07-26 torque compensation gain) till		
			eases and the motor does not stall.	
Malfunction caused by		Verify the wiring of the control circuit and the wiring/grounding of the main circuit		
interfere		to prevent interference.		
The leng	gth of motor cable is too	Increase the drive capacity.		
long		Install AC reactor(s) on	the output side (U/V/W).	

	The ocA occurs due to the short circuit or ground fault at the output side of the	
	drive.	
Hardware failure	Check for possible short circuits between terminals with the electric meter:	
	B1 corresponds to U, V and W; DC- corresponds to U, V and W; $\stackrel{\textcircled{=}}{=}$	
	corresponds to U, V and W.	
Check if the setting for stall	Set the stall provention to the preper value	
prevention is correct	Set the stall prevention to the proper value.	

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
			Output current exceeds three times of the rated current	
		Over-current during	during acceleration. When ocn occurs, the drive closes	
3	000	steady operation (ocn)	the gate of the output immediately, the motor runs	
			freely, and the display shows an ocn error.	
		Action and	d Reset	
	Action level	250% of the rated curre	nt	
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in five seconds a	fter the fault is cleared	
	Record	Yes		
	Cause		Corrective Actions	
Short-cir	rcuit at motor output due to	Check the motor cable	and remove causes of the short circuits, or replace the	
poor ins	ulation wiring	cable before turning on	the power.	
Check for	or possible shaft lock,	Troubleshoot the motor shaft lock.		
burnout	or aging insulation of the	Check the motor insulation value with megger. Replace the motor if the insulation		
motor		is poor.		
Impulsiv	e change of the load	Reduce the load or increase the capacity of AC motor drive.		
Use spe	cial motor or motor with	Check the motor capacity (the rated current on the motor's nameplate should ≤		
larger ca	apacity than the drive	the rated current of the drive)		
Use ON	/ OFF controller of an	Check the action timing of the contactor and make sure it is not turned ON / OFF		
electrom	nagnetic contactor at the	when the drive outputs the voltage.		
output (l	U/V/W) of the drive			
V/F curv	e setting error	-	tting and frequency/voltage. When the fault occurs, and	
	5		s too high, reduce the voltage.	
Torque o	compensation is too large		ensation value (Pr.07-26 torque compensation gain) till	
		the output current decreases and the motor does not stall.		
	tion caused by	Verify the wiring of the control circuit and the wiring/grounding of the main circuit		
interference		to prevent interference.		
The length of motor cable is too		Increase the drive capacity.		
long		Install AC reactor(s) on the output side (U/V/W).		
		The ocA occurs due to the short circuit or ground fault at the output side of the		
		drive.		
Hardwar	re failure	Check for possible short circuits between terminals with the electric meter:		
		B1 corresponds to U, V and W; DC- corresponds to U, V and W; 🚖		
		corresponds to U, V and	d W.	

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
			Over-current or hardware failure in current detection at	
6	065	Over-current at stop	stop.	
0	000	(ocS)	Cycle the power after ocS occurs. If the hardware	
			failure occurs, the display shows cd1, cd2 or cd3.	
		Action and	d Reset	
	Action level	240% of the rated curre	ent	
	Action time	Immediately act		
Fau	Ilt treatment parameter	N/A		
Reset method		Manual reset		
	Reset condition	Reset in five seconds after the fault is cleared		
	Record	Yes		
	Cause	Corrective Actions		
Malfunc	tion caused by	Verify the wiring of the control circuit and the wiring/grounding of the main circuit		
interference		to prevent interference.		
Hordura	re failure	Check if other error cod	es such as cd1–cd3 occur after cycling the power. If yes,	
nardwa		return to the factory for repair.		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
			DC bus over-voltage during acceleration. When ovA	
7	oū8	Over-voltage during	occurs, the drive closes the gate of the output, the	
		acceleration (ovA)	motor runs freely, and the display shows an ovA error.	
		Action and	d Reset	
	Action level	230V models: 410 V_{DC}		
	Action level	460V models: 820 V _{DC}		
	Action time	Immediately act when t	he DC bus voltage is higher than the level	
Fau	lt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset only when the D	C bus voltage is lower than 90% of the over-voltage level	
	Record	Yes		
	Cause		Corrective Actions	
Accelera	ation is too slow (e.g. when	Decrease the accelerat	ion time	
lifting loa	ad decreases acceleration	Use a braking unit or D	C bus	
time)		Replace the drive with a	a larger capacity model.	
The sett	ing for stall prevention			
level is s	smaller than no-load	The setting for the stall prevention level should be larger than no-load current		
current				
Power v	oltage is too high	Check if the input voltage is within the rated AC motor drive input voltage range,		
		and check for possible voltage spikes.		
	F switch action of phase-	If the phase-in capacitor or active power supply unit acts in the same power		
-	itor in the same power	system, the input voltage may surge abnormally in a short time. In this case,		
system		install an AC reactor.		
Regene	rative voltage of motor	Use over-voltage stall prevention function (Pr.06-01)		
inertia		Use auto-acceleration and auto-deceleration setting (Pr.01-44)		
		Use a braking unit or D		
		Check if the over-voltage warning occurs after acceleration stops. When the		
		warning occurs, do the following:		
Accelera	ation time is too short	1. Increase the acceleration time		
		2. Set Pr.06-01 over-voltage stall prevention		
			y value for Pr.01-25 S-curve acceleration arrival time 2	
		The ground short circuit current charges the capacitor in the main circuit through		
Motor gr	round fault	the power. Check if there is ground fault on the motor cable, wiring box and its		
		internal terminals. Troubleshoot the ground fault.		
Incorrec	t wiring of brake resistor or			
Incorrect wiring of brake resistor or brake unit		Check the wiring of the brake resistor and braking unit.		
		Verify the wiring of the control circuit and the wiring/grounding of the main circuit		
interfere	-	to prevent interference.		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
			DC bus over-voltage during deceleration. When ovd	
0	- ,	Over-voltage during	occurs, the drive closes the gate of the output	
8	oūd	deceleration (ovd)	immediately, the motor runs freely, and the display	
			shows an ovd error.	
		Action and	d Reset	
	Action level	230V models: 410 V _{DC}		
	Action level	460V models: 820 V _{DC}		
	Action time	Immediately act when t	he DC bus voltage is higher than the level	
Fau	lt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset only when the DO	C bus voltage is lower than 90% of the over-voltage level	
	Record	Yes		
	Cause		Corrective Actions	
		1. Increase the settin	ng value of Pr.01-13, Pr.01-15, Pr.01-17 and Pr.01-19	
		(deceleration time)		
		2. Connect COMMON DC bus to the drive.		
Decelera	ation time is too short,	3. Reduce the brake frequency.		
causing	too large regenerative	4. Replace the drive with a larger capacity model.		
energy o	of the load	5. Use S-curve acceleration/deceleration.		
		6. Use over-voltage stall prevention function (Pr.06-01)		
		7. Use auto-acceleration and auto-deceleration setting (Pr.01-44)		
		8. Adjust braking level (Pr.07-01).		
The sett	ing for stall prevention			
level is s	smaller than no-load	The setting for the stall	prevention level should be larger than no-load current	
current				
Power v	oltage is too high	Check if the input voltage	ge is within the rated AC motor drive input voltage range,	
		and check for possible voltage spikes.		
ON / OF	F switch action of phase-	If the phase-in capacito	r or active power supply unit acts in the same power	
in capac	itor in the same power	system, the input voltag	ge may surge abnormally in a short time. In this case,	
system		install an AC reactor.		
		The ground short circuit current charges the capacitor in the main circuit through		
Motor ar	ound fault	the power. Check if there is ground fault on the motor cable, wiring box and its		
linetor gi		internal terminals.		
		Troubleshoot the groun	d fault.	
Malfunct	Malfunction caused by Verify the wiring of the control circuit and the wiring/grounding of the main		control circuit and the wiring/grounding of the main	
interference circuit to prevent interference.			erence.	

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
			DC bus over-voltage at constant speed. When ovn	
0	-	Over-voltage during	occurs, the drive closes the gate of the output	
9	000	constant speed (ovn)	immediately, the motor runs freely, and the display	
			shows an ovn error.	
		Action and	d Reset	
		230V models: 410 V _{DC}		
	Action level	460V models: 820 V _{DC}		
	Action time	Immediately act when t	he DC bus voltage is higher than the level	
Fau	lt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset only when the DO	C bus voltage is lower than 90% of the over-voltage level	
	Record	Yes		
	Cause		Corrective Actions	
		1. Connect DC bus to	the drive.	
Impulciv	e change of the load	2. Reduce the load.		
IIIIpuisiv	e change of the load	3. Replace the drive w	vith a larger capacity model.	
		4. Adjust braking level (Pr.07-01).		
The setting for stall prevention				
level is s	smaller than no-load	The setting for the stall prevention level should be larger than no-load current		
current				
Regenerative voltage of motor Use over-voltage stall prevention function (Pr.06-01)		revention function (Pr.06-01)		
inertia Use a braking unit or D		Use a braking unit or D	C bus	
Power v	oltage is too high	Check if the input voltage is within the rated AC motor drive input voltage range,		
		and check for possible voltage spikes.		
ON / OF	F switch action of phase-	If the phase-in capacito	r or active power supply unit acts in the same power	
in capac	itor in the same power	system, the input voltage may surge abnormally in a short time. In this case,		
system		install an AC reactor.		
		The ground short circuit current charges the capacitor in the main circuit through		
Motor ar	ound fault	the power. Check if there is ground fault on the motor cable, wiring box and its		
initiation gr		internal terminals.		
		Troubleshoot the groun	d fault.	
Malfunct	tion caused by	Verify the wiring of the o	control circuit and the wiring/grounding of the main	
interfere	nce	circuit to prevent interference.		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
10	oū5	Over-voltage at stop (ovS)	Over-voltage at stop	
		Action and	d Reset	
		230V models: 410 V _{DC}		
	Action level	460V models: 820 V _{DC}		
	Action time	Immediately act when the	he DC bus voltage is higher than the level	
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset only when the DC	C bus voltage is lower than 90% of the over-voltage level	
Record		Yes		
Cause		Corrective Actions		
Power v	oltage is too high	Check if the input voltage is within the rated AC motor drive input voltage		
Power voltage is too high		range, and check for possible voltage spikes.		
ON / OF	F switch action of phase-	If the phase-in capacitor or active power supply unit acts in the same power		
in capac	itor in the same power	system, the input voltage may surge abnormally in a short time. In this case,		
system		install an AC reactor.		
Malfunct	tion caused by	Verify the wiring of the c	control circuit and the wiring/grounding of the main circuit	
interfere	nce	to prevent interference.		
Hardwar	re failure	Check if other error cod	es such as cd1–cd3 occur after cycling the power. If	
Hardwar	re failure in voltage	yes, return to the factory for repair.		
detection	detection yes, return to the factory for repair.			
		The ground short circuit current charges the capacitor in the main circuit		
Motor ar	ound fault	through the power. Check if there is ground fault on the motor cable, wiring box		
l l l l l l l l l l l l l l l l l l l		and its internal terminals.		
		Troubleshoot the ground	d fault.	

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
11	, -0	Low-voltage during	DC bus voltage is lower than Pr.06-00 setting value	
	158	acceleration (LvA)	during acceleration	
Action and Reset				
Action level		Pr.06-00 (Default = depending on the model)		
	Action time	Immediately act when th	he DC bus voltage is lower than Pr.06-00	
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Depart condition	Reset when DC bus vol	tage is higher than Pr.06-00 + 30 V (230V model),	
	Reset condition	Pr.06-00 + 60 V (460V ı	model).	
Record		Νο		
Cause		Corrective Actions		
Power-c	off	Improve power supply condition.		
Power v	oltage changes	Adjust voltage to the power range of the drive		
Start up	the motor with large	Check the power syster	n.	
capacity	1	Increase the capacity of	f power equipment.	
		Reduce the load.		
The load	d is too large.	Increase the drive capacity.		
		Increase the acceleration time.		
DC bus		Install DC reactor(s).		
Check if	there is short circuit plate	Connect short circuit of	ate or DC reactor between terminal +1 and +2	
or any DC reactor installed		Connect short circuit plate or DC reactor between terminal +1 and +2. If the error still exists, return to the factory for repair.		
between terminal +1 and +2				

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
10	, - ,	Low-voltage during	DC bus voltage is lower than Pr.06-00 setting value	
12	Lūd	deceleration (Lvd)	during deceleration	
		Action and	d Reset	
	Action level	Pr.06-00 (Default = dep	ending on the model)	
	Action time	Immediately act when the	he DC bus voltage is lower than Pr.06-00	
Fau	ult treatment parameter	N/A		
	Reset method	Manual reset		
		Reset when DC bus voltage is higher than Pr.06-00 + 30 V (230V model),		
Reset condition		Pr.06-00 + 60 V (460V model).		
	Record	No		
	Cause	Corrective Actions		
Power-c	off	Improve power supply condition.		
Power v	voltage changes	Adjust voltage to the po	wer range of the drive	
Start up	the motor with large	Check the power system.		
capacity Increase the capacity of power equipment.		f power equipment.		
Sudden		Reduce the load.		
Suuden		Increase the drive capacity.		
DC bus		Install DC reactor(s).		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
		Low-voltage at	DC bus voltage is lower than Pr.06-00 setting value at	
13	Lun	constant speed (Lvn)	constant speed	
		Action and	·	
	Action level	Pr.06-00 (Default = dep	ending on the model)	
	Action time	Immediately act when th	he DC bus voltage is lower than Pr.06-00	
Fau	Ilt treatment parameter	N/A		
	Reset method	Manual reset		
Reset condition		Reset when DC bus voltage is higher than Pr.06-00 + 30 V (230V model),		
		Pr.06-00 + 60 V (460V model).		
	Record No			
Cause Corrective Actions		Corrective Actions		
Power-c	off	Improve power supply condition.		
Power v	oltage changes	Adjust voltage to the po	wer range of the drive	
Start up	the motor with large	Check the power system.		
capacity		Increase the capacity of power equipment.		
Sudden	load	Reduce the load.		
Sudden		Increase the drive capacity.		
DC bus		Install DC reactor(s).		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
14	LŪS	Low-voltage at stop (LvS)	 DC bus voltage is lower than Pr.06-00 setting value at stop Hardware failure in voltage detection 	
		Action and	l Reset	
	Action level	Pr.06-00 (Default = dep	ending on the model)	
	Action time	Immediately act when the	ne DC bus voltage is lower than Pr.06-00	
Fau	It treatment parameter	N/A		
Reset method		Manual / Auto: 230V models: Lv level + 30 V _{DC} + 500 ms 460V models: Lv level + 60 V _{DC} + 500 ms		
Reset condition		500 ms		
Record Yes		Yes		
Cause			Corrective Actions	
Power-c	off	Improve power supply c	condition.	
Incorrec	t drive models	Check if the power specification matches the drive.		
Power v	oltage changes	Adjust voltage to the power range of the drive Cycle the power after checking the power. If LvS error still exists, return to the factory for repair.		
Start up	the motor with large	Check the power syster	n.	
capacity		Increase the capacity of power equipment.		
DC bus		Install DC reactor(s).		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
15	orP	Phase loss protection (orP)	Phase loss of power input	
		Action and	l Reset	
	Action level	When DC bus is lower than Pr.07-00 and the ripple is too high.		
	Action time	N/A		
Fau	It treatment parameter	Pr.06-53		
	Reset method	Manual reset		
	Reset condition	Immediately reset when	DC bus is higher than Pr.07-00	
	Record	Yes		
	Cause	Corrective Actions		
Phase loss of input power		Correctly install the wiring of the main circuit power.		
Single p phase m	hase power input to three- nodel	Choose the model whose power matches the voltage.		
		If the main circuit power	works normally, verify the main circuit.	
Power v	oltage changes	Cycle the power after checking the power, if orP error still exists, return to the		
		factory for repair.		
Loose wiring terminal of input power		Tighten the terminal screws according to the torque described in the user man		
The inpu	ut cable of three-phase	Wire correctly.		
power is	s cut off	Replace the cut off cable.		
Unbalan power	nced three-phase of input	Check the power three-phase status.		
Use Open Delta Connection system		Install reactors or use d	rives with higher power.	

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
16	oX	IGBT overheating (oH1)	IGBT temperature exceeds the protection level. (Refer to Pr.06-15)	
		Action and	d Reset	
Action level		(When Pr.06-15 is higher than the IGBT overheating protection level, the drive shows oH1 error without displaying oH1 warning.)		
	Action time	IGBT temperature exce occurs.	eds the protection level for more than 100 ms, oH1 error	
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
Reset condition		5	rror occurs, and the drive stops. Reset only when IGBT an oH1 error level minus (-) 10°C	
Record		Yes		
Cause		Corrective Actions		
or tempe cabinet i obstructi of the co	Check if the ambient temperature or temperature inside the control cabinet is too high, or if there is obstruction in the ventilation hole of the control cabinet. Check ambient temperature. Regularly inspect the ventilation hole of the control cabinet. Change the installed place if there are heating objects, such as brake re- in the surroundings. Install / add cooling fan or air conditioner to lower the temperature inside cabinet.		entilation hole of the control cabinet. ace if there are heating objects, such as brake resistors,	
	there is any obstruction eat sink or if the fan is	Remove the obstruction or replace the cooling fan.		
Insufficie	ent ventilation space	Increase ventilation spa	ice of the drive.	
	the drive matches the onding load	 Reduce the load. Reduce the carrier wave Replace the drive with a larger capacity model. 		
	e has run 100% or more 0% of the rated output for me	Replace the drive with a larger capacity model.		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
18	٤X /o	IGBT temperature detection failure (tH1o)	IGBT hardware failure in temperature detection	
		Action and	I Reset	
	Action level	NTC broken or wiring fa	ilure	
	Action time	When the IGBT temperature is higher than the protection level, and detection		
		time exceeds 100 ms, the tH1o protection activates.		
Fault treatment parameter		N/A		
Reset method		Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
Cause		Corrective Actions		
Hardware failure		Wait for 10 minutes, and exists. If yes, return to t	d then cycle the power. Check if tH1o protection still ne factory for repair.	

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
21	σί	Over load (oL)	The AC motor drive detects excessive drive output current. Normal duty: Sustains for one minute when the drive outputs 120% of the drive's rated output current. Sustains for three seconds when the drive outputs 150% of the drive's rated output current. Heavy duty: Sustains for one minute when the drive outputs 150% of the drive's rated output current. Sustains for three seconds when the drive outputs 200% of the drive's rated output current.	
		Action and	d Reset	
	Action level	Based on overload curv	e and derating curve (refer to Pr.06-55)	
	Action time	When the load is higher the oL protection activa	r than the protection level and exceeds allowable time, tes.	
Fau	It treatment parameter	N/A		
Reset method		Manual reset		
Reset condition		Reset in five seconds after the fault is cleared		
Record		Yes		
Cause			Corrective Actions	
The load is too large. Reduce the				
The load	d is too large.	Reduce the load.		
Accel./D	d is too large. Decel. time or the working e too short		ue for Pr.01-12–01-19 (accel./decel. time)	
Accel./D	ecel. time or the working	Increase the setting val	ue for Pr.01-12–01-19 (accel./decel. time) //F curve (Motor 1: Pr.01-01–01-08). Especially the	
Accel./D cycle are	ecel. time or the working e too short	Increase the setting val Adjust the settings for V		
Accel./D cycle are	ecel. time or the working	Increase the setting val Adjust the settings for V	//F curve (Motor 1: Pr.01-01-01-08). Especially the d-point voltage (if the mid-point voltage is set too low,	
Accel./D cycle are	ecel. time or the working e too short	Increase the setting value Adjust the settings for V setting value for the mic	//F curve (Motor 1: Pr.01-01–01-08). Especially the d-point voltage (if the mid-point voltage is set too low, ases at low speed).	
Accel./D cycle are V/F volta	ecel. time or the working e too short	Increase the setting value Adjust the settings for V setting value for the mid the load capacity decrea Refer to the V/F curve s	//F curve (Motor 1: Pr.01-01–01-08). Especially the d-point voltage (if the mid-point voltage is set too low, ases at low speed).	
Accel./D cycle are V/F volta The cap small	e too short age is too high acity of the drive is too	Increase the setting value Adjust the settings for V setting value for the mid the load capacity decrea Refer to the V/F curve s	//F curve (Motor 1: Pr.01-01–01-08). Especially the d-point voltage (if the mid-point voltage is set too low, ases at low speed). selection of Pr.01-43.	
Accel./D cycle are V/F volta The cap small Overload	e too short age is too high acity of the drive is too	Increase the setting value Adjust the settings for V setting value for the mice the load capacity decrea Refer to the V/F curve se Replace the drive with a	<pre>//F curve (Motor 1: Pr.01-01-01-08). Especially the d-point voltage (if the mid-point voltage is set too low, ases at low speed). selection of Pr.01-43. a larger capacity model. low-speed operation.</pre>	
Accel./D cycle are V/F volta The cap small	e too short age is too high acity of the drive is too	Increase the setting value Adjust the settings for V setting value for the mid the load capacity decrea Refer to the V/F curve s Replace the drive with a Reduce the load during	<pre>//F curve (Motor 1: Pr.01-01-01-08). Especially the d-point voltage (if the mid-point voltage is set too low, ases at low speed). selection of Pr.01-43. a larger capacity model. low-speed operation. city.</pre>	
Accel./D cycle are V/F volta The cap small Overload operatio	becel. time or the working e too short age is too high acity of the drive is too d during low-speed n.	Increase the setting value Adjust the settings for V setting value for the mid the load capacity decrea Refer to the V/F curve se Replace the drive with a Reduce the load during Increase the drive capa Decrease the carrier free	<pre>//F curve (Motor 1: Pr.01-01-01-08). Especially the d-point voltage (if the mid-point voltage is set too low, ases at low speed). selection of Pr.01-43. a larger capacity model. low-speed operation. city.</pre>	
Accel./D cycle are V/F volta The cap small Overload operatio	e too short age is too high acity of the drive is too	Increase the setting value Adjust the settings for V setting value for the mid the load capacity decrea Refer to the V/F curve se Replace the drive with a Reduce the load during Increase the drive capa Decrease the carrier free Readjust the torque cor	<pre>//F curve (Motor 1: Pr.01-01-01-08). Especially the d-point voltage (if the mid-point voltage is set too low, ases at low speed). selection of Pr.01-43. a larger capacity model. low-speed operation. city. equency of Pr.00-17.</pre>	
Accel./D cycle are V/F volta The cap small Overload operatio Torque c Check if	becel. time or the working e too short age is too high acity of the drive is too d during low-speed n.	Increase the setting value Adjust the settings for V setting value for the mid the load capacity decrea Refer to the V/F curve se Replace the drive with a Reduce the load during Increase the drive capa Decrease the carrier free Readjust the torque cor	<pre>//F curve (Motor 1: Pr.01-01-01-08). Especially the d-point voltage (if the mid-point voltage is set too low, ases at low speed). selection of Pr.01-43. a larger capacity model. low-speed operation. city. equency of Pr.00-17. mpensation value (Pr.07-26 torque compensation gain) ecreases and the motor does not stall.</pre>	
Accel./D cycle are V/F volta The cap small Overload operatio Torque o Check if preventi	becel. time or the working e too short age is too high acity of the drive is too d during low-speed n. compensation is too large the setting for stall on is correct	Increase the setting value Adjust the settings for V setting value for the mid the load capacity decrea Refer to the V/F curve s Replace the drive with a Reduce the load during Increase the drive capa Decrease the carrier fre Readjust the torque cor till the output current de	<pre>//F curve (Motor 1: Pr.01-01-01-08). Especially the d-point voltage (if the mid-point voltage is set too low, ases at low speed). selection of Pr.01-43. a larger capacity model. low-speed operation. city. equency of Pr.00-17. mpensation value (Pr.07-26 torque compensation gain) ecreases and the motor does not stall. to the proper value.</pre>	
Accel./D cycle are V/F volta The cap small Overload operatio Torque o Check if preventi	becel. time or the working e too short age is too high acity of the drive is too d during low-speed n. compensation is too large	Increase the setting value Adjust the settings for V setting value for the mid the load capacity decrea Refer to the V/F curve se Replace the drive with a Reduce the load during Increase the drive capa Decrease the carrier free Readjust the torque cor till the output current de Set the stall prevention Check the status of three	<pre>//F curve (Motor 1: Pr.01-01-01-08). Especially the d-point voltage (if the mid-point voltage is set too low, ases at low speed). selection of Pr.01-43. a larger capacity model. low-speed operation. city. equency of Pr.00-17. mpensation value (Pr.07-26 torque compensation gain) ecreases and the motor does not stall. to the proper value.</pre>	

Improper parameter settings for	
the speed tracking function	Correct the parameter settings for speed tracking.
	Start the speed tracking function.
(including restart after momentary	Adjust the maximum current for Pr.07-09 speed tracking.
power loss and restart after fault)	, , , , , , , , , , , , , , , , , , , ,

22 EoL Solution Electronics thermal relay 1 protection (EoL1) Electronic the to stop once it	rmal relay 1 protection. The drive coasts	
Action and Reset		
Action level Start counting when the output current	t > 150% of the motor 1 rated current	
Action time	Pr.06-14 (If the output current is larger than 105% of the motor 1 rated current again within 60 sec., the counting time reduces and is less than Pr.06-14)	
Fault treatment parameter N/A		
Reset method Manual reset		
Reset condition Reset in five seconds after the fault is	cleared	
Record Yes		
Cause Correct	tive Actions	
The load is too large. Reduce the load.		
Accel./Decel. time or the working cycle are too short Increase the setting value for Pr.01-12	2–01-19 (accel./decel. time)	
	Adjust the settings for V/F curve (Motor 1: Pr.01-01-01-08). Especially the setting value for the mid-point voltage (if the mid-point voltage is set too low, the load capacity decreases at low speed).	
Overload during low-speed		
operation. When using a general motor, even it operates below rated current, an overload may still occur during low-speed operation.	VFD model.	
When using VFD dedicated motor, Pr.06-13=0 (electronic thermal relay selection motor 1 = drive motor)Pr.06-13=1 electronic thermal relay selection with fan on the shaft).	election motor 1 = standard motor (motor	
Incorrect value of electronic thermal relay Reset to the correct motor rated curre	nt.	
The maximum motor frequency is set too low Reset to the correct motor rated frequency	ency.	
One drive to multiple motors Set Pr.06-13=2 electronic thermal relation thermal relay on each motor.	ay selection motor 1= disable, and install	
Check if the setting for stall prevention is correct Set the stall prevention to the proper v	/alue.	
Torque compensation is too large	Adjust the torque compensation value (Pr.07-26 torque compensation gain) till the output current decreases and the motor does not stall.	
Motor fan error Check the status of the fan, or replace	Check the status of the fan, or replace the fan.	

Unbalanced three-phase	Replace the motor.
impedance of the motor	

ID* Display on LED	Keypad	Fault Name	Fault Descriptions	
			When the output current exceeds the over-torque	
	26 o t	Over torque 1	detection level (Pr.06-07) and exceeds over-torque	
²⁶ oč		(ot1)	detection time (Pr.06-08), and when Pr.06-06 or Pr.06-	
			09 is set to 2 or 4, the ot1 error displays.	
I		Action and Reset		
Action level		Pr.06-07		
Action time		Pr.06-08		
		Pr.06-06		
		0: No detection		
		1: Continue operation a	fter over-torque detection during constant speed	
Fault treatment param	neter	operation		
		2: Stop after over-torqu	e detection during constant speed operation	
		3: Continue operation a	fter over-torque detection during RUN	
		4: Stop after over-torqu	e detection during RUN	
		When Pr.06-0	6=1 or 3, ot1 is a "Warning". The warning is automatically	
Reset method		Auto cleared when	the output current < (Pr.06-07–5%)	
		Manual When Pr.06-0	6=2 or 4, ot1 is a "Fault". You must reset manually.	
Reset condition		Immediately reset		
Record		When Pr.06-06=2 or 4,	ot1 is a "Fault", and the fault is recorded.	
Cause				
Cause			Corrective Actions	
Cause Incorrect parameter setting	g	Configure the settings f		
	/er-		Corrective Actions for Pr.06-07 and Pr.06-08 again.	
Incorrect parameter setting	/er-	Configure the settings f Remove the causes of	Corrective Actions for Pr.06-07 and Pr.06-08 again.	
Incorrect parameter setting Mechanical failure (e.g. ov torque, mechanical lock)	/er-		Corrective Actions for Pr.06-07 and Pr.06-08 again.	
Incorrect parameter setting Mechanical failure (e.g. ov	/er-	Remove the causes of Reduce the load.	Corrective Actions for Pr.06-07 and Pr.06-08 again.	
Incorrect parameter setting Mechanical failure (e.g. ov torque, mechanical lock)	ver-	Remove the causes of Reduce the load. Replace the motor with	Corrective Actions for Pr.06-07 and Pr.06-08 again. malfunction. a larger capacity model.	
Incorrect parameter setting Mechanical failure (e.g. ov torque, mechanical lock) The load is too large.	ver-	Remove the causes of Reduce the load. Replace the motor with	Corrective Actions for Pr.06-07 and Pr.06-08 again. malfunction.	
Incorrect parameter setting Mechanical failure (e.g. ov torque, mechanical lock) The load is too large. Accel./Decel. time or the v	vorking	Remove the causes of Reduce the load. Replace the motor with Increase the setting val	Corrective Actions for Pr.06-07 and Pr.06-08 again. malfunction. a larger capacity model.	
Incorrect parameter setting Mechanical failure (e.g. ov torque, mechanical lock) The load is too large. Accel./Decel. time or the v	vorking	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for V	Corrective Actions for Pr.06-07 and Pr.06-08 again. malfunction. a larger capacity model. ue for Pr.01-12–01-19 (accel./decel. time)	
Incorrect parameter setting Mechanical failure (e.g. ov torque, mechanical lock) The load is too large. Accel./Decel. time or the w cycle are too short	vorking	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for V	Corrective Actions for Pr.06-07 and Pr.06-08 again. malfunction. a larger capacity model. ue for Pr.01-12–01-19 (accel./decel. time) //F curve (Motor 1: Pr.01-01–01-08). Especially the d-point voltage (if the mid-point voltage is set too low,	
Incorrect parameter setting Mechanical failure (e.g. ov torque, mechanical lock) The load is too large. Accel./Decel. time or the w cycle are too short	vorking	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for \ setting value for the mid the load capacity decre	Corrective Actions for Pr.06-07 and Pr.06-08 again. malfunction. a larger capacity model. ue for Pr.01-12–01-19 (accel./decel. time) //F curve (Motor 1: Pr.01-01–01-08). Especially the d-point voltage (if the mid-point voltage is set too low,	
Incorrect parameter setting Mechanical failure (e.g. ov torque, mechanical lock) The load is too large. Accel./Decel. time or the v cycle are too short V/F voltage is too high	vorking	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for \ setting value for the mid the load capacity decre	Corrective Actions for Pr.06-07 and Pr.06-08 again. malfunction. a larger capacity model. ue for Pr.01-12–01-19 (accel./decel. time) //F curve (Motor 1: Pr.01-01–01-08). Especially the d-point voltage (if the mid-point voltage is set too low, ases at low speed). a larger capacity model.	
Incorrect parameter setting Mechanical failure (e.g. ov torque, mechanical lock) The load is too large. Accel./Decel. time or the v cycle are too short V/F voltage is too high The motor capacity is too	vorking small	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for V setting value for the mid the load capacity decre Replace the motor with	Corrective Actions for Pr.06-07 and Pr.06-08 again. malfunction. a larger capacity model. ue for Pr.01-12–01-19 (accel./decel. time) //F curve (Motor 1: Pr.01-01–01-08). Especially the d-point voltage (if the mid-point voltage is set too low, ases at low speed). a larger capacity model. low-speed operation.	
Incorrect parameter setting Mechanical failure (e.g. ov torque, mechanical lock) The load is too large. Accel./Decel. time or the v cycle are too short V/F voltage is too high The motor capacity is too s Overload during low-speed operation.	vorking small	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for V setting value for the mid the load capacity decre Replace the motor with Reduce the load during Increase the motor cap	Corrective Actions for Pr.06-07 and Pr.06-08 again. malfunction. a larger capacity model. ue for Pr.01-12–01-19 (accel./decel. time) //F curve (Motor 1: Pr.01-01–01-08). Especially the d-point voltage (if the mid-point voltage is set too low, ases at low speed). a larger capacity model. low-speed operation.	
Incorrect parameter setting Mechanical failure (e.g. ov torque, mechanical lock) The load is too large. Accel./Decel. time or the v cycle are too short V/F voltage is too high The motor capacity is too s Overload during low-speed	vorking small d	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for V setting value for the mid the load capacity decre Replace the motor with Reduce the load during Increase the motor cap Adjust the torque comp	Corrective Actions for Pr.06-07 and Pr.06-08 again. malfunction. a larger capacity model. ue for Pr.01-12–01-19 (accel./decel. time) //F curve (Motor 1: Pr.01-01–01-08). Especially the d-point voltage (if the mid-point voltage is set too low, ases at low speed). a larger capacity model. low-speed operation. acity.	
Incorrect parameter setting Mechanical failure (e.g. ov torque, mechanical lock) The load is too large. Accel./Decel. time or the v cycle are too short V/F voltage is too high The motor capacity is too s Overload during low-speed operation.	vorking small d oo large	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for V setting value for the mid the load capacity decre Replace the motor with Reduce the load during Increase the motor cap Adjust the torque comp the output current decre	Corrective Actions for Pr.06-07 and Pr.06-08 again. malfunction. a larger capacity model. ue for Pr.01-12–01-19 (accel./decel. time) //F curve (Motor 1: Pr.01-01–01-08). Especially the d-point voltage (if the mid-point voltage is set too low, ases at low speed). a larger capacity model. low-speed operation. acity. ensation value (Pr.07-26 torque compensation gain) till eases and the motor does not stall.	
Incorrect parameter setting Mechanical failure (e.g. ov torque, mechanical lock) The load is too large. Accel./Decel. time or the v cycle are too short V/F voltage is too high The motor capacity is too s Overload during low-speed operation. Torque compensation is to	vorking small d po large gs for n	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for V setting value for the mid the load capacity decre Replace the motor with Reduce the load during Increase the motor cap Adjust the torque comp the output current decre	Corrective Actions for Pr.06-07 and Pr.06-08 again. malfunction. a larger capacity model. ue for Pr.01-12–01-19 (accel./decel. time) //F curve (Motor 1: Pr.01-01–01-08). Especially the d-point voltage (if the mid-point voltage is set too low, ases at low speed). a larger capacity model. I low-speed operation. acity. ensation value (Pr.07-26 torque compensation gain) till eases and the motor does not stall. settings for speed tracking.	
Incorrect parameter setting Mechanical failure (e.g. ov torque, mechanical lock) The load is too large. Accel./Decel. time or the v cycle are too short V/F voltage is too high The motor capacity is too s Overload during low-speed operation. Torque compensation is too Improper parameter settin	vorking small d oo large gs for n mentary	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for V setting value for the mid the load capacity decre Replace the motor with Reduce the load during Increase the motor cap Adjust the torque comp the output current decre Correct the parameter s Start the speed tracking	Corrective Actions for Pr.06-07 and Pr.06-08 again. malfunction. a larger capacity model. ue for Pr.01-12–01-19 (accel./decel. time) //F curve (Motor 1: Pr.01-01–01-08). Especially the d-point voltage (if the mid-point voltage is set too low, ases at low speed). a larger capacity model. I low-speed operation. acity. ensation value (Pr.07-26 torque compensation gain) till eases and the motor does not stall. settings for speed tracking.	

ID*	Display on LED Keypad	Fa	ult Name	Fault Descriptions
28	υ[Und	ler current (uC)	Low current detection
			Action and	l Reset
	Action level	Pr.06-71		
	Action time	Pr.06-72		
		Pr.06-73		
		0: Norma	al deceleration	
Fau	lt treatment parameter	1: Fault a	and coast to sto	qq
		2: Fault and ramp to stop by the 2nd deceleration time		
		3: Warn and continue operation		
		Wh Auto	When Pr.06-73	3=3, uC is a "Warning". The warning is automatically
	Reset method	Auto	cleared when	the output current > (Pr.06-71+0.1 A).
		Manual When Pr.06-73=1 or 2, uC is a "Fault". You must reset manually.		
	Reset condition	Immedia	tely reset	
	Record	When Pr	.06-71=1 or 2,	uC is a "Fault", and the fault is recorded.
	Cause			Corrective Actions
Motor ca	able disconnection	Troubleshoot the connection between the motor and the load.		ction between the motor and the load.
Imprope	r setting of low-current	Reast Dr.06.71. Dr.06.72 and Dr.06.72 to prepar actings		
protection Reset Pr.06-71, Pr.06-72 and Pr.06-73 to proper settings.				
The less	d is too low	Check the load status.		
		Check if the motor capacity matches the load.		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
31	cf2	EEPROM read error (cF2)	Internal EEPROM cannot be read	
		Action and	l Reset	
	Action level	Firmware internal detec	tion	
	Action time	cF2 acts immediately w	hen the drive detects the fault	
Fault treatment parameter		N/A		
Reset method		Manual reset		
	Reset condition	Immediately reset		
Record		Yes		
Cause			Corrective Actions	
		Press RESET key. If cF2 error still displays on the keypad, return to the factory		
		for repair.		
Internal	EEPROM cannot be read	Reset the parameter to	the default setting. If cF2 fault still displays on the	
		keypad, return to the factory for repair.		
		Cycle the power, if cF2	error still exists, return to the factory for repair.	

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
33	c d	U-phase error (cd1)	U-phase current detection error when power is ON	
		Action and	d Reset	
	Action level	Hardware detection		
	Action time	cd1 acts immediately when the drive detects the fault		
Fault treatment parameter		N/A		
	Reset method	Power-off		
	Reset condition	N/A		
Record		Yes		
Cause		Corrective Actions		
Hardware failure		Cycle the power. If fault code still exists, i	return to the factory for repair.	

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
34	c d 2	V-phase error (cd2)	V-phase current detection error when power ON	
		Action and	d Reset	
	Action level	Hardware detection		
	Action time	cd2 acts immediately when the drive detects the fault		
Fau	Ilt treatment parameter	N/A		
	Reset method	Power-off		
	Reset condition	N/A		
	Record	Yes		
Cause		Corrective Actions		
Hardware failure		Cycle the power. If fault code still exists, return to the factory for repair.		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
35	cd3	W-phase error (cd3)	W-phase current detection error when power ON	
		Action and	d Reset	
	Action level	Hardware detection		
	Action time	cd3 acts immediately when the drive detects the fault		
Fault treatment parameter		N/A		
Reset method		Power-off		
	Reset condition	N/A		
	Record	Yes		
Cause			Corrective Actions	
Hardware failure		Cycle the power. If fault code still exists, i	return to the factory for repair.	

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
36	890 8		cc (current clamp) hardware protection error when power is ON	
		Action and	l Reset	
	Action level	Hardware detection		
	Action time	Hd0 acts immediately when the drive detects the fault		
Fault treatment parameter		N/A		
	Reset method	Power-off		
Reset condition		N/A		
	Record	Yes		
Cause		Corrective Actions		
Hardwa	re failure	Cycle the power.		
laiuwa		If fault code still exists, return to the factory for repair.		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
37	X9 :	oc hardware error (Hd1)	oc hardware protection error when power is ON	
		Action and	d Reset	
	Action level	Hardware detection		
	Action time	Hd1 acts immediately when the drive detects the fault		
Fault treatment parameter		N/A		
	Reset method	Power-off		
Reset condition N		N/A		
Record		Yes		
Cause			Corrective Actions	
Hardwa	re failure	Cycle the power.		
naruwa		If cd1 still exists, return to the factory for repair.		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
49	۶۶	External fault (EF)	External fault. When the drive decelerates based on the setting of Pr.07-20, the EF fault displays on the keypad.	
	I	Action and	d Reset	
	Action level	MIx=EF and the MI tern	ninal is ON	
	Action time	Immediately act		
		Pr.07-20		
		0 (Coast to stop)		
		1: By the first deceleration time		
Eau	Ilt treatment parameter	2: By the second deceleration time		
Гац	in treatment parameter	3: By the third deceleration time		
		4: By the fourth deceleration time		
		5: System deceleration		
		6: Automatic deceleration (Pr.01-46)		
	Reset method	Manual reset		
	Reset condition	Manual reset only after the external fault is cleared (terminal status is recovere		
	Record	Yes		
	Cause	Corrective Actions		
Externa	l fault	Press RESET key after	the fault is cleared.	

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
50	881	Emergency stop (EF1)	When the contact of MI = EF1 is ON, the output stops immediately and displays EF1 on the keypad. The motor is in free running.	
		Action and	l Reset	
	Action level	MIx=EF1 and the MI ter	minal is ON	
Action time		Immediately act		
Fault treatment parameter		N/A		
Reset method		Manual reset		
	Reset condition	Manual reset only after the external fault is cleared (terminal status is recovered)		
Record		Yes		
Cause		Corrective Actions		
When M	IIx=EF1 activates	Verify if the system is back to normal condition, and then press "RESET" key to go back to the default.		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
51	ხხ	External base block (bb)	When the contact of MI = bb is ON, the output stops immediately and displays bb on the keypad. The motor is in free running.	
		Action and	l Reset	
	Action level	MIx=bb and the MI term	inal is ON	
Action time		Immediately act		
Fault treatment parameter		N/A		
	Reset method	The display "bb" is automatically cleared after the fault is cleared.		
	Reset condition	N/A		
Record No				
	Cause	use Corrective Actions		
When MIx=bb activates		Verify if the system is back to normal condition, and then press "RESET" key to go back to the default.		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
52	Pcod	Password is locked (Pcod)	Entering the wrong password three consecutive times	
		Action and	l Reset	
	Action level	Entering the wrong pase	sword three consecutive times	
	Action time	Immediately act		
Fau	ult treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Power-off		
	Record	Yes		
	Cause		Corrective Actions	
		1. Input the correct password after rebooting the motor drive.		
		2. If you forget the password, enter 9999.		
Incorrect password input through		3. Press ENTER, and then enter 9999 again.		
Pr.00-07	7	4. You must finish pressing ENTER within 10 seconds. If not, you must repeat		
		the entering. After you successfully unlock the password, the parameter		
		settings return to the default.		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
54	[5]	Illegal command (CE1)	Communication command is illegal	
		Action and	l Reset	
	Action level	When the function code	is not 03, 06, 10, or 63.	
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	No		
	Cause	Corrective Actions		
	t communication	Check if the communication command is correct.		
Malfunction caused by interference		Verify the grounding and wiring of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
	Different communication setting from the upper unit			
Disconn of the ca	ection or bad connection able	Check the cable and replace it if necessary.		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
55	533	lllegal data address (CE2)	Data address is illegal	
		Action and	l Reset	
	Action level	When the data address	is incorrect.	
	Action time	Immediately act		
Fau	Ilt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	No		
	Cause		Corrective Actions	
Incorrect communication command from the upper unit		Check if the communication command is correct.		
Malfunction caused by interference		Verify the grounding and wiring of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
Different communication setting from the upper unit Check if the setting for Pr.09-02 is the same as			Pr.09-02 is the same as the setting for the upper unit.	
Disconn of the ca	ection or bad connection able	Check the cable and replace it if necessary.		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
56	683	lllegal data value (CE3)	Data value is illegal	
		Action and	l Reset	
	Action level	When the data length is	too long	
	Action time	Immediately act		
Fau	Ilt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	No		
	Cause		Corrective Actions	
	t communication	Check if the communication command is correct.		
Malfunction caused by interference		Verify the grounding and wiring of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
Different communication setting from the upper unit Check if the setting for Pr.09-02 is the same as the setting for the upper			Pr.09-02 is the same as the setting for the upper unit.	
Disconn of the ca	ection or bad connection able	Check the cable and replace it if necessary.		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions		
57	(64	Data is written to read-only address (CE4)	Data is written to read-only address		
	•	Action and Reset			
	Action level	Data is written to read-only address			
	Action time	Immediately act			
Fau	Ilt treatment parameter	N/A			
	Reset method	Manual reset			
	Reset condition	Immediately reset			
	Record	No			
	Cause	Correctiv	e Actions		
	t communication nd from the upper unit	Check if the communication command is correct.			
Malfunction caused by interference		Verify the grounding and wiring of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.			
Different communication setting from the upper unit Check if the setting for Pr.09-02 is the same as the setting for the			ame as the setting for the upper unit.		
Disconn of the ca	ection or bad connection able	Check the cable and replace it if necessary.			

ID*	Display on LED k	Keypad	Fault Name	Fault Descriptions		
58	01 33	î I	Modbus transmission time-out (CE10)	Modbus transmission time-out occurs		
			Action and	l Reset		
	Action level		When the communication communication	on time exceeds the detection time for Pr.09-03 t.		
	Action time		Pr.09-03			
			Pr.09-02			
			0: Warn and continue o	peration		
Fau	It treatment parame	eter	1: Warn and ramp to stop			
			2: Warn and coast to stop			
			3: No Warn and continue operation			
	Reset method		Manual reset			
	Reset condition		Immediately reset			
	Record		Yes			
	Cause		Corrective Actions			
The upper unit does not transmit the communication command within Pr.09-03 setting time.		Check if the upper unit t time for Pr.09-03.	ransmits the communication command within the setting			
Malfunction caused by interference Verify the grounding and wiring of the communication circuit. It is recor- for effective anti-interference performance.		nication circuit from the main circuit, or wire in 90 degree				
Different communication setting from the upper unit		Check if the setting for Pr.09-02 is the same as the setting for the upper unit.				
Disconn of the ca	ection or bad conn able	ection	Check the cable and replace it if necessary.			

15.4		-		
ID*	Display on LED Keypad	Fai	ult Name	Fault Descriptions
				When Pr.07-13 is not 0, and the power is suddenly off,
62	486	Decelei	ration energy	causing the DC bus voltage lower than the dEb action
02	000	backup	o error (dEb)	level, the dEb function acts and the motor ramps to
				stop. Then dEb displays on the keypad.
			Action and	d Reset
	Action level	When Pr.	.07-13 is not 0,	and the DC bus voltage is lower than the level of dEb.
	Action time	Immediat	tely act	
Fau	It treatment parameter	N/A		
			When Pr.07-1	3=2 (dEb with auto-acceleration / auto-deceleration, the
		Auto	drive outputs t	the frequency after the power is restored): dEb is
	Decent weather d	automatically		cleared.
	Reset method		When Pr.07-1	3=1 (dEb, the drive does not output the frequency after
		Manual	the power is re	estored): The drive stops when dEb acts and the rotation
		speed bec		es 0 Hz, then the drive can be reset manually.
	Reset condition	Auto: The fault is automatically cleared.		
	Reset condition	Manual: When the drive decelerates to 0 Hz.		
	Record	Yes		
	Cause	Corrective Actions		
Unstable power source or the				
power is off		Check the power system.		
There is	any other large load	Replace power system with a larger capacity.		
operates in the power system		Use a different power system from the large load system.		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions		
79	Roc		U-phase short circuit detected when the output wiring detection is performed before the drive runs.		
		Action and	l Reset		
	Action level	240% of the rated curre	nt		
	Action time	Immediately act			
Fau	lt treatment parameter	N/A			
	Reset method	Manual reset			
	Reset condition	Reset in five seconds a	fter the fault is cleared		
	Record	Yes			
	Cause	Corrective Actions			
Incorrec	t wiring for the motor	Check if the motor's internal wiring and the UVW wiring of the drive output			
Inconec		terminal are correct.			
Short-ci	rcuit at motor output due to	Check the motor cable a	and remove causes of the short circuits, or replace the		
poor ins	ulation wiring	cable before turning on the power.			
Check for	or possible burnout or	Check the motor insulation value with megger. Replace the motor if the insulation			
aging in	sulation of the motor	is poor.			
Malfunct	tion caused by	Verify the wiring of the control circuit and the wiring/grounding of the main circuit			
interfere	nce	to prevent interference.			
The leng	gth of motor cable is too	Increase the drive capa	city.		
long		Install AC reactor(s) on	the output side (U/V/W).		
		The ocA occurs due to t	he short circuit or ground fault at the output side of the		
		drive.			
Hardwar	re failure	Check for possible short circuits between terminals with the electric meter:			
laiuwal		B1 corresponds to U, V and W; DC- corresponds to U, V and W; $\textcircled{=}$			
		corresponds to U, V and W.			
		If short circuit occurs, return to the factory for repair.			

ID*	Display on LED Keypad	Fault Name	Fault Descriptions		
80	boc	V-phase over-current before run (boc)	V-phase short circuit detected when the output wiring detection is performed before the drive runs.		
		Action and	d Reset		
	Action level	240% of the rated curre	nt		
	Action time	Immediately act			
Fau	lt treatment parameter	N/A			
	Reset method	Manual reset			
	Reset condition	Reset in five seconds a	fter the fault is cleared		
	Record	Yes			
	Cause	Corrective Actions			
Incorrec	t wiring for the motor	Check if the motor's internal wiring and the UVW wiring of the drive output terminal are correct.			
Short-cir	rcuit at motor output due to	Check the motor cable and remove causes of the short circuits, or replace the			
poor ins	ulation wiring	cable before turning on the power.			
Check for	or possible burnout or	Check the motor insulation value with megger. Replace the motor if the insulation			
aging in	sulation of the motor	is poor.			
Malfunct	tion caused by	Verify the wiring of the control circuit and the wiring/grounding of the main circuit			
interfere	nce	to prevent interference.			
The leng	gth of motor cable is too	Increase the drive capacity.			
long		Install AC reactor(s) on	stall AC reactor(s) on the output side (U/V/W).		
		The ocA occurs due to t	the short circuit or ground fault at the output side of the		
		drive.			
Hardwar	re failure	Check for possible short circuits between terminals with the electric meter:			
laiuwai		B1 corresponds to U, V and W; DC- corresponds to U, V and W; 😑 corresponds to U, V and W.			
		If short circuit occurs, return to the factory for repair.			

ID*	Display on LED Keypad	Fault Name	Fault Descriptions		
81	coc	W-phase over-current before run (coc)	W-phase short circuit detected when the output wiring detection is performed before the drive runs.		
		Action and	d Reset		
	Action level	240% of the rated curre	nt		
	Action time	Immediately act			
Fau	lt treatment parameter	N/A			
	Reset method	Manual reset			
	Reset condition	Reset in five seconds at	fter the fault is cleared		
	Record	Yes			
	Cause	Corrective Actions			
Incorrec	t wiring for the motor	Check if the motor's internal wiring and the UVW wiring of the drive output			
	· · · · · · · · · · · · · · · · · · ·	terminal are correct.			
Short-ci	rcuit at motor output due to	Check the motor cable and remove causes of the short circuits, or replace the			
poor ins	ulation wiring	cable before turning on the power.			
Check for	or possible burnout or	Check the motor insulation value with megger. Replace the motor if the insulation			
aging in	sulation of the motor	is poor.			
Malfunct	tion caused by	Verify the wiring of the control circuit and the wiring/grounding of the main circuit			
interfere	ence	to prevent interference.			
The leng	gth of motor cable is too	Increase the drive capa	city.		
long		Install AC reactor(s) on	the output side (U/V/W).		
		The ocA occurs due to t	he short circuit or ground fault at the output side of the		
		drive.			
Hardwar	re failure	Check for possible short circuits between terminals with the electric meter:			
		B1 corresponds to U, V and W; DC- corresponds to U, V and W; $\stackrel{\textcircled{=}}{=}$			
		corresponds to U, V and W.			
		If short circuit occurs, return to the factory for repair.			

ID* Display on LED Keypad	Fault Name	Fault Descriptions	
82 oPL /	Output phase loss U phase (oPL1)	U phase output phase loss	
	Action and	d Reset	
Action level	Pr.06-47		
	Pr.06-46		
Action time	Pr.06-48: Use the settin	g value of Pr.06-48 first. If DC braking function activates,	
	use that of Pr.06-46.		
	Pr.06-45		
	0: Warn and continue o	peration	
Fault treatment parameter	1: Warn and ramp to sto	qq	
	2: Warn and coast to stop		
	3: No warning		
Reset method	Manual reset		
Reset condition	Immediately reset		
Record	Pr.06-45=1 or 2 is "Fault", and the fault is recorded.		
Cause	Corrective Actions		
Unbalanced three-phase impedance of the motor	Replace the motor.		
	Check the cable conditi	on. Replace the cable.	
The motor is wired incorrectly	Check the motor's internal wiring. If the fault still exists, replace the motor.		
Using a single-phase motor	Choose a three-phase motor		
	Check the flat cable of the control board. Re-do the wiring and test again if the		
Check if the surrent concer is	flat cable is loose. If the fault still exists, return to the factory for repair.		
Check if the current sensor is broken.	Check if the three-phase current is balanced with a current clamp meter. If the		
DIOREII.	current is balanced and the oPHL error still shows on the display, return to the		
	factory for repair.		
The drive capacity is much larger	Make sure the capacity of the drive and motor match to each other.		
than the motor capacity			

ID*	Display on LED Keypad	Fault Name	Fault Descriptions		
83	0965	Output phase loss V phase (oPL2)	V phase output phase loss		
		Action and	d Reset		
	Action level	Pr.06-47			
		Pr.06-46			
	Action time	Pr.06-48: Use the settin	g value of Pr.06-48 first. If DC braking function activates,		
		use that of Pr.06-46.			
		Pr.06-45			
		0: Warn and continue o	peration		
Fau	lt treatment parameter	1: Warn and ramp to sto	qq		
		2: Warn and coast to stop			
		3: No warning			
	Reset method	Manual reset			
	Reset condition	Immediately reset			
	Record	Pr.06-45=1 or 2 is "Fault", and the fault is recorded.			
	Cause	Corrective Actions			
Unbalan	ced three-phase	Replace the motor.			
impedar	nce of the motor	Replace the motor.			
The mot	or is wired incorrectly	Check the cable conditi	on. Replace the cable.		
memou		Check the motor's internal wiring. If the fault still exists, replace the motor.			
Using a	single-phase motor	Choose a three-phase r	notor		
		Check the flat cable of t	the control board. Re-do the wiring and test again if the		
Chock if	the current sensor is	flat cable is loose. If the fault still exists, return to the factory for repair.			
broken.		Check if the three-phase current is balanced with a current clamp meter. If the			
		current is balanced and the oPHL error still shows on the display, return to the			
		factory for repair.			
	e capacity is much larger motor capacity	Make sure the capacity of the drive and motor match to each other.			

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
84	oPL3	Output phase loss W phase (oPL3)	W phase output phase loss	
		Action and Reset		
	Action level	Pr.06-47		
		Pr.06-46		
	Action time	Pr.06-48: Use the settin	g value of Pr.06-48 first. If DC braking function activates,	
		use that of Pr.06-46.		
		Pr.06-45		
		0: Warn and continue o	peration	
Fau	lt treatment parameter	1: Warn and ramp to sto	qq	
		2: Warn and coast to stop		
		3: No warning		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Pr.06-45=1 or 2 is "Fault", and the fault is recorded.		
	Cause		Corrective Actions	
Unbalan	iced three-phase	Replace the motor.		
impedar	nce of the motor			
The mot	tor is wired incorrectly	Check the cable condition	on. Replace the cable.	
		Check the motor's internal wiring. If the fault still exists, replace the motor.		
Using a	single-phase motor	Choose a three-phase r	notor	
		Check the flat cable of t	he control board. Re-do the wiring and test again if the	
Check if	the current sensor is	flat cable is loose. If the fault still exists, return to the factory for repair.		
broken.		Check if the three-phase current is balanced with a current clamp meter. If the		
		current is balanced and the oPHL error still shows on the display, return to the		
		factory for repair.		
The driv	e capacity is much larger	Make sure the capacity	of the drive and motor match to each other.	
than the	motor capacity			

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
87	ol 3	87: Low frequency overload protection (oL3)	Low frequency and high current protection	
		Action and	l Reset	
	Action level	Software detection		
	Action time	Immediately act		
Fau	ult treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
Record		Yes		
	Cause	Corrective Actions		
The drive operates at a frequency below 15 Hz, and output current is too large.		 Lower the carrier free Decrease the voltage the V/F curve. Change Pr.00-11 to 	issipation capacity for the cabinet. equency (Pr.00-17). ge settings that correspond to frequency below 15 Hz in general control mode. rith a larger power model.	

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
101	3673	CANopen guarding	CANopen guarding error 1	
		error (CGdE)		
		Action and	d Reset	
		When CANopen Node C	Guarding detects that one of the slaves does not respond,	
	Action level	the CGdE fault occurs.		
		The upper unit sets the	factor and time during configuration.	
	Action time	The time that the upper	unit sets during configuration	
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	The upper unit sends a reset package to clear this fault.		
	Record	Yes		
	Cause	Corrective Actions		
The guarding time is too short, or		Increase the guarding ti	me (Index 100C) and detection times	
less det	ection times	Increase the guarding time (Index 100C) and detection times		
		1. Verify the grounding	g and wiring of the communication circuit. It is	
	<i>e</i> 11	recommended to se	eparate the communication circuit from the main circuit,	
	tion caused by	or wire in 90 degree for effective anti-interference performance.		
interfere		2. Make sure the communication circuit is wired in series.		
		3. Use CANopen cable or add terminating resistance.		
Disconn	ection or bad connection			
of the ca	able	Check the cable and replace it if necessary.		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
102	£ 86	CANopen heartbeat	CANopen heartbeat error 2	
102	L00C	error (CHbE)	CANopen hearbear enor 2	
		Action and	d Reset	
		When CANopen Heartb	eat detects that one of the slaves does not respond, the	
	Action level	CHbE fault occurs.		
	Action level	The upper unit sets the	confirming time of producer and consumer during	
		configuration.		
	Action time	The upper unit sets the	confirming time of producer and consumer during	
	Action time	configuration.		
Fau	lt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	The upper unit sends a reset package to clear this fault.		
	Record	Yes		
	Cause	Corrective Actions		
The hea	rtbeat time is too short	Increase heartbeat time (Index 100C)		
		1. Verify the grounding	g and wiring of the communication circuit. It is	
Molfupot	ion occurred by	recommended to se	eparate the communication circuit from the main circuit,	
	tion caused by	or wire in 90 degree for effective anti-interference performance.		
interfere	nce	2. Make sure the com	munication circuit is wired in series.	
		3. Use CANopen cable or add terminating resistance.		
Disconne	ection or bad connection			
of the ca	ble	Check the cable and replace it if necessary.		

ID*	Display on LED Keypad	Faul	t Name	Fault Descriptions
104	6868	•	bus off error bFE)	CANopen bus off error
			Action and	d Reset
		Hardware	When CANo	pen card is not installed, the CbFn warning occurs.
			When the ma	aster receives wrong communication package, the CbFE
	Action level		fault occurs.	
	Action level	Software	Too much int	terference on BUS
			The master r	receives wrong package when the CAN_H and CAN_L
			communicati	on cables are short, CbFE fault occurs.
	Action time	Immediate	ly act	
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Cycle the power		
	Record	Yes		
	Cause	Corrective Actions		
Check if correct	the CANopen speed is	Reset CAN	Nopen speed	(Pr.09-37)
Malfunction caused by interference1. Verify the grounding and wiring of the communication circuit. It is recommended to separate the communication circuit from the mail or wire in 90 degree for effective anti-interference performance. 2. Make sure the communication circuit is wired in series. 3. Use CANopen cable or add terminating resistance.		eparate the communication circuit from the main circuit, e for effective anti-interference performance. munication circuit is wired in series.		
Disconn of the ca	ection or bad connection able	4. Check	the cable an	d replace it if necessary.

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
105	3633	CANopen index error (CidE)	CANopen index error	
		Action and	l Reset	
	Action level	Software detection		
	Action time	Immediately act		
Fau	Ilt treatment parameter	N/A		
Reset method		Manual reset		
	Reset condition	The upper unit sends a reset package to clear this fault.		
	Record Yes			
Cause		Corrective Actions		
Incorrec index	t setting of CANopen	Reset CANopen Index ((Pr.00-02=7)	

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
106	3683	CANopen station address error (CAdE)	CANopen station address error (only supports 1–127)	
		Action and	d Reset	
	Action level	Software detection		
	Action time	Immediately act		
Fau	ult treatment parameter	N/A		
	Reset method	Manual reset (Pr.00-02=7)		
	Reset condition	N/A		
	Record	Yes		
Cause		Corrective Actions		
Incorrect setting of CANopen station address		 Disable CANopen (Pr.09-36=0) Reset CANopen (Pr.00-02=7) Reset CANopen station address (Pr.09-36) 		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
107	[8-8	CANopen index setting	CANopen memory error	
		exceed limit (CFrE)	· · ·	
		Action and	Reset	
	Action level	When you update the fir	mware version of the control board, the FRAM internal	
	Action level	data does not change, t	hen CFrE fault occurs.	
	Action time	Immediately act		
Fau	Ilt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Pr.00-02=7		
	Record	Pr.00-21=3, the fault is recorded		
Cause Corrective Actions		Corrective Actions		
		1. Disable CANopen (Pr.09-36=0)		
CANope	en internal memory error	2. Reset CANopen (Pr.00-02=7)		
		3. Reset CANopen station address (Pr.09-36)		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
111	īct8	InrCOM time-out error (ictE)	Internal communication time-out	
		Action and	l Reset	
	Action level	Pr.09-31 = -1~ -10 (ther	e is no -9), when the internal communication between	
	Action level	Slave and Master is abr	normal, IctE fault occurs.	
	Action time	Immediately act		
Fau	lt treatment parameter	N/A		
	Reset method	Automatically reset after the internal communication is normal		
	Reset condition	N/A		
	Record	Yes		
	Cause	Corrective Actions		
Molfund	tion caused by	Verify the grounding and wiring of the communication circuit. It is recommended		
interfere	2	to separate the communication circuit from the main circuit, or wire in 90 degree		
Interiere		for effective anti-interference performance.		
Different communication setting		Chock if the setting for I	Pr.09-02 is the same as the setting for the upper unit.	
from the	upper unit			
Disconn	ection or bad connection	Check the cable and re-		
of the ca	able	Check the cable and replace it if necessary.		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
121	6850	Internal communication	Internal communication time-out	
121		error (CP20)		
		Action and	l Reset	
	Action level	Software detection	Software detection	
	Action time	Immediately act		
Fau	Ilt treatment parameter	N/A		
	Reset method	N/A		
	Record	Yes		
	Cause	Corrective Actions		
Internal communication error		Contact local agent or Delta		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
123	5593	Internal communication error (CP22)	Abnormal internal communication	
		Action and	d Reset	
	Action level	Software detection		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	N/A		
	Record	Yes		
	Cause	Corrective Actions		
Internal	communication error	Contact local agent or D	Delta	

ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
124	5693	Internal communication	Internal communication time-out	
124		error (CP30)		
		Action and	l Reset	
	Action level	Software detection		
	Action time	Immediately act		
Fau	Ilt treatment parameter	N/A		
	Reset method	N/A		
Record		Yes		
Cause		Corrective Actions		
Internal communication error		Contact local agent or Delta		


ID*	Display on LED Keypad	Fault Name	Fault Descriptions	
126	5693	Internal communication	Abnormal internal communication	
120		error (CP32)		
		Action and	d Reset	
	Action level	Software detection		
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	N/A		
Record		Yes		
	Cause	Corrective Actions		
Internal communication error		Contact local agent or Delta		

ID*	Display on LED Keypad	Fault Name	Fault Descriptions		
127	CP33		Abnormal internal communication		
		error (CP33)			
		Action and	l Reset		
	Action level	Software detection	Software detection		
	Action time	Immediately act			
Fau	It treatment parameter	N/A			
Reset method		N/A			
Record		Yes			
Cause		Corrective Actions			
Internal communication error		Contact local agent or Delta			

10*	Disulary and ED Kaymond	E suit Nama			
ID*	Display on LED Keypad	Fault Name	Fault Descriptions		
1.1.1	¹⁴¹ 640	Short circuit before run			
141	0,00	(b4oc)	A short circuit is detected before the drive runs		
		Action and	l Reset		
	Action level	240% of the rated curre	nt		
	Action time	Immediately act			
Fau	Ilt treatment parameter	N/A			
	Reset method	N/A			
	Record	Yes			
	Cause	Corrective Actions			
Incorroo	t wiring for the motor	Check if the motor's internal wiring and the UVW wiring of the drive output			
Incorrect wiring for the motor		terminal are correct.			
Short-circuit at motor output due to Check the motor cable and remove causes of the shor			and remove causes of the short circuits, or replace the		
poor insulation wiring		cable before turning on the power.			
The inte	ernal circuit of the drive is	Contact your loool distributor or Dolto			
abnorma	al	Contact your local distributor or Delta.			

Appendix A. Optional Accessories

- A-1 Circuit Breaker
- A-2 Reactors
- A-3 Remote Operation Keypad
- A-4 The Assembly of Fan Kit
- A-5 CANopen Accessories



A-1 Circuit Breaker

The rated current of the breaker shall be 2–4 times of the maximum rated input current of the AC motor drive.

Single-phase			
Model	Suggested current [A]		
VFD002EL21C	10		
VFD004EL21C	15		
VFD007EL21C	20		
VFD015EL21C	30		
VFD022EL21C	50		

Three-phase				
Model Suggested curren				
VFD004EL43C	5			
VFD007EL43C	5			
VFD015EL43C	10			
VFD022EL43C	15			
VFD040EL43C	20			
VFD055EL43C	30			

Fuse Specification Chart (Fuse specifications lower than the table shown below are allowed.)

Model	Input Current (A)	Output Current (A)	Line Fuse		
Model	Input Current (A)	Output Current (A)	I (A)	Bussmann P/N	
VFD002EL21C	4.9	1.6	10	JJN-10	
VFD004EL21C	6.5	2.5	15	JJN-15	
VFD004EL43C	1.8	1.5	5	JJS-6	
VFD007EL21C	9.3	4.2	20	JJN-20	
VFD007EL43C	3.2	2.5	5	JJS-6	
VFD015EL21C	15.7	7.5	30	JJN-30	
VFD015EL43C	4.3	4.2	10	JJS-10	
VFD022EL21C	24.0	11.0	50	JJN-50	
VFD022EL43C	7.1	5.5	15	JJS-15	
VFD040EL43C	10.0	9.0	20	JJS-20	
VFD055EL43C	17.0	13.0	30	JJS-30	

A-2 AC Reactor

A-2-1 AC Reactor

AC Input Reactor

230V, 50 / 60 Hz, Single-phase

kW	HP	Basic Amps	Maximum continuous Amps	Inductance (mH) 3–5% Impedance
0.2	0.25	4	6	6.5
0.4	0.5	5	7.5	3
0.75	1	8	12	1.5
1.5	2	12	18	1.25
2.2	3	18	27	0.8

460V, 50 / 60 Hz, Three-phase

	ЦП	Pasia Amna	Pasia Ampa	Inductance (mH)		
kW	HP	Basic Amps	Maximum continuous Amps	3% Impedance	5% Impedance	
0.4	0.5	2	3	20	32	
0.75	1	4	6	9	12	
1.5	2	4	6	6.5	9	
2.2	3	8	12	5	7.5	
4.0	5.5	8	12	3	5	
5.5	7.5	12	18	2.5	4.2	

AC Output Reactor

230V, 50 / 60 Hz, Three-phase

	kW HP Basic Amps		Maximum continuous Amns	Inductance (mH)		
KVV	ΠP	Basic Amps	Maximum continuous Amps	3% Impedance	5% Impedance	
0.2	0.25	4	6	9	12	
0.4	0.5	4	6	6.5	9	
0.75	1	8	12	3	5	
1.5	2	8	12	1.5	3	
2.2	3	12	18	1.25	2.5	

460V, 50 / 60 Hz, Three-phase

kW	HP	Decis Amno	Maximum continuous Amno	Inductar	ice (mH)
ĸvv		Basic Amps	Maximum continuous Amps	3% Impedance	5% Impedance
0.4	0.5	2	3	20	32
0.75	1	4	6	9	12
1.5	2	4	6	6.5	9
2.2	3	8	12	5	7.5
4.0	5.5	12	18	3	5
5.5	7.5	18	27	1.5	2.5

AC reactor application


Connected in input circuit

Application-1

The same power supply is connected to multiple drives and the drive is running, a certain drive power supply is turned on.

Causes / problems: In the same power system, when the solenoid valve of the drive is turned on, the charging current of the capacitor will cause voltage ripples, and the DC side voltage of other drives will fluctuate too much at the same time.

The correct wiring:




Application-2

The silicon rectifier (such as DC motor drive, etc.) and the drive are both connected to the same power supply.

Causes / problems: Since the silicon rectifier is a switching element, there will be a surge at the moment

of ON/OFF, which may cause damage to the main circuit protection action.

The correct wiring:




Application-3

When the power supply capacity is greater 10 times of the capacity of the dual-frequency device.

Causes / problems: When the power supply capacity is large, the charging current is too large due to the small power supply impedance, which may easily cause high temperature or damage to the commutator of the main circuit.


The correct wiring:



A-2-2 Zero phase reactor

RF220X00A


UNIT: mm [inch]



Cable trimeNote	Recommended Wire Size (mm ²)			Otv	Wiring	
Cable type ^{Note}	*AWG	mm²	Nominal (mm²)	Qty.	Method	
Single-core	≤10	≤5.3	≤5.5	1	Figure A	
Single-core	≤2	≤33.6	≤38	4	Figure B	
Three-core	≤12	≤3.3	≤3.5	1	Figure A	
Thee-cole	≤1	≤42.4	≤50	4	Figure B	

Figure A

Each line needs four turns when passing through the zero-phase reactor. This reactor should be as close as possible to the drive.




NOTE:

600V insulated power lines.

- The above table is for reference only, please use the appropriate cable type and diameter; in short, the cable must be suitable for passing through the center of the zero-phase reactor.
- 2. Do not pass through the ground cable when wiring, only pass through the motor cable or power cable.
- 3. When using a long motor output cable, it may be necessary to use a zero-phase reactor to reduce radiation.

Figure B Please pass the cables through the four parallel zero-phase reactors directly.



A-3 Remote Operation Keypad

A-3-1 VFD-PU08V Keypad

Main display area Frequency, current, voltage, user- define, fault code, etc. display Status display area Indicate frequency status: run, stop, forward, reverse, enable / disable the frequency setting knob. Direction function key (Up) Adjust the parameters or the values Run Start VFD operation	RUN A BOVR: REV RUN A BOVR: REV RUN A MODE RESET	ModeTo change the different modeselection step by stepEnter1. To enter the settings page2. To confirm the parametersettingDirection function key(Down & left)Adjust the parameters or thevalues / Long press MODEbutton to switch between down
Stop/Reset Stop or reset VFD		or left button Frequency setting knob Input the main frequency

A-3-2 VFD-PU08V status, key and digital dial function

1. Status Descriptions

Status displayed	Note	
RUNI FWD REV	RUN: VFD is running	
	FWD: VFD is running forwardly	
	REV: VFD is running reversely	
	STOP: VFD is stopped	
	STOP Flashing: VFD is stopping	
	VR light on: VFD potentiometer function is enabled	
	VR light off: Up and Down direction function is enabled	

2. Keypad Function Descriptions

The following VFD-PU08V keys support mode switching, and the operation of other keys is the same as that of the drive

MODE	Mode switch	Press MODE botton for 2 seconds, when "X" flashing, , the direction function key " < " is enabled and the direction function key "▼ " is disabled. When the direction function key " < " is enabled, long press MODE botton again, the "X" stop flashing and the direction function key "▼ " is enabled.
<	Decrease / Shift	decrease the value, shift the set value and parameter and the digits of the value setting moving

- 3. Variable Resistor (VR)
 - (1) 3. Variable Resistor function
 - A. When the function is enabled, •VR O is always on, and the drive running frequency command F can be adjusted.

Appendix A. Optional Accessories | EL-C

- B. If the power is turned off and on again, the default function is enabled
- (2) Function enable

When the power supply of VFD-PU08V is normal, and the drive matches the communication protocol and model setting of VFD-PU08V, the preset will affect.

- (3) Function switch
 - A. When •VR vice is always on, press the MODE + ENTER compound key to switch to the up

key \blacktriangle and <SHIFT> / down key \checkmark to adjust the drive frequency command, and

•VR ② will be off at the same time.

- B. If you press the MODE+ENTER composite key again when •VR ◎ is off, it will switch back to the state where the frequency is adjusted by the variable resistor and •VR ◎ light up.
- C. •VR ◎ is off, the frequency is adjusted by the up and down keys, and will not be maintained when the power is off. When the VFD-PU08 is powered on again, it is still adjusted by the variable resistor and •VR ◎ lights up.


A-3-3 Extension cable and interface definition for connecting to the drive

VFD-PU08V does not include extension cables, users need to choose extension cables according to their needs.

Figure	PIN	PU08V pin function
	1	NC
8 ←1	2	NC
	3	DGND
	4	SG-
L (((((()	5	SG+
	6	NC
RS-485	7	NC
	8	Vcc

Note: NC stands for Not Connect

A-3-4 VFD-PU08V Dimensions



A-4 The Assembly of Fan Kit

After the VFD007EL21C is installed with a cooling fan, the upper limit of the ambient operating temperature is increased to 50°C without derating. If the fan is not installed, the upper limit of the ambient operating temperature is 40°C without derating.

The power supply of the fan is 24V which can be powered from the drive control terminal +24V / DCM. After using the fan, only MI terminal can be normal used, other loads are not allowed to be connected to prevent the +24V terminal from being overloaded and causing damage to the drive.

Models	Applicable model	Fan Kit
KEL-AFKM1	VFD007EL21C	

Note: The length of the fan cable is about 150mm.

Fan installation

Step		Figure	
1.	As shown in the figure on the right, according to the direction of the arrow, remove the front cover first.		
2.	Place the fan according to the diagram on the right to makes the arrow on the fan points to the heat sink, and assemble the fan net and fan on the heat sink with screws. Positive electrode of the fan: connect the red cable to the +24V terminal. Negative electrode of the fan: connect the black cable to the DCM terminal.		
3.	Reinstall the front cover, and the fan installation is complete.		

A-5 CANopen Acessories

A-5-1 CANopen junction box

Model	Description	
TAP-CN01	1 point 2, built-in 121Ω terminal resistance	
TAP-CN02	1 point 4, built-in 121Ω terminal resistance	
TAP-CN03	1 point 4, RJ45 connector, built-in 121Ω terminal resistance	
	Unit: mm [inch]	





 FAP-CN03

 Image: Constraint of the state of t

A-5-2 TAP-TR01 terminal resistor



A-5-3 Standard extension cable



No	Models	L	
		mm	inch
1	UC-CMC003-01A	300	11.8
2	UC-CMC005-01A	500	19.6
3	UC-CMC010-01A	1000	39.0
4	UC-CMC015-01A	1500	59.0
5	UC-CMC020-01A	2000	78.7
6	UC-CMC030-01A	3000	118.1
7	UC-CMC050-01A	5000	196.8

[This page is intentionally left blank]